
INSTRUCTION BOOK

TERMALINE® LOAD RESISTOR SERIES 8860

COVERING MODELS:

8860

8861

8862

8863

8864

8862D

8862D13-30

8864D

BIRD®
Electronic Corporation
Cleveland (Solon) Ohio USA

©Copyright 2003 by Bird Electronic Corporation
Instruction Book Part Number 920-8860S Rev. C

Termaline® and Tenuline® are Registered Trademarks
of Bird Electronic Corporation

Safety Precautions

The following are general safety precautions that are not necessarily related to any specific part or procedure and do not necessarily appear elsewhere in this publication. These precautions must be thoroughly understood and apply to all phases of operation and maintenance.

Keep Away From Live Circuits

Operating personnel must at all times observe normal safety regulations. Do not replace components or make adjustments inside the equipment with high voltage turned on. To avoid casualties, always remove power.

Shock Hazard

Do not attempt to remove the RF transmission line while RF power is present.

Do Not Service or Adjust Alone

Under no circumstances should any person reach into an enclosure for the purpose of service or adjustment of equipment except in the presence of someone who is capable of rendering aid.

Safety Earth Ground

An uninterruptible earth safety ground must be supplied from the main power source to test instruments. Grounding one conductor of a two conductor power cable is not sufficient protection. Serious injury or death can occur if this grounding is not properly supplied.

Chemical Hazard

Dry cleaning solvents for cleaning parts may be potentially dangerous. Avoid inhalation of fumes or prolonged contact with skin.

Resuscitation

Personnel working with or near high voltages should be familiar with modern methods of resuscitation.

Safety Symbols

WARNING

Warning notes call attention to a procedure which, if not correctly performed, could result in personal injury.

CAUTION

Caution notes call attention to a procedure which, if not correctly performed, could result in damage to the instrument.



This symbol indicates that a shock hazard exists if the precautions in the instruction manual are not followed.



The caution symbol appears on the equipment indicating there is important information in the instruction manual regarding that particular area.



This symbol indicates that the unit radiates heat and should not be touched while hot.

 NOTE: Calls attention to supplemental information.

Warning Statements

The following safety warnings appear in the text where there is danger to operating and maintenance personnel and are repeated here for emphasis.

WARNING

The vent plug must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

WARNING

Oil is slippery. If a leak occurs, be careful not to fall.

Caution Statements

The following equipment cautions appear in the text whenever the equipment is in danger of damage and are repeated here for emphasis.

CAUTION

This load is designed for operation in a horizontal position only, with the vent plug up. Do not use in any other manner.

CAUTION

If installed, connect optional interlock before applying RF power.

CAUTION

Use only Bird coolant, P/N 5-1070, to prevent damage to the load.

Safety Statements



USAGE

ANY USE OF THIS INSTRUMENT IN A MANNER NOT SPECIFIED BY THE MANUFACTURER MAY IMPAIR THE INSTRUMENT'S SAFETY PROTECTION.

USO

EL USO DE ESTE INSTRUMENTO DE MANERA NO ESPECIFICADA POR EL FABRICANTE, PUEDE ANULAR LA PROTECCIÓN DE SEGURIDAD DEL INSTRUMENTO.

BENUTZUNG

WIRD DAS GERÄT AUF ANDERE WEISE VERWENDET ALS VOM HERSTELLER BESCHRIEBEN, KANN DIE GERÄTESICHERHEIT BEEINTRÄCHTIGT WERDEN.

UTILISATION

TOUTE UTILISATION DE CET INSTRUMENT QUI N'EST PAS EXPLICITEMENT PRÉVUE PAR LE FABRICANT PEUT ENDOMMAGER LE DISPOSITIF DE PROTECTION DE L'INSTRUMENT.

IMPIEGO

QUALORA QUESTO STRUMENTO VENISSE UTILIZZATO IN MODO DIVERSO DA COME SPECIFICATO DAL PRODUTTORE LA PROZIONE DI SICUREZZA POTREBBE VENIRNE COMPROMESSA.



SERVICE

SERVICING INSTRUCTIONS ARE FOR USE BY SERVICE - TRAINED PERSONNEL ONLY. TO AVOID DANGEROUS ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING UNLESS QUALIFIED TO DO SO.

SERVICIO

LAS INSTRUCCIONES DE SERVICIO SON PARA USO EXCLUSIVO DEL PERSONAL DE SERVICIO CAPACITADO. PARA EVITAR EL PELIGRO DE DESCARGAS ELÉCTRICAS, NO REALICE NINGÚN SERVICIO A MENOS QUE ESTÉ CAPACITADO PARA HACERLO.

WARTUNG

ANWEISUNGEN FÜR DIE WARTUNG DES GERÄTES GELTEN NUR FÜR GESCHULTES FACHPERSONAL.

ZUR VERMEIDUNG GEFÄHRLICHER, ELEKTRISCHER SCHOCKS, SIND WARTUNGSARBEITEN AUSSCHLIEßLICH VON QUALIFIZIERTEM SERVICEPERSONAL DURCHZUFÜHREN.

ENTRETIEN

L'EMPLOI DES INSTRUCTIONS D'ENTRETIEN DOIT ÊTRE RÉSERVÉ AU PERSONNEL FORMÉ AUX OPÉRATIONS D'ENTRETIEN. POUR PRÉVENIR UN CHOC ÉLECTRIQUE DANGEREUX, NE PAS EFFECTUER D'ENTRETIEN SI L'ON N'A PAS ÉTÉ QUALIFIÉ POUR CE FAIRE.

ASSISTENZA TECNICA

LE ISTRUZIONI RELATIVE ALL'ASSISTENZA SONO PREVISTE ESCLUSIVAMENTE PER IL PERSONALE OPPORTUNAMENTE ADDESTRATO. PER EVITARE PERICOLOSE SCOSSE ELETTRICHE NON EFFETTUARE ALCUNA RIPARAZIONE A MENO CHE QUALIFICATI A FARLA.



CONNECT INTERLOCK TO TRANSMITTER/GENERATOR/AMPLIFIER BEFORE OPERATING.

BRANCHER LE VERROUILLAGE À L'ÉMETTEUR/GÉNÉRATEUR/AMPLIFICATEUR AVANT EMPLOI.

CONECTE EL INTERBLOQUEO AL TRANSMISOR/GENERADOR/AMPLIFICADOR ANTES DE LA OPERACION.

VOR INBETRIEBNAHME VERRIEGELUNG AM SENDER/GENERATOR/VERSTÄRKER ANSCHLIESSEN.

PRIMA DI METTERE IN FUNZIONE L'APPARECCHIO, COLLEGARE IL DISPOSITIVO DI BLOCCO AL TRASMETTITORE/GENERATORE/AMPLIFICATORE.

About This Manual

This instruction book is arranged so that essential information on safety is in the front of the book. Reading the Safety Precautions before operating the equipment is strongly advised. The remainder of this instruction book is divided into Chapters and Sections.

Operation

First time operators should read Chapter 1 – Introduction, and Chapter 3 – Installation, to get an overview of equipment capabilities and how to install it. An experienced operator can refer to Chapter 4 – Operating Instructions. All instructions necessary to operate the equipment, are contained in this section.

Maintenance

All personnel should be familiar with preventative maintenance found in Chapter 5 – Maintenance. If a failure should occur, the trouble-shooting section will aid in isolating and repairing the failure. Parts lists and repair instructions are also in this chapter.

Changes

We have made every effort to ensure this manual is accurate at the time of publication. If you should discover any errors or if you have suggestions for improving this manual, please send your comment to our factory. This manual may be periodically updated. When inquiring about updates to this manual, refer to the part number and revision level on the title page.

Table of Contents

Safety Precautions	i
About This Manual	v
Introduction	1
Items Supplied	1
Items Required but not Supplied	1
Optional Accessories	1
Theory of Operation.	3
Load Resistor	3
Coolant	3
Thermal Interlock	3
Installation.	5
Unpacking and Inspection	5
Mounting	5
Setup	5
Thermoswitch	6
Interlock Connection	7
Connecting RF Power	8
Operating Instructions	11
Normal Operation	11
Operation Under Abnormal Conditions	11
Shutdown	11
Emergency Shutdown	11
Maintenance.	13
Troubleshooting	13
Maintenance	14
Cleaning	14
Inspection	14
DC Resistance	14
Coolant Level	15

Repair	16
RF Connector	16
Load Resistor	16
Storage and Shipment	17
Customer Service	17
Specifications	18
Replacement Parts	19
Available “QC” Type Connectors	19

Bird 8860 Series Loads are portable 50 ohm coaxial RF transmission line terminations, designed for frequency ranges of dc – 2000 MHz. Bird 8860D Series Loads are identical, except that they are designed for the UHF (470 – 860 MHz) band. They provide accurate, dependable, and low reflection line terminations. Up to 1500 watts of RF power can be dissipated.

The load has a coolant chamber surrounded by radiator fins. The front and rear fins form mounting flanges which can be used as supports for freestanding use or as brackets for fixed mounting. A vent plug at the top of the unit relieves internal pressure from coolant expansion. The load's simple and rugged design minimizes maintenance requirements.

Items Supplied

- Load Resistor: Pre-filled with coolant at the factory
- Shipping Plug
- Vent Plug
- Instruction Manual


**Items Required but
not Supplied**

- Coupling Kit: Connects the load to the RF line

**Optional
Accessories**

- Interlock Thermoswitch: Automatically shuts off the transmitter to prevent overheating of the load

Figure 1
Bird 8860 Series
Outline Drawing



Load Resistor Bird 8860 Loads consist of a thin-film-on-ceramic resistor immersed in a dielectric coolant. The resistor, individually selected for its accuracy, is enclosed in a special housing. When surrounded by the coolant, this produces a uniform, practically reflectionless line termination over the specified frequencies.

Coolant The load is cooled by natural fluid and air convection currents. The coolant, chosen for its dielectric and thermal characteristics, carries heat from the resistor to the walls of the cooling tank, where radiator fins surrounding the tank transfer the heat to the air.

When the coolant is heated, thermal expansion causes an increase in the internal pressure. The vent plug relieves this pressure while protecting the opening from dirt or other contaminants.

Thermal Interlock Loads can be supplied with an optional passive overtemperature thermoswitch. Normally closed, it opens at the maximum safe load temperature of 236 °C (457 °F), turning off transmitter power. The interlock system will not permit reoperation of the transmitter until the load has reached a lower, safe temperature.

Figure 2
Shipping Plug





Figure 3
Vent Plug



This chapter provides information for on-site requirements, unpacking, inspection, and preparing the load for use.

Unpacking and Inspection

1. Carefully inspect the shipping container for signs of damage. If damage is noticed, do not unpack the unit. Immediately notify the shipping carrier and Bird Electronic Corporation.
2. If the container is not damaged, unpack the unit. Save the packing materials in case the unit needs to be shipped again.
3. Inspect all of the components for visible signs of damage. Immediately notify the shipping carrier and Bird Electronic Corporation of equipment damage or missing parts.

Mounting

Place the load in a dry, dust and vibration free environment. Do not use outdoors or in areas of condensing humidity. Allow at least 12" (30 cm) of clearance on all sides of the load.

CAUTION

This load is designed for operation in a horizontal position only, with the vent plug up. Do not use in any other manner.

These loads are equipped for either portable use or fixed installation. The mounting brackets on the front and rear faces have four mounting slots arranged in a $4\frac{1}{2}" \times 14\frac{7}{32}"$ rectangle (114.3 x 361.2 mm). Use a screw with a $\frac{3}{8}"$ (9.53 mm) diameter max.

Setup

WARNING

The vent plug must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

- Before first using the load, get a resistance baseline for future maintenance. Refer to "DC Resistance" on page 14 for details.
- Remove the shipping plug from the load and replace it with the vent plug. Refer to Figure 2 and Figure 3 for pictures of the plugs.

Thermoswitch Bird 8860 series loads can be equipped with an optional interlock thermoswitch, P/N 8890-008. It is normally closed, opening at 236 °C (457 °F), with a rating of 10A @ 120Vac and 5A @ 230Vac.

WARNING

The vent plug must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

To install or replace the thermoswitch:

1. Remove the vent plug and install the shipping plug.
2. Stand the unit on its front, supporting it so that the connector is not damaged. In this position there is no danger of the coolant pouring out through the socket plug hole.
3. Remove the socket plug just above the connector assembly, using a $\frac{9}{16}$ " hex wrench.
4. Replace the plug with the thermoswitch. Sparingly apply pipe sealing compound to the external threads, only, of the thermoswitch. Do not contaminate the coolant with pipe sealant.
5. Check for coolant leaks upon completion.
6. Remove the shipping plug and install the vent plug.

**Interlock
Connection**


Connect the thermoswitch to the interlock as follows (see Figure 4):

CAUTION

If installed, connect optional interlock before applying RF power.

1. Unscrew the large knurled ring-nut (A) at the lower end of the coupling jack assembly. Pull it off the thermoswitch jack (B). Unscrew the small knurled cover fitting from the base plug (D) of the connector to release the base.
 2. Thread the control switch wires through the clamp (E) with the washers (F) inside and with its threaded fitting in place. Service the control switch wire with short tips and put spaghetti sleeves over the wire ends if necessary.
 3. Securely solder the control switch leads to the lugs (G) of the connector base.
- ⓘ NOTE: The ring-nut (A) must be in place over the base plug (D) with the knurled end facing out.
4. Screw on the cover ring, then fasten the cable clamp (E) in place and tighten both yoke screws (H).
 5. Put the plug back on the thermoswitch and tighten the nut (A).

*Figure 4
Thermoswitch
Assembly*



Connecting RF Power

After installing the load, the RF transmission line can be attached using standard coaxial line coupling kits.

WARNING


Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

“QC” Connector Coupling: Use 50 ohm coaxial cable such as RG-218/U or -220/U (-17A or -19A), appropriate for the frequency and power level of operation. Use a cable connector which will mate with the one on the load.

13-30 Coupling: Use 50 ohm coaxial cable such as RG-8A/U, RG-9U, RG-213/U, or equivalent with a male 13-30 plug.

Swivel Flanged Coupling: To couple the swivel flange with a flanged RF transmission line, use an appropriate coupling kit. Refer to Figure 5 while following the instructions below:


*Figure 5
Swivel Flanged
Coupling*



- Insert the center bullet and push it in until it is fully seated.
 - Connect the coaxial input in a straight line and push carefully on the center conductor to close.
- ⓘ NOTE: The swivel flange on the load makes connection independent of the orientation of the fixed flange on the coaxial input outer conductor.
- Insert the bolt sets and tighten evenly all around to transmission line manufacturer's recommended torque. Use all of the bolts.

Unflanged Coupling: To couple the unflanged connector with an unflanged RF line, use an appropriate coupling kit. Refer to Figure 6 while following the instructions below:

Figure 6
Unflanged
Coupling



- Insert the center bullet and bottom it on the midpoint nibs.
- Position the outer sleeve, with clamping bands, over the input connector.
- Set the transmission line snugly against the coupling stops.
- Position the clamping bands evenly about 3/4" from the ends of the sleeve.
- Tighten the clamping bands.

Normal Operation Bird 8860 series Loads have no indicators or operating controls. They require no special operating procedures or surveillance when their performance limits are not exceeded. Follow the instructions for the specific transmitter equipment.

Operation Under Abnormal Conditions The load can be subjected to moderate overloads for short periods. If this is likely, make sure the interlock is properly connected to prevent damage to the load.

Shutdown These loads are passive devices, so have no way of being turned off. Turn off RF power at the source.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

Emergency Shutdown Turn off RF power at the source.

If the interlock thermoswitch is properly connected, RF power will be automatically turned off when the coolant temperature reaches an unsafe level.

This chapter covers cleaning, inspection, trouble-shooting, and specifications for the Bird 8860 series loads.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

WARNING

Oil is slippery. If a leak occurs, be careful not to fall.

Troubleshooting

The table below contains troubleshooting information for problems which can occur during normal operation. This manual cannot list all malfunctions that may occur, or their corrective actions. If a problem is not listed or is not corrected by the listed actions, notify a qualified service center.

PROBLEM	POSSIBLE CAUSE	CORRECTION
Leaking coolant	Loose clamping band	Tighten the clamping band
	Defective or improperly installed O-ring	Replace the O-ring (See “Load Resistor” on page 16)
High or low dc resistance	Loose RF connector	Tighten connector
	Faulty RF input connector	Model 8860: Replace connector (See “RF Connector” on page 16) All other models: Return the unit for service
	Faulty resistor	Replace the resistor (See “Load Resistor” on page 16)

PROBLEM	POSSIBLE CAUSE	CORRECTION
Overheating radiator	RF power too high	Lower RF power
	Coolant level too low	Check the coolant level. Add coolant if necessary (See “Coolant Level” on page 15)
	Coolant degraded	Replace the coolant (See “Coolant Level” on page 15)
	Faulty resistor	Replace the resistor (See “Load Resistor” on page 16)

Maintenance

Cleaning The outside surface of the instrument should be wiped free of dust and dirt when necessary. Excessive dust on the cooling fins will interfere with heat dissipation. Clean the RF connector, both metallic and insulating surfaces, with a dry, non-residue forming solvent.

WARNING


Oil is slippery. If a leak occurs, be careful not to fall.

Inspection Inspect the unit every six months. Check for coolant leakage around the clamping band and the thermoswitch. Also check for corrosion.

DC Resistance Measuring the dc resistance between the inner and outer conductors of the RF connector shows changes in the load over time, a good check of the load resistor's condition. Under normal operating conditions, the resistor should provide at least 5,000 hours of operation before requiring any additional service. DC resistance tracking must start before the load is put into service, and should be measured annually.

Perform the following steps and record the value for future comparison. Make sure that you have an ohmmeter with an accuracy of $\pm 1\%$ at 50 ohms and that the load temperature is between 20 and 25 °C (68 to 77 °F) before starting.

*Figure 7
Measuring
Resistance*



WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

1. Turn off the RF power and interlock circuitry.
2. Disconnect the RF line.
3. Connect the multimeter test leads to the center and outer conductor of the load resistor. Refer to Figure 7.
4. Compare the measured value with the previous measurement and with the baseline resistance, measured when the load was put into service. If the new value differs from either of these by more than 2 ohms this could indicate a failing resistor.

Coolant Level

Coolant lifetime will vary greatly depending on the operating temperature. For heavy use (full RF power for long times, high ambient temperature), check the coolant every 500 hours. If the load has only had light duty (fraction of full power, low temperature), then inspection may only be necessary every 2,000 hours.

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

WARNING

Oil is slippery. If a leak occurs, be careful not to fall.

CAUTION

Use only Bird coolant, P/N 5-1070, to prevent damage to the load.

To inspect the coolant:

🔧 **NOTE:** Correct any coolant leakage before inspection. (See “Troubleshooting” on page 11)

- Remove the load resistor (Refer to “Load Resistor” on page 18).
- The coolant should be clear, with a faint yellow tinge, and have a slightly sweet smell. If it is black with a burnt or acrid smell, drain it and add about 1.5 gal (5.7 L) of coolant.
- With the load still on end, the coolant level should be $3\frac{5}{8}$ " (92 mm) below the top surface of the resistor assembly mounting ring, at ambient temperature. Add coolant if necessary.

Repair

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

RF Connector

The Model 8860, *only*, has a special Bird “QC” connector which allows easy changing of the RF connector. This does not disturb the coolant seal or affect the electrical continuity of the load. To change the connector, proceed as follows:

- Remove the four screws at the corners of the RF connector.
- Pull the connector straight out.
- Push the new connector in. Make sure that the center pin on the connector is properly seated in the mating socket on the load.
- Replace the screws.

☞ NOTE: If not using the connector normally supplied, frequency and power must be limited to the capabilities of the connector.

Load Resistor

To change the load resistor assembly:

WARNING

Oil is slippery. If a leak occurs, be careful not to fall.

1. Remove the vent plug and install the shipping plug.
2. Supporting the unit to prevent damage to the interlock, stand it on its back with the connector end up. In this position there is no danger of the coolant pouring out through the resistor hole.
3. Unscrew and remove the clamping band.
4. Lift the load resistor assembly out of the tank and allow any coolant to drip back into the tank.
5. The O-Ring should be free of twists and positioned evenly around the flange of the resistor housing. If it shows signs of deterioration (e.g. is no longer pliable or has surface cracks) replace it.
6. Replace the entire load resistor assembly. It cannot be further disassembled.
7. Put the clamping band in place and tighten it.
8. Remove the shipping plug and install the vent plug.

Storage and Shipment

Cover the load before storing to keep out dust and dirt. It is not necessary to install the shipping plug. Store in a dry, dust-free environment where the ambient temperature will remain between -40 and $+45^{\circ}\text{C}$ (-40 to $+113^{\circ}\text{F}$).

To ship the load, take the following precautions:

- Remove the vent plug and replace it with the shipping plug. Wrap the vent plug with padding and tape it to the side of the load for protection.

☞ NOTE: With the shipping plug installed, it is not necessary to empty out the coolant.

- Wrap the connector in padding.
- Pack and brace the load in a sturdy wooden crate for shipment.

Customer Service

Any maintenance procedure beyond the scope of those provided in this chapter should be referred to a qualified service center.

If you need to return the unit for any reason, contact the Bird Service Center for a return authorization. All instruments returned must be shipped prepaid and to the attention of Bird Service Center.

Bird Service Center

30303 Aurora Road
Cleveland (Solon), OH 44139-2794
Phone: (440) 519-2298
Fax: (440) 519-2326
E-mail: *bsc@bird-technologies.com*

For the location of the Sales Office nearest you, give us a call or visit our Web site at:

<http://www.bird-electronic.com>

Specifications

Frequency Range	
8862D, 8862D13-30, 8864D	470 – 860 MHz
All other models	dc – 2000 MHz
Power Rating	1500 W continuous duty
Impedance, Nominal	50 ohms
VSWR	
8862D, 8862D13-30, 8864D	1.065
All other models	dc – 1 GHz: 1.1 1 – 2 GHz: 1.25
Connectors	
8860	Female LC
8861	1-5/8" unflanged
8862, 8862D	1-5/8" EIA flanged
8862D13-30	Female 13-30
8863	3-1/8" unflanged
8864, 8864D	3-1/8" EIA flanged
Interlock Thermoswitch	Normally closed. Opens at 236°C (457°F)
Thermoswitch Rating	
115 Vac	10 A
230 Vac	5 A
Ambient Temperature	–40 to +45 °C (–40 to +113 °F)
Altitude*	1520 m (5000 ft.)
Humidity	95% noncondensing max
Cooling method	Oil dielectric and convection currents
Dimensions	17.5" L x 7.5" W x 13 ¹ / ₈ " H (445 x 190 x 334 mm)
Weight, Nominal	27.8 lb. (12.6 kg)
Finish	Grey Powder Coat

* Derate RF power by 250 W for every 305m (1,000 ft.) above 1,520m (5,000 ft.)

Replacement Parts

DESCRIPTION	QTY	PART NUMBER
RF Load Resistor	1	
8860		8890-050
8861		8895-015
8862, 8862D		8892-015
8862D13-30		8862-017
8863		8897-003
8864		8891-050
8864D		8891-071
Resistor O-Ring	1	5-230
Clamping Band Assembly	1	2430-055
Plug	1	
Vent		2450-094
Shipping		2450-049
Overtemp Thermoswitch	1	8890-008
Coolant, 1.5 gal (5.7 liter)	1	5-1070-3
Radiator Assembly	1	8860-002
Access Plug 3/4"-14 Hex Socket	1	5020-103

Available “QC” Type Connectors

Connector	Part Number	Connector	Part Number	Connector	Part Number
BNC-Female	4240-125	LT-Female	4240-018	Mini UHF-Female	4240-346
BNC-Male	4240-132	LT-Male	4240-012	UHF-Female	4240-050
C-Female	4240-100	N-Female	4240-062	UHF-Male	4240-179
C-Male	4240-110	N-Male	4240-063	1-5/8" EIA Fixed	4240-096
HN-Female	4240-268	SC-Female	4240-090	1-5/8" EIA Swivel	4240-208
HN-Male	4240-278	SMA-Female	4240-336	7/8" EIA	4240-002
LC-Female*	4240-031	SMA-Male	4240-334	TNC-Female	4240-156
LC-Male	4240-025	7/16 Jack, IEC Type 169-4	4240-344	TNC-Male	4240-160
Open Term. # 10-32 Nut	4240-080	7/16 Plug, IEC Type 169-4	4240-363		

* Normally supplied on the 8860

Limited Warranty

All products manufactured by Seller are warranted to be free from defects in material and workmanship for a period of one (1) year, unless otherwise specified, from date of shipment and to conform to applicable specifications, drawings, blueprints and/or samples. Seller's sole obligation under these warranties shall be to issue credit, repair or replace any item or part thereof which is proved to be other than as warranted; no allowance shall be made for any labor charges of Buyer for replacement of parts, adjustment or repairs, or any other work, unless such charges are authorized in advance by Seller.

If Seller's products are claimed to be defective in material or workmanship or not to conform to specifications, drawings, blueprints and/or samples, Seller shall, upon prompt notice thereof, either examine the products where they are located or issue shipping instructions for return to Seller (transportation-charges prepaid by Buyer). In the event any of our products are proved to be other than as warranted, transportation costs (cheapest way) to and from Seller's plant, will be borne by Seller and reimbursement or credit will be made for amounts so expended by Buyer. Every such claim for breach of these warranties shall be deemed to be waived by Buyer unless made in writing within ten (10) days from the date of discovery of the defect.

The above warranties shall not extend to any products or parts thereof which have been subjected to any misuse or neglect, damaged by accident, rendered defective by reason of improper installation or by the performance of repairs or alterations outside of our plant, and shall not apply to any goods or parts thereof furnished by Buyer or acquired from others at Buyer's request and/or to Buyer's specifications. Routine (regularly required) calibration is not covered under this limited warranty. In addition, Seller's warranties do not extend to the failure of tubes, transistors, fuses and batteries, or to other equipment and parts manufactured by others except to the extent of the original manufacturer's warranty to Seller.

The obligations under the foregoing warranties are limited to the precise terms thereof. These warranties provide exclusive remedies, expressly in lieu of all other remedies including claims for special or consequential damages. SELLER NEITHER MAKES NOR ASSUMES ANY OTHER WARRANTY WHATSOEVER, WHETHER EXPRESS, STATUTORY, OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, AND NO PERSON IS AUTHORIZED TO ASSUME FOR SELLER ANY OBLIGATION OR LIABILITY NOT STRICTLY IN ACCORDANCE WITH THE FOREGOING.

DECLARATION OF CONFORMITY

Manufacturer: Bird Electronic Corporation
30303 Aurora Road
Cleveland, Ohio 44139-2794

Product: Termaline Load Resistor

Models: 8860 8861 8862 8863 8864
8862D 8862D13-30

The undersigned hereby declares, on behalf of Bird Electronic Corporation of Cleveland, Ohio, that the above-referenced products, to which this declaration relates, are in conformance with the provisions of the following standards.

- European Standard EN 61326-1:1997 - Electronic Equipment for Measurement, Control and Laboratory Use - EMC Requirements
- European Standard EN 55011:1998 - Emissions
- European Standard EN 61000-4-2:1995 - ESD Immunity
- European Standard EN 61000-4-3:1995 - Radiated RF / EMF Immunity
- European Standard EN 61000-4-4:1995 - Fast Transient / Burst Immunity
- European Standard EN 61000-4-5:1995 - Surge Immunity
- European Standard EN 61000-4-6:1995 - Conducted Immunity
- European Standard EN 61000-4-11:1995 - Voltage Dips & Interruptions

These standards are in accordance with EMC Directive (89/336/EEC).

- European Standard EN 61010-1:1993 - Part 1: General Requirements Including Amendment 2: 1995

This standard is in accordance with Low Voltage Directive (73/23/EEC), 1973 Including Amendment (93/68/EEC), 1993

The technical documentation supporting compliance with these directives is maintained at Bird Electronic Corporation, 30303 Aurora Road, Cleveland, Ohio 44139



Bob Gardiner
Director of Quality
Bird Electronic Corporation