
INSTRUCTION BOOK

**TERMALINE® LOAD RESISTOR
SEMICONDUCTOR
SERIES 8920**



Bird Electronic Corporation
Cleveland (Solon) Ohio USA

©Copyright 2002 by Bird Electronic Corporation
Instruction Book Part Number 920-8920-SEMICON

Rev. A

Termaline® and Thruline® are Registered Trademarks
of Bird Electronic Corporation

Safety Precautions

The following are general safety precautions that are not necessarily related to any specific part or procedure and do not necessarily appear elsewhere in this publication. These precautions must be thoroughly understood and applied to all phases of operation and maintenance.

Keep Away From Live Circuits

Operating personnel must at all times observe normal safety regulations. Do not replace components or make adjustments inside the equipment with high voltage turned on. To avoid casualties, always remove power.

Shock Hazard

Do not attempt to remove the RF transmission line while RF power is present.

Do Not Service Or Adjust Alone

Under no circumstances should any personnel reach into an enclosure for the purpose of service or adjustment of equipment except in the presence of someone who is capable of rendering aid.

Safety Earth Ground

An uninterruptible earth safety ground must be supplied from the main power source to test instruments. Grounding one conductor of a two conductor power cable is not sufficient protection. Serious injury or death can occur if this grounding is not properly supplied.

Chemical Hazard

Dry cleaning solvents for cleaning parts may be potentially dangerous. Avoid inhalation of fumes or prolonged contact with skin.

Resuscitation

Personnel working with or near high voltages should be familiar with modern methods of resuscitation.

Safety Symbols

WARNING

Warning notes call attention to a procedure, which if not correctly performed, could result in personal injury.

CAUTION

Caution notes call attention to a procedure, which if not correctly performed, could result in damage to the instrument.



This symbol indicates that a shock hazard exists if the precautions in the instruction manual are not followed.



The caution symbol appears on the equipment indicating there is important information in the instruction manual regarding that particular area.



This symbol indicates that the unit radiates heat and should not be touched while hot.

☞ **NOTE:** Calls attention to supplemental information.

Warning Statements

The following safety warnings appear in the text where there is danger to operating and maintenance personnel and are repeated here for emphasis.

WARNING

BOTH vent plugs must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

Caution Statements

The following equipment cautions appear in the text whenever the equipment is in danger of damage and are repeated here for emphasis.

CAUTION

This load is designed for operation in a horizontal position only, with the vent plugs up. Do not use in any other manner.

CAUTION

If installed, connect optional interlock before applying RF power.

CAUTION

Use only Bird coolant, P/N 5-1070, to prevent damage to the load.

Safety Statements



USAGE

ANY USE OF THIS INSTRUMENT IN A MANNER NOT SPECIFIED BY THE MANUFACTURER MAY IMPAIR THE INSTRUMENT'S SAFETY PROTECTION.

USO

EL USO DE ESTE INSTRUMENTO DE MANERA NO ESPECIFICADA POR EL FABRICANTE, PUEDE ANULAR LA PROTECCIÓN DE SEGURIDAD DEL INSTRUMENTO.

BENUTZUNG

WIRD DAS GERÄT AUF ANDERE WEISE VERWENDET ALS VOM HERSTELLER BESCHRIEBEN, KANN DIE GERÄTESICHERHEIT BEEINTRÄCHTIGT WERDEN.

UTILISATION

TOUTE UTILISATION DE CET INSTRUMENT QUI N'EST PAS EXPLICITEMENT PRÉVUE PAR LE FABRICANT PEUT ENDOMMAGER LE DISPOSITIF DE PROTECTION DE L'INSTRUMENT.

IMPIEGO

QUALORA QUESTO STRUMENTO VENISSE UTILIZZATO IN MODO DIVERSO DA COME SPECIFICATO DAL PRODUTTORE LA PROZIONE DI SICUREZZA POTREBBE VENIRNE COMPROMESSA.



SERVICE

SERVICING INSTRUCTIONS ARE FOR USE BY SERVICE - TRAINED PERSONNEL ONLY. TO AVOID DANGEROUS ELECTRIC SHOCK, DO NOT PERFORM ANY SERVICING UNLESS QUALIFIED TO DO SO.

SERVICIO

LAS INSTRUCCIONES DE SERVICIO SON PARA USO EXCLUSIVO DEL PERSONAL DE SERVICIO CAPACITADO. PARA EVITAR EL PELIGRO DE DESCARGAS ELÉCTRICAS, NO REALICE NINGÚN SERVICIO A MENOS QUE ESTÉ CAPACITADO PARA HACERLO.

WARTUNG

ANWEISUNGEN FÜR DIE WARTUNG DES GERÄTES GELTEN NUR FÜR GESCHULTES FACHPERSONAL.

ZUR VERMEIDUNG GEFÄHRLICHER, ELEKTRISCHER SCHOCKS, SIND WARTUNGSARBEITEN AUSSCHLIEßLICH VON QUALIFIZIERTEM SERVICEPERSONAL DURCHZUFÜHREN.

ENTRETIEN

L'EMPLOI DES INSTRUCTIONS D'ENTRETIEN DOIT ÊTRE RÉSERVÉ AU PERSONNEL FORMÉ AUX OPÉRATIONS D'ENTRETIEN. POUR PRÉVENIR UN CHOC ÉLECTRIQUE DANGEREUX, NE PAS EFFECTUER D'ENTRETIEN SI L'ON N'A PAS ÉTÉ QUALIFIÉ POUR CE FAIRE.

ASSISTENZA TECNICA

LE ISTRUZIONI RELATIVE ALL'ASSISTENZA SONO PREVISTE ESCLUSIVAMENTE PER IL PERSONALE OPPORTUNAMENTE ADDESTRATO. PER EVITARE PERICOLOSE SCOSSE ELETTRICHE NON EFFETTUARE ALCUNA RIPARAZIONE A MENO CHE QUALIFICATI A FARLA.



CONNECT INTERLOCK TO TRANSMITTER/GENERATOR/AMPLIFIER BEFORE OPERATING.

BRANCHER LE VERROUILLAGE À L'ÉMETTEUR/GÉNÉRATEUR/AMPLIFICATEUR AVANT EMPLOI.

CONECTE EL INTERBLOQUEO AL TRANSMISOR/GENERADOR/AMPLIFICADOR ANTES DE LA OPERACION.

VOR INBETRIEBNAHME VERRIEGELUNG AM SENDER/GENERATOR/VERSTÄRKER ANSCHLIESSEN.

PRIMA DI METTERE IN FUNZIONE L'APPARECCHIO, COLLEGARE IL DISPOSITIVO DI BLOCCO AL TRASMETTITORE/GENERATORE/AMPLIFICATORE.

About This Manual

This instruction book covers the models listed below:

8921SC13

This instruction book is arranged so that essential information on safety is in the front of the book. Reading the Safety Precautions before operating the equipment is strongly advised. The remainder of this instruction book is divided into Chapters and Sections.

Operation

First time operators should read Chapter 1 - Introduction, Chapter 2 - Theory of Operation, and Chapter 3 - Installation to get an overview of equipment capabilities and how to install it. An experienced operator can refer to Chapter 4 - Operating Instructions. All instructions necessary to operate the equipment are contained in this chapter.

Maintenance

All personnel should be familiar with preventative maintenance found in Chapter 5 – Maintenance. If a failure should occur, the trouble-shooting section will aid in isolating and repairing the failure. Parts lists and repair instructions are also in this chapter.

Changes To The Manual

We have made every effort to ensure this manual is accurate at the time of publication. If you should discover any errors or if you have suggestions for improving this manual, please send your comment to our factory. This manual may be periodically updated. When inquiring about updates to this manual, refer to the part number and revision level on the title page.

Table of Contents

Safety Precautions	i
About This Manual	v
Introduction	1
Items Supplied	1
Items Required but not Supplied	1
Optional Accessories	1
Theory of Operation.	3
Load Resistor	3
Coolant	3
Thermal Interlock	3
Installation.	5
Unpacking and Inspection	5
Setup	5
Mounting	5
Installing Thermoswitch	6
Interlock Connection	7
Connecting RF Power	8
Operating Instructions	9
Normal Operation	9
Operation Under Abnormal Conditions	9
Shutdown	9
Emergency Shutdown	9
Maintenance.	11
Troubleshooting	11
Maintenance	12
Cleaning	12
Inspection	12
DC Resistance	12
Coolant Level	13

Repair	14
RF Connector	14
Load Resistor	14
Storage and Shipment	15
Customer Service	15
Specifications	16
Replacement Parts	17
Available “QC” Type Connectors	17

Bird 8920 Series Semiconductor Loads are portable, 50 ohm, coaxial RF transmission line terminations. They are designed for frequency ranges of dc – 28 MHz, specially calibrated for greater stability at 13.56 MHz. They provide accurate, dependable, and low reflection line terminations. Up to 5000 watts of RF power can be dissipated.

The load has a coolant chamber surrounded by radiator fins. The front and rear fins form mounting flanges which can be used as supports for freestanding use or as brackets for fixed mounting. A pair of vent plugs at the top of the unit relieves internal pressure from coolant expansion. The load's simple and rugged design minimizes maintenance requirements.

Items Supplied

- Load Resistor: Pre-filled with coolant at the factory
- Two Shipping Plugs
- Two Vent Plugs
- Instruction Manual


**Items Required but
not Supplied**

- Coupling Kit: Connects the load to the RF line

**Optional
Accessories**

- Interlock Thermoswitch: Automatically shuts off the RF generator to prevent overheating of the load

Figure 1
Bird 8920 Series
Outline Drawing



Load Resistor Bird 8920 series loads consist of a thin-film-on-ceramic resistor immersed in a dielectric coolant. The resistor, individually selected for its accuracy, is enclosed in a special housing. When surrounded by the coolant, this produces a uniform, practically reflectionless line termination over the specified frequencies.

Coolant The load is cooled by natural fluid and air convection currents. The coolant, chosen for its dielectric and thermal characteristics, carries heat from the resistor to the walls of the cooling tank, where radiator fins surrounding the tank transfer the heat to the air.

When the coolant is heated, thermal expansion causes an increase in the internal pressure. The vent plugs relieve this pressure while protecting the opening from dirt or other contaminants.

Thermal Interlock Loads can be supplied with an optional passive overtemperature thermoswitch. Normally closed, it opens at the maximum safe load temperature of 236 °C (457 °F), turning off power to the RF generator. The interlock system will not permit use of the generator until the load has reached a safe temperature.

Figure 2
Shipping Plug





Figure 3
Vent Plug



This chapter provides information for on-site requirements, unpacking, inspection, and preparing the load for use.

Unpacking and Inspection

1. Carefully inspect the shipping container for signs of damage. If damage is noticed, do not unpack the unit. Immediately notify the shipping carrier and Bird Electronic Corporation.
2. If the container is not damaged, unpack the unit. Save the packing materials in case the unit should need to be shipped again.
3. Inspect all of the components for visible signs of damage. Immediately notify the shipping carrier and Bird Electronic Corporation of equipment damage or missing parts.

Setup

- Before first using the load, get a resistance baseline for future maintenance. Refer to “DC Resistance” on page 12 for details.
- Remove both shipping plugs from the load and replace them with the vent plugs. Refer to Figure 2 and Figure 3 for pictures of the plugs.

WARNING

BOTH vent plugs must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

Mounting

Place the load in a dry, dust and vibration free environment. Do not use outdoors or in areas of condensing humidity. Allow at least 12" (30 cm) of clearance on all sides of the load.

CAUTION

This load is designed for operation in a horizontal position only, with the vent plugs up. Do not use in any other manner.

The load is equipped for either portable use or fixed installation. The mounting brackets on the front and rear faces have four mounting slots arranged in a $4\frac{1}{2}" \times 14\frac{7}{32}"$ rectangle (114.3 x 361.2 mm). Use a screw with a $\frac{3}{8}"$ (9.53 mm) diameter max.

**Installing
Thermoswitch**

Bird 8920 series loads can be equipped with an optional interlock thermoswitch, P/N 8890-008. It is normally closed, opening at 236 °C (457 °F), with a rating of 10A @ 120 Vac and 5A @ 230 Vac.

WARNING

BOTH vent plugs must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

To install or replace the thermoswitch:

1. Remove the vent plugs. Install the shipping plugs.
2. Stand the unit on its front, supporting it so that the connector is not damaged. In this position there is no danger of the coolant pouring out through the socket plug hole.
3. Remove the socket plug just above the connector assembly, using a $\frac{9}{16}$ " hex wrench.
4. Replace the plug with the thermoswitch. Sparingly apply pipe sealing compound to the external threads, only, of the thermoswitch. Do not contaminate the coolant with pipe sealant.
5. Check for coolant leaks upon completion.
6. Remove the shipping plugs. Install the vent plugs.

**Interlock
Connection**


Connect the thermoswitch to the interlock as follows (see Figure 4):

CAUTION

If installed, connect optional interlock before applying RF power.

1. Unscrew the large knurled ring-nut (A) at the lower end of the coupling jack assembly. Pull it off the thermoswitch jack (B). Unscrew the small knurled cover fitting from the base plug (D) of the connector to release the base.
☞ NOTE: The ring-nut (A) must be in place over the base plug (D) with the knurled end facing out.
2. Thread the control switch wires through the clamp (E) with the washers (F) inside and with its threaded fitting in place. Service the control switch wire with short tips and put spaghetti sleeves over the wire ends if necessary.
3. Securely solder the control switch leads to the lugs (G) of the connector base.
4. Screw on the cover ring, then fasten the cable clamp (E) in place and tighten both yoke screws (H).
5. Put the plug back on the thermoswitch and tighten the nut (A).

*Figure 4
Thermoswitch
Assembly*



**Connecting RF
Power**

After installing the load, the RF transmission line can be attached using standard coaxial line coupling kits.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

“QC” Connector Coupling: Use 50 ohm coaxial cable such as RG-218/U or -220/U (-17A or -19A), appropriate for the frequency and power level of operation. Use a cable connector which will mate with the one on the load.

WARNING

BOTH vent plugs must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

- Normal Operation** Bird 8920 series loads have no indicators or operating controls. They require no special operating procedures or surveillance when their performance limits are not exceeded. Follow the instructions for the specific generator equipment.
- Operation Under Abnormal Conditions** The load can be subjected to moderate overloads for short periods. If this is likely, make sure the interlock is properly connected to prevent damage to the load.
- Shutdown** These loads are passive devices, so have no way of being turned off. Turn off RF power at the source.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

- Emergency Shutdown** Turn off RF power at the source.
- If the interlock thermoswitch is properly connected, RF power will be automatically turned off when the coolant temperature reaches an unsafe level.

This chapter covers cleaning, inspection, trouble-shooting, and specifications for the Bird 8920 series loads.

WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

Troubleshooting

The table below contains troubleshooting information for problems which can occur during normal operation. This manual cannot list all malfunctions that may occur, or their corrective actions. If a problem is not listed or is not corrected by the listed actions, notify a qualified service center.

PROBLEM	POSSIBLE CAUSE	CORRECTION
Leaking coolant	Loose clamping band	Tighten the clamping band
	Defective or improperly installed O-ring	Replace the O-ring (See "Load Resistor" on page 14)
High or low dc resistance	Loose RF input connector	Tighten connector
	Faulty RF input connector	Replace connector (See "RF Connector" on page 14)
	Faulty resistor	Replace the resistor (See "Load Resistor" on page 14)


PROBLEM	POSSIBLE CAUSE	CORRECTION
Overheating radiator	RF power too high	Lower RF power (See "Specifications" on page 16 for maximum RF power)
	Coolant level too low	Check the coolant level. Add coolant if necessary (See "Coolant Level" on page 13)
	Coolant degraded	Replace the coolant (See "Coolant Level" on page 13)
	Faulty resistor	Replace the resistor (See "Load Resistor" on page 14)

Maintenance

- Cleaning** The outside surface of the instrument should be wiped free of dust and dirt when necessary. Excessive dust on the cooling fins will interfere with heat dissipation. Clean the RF connector, both metallic and insulating surfaces, with a dry, non-residue forming solvent.
- Inspection** Inspect the unit every six months. Check for coolant leakage around the clamping band and the thermoswitch. Also check for corrosion.
- DC Resistance** Measuring the dc resistance between the inner and outer conductors of the RF connector provides a good check of the condition of the load resistor. This simply measures changes in the resistor's condition over time. Under normal operating conditions, the resistor should provide at least 5,000 hours of operation before requiring any additional service. DC resistance tracking must start before the resistor is put into service, and should be measured annually.

Perform the following steps and record the value for future comparison. Make sure that you have an ohmmeter with an accuracy of $\pm 1\%$ at 50 ohms and that the load temperature is between 20 and 25 °C (68 to 77 °F) before starting.

Figure 5
Measuring
Resistance



WARNING

Never attempt to connect or disconnect RF equipment from the transmission line while RF power is being applied.
Leaking RF energy is a potential health hazard.

1. Turn off the RF power and interlock circuitry.
2. Disconnect the RF line.
3. Connect the multimeter test leads to the center and outer conductor of the load resistor. Refer to Figure 5.
4. Compare the measured value with the previous measurement and with the baseline resistance, measured when the load was put into service. If the new value differs from either of these by more than 1 ohm this could indicate a failing resistor.

Coolant Level Coolant lifetime will vary greatly depending on operating conditions. For heavy use (full RF power for long times, high ambient temperature), check the coolant every 500 hours. If the load has only had light duty (fraction of full power, low ambient temperature), then coolant inspection may only be necessary every 2,000 hours.

☞ **NOTE:** Correct any coolant leakage before inspection. (See “Troubleshooting” on page 11)

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

To inspect the coolant:

- Remove the load resistor (Refer to “Load Resistor” on page 18).

CAUTION

Use only Bird coolant, P/N 5-1070, to prevent damage to the load.

- The coolant should be clear, with a faint yellow tinge, and have a slightly sweet smell. If it is black with a burnt or acrid smell, drain it and add about 6.7 gal (25.2 L) of coolant.
- With the load still on end, the coolant level should be $4\frac{3}{4}$ " (125 mm) below the top surface of the resistor assembly mounting ring, at ambient temperature. Add coolant if necessary.

Repair

WARNING

Disconnect the unit from all power sources before servicing.
The unit may be energized from multiple sources.
The potential for electric shock exists.

WARNING

BOTH vent plugs must be used at all times when the unit is operating or cooling. Failure to do so could result in an explosion or severe burns.

RF Connector

The 8921SC13 has a Bird “QC” connector which allows easy changing of the RF connector. This does not disturb the coolant seal or affect the electrical continuity of the load. To change the connector:

- Remove the four screws at the corners of the RF connector.
- Pull the connector straight out.
- Push the new connector in. Make sure that the center pin on the connector is properly seated in the mating socket on the load.
- Replace the screws.

☞ NOTE: If not using the LC connector normally supplied, the frequency and power must be limited to the capabilities of the connector.

Load Resistor

To change the load resistor assembly:

1. Remove the vent plugs. Install the shipping plugs.
2. Supporting the unit to prevent damage to the interlock, stand it on its back with the connector end up. In this position there is no danger of the coolant pouring out through the resistor hole.
3. Unscrew and remove the clamping band.
4. Lift the load resistor assembly out of the tank and allow any coolant to drip back into the tank.
5. The O-Ring should be free of twists and positioned evenly around the flange of the resistor housing. If the O-ring shows signs of deterioration (e.g. is no longer pliable or has surface cracks) replace it.

6. Replace the entire load resistor assembly. It cannot be further disassembled.
7. Put the clamping band in place and tighten it.
8. Remove the shipping plugs. Install the vent plugs.

Storage and Shipment

Cover the load before storing to keep out dust and dirt. It is not necessary to install the shipping plugs. Store in a dry, dust-free environment where the ambient temperature will remain between -40 and $+45$ °C (-40 to $+113$ °F).

To ship the load, take the following precautions:

- Remove both vent plugs and replace them with the shipping plugs. Wrap the vent plugs with padding and tape them to the side of the load for protection.

☞ NOTE: With the shipping plugs installed, it is not necessary to empty out the coolant.

- Wrap the connector in padding.
- Pack and brace the load in a sturdy wooden crate for shipment.

Customer Service

Any maintenance or service procedure beyond the scope of those in this chapter should be referred to a qualified service center.

If you need to return the unit for any reason, contact the Bird Service Center for a return authorization. All instruments returned must be shipped prepaid and to the attention of Bird Service Center.

Bird Service Center

30303 Aurora Road
Cleveland (Solon), OH 44139-2794
Phone: (440) 519-2298
Fax: (440) 519-2326

For the location of the Sales Office nearest you, give us a call or visit our Web site at:

<http://www.bird-electronic.com>

Specifications

Frequency Range	dc – 28 MHz
Power Rating	5000 W continuous duty
Impedance, Nominal	50 ohms
VSWR	1.1 max
VSWR Stability	< 0.1 dB, from 0 to 100% rated power at stability frequency
Stability Frequency	13.56 MHz \pm 10 kHz
Connectors	“QC” Type, Female LC normally supplied
Interlock Thermoswitch (Optional)	Normally closed. Opens at 236 °C (457 °F)
Thermoswitch Rating:	
115 Vac	10 A
230 Vac	5 A
Temperature, Operating	+5 to +40 °C (+41 to +104 °F)
Temperature, Storage	–40 to +45 °C (–40 to +113 °F)
Altitude*	1520 m (5000 ft.)
Humidity	95% noncondensing max
Cooling Method	Oil dielectric and convection currents
Dimensions	29”L x 9-1/2”W x 26-53/64”H (737 x 241 x 681 mm)
Weight, Nominal	119 lb. (54 kg)
Finish	Black Epoxy Resin

* Derate RF power by 2.5% for every 305m (1,000 ft.) above 1,520m (5,000 ft.).

Replacement Parts

DESCRIPTION	QTY	PART NUMBER
RF Load Resistor	1	8890-060
Resistor O-Ring	1	5-230
Clamping band assembly	1	2430-055
Plug Vent Shipping	2	2450-094 2450-049
Interlock Thermoswitch	1	8890-008
Thermoswitch Body	1	8890-005
Thermoswitch Jack	1	2450-018
Radiator Assembly	1	8921-002
Access Plug, 3/4"-14 Hex Socket	1	5020-103
Coolant, 6.7 gal (23 liters)	1	5-1070-3

Available “QC” Type Connectors

Connector	Part Number	Connector	Part Number	Connector	Part Number
BNC-Female	4240-125	LT-Female	4240-018	Mini UHF-Female	4240-346
BNC-Male	4240-132	LT-Male	4240-012	UHF-Female	4240-050
C-Female	4240-100	N-Female	4240-062	UHF-Male	4240-179
C-Male	4240-110	N-Male	4240-063	1-5/8" EIA Fixed	4240-096
HN-Female	4240-268	SC-Female	4240-090	1-5/8" EIA Swivel	4240-208
HN-Male	4240-278	SMA-Female	4240-336	7/8" EIA	4240-002
LC-Female *	4240-031	SMA-Male	4240-334	TNC-Female	4240-156
LC-Male	4240-025	7/16 Jack, IEC Type 169-4	4240-344	TNC-Male	4240-160
Open Term. # 10-32 Nut	4240-080	7/16 Plug, IEC Type 169-4	4240-363		

* Normally supplied

Limited Warranty

All products manufactured by Seller are warranted to be free from defects in material and workmanship for a period of one (1) year, unless otherwise specified, from date of shipment and to conform to applicable specifications, drawings, blueprints and/or samples. Seller's sole obligation under these warranties shall be to issue credit, repair or replace any item or part thereof which is proved to be other than as warranted; no allowance shall be made for any labor charges of Buyer for replacement of parts, adjustment or repairs, or any other work, unless such charges are authorized in advance by Seller.

If Seller's products are claimed to be defective in material or workmanship or not to conform to specifications, drawings, blueprints and/or samples, Seller shall, upon prompt notice thereof, either examine the products where they are located or issue shipping instructions for return to Seller (transportation-charges prepaid by Buyer). In the event any of our products are proved to be other than as warranted, transportation costs (cheapest way) to and from Seller's plant, will be borne by Seller and reimbursement or credit will be made for amounts so expended by Buyer. Every such claim for breach of these warranties shall be deemed to be waived by Buyer unless made in writing within ten (10) days from the date of discovery of the defect.

The above warranties shall not extend to any products or parts thereof which have been subjected to any misuse or neglect, damaged by accident, rendered defective by reason of improper installation or by the performance of repairs or alterations outside of our plant, and shall not apply to any goods or parts thereof furnished by Buyer or acquired from others at Buyer's request and/or to Buyer's specifications. Routine (regularly required) calibration is not covered under this limited warranty. In addition, Seller's warranties do not extend to the failure of tubes, transistors, fuses and batteries, or to other equipment and parts manufactured by others except to the extent of the original manufacturer's warranty to Seller.

The obligations under the foregoing warranties are limited to the precise terms thereof. These warranties provide exclusive remedies, expressly in lieu of all other remedies including claims for special or consequential damages. SELLER NEITHER MAKES NOR ASSUMES ANY OTHER WARRANTY WHATSOEVER, WHETHER EXPRESS, STATUTORY, OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, AND NO PERSON IS AUTHORIZED TO ASSUME FOR SELLER ANY OBLIGATION OR LIABILITY NOT STRICTLY IN ACCORDANCE WITH THE FOREGOING.

DECLARATION OF CONFORMITY

Manufacturer: Bird Electronic Corporation
30303 Aurora Road
Cleveland, Ohio 44139-2794

Product: Termaline Load Resistor

Models: 8921SC13

The undersigned hereby declares, on behalf of Bird Electronic Corporation of Cleveland, Ohio, that the above referenced products, to which this declaration relates, are in conformance with the provisions of the following standards.

- European Standard 61326-1:1997 – Electronic Equipment for Measurement, Control and Laboratory Use – EMC Requirements

These standards are in accordance with EMC Directive (89/336/EEC).

- European Standard EN 61010-1:1993 – Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use: Including Amendment 2: 1995

This standard is in accordance with Low Voltage Directive (73/23/EEC), 1973 Including Amendment (93/68/EEC), 1993

The technical documentation supporting compliance with these directives is maintained at Bird Electronic Corporation, 30303 Aurora Road, Cleveland, Ohio 44139



Bob Gardiner
Director of Quality
Bird Electronic Corporation