

CHAPTER

25

**EQUIPMENT/
FURNISHINGS**



737-600/700/800/900

FAULT ISOLATION MANUAL**CHAPTER 25
EQUIPMENT/FURNISHINGS**

Page	Date	COC	Page	Date	COC	Page	Date	COC
EFFECTIVE PAGES			25-51 TASKS					
1	Jun 15/2009		201	Feb 15/2009				
2	BLANK		202	Feb 15/2009				
25-HOW TO USE THE FIM			25-61 TASKS					
1	Feb 10/2005		201	Feb 10/2005				
2	Feb 10/2005		202	Feb 10/2005				
3	Jun 10/2006		25-99 TASKS					
4	Oct 10/2006		201	Feb 10/2005				
5	Feb 10/2005		202	BLANK				
6	Feb 10/2005							
25-FAULT CODE INDEX								
101	Feb 10/2007							
102	Feb 10/2007							
25-21 TASKS								
201	Feb 10/2006							
202	Feb 10/2006							
203	Feb 10/2006							
204	Feb 10/2006							
205	Feb 10/2006							
206	BLANK							
25-22 TASKS								
201	Feb 10/2005							
202	BLANK							
25-23 TASKS								
201	Feb 10/2005							
202	Feb 10/2005							
25-24 TASKS								
201	Jun 10/2007							
202	Jun 10/2007							
203	Jun 10/2007							
204	BLANK							
25-31 TASKS								
201	Feb 15/2009							
202	Feb 15/2008							
203	Feb 15/2008							
204	Feb 15/2008							
25-40 TASKS								
201	Feb 10/2005							
202	Feb 10/2005							

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated

25-EFFECTIVE PAGES

 **BOEING®**
737-600/700/800/900
FAULT ISOLATION MANUAL

YOU FIND A FAULT WITH
AN AIRPLANE SYSTEM

These are the possible types
of faults:

1. Observed Fault
2. Cabin Fault



USE BITE TO GET
MORE INFORMATION

If you did a BITE test already,
then you can go directly to the
fault isolation procedure for
the maintenance message.

For details, see Figure 2 →



GO TO THE
FAULT ISOLATION
TASK IN THE FIM

Use the fault code or description
to find the task in the FIM. There
is a numerical list of fault codes
in each chapter. There are lists
of fault descriptions at the front
of the FIM.

For details, see Figure 3 →



FOLLOW THE STEPS OF THE
FAULT ISOLATION TASK

The fault isolation task explains
how to find the cause of the fault.
When the task says "You corrected
the fault" you know that the fault
is gone.

For details, see Figure 4 →

Basic Fault Isolation Process
Figure 1

EFFECTIVITY
HAP ALL

25-HOW TO USE THE FIM

 **BOEING®**
737-600/700/800/900
FAULT ISOLATION MANUAL

Some airplane systems have built-in test equipment (BITE). IF the system finds a fault when you do a BITE test, it will give you a maintenance message.

A maintenance message can be any of these:

- a code
- a text message
- a light
- an indication.

To find the fault isolation task for a maintenance message, go to the Maintenance Message Index in the chapter for the applicable system.

If you do not know which chapter is the correct one, look at the list at the front of any Maintenance Message Index. For each system or component (LRU) that has BITE, this list gives the chapter number where you can find the Index that you need.

Find the maintenance message for the applicable LRU or system in the Index. Then find the task number on the same line as the maintenance message. Go to the task in the FIM and do the steps of the task (see Figure 4).

Getting Fault Information from BITE
Figure 2

EFFECTIVITY
HAP ALL

25-HOW TO USE THE FIM

IF YOU HAVE:

THEN DO THIS TO FIND THE TASK IN THE FIM:

FAULT CODE

1. The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code. If the fault code starts with a letter, then go to the Cabin Fault Code Index at the front of the FIM.
2. Find the task number on the same line as the fault code. Go to the task in the FIM and do the steps in the task (see Figure 4).

OBSERVED FAULT DESCRIPTION

1. Go to the Observed Fault List at the front of the FIM and find the best description for the fault.
2. Find the task number on the same line as the fault description. Go to the task in the FIM and do the steps of the task (see Figure 4).

CABIN FAULT DESCRIPTION

1. Go to the Cabin Fault List at the front of the FIM and find the best description for the fault.
2. Find the task number on the same line as the fault description. Go to the task in the FIM and do the steps of the task (see Figure 4).

MAINTENANCE MESSAGE (FROM BITE)

1. Go to the Maintenance Message Index in the chapter for the LRU (the front of each Index gives you the chapter number for all LRUs). Find the maintenance message in the Index.
2. Find the task number on the same line as the maintenance message. Go to the task in the FIM and do the steps in the task (see Figure 4).

Finding the Fault Isolation Task in the FIM
Figure 3

EFFECTIVITY
HAP ALL

25-HOW TO USE THE FIM

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is ON
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- No equipment in the system is deactivated

POSSIBLE CAUSES

- The list of possible causes has the most likely cause first and the least likely cause last.
- You can use the maintenance records of your airline to determine if the fault occurred before. Compare the list of possible causes to the past maintenance actions. This will help prevent repetition of the same maintenance actions.

INITIAL EVALUATION PARAGRAPH

- The primary purpose of the Initial Evaluation paragraph at the start of the task is to help you find out if you can detect the fault right now:
 - If you cannot detect the fault right now, then the task cannot isolate the fault and the Initial Evaluation paragraph will say that there was an intermittent fault.
 - If you have an intermittent fault, you must use your judgement (and follow your airline's policy) to decide which maintenance action to take. Then monitor the airplane to see if the fault happens again on subsequent flights.
- The Initial Evaluation paragraph can also help you find out which Fault Isolation Procedure to use to isolate and correct the fault.

FAULT ISOLATION STEPS


- Do the steps of the task in the specified order. The "If ... then" statements that you see will guide you along the correct path.
- When you are at the endpoint of the path, the step says "...you corrected the fault." Complete the step and exit the procedure.

Doing the Fault Isolation Task
Figure 4

EFFECTIVITY
HAP ALL

25-HOW TO USE THE FIM

 **BOEING®**
737-600/700/800/900
FAULT ISOLATION MANUAL




Subjects at Front of FIM
 Figure 5



25-HOW TO USE THE FIM

Page 5
 Feb 10/2005


BOEING®
737-600/700/800/900
FAULT ISOLATION MANUAL



Subjects in Each FIM Chapter
 Figure 6



25-HOW TO USE THE FIM



737-600/700/800/900

FAULT ISOLATION MANUAL

FAULT CODE	FAULT DESCRIPTION	GO TO FIM TASK
251 020 31	Seat: horizontal adjustment problem - captain's.	25-99 TASK 801
251 020 32	Seat: horizontal adjustment problem - first officer's.	25-99 TASK 801
251 030 31	Seat: lumbar adjustment problem - captain's.	25-99 TASK 801
251 030 32	Seat: lumbar adjustment problem - first officer's.	25-99 TASK 801
251 040 31	Seat: recline adjustment problem - captain's.	25-99 TASK 801
251 040 32	Seat: recline adjustment problem - first officer's.	25-99 TASK 801
251 050 31	Seat: vertical adjustment problem - captain's.	25-99 TASK 801
251 050 32	Seat: vertical adjustment problem - first officer's.	25-99 TASK 801
251 060 31	Seat arm rest problem - captain's.	25-99 TASK 801
251 060 32	Seat arm rest problem - first officer's.	25-99 TASK 801
251 070 31	Seat belt problem - captain's.	25-99 TASK 801
251 070 32	Seat belt problem - first officer's.	25-99 TASK 801
251 070 33	Seat belt problem - first observer's.	25-99 TASK 801
251 070 34	Seat belt problem - second observer's.	25-99 TASK 801
251 080 31	Seat track: does not move freely - captain's.	25-99 TASK 801
251 080 32	Seat track: does not move freely - first officer's.	25-99 TASK 801
251 090 31	Shoulder harness: does not extend or retract - captain's.	25-99 TASK 801
251 090 32	Shoulder harness: does not extend or retract - first officer's.	25-99 TASK 801
251 090 33	Shoulder harness: does not extend or retract - first observer's.	25-99 TASK 801
251 100 31	Assist handle problem - captain's.	25-99 TASK 801
251 100 32	Assist handle problem - first officer's.	25-99 TASK 801
251 110 00	Spare bulb kit: needs replenishing.	25-99 TASK 801
251 120 31	Sun visor problem - captain's.	25-99 TASK 801
251 120 32	Sun visor problem - first officer's.	25-99 TASK 801
251 130 31	Chart holder, sidewall problem - captain's.	25-99 TASK 801
251 130 32	Chart holder, sidewall problem - first officer's.	25-99 TASK 801
251 140 31	Cup holder problem - captain's.	25-99 TASK 801
251 140 32	Cup holder problem - first officer's.	25-99 TASK 801
251 681 31	PC power system for flight deck: status LED at outlet does not operate normally - captain's.	23-82 TASK 801
251 681 32	PC power system for flight deck: status LED at outlet does not operate normally - first officer's.	23-82 TASK 801
256 010 00	Fireproof gloves: missing.	25-99 TASK 801



25-FAULT CODE INDEX



737-600/700/800/900

FAULT ISOLATION MANUAL

FAULT CODE	FAULT DESCRIPTION	GO TO FIM TASK
256 015 00	Fireproof gloves: damaged.	25-99 TASK 801
256 020 00	Crash ax: missing.	25-99 TASK 801
256 050 31	Life vest: missing/damaged - captain's.	25-99 TASK 801
256 050 32	Life vest: missing/damaged - first officer's.	25-99 TASK 801
256 050 33	Life vest: missing/damaged - first observer's.	25-99 TASK 801
256 050 34	Life vest: missing/damaged - second observer's.	25-99 TASK 801
256 060 31	Smoke goggles: missing - captain's.	25-99 TASK 801
256 060 32	Smoke goggles: missing - first officer's.	25-99 TASK 801
256 070 00	Flashlight: battery low.	25-99 TASK 801
256 080 00	Flashlight: damaged.	25-99 TASK 801
256 090 00	Flashlight: does not come on.	33-55 TASK 801
256 091 00	Flashlight: does not go off.	33-55 TASK 801
256 100 00	Flashlight: missing.	25-99 TASK 801
256 110 00	Flashlight LED: does not come on.	33-55 TASK 801
256 120 31	Escape rope (lanyard) compartment cover: will not close - captain's.	25-61 TASK 801
256 120 32	Escape rope (lanyard) compartment cover: will not close - first officer's.	25-61 TASK 801
256 130 31	Escape rope (lanyard): damaged - captain's.	25-61 TASK 802
256 130 32	Escape rope (lanyard): damaged - first officer's.	25-61 TASK 802
256 140 31	Escape rope (lanyard): unstowed - captain's.	25-61 TASK 803
256 140 32	Escape rope (lanyard): unstowed - first officer's.	25-61 TASK 803
256 201 00	Circuit breaker collars (spare): missing.	25-99 TASK 801



FAULT ISOLATION MANUAL

803. Cabin Window Shade - Fault Isolation

A. Description

- (1) This task is for the cabin window shade:
 - (a) The cabin window shade is stuck.
 - (b) The cabin window shade does not open/close smoothly.
 - (c) The cabin window shade is too loose.

B. Possible Causes

- (1) The cabin window shade is stuck if:
 - (a) There is unwanted material in the track.
 - (b) The shade and track are too tight.
- (2) The cabin window shade does not open/close smoothly if:
 - (a) There is an obstruction in the track.
 - (b) The shade and track are too tight.
- (3) The cabin window shade is too loose if:
 - (a) The shade or track is worn.
 - (b) The shade and track do not fit correctly.

C. Initial Evaluation

- (1) Do this check of the cabin window shade:
 - (a) Make sure that the cabin window shade opens/closes.
 - 1) If the window shade is stuck, then do the Fault Isolation Procedure - Cabin Window Shade Is Stuck.
 - (b) Make sure that the cabin window shade opens/closes smoothly.
 - 1) If the window shade does not open/close smoothly, then do the Fault Isolation Procedure - Cabin Window Shade Does Not Open/Close Smoothly.
 - (c) Make sure the window shade stays in all positions:
 - 1) If the window shade does not stay in the adjusted position, then do the Fault Isolation Procedure - Cabin Window Shade Is Too Loose.

D. Fault Isolation Procedure - Cabin Window Shade Is Stuck

- (1) Remove unwanted material from the window shade tracks.
 - (a) Open and close the window shade three to five times.
 - (b) If the window shade opens/closes correctly, then you corrected the fault.
 - (c) If the window shade does not open/close correctly, then continue.
- (2) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) Open and close the window shade three to five times.
 - (b) If the window shade opens/closes correctly, then you corrected the fault.
 - (c) If the window shade does not open/close correctly, then continue.
- (3) Remove the window shade. To remove the window shade, do this task: Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-020-801.



25-21 TASK 803



737-600/700/800/900

FAULT ISOLATION MANUAL

- (a) Examine the window shade and track. Remove unwanted material, apply silicone lubricant, and make necessary adjustments.
 - (b) Re-install the window shade. To install it, do this task: Window Shade and Reveal Assembly Installation, AMM TASK 25-21-12-400-801.
 - (c) If the window shade opens/closes correctly, then you corrected the fault.
 - (d) If the window shade does not open/close correctly, then continue.
- (4) Replace the window shade.

These are the tasks:

Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-020-801,

Window Shade and Reveal Assembly Installation, AMM TASK 25-21-12-400-801.

- (a) If the window shade opens/closes correctly, then you corrected the fault.

E. Fault Isolation Procedure - Cabin Window Shade Does Not Open/Close Smoothly

- (1) Make sure that unwanted material is not caught in the window shade track area.
 - (a) If unwanted material is present, then remove this material and make sure that the window shade opens and closes.
 - (b) If the window shade closes correctly, then you corrected the fault.
 - (c) If the window shade does not close correctly, then continue.
- (2) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) If the window shade closes correctly, then you corrected the fault.
 - (b) If the window shade does not close correctly, then continue.
- (3) Remove the window shade. To remove the window shade, do this task: Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-020-801.
 - (a) Inspect shade and track. Remove unwanted material, apply silicon lubricant, and adjust as necessary.
 - (b) Re-install the window shade. To install it, do this task: Window Shade and Reveal Assembly Installation, AMM TASK 25-21-12-400-801.
 - (c) If the shade and track operate correctly, then you corrected the fault.
 - (d) If the window shade does not operate correctly, then continue.
- (4) Replace the window shade. To replace the window shade, do this task: Window Shade and Reveal Assembly Installation, AMM TASK 25-21-12-400-801.
 - (a) If the window shade opens/closes correctly, then you corrected the fault.

F. Fault Isolation Procedure - Window Shade Is Too Loose

- (1) Replace window shade.

These are the tasks:

Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-020-801,

Window Shade and Reveal Assembly Installation, AMM TASK 25-21-12-400-801.

- (a) If the window shade operates correctly, then you corrected the fault.

————— END OF TASK —————





737-600/700/800/900

FAULT ISOLATION MANUAL

804. Emergency Exit Door Window Shade - Fault Isolation

A. Description

- (1) This task is for the emergency exit door window shade:
 - (a) The emergency exit door window shade is stuck.
 - (b) The emergency exit door window shade does not open/close smoothly.
 - (c) The emergency exit door window shade is too loose.

B. Possible Causes

- (1) The emergency exit door window shade is stuck if:
 - (a) There is unwanted material in the track.
 - (b) The shade handle/stiffener and track are too tight.
- (2) The emergency exit door window shade does not open/close smoothly if:
 - (a) There is unwanted material in the track.
 - (b) The shade handle/stiffener and track are too tight.
- (3) The emergency exit door window shade is too loose if:
 - (a) The velcro pad on the handle/stiffener or the track is worn.
 - (b) The handle/stiffener and track do not fit correctly.

C. Initial Evaluation

- (1) Do this check of the emergency exit door window shade:
 - (a) Make sure that the emergency exit door window shade opens and closes.
 - 1) If the emergency exit door window shade is stuck, then do the Fault Isolation Procedure - Emergency Exit Door Window Shade Is Stuck.
 - (b) Make sure that the emergency exit door window shade opens and closes smoothly.
 - 1) If the emergency exit door window shade does not open/close smoothly, then do the Fault Isolation Procedure - Emergency Exit Door Window Shade Does Not Open/Close Smoothly.
 - (c) Make sure the emergency exit door window shade stays in all positions:
 - 1) If the emergency exit door window shade does not stay in the adjusted position, then do the Fault Isolation Procedure - Emergency Exit Door Window Shade Is Too Loose.

D. Fault Isolation Procedure - Emergency Exit Door Window Shade Is Stuck

- (1) Remove unwanted material from the emergency exit door window shade tracks.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes correctly, then you corrected the fault.
 - (c) If the emergency exit door window does not open/close correctly, then continue.
- (2) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes correctly, then you corrected the fault.
 - (c) If the emergency exit door window shade does not open correctly, then continue.





737-600/700/800/900

FAULT ISOLATION MANUAL

- (3) Remove the emergency exit door window shade and reveal assembly. To remove this assembly, do this task: Emergency Exit Door Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-000-801.
- (4) Examine the velcro pad that is on each end of the handle/stiffener assembly for damage.
 - (a) If the velcro pad is damaged, then replace the velcro pad.
- (5) Examine the velcro pad and the shade track surfaces for unwanted material.
 - (a) If there is unwanted material on the velcro pad, then remove the unwanted material.
- (6) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
- (7) Examine the emergency exit door window shade roller to make sure that the spring moves freely, and that there is no unwanted material in the area of the bearing.
 - (a) If there is unwanted material in this area, then remove this material.
- (8) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes correctly, then you corrected the fault.
 - (c) If the emergency exit door window shade does not open/close correctly, then continue.
- (9) Replace the emergency exit door window shade and reveal assembly. To install this assembly, do this task: Emergency Exit Door Window Shade and Reveal Installation, AMM TASK 25-21-12-400-802.

E. Fault Isolation Procedure - Emergency Exit Door Window Shade Does Not Open/Close Smoothly

- (1) Remove unwanted material from the emergency exit door window shade tracks.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes smoothly, then you corrected the fault.
 - (c) If the emergency exit door window shade does not open/close smoothly, then continue.
- (2) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes smoothly, then you corrected the fault.
 - (c) If the emergency exit door window shade does not open smoothly, then continue.
- (3) Remove the emergency exit door window shade and reveal assembly. To remove this assembly, do this task: Emergency Exit Door Window Shade and Reveal Assembly Removal, AMM TASK 25-21-12-000-801.
- (4) Examine the velcro pad that is on each end of the handle/stiffener assembly for damage.
 - (a) If the velcro pad is damaged, then replace the velcro pad.
- (5) Examine the velcro pad and the shade track surfaces for unwanted material.
 - (a) If there is unwanted material on the velcro pad, then remove the unwanted material.



25-21 TASK 804



737-600/700/800/900

FAULT ISOLATION MANUAL

- (6) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
- (7) Examine the emergency exit door window shade roller to make sure that the spring moves freely, and that there is no unwanted material in the area of the bearing.
 - (a) If there is unwanted material in this area, then remove this material.
- (8) Apply a small amount (one drop) of Dow Corning 200 lubricant, D00050, or GE Silicones VISC-5M, or silicone compound, D00254 to the side of each track with a small cotton swab.
 - (a) Open and close the emergency exit door window shade three to five times.
 - (b) If the emergency exit door window shade opens/closes smoothly, then you corrected the fault.
 - (c) If the emergency exit door window shade does not open/close smoothly, then continue.
- (9) Replace the emergency exit door window shade and reveal. To install this assembly, do this task: Emergency Exit Door Window Shade and Reveal Installation, AMM TASK 25-21-12-400-802.

F. Fault Isolation Procedure - Emergency Exit Door Window Shade Is Too Loose

- (1) Replace the emergency exit door window shade.

These are the tasks:

Emergency Exit Door Window Shade and Reveal Assembly Removal, AMM
TASK 25-21-12-000-801,

Emergency Exit Door Window Shade and Reveal Installation, AMM TASK 25-21-12-400-802.

- (a) If the emergency exit door window shade operates correctly, then you corrected the fault.

————— END OF TASK ————





737-600/700/800/900

FAULT ISOLATION MANUAL

801. Passenger Seat Back Problem - Fault Isolation

A. Description

- (1) This task is for these seat back problems:
 - (a) A damaged seat back.
 - (b) The seat back does not recline.
 - (c) The seat back does not stay in position.

B. Possible Causes

- (1) Unwanted material prevents correct movement of the seat back
- (2) Damaged seat back mechanism

C. Initial Evaluation

- (1) Do this check of the seat back:
 - (a) Push the seat back release button.
 - (b) Move the seat back forward and aft.
 - (c) If the seat back does not move correctly, then do the Fault Isolation Procedure below.
 - (d) If the seat back moves correctly, then there was an intermittent fault.

D. Fault Isolation Procedure

- (1) Look for unwanted material that can prevent the movement of the seat.
 - (a) If you find unwanted material, then do these steps:
 - 1) Remove the unwanted material.
 - 2) Push the seat back release button.
 - 3) Move the seat back forward and aft.
 - 4) If the seat moved correctly, then you corrected the fault.
 - (b) If you do not find unwanted material, then continue.
- (2) Replace the seat.

These are the tasks:

Passenger Seat Removal, AMM TASK 25-22-00-000-801,

Passenger Seat Installation, AMM TASK 25-22-00-400-802.

- (a) Push the seat back release button.
- (b) Move the seat back forward and aft.
- (c) If the back of the seat moves, then you corrected the fault.

————— END OF TASK —————



FAULT ISOLATION MANUAL

801. Passenger Service Unit Problem - Fault Isolation

A. Description

- (1) This task is for these passenger service unit (PSU) problems:
 - (a) The PSU does not close correctly.
 - (b) The PSU is loose.
 - (c) The PSU air outlet is inoperative.

B. Possible Causes

- (1) The PSU does not close correctly if:
 - (a) The gasper air hose is out of its position.
 - (b) The wire bundle or other object is in the way.
 - (c) The spacer panel is not adjusted correctly.
 - (d) The latch assembly is worn or does not operate correctly.
- (2) The PSU is loose if:
 - (a) Unwanted material is in the door, latch, or hinge area.
 - (b) The latch mechanism is worn or does not operate correctly.
 - (c) The springs are worn or do not operate correctly.
 - (d) The spacer panel is not aligned correctly.
- (3) The PSU air outlet is inoperative if:
 - (a) Unwanted material is present.
 - (b) The air outlet is worn.

C. Initial Evaluation

- (1) Do this check of the passenger service unit:
 - (a) Make sure that the passenger service unit panel opens and closes correctly.
 - 1) If it does not close correctly, then do the Fault Isolation Procedure - Passenger Service Unit Panel Does Not Close Correctly.
 - (b) Make sure that the passenger service unit is not too loose.
 - 1) If it does not fit correctly, then do the Fault Isolation Procedure - Passenger Service Unit Is Loose.
 - (c) Make sure that the passenger service unit air outlet operates correctly:
 - 1) Make sure that air flows through the outlet.
 - 2) Make sure that the outlet is adjustable.
 - 3) If the air outlet does not operate correctly, then do the Fault Isolation Procedure - Passenger Service Unit Air Outlet Is Inoperative.

D. Fault Isolation Procedure - Passenger Service Unit Panel Does Not Close Correctly

- (1) Make sure the gasper air hose is in its correct position.
 - (a) If the passenger service unit closes correctly, then you corrected the fault.
 - (b) If the passenger service unit does not close correctly, then continue.
- (2) Make sure that the wire bundle or other objects are not blocking the movement of the passenger service unit.



25-23 TASK 801

FAULT ISOLATION MANUAL

- (a) If the passenger service unit closes correctly, then you corrected the fault.
- (b) If the passenger service unit does not close correctly, then continue.
- (3) Adjust the adjacent spacer panels. To adjust the panels, do this task: Passenger Service Unit (PSU) Adjustment, AMM TASK 25-23-61-820-801.
 - (a) If the PSU closes correctly, then you corrected the fault.
 - (b) If the PSU does not close correctly, then continue.
- (4) Replace the springs.
 - (a) Open and close the PSU three to five times.
 - (b) If the PSU closes correctly, then you corrected the fault.
 - (c) If the PSU does not close correctly, then continue.
- (5) Replace the latch assemblies.
 - (a) Open and close the PSU three to five times.
 - (b) If the PSU closes correctly, then you corrected the fault.
 - (c) If the PSU does not close correctly, then continue.

E. Fault Isolation Procedure - Passenger Service Unit Panel Is Loose

- (1) Adjust the adjacent spacer panels. To adjust the panels, do this task: Passenger Service Unit (PSU) Adjustment, AMM TASK 25-23-61-820-801.
 - (a) If the PSU panel closes correctly, then you corrected the fault.
 - (b) If the PSU does not close correctly, then continue.
- (2) Replace the springs, as necessary.
 - (a) Open and close the PSU three to five times.
 - (b) If the PSU closes correctly, then you corrected the fault.
 - (c) If the PSU does not close correctly, then continue.
- (3) Replace the latch assemblies, as necessary.
 - (a) Open and close PSU three to five times.
 - (b) If the PSU closes correctly, then you corrected the fault.
 - (c) If the PSU does not close correctly, then continue.
- (4) Make sure that unwanted material is not caught in the door, latch, or hinge area.
 - (a) If unwanted material is present, then remove this material and make sure that the door closes correctly.
 - (b) If the door closes correctly, then you corrected the fault.

F. Fault Isolation Procedure - Passenger Service Unit Air Outlet Is Inoperative.

- (1) If unwanted material is present, then remove this material and make sure that the outlet operates correctly.
 - (a) If the air outlet operates correctly, then you corrected the fault.
 - (b) If the PSU does not close correctly, then continue.
- (2) Replace the air outlet.
 - (a) If the air outlet operates correctly, then you corrected the fault.

END OF TASK**25-23 TASK 801**



737-600/700/800/900

FAULT ISOLATION MANUAL

801. Overhead Stowage Bin Problem - Fault Isolation

A. Description

- (1) This task is for these overhead stowage bin problems:
 - (a) The overhead stowage bin door does not open correctly.
 - (b) The overhead stowage bin door does not close correctly.
 - (c) The overhead stowage bin door needs adjustment.

B. Possible Causes

- (1) The overhead stowage bin door does not open correctly if:
 - (a) The latch assembly is worn or does not operate correctly.

HAP 001-013, 015-026, 028-030

- (b) The actuator does not operate correctly.

HAP ALL

- (2) The overhead stowage bin door does not close correctly if:
 - (a) Unwanted material is in the door, latch, or hinge area.
 - (b) The latch mechanism is not aligned correctly with the strike assembly.
 - (c) The latch mechanism is worn or does not operate correctly.

HAP 001-013, 015-026, 028-030

- (d) The actuator is worn or does not operate correctly.

HAP ALL

- (3) Adjustment of the overhead stowage bin door can become necessary after the door is opened and closed many times.

C. Initial Evaluation

- (1) Do this check of the overhead stowage bin door:
 - (a) Make sure that the stowage bin door opens correctly.
 - 1) If it does not open correctly, then do the Fault Isolation Procedure below - Overhead Stowage Bin Door Does Not Open Correctly.
 - (b) Make sure that the stowage bin door closes correctly.
 - 1) If it does not close correctly, then do the Fault Isolation Procedure below - Overhead Stowage Bin Door Does Not Close Correctly.
 - (c) Do this check of the stowage bin door adjustment:
 - 1) Make sure there is approximately the same space at each end of the stowage bin door when the door is closed.
 - 2) Make sure the stowage bin door aligns with the adjacent stowage bin doors when the doors are open.
 - 3) If the stowage bin door is not adjusted correctly, then do the Fault Isolation Procedure below - Overhead Stowage Bin Door Adjustment.

D. Fault Isolation Procedure - Overhead Stowage Bin Door Does Not Open Correctly

- (1) To open the overhead stowage bin door when the latch mechanism does not operate correctly, do this task: Overhead Stowage Bin Door Latch - Alternate Release Method, AMM TASK 25-24-36-820-801.

EFFECTIVITY

HAP ALL

25-24 TASK 801

FAULT ISOLATION MANUAL

- (a) Open and close the stowage bin door three to five times.
 - (b) If the stowage bin door opens correctly, then you corrected the fault.
 - (c) If the stowage bin door does not open correctly, then continue.
- (2) Replace the latch assembly.

These are the tasks:

Overhead Stowage Bin Latch Assembly Removal, AMM TASK 25-24-36-000-803,

Overhead Stowage Bin Latch Assembly Installation, AMM TASK 25-24-36-400-804.

- (a) Open and close the stowage bin door three to five times.
- (b) If the stowage bin door opens correctly, then you corrected the fault.

HAP 001-013, 015-026, 028-030

- (c) If the stowage bin door does not open correctly, then continue.

- (3) Replace the actuator.

These are the tasks:

Standard Stowage Bin Door Actuator Removal, AMM TASK 25-24-36-020-801,

Standard Stowage Bin Door Actuator Installation, AMM TASK 25-24-36-400-801.

- (a) Open and close the stowage bin door three to five times.
- (b) If the stowage bin door opens correctly, then you corrected the fault.

HAP ALL**E. Fault Isolation Procedure - Overhead Stowage Bin Door Does Not Close Correctly**

- (1) Make sure that unwanted material is not caught in the door, latch, or hinge area.
 - (a) If unwanted material is present, then remove this material and make sure that the door opens and closes.
 - (b) If the door closes correctly, then you corrected the fault.
 - (c) If the door does not close correctly, then continue.
- (2) It is possible that the latch mechanism is not aligned with the strike assembly, or the latch is worn.
 - (a) To make a small adjustment to align the latch mechanism with the strike assembly, do this task: Overhead Stowage Bin Door Adjustment - Closed Position, AMM TASK 25-24-36-820-802.
 - (b) If the door closes correctly, then you corrected the fault.
 - (c) If the door does not close correctly, then continue.
 - (d) Replace the latch mechanism.

These are the tasks:

Overhead Stowage Bin Latch Assembly Removal, AMM TASK 25-24-36-000-803,

Overhead Stowage Bin Latch Assembly Installation, AMM TASK 25-24-36-400-804.
 - (e) If the door closes correctly, then you corrected the fault.
 - (f) If the door does not close correctly, then continue.
 - (g) Remove and install the stowage bin.

These are the tasks:

Overhead Stowage Bin Removal, AMM TASK 25-24-31-020-801,

**25-24 TASK 801**



737-600/700/800/900

FAULT ISOLATION MANUAL

Overhead Stowage Bin Installation, AMM TASK 25-24-31-400-801.

- (h) If the door closes correctly, then you corrected the fault.

HAP 001-013, 015-026, 028-030

- (i) If the door does not close correctly, then continue.

- (3) Replace the actuator.

These are the tasks:

Standard Stowage Bin Door Actuator Removal, AMM TASK 25-24-36-020-801,

Standard Stowage Bin Door Actuator Installation, AMM TASK 25-24-36-400-801.

- (a) If the door closes correctly, then you corrected the fault.

HAP ALL

F. Fault Isolation Procedure - Overhead Stowage Bin Door Adjustment

- (1) To adjust the stowage bin door so that there is the same space at each end of the door, do this task: Overhead Stowage Bin Door Adjustment - Closed Position, AMM TASK 25-24-36-820-802.
- (2) To adjust the stowage bin door so that the door aligns with the adjacent stowage bin doors when the doors are open, do this task: Overhead Stowage Bin Door Adjustment - Open Position, AMM TASK 25-24-36-820-803.

————— END OF TASK —————



FAULT ISOLATION MANUAL

801. Inoperative Galley Power - Fault Isolation**A. Description**

- (1) This task is for no galley power.
 - (a) The Galley Power Switch or Cabin/Util Switch is located on the P5-13 module provides power control to all of the galleys through the Bus Power Control Unit (BPCU).
 - (b) The BPCU will automatically remove power to the galleys by de-energizing the Load Shed Relays when an overcurrent condition is sensed.
 - (c) The BPCU is located on the E4-2 rack in the Electronic Equipment Area.
 - (d) The Load Shed Relays are located in the back of the P91 and P92 Power Distribution Panels.
 - (e) The Galley Power Switch or Cabin/Util Switch is located on the P5-13 module on the P5 overhead panel in the Flight Compartment.

B. Possible Causes

- (1) Load Shed Relays
- (2) Bus Power Control Unit, G15
- (3) Galley Power or Cabin/Util Control Switch (S4), P5-13
- (4) Wiring

C. Circuit Breakers

- (1) These are the primary circuit breakers related to the fault:

Power Distribution Panel Number 1, P91

Row	Col	Number	Name
C	7	C01288	GEN 1 LOAD SHED
HAP 037-054, 101-999			
F	7	C00913	GALLEY BUS C
HAP ALL			
F	8	C00915	GALLEY BUS D

Power Distribution Panel Number 2, P92

Row	Col	Number	Name
C	7	C01289	GEN 2 LOAD SHED
HAP 001-013, 015-026, 028-054, 107-999			
F	7	C00912	GALLEY BUS A
HAP 001-013, 015-026, 028-030			
F	7	C00914	GALLEY BUS B
HAP 031-054, 101-999			
F	8	C00914	GALLEY BUS B
HAP ALL			

D. Related Data

- (1) (SSM 24-28-41)
- (2) (SSM 24-51-11)
- (3) (SSM 24-51-21)

**25-31 TASK 801**



737-600/700/800/900

FAULT ISOLATION MANUAL

(4) (SSM 24-61-11)

(5) (SSM 25-31-11)

(6) (WDM 24-28-41)

(7) (WDM 24-51-11)

(8) (WDM 24-51-21)

(9) (WDM 24-61-11)

(10) (WDM 25-31-11)

E. Initial Evaluation

(1) Make sure that the power source supplies sufficient power for the equipment available in the galley.

NOTE: If the power source is not sufficient, then load shedding of the galley (the automatic removal of electrical power) will occur.

(2) Do this check for power in each galley:

(a) Set all switches in the galley to the ON position.

(3) If there is no power available in the galley, then do the Fault Isolation Procedure below.

(4) If there is power available in the galley, then there was an intermittent fault.

F. Fault Isolation Procedure

(1) Do this check of the galley power system:

(a) Set the Galley Power or Cabin/Util Switch on the P5-13 module to the OFF position.

(b) Open these circuit breakers:

Power Distribution Panel Number 1, P91

Row	Col	Number	Name
C	7	C01288	GEN 1 LOAD SHED

Power Distribution Panel Number 2, P92

Row	Col	Number	Name
C	7	C01289	GEN 2 LOAD SHED

(c) Disconnect the applicable galley power connector (WDM 25-31-11).

NOTE: Do not let the connector touch the airplane structure/ground.

(d) Close these circuit breakers:

Power Distribution Panel Number 1, P91

Row	Col	Number	Name
C	7	C01288	GEN 1 LOAD SHED

Power Distribution Panel Number 2, P92

Row	Col	Number	Name
C	7	C01289	GEN 2 LOAD SHED

(e) Set the Galley Power or Cabin/Util Switch on the P5-13 module to the ON position.



25-31 TASK 801

FAULT ISOLATION MANUAL

- (f) Do a check for 3-phase 115 VAC from pins A, B, and C to pin D on the connector that was removed from the galley.
 - 1) If 3-phase 115 VAC is present, then the problem is in the galley.
 - a) If there is a problem with power in the galley, then use the standard method of your airline to correct this fault.
 - 2) If 3-phase 115 VAC is not present, then continue.
 - (g) Set the Galley Power or Cabin/Util Switch to the OFF position.
 - (h) Remove external power. To remove external power, do this task: Remove External Power, AMM TASK 24-22-00-860-814.
 - (i) Re-connect the galley power connector to the galley.
- (2) Do the Bus Power Control Unit (BPCU) BITE procedure. To do this procedure, do this task: Bus Power Control Unit BITE Procedure, 24-41 TASK 801.
- (a) If no faults are detected, then continue.
 - (b) If a fault is detected, then do the fault isolation task for the applicable maintenance message.
 - (c) Do the Repair Confirmation at the end of this task.
 - (d) If the repair confirmation is not satisfactory, then continue.
- (3) Replace the applicable Load Shed Relay (WDM 24-51-11), (WDM 24-51-21).

These are the tasks:

Load Shed Relay Removal, AMM TASK 24-51-11-000-801,

Load Shed Relay Installation, AMM TASK 24-51-11-400-801.

- (a) Do the Repair Confirmation at the end of this task.

- (b) If the repair confirmation is not satisfactory, then continue.

- (4) Replace the Galley Power or Cabin/Util Switch (S4). To replace this switch, replace the P5-13 Module.

These are the tasks:

Electrical Meters, Battery and Galley Power Module Removal, AMM TASK 24-21-53-000-801,

Electrical Meters, Battery and Galley Power Module Installation, AMM TASK 24-21-53-400-801.

- (a) Do the Repair Confirmation at the end of this task.

- (b) If the repair confirmation is not satisfactory, then continue.

- (5) Do these checks of the wiring:

- (a) Do a check of the wiring between the Transformer Rectifier Units and the Generator Load Shed Circuit Breakers C1288 and C1289 (WDM 24-61-11).

- 1) If you find a problem with the wiring, then do these steps:

- a) Repair the wiring.

- b) Do the Repair Confirmation at the end of this task.

- 2) If you do not find a problem with the wiring, then continue.

- (b) Do a check of the wiring between the pins of the Galley Power or Cabin/Util Switch (S4) in the P5-13 module and the Bus Power Control Unit (G15) (WDM 24-28-41).

- 1) If you find a problem with the wiring, then do these steps:



25-31 TASK 801

Page 203

Feb 15/2008



737-600/700/800/900

FAULT ISOLATION MANUAL

- a) Repair the wiring.
- b) Do the Repair Confirmation at the end of this task.
- 2) If you do not find a problem with the wiring, then continue.
- (c) Do a check of the wiring between the pins of the Bus Power Control Unit (G15) and the Load Shed Relays (WDM 24-51-11), (WDM 24-51-21), (WDM 24-28-41).
 - 1) If you find a problem with the wiring, then do these steps:
 - a) Repair the wiring.
 - b) Do the Repair Confirmation at the end of this task.
 - 2) If you do not find a problem with the wiring, then continue.
- (d) Do a check of the wiring between the galley bus circuit breakers and the galley connector (WDM 25-31-11).
 - 1) If you find a problem with the wiring, then do these steps:
 - a) Repair the wiring.
 - b) Do the Repair Confirmation at the end of this task.

G. Repair Confirmation

- (1) Do these steps:
 - (a) Set the Galley Power or Cabin/Util Switch to the ON position.
 - (b) Set all switches in the galley to the ON position.
 - (c) If power is available in the galley, then you corrected the fault.

————— END OF TASK ————



25-31 TASK 801

FAULT ISOLATION MANUAL

801. Lavatory Waste Chute Door Problem - Fault Isolation

A. Description

- (1) This task is for this lavatory waste chute door problems:
 - (a) The waste chute door is misaligned.

B. Possible Causes

- (1) Unwanted material in the chute door.
- (2) Damaged spring.
- (3) Damaged hinge components.
- (4) Damaged chute door.

C. Initial Evaluation

- (1) Do this check of the waste chute door:
 - (a) Depress waste chute door and release.
 - (b) If the chute door does not move or align correctly, then do the Fault Isolation Procedure below.
 - (c) If the chute door opens and closes correctly, then there was an intermittent fault.

D. Fault Isolation Procedure

- (1) To look for unwanted material that can prevent the movement of the waste chute door, do this task: Lavatory Waste Compartment Inspection, AMM TASK 25-40-08-200-801.
 - (a) If you find unwanted material, then do these steps:
 - 1) Remove the unwanted material.
 - 2) Depress the waste chute door and release.
 - a) If the waste chute door operates correctly, then you corrected the fault.
 - (b) If you do not find unwanted material, then continue.
- (2) Examine the spring for the waste chute door.
 - (a) If the spring is broken, then do these steps:
 - 1) Replace the spring.
 - 2) Depress the waste chute door and release.
 - a) If the waste chute door is aligned and operates correctly, then you corrected the fault.
 - (b) If the spring is not broken, then continue.
- (3) Examine the hinge for the waste chute door.
 - (a) If the hinge is damaged or has parts missing, then do these steps:
 - 1) Replace the hinge.
 - 2) Depress waste chute door and release.
 - a) If the waste chute door is aligned and operates correctly, then you corrected the fault.
- (4) Examine the waste chute door.
 - (a) If waste chute door is bent, then do these steps:
 - 1) Replace the waste chute door.



25-40 TASK 801



737-600/700/800/900

FAULT ISOLATION MANUAL

- 2) Depress waste chute door and release.
 - a) If the waste chute door is aligned and operates correctly, then you corrected the fault.

————— END OF TASK —————



25-40 TASK 801

Page 202
Feb 10/2005

D633A103-HAP



737-600/700/800/900

FAULT ISOLATION MANUAL

801. Aft Cargo Loader Relay - Fault Isolation

A. Description

- (1) This task is for this PSEU maintenance message:
 - (a) 52-76002 AFT LDR RLY FLT
- (2) The proximity switch electronics unit (PSEU) gives a ground to the enable relay for the aft cargo loader when the airplane is on the ground and the aft cargo door is open.
- (3) This maintenance message can show during the PSEU BITE test or LRU test when the PSEU does not find 28 VDC from the enable relay for the aft cargo loader.

B. Possible Causes

- (1) Aft cargo loader enable relay, R489
- (2) Wiring problem
- (3) Proximity switch electronics unit (PSEU), M2061

C. Circuit Breakers

- (1) These are the primary circuit breakers related to the fault

F/O Electrical System Panel, P6-11

Row	Col	Number	Name
D	8	C01139	AFT CARGO LOADER CONT

D. Related Data

- (1) (SSM 25-51-21)
- (2) (WDM 25-51-21)

E. Initial Evaluation

- (1) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801.
 - (a) If the maintenance message does not show, then there was an intermittent fault.
 - (b) If the maintenance message shows, then do the Fault Isolation Procedure below.

F. Fault Isolation Procedure

- (1) Do this check for 28 VDC at the enable relay for the aft cargo loader:

- (a) Remove the enable relay for the aft cargo loader, R489.

NOTE: The R489 relay is on the P91 power distribution panel in the EE bay.

- (b) Do a check for 28 VDC between pin X1 of connector D176 for the R489 relay and structure ground.

- (c) If there is not 28 VDC at pin X1 of D176, then do these steps:

- 1) Do a wiring check between these pins of connector D176 for the R489 relay and the AFT CARGO LOADER CONT circuit breaker, C1139:

D176	C1139
pin X1	----- term L

- 2) Repair the problem that you find.
 - 3) Re-install the enable relay for the aft cargo loader, R489.

EFFECTIVITY
HAP 001-013, 015-026, 028-049, 051-053, 101-999

25-51 TASK 801



737-600/700/800/900

FAULT ISOLATION MANUAL

- 4) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801.
 - a) If the maintenance message does not show, then you corrected the fault.
- (d) If there is 28 VDC at pin X1 of D176, then continue.
- (2) Install a new enable relay for the aft cargo loader, R489.
 - (a) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801.
 - 1) If the maintenance message does not show, then you corrected the fault.
 - 2) If the maintenance message shows, then continue.
- (3) Do this check of the wiring:
 - (a) Remove the enable relay for the aft cargo loader, R489.
 - (b) Disconnect connector D10986 from the PSEU.
 - (c) Do a wiring check between these pins of connector D10986 at the PSEU and connector D176 at the P91 panel:

D10986	-----	D176
pin 54	-----	pin X2
- (d) If you find a problem with the wiring, then do these steps:
 - 1) Repair the wiring.
 - 2) Re-install the enable relay for the aft cargo loader, R489.
 - 3) Re-connect connector D10986 to the PSEU.
 - 4) Do this task: Proximity Switch Electronics Unit (PSEU) BITE Procedure, 32-09 TASK 801.
 - a) If the maintenance message does not show, then you corrected the fault.
- (e) If you do not find a problem with the wiring, then re-install the enable relay for the aft cargo loader, R489 and continue.

- (4) Replace the PSEU, M2061.

These are the tasks:

Proximity Switch Electronics Unit (PSEU) Removal, AMM TASK 32-09-10-000-801,

Proximity Switch Electronics Unit (PSEU) Installation, AMM TASK 32-09-10-400-801.

- (a) If the maintenance message does not show during the PSEU replacement test, then you corrected the fault.

————— END OF TASK —————

EFFECTIVITY
HAP 001-013, 015-026, 028-049, 051-053, 101-999

25-51 TASK 801

801. Escape Rope (Escape Lanyard) Compartment Cover Will Not Close - Fault Isolation**A. Description**

- (1) This task is for a cover that will not close on the compartment containing the escape rope (escape lanyard) installed:
 - (a) Above the captain's seat.
 - (b) Above the first officer's seat.

B. Possible Causes

- (1) Escape rope not stowed correctly

C. Initial Evaluation

- (1) To make sure the escape rope is stowed correctly, do this task: Flight Compartment Escape Rope Inspection, AMM TASK 25-61-10-210-801.
- (2) If the escape rope is not stowed correctly, then do the Fault Isolation Procedure below.

D. Fault Isolation Procedure

- (1) Install the escape rope. To install the escape rope, do this task: Flight Compartment Escape Rope Installation, AMM TASK 25-61-10-400-801.

END OF TASK

802. Damaged Escape Rope (Escape Lanyard) - Fault Isolation**A. Description**

- (1) This task is for a damaged escape rope (escape lanyard) installed in the flight compartment:
 - (a) Above the captain's seat.
 - (b) Above the first officer's seat.
- (2) Damage to an escape rope can occur if:
 - (a) There are knots in the escape rope.
 - (b) The escape rope is wet when stowed in its compartment.
 - (c) The anchor plate in the escape rope compartment is loose or shows corrosion.
 - (d) The anchor fitting in the escape rope compartment is bent or shows corrosion.
 - (e) The anchor fitting is not correctly engaged in the detent at the center of the anchor plate.
 - (f) The escape rope is not correctly coiled and stowed in its compartment.
 - (g) The escape rope compartment cover is not closed.

B. Initial Evaluation

- (1) To examine the escape rope for damage, do this task: Flight Compartment Escape Rope Inspection, AMM TASK 25-61-10-210-801.
 - (a) If the escape rope is damaged, then do the Fault Isolation Procedure below.

C. Fault Isolation Procedure

- (1) Replace the escape rope.

These are the tasks:

Flight Compartment Escape Rope Removal, AMM TASK 25-61-10-000-801,

**25-61 TASKS 801-802**

FAULT ISOLATION MANUAL

Flight Compartment Escape Rope Installation, AMM TASK 25-61-10-400-801.

END OF TASK

803. Unstowed Escape Rope (Escape Lanyard) - Fault Isolation**A. Description**

- (1) This task is for an unstowed escape rope (escape lanyard) installed:
 - (a) Above the captain's seat.
 - (b) Above the first officer's seat.

B. Initial Evaluation

- (1) To make sure the escape rope is correctly stowed, do this task: Flight Compartment Escape Rope Inspection, AMM TASK 25-61-10-210-801.
 - (a) If the escape rope is not correctly stowed, then do the Fault Isolation Procedure below.

C. Fault Isolation Procedure

- (1) Install the escape rope. To install the escape rope, do this task: Flight Compartment Escape Rope Installation, AMM TASK 25-61-10-400-801.

END OF TASK

805. Unstowed Emergency Exit Hatch Lifeline (Escape Strap) - Fault Isolation**A. Description**

- (1) This task is for an unstowed emergency exit hatch lifeline (escape strap) installed in the passenger cabin near the emergency exit.
- (2) The lifeline is installed in a stowage tube. Damage can occur if:
 - (a) The cloth cover that holds the hook and lifeline is damaged or missing.
 - (b) The lifeline is wet when stowed in its stowage tube.
 - (c) The anchor plate in the stowage tube is loose or shows corrosion.
 - (d) The lifeline is not correctly folded and stowed in its compartment.

B. Initial Evaluation

- (1) To make sure the lifeline is correctly stowed, do this task: Emergency Exit Door Life Line Check, AMM TASK 25-61-10-710-801.
 - (a) If the lifeline is not correctly stowed, then do the Fault Isolation Procedure below.

C. Fault Isolation Procedure

- (1) Install the lifeline. To install the lifeline, do this task: Emergency Exit Door Life Line Installation, AMM TASK 25-61-10-400-802.

END OF TASK

**25-61 TASKS 802-805**



737-600/700/800/900

FAULT ISOLATION MANUAL

801. Procedure by Airline Method - Fault Isolation

A. Initial Evaluation

NOTE: Use the standard method of your airline to correct this fault.

————— END OF TASK —————

