

# **Fault Location: General**

---

## **Introduction**

---

Maintenance is intended as the actions which, in presence of alarm conditions, enable to locate the faulty unit and replace it with a spare one as soon as possible.

A fault in the equipment is indicated with an optical alarm on the front of the faulty unit, the issue of ground alarm contact to the exchange and the display of the alarm on the Local Controller and NMC.

The procedures to follow in case of a fault are explained in the volume 2 ” Local Controller Handbook ” in the chapter ” Fault Detection Procedure ”, which have alarm messages and alarm sources as entry points.

For each alarm the procedures to locate faults as well the action to take to restore service are described.

PAGE INTENTIONALLY LEFT BLANK