
Chapter Descriptions

1 Product Information

Contains printer features and product overview, tray capacities and sizes, media specifications, service approach, and how to get technical assistance.

2 Site Requirements

Contains space and environmental requirements.

3 Operating Overview

Contains details about control panel menus, restoring factory defaults, and resetting and testing the printer.

4 Maintenance and Adjustments

Contains cleaning and preventive maintenance information, and adjustment procedures for Tray 2, Tray 3, and Tray 4.

5 Functional Overview

Contains block diagrams and basic theory of operation for the printer systems, paper paths, and paper handling accessories.

6 Removal and Replacement

Contains step-by-step procedures for replacing field replaceable units (FRUs) in the printer, 2000-Sheet Input Unit, Multi-Bin Mailbox, and the Mailbox with Stapler.

7 Troubleshooting

Contains a preliminary troubleshooting table, a table with descriptions and recommended actions for all control panel messages, image defect samples, and troubleshooting checks and tools.

8 Parts and Diagrams

Contains exploded view drawings and part number listings for all replaceable parts in the printer, 2000-Sheet Input Unit, Multi-Bin Mailbox, and Mailbox with Stapler.

A Parts Index

Contains two replaceable parts tables: one sorted alphabetically by part name, and one sorted numerically by part number. Both tables are cross referenced to the diagrams in Chapter 8.

B I\O Information

Contains basic cabling and configuration information for connecting the printer to supported networks.

C Regulatory Information

Contains required safety and compliance statements.

Subject Index

Contains an alphabetical, cross referenced listing of information found in the main body of the manual.

Index

- !**
2000-sheet input unit
 components 5-23
 operation 5-26
 see "tray 4 " 6-67
- A**
ac access cover 6-19
ac power distribution 5-6
accessories
 user installable 6-7
accessories and options
 1-17
acoustic emissions 1-10
adding
 memory 6-7
 personalities 6-7
adhesive labels 1-12
anti-static wrist wrap 6-7
- B**
back cover 6-20
black lines 7-67
blank (white) page 7-64
bubble print 7-71
- C**
cartridge slots 1-3
character voids 7-70
cleaning
 printer 4-3
 spilled toner 4-5
clutches 5-10
cold reset 3-6
 printer memory 3-28
cold reset default
 paper size 3-22
components
 2000-sheet input unit
 (tray 4) 5-23
 multi-bin mailbox 5-28
 configuration menu
 3-13
consumables
 printer 1-22
control panel 3-3, 6-18
- configuration menu
 3-13
 features 1-3, 3-3
 I/O menu 3-17
 job menu 3-11
 keys 3-3
 layout 3-3
 lights 3-4
 menu map 3-9
 menus 3-8
 MIO 1 and 2 menus
 3-18
 printing menu 3-5
 selecting a menu 3-8
 setting defaults 3-5
 test menu 3-12
 tray menu 3-10
covers 6-19
 ac access 6-19
 back 6-20
 front 6-21
 lower left 6-23
 top 6-24
- D**
dc controller system 5-10
default settings 3-5
defaults
 factory 3-5
delivery unit 6-26
detector
 toner cartridge 5-7
determining memory
 requirements 1-20
dimensions, printer 1-8
disk drive
 replacing 6-8
display language 3-6
diverter assembly 6-28
documentation, related
 1-24
door assembly
 diverter 6-29
 right lower 6-30
draft mode
 see EconoMode 5-9
dropout 7-67
drum cleaning 5-14
drum conditioning 5-15
drum rotation functional
 check 7-75
duplex printing 5-39
duplex unit
 paper paths 5-20
 replacing 6-10
Duty Cycle 1-28
- E**
EconoMode 1-3, 5-9
electrical specifications
 1-9
electrostatic discharge sensitive
 (ESD) 6-5
emissions
 acoustic 1-10
engine test 7-8
 button location 7-8
 printing 7-8
engine test microswitch
 5-11
envelope feeder
 paper paths 5-20
 replacing 6-11
envelope specifications
 1-11
environment, operating
 2-3
environmental requirements
 2-4
ESD caution 6-5
exchange program 1-21
exhaust
 fan 1 6-32
 fan 3 6-35
 fan 4 6-36
exhaust
 fan 2 6-34
external paper handling
 controller
 replacing 6-12
- F**
factory defaults 3-5
 settings list 3-7
factory settings
 restoring 3-6
fan 1 6-32
fan 1 housing 6-32
fan 1 housing assembly
 6-32
fan 1 motor 6-33
fan 2 (lvps) 6-34
fan 3 (formatter) 6-35
fan 3 housing 6-35
fan 3 housing assembly
 6-35
fan 3 motor 6-35
fan 4 (delivery unit)
 6-36
fan motors 5-11
faulty image examples
 7-16, 7-63
faulty registration 7-70
fax information service (HP

FIRST)	1-25	image defects		memory	
features	1-3	black lines	7-67	printer	1-3
control panel	1-3	blank (white) page	7-64	upgrade	6-7
feed roller		bubble print	7-71	memory requirements	1-20
tray 1	6-58	character voids	7-70	menu map	3-9
tray 2	6-60	dropout	7-67	menus	
tray 3	6-60	faulty registration	7-71	control panel	3-8
feeder assembly	6-37	improperly formed		selecting	3-8
fonts		characters	7-70	Menus, key	3-3
internal	1-3	line at edge of paper	7-69	MIO	
formatter assembly	6-39	partial blank page	7-72	Jet Direct	1-3
formatter system	5-8	repetitive defects	7-69	MIO 1 and 2 menus	3-18
front cover	6-21			model number	1-7
functional block diagram	5-4	image formation		motors	5-11
functional overview	5-1 - 5-42	system	5-12	fan	5-11, 6-33,
fusing assembly	6-41	troubleshooting	7-63	6-35	
G		image skew	7-71	main	5-11
guidelines		image skew		main assembly	6-46
media selection	1-11	specification	7-81	scanner	5-11
H		indicator lights	3-4	tray 2 & 3 pick-up	5-11
half self test functional		input sources	5-38	multi-bin mailbox	6-80
check	7-74	interfaces		blind cover	6-98
hardware table	6-16	standard	1-3	components	5-28
high voltage power		internal typefaces	1-3	covers	6-80
distribution	5-7	Items, key	3-3	delivery head assembly	
high voltage power supply		J		6-81	
6-54		job menu	3-11	encoder assembly	6-96
high-voltage power supply		L		flipper assembly	6-83
check	7-76	labels, adhesive	1-12	input paper guide	6-85
HPASAP	1-25	languages		interlock switch	6-86
HPAUDIO-TIPS	1-25	setting the display	3-6	jam access door assembly	6-87
HP CompuServe Forum	1-26	languages, printer	1-3	lower elevator pulley	
HP FIRST (Fax Information		laser drive	5-10	assemblies	6-90
Retrieval Support		laser/scanner		metallic tape and housing	
Technology)	1-25	assembly	6-42	assembly	6-92
HP Reseller Sales and Service		fan	6-32	motor	6-96
Support Line	1-26	left cover	6-23	motor, delivery head position	
HP's Distribution Center	1-21	lights		6-95	
HPD, HP's Distribution		control panel	3-4	operation	5-31
Center	1-21, 1-24	low voltage power distribution		paper bins	6-98
hyps	5-7	system	5-5	paper paths	5-28
see "high voltage power		low voltage power supply	5-6, 6-55	PCA, controller	6-99
supply"	6-54	lower left cover	6-23	replacing	6-14
I		lvps	5-5	strings, anti-curl	6-100
I/O menu	3-17	see "low voltage power		transport belt	6-96
identification, printer	1-7	supply"	6-55	N	
image		M		NARC	1-26
developing	5-17	main gear assembly	6-43	North American Response	
fusing	5-19	main motor	5-11	Center (NARC)	1-26
transferring	5-18	main motor assembly	6-46	O	
writing	5-16	maintenance	4-1 - 4-10	On Line key	3-3
image defaults		preventive	4-6	operating	
white stripes	7-71	maintenance count, setting	3-21, 6-40	environment	2-3
		media selection guidelines	1-11	optional printer memory	1-3
		media separation	5-18	ordering	
				parts	1-21
				related documentation	1-24
				overcurrent protection	5-6

- overhead transparency specifications 1-12
- overvoltage protection 5-6
- P**
- page count
 - setting 3-21, 6-40
 - verification 3-19
- page usage, monthly 1-3
- paper capacities 1-4
- paper curl 7-85
- paper input unit
 - sensor 6-61
- paper input unit (PIU) 6-47
- paper jam detection 5-40
- paper jams 7-77
- paper motion
 - monitoring and control 5-10
- paper paths
 - 2000-sheet input unit 5-23
 - duplex unit 5-20
 - envelope feeder 5-20
 - multi-bin mailbox 5-28
- printer 5-20
- paper paths and components 5-20
- paper size switches 5-38
- paper sizes 1-4
- paper specifications 1-11
- parts
 - HPD 1-24
 - ordering 1-21
- PDO, Parts Direct Ordering 1-24
- SME, Support Materials Europe 1-24
- parts and diagrams 8-1 - 8-32
 - pca
 - dc controller 6-48
 - output paper sensor 6-49
- paper size 6-52
- PCL configuration page 3-23
- PDO, Parts Direct Ordering 1-24
- personality
 - upgrade 6-7
- phone numbers
- parts sources 1-21
 - technical assistance 1-25
- photosensitive drum 5-13
 - cleaning 5-14
 - conditioning 5-15
- pick-up motor 5-11
- pickup roller
 - tray 2 6-60
 - tray 3 6-60
- PIU
 - See "paper input unit" 6-47
- power control 1-3
- power distribution system 5-5
- power save 5-8
- power save mode 1-3, 1-9, 3-22
- power supply
 - high voltage 6-54
 - low voltage 6-55
- preventive maintenance 4-6
- print capacity, toner 1-22
- print density adjustment 5-7
- print media
 - shipping 1-13
 - specifications 1-11
 - storing 1-13
- print quality
 - cleaning printer 4-3
 - HP LaserJet toner cartridges 1-23
 - refilled toner cartridges 1-23
 - transfer roller 4-3
- print resolution 1-3
- print speed 1-3
- printer
 - accessories and options 1-17
 - adjustments 4-1 - 4-10
 - cleaning 4-3
 - external view 1-14
 - fonts 1-3
 - formatter assemblies 1-16
 - functional block diagram 5-4
 - functionality 5-3
 - identification 1-7
 - input sources 5-38
 - maintenance 4-1 - 4-10
 - model number 1-7
 - optional memory 1-3
- paper paths 5-20
 - serial number 1-7
 - specifications 1-8
 - standard memory 1-3
 - testing 3-23
 - timing 5-40
- printer dimensions 1-8
- printer features 1-3
 - comparison 1-3
- printer information 1-1 - 1-28
- printer languages 1-3
- printer space requirements 2-4
- printing
 - from the envelope feeder 5-39
 - from tray 1 5-39
 - from tray 2 5-38
 - from tray 3 5-38
 - from tray 4 5-39
 - two-sided 5-39
- printing menu 3-5
 - default settings 3-5
- product information 1-1 - 1-28
- product overview 1-14
- PS1
 - see "registration sensor" 6-62
- PS2
 - see "paper input unit sensor" 6-61
- R**
- recycling toner cartridges 1-23
- reference diagrams 7-86
- refilled toner cartridges 1-23
- registration assembly 6-56
- registration sensor 6-62
- related documentation 1-24
- remanufactured assemblies 1-21
- removal and replacement
 - strategy 6-5
- repair philosophy 1-21
- repetitive defects 7-69
- repetitive image defect ruler 7-71
- replacing
 - disk drive 6-8
 - duplex unit 6-10
 - envelope feeder 6-11
 - external paper handling controller 6-12
 - multi-bin mailbox 6-14
 - tray 4 6-13
- required tools 6-6
- requirements
 - space 2-4
- reset, cold 3-28
- Resolution Enhancement
 - technology 1-3, 5-9
- resolution, print 1-3
- restoring factory settings 3-6
- REt
 - see "Resolution Enhancement technology" 1-3, 5-9
- REt, Resolution Enhancement
 - technology 1-3
- roller
 - transfer 6-64

rollers		toner cartridge		troubleshooting	
tray 1	6-58	cleaning spills	4-5	drum rotation functional	
tray 2	6-60	defective	4-5	check	7-75
tray 3	6-60	detector	5-7	engine test	7-8
S		hvps contacts	5-13	faulty image examples	
saving menu selections		image formation system		7-63	
3-8		5-13		faulty image examples	
scanner drive	5-10	life expectancy	1-22	7-16	
scanner motor	5-11	photosensitive drum		half self test functional	
scanner/laser assembly		5-13		check	7-74
6-42		print quality	1-23	high-voltage power supply	
screwdrivers	6-6	recycling	1-23	check	7-76
screws		refilled	1-23	image formation	7-63
descriptions	6-16	troubleshooting	7-16, 7-63	paper curl	7-85
Select, key	3-3	used	1-23	paper jams	7-77
sensor		warranty	1-23	troubleshooting checks	
paper input unit	6-61	tools	6-6	7-78	
registration	6-62	top cover	6-24	troubleshooting tools	
separation pad		training media	1-24	repetitive image defect	
tray 1	6-58	transfer roller assembly		ruler	7-72
separation roller		6-64		two-sided printing	5-39
tray 2	6-60	transparency specifications		typefaces	
tray 3	6-60	1-12		internal	1-3
serial number	1-7	tray 1		U	
setting	3-21, 6-40	assembly	6-65	upgrading	
service approach	1-21	feed roller	6-58	memory	6-7
service mode	3-19, 7-79	media guidelines	1-4	personalities	6-7
settings and defaults	3-5	separation pad	6-58	user installable accessories	
shipping print media	1-13	tray 2		6-7	
site requirements	2-1 - 2-4	adjustment procedure		W	
SL3		4-7		warranty	1-27
See "solenoid assembly"		assembly	6-66	warranty limitations	1-28
6-63		media guidelines	1-5	white stripes	7-71
slots		rollers	6-60		
cartridge	1-3	tray 3			
SME, Support Materials		adjustment procedure			
Europe	1-21, 1-24	4-7			
SMO, Support Materials		assembly	6-66		
Organization	1-21	media guidelines	1-6		
solenoid assembly	6-63	rollers	6-60		
space requirements	2-4	tray 4	6-67		
specifications		back cover	6-67		
adhesive labels	1-12	left cover	6-68		
electrical	1-9	main drive assembly			
paper	1-11,	6-70			
1-24		media guidelines	1-6		
printer	1-8	paper quantity switch			
standard interfaces	1-3	assembly	6-77		
standard printer memory		paper size switch			
1-3		assembly	6-77		
storing print media	1-13	paper tray	6-71		
Support Materials Europe		pca controller	6-72		
1-21		photosensors	6-74		
Support Materials		pickup assembly	6-73		
Organization	1-21	power supply	6-75		
T		replacing	6-13		
technical assistance	1-25	right cover	6-69		
temporary settings	3-5	rollers	6-76		
test menu	3-12	transfer assembly	6-78		
tests		tray menu	3-10		
printer	3-23				



Copyright© 1997
Hewlett-Packard Co.
Printed in USA 7/97

Manual Part No.
C4077-90960



Printed on at least
50% Total Recycled Fiber with
at least 10% Post-Consumer Paper



C4077-90960