

Field Feature Bill of Material

PN 02L3675

Install Network Node Control Point (NNP-A) Feature Code 5122

on IBM 3746-900.

Written by: J. Michaut Illustration by: S. Vaccaro Checked by: Approved by: A. Badino Reviewed by: A. Bowen

3746 PN 02L3675 EC F12391A FFBM 1 of 18 28 Jan 98

© Copyright IBM Corp. 1998

1

3746 PN 02L3675 FFBM 2 of 18 EC F12391A 28 Jan 98



Before Installation (Steps 1-8)

1.0 Machines Affected

3746 Model 900

This feature should only be applied on the machine serial number for which it is specified.

2.0 Related BMs and ECs

2.1 Prerequisites

(Must be installed prior to this installation)

Feature	Title
5023	Controller Expansion (B/M 29H4173)
9018	Controller Bus and Service Processor Type 2 - (B/M 59G0456), or
9023	Controller Bus and Service Processor Type 3 - (B/M 94H7367).
5026	Hard Disk Drive Exchange (B/M 29H4179) (If Service Processor type 9577 only).
EC	Title
D46130	Licensed Internal Code (Minimum level)
	Checkpoint: Check that the CSS 1 EC Level is D46130.000 or higher.
	Note: Refer to SPIM, Chapter 3. Displaying the EC Level of the Code.

2.2 Concurrent ECs

(Must be installed together)

None.

2.3 Companion ECs

(May be installed together)

None.

3746	PN 02L3675	EC F12391A		
FFBM	3 of 18	28 Jan 98		



3.0 BMs to be Installed


Feature


B/M Title

02L3674 Network Node Processor A (NNP-A) Feature Code 5122


4.0 Preparation

- 1. Familiarize yourself with the purpose and details of the installation instruction before negotiating machine time with the customer.
- 2. Check all items listed on the BM(s) to determine that all parts have been received.
- Brackets (X2) and Screws (X4)
- 7585-P02 System Unit and Power Cord
- Publications and diskette









- 3. The set up of the NNP-A has no impact on customer operations.
- 4. Obtain from the customer the Parameter worksheet.

5.0 Programming

None.



6.0 Purpose and Description

6.1 Purpose

To support the APPN, X25, IP or ISDN operation on 3746-900.

6.2 Description

The installation of the NNP-A is divided into three main procedures:

- 1. Installing the NNP code on the SP hard disk.
- 2. Installing the 7585-P02 system unit
- 3. Loading the code on the NNP-A.

7.0 Installation Time

FFBM	Machine Hrs.	System Hrs.	Nbr of CEs
02L3675	0.2	0.0	1

Note: To reduce the MES installation time it is recommended that you load the Network Node Processor Code on the Service Processor and install the system unit at the same time.

No impact on 3745 customer operations.

8.0 Tools/Material Required

None.

3746	PN 02L3675	E
FFBM	5 of 18	28

EC F12391A		
28 Jan 98		




Figure 1. NNP-A installed with SP 7585.




Figure 2. NNP-A installed with SP 9577.




Figure 3. NNP-A installed with SP 3172.




Figure 4. NNP-A installed with SP 9585.

3746	PN 02L3675	EC F12391A		
FFBM	6 of 18	28 Jan 98		




Figure 5. Installing Brackets for Processor Type 7585

3746	PN 02L3675	EC F12391A		
FFBM	7 of 18	28 Jan 98		

Installation (Steps 9-12)

9.0 Safety

Review the **Safety Notices** and the **Safety Inspection Procedures** located at the beginning of the *IBM 3745 Communication Controller All Models*, *IBM 3746 Expansion Unit Model 900*, *IBM 3746 Nways Multiprotocol Controller Model 950 Safety Information*, GA33-0400.

10.0 Details of Installation.

Notes -

For any unexpected message or error concerning the service processor, go to **Chapter 4. Problem Determination** of the:

- Service Processor Installation and Maintenance (Based on 7585, 3172, 9585, and 9577), SY33-2115, or
- Service Processor Installation and Maintenance (Based on 7585, 3172, and 9585), SY33-2120.

10.1 Installing the NNP Code on the SP hard Disk.

Compact Disk
Go to 10.1.1, "Installing the NNP Code from the Compact Disk"

Optical Disk
Go to 10.1.2, "Installing the NNP Code from the Optical Disk" on page 9

10.1.1 Installing the NNP Code from the Compact Disk

On the Service Processor

	1. Enter the Service Processor Maintenance password (default is IBM3745
	2. Double click on the Service Processor object icon.
	3. Click on Configuration Management
	4. Insert the Licensed Internal Code CD-ROM in the CD-ROM drive.
_	Double click on the Install 3746 and NNP LIC on SP Hard Disk, then follow the prompts.
	Wait (Up to 45 minutes) for the message: Operation successfully completed.

Go to 10.2, "Installing the System Unit" on page 11


3746	PN 02L3675	EC F12391A		
FFBM	8 of 18	28 Jan 98		



10.1.2 Installing the NNP Code from the Optical Disk

Shut Down and Power OFF the Service Processor (If not already done):

- __ 1. On the "MOSS-E view" window click on "Program".
- Click on "Shut down".



- __ 3. Enter the Service Processor maintenance password (default is IBM3745). Then, click on "OK" button.
- 4. Power **OFF** the service processor.

Installing the Code:

- __ 5. Install the **Service Processor installation diskette 1** in the Service Processor diskette drive.
- ___ 6. Power **ON** the service processor.
- 7. Install the Licensed Internal Code optical disk, at EC D46130 or higher, in the Service Processor optical disk drive.
- ___ 8. On the first screen displayed, press "Enter" key.

١	Then, press "Enter" key to start the process then follow the prom -
	Service Processor Installation Main Menu
	Select one of the following options using \uparrow and \downarrow or tab keys, then press Enter:
	 Update Licensed Internal Code (LIC) when installing a 3746-9XX Update Licensed Internal Code Restore hard disk
	4. Save hard disk 5. Update Licensed Internal Code when installing a Network Node Processo 6. Exit
	Enter
	Vait (Up to 45 minutes) for the message: Operation successfully leted.
p 11. <i>A</i>	
p 11. <i>A</i>	eleted . At the end, select " Exit " and press the Enter key from the primary
p 11. <i>A</i>	At the end, select "Exit" and press the Enter key from the primary vindow and follow the prompts. Service Processor Installation Main Menu Select one of the following options using ↑ and ↓ or tab keys,
p 11. <i>A</i>	At the end, select " Exit " and press the Enter key from the primary vindow and follow the prompts. Service Processor Installation Main Menu
p 11. <i>A</i>	At the end, select "Exit" and press the Enter key from the primary vindow and follow the prompts. Service Processor Installation Main Menu Select one of the following options using ↑ and ↓ or tab keys, then press Enter: 1. Update Licensed Internal Code (LIC) when installing a 3746-9XX 2. Update Licensed Internal Code


3746 PN 02L3675 EC F12391A FFBM 10 of 18 28 Jan 98




10.2 Installing the System Unit

- 1. If not already done, open the front and rear doors of the Controller Expansion.
- 2. Locate the location to install the NNP-A in the Controller Expansion (Refer to Figure 1 on page 6 to Figure 4 on page 6).
- ___ 3. Install the right and left brackets 1 (PN 58G5752), provided with the FFB/M, in the controller expansion. Then, tighten using the four screws (p/n 2665527 2

Note: If some brackets are already install in the position where the NNP-A must be install, remove those left and right brackets.




4. Install four captive nuts (PN 58G5766) on the left and right side of the controller expansion (Refer to Figure 5 on page 7).




EC F12391A		
28 Jan 98		

5. Slide the network node processor unit in the controller expansion from the front side, then fasten the unit using four screws (PN 1621230).




6. Using label (PN 0792966), identify your Network Node Processor-A by sticking the appropriate label A on the front and rear side of the unit.





10.3 Connecting the NNP-A.

- 1. Plug connector 1 of cable A (PN 6339098) to the token-ring card connector.
- 2. Using a sticker, identify the cable A as the "network node processor cable" and plug connector 2 to any plug of the 8228 from 1 to 8
- ___ 3. Connect power cord 3 from J2 to the ac outlet of the NNP-A.



On the NNP-A Front Side:

4. Open the access door, then press the Power button to Switch ON the NNP-A system unit.

Note: For any unexpected message or error concerning the NNP-A, go to **Chapter 3. Network Node Processor Problem Determination** of the *Network Node Processor Installation and Maintenance* Manual. SY33-2111.


3746	PN 02L3675	EC F12391A		
FFBM	13 of 18	28 Jan 98		




10.4 Installing the Code on the Network Node Processor

On the Service Processor 1. Double click on the 3746-900 icon where you are going to install the NNP-A.

- 2. From the 3746-9x0 menu, click on Network Node Processor (NNP) Man-
- 3. Double click on (M) Install/Remove/Change/Restore LIC/NNP.
- 4. Click on the NNP-A radio button, then click on Install NNP button.
- 5. Click on OK.
 - 6. If necessary, modify the IP address and the Subnet mask for the service processor and the network node processor according to the values recorded by the customer on the parameter worksheet. Otherwise keep the default values and record the hostnames for later use. Then, Click on OK button.




7. Insert the Network Node Processor installation diskette in the diskette drive of the Service Processor. Then, click on OK button.






___ 8. Click on the **IBM7585** radio button, then click on **OK** button.




- 9. When the process is completed, power OFF the Network Node Processor A.
- ___ 10. Remove the **NNP Installation Diskette**from the **Service Processor**; Then insert it in the **NNP-A** diskette drive.



- __ 11. Power ON the Network Node Processor A.
- __ 12. Then click on **OK** button.
- __ 13. To follow the progress of the installation, read the messages prompted in 'Messages' box.

Note: It takes about 30 minutes to complete the installation

___ 14. As indicated in the following information message, remove the Network Node Processor installation diskette, then click on **OK** button.



3746 PN 02L3675 FFBM 15 of 18

EC F12391A		
28 Jan 98		



	Installation I	nstructions
		15. The installation is completed, click on OK button. BS5/3746-900/BS5/3746-900/NNP Licensed Internal Code (LIC) Management NNP Installation. Operation successfully completed. Now shutdown and restart the Service Processor. And re-iml the 3746.
		16. Click on Close button.
		17. Ask the customer for a maintenance window on 3746-900 with traffic deactivated.
		18. Shutdown and restart the Service Processor and re-iml the 3746-9x0
10.5	Returning	the Machine to the Customer 1. Inform the Customer that the machine is now ready to receive the APPN configuration.
11.0	Test Pro	ocedures
		No test required.
12.0	Field U	odating
		None.



After Installation (steps 13-15)

13.0 Field Updating

None.

14.0 Publications Update

None.

15.0 Parts Disposition

15.1 Purchased Machines

Refer to the parts ownership matrix to determine the correct owner of removed/unused parts.

- For EMEA/APG/AG Areas, refer to Hardware and General Service Code Description.
- · For Domestic Areas, return parts to the customer.

16.0 Machine Records

- · Install the new MACHINE HISTORY supplied.
- Report installation and quality problems using existing procedures.

End of instructions.

3746	PN 02L3675	EC F12391A		
FFBM	17 of 18	28 Jan 98		

3746	PN 02L3675	EC F12391A		
FFBM	18 of 18	28 Jan 98		