

Part No. Z1-002-592, IB003143

Jul. 2006

## OPERATION MANUAL

---

Impedance Measurement Unit  
PFX2000 Series

# PFX2211



## **Use of Operation Manual**

Please read through and understand this Operation Manual before operating the product. After reading, always keep the manual nearby so that you may refer to it as needed. When moving the product to another location, be sure to bring the manual as well.

If you find any incorrectly arranged or missing pages in this manual, they will be replaced. If the manual gets lost or soiled, a new copy can be provided for a fee. In either case, please contact Kikusui distributor/agent, and provide the “Kikusui Part No.” given on the cover.

This manual has been prepared with the utmost care; however, if you have any questions, or note any errors or omissions, please contact Kikusui distributor/agent.

Reproduction and reprinting of this operation manual, whole or partially, without our permission is prohibited.

Both unit specifications and manual contents are subject to change without notice.

Copyright© 2004 - 2006 Kikusui Electronics Corporation

## Power Requirements of this Product

Power requirements of this product have been changed and the relevant sections of the Operation Manual should be revised accordingly.

(Revision should be applied to items indicated by a check mark ☒)

### ☐ Input voltage

The input voltage of this product is \_\_\_\_\_ VAC,  
and the voltage range is \_\_\_\_\_ to \_\_\_\_\_ VAC. Use the product within this range only.

### ☐ Input fuse

The rating of this product's input fuse is \_\_\_\_\_ A, \_\_\_\_\_ VAC, and \_\_\_\_\_.


- 
- ⚠ WARNING**
- To avoid electrical shock, always disconnect the AC power cord or turn off the switch on the switchboard before attempting to check or replace the fuse.
  - Use a fuse element having a shape, rating, and characteristics suitable for this product. The use of a fuse with a different rating or one that short circuits the fuse holder may result in fire, electric shock, or irreparable damage.
- 

### ☐ AC power cord


The product is provided with AC power cords described below. If the cord has no power plug, attach a power plug or crimp-style terminals to the cord in accordance with the wire colors specified in the drawing.

- 
- ⚠ WARNING**
- The attachment of a power plug or crimp-style terminals must be carried out by qualified personnel.
- 


#### ☐ Without a power plug




#### ☐ Without a power plug



#### ☐ Plugs for USA



#### ☐ Plugs for Europe



#### ☐ Provided by Kikusui distributor/agent

Kikusui distributor/agent can provide you with suitable AC power cord.  
For further information, contact Kikusui distributor/agent.



## Safety Symbols

For the safe use and safe maintenance of this product, the following symbols are used throughout this manual and on the product. Understand the meanings of the symbols and observe the instructions they indicate (the choice of symbols used depends on the products).



Indicates that a high voltage (over 1 000 V) is used here. Touching the part causes a possibly fatal electric shock. If physical contact is required by your work, start work only after you make sure that no voltage is output here.

**DANGER**

Indicates an imminently hazardous situation which, if ignored, will result in death or serious injury.



Indicates a potentially hazardous situation which, if ignored, could result in death or serious injury.



Indicates a potentially hazardous situation which, if ignored, may result in damage to the product and other property.



Shows that the act indicated is prohibited.



Is placed before the sign “DANGER,” “WARNING,” or “CAUTION” to emphasize these. When this symbol is marked on the product, see the relevant sections in this manual.



Indicates a protective conductor terminal.



Indicates a chassis(frame) terminal.



# Safety Precautions

The following safety precautions must be observed to avoid fire hazard, electrical shock, accidents, and other failures. Keep them in mind and make sure that all of them are observed properly.




## Users

- This product must be used only by qualified personnel who understand the contents of this operation manual.
- If it is handled by disqualified personnel, personal injury may result. Be sure to handle it under supervision of qualified personnel (those who have electrical knowledge.)
- This product is not designed or manufactured for general home or consumer use.



## Purposes of use

- Do not use the product for purposes other than those described in the operation manual.



## Input power

- Use the product with the specified input power voltage.
- For applying power, use the AC power cord provided. Note that the provided power cord is not use with some products that can switch among different input power voltages or use 100 V and 200 V without switching between them. In such a case, use an appropriate power cord.




## Fuse

- With products with a fuse holder on the exterior surface, the fuse can be replaced with a new one. When replacing a fuse, use the one which has appropriate shape, ratings, and specifications.



## Cover

- There are parts inside the product which may cause physical hazards. Do not remove the external cover.



## **Installation**

- When installing products be sure to observe “Installation” described in this manual.
- To avoid electrical shock, connect the protective ground terminal to electrical ground (safety ground).
- When connecting the AC power cord to a switchboard, be sure work is performed by a qualified and licensed electrician or is conducted under the direction of such a person.
- When installing products with casters, be sure to lock the casters.



## **Relocation**

- Turn off the power switch and then disconnect all cables when relocating the product.
- Use two or more persons when relocating the product which weights more than 20 kg. The weight of the products can be found on the rear panel of the product and/or in this operation manual.
- Use extra precautions such as using more people when relocating into or out of present locations including inclines or steps. Also handle carefully when relocating tall products as they can fall over easily.
- Be sure the operation manual be included when the product is relocated.



## **Operation**

- Check that the AC input voltage setting and the fuse rating are satisfied and that there is no abnormality on the surface of the AC power cord. Be sure to unplug the AC power cord or stop applying power before checking.
- If any abnormality or failure is detected in the products, stop using it immediately. Unplug the AC power cord or disconnect the AC power cord from the switchboard. Be careful not to allow the product to be used before it is completely repaired.
- For output wiring or load cables, use connection cables with larger current capacity.
- Do not disassemble or modify the product. If it must be modified, contact Kikusui distributor/agent.



## **Maintenance and checking**

- To avoid electrical shock, be absolutely sure to unplug the AC power cord or stop applying power before performing maintenance or checking.
- Do not remove the cover when performing maintenance or checking.
- To maintain performance and safe operation of the product, it is recommended that periodic maintenance, checking, cleaning, and calibration be performed.



## **Service**

- Internal service is to be done by Kikusui service engineers. If the product must be adjusted or repaired, contact Kikusui distributor/agent.

# Contents

|  |     |
|--|-----|
| Safety Symbols                                     | III |
| Safety Precautions                                 | IV  |
| Preface  | P-1 |
| Chapter 1 Setup                                    | 1-1 |
| 1.1 Checking the Package Contents                  | 1-1 |
| 1.2 Installation                                   | 1-2 |
| 1.2.1 Precautions Concerning Installation Location | 1-2 |
| 1.2.2 Rack Mounting                                | 1-3 |
| 1.3 Precautions When Moving the Product            | 1-3 |
| 1.4 Connecting the Power Cord                      | 1-4 |
| 1.5 Connecting to the 5-Unit Frame                 | 1-6 |
| 1.6 Connecting the TP-BUS                          | 1-8 |
| 1.6.1 Connecting TP-BUS Cables                     | 1-8 |
| 1.6.2 Setting the Termination                      | 1-9 |
| Chapter 2 Turning On the Power                     | 2-1 |
| Chapter 3 Names and Functions of Parts             | 3-1 |
| Chapter 4 Maintenance                              | 4-1 |
| 4.1 Cleaning                                       | 4-1 |
| 4.2 Inspection                                     | 4-1 |
| 4.3 Replacing the Fuse                             | 4-2 |
| 4.4 Calibration                                    | 4-2 |
| 4.5 Malfunctions and Causes                        | 4-3 |
| Chapter 5 Specifications                           | 5-1 |
| 5.1 Functional Specifications                      | 5-1 |
| 5.2 Electrical Specifications                      | 5-1 |
| 5.3 General Specifications                         | 5-2 |
| 5.4 Outline Drawing                                | 5-4 |



# Preface

## About This Manual

This operation manual covers information about the hardware of the PFX2211 Impedance Measurement Unit in the PFX2000 Series Charge/Discharge Battery Test System.

For information about the hardware of the entire PFX2000 system, see the *PFX2000 Series Charge/Discharge Battery Test System Operation Manual* that is included with the PFX2121 Control Unit.

This product is controlled using BPChecker2000, an application software. For details on how to use the application, see the *BPChecker2000 User's Manual*.

## Product Overview

The PFX2211 Impedance Measurement Unit enables the measurement of internal impedance of batteries. It is combined with the 5-Unit Frame and Charge/Discharge Power Supply Units.

A single unit can measure up to 120 channels for each control unit.

## Features

- Highly accurate impedance measurement is possible using the AC four-wire system (complies with Japanese Industrial Standard: JIS C8705 and C8708 1-kHz Alternating Current Method).
- Adoption of a constant current system enables measurements free from the effects of the output cable resistance and bad contacts of fixtures.
- Designed specifically for measuring the internal impedance of the secondary batteries such as Nickel-Metal Hydride (Ni-MH), Nickel-Cadmium (Ni-cd), and lithium ion, the operation is easier than general LCR meters.
- Measures  $R$ ,  $jX$ , and  $|Z|$  in the range of  $10\ \mu\Omega$  to  $10\ \Omega$  and phase difference  $\theta$  between  $+90^\circ$  to  $-90^\circ$  at a minimum resolution of  $10\ \mu\Omega/0.1^\circ$  at a frequency of 1 kHz.

## Optional accessories

### Cables

To connect the impedance measurement unit to the 5-Unit Frame, you will need modular cables and UTP cables for the number of frames to be used.

These cables are sold as optional accessories so that you can purchase the required number of cables. The cable set includes one modular cable and one UTP cable, and you can purchase any number of sets. If you require cables, contact your Kikusui agent or distributor.

TableP-1 Cable Set (Sold Separately)

| Code  | Model        | Contents   |
|-------|--------------|--|
| 84270 | TL02-PFX(1M) | Modular cable: 1 pc. (1 m)<br>UTP cable: 1 pc. (1 m) |
| 84280 | TL02-PFX(3M) | Modular cable: 1 pc. (3 m)<br>UTP cable: 1 pc. (3 m) |
| 84290 | TL02-PFX(5M) | Modular cable: 1 pc. (5 m)<br>UTP cable: 1 pc. (5 m) |




Fig.P-1 Cables

This chapter describes the steps taken before actually using the product such as unpacking, installation, etc.

## 1.1 Checking the Package Contents

When you receive the product, check that all accessories are included and that the accessories have not been damaged during transportation.

If any of the accessories are damaged or missing, contact your Kikusui agent or distributor.

### NOTE

- It is recommended that all packing materials be saved, in case the product needs to be transported at a later date.




Fig.1-1 Accessories

## 1.2 Installation

This section describes the precautions concerning the installation location of the product and the rack mounting of the product.

### 1.2.1 Precautions Concerning Installation Location

This section describes the precautions to be taken when installing the product. Make sure to observe them.

■ **Do not use the product in a flammable atmosphere.**

To prevent the possibility of explosion or fire, do not use the product near alcohol or thinner or in an atmosphere containing such vapors.

■ **Avoid locations where the product is exposed to high temperature or direct sunlight.**

Do not place the product near a heater or in areas subject to drastic temperature changes.

Operation temperature range: 0 °C to +40 °C

Storage temperature range: -10 °C to +60 °C

■ **Avoid locations of high humidity.**

Do not place the product in high-humidity locations, i.e., near a boiler, humidifier, water supply, etc.

Operation humidity range: 30 % to 80 % [RH] (no condensation)

Storage humidity range: 20 % to 80 % [RH] (no condensation)

Condensation may occur even in the operation humidity range. In such case, do not use the product until the condensation dries up completely.

■ **Do not place the product in a corrosive atmosphere.**

Do not install the product in a corrosive atmosphere or in environments containing sulfuric acid mist, etc. This may cause corrosion of various conductors and bad contacts of connectors inside the product leading to malfunction and failure, or in the worst case, a fire.

■ **Do not place the product in a dusty location.**

Accumulation of dust can lead to electric shock or fire.

■ **Do not use the product where ventilation is poor.**

Secure adequate space around the product so that air can circulate around it.

■ **Do not place objects on top of the product.**

Placing objects on top of the product can cause failures (especially heavy objects).

■ **Do not place the product on an inclined surface or location subject to vibrations.**

The product may fall or tip over causing damages and injuries.

- **Do not use the unit in a location subject to strong magnetic or electric fields.**

The unit may malfunction and cause electric shock or fire.

- **Do not use the product near highly sensitive measuring instruments or transceivers.**

The noise generated by the product may affect them.

## 1.2.2 Rack Mounting

The Impedance Measurement Unit is designed on the assumption that it be rack mounted in an EIA standard rack with the 5-Unit Frames.

For more details on rack mounting, see section 1.2.2, “Rack Mounting” in the *PFX2000 Series Charge/Discharge Battery Test System Operation Manual* that comes with the Control Unit.

## 1.3 Precautions When Moving the Product

When moving the product to the installation location or when transporting the unit, note the following points.

- **Turn off the POWER switch.**

Moving the unit while the power is turned on can cause electric shock or damage to the unit.

- **Remove wiring.**

Moving the product with the cables connected can cause wires to break or injuries if the product is dropped.

- **When transporting the product, be sure to use the original packing materials.**

Otherwise, damage may result from vibrations or from the product falling during transportation.

## 1.4 Connecting the Power Cord

---

**⚠ WARNING**

- Have a qualified engineer connect the power cord.
- To prevent the possibility of electric shock, turn off the switchboard (the switch that cuts off the power supply from the switchboard) before connecting the cord.
- Connect the product to the power source by keeping the distance between the product and the switchboard switch under 3 m. By doing so, you will be able to easily access the switch in a case of emergency.  
If the distance must be greater than 3 m, provide a separate switch within 3 m from the product. Use a two-pole switch that cuts off L and N wires simultaneously.

**⚠ CAUTION**

- Inside the product, protective circuits including input fuses are connected to match the polarity of the input terminal. Make sure the colors of the wires connected to the corresponding input terminals (L, N, and ⊕ (GND)) are correct.
- 

Keep in mind that the product is designed for Overvoltage Category II.

1. Check that the AC power supply meets the AC input specifications of the PFX2211.

Nominal input rating: 200 VAC to 240 VAC, 50/60 Hz, single phase

Power consumption: 25 VA max

2. Turn off the power switch.
3. Prepare the terminals at the AC power supply end of the power cord as shown in Fig. 1-2.

The AC power supply end of the power cord that comes with the PFX2211 comes in a cut condition. Remove the insulation so that a plug or crimp terminal can be attached to the wires.

4. Attach a plug or crimp terminals to the power cord.
5. Connect the power cord to the AC LINE connector on the rear panel.
6. Connect the power cord to a power outlet or a switchboard.  
If you are connecting the power cord to a switchboard, turn off the switchboard switch beforehand.




Fig. 1-2 Power Cord

## Grounding

Securely connect the GND wire of the power cord to a dedicated earth ground terminal.

---

### **⚠ WARNING**

- Electric shock may occur, if proper grounding is not furnished.
- Connect the ground terminal to an adequate earth ground.

### **⚠ CAUTION**

- If you do not ground the product, malfunction may occur due to external noise, or the noise generated by the product may become large.
-

## 1.5 Connecting to the 5-Unit Frame

The Impedance Measurement Unit has 12 ports for connecting to the 5-Unit Frames (up to 12 5-Unit Frames to be connected).

Each port consists of a DUT terminal (8 pins) and a CONT terminal (6 pins). The number assigned to each port (FRAME 1 to 12) corresponds to the frame address number of the frame to be connected. For example, the DUT and CONT terminals of port 1 (FRAME 1) are connected to the DUT and CONT terminals of the 5-Unit Frame with frame address 1. DUT terminals are connected using an UTP cable; CONT terminals are connected using a modular cable. See Fig. 1-4 and Table 1-1.

**NOTE**

- The modular and UTP cables are sold separately. The cable set contains one of each cable, and you can purchase any number of cable sets. If you require cables, contact your Kikusui agent or distributor.

Table1-1 Cable Set (Sold Separately)

| Code  | Model        | Contents   |
|-------|--------------|--|
| 84270 | TL02-PFX(1M) | Modular cable: 1 pc. (1 m)<br>UTP cable: 1 pc. (1 m) |
| 84280 | TL02-PFX(3M) | Modular cable: 1 pc. (3 m)<br>UTP cable: 1 pc. (3 m) |
| 84290 | TL02-PFX(5M) | Modular cable: 1 pc. (5 m)<br>UTP cable: 1 pc. (5 m) |




Fig. 1-3 Cables






Fig. 1-4 Connection with Frames

Table 1-2 Connection Table

| PFX2211 | ↔    | 5-Unnit Frame   | PFX2211  | ↔    | 5-Unnit Frame   |
|---------|------|-----------------|----------|------|-----------------|
| FRAME 1 | CONT | Frame address 1 | FRAME 7  | CONT | Frame address 7 |
|         | DUT  |                 |          | DUT  |                 |
| FRAME 2 | CONT | Frame address 2 | FRAME 8  | CONT | Frame address 8 |
|         | DUT  |                 |          | DUT  |                 |
| FRAME 3 | CONT | Frame address 3 | FRAME 9  | CONT | Frame address 9 |
|         | DUT  |                 |          | DUT  |                 |
| FRAME 4 | CONT | Frame address 4 | FRAME 10 | CONT | Frame address A |
|         | DUT  |                 |          | DUT  |                 |
| FRAME 5 | CONT | Frame address 5 | FRAME 11 | CONT | Frame address B |
|         | DUT  |                 |          | DUT  |                 |
| FRAME 6 | CONT | Frame address 6 | FRAME 12 | CONT | Frame address C |
|         | DUT  |                 |          | DUT  |                 |

---

## 1.6 Connecting the TP-BUS

### 1.6.1 Connecting TP-BUS Cables

The Control Unit, 5-Unit Frames, and Impedance Measurement Unit are connected using the TP-BUS. The TP-BUS is connected in a chain by connecting twisted-pair cables to the TP-BUS connectors (plug) provided.

For the procedure in connecting the TP-BUS, see section 1.7, “Connecting the TP-BUS” in the *PFX2000 Series Charge/Discharge Battery Test System Operation Manual* that comes with the Control Unit.

---

**NOTE**

- Be sure to connect the Impedance Measurement Unit to TP-BUS 1.
- On the 5-Unit Frame, you must set a frame address on each frame as an address on the TP-BUS. However, this product does not require the setting of an address on the TP-BUS.

Like the charge/discharge power supply units, the address of the product is managed using a node number, and the number is fixed inside the product. Therefore, you cannot connect multiple impedance measurement units to a single control unit.

---

## 1.6.2 Setting the Termination

- 
- ⚠ CAUTION** • If the termination is not set properly, communications become unstable and erroneous operation may result.
- 

Turn on the termination on the device at the end of the TP-BUS located opposite to the Control Unit.

Taking the TP-BUS connection diagram in section 1.7.1, “Connecting TP-BUS Cables” in the *PFX2000 Series Charge/Discharge Battery Test System Operation Manual* as an example, the termination on the 5-Unit Frame at the end of the TP-BUS is turned on, and the termination on all other units are turned off. Therefore, turn off the termination also on the impedance measurement unit.

If you are connecting the impedance measurement unit to the end of the TP-BUS, turn on the S1 switch as shown in Fig. 1-5.




Fig. 1-5 Termination ON Setting



This chapter describes the procedures for turning on the power.

This product is controlled using BPChecker2000, an application software. For details on how to use the application, see the *BPChecker2000 User's Manual*.

There is no particular order for turning on the PFX2000 Series Battery Test System. You can first turn on the Control Unit, any of the 5-Unit Frames, or the Impedance Measurement Unit.

1. Check that the power cord is correctly connected.
2. Turn on the POWER switch on the rear panel.

The POWER/ALARM LED and the MEASUREMENT LED blink alternately green and red for a few seconds, and then the POWER/ALARM LED illuminates in green.




Fig. 2-1 Status after Power On



## Chapter 3

# Names and Functions of Parts

This chapter describes the names and functions of switches, displays, connectors, and other parts of the panels.

**Read this chapter to learn about the details of the ⚠ (alert) marks indicated on the panel.**




Fig.3-1 PFX2211 Front Panel

### [1] Bracket

Bracket for racking the unit on an EIA standard rack.

For details on rack mounting, see section 1.2.2, “Rack Mounting.”

### [2] POWER/ALARM

The operation status of this product is indicated using LED colors.

- Illuminated in green: Indicates the power is being supplied to the product.
- Illuminated in red: Indicates the alarm status.

### [3] MEASUREMENT

The operation status of this product is indicated using LED colors.

- Illuminated in red: Indicates that impedance is being measured.




Fig. 3-2 PFX2211 Rear panel

#### [4] FRAME 1 to 12 (port)

Connector for connecting to the 5-Unit Frame. Each port consists of a DUT terminal (8 pins) and a CONT terminal (6 pins).

For details on the connection, see section 1.5, “Connecting to the 5-Unit Frame.”

#### [5] S1 ⚠

Of the eight switches that are aligned, the left-most switch when facing the rear panel is the switch used to turn on/off the TP-BUS termination (TERMN). Turn off all other switches.

For a description of the TERMN setting, see section 1.6.2, “Setting the Termination.”

#### [6] TP-BUS

Connector for connecting the TP-BUS cable.

For details on the connection, see section 1.6, “Connecting the TP-BUS.”

#### [7] POWER

Power switch of the product. “|” side is on; “O” side is off.

#### [8] AC LINE

Power cord connector for supplying power to the product. Insert the power cord that came with the package.

---

**⚠ WARNING** • Improper handling can lead electric shock. When connecting the power cord, be sure to read section 1.4, “Connecting the Power Cord.”

---

#### [9] FUSE

Contains an input fuse and a spare fuse.


---

**⚠ WARNING** • Improper handling can lead electric shock. When replacing the fuse, be sure to read section 4.3, “Replacing the Fuse.”

---





This chapter describes maintenance and calibration of the product. It also describes troubleshooting measures when you suspect that malfunction has occurred while using the product.

- 
-  **WARNING** • Some parts inside the product may cause physical hazards. Do not remove the external cover.
- 

## 4.1 Cleaning

### Cleaning the panels


If the panel needs cleaning, gently wipe using a soft cloth with water-diluted neutral detergent.

- 
-  **WARNING** • Be sure to turn off the POWER switch on the device and the switchboard switch.
-  **CAUTION** • Do not use volatile solvents such as thinner or benzene. They may discolor the surface or erase the printed characters.
- 

## 4.2 Inspection

### Power cord

Check that the insulation coating is not broken, that the crimp terminal is not loose, and that the wire is not broken.

- 
-  **WARNING** • Be sure to turn off the POWER switch on the device and the switchboard switch.
- Breaks in the insulation coating may cause electric shock. If a break is found, stop using it immediately.
- 

To purchase accessories, contact your Kikusui agent or distributor.

## 4.3 Replacing the Fuse

You can replace the input fuse of this product. If the fuse blows due to deterioration, you must replace the fuse.

### **⚠ WARNING**

- To prevent the possibility of electric shock, be sure to turn OFF the POWER switch and the switchboard switch before replacing the fuse.
- Use a fuse of shape, rating, and characteristics that conform to the product (1 A (T), 250 VAC). Using a fuse of a different rating or shorting the fuse holder is dangerous. Never carry out such acts.

1. Turn off the POWER switch and the switchboard switch.
2. Remove the power cord from the AC LINE connector on the rear panel.
3. Remove the fuse holder using a tool such as a flat-blade screwdriver as shown in Fig. 4-1.




Fig.4-1 Method of Removing the Fuse Holder

## 4.4 Calibration

The product is calibrated at the factory before shipment. However, periodic calibration is necessary due to changes that occur after extended use.

For calibration, contact your Kikusui agent or distributor.

## 4.5 Malfunctions and Causes

This section describes remedies for malfunctions encountered during the use of the product.

Typical symptoms and check items are indicated. In some cases, the problem can be solved quite easily.

If you find an item that corresponds to your case, follow the remedy for the item. If the remedy does not solve the problem or if your case does not match any of the items, contact your Kikusui agent or distributor.

### ■ Symptom 1: The LED indication is abnormal.

| Check Item  | Cause and Remedy   |
|---|--|
| ■ After turning on the power, the two LEDs on the panel remain blinking. Or, the POWER/ALARM LED is illuminated in red. | <ul style="list-style-type: none"><li>• A malfunction has occurred inside the device. Power-cycle the system. If the LED keeps blinking even after power-cycling the product, contact your Kikusui agent or distributor.</li></ul> |

### ■ Symptom 2: The measured value is way off.

| Check Item  | Cause and Remedy   |
|---|--|
| ■ The UTP cable connected to the DUT terminal is broken.  | <ul style="list-style-type: none"><li>• Replace the UTP cable with a new one.</li></ul>  |
| ■ The DUT and CONT terminals of a frame different from the one that is actually measured are connected. | <ul style="list-style-type: none"><li>• See section 1.5, “Connecting to the 5-Unit Frame” and properly connect the cables.</li></ul>   |
| ■ The UTP and module cable pair is unmatched.   | <ul style="list-style-type: none"><li>• See section 1.5, “Connecting to the 5-Unit Frame” and properly connect the cables.</li></ul>   |
| ■ The current line or sensing line is not connected.  | <ul style="list-style-type: none"><li>• See section 2.2, “Connecting the Output Cables” in the <i>PFX2000 Series Charge/Discharge Battery Test System Operation Manual</i> and connect the cables correctly.</li></ul> |



This chapter describes the electrical and mechanical specifications of this product.

## 5.1 Functional Specifications

| Item   |             | PFX2211 Specifications                        |
|--|-------------|---|
| Function   |             |   |
| Number of connectable frames                     |             | 12 frames                                     |
| Number of controllable external scanner channels |             | 10 channels (per frame)                       |
| Maximum number of measurement channels           |             | 120 channels (when combined with the PFX2332) |
| Measurement                                      |             |   |
| Measurable battery voltage range                 |             | -2.0 V to 20.0 V                              |
| Measurement time                                 |             | 3 s (per channel)                             |
| Measurement parameter                            | Resistance  | R [ $\Omega$ ]                                |
|  | Reactance   | $\pm jX$ [ $\Omega$ ]                         |
|  | Impedance   | $ Z $ [ $\Omega$ ]                            |
|  | Phase angle | $\theta$ [deg]                                |

## 5.2 Electrical Specifications

Unless specified otherwise, the specifications are for the following conditions.

- Ambient temperature:  $23\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$
- Ambient humidity: 20 % to 80 % RH (no condensation)

| Item                           |                 |                              | PFX2211 Specifications          |
|--------------------------------|-----------------|------------------------------|---------------------------------|
| Measurement range and accuracy |                 |                              |                                 |
| R,<br>±jX,<br> Z <br>(*1)      | 100 mΩ<br>Range | Measurement range            | 0.01 mΩ to 101.00 mΩ            |
|                                |                 | Accuracy                     | ± (0.8 % of reading + 0.8 % FS) |
|                                |                 | Resolution                   | 0.01 mΩ                         |
|                                |                 | Measurement current          | 18 mA [rms]                     |
|                                |                 | Measurement current accuracy | ±10 %                           |
|                                | 1 Ω<br>Range    | Measurement range            | 0.0001 Ω to 1.0100 Ω            |
|                                |                 | Accuracy                     | ± (0.8 % of reading + 0.8 % FS) |
|                                |                 | Resolution                   | 0.1 mΩ                          |
|                                |                 | Measurement current          | 1.8 mA [rms]                    |
|                                |                 | Measurement current accuracy | ±10 %                           |
|                                | 10 Ω<br>Range   | Measurement range            | 0.001 Ω to 10.100 Ω             |
|                                |                 | Accuracy                     | ± (0.8 % of reading + 0.8 % FS) |
|                                |                 | Resolution                   | 1 mΩ                            |
|                                |                 | Measurement current          | 0.18 mA [rms]                   |
|                                |                 | Measurement current accuracy | ±10 %                           |

| Item                                       |                   | PFX2211 Specifications                              |
|--|-------------------|---|
| Measurement range and accuracy (continued) |                   |   |
| $\theta$ (*2)                              | Measurement range | -90.0 deg to 90.0 deg                               |
|  | Resolution        | 0.1 deg   |
| Output signal                              |                   |   |
| Measurement signal                         | Frequency         | 1.0 kHz   |
|  | Accuracy          | $\pm 0.1$ %   |
| Indication                                 |                   |   |
| POWER/<br>ALARM                            | Green/red         | Blinking: Only during power-on. Blinks alternately. |
|  | Green             | Illuminated: When power is supplied.                |
|  | Red               | Illuminated: When alarm occurs.                     |
| MEASURE                                    | Green/red         | Blinking: Only during power-on. Blinks alternately. |
|  | Red               | Illuminated: Impedance being measured.              |

\*1 The value of  $|Z|$  is indicated as a value that is derived by the application based on R and jX.

\*2 The value of  $\theta$  is indicated as a value that is derived by the application based on R and jX.

## 5.3 General Specifications

| Item                  |  | PFX2211 Specifications                   |
|-----------------------|--|--|
| Temperature range     | Operating temperature range                | 0 °C to 40 °C                            |
|                       | Storage temperature range                  | -10 °C to 60 °C                          |
| Humidity range        | Operating humidity range                   | 30 % to 80 % RH (no condensation)        |
|                       | Storage humidity range                     | 20 % to 80 % RH (no condensation)        |
| Insulation resistance | Between AC input and chassis               | 100 M $\Omega$ or more at 500 VDC        |
|                       | Between input/output connector and chassis | 20 M $\Omega$ or more at 50 VDC          |
| Withstand voltage     | Between AC input and chassis               | 1 500 VAC, 10 mA or less for 1 minute    |
| AC input              | Nominal input rating                       | 200 V to 240 VAC, 50/60 Hz, single phase |
|                       | Input voltage range                        | 180 V to 250 VAC                         |
|                       | Power consumption                          | 25 VA max                                |
| TP-BUS interface      | Address                                    | Fixed                                    |
| Dimensions            |  | See outline drawing                      |
| Weight                |  | Approx. 4 kg                             |
| Accessories           |  | Binding screws: 4 pcs                    |
|                       |  | Flat washers: 4 sheets                   |
|                       |  | TP-BUS connector: 1 pc                   |
|                       |  | TP-BUS core: 1 pc                        |
|                       |  | Fuse: 2 pcs. (1 A (T), 250 VAC)          |
|                       |  | Operation manual: 1 pc                   |
|                       |  | Power cord: 1 pc                         |

## Input/output connector

| Item                                 |               |            | PFX2211 Specifications   |                   |
|--------------------------------------|---------------|------------|--|-------------------|
| TP-BUS connector                     |               |            |  |                   |
| Number of lines                      |               |            | 1 line   |                   |
| Connection                           |               |            | Connect with the Control Unit<br>Using the TP-BUS connector included in the package. |                   |
|                                      |               |            | Total length   | 200 m or less     |
|                                      |               |            | Number of twists   | 1 turn/cm or more |
| Polarity                             |               |            | None   |                   |
| Recommended wire size                | Solid line    |            | φ 0.65 (AWG22)   |                   |
|                                      | Stranded wire |            | 0.32 mm <sup>2</sup>   |                   |
| DUT connector (FRAME 1 to FRAME 12)  |               |            |  |                   |
| Number of lines                      |               |            | 12 lines   |                   |
| Connection                           |               |            | Connect with the 5-Unit Frame  |                   |
| Recommended cable                    |               |            | UTP cable  |                   |
| Pin assignments                      | 1             | FG         | Chassis ground (for sensing wire shield)   |                   |
|                                      | 2             | FG         | Chassis ground (for sensing wire shield)   |                   |
|                                      | 3             | AC SRC P   | Measured current output terminal (+)   |                   |
|                                      | 4             | AC SENSE P | Impedance detection terminal (+)   |                   |
|                                      | 5             | AC SENSE N | Impedance detection terminal (-)   |                   |
|                                      | 6             | AC SRC N   | Measured current output terminal (-)   |                   |
|                                      | 7             | +5VR       | Power to the PFX2332 scanner   |                   |
|                                      | 8             | GND        | Power to the PFX2332 scanner   |                   |
| CONT connector (FRAME 1 to FRAME 12) |               |            |  |                   |
| Number of lines                      |               |            | 12 lines   |                   |
| Connection                           |               |            | Connect with the 5-Unit Frame  |                   |
| Recommended cable                    |               |            | 4-pin modular cable  |                   |
| Pin assignments                      | 1             | NC         | Not used   |                   |
|                                      | 2             | CHSEL 0    | Frame scanner control logic (bit 0)  |                   |
|                                      | 3             | CHSEL 1    | Frame scanner control logic (bit 1)  |                   |
|                                      | 4             | CHSEL 2    | Frame scanner control logic (bit 2)  |                   |
|                                      | 5             | CHSEL 3    | Frame scanner control logic (bit 3)  |                   |
|                                      | 6             | NC         | Not used   |                   |

# 5.4 Outline Drawing




Fig. 5-1 PFX2211 Impedance Measurement Unit





