



This manual is for reference and historical purposes, all rights reserved.

This page is copyright© by M. Butkus, NJ.

This page may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

This is the full text and images from the manual. This may take 3 full minutes for the PDF file to download.

If you find this manual useful, how about a donation of \$3 to: M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701 and send your e-mail address so I can thank you. Most other places would charge you \$7.50 for a electronic copy or \$18.00 for a hard to read Xerox copy.

This will allow me to continue to buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

**If you use Pay Pal or wish to use your credit card,
click on the secure site on my main page.**

PayPal Name Lynn@butkus.org




Nikon **PRONEA S**

INSTRUCTION MANUAL


CE

E

Nomenclature



Accessories



Optional Remote Control Unit ML-L1



1. Transmitter
2. Shutter release button

Print type lever P. 26

Rubber eyecup DK-11 P. 62

Speedlight lock-release lever
P. 30

Finder eyepiece P. 62

Exposure mode dial P. 24

Diopter adjustment lever
P. 62

Film cartridge
chamber cover P. 20

Battery chamber cover
lock release P. 16

LCD panel P. 4

Battery chamber P. 16

Hatch cover

Tripod socket

Inside the hatch

Mid-roll rewind/SEL (select) button PP. 38, 53


DATE/T/Self-timer/Remote
control button PP. 54, 59, 60

ADJ (adjust)/Flash sync mode button
PP. 53, 64


Exposure compensation
button P. 51

Language button P. 57

Title button P. 57




LCD Panel/Viewfinder Display



- | | |
|------------------------------|--|
| 1. Shutter speed/date | 7. Aperture/date |
| 2. Data recording (page 54) | 8. Title (page 57) |
| 3. Battery power (page 17) | 9. Language (page 57) |
| 4. Flash sync mode (page 63) | 10. Frame counter/exposure compensation value (pages 21, 51) |
| 5. Self-timer (page 59) | 11. Exposure compensation (page 51) |
| 6. Film cartridge (page 21) | 12. Remote control (page 60) |

NOTE: About LCD

- At high temperatures of 60°C (140°F) or above, the display turns black, making it impossible to read. It returns to normal when the temperature drops to 20°C (68°F).
- At temperatures below freezing, the LCD's response time slows; when the temperature rises, it returns to normal.



1. Exposure compensation mark
(page 51)

2. Shutter speed


3. Aperture

4. Focus indicator (page 27)


5. Flash recommended/ready-light
(page 30)

6. Focus brackets (page 27)

- The print type selected in the illustration above is wide-vision (H) (V:H = 9:16 aspect ratio).
- Rotate the print type lever to select print type H, P or C; the viewfinder display changes accordingly.



Panorama (P) print type (V:H = 1:3 aspect ratio)



Classic (C) print type (V:H = 2:3 aspect ratio)

Introduction

Thank you for purchasing the Nikon PRONEA S camera. We are sure that you will enjoy using this camera and that it will make photography a bigger part of your life. Before using your PRONEA S camera, be sure to read this manual thoroughly. Also, we recommend that you keep this manual handy.

■ Main features of the PRONEA S:

- The Nikon PRONEA S employs the Advanced Photo System, making it possible for you to enjoy both the portability of a compact camera and the exciting features offered by an SLR camera.
- The individual exposure modes are displayed on the exposure mode dial for one-touch changing of modes and quick set-up for advanced picture-taking.
- The PRONEA S's new Auto-Servo AF is so advanced that it can detect whether a subject is stationary or moving, and also detects direction. According to the detected information, it automatically chooses to lock focus or activate focus tracking—either way, you're assured autofocus that works fast, accurately, and easily.

■ Take trial shots

Take trial shots before shooting at important occasions like weddings or graduations.


■ Have Nikon spot check your camera regularly

Nikon recommends that you have your camera serviced by an authorized dealer or service center at least once every two years.

■ Using your camera correctly

The Nikon PRONEA S's performance has been optimized for use with Nikon brand accessories. Accessories made by other manufacturers may not meet Nikon's criteria for specifications, and nonconforming accessories could damage the PRONEA S's components. Nikon cannot guarantee the PRONEA S's performance when it is used with accessories by makers other than Nikon.

About Advanced Photo System

The Nikon PRONEA S camera employs the Advanced Photo System (IX240). IX240 cameras are identified by the  symbol.

Advanced Photo System provides the following features:

- Film loading is extremely simple, and the film status can be confirmed via the Visual Exposure Indicator (VEI). Mid-Roll Change is also possible.
 - With IX240 film you don't have to pull out the film leader.
 - Four types of Visual Exposure Indicators on the film cartridge enable you to determine film status—unexposed, partially exposed, fully exposed or processed.
 - Mid-Roll Change (page 39) enables you to rewind film before you reach the end of the roll, then use the partially exposed film (used in this camera or another Nikon IX240 camera) again.
- Three print types are available on the same film.
 - Wide-vision with 9:16 aspect ratio, panorama with 1:3 or classic with 2:3 print types can be selected.



Wide-vision (H) print type
(9:16 aspect ratio)



Panorama (P) print type (1:3 aspect ratio)



Classic (C) print type
(2:3 aspect ratio)

www.butkus.us

■ **Date/time and provided short messages can be imprinted**

- Messages (as many as 30 in up to 12 languages), as well as the date and time, can be imprinted on the picture.

■ **For processing and printing IX240 films**

We recommend bringing your IX240 film cartridge to a photofinisher displaying the "Certified Photofinisher Mark" sign for processing and printing.



Certified photofinishers offer the following services

- Three different print types
Classic (C), wide-vision (H) and panorama (P) types are available.
- Data printing
See page 53.
- Index Prints
Positive images of all exposed frames are printed on one sheet.
- Negative Return in Cartridge (NRIC)
Your negatives are returned inside the cartridge for easy storage.

For further details, ask your certified photofinisher.

Contents

The “BASIC OPERATION” section introduces battery, lens, film, focusing, exposure and shooting in basic steps for easy picture-taking—even for SLR camera beginners.


“DETAILED OPERATION” explains each function from lens to exposure in detail, in approximately the same order as the steps in the “BASIC OPERATION” section. After becoming familiar with basic shooting, refer to the detailed explanation of each operation/function to step up to advanced shooting that requires more advanced techniques.

“Flash Photography” introduces flash photography using the PRONEA S’s built-in Speedlight in the dark, as well as other flash-shooting situations in bright conditions. Please read this manual thoroughly and carefully to get the most out of your Nikon PRONEA S.

PREPARATION.....2-13

Nomenclature	2-3
LCD Panel/Viewfinder Display.....	4-5
Introduction	6-7
About Advanced Photo System.....	8-9
About This Manual	12-13

BASIC OPERATION.....15-32

1. Install Batteries and Check Battery Power.....	16-17
2. Mount Lens	18-19
3. Load Film	20-21
4. Set Focus Mode Selector to AF	22-23
5. Set Exposure Mode Dial to 	24-25
6. Select Print Type, Hold Camera and Focus	26-27
7. Confirm Indications in Viewfinder and Release Shutter	28-29
8. Using Built-In Speedlight	30-31
About Focus and Exposure	32

www.butkus.us

DETAILED OPERATION33-68

Lens Compatibility.....	34-36
Film.....	37-39
Focus Mode.....	40-41
Focus Lock.....	42
Shooting in Each Exposure Mode.....	43-46
General-Purpose Program.....	43
Auto-Multi Program.....	44
Shutter-Priority Auto.....	45
Aperture-Priority Auto.....	46
Vari-Program.....	47-48
Flexible Program/Exposure Metering System.....	49
Long Time Exposure (Bulb).....	50
Exposure Compensation.....	51
Print Type.....	52
Setting/Imprinting Date/Time.....	53-55
Setting/Imprinting Language/Title.....	56-58
Self-Timer Operation.....	59
Remote Control Operation/Time Exposure (optional).....	60-61
Diopter Adjustment/Eyepiece Cap.....	62
Flash Photography.....	63-67
Available Mode Combinations.....	68

MISCELLANEOUS69-81

Optional Accessories.....	70
Camera Care.....	71-72
Notes on Batteries.....	73
Troubleshooting.....	74-76
Specifications.....	77-79
Index.....	80-81


About This Manual

Basic Operation

P. 15-32

- 1** Install Batteries and Check Battery Power

P. 16-17




- 2** Mount lens

P. 18-19




- 3** Load Film


P. 20-21




- 4** Set Focus Mode Selector to AF

P. 22-23




- 5** Set Exposure Mode Dial to  AUTO

P. 24-25



- 6** Select Print Type, Hold Camera and Focus

P. 26-27



- 7** Confirm Indications in Viewfinder and Release Shutter

P. 28-29



- 8** Using Built-In Speedlight

P. 30-31

www.butkus.us







Notes on Batteries (P. 73)

Lens Compatibility (P. 34-36)—CPU Nikkor lens (P. 34)/Non-CPU lens (P. 35)/
Focal Length Conversion (P. 36)

Film (P. 37-39)—About IX240 film (P. 37)/Mid-roll rewind (P. 38)/In case film does not start rewind
or film rewind stops at mid-roll (P. 38)/Mid-Roll Change (P. 39)

Focus Mode (P. 40-41)—Autofocus (P. 40)/AF-Assist Illuminator (P. 40-41)/
Manual focus (P. 41);
Focus Lock (P. 42)


Shooting in Each Exposure Mode (P. 43-46)—: General-Purpose Program (P. 43)/**P**: Auto-Multi
Program (P. 44)/**S**: Shutter-Priority Auto (P. 45)/**A**: Aperture-Priority Auto (P. 46); **Vari-Program**
(P. 47-48)—**z**: Portrait (P. 48)/: Landscape (P. 48)/: Close-Up (P. 48)/: Night Scene (P. 48);
Flexible Program/Exposure Metering System (P. 49); Long Time Exposure (Bulb) (P. 50); Exposure
Compensation (P. 51)

Print Type (P. 52); Setting/Imprinting Date/Time (P. 53-55); Setting/Imprinting Language/Title
(P. 56-58); Self-Timer Operation (P. 59); Remote Control Operation/Time Exposure (P. 60-61);
Diopter Adjustment/Eyepiece Cap (P. 62); Available Mode Combinations (P. 68)


Flash Photography (P. 63-67)—Built-in Speedlight and Matrix Balanced Fill-Flash (P. 63)/Flash
sync mode (P. 63)/Using the built-in Speedlight (P. 64-66)/Usable lenses with built-in Speedlight
(P. 66)/Flash shooting distance range (P. 67)/Wireless Slave Flash Controller SU-4 (P. 67)


Blank
Butkus.us

BASIC OPERATION

This section guides you through basic operations with the camera set to  mode.

Settings are as follows:


Attached lens	IX-Nikkor
Focus mode	Autofocus
Exposure mode	 (General-Purpose Program)
Exposure metering	Matrix Metering
Built-in Speedlight	Normal sync*

* Automatically set when exposure mode is set to .

Install Batteries and Check Battery Power



1

Use two CR2-type lithium batteries with this camera. (1.5V AA-type batteries can be used in combination with optional Power Pack MB-11.)



1.1



Turn off the power switch and open the battery chamber cover.



- The batteries that power the camera also supply power to the date/time display. Set the date/time (page 53) after installing batteries for the first time. When changing batteries, previously set date/time remains in the camera's memory for about five minutes without the batteries. If the camera is left without batteries for more than five minutes, you must reset the date/time.

1.2

Insert batteries with the “+” and “-” ends positioned as marked inside the battery chamber, then firmly close the battery chamber cover.








- Incorrect positioning of + and - poles may cause damage to the camera.
- Install one battery to the - side (the side with the spring) first, then insert the other battery, pressing down to ensure it is all the way in the chamber.

✓ Check points



- ☐ Keep the batteries out of the reach of children. If swallowed, contact a doctor immediately. (For "Notes on Batteries", see page 73.)
- ☐ When replacing batteries, be sure to turn the power switch off and replace both batteries at the same time. Always use fresh batteries of the same brand.
- ☐ We recommend that you take spare batteries with you, especially when traveling, since the batteries used may be difficult to obtain in some areas.

1.3 Turn on the power switch and confirm battery power with the indication.



- Battery power
 -  appears: Sufficient battery power.
 -  appears: Batteries are nearing exhaustion. Have a fresh set ready. (The indication disappears in the viewfinder when the finger is removed from the shutter release button.)
 -  blinks: Batteries are exhausted. Replace batteries. (The shutter locks.)
- Shutter speed and aperture indications in the LCD panel and viewfinder automatically turn off if the camera's power switch is turned on and the camera is left unused for 5 sec.

1.4 Lightly press the shutter release button to activate the exposure meter.




- Lightly pressing the shutter release button reactivates the exposure meter and the shutter speed and aperture indications in the LCD panel and viewfinder. The indications automatically turn off 5 sec. after you release the shutter release button.

2



Mount Lens

Turn the power switch off and mount the lens. When attaching a CPU lens other than IX-Nikkor, set the lens' aperture to its minimum setting (largest f-number).



2.1

Turn the power switch off and mount lens to the camera body.



- Position the lens in the camera's bayonet mount so that the mounting indexes on the lens and the camera body are aligned, then twist the lens counterclockwise until it locks in place. (Be sure not to touch the lens release button.)
- When the lens is not attached or when a non-CPU lens is attached and the power switch is turned on, F - - blinks in the LCD panel and viewfinder and the shutter cannot be released. (F - - appears and the shutter can be released when the exposure mode is set to Shutter-Priority Auto.)

2.2

Detaching the lens.





- Push and hold the lens release button, then turn the lens clockwise.
- If you leave the camera unattended without a lens attached, be sure to attach the supplied body cap, or optional body cap BF-1A. (BF-1 body cap cannot be used.)

✓ Check points

- ☐ Use an IX or D-type AF Nikkor lens in order to utilize all the functions of this camera. (See page 34 for Lens Compatibility.)
- ☐ Make sure to turn the power switch off and avoid direct sunlight when attaching/detaching the lens.
- ☐ When attaching the lens, take care not to press the lens release button.



2.3 When attaching a CPU lens other than IX-Nikkor, set the lens' aperture ring to its minimum setting and lock.



- When the lens' aperture ring is not set to its minimum and the power switch is turned on, FEE blinks in the LCD panel and viewfinder and the shutter cannot be released.
- Since IX240 film differs in size from 135 film, the images obtained by the same lens are also different. (Page 36.)

NOTE: Mount IX-Nikkor lens carefully


Do not bump the aperture coupling lever inside the camera's mounting flange against the rear edge of the lens (lens protector). A damaged aperture coupling lever could cause the camera to malfunction.



3


Load Film

Turn the power switch on and load the film cartridge. When the film cartridge chamber cover is closed, the film automatically advances to the first frame and the film speed is set automatically (ISO25-10000).



3.1

Confirm the film status via the Visual Exposure Indicator on the film cartridge.





- : Unexposed film inside cartridge
- D: Partially exposed film inside cartridge
- ⊗: Fully exposed but unprocessed film inside cartridge
- : Processed film inside cartridge

- Before installing film, confirm that the Visual Exposure Indicator shows ○ (unexposed) or D (partially exposed).

3.2

Turn the power switch on, open the film cartridge chamber cover by turning the lock release, and then install the film cartridge.






- Insert the film cartridge all the way into the cartridge holder on the back of the cover.

✓ Check points

- ☐ Use only IX240 film with the PRONEA S. (Do not use conventional 135 film.)
- ☐ Before installing film, confirm the film status via the Visual Exposure Indicator on the film cartridge. Partially exposed film can also be reinstalled. For details, see page 39.
- ☐ Check the LCD panel to ensure that the film has been installed correctly.
- ☐ When changing film outdoors, avoid exposing the film cartridge to direct sunlight.

3.3 Gently close the film cartridge chamber cover until the lock release snaps closed. The film automatically advances.



- When  and the number of available frames appear on the LCD panel, the film has advanced.
- When **Err** and  blink on the LCD panel, the film is not properly installed or fully exposed or processed film is installed. Open the film cartridge chamber cover again and reload the film properly or load new film.
- Film is automatically rewound when the film reaches the end of the roll. (See page 29.)


NOTE: Closing the film cartridge chamber cover

Using too much force when closing the film cartridge chamber cover can cause damage to the internal mechanism. Make sure to close the cover gently.

4


Set Focus Mode Selector to AF

When the focus mode selector is set to AF (autofocus), the camera focuses automatically.



4.1

Set the focus mode selector to AF (autofocus).



- Make sure to turn the focus mode selector until it clicks into position.
- To focus, lightly press the shutter release button. (See page 27.)

4.2

Situations where autofocus may not work as expected:

- Autofocus may not work as expected in the following situations. In such situations, focus on a different subject located at the same distance, use focus lock, (page 42) then recompose.
- When you are unable to perform focus lock, set the focus mode selector to **M** (manual) and focus manually using the clear matte field.


☒ Check points

- ☐ Do not attempt to rotate the lens' focus ring manually with the focus mode set to AF.
- ☐ With the focus mode set to AF, the shutter cannot be released when the subject is out of focus. For details on focus mode, see page 40.



Low-contrast scenes

Ex. Where the subject is wearing the same color clothing as a wall or other background.




Patterned subject or scene

Ex. The windows of a building.



Scenes where subjects are located at different distances within the focus brackets


Ex. When shooting an animal inside a cage or a person in a forest.




Scenes in which there is a pronounced difference in brightness within the focus brackets


Ex. When the sun is in the background and your main subject is in shadow.

Set Exposure Mode Dial to

With the exposure mode set to  (General-Purpose Program), the camera automatically controls your exposure.



Set the exposure mode dial to .








- Shutter speed and aperture appear on the LCD panel when the shutter release button is lightly pressed.

- ☐ Eight exposure modes are available with this camera. Four types of Vari-Programs enable you to easily choose proper exposure controls in various shooting situations.

See step 5.2 for the summary of each exposure mode and each reference page for the operating instructions and details.

5.2


About exposure mode and type of program

Symbol	Exposure mode/ Type of program	Characteristics/shooting situations
	General-Purpose Program P. 43	The easiest exposure mode for general shooting. Suitable for portraits and other general pictures, or when you want to take pictures first-hand.
P	Auto-Multi Program P. 44	The camera controls exposure automatically, while allowing you to make other settings, such as Flexible Program or exposure compensation.
S	Shutter-Priority Auto P. 45	You set your desired shutter speed, and the camera selects the correct aperture. You can "stop" the motion of a moving subject with a fast shutter speed or create blur with a slower speed.
A	Aperture-Priority Auto P. 46	You set the desired aperture, and based on that, the camera selects the correct shutter speed. The camera lets you determine the depth of the in-focus area; near and far subjects can be sharply focused or the background can be blurred.
Vari-Program	 Portrait Program P. 48	Use this program to take portraits. With a shallow depth of field (in-focus area), it creates a blurred background to accentuate your main subject.
	 Landscape Program P. 48	Use this program to take pictures of distant scenes. With a deep depth of field, the overall landscape will be sharply focused.
	 Close-Up Program P. 48	Use this program to take up-close pictures. With a shallow depth of field, your close-ups will be taken with an artistically blurred background.
	 Night Scene Program P. 48	Use this program in the evening or at night. Even a very dark subject will be exposed so it captures the beauty of all the light available in your night scene.

Select Print Type, Hold Camera and Focus



H, P and C print types are available.
(Page 52.)

Lightly pressing the shutter release button automatically focuses the camera on the subject and, when the subject is in focus, causes ● to appear in the viewfinder.



6.1

Select print type and hold the camera properly.



- H, P or C print types (aspect ratio of 9:16, 1:3 or 2:3 respectively) can be selected. Explanations in this section are based on H print type. See page 52 for details on print types.
- Stand with one foot a half step forward and keep your upper body still. Keep your elbow propped against your body for support, grasp the camera handgrip with your right hand and use your left hand to cradle the lens.
- In general, you should set the shutter speed faster than '1/focal length of your lens' sec. (Example: when using a 50mm lens, set the shutter speed faster than 1/50 sec.) Use of a tripod is recommended for shooting at slower shutter speeds.



NOTE: Composing frame

The frame coverage of this camera's finder is approximately 87% of the actual exposed frame on the film. Therefore, the actual exposed frame is somewhat larger than the image you see through the viewfinder. Also, frame coverage of the finder is approximately 95% of the actual printed frame. Note that the edges of a film negative are partially cropped by most labs.

✓ Check points

- ☐ Diopter adjustment (page 62) is available to enable you to see through the viewfinder more clearly.
- ☐ To take a picture of an off-center subject, use focus lock (page 42).
- ☐ Date/time (page 53) and as many as 30 kinds of messages in up to 12 languages (page 56) can be imprinted on your photos (pages 54, 57).

6.2 Compose the frame and focus by lightly pressing the shutter release button.



- Center the focus brackets on your subject and lightly press the shutter release button. The camera focuses automatically and the focus indicator appears or blinks.
 - appears: Subject is in focus. In some cases with a moving subject, ● may not appear when the subject is in focus and ● appears simultaneously with the shutter release.
 - ◀ appears: Subject is located closer than the lens' closest focusing distance.
 - ▶◀ blinks: Unable to focus with autofocus.


When the subject is dark, the camera's AF-Assist Illuminator is activated to achieve correct focus. For details on focusing, see page 40.

- To take a picture of a subject outside the focus brackets, use focus lock (page 42).
- In situations where autofocus may not work as expected, see page 22.

Confirm Indications in Viewfinder and Release Shutter



7


Confirm that ● (focus indicator) appears in the viewfinder, then release the shutter by slowly and fully depressing the shutter release button. See page 40 for a moving subject.



7.1



Confirm the indications in the viewfinder while lightly pressing the shutter release button.



- When  (ready-light indication) blinks, use the built-in Speedlight. (See pages 30, 63.)
- If a warning indication appears in the viewfinder, see page 74.

7.2

Confirm that the focus indicator ● appears without blinking and slowly and fully depress the shutter release button.




- After the shutter is released, the film automatically advances to the next frame and the next shot can be taken.

✓ Check points


- ☐ Focus, shutter speed and aperture can be confirmed in the viewfinder. If any other indications appear, see page 74.
- ☐ When you reach the end of the film roll, the film starts to rewind automatically.
- ☐ For details on Mid-roll rewind, see page 38.
- ☐ For self-timer operation and remote control operation, see pages 59, 60.
- ☐ See page 9 before you have your film processed.

7.3 The film starts to rewind automatically when it reaches the end of the roll.




- The frame counter shows the number of exposure, and **0** appears in the LCD panel during film rewind and the frame counter counts backwards until rewind is complete.
- Data is recorded during film rewinding. To ensure proper recording, do not subject the camera to shock or vibration during rewinding. See also pages 38, 55 and 58.

7.4 Confirm that the film is completely rewound, then remove the film cartridge.



- The film is completely rewound when the frame counter shows “E” and **0** blinks. Open the film cartridge chamber cover gently, slide the lever on the film holder and remove the film cartridge. If the shutter release button is depressed while rewound film is still in the film cartridge chamber, “**0**” blinks. Remove the film cartridge.
- When removing the film cartridge, be careful not to drop it.


Using Built-In Speedlight


If  (ready-light indication) blinks in the viewfinder when you lightly press the shutter release button, use the built-in Speedlight.



8.1

Slide the Speedlight lock-release lever to release the Speedlight.



- As soon as the Speedlight is released it starts recharging, and when the Speedlight is ready to fire  appears without blinking in the viewfinder (when the camera's meter is on).
- To close the Speedlight, press gently until it clicks shut. (To conserve power, keep the Speedlight closed when it is not in use.)

Matrix Balanced Fill-Flash

Matrix Balanced Fill-Flash enables proper evaluation of exposure for the main subject and background, and ensures adequate flash output. (For details, see page 63.)


NOTE: Continuous use of built-in Speedlight


After continuous use of the built-in Speedlight, it may stop firing to protect the firing tube. Wait for a while before using the Speedlight again.

✓ Check points

- ☐ The built-in Speedlight offers an angle of coverage of 24mm lens with a guide number of 16/52 (ISO200, m/ft.) at 1m (3.3 ft.) or longer shooting distance.
- ☐ Using a CPU lens enables you to perform Matrix Balanced Fill-Flash shooting. (For details, see page 63.)
- ☐ Be sure to remove (or store) the lens hood before flash shooting.
- ☐ Some zoom lenses have limitations regarding Speedlight use and vignetting may occur. (For details, see page 66.)

8.2 Confirm appears without blinking in viewfinder, then compose, focus and take the picture.



-  blinks in the viewfinder approx. 3 sec. after full flash output. If this happens, underexposure may have occurred. Check the flash shooting distance range (page 67) and shoot again.
- Normal sync mode is introduced in this section. Flash with Red-Eye Reduction, which reduces the “red-eye” effect with a person or animal, and Slow Sync flash, which brings out the background details, are also available. For details, see page 63.
- With dark subjects (within 0.5m to 3m or 1.6 to 9.8 ft.), the camera’s AF-Assist Illuminator (page 40) is automatically activated to guide autofocus.

About Focus and Exposure

Focus, exposure and the metering system are important factors in taking pictures. Knowing the characteristics of each helps you widen your photographic expression.

■ Focus and depth of field

When focusing, depth of field should be considered. Depth of field is the zone of sharpest focus in front of and behind the subject on which the lens is focused. It varies according to shooting distance, focal length and, above all, aperture. Smaller apertures (larger f-numbers) will produce a deeper depth of field where the background and foreground become sharper; larger apertures (smaller f-numbers) will produce a shallower depth of field where the background becomes blurred.

■ Exposure

Light from the subject passes through the lens and is sensed by the film. Light reaching the film is controlled by the shutter speed and aperture. The proper combination of shutter speed and aperture for subject brightness and film sensitivity results in the correct exposure.

The PRONEA S's General-Purpose Program, Auto-Multi Program and Vari-Program automatically control shutter speed and aperture. In Shutter-Priority Auto exposure mode, you can manually set the shutter speed and the camera automatically sets the proper aperture. In Aperture-Priority Auto exposure mode, you can manually set aperture and the camera automatically sets the proper shutter speed.

■ Metering System

As the proper combination of shutter speed and aperture for correct exposure is determined according to subject brightness and film sensitivity, measuring subject brightness is very important.

In general, brightness inside the viewfinder is not uniform. The PRONEA S provides Matrix Metering. With Matrix Metering, data on scene brightness is detected by the six-segment Matrix sensor.

(With IX-Nikkor and D-type AF Nikkor lenses, the PRONEA S camera performs 3D Matrix Metering. See page 49.)


Butkus US

DETAILED OPERATION


This section features detailed descriptions of all camera functions—including lens, film, focus, exposure and more.

Lens Compatibility

- Use a CPU lens with this camera. IX-Nikkor and D-type AF Nikkor lenses give you access to all available functions.



CPU contacts of CPU lens



D-type AF Nikkor

- Types of CPU lenses and other usable lenses

Lens \ Mode		Focus mode			Exposure mode	Metering system	
		Autofocus	Manual with electronic rangefinder	Manual	AUTO, P, S, A, $\frac{1}{x}$, $\frac{1}{y}$, $\frac{1}{z}$, $\frac{1}{w}$	Matrix	
						3D 6-segment	6-segment
CPU Nikkor	IX-Nikkor						—
	D-type AF Nikkor	○	○	○	○	○	—
	AF-S, AF-I Nikkor						
	AF-I Teleconverter*1						
	Non-D-type AF Nikkor (except AF Nikkor for F3AF)	○	○	○	○	—	○
AI-P Nikkor		—	○*2	○	○	—	○
Non-CPU lens		—	○*2	○	△*3	—	—

*1 Make sure to set the lens' aperture to its minimum setting. (FEE warning does not blink in the LCD and viewfinder.)

*2 With maximum aperture of f/5.6 or faster.

*3 Set the exposure mode to S. The shutter speed and aperture can only be set manually. (See the next page for details on using a non-CPU lens.)

When a non-CPU lens is attached

- Usable exposure modes are limited.

A non-CPU lens can be used only when the exposure mode is set to **S** (Shutter-Priority Auto) and the shutter speed and aperture can only be set manually. With a non-CPU lens, the exposure meter cannot be activated. **F - -** appears in place of the aperture indication in the LCD panel and viewfinder; set/confirm the aperture using the lens' aperture ring.

NOTE: Nikkor lenses that cannot be attached to the PRONEA S

The following Nikkor lenses cannot be attached to the PRONEA S (camera body or lens may be damaged):


- AF Teleconverter TC-16A
- Non-AI lenses
- 400mm f/4.5 and 600mm f/5.6 with Focusing Unit AU-1
- Fisheye 6mm f/5.6 and Fisheye OP 10mm f/5.6
- ED 180-600mm f/8 (No. 174166 or smaller)
- ED 360-1200mm f/11 (No. 174087 or smaller)
- 200-600mm f/9.5 (No. 300490 or smaller)
- 80mm f/3.5, 200mm f/3.5 and TC-16 Teleconverter for F3AF
- PC 28mm f/4 (No. 180900 or smaller)
- PC 35mm f/2.8 (No. 906200 or smaller)
- Reflex 1000mm f/11 (No. 142361 to 143000)
- Reflex 2000mm f/11 (No. 200310 or smaller)
- Medical 120mm f/4
- Medical 200mm f/5.6

- When a Nikkor lens with tripod socket is attached to the camera, make sure to always hold the lens instead of the camera body.

Lens Compatibility—continued

Focal Length Conversion



The frame size of conventional 135 film is 24 x 36mm, and an IX240 film frame measures 16.7 x 30.2mm. Because IX240 film differs in size from 135 film, images obtained using the same lens will also differ.



- The size of one IX240 film frame is approximately 0.8 times that of conventional 135 film in diagonal line. Therefore, the focal length of 135 format x 0.8 is equal to the focal length of the IX240 format, and focal length of IX240 format x 1.25 is equal to the focal length of the 135 format, yielding the same picture angle.
- The following table shows the approximate focal length of the IX240 and 135 formats: (mm)

IX240 (H type)	19	20	22	24	28	30	40	48	56	60	68	70	84	108	144	160	180
135	24	25	28	30	35	37.5	50	60	70	75	85	87.5	105	135	180	200	225

About IX240 film





- Conventional 135 film cannot be used with the PRONEA S.
- 15-, 25- and 40-exposure IX240 films are available.
- The film leader of IX240 film is inside the cartridge and is automatically pulled out and rewound when the film is loaded.
- Four types of Visual Exposure Indicators on the film cartridge enable you to determine the film status. Before installing film, confirm that the Visual Exposure Indicator shows ○ (unexposed) or ⌋ (partially exposed).



NOTE: IX240 film cartridge

- Do not disassemble or subject to shock or vibration.
- Do not touch the data disk. Doing so may inhibit proper operation and/or processing.
- Do not break the Irreversible Processed Indicator (IPI) on the cartridge, as film processing and printing may become impossible. Consult your photofinisher if the IPI is broken.
- Do not press on the lightlock door drive with a pointed object (e.g., a pen), as this may damage the camera body or cause the camera to malfunction. This may also open the door and expose the film.
- Do not attempt to rotate the cartridge spool with a pointed object (e.g., a screwdriver). This can expose the film, alter the Visual Exposure Indicator (VEI), or inhibit proper operation and/or processing.
- Do not store the film cartridge:
 - a) In direct sunlight, near heating devices, appliances or in a hot place.
 - b) Around dirt or dust.
 - c) In hot or humid and moldy environments.
 - d) Near strong magnetic devices (e.g. motors or transformers).
- Condensation may occur when using a film stored at low temperatures such as in a refrigerator. If a film is loaded with condensation, data may not be read properly and the camera may identify the film as already exposed.


Film—continued



Mid-roll rewind




- To rewind film at mid-roll, press and hold the  (mid-roll rewind) button for more than 0.5 sec. When the film is completely rewound, ϵ appears and  blinks in the LCD panel. Open the film cartridge chamber cover and remove the film cartridge. (Page 29.)
- Same as the film rewind at the end of the film roll, data is recorded during film rewinding.

In case film does not start to rewind or film rewind stops at mid-roll



- When battery power is very low, or when the ambient temperature is low, the film may not start rewinding or film rewind may stop at mid-roll, and  and ϵ rr blink in the LCD panel. In this case, turn off the power switch, change batteries, then turn on the power switch to rewind the film again. When film rewind resumes, ϵ rr,  and $\cdot\cdot$ blink and data is not recorded on the data disk of the film cartridge.


Mid-Roll Change



- Mid-Roll Change enables you to rewind film before you reach the end of the roll, then reuse the partially exposed film (used in this camera or another Nikon IX240 camera). When partially exposed film is installed, the camera automatically advances the film to the frame immediately after the last exposed frame and becomes ready to resume shooting from that frame.
- Before installing partially exposed film (page 37), confirm that the Visual Exposure Indicator shows D (partially exposed).
- The Mid-Roll Change can be performed reciprocally with the Nikon PRONEA 600i/6i, the Nuvis 160i and this camera.



NOTE: Reloading partially exposed film

- Avoid strong magnetic fields such as near TV sets or speakers when re-installing partially exposed film. Take special care to avoid re-installing near an optional Speedlight while it is charging. Doing so may cause the camera to malfunction and automatically advance the film to the end.
- Film advance stops if any noise is detected while the film is advancing to the frame immediately after the last exposed frame. Turn the power switch off and turn it on again, or remove and reload the film cartridge. Film advance resumes.



Focus Mode

Autofocus




- With the focus mode selector set to AF, lightly pressing the shutter release button automatically focuses the camera on the subject and causes ● to appear in the viewfinder.

Auto-Servo AF:


Camera automatically chooses Single Servo AF or Continuous Servo AF operation according to the subject status, i.e. stationary or moving (including directional information).

1. **Single Servo AF:** Once focused on a subject, focus is locked.
 2. **Continuous Servo AF:** The camera continuously focuses on a moving subject.
- In either case, the shutter can be released when the subject is in focus and ● appears in the viewfinder. However, in some cases with a moving subject, the shutter can be released when the subject is in focus (without ● indication) and ● appears simultaneously with the shutter release.

AF-Assist Illuminator



With the Speedlight down



With the Speedlight up



- The AF-Assist Illuminator provides the necessary illumination to focus on dark subjects. The camera activates the AF-Assist Illuminator in the following conditions.
1. When an AF Nikkor lens is attached, the focus mode is set to AF, and the subject is dark.
 2. When exposure mode is not set to Landscape.

The AF-Assist Illuminator is activated automatically and cannot be canceled. It is effective for lenses with a focal length of 22mm to 180mm, and the effective focus distance is 0.5 to 3m (1.6 to 9.8 ft.) with the built-in Speedlight on, or 0.5 to 2m (1.6 to 6.6 ft.) with the Speedlight off.

NOTE: Continuous use of AF-Assist Illuminator

After continuous use of the AF-Assist Illuminator, it may stop emitting light in order to protect the firing tube. Wait for a while before using the Illuminator again.

Manual focus



- Set the focus mode selector to **M**. Look through the viewfinder and rotate the lens focusing ring until the image appears sharp on the clear matte field in the viewfinder. The shutter can be released whether or not the subject is in focus. Use Manual focus in situations where autofocus may not work as expected (page 22) or when a lens other than AF Nikkor (page 35) is attached.


Electronic Rangefinder

Lightly pressing the shutter release button and rotating the lens focusing ring activate the Electronic Rangefinder to indicate the focus status in the viewfinder. When the subject within the focus brackets is in focus, ● appears in the viewfinder. In manual focus, the shutter can be released anytime. The Electronic Rangefinder works with most Nikkor lenses (including IX-Nikkors and AF Nikkors when operated manually) having a maximum aperture of f/5.6 or faster.

Focus Lock


- Focus Lock proves useful in autofocus shooting when you want to capture an off-center subject. It is also effective in situations where autofocus may not work as expected (page 22).

1 Position the focus brackets on the subject and lightly press the shutter release button.



- ● appears when the subject is in focus. The focus remains locked as long as you continue to hold down the shutter release button.
- When you want to lock focus on a stationary subject that has been moving and tracked with Continuous Servo AF (changed to Single Servo AF from Continuous Servo AF), remove your finger from the shutter release button once and focus again.

2 Confirm focus indicator ● then (while keeping shutter release button lightly pressed) recompose and shoot.



- After you have locked the focus, do not change the camera-to-subject distance. If you keep the shutter release button lightly pressed after releasing the shutter, the shutter can be released repeatedly with the same focusing.

www.butkus.us


Shooting in Each Exposure Mode


AUTO: General-Purpose Program

This is the simplest exposure mode with this camera. The camera automatically controls your exposure. This program is recommended for SLR camera beginners.





For available mode combinations, see page 68.

1 Set the exposure mode dial to .



- With the exposure mode set to , flash sync mode is automatically set to Normal sync. Flexible Program, exposure compensation and Slow Sync flash cannot be used.

2 Confirm focus indicator ● and shoot.

- When the subject is too dark or too bright, one of the following warning indications appears in the LCD panel or viewfinder.
 -  : Use ND filter.
 -  : Use Speedlight.

Difference between (General-Purpose Program) and P (Auto-Multi Program)

Although exposure controls are the same, with Auto-Multi Program, you can select functions such as Flexible Program (page 49), exposure compensation (page 51) or Slow Sync flash (page 63) for more flexible shooting.


Shooting in Each Exposure Mode—continued

■ P: Auto-Multi Program

The camera automatically controls your exposure to achieve the correct exposure in any shooting situation. For more complex shooting, use Flexible Program (page 49) or exposure compensation (page 51).
For available mode combinations, see page 68.



1 Set the exposure mode dial to P.



2 Confirm focus indicator ● and shoot.

- Flexible Program, in which the combination of shutter speed and aperture can be shifted while maintaining the correct exposure, can be used in Auto-Multi Program. (P. 49.)
- When the subject is too dark or bright, one of the following warning indications will appear in the LCD panel or viewfinder:
 - \mathcal{H} : Use ND filter.
 - \mathcal{L} : Use Speedlight.


■ S: Shutter-Priority Auto

Enables you to manually set the desired shutter speed (30-1/2000 sec.); the camera automatically selects the proper aperture to provide the correct exposure. With higher shutter speeds, you can freeze the motion of a fast-moving subject; with slower speeds, you can create a motion effect.

For available mode combinations, see page 68.



- 1 Set the exposure mode dial to **S** and set the shutter speed (30-1/2000 sec.) with the Command Dial.



- 2 Confirm focus indicator ● and shoot.

- When the subject is too dark or bright, one of the following warning indications will appear in the LCD panel or viewfinder:
 - **H**: Select higher shutter speed. If the warning indication persists, use an ND filter.
 - **L**: Select a slower shutter speed. If the warning indication persists, use the Speedlight.
- Only **S** mode can be used with a non-CPU lens and the shutter speed and aperture can only be set manually. With a non-CPU lens, the exposure meter cannot be activated. **F--** appears in place of the aperture indication in the LCD panel and viewfinder; set/confirm aperture using the lens' aperture ring.
- Select Long Time Exposure (Time or Bulb) by setting the shutter speed indication to **bulb** (blinking). For details on Long Time Exposure, see pages 50, 61.

Shooting in Each Exposure Mode—continued


A: Aperture-Priority Auto

Enables you to manually set the desired aperture. The camera automatically selects a suitable shutter speed to give you the correct exposure. By varying the aperture, and thus controlling the depth of field, you can make the background and foreground sharper, or blur the background. In flash photography, varying the aperture changes the flash shooting distance.

For available mode combinations, see page 68.



- 1** Set the exposure mode dial to **A**, then set the aperture using the Command Dial.



- 2** Confirm focus indicator ● in the viewfinder and shoot.

- When the subject is too dark or too bright, one of the following warnings will appear in the LCD panel or viewfinder:
 - H** : Select a smaller aperture (larger f-number). If the warning indication persists, use an ND filter.
 - L** : Select a larger aperture (smaller f-number). If the warning indication persists, use the Speedlight.
- To set aperture in Long Time Exposure (Time or Bulb), set the exposure mode dial to **A**. For details, see pages 50, 61.

Vari-Program


■ Vari-Program

Vari-Program gives you the option to choose from four different programs designed for specific picture-taking situations.

For available mode combinations, see page 68.

■ Shooting with Vari-Program

Set the exposure mode dial to the desired Vari-Program, confirm that focus indicator ● appears in the viewfinder, and shoot.



- The following warning indications appear in the LCD panel or viewfinder when the subject is too dark or bright:

- H f : Use ND filter.
- L o : Use Speedlight.

NOTE: Vari-Program

- The camera automatically selects a slower shutter speed in certain situations (in programs other than Portrait Program). Use a tripod to avoid camera shake.

Shooting in Each Exposure Mode—continued

Vari-Program selection

Portrait Program

Use this program whenever you are taking pictures of people. It uses a relatively large aperture (smaller f-number) and shallow depth of field to create a blurred background which accentuates your main subject. Recommended AF Nikkor lenses: 85mm to 200mm telephoto lenses with large maximum apertures.



Landscape Program

Use this program whenever you are taking a picture of a distant scene. It generally selects a smaller aperture to assure sharply focused landscape pictures. Recommended lenses: you can use the full range of lenses (wideangle to telephoto) to achieve different effects.



Close-Up Program


Use this program when you are taking pictures up close. It uses a larger aperture (smaller f-number) and a shallow depth of field to create a blurred background that accentuates your main subject. Recommended AF Nikkor lenses: AF Micro-Nikkor lenses.



Night Scene Program

Use this program in the evening or at night. It allows you to capture the beauty of nighttime scenes. You can also use it with the flash when you want to include portraits in nightscene composition. Recommended lenses: you can use the full range of lenses (wideangle to telephoto) to achieve different effects.





www.butkus.us




Flexible Program/Exposure Metering System

■ Flexible Program

In Auto-Multi Program or in Vari-Program, by rotating the Command Dial you can change the combination of shutter speed and aperture while maintaining a correct exposure. With this function, you can shoot in Auto-Multi Program or Vari-Program as though shooting in Shutter-Priority Auto or Aperture-Priority Auto.


Set the exposure mode dial to P, , ,  or , and rotate the Command Dial to select the desired shutter speed/aperture combination. Compose, confirm focus indicator ● and shoot.



- To cancel the Flexible Program, change the exposure mode, turn off the power switch, or use the built-in Speedlight (page 63).

■ Matrix Metering/3D Matrix Metering


Matrix Metering provides correct exposure control using a six-segment Matrix Sensor. With IX-Nikkor or D-type AF Nikkor lenses, 3D Matrix Metering automatically activates to use scene brightness, scene contrast and subject distance information to ensure even more accurate exposure control.



Long Time Exposure (Bulb)


- This function is useful for shooting nighttime scenes or stars, which require extended exposure of more than 30 sec. (Use of a tripod is recommended.)

1 Set the exposure mode dial to **S** and rotate the Command Dial to select *bulb*.




- *bulb* blinks and the shutter cannot be released (with CPU lens).


2 Set the exposure mode dial to **A** and rotate the Command Dial to select the desired aperture. Compose, focus and shoot.






- The shutter will be open as long as the shutter release button is kept pressed. (Bulb exposure)
- When the optional remote control unit (page 60) is used, pressing the shutter release button once opens the shutter and pressing again closes the shutter (Time exposure).
- Continuous exposure of approx. 2 hours is possible with a fresh set of lithium batteries. Note that continuous exposure time is reduced when shooting in low temperatures.
- To cancel Long Time Exposure, set the exposure mode dial to **S** and select a shutter speed faster than 30 sec. (other than *bulb*).

Exposure Compensation

- To modify exposure control (i.e. from the ISO standard), use the exposure compensation function. This can be useful when the subject has pronounced contrast or when proper exposure is difficult to determine. You can modify exposure control from -2EV to +2EV in 1/2 steps (except in  mode).


- 1 Compensate exposure by rotating the Command Dial while pressing the  button until the desired compensation value appears.



- When the exposure compensation is set,  appears in the LCD panel and viewfinder. The compensation value can be checked by pressing the  button. In flash photography, the flash output level is also compensated.
- Normally, you should compensate exposure to the + side when the background is brighter than your main subject, or to the - side when the background is darker.

- 2 Compose picture, confirm focus indicator ● and shoot.




- To cancel exposure compensation in **P**, **S** or **A** exposure mode, rotate the Command Dial while pressing the  button to reset the compensation value to 0. To cancel exposure compensation in any of the Vari-Programs, select another exposure mode. Turning the camera off does not cancel the exposure compensation function.

Print Type


- You can select any one of three print types—wide-vision (H, aspect ratio of 9:16), panorama (P, aspect ratio of 1:3) or classic (C, aspect ratio of 2:3)—at any time.

1 Set the desired print type by turning the print type lever.



H Wide-vision type
(vertical vs. horizontal = 9:16)

- The frame inside the viewfinder changes according to the selected print type.



P Panorama type
(vertical vs. horizontal = 1:3)



C Classic type
(vertical vs. horizontal = 2:3)

- See “About Advanced Photo System” on page 8 for sample photographs of each print type.

2 Compose, confirm focus indicator ● and shoot.

NOTE: Changing the print type


Since the print type lever is located next to the viewfinder, be careful not to poke yourself in the eye with your finger or fingernail while turning the lever.

Setting/Imprinting Date/Time

- You can imprint the following data information on your picture (in any exposure mode): Year/Month/Day, Hour/Minute (24-hour clock), Month/Day/Year or Day/Month/Year.

■ Adjusting date and time

- 1 Turn the power switch off and press the SEL button to select the item to be adjusted.




- Each press of the SEL button changes the blinking display in the following order: year, month, day, hour, and minute.

Changing batteries and data imprinting function

The batteries that power the camera also supply power to the date/time display. When changing batteries, previously set date/time remains in the camera's memory for about five minutes without the batteries. If the camera is left without batteries for more than five minutes, you must reset the date/time. (If the camera is left without batteries for more than five minutes, the date/time display is reset to 0000 00.)

- 2 Press the ADJ button to set the correct number. Then press the SEL button until the number stops blinking.




- To change the numerical indication rapidly, hold the ADJ button down. The years are numbered in order from 98 to 29. To complete the adjustment, press the SEL button so the minute number stops blinking and date display appears.


Setting/Imprinting Date/Time—continued

 Taking pictures with imprinted date/time

- 1 Turn the power switch off and push the DATE/T button to select available imprinting displays.



- Each time you push the DATE/T button, the display changes as follows:



- When the DATE/T button is kept pressed for more than two sec. with a date display, the display changes as follows:



- The data displayed on the LCD is front/backprinted on the picture and **PRINT** (data recording) appears on the LCD panel.
- Date/time is always backprinted even when ---- (no imprint) is selected. **PRINT** does not appear on the LCD panel in this case.

Location of imprinted data



Ask your certified photofinisher regarding the location of the date/time imprint on your picture with H, P and C print types or date/time imprint on a color slide film.

Available types of date/time data:

LCD panel	Imprinted data	
	Front	Back
year/month/day	year/month/day	year/month/day
month/day/year	month/day/year	month/day/year
day/month/year	day/month/year	day/month/year
hour/minute	hour/minute	hour/minute
----	no imprint	date/time*

- * Year/month/day/hour/minute, month/day/year/hour/minute or day/month/year/hour/minute, whichever is selected before hour/minute is set will be imprinted.

- 2** Turn the power switch on, then fully depress the shutter release button to take a picture. The selected date/time will be imprinted on the print.



- Data, such as date/time or title, is magnetically recorded on the data disk of the film cartridge during film rewind. If exhausted batteries are used at low temperatures, data may not be recorded properly. To avoid this, we recommend not to rewind film at low temperatures or make sure the battery power is sufficient before film rewind.

Setting/Imprinting Language/Title

- The PRONEA S offers imprinting of any of 30 titles on back of the prints in up to 12 languages.

Language number 12 is set at the factory.

■ Languages provided

Language No.	Language	Language No.	Language	Language No.	Language
01	Danish	05	Italian	10	Spanish
02	Finnish	06	Japanese	11	Swedish
03	French	08	Norwegian	12	British English
04	German	09	Portuguese	13	American English

* Language number 07 cannot be set.


■ Titles provided for British English (language number 12)


Title number	Title	Title number	Title	Title number	Title
01	Honeymoon	11	Trip	21	Reunion
02	Wedding	12	I Love You	22	Father's Day
03	Hanukkah	13	Thank You	23	Mother's Day
04	Graduation	14	Season's Greetings	24	Baptism
05	Family	15	Happy Birthday	25	St. Valentine's Day
06	Party	16	Congratulations	26	Good Friday
07	Holiday	17	Merry Christmas	27	Easter Monday
08	Anniversary of Marriage	18	Festival	28	Happy Easter
09	Friends	19	First Day of School	29	St. George's Day
10	School Event	20	Happy New Year	30	May Day Holiday

■ Titles provided for American English (language number 13)

Title number	Title	Title number	Title	Title number	Title
01	Party	11	Wedding	21	New Year's
02	Birthday	12	Honeymoon	22	Happy New Year
03	Happy Birthday	13	Anniversary	23	Happy Holiday
04	Family	14	Thanksgiving	24	Father's Day
05	Friends	15	Season's Greetings	25	Mother's Day
06	Graduation	16	Rosh Hashanah	26	Independence Day
07	Thank You	17	Hanukkah	27	Valentine's Day
08	Congratulations	18	Easter	28	Victoria Day
09	Trip	19	Christmas	29	Canada Day
10	Vacation	20	Merry Christmas	30	Halloween


Setting language and title

- 1 Turn the power switch on. Press the data recording language button  and rotate the Command Dial to select the language to be recorded.



- The language and title can be changed from frame to frame. Language number 12 (British English) and title number -- (no title) are set at the factory.
- See the accompanying "List of Imprinted User Titles" for the titles in other languages.
- Note that data printing service is available only at certified photofinishers. When ordering prints, ask if they can handle data printing.


- 2 Rotate the Command Dial while pressing the data recording title button  to select the title number to be recorded.



- To cancel, set the title number to -- (no title).

Setting/Imprinting Language/Title—continued

- 3** Fully depress the shutter release button to take a picture. The selected title in the selected language will be imprinted on the print.







- The selected title number can be confirmed by pressing the **7** button, and the selected language number can be confirmed by pressing the **2** button.
- Data, such as date/time or title, is magnetically recorded on the data disk of the film cartridge during film rewind. If exhausted batteries are used at low temperatures, data may not be recorded properly. To avoid this, we recommend not to rewind film at low temperatures or make sure the battery power is sufficient before film rewind.


NOTE: Canceling language and title numbers

The selected language and title numbers remain unless -- (no title) or another number is selected. Note that turning the power switch off or changing the batteries does not cancel the numbers.

Self-Timer Operation


- You can use the self-timer when you want to be in the photograph. Use a tripod or place the camera on a stable surface before using the self-timer.







- 1** Press the  (self-timer) button and confirm that  appears on the LCD panel. (Or press the  button and rotate the Command Dial until  appears.)



- The self-timer cannot be operated unless the camera's shutter can be released (i.e. when subject cannot be in focus with autofocus). (Be sure to check for warning indications.)
- Cover the eyepiece with the supplied eyepiece cap (page 62) or your hand before pressing the shutter release button in order to prevent interference from stray light and achieve the correct exposure.
- Do not stand in front of the lens when setting the self-timer in the autofocus mode.







- 2** Compose the picture, focus and fully depress the shutter release button.








- When the self-timer is activated, the shutter releases in 10 seconds. The self-timer/red-eye reduction lamp blinks for 8 sec. and then stops blinking for 2 sec. before the shutter is released (and  in the LCD panel blinks for 10 sec.). When Red-Eye Reduction (page 63) is set, the self-timer/red-eye reduction lamp lights at the same output level as the normal Red-Eye Reduction function before the shutter releases.
- To cancel the self-timer before self-timer operation, press the  button again or rotate the Command Dial while pressing the  button so  and  disappear from the LCD panel. To cancel the self-timer during self-timer operation, turn the power switch off or press the  button again.
- When bulb is set, shutter speed is automatically controlled to 1/30 sec.

Remote Control Operation/Time Exposure (optional)


- Use the optional remote control to release the camera's shutter from a distance. As with self-timer operation, the remote control can also be used when you want to be in the photograph, or it can be used simply as a cable release. Use a tripod or place the camera on a stable surface before using the remote control. When the camera is set to Long Time Exposure (Bulb), pressing the remote control unit's shutter release button opens and closes the camera's shutter (Time exposure).

1 Press the  button and confirm that  or  appears on the LCD panel. (Or press the  button and rotate the Command Dial until  or  appears.)



- You can select to release the shutter either two sec. after () or immediately () after the shutter release button on the remote control unit is pressed.
- Once remote control operation is set, the camera remains ready to receive a signal from the remote control unit for 60 sec. After 60 sec., the remote control mode is canceled and  or  disappears from the LCD panel.
- Two methods to shoot with autofocus with remote control:
 1. Autofocus activated by the signal from remote control:
Shutter is released when (or two sec. after) the subject is in focus. However, when focus cannot be achieved, it remains in standby mode.
 2. Autofocus activated by lightly pressing the shutter release button on the camera body before remote control operation:
Lightly press the shutter release button on the camera body while the remote control is standing by to achieve focus. Once focus is achieved, focus is locked (even though the finger is removed from the shutter release button). Shutter is released when (or two sec. after) the shutter release signal is received from the remote control unit.
- The remote control cannot be operated unless the camera's shutter can be released (i.e. when subject cannot be in focus with autofocus).
- Cover the eyepiece with the supplied eyepiece cap (page 62) or your hand before pressing the shutter release button in order to prevent interference from stray light and to achieve the correct exposure.
- After the shutter is released, the camera remains ready to receive a signal from the remote control unit for 20 sec.

2 Point the remote control unit toward the camera and press the shutter release button.




- The shutter is released after the self-timer/red-eye reduction lamp lights for approx. 2 sec. in 2 sec. delay mode. When immediate release is selected, the self-timer/red-eye reduction lamp lights after shutter release (except shooting with flash). When Red-Eye Reduction (page 63) is set, the self-timer/red-eye reduction lamp lights at the same output level as the normal Red-Eye Reduction function before the shutter releases and the flash fires when the shutter is released.
- To cancel the remote control before remote control operation, press the button again or rotate the Command Dial while pressing the button so or disappears from the LCD panel. To cancel during remote control operation, turn the power switch off or press the button again.
- The shooting distance for remote control operation is within 5m (16 ft.) directly in front of the camera. To shoot beyond the shooting distance of the remote control, use the self-timer (page 59). Remote control operation cannot be performed when the subject has extreme backlighting.
- If the shutter cannot be released with the remote control, change the battery inside the remote control unit. (The life of the battery inside the remote control is approx. 10 years.) Visit an authorized Nikon dealer or service center to change it.

Time exposure

When the camera is set to Long Time Exposure (Bulb) (page 50), the camera performs Time exposure with remote control operation. Press the remote control unit's shutter release button to open the camera's shutter and press the shutter release button again to close the shutter. As with Bulb exposure, this function is useful for shooting nighttime scenes or stars. (Use of a tripod is recommended.) Self-timer/red-eye reduction lamp lights slightly once every 2 sec. during Time exposure.

Diopter Adjustment/Eyepiece Cap

- The finder diopter enables near- or far-sighted photographers to adjust the eyepiece diopter to suit their vision.





- Slide the diopter adjustment lever while looking through the viewfinder until the focus brackets in the viewfinder appear sharp. The adjustable range of the finder diopter is -1.5 DP. to $+0.5$ DP. Nine optional eyepiece correction lenses provide viewfinder diopter of -5.0 to $+3.0$ DP.

NOTE: Using the diopter adjustment lever

Since the diopter adjustment lever is located next to the viewfinder, be careful not to poke yourself in the eye with your finger or fingernail while sliding the lever.

- Attaching the eyepiece cap or optional eyepiece correction lens



- To attach an eyepiece cap or optional eyepiece correction lens, remove the rubber eyecup and slide down the eyepiece cap or eyepiece correction lens. When reattaching the rubber eyecup, make sure to attach it in the correct direction.

Flash Photography

■ Built-in Speedlight and Matrix Balanced Fill-Flash

This camera is equipped with a built-in Speedlight that provides an angle of coverage for a 24mm lens with a guide number of 16 (ISO200, m) or 52 (ISO200, ft.).

Matrix Balanced Fill-Flash ensures proper exposure of the main subject and background, and provides adequate flash output to enable natural-looking flash photography (with CPU lens).

In addition to shooting in dim light, the flash can be used in daylight to reduce shadows on the main subject or to put catchlights in your subject's eyes.

- When using a non-CPU lens, standard TTL flash is the only flash mode available. To ensure optimum performance, use only CPU lenses.

■ Flash sync mode

Five flash sync modes—Normal Sync, Red-Eye Reduction, Slow Sync and Red-Eye Reduction with Slow Sync, and Flash Cancel—are available with this camera.

⚡👁: Red-Eye Reduction

In order to reduce the red-eye effect in photos of people or animals, the Red-Eye Reduction lamp lights for approx. 1 sec. before the flash fires.



⚡^{SLOW}: Slow Sync


Normally, the camera's shutter speed is automatically set between 1/60 to 1/125 sec. with flash photography. However, for shooting nighttime scenes, Slow Sync uses a slower shutter speed to bring out background details using all of the available light.






- Red-Eye Reduction and Slow Sync can be set simultaneously by selecting ⚡^{SLOW}👁. See page 64.
- Selectable flash sync modes depend on the exposure mode selected. See page 68 for the available combinations of flash sync modes and exposure modes.


Flash Photography—continued




Using the built-in Speedlight

- 1 Release the built-in Speedlight by sliding the Speedlight lock-release lever, and set the flash sync mode by pressing the  button.



- The Speedlight starts to charge when it is released and  appears in the viewfinder when Speedlight is fully charged (when the camera's meter is on).
- Pressing the  button changes the flash sync mode as follows (— line): Rotating the Command Dial while pressing the  button changes the mode as follows (--- line):



-  (normal sync) disappears from the LCD panel when Normal Sync is set and the  button is released.
- When the Night Scene Program  is set, Slow Sync flash is automatically selected. (Page 68.)
- Press down gently on the Speedlight to retract.
- Flash Cancel can only be set when the built-in Speedlight is released. (Retracting the built-in Speedlight cancels the Flash Cancel.)

NOTE: Flash Sync Modes

- When Red-Eye Reduction or Red-Eye Reduction with Slow Sync is set, the Red-Eye Reduction lamp lights for approx. 1 sec. before the flash fires. Do not move the camera or let the subject move until the shutter is released.
- With some lenses, light from the Red-Eye Reduction lamp may not reach the subject's eyes. In some cases, the red-eye effect may not be reduced effectively due to the location of the main subject.
- With Slow Sync and Red-Eye Reduction with Slow Sync, keep the camera steady to prevent picture blur since the shutter speed is slow. Use of a tripod is recommended.

2 Set the exposure mode and confirm the shutter speed and aperture.

- Available shutter speed and aperture in each exposure mode:


Exposure mode	Available shutter speed	Available aperture	Page
General-Purpose Program Auto-Multi Program Vari-Program	Automatically set	Automatically set	43
			44
			47
Shutter-Priority Auto	1/125-30 sec.*1	Automatically set	45
Aperture-Priority Auto	Automatically set	Desired setting*2	46

*1 The shutter speed shifts automatically to 1/125 sec. when the shutter speed is faster than 1/125 sec. and the flash is fired.

*2 The flash shooting distance range depends on the ISO film speed of the film in use and the aperture selected. In Aperture-Priority Auto exposure mode, set the aperture according to the flash shooting distance range table on page 67.

Flash Photography—continued

- 3** Confirm that **4** appears in the viewfinder and make sure the subject is within the flash shooting distance range (page 67).



- **4** in the viewfinder blinks approx. 3 sec. after full flash output. This may indicate that underexposure has occurred. Check the focus distance, aperture or flash shooting distance range and shoot again.
- When the subject is dimly lit, the AF-Assist Illuminator automatically emits (page 40) to guide autofocus.

Usable lenses with built-in Speedlight

24mm (1m or longer shooting distance), 28mm to 300mm (0.6m/2 ft. or longer shooting distance) CPU lenses can be used with the built-in Speedlight.

- Vignetting occurs at the edges of the frame resulting in underexposure with the following AF zoom lenses, which have limitations in usable focal length or shooting distance:

Lens	Limitations
24-50mm f/3.3-4.5	24mm focal length cannot be used.
24-120mm f/3.5-5.6	24mm focal length cannot be used. 50mm focal length at 1.5m (4.9 ft.) or longer shooting distance or 120mm at 0.8m (2.6 ft.) or longer.
28-70mm f/3.5-4.5	28mm focal length at 1m (3.3 ft.) or longer shooting distance
28-80mm f/3.5-5.6	28mm focal length at 1.2m (3.9 ft.) or longer shooting distance
28-85mm f/3.5-4.5	28mm and 35mm focal length cannot be used
28-200mm f/3.5-5.6	28mm and 35mm focal length cannot be used
35-70mm f/2.8	35mm focal length cannot be used
35-135 f/3.5-4.5	35mm focal length at 2m (6.6 ft.) or longer shooting distance
70-180mm f/4.5-5.6	70mm focal length at 3m or longer shooting distance, or 100mm at 1m (3.3 ft.) or longer.
80-200mm f/2.8	80mm focal length cannot be used.

- Do not set the zoom lens to Macro in wideangle and always remove the lens hood when using the built-in Speedlight.
- Following lenses with focal length shorter than 300mm cannot be used:
AF-S 300mm f/2.8D, AF-I 300mm f/2.8D, AF 28mm f/1.4, AF Zoom 20-35mm f/2.8D
- Use of lens other than AF Nikkor is not recommended.
- Focal length and picture angle of the IX240 film differ from those of the 135 format film (page 36).

Flash shooting distance range

The flash shooting distance changes according to the film speed in use and aperture setting.

ISO Film Speed	25	50	100	200	400	800	Flash shooting distance range (m/ft.)
Guide number (m/ft.)	5.5/18	7.8/26	11/36	15.6/51	22/72	31/102	
Aperture	—	—	1.4	2	2.8	4	1.4-7.9/4.6-26
	—	1.4	2	2.8	4	5.6	1-5.5/3.3-18
	1.4	2	2.8	4	5.6	8	0.7-3.9/2.3-13
	2	2.8	4	5.6	8	11	0.6-2.8/2.0-9.2
	2.8	4	5.6	8	11	16	0.6-2/2.0-6.6
	4	5.6	8	11	16	22	0.6-1.4/2.0-4.6
	5.6	8	11	16	22	32	0.6-1/2.0-3.3
	8	11	16	22	32	—	0.6-0.7/2.0-2.3

- The flash shooting distance range can also be calculated by dividing the guide number by the aperture value selected.

Example: when f/2.8 is selected with ISO 200 film using this camera's built-in Speedlight, the maximum flash shooting distance is:

$$\frac{15.6}{2.8} = \text{approx. } 5.5\text{m} \quad \text{or} \quad \frac{51}{2.8} = \text{approx. } 18 \text{ ft.}$$

Wireless Slave Flash Controller SU-4

Optional Speedlights can be fired simultaneously with the built-in Speedlight using the Wireless Slave Flash Controller SU-4. See page 70 for accessories.

Available Mode Combinations

■ The following chart lists available modes when an IX-Nikkor or AF Nikkor is attached.

Exposure mode	AF mode*	AF-Assist Illuminator	Flexible Program	Exposure compensation	Metering system	Normal sync	Red-Eye Reduction	Red-Eye Reduction with Slow Sync	Slow Sync	Flash Cancel
AUTO	Auto-Servo AF	○	—	—	Matrix	⊙	○	—	—	—
P	Auto-Servo AF	○	○	○	Matrix	○	○	○	○	○
S	Auto-Servo AF	○	—	○	Matrix	○	○	—	—	○
A	Auto-Servo AF	○	—	○	Matrix	○	○	○	○	○
TTL	Auto-Servo AF	○	○	○	Matrix	⊙	○	—	—	○
Matrix	Auto-Servo AF	—	○	○	Matrix	⊙	○	—	—	○
Flash	Auto-Servo AF	○	○	○	Matrix	⊙	○	—	—	○
Flash	Auto-Servo AF	○	○	○	Matrix	—	—	○	⊙	○

○ : Can be set.

⊙ : Automatically selected when the exposure mode is set. (Can be changed to another flash sync mode.)

— : Cannot be set.

* AF mode does not switch to Continuous Servo AF when AF-Assist Illuminator emits, Red-Eye Reduction lamp lights up, or during self-timer or remote control operation.

- A non-CPU lens can be used only when the exposure mode is set to **S** (Shutter-Priority Auto) and the shutter speed and the aperture can only be set manually. With a non-CPU lens, the exposure meter cannot be activated. **F -** appears in place of the aperture indication in the LCD panel and viewfinder; set/confirm the aperture using the lens' aperture ring. In **S** mode, Long Time Exposure (Bulb or Time) can be performed.
- With the built-in Speedlight, each flash sync mode is controlled with the Matrix Balanced Fill-Flash (page 63); however, Standard TTL Flash performs with non-CPU lenses.

MISCELLANEOUS

The Nikon PRONEA S is a high-performance, precision instrument, designed to give you superior pictures. You'll want to take good care of your camera to ensure the best performance. Take time to review this section thoroughly, as doing so will add to your picture-taking pleasure.

We've also included information about optional accessories and a detailed section with technical specifications. Please read them carefully.

Optional Accessories

Soft Case

Two camera cases are available for this camera.

- CS-27: Camera body fits inside case with IX30-60mm f/4-5.6 lens attached.
- CS-28: Camera body fits inside case with IX60-180mm f/4.5-5.6 lens attached.

Power Pack MB-11

When Power Pack MB-11 is attached to the bottom of the PRONEA S, four AA-type alkaline-manganese or lithium batteries can be used to power the PRONEA S. AA-type batteries are widely available compared to CR2 batteries, and lithium batteries enable you to shoot more rolls of film and yield stable performance in lower temperatures.

IX-Nikkor/AF Nikkor Lens

IX-Nikkor 30-60mm f/4-5.6, 60-180mm f/4.5-5.6, 20-60mm f/3.5-5.6, 24-70mm f/3.5-5.6 and 60-180mm f/4-5.6 lenses are available exclusively for Nikon PRONEA cameras. Also, various AF Nikkor lenses, from 16mm fisheye to 600mm telephoto, are available. Most AF Nikkor lenses can be used with this camera.

Filters

Nikon offers a range of filters including the NC filter for lens protection, and the Circular Polarizing Filter C-PL for special effects.

Wireless Slave Flash Controller SU-4

TTL multi-flash, where an optional Speedlight is fired simultaneously with the built-in Speedlight, is possible with the Wireless Slave Flash Controller SU-4.

Bracket SK-7

Bracket SK-7 enables you to attach a TTL Speedlight unit connected to Wireless Slave Flash Controller SU-4 next to the PRONEA S.

www.butkus.us

Camera Care



WARNING



Do not use

Do NOT ever use organic solvents like thinner or benzene.

They are flammable and hazardous to your health, and can cause damage to the camera.

• **Cleaning camera body**

Use a blower brush to remove dirt and dust from the camera body, and clean the body with a soft, clean cloth. After using the camera near sea water, wipe the camera body with a soft, clean cloth slightly moistened with pure water to remove salt, and then dry it with a dry cloth.

• **Cleaning mirror and lens**

Use a blower brush to remove dirt and dust from the mirror or lens. To remove fingerprints or smudges, use a soft, clean cotton cloth or lens tissue moistened with ethanol (alcohol) or lens cleaner.

• **Do not subject the camera or lens to strong vibration or shock**

Do not drop the camera body and lens or allow them to hit a hard surface as this may damage the precision mechanisms.

• **Avoid strong electric or magnetic fields**

The camera may not function properly in strong electric or magnetic fields such as near a transmitter tower. Avoid using the camera in such locations.

• **Store the camera in a cool, dry place**

Store the camera in a cool, dry place to prevent mold and mildew.

- Keep it away from naphthalene or camphor (moth repellent), electrical appliances that generate magnetic fields, or excessively hot places such as inside a vehicle during the summer or near a heater.

• **Avoid extreme temperature changes**

An extreme temperature change can cause condensation inside the camera body. When taking the camera to a very hot place from a very cold place or vice versa, place it inside an airtight container such as a plastic bag and leave it inside a while to expose the camera gradually to the temperature change.

Camera Care—continued

Butkus.us

Remove the batteries and store the camera with a desiccant

If you do not intend to use the camera for a long time, remove the batteries to protect the camera from battery leakage.

- In a humid environment, store the camera inside a plastic bag with a desiccant to keep out dust, moisture and salt. Note, however, that storing leather cases in vinyl bags may cause the leather to deteriorate. Keep the batteries in a cool, dry place away from heat or humidity.
- Change the desiccant occasionally since it eventually loses its ability to absorb moisture effectively.
- Leaving the camera unused for a long period of time may cause mold to grow and result in malfunction. Turn the power on and release the shutter a few times once per month.
- To maintain the built-in Speedlight in peak condition, fire it a few times every month. This will enable you to use the flash for many years.

Nikon cannot be held responsible for any malfunction resulting from the use of the camera other than as specified in this manual.

www.butkus.us

Notes on Batteries



WARNING



Do not leave

Keep batteries out of the reach of children.

If batteries are accidentally swallowed, call a doctor immediately.

• Use two CR2 lithium batteries

Change the batteries well before the end of their life expectancy and prepare spare batteries before important picture-taking situations.

• Turn the camera power off when changing the batteries

Turn the camera power off before changing the batteries, and insert the batteries with ⊕ and ⊖ ends positioned correctly.

- When changing batteries, make sure to use batteries of the same brand and manufacturer.
- Stains on the battery poles may cause poor contact. Wipe the batteries well with a dry cloth before installing.

• Use fresh batteries at low temperatures






Battery power diminishes at extremely low temperatures, and the camera may not function properly with old batteries. Use a fresh set of batteries at low temperatures, keep spare batteries warm, and use them alternately.



- Film advance speed lowers and picture capacity decreases at low temperatures. However, battery power may be restored when the temperature returns to normal.

• Do not throw batteries into a fire or short circuit them

Do not throw batteries into a fire. Do not short, disassemble, heat or charge batteries.

Troubleshooting

LCD panel	Viewfinder	Causes	Remedy	Page
FEF blinks	FEF blinks	<ul style="list-style-type: none"> • Lens is not set to its minimum aperture. 	<ul style="list-style-type: none"> • Set lens to minimum aperture. 	19
 appears	—	<ul style="list-style-type: none"> • Batteries are nearing exhaustion. 	<ul style="list-style-type: none"> • Have fresh ones ready. 	17
 blinks	—	<ul style="list-style-type: none"> • Batteries are exhausted. 	<ul style="list-style-type: none"> • Replace the batteries with new ones. 	17
Err and  blink	Err blinks	<ul style="list-style-type: none"> • Battery power is low or ambient temperature is low. When camera operation becomes too slow in low temperatures, all operation stops and warning indications appear. 	<ul style="list-style-type: none"> • Turn the power off and replace the batteries with new ones. Then, turn the power on. 	16
F-- blinks	F-- blinks	<ul style="list-style-type: none"> • Non-CPU lens is attached or lens is not attached. 	<ul style="list-style-type: none"> • Attach CPU lens (including IX-Nikkor) correctly. (Or set the exposure mode to S.) 	18
Err and  blink and E appears	Err blinks	<ul style="list-style-type: none"> • Film is not correctly positioned or exposed film remains in the film cartridge chamber. • Magnetic noise is detected when a partially exposed film is loaded. • No data is detected or fully exposed data is detected when a partially exposed film is loaded. • Unusable (damaged) film is loaded. 	<ul style="list-style-type: none"> • Reload the film or load new film. • Turn the power switch off and on, or reload the film. • Reload new film • Reload new film 	20
 blinks	—	<ul style="list-style-type: none"> • Exposed film remains in the film cartridge chamber. • Film is loaded without batteries (without battery power) and new batteries are loaded afterwards. 	<ul style="list-style-type: none"> • Remove film cartridge. • Turn the power switch on and reload the film. 	29 20

LCD panel	Viewfinder	Causes	Remedy	Page
Err and  blink	—	<ul style="list-style-type: none"> Battery power is low or temperature is too low to rewind film. 	<ul style="list-style-type: none"> Turn the power off and replace the batteries with new ones. Then turn the power on and rewind the film again. 	16
Err and PRINT blink, or Err, PRINT and  blink	Err blinks	<ul style="list-style-type: none"> Malfunction detected during film rewind. Film cartridge chamber cover is opened during film rewind. Proper film rewind cannot be performed (low power voltage). Number of exposures in the roll is different from the available number of exposures. 	<ul style="list-style-type: none"> Turn the power off and on again. If film rewind does not start again, turn the power off and replace the batteries with new ones. Then, turn the power on and rewind film again. 	38
Err blinks	Err blinks	<ul style="list-style-type: none"> Malfunction detected. 	<ul style="list-style-type: none"> Turn the power switch off and turn it on again. 	17
—	▶◀ blinks	<ul style="list-style-type: none"> Autofocus is not possible. 	<ul style="list-style-type: none"> Focus manually. 	41
—	◀ appears	<ul style="list-style-type: none"> Subject is too near. 	<ul style="list-style-type: none"> Move away from the subject and shoot again. 	27
H ! appears	H ! appears	<ul style="list-style-type: none"> Overexposure possible. 	<ul style="list-style-type: none"> In S mode, select a faster shutter speed. In A mode, select a smaller aperture (larger f-number). In other exposure modes, use an ND filter. 	45 46 43, 44, 47
L o appears	L o appears	<ul style="list-style-type: none"> Underexposure possible. 	<ul style="list-style-type: none"> In S mode, select a slower shutter speed. In A mode, select a larger aperture (smaller f-number). In other exposure modes, use the Speedlight. 	45 46 43, 44, 47

Troubleshooting—continued

LCD panel	Viewfinder	Causes	Remedy	Page
bulb and F-- blink	bulb and F-- blink	<ul style="list-style-type: none"> Shutter speed is set to bulb in S mode. 	<ul style="list-style-type: none"> Cancel the bulb by selecting 30 sec. or faster shutter speed, or select A mode and set the aperture with the Command Dial to perform Long Time Exposure. 	45, 50
—	⚡ blinks	<ul style="list-style-type: none"> Speedlight recommended. 	<ul style="list-style-type: none"> Use the built-in Speedlight. 	30
—	⚡ blinks for approx. 3 sec. after flash	<ul style="list-style-type: none"> Flash has fired at full output and underexposure may have occurred. 	<ul style="list-style-type: none"> Shoot again after confirming focus distance, aperture or flash shooting distance range. 	66
Shutter indication blinks	1/25 appears	<ul style="list-style-type: none"> Shutter speed faster than 1/125 sec. is selected when the built-in Speedlight is used in S mode and the shutter speed is automatically controlled to 1/125 sec. 	<ul style="list-style-type: none"> Release the shutter as it is to take a picture with flash with shutter speed at 1/125 sec. 	65

In certain cases, due to static electricity or improperly loaded batteries, the PRONEA S camera's microcomputer may turn the camera off. This can happen even with fresh, properly installed batteries. It may also keep the film from advancing properly. In each of these cases, to resume operation, simply turn the power off and on again, or remove and reinstall the batteries.




www.butkus.us

Specifications

Type of camera	Integral-motor autofocus, built-in Speedlight, electronically controlled focal plane shutter Advanced Photo System (IX240) single-lens reflex
Exposure modes	Auto: General-Purpose Program P: Auto-Multi Program (Flexible Program possible) S: Shutter-Priority Auto A: Aperture-Priority Auto Vari-Program (☉: Portrait, ■: Landscape, ☼: Close-Up, ☀: Night Scene; Flexible Program possible)
Print type	Three print types are available: H, P and C
Picture format	16.7 x 30.2mm
Lens mount	Nikon F mount
Lens	Nikkor and Nikon lenses having Nikon F mount* * With limitations; see chart on p. 34.
Compatible film	IX240 cartridge film
Viewfinder	Fixed-eyelevel penta-Dach-mirror type (eyepoint: approx. 18 mm)
Focusing screen	Clear Matte Screen IV (with focus brackets), fixed
Viewfinder frame coverage/ Print frame coverage	Approx. 87% (50mm lens) Approx. 95%, with H, P and C print types
Finder magnification	Approx. 0.72X to 0.79X with 50mm lens set at infinity
Diopter adjustment	-1.5 DP. to +0.5 DP.
Viewfinder information	Focus indication (in-focus indication, front-focus, rear focus and AF impossible warning), FEE warning, F - - warning, exposure value (shutter speed, aperture), exposure warning, exposure compensation, focus brackets, frames for H, P and C print types, flash ready-light (charged indication, full output warning), flash recommended
Autofocus	<ul style="list-style-type: none"> • TTL phase detection AF system with AF-Assist Illuminator (available with 22mm to 180mm lens, approx. 0.5 to 3m, approx. 0.5 to 2m without built-in Speedlight) • Activated by lightly pressing the shutter release button • Detection range: EV 0 to EV 20 (at ISO 200, normal temperature)
Lens servo	AF: Auto-Servo AF: Camera automatically chooses Single Servo AF or Continuous Servo AF operation according to the subject status, i.e. stationary or moving (including directional information). <ul style="list-style-type: none"> • Single Servo AF: Once focused on a subject, focus is locked • Continuous Servo AF: The camera continuously focuses on a moving subject M: Manual

Specifications—continued

Focus lock	Focus is locked when the shutter release button is lightly pressed and subject is in focus in Single Servo AF
Exposure metering	Six-segment 3D Matrix: with IX-Nikkor, D-type AF Nikkor, AF-S Nikkor, AF-I Nikkor Six-segment Matrix: with non-D-type AF Nikkor (except AF lens for F3AF), AI-P Nikkor
Metering range	EV 2 to EV 21 at ISO 200, 50mm f/1.4 lens
Film speed setting	Automatically set with IX-system; film speed range: ISO 25 to 10000
Exposure meter	Activated by turning on power, lightly pressing shutter release button; stays on for 5 sec. after removing finger from button, or 2 sec. (or 5 sec. after flash use) after releasing shutter
Exposure compensation	±2 EV range, in 1/2 steps
Shutter	Electronically controlled vertical-travel focal-plane shutter
Shutter speeds	<ul style="list-style-type: none"> In M, P, A, S, B, L, T: 30 to 1/2000 sec. automatically set In S: Bulb, 30 to 1/2000 sec., Time (with remote control operation)
Self-timer	Electronically controlled; timer duration: 10 sec.; can be canceled
Remote control	Infrared, activated by pressing the shutter release button; immediate release mode and 2 sec. delay mode; operating distance: approx. 5m directly in front of the camera; battery life: approx. 10 years; dimensions: approx. 60 x 27 x 10mm (W x H x D); weight: approx. 13g including battery
Sync contact (no external contact)	<ul style="list-style-type: none"> Flash synchronization up to 1/125 sec. Automatically set to 1/125 sec. when shutter speed is set from 1/2000 to 1/180 sec.
Built-in Speedlight	Activated by sliding Speedlight lock-release lever, guide number: 16/52 (at ISO 200, m/ft.); flash coverage: 24mm or longer lens; film speed range: ISO 25 to ISO 800
Flash control	Controlled by TTL Sensor <ul style="list-style-type: none"> Matrix Balanced Fill-Flash: possible with CPU lens Standard TTL: non-CPU lens
Flash sync mode	Normal, Red-Eye Reduction, Red-Eye Reduction with Slow Sync, Slow Sync, Flash Cancel
Flash recommended indication	Blinks in low brightness or when flash is recommended
Ready-light	<ul style="list-style-type: none"> Flash fully charged: lights (minimum charging time: approx. 3-3.5 sec.) Full output warning: blinks (approx. 3 sec. after flash)
Film loading	One-touch loading, film automatically advances to first unexposed frame when film cartridge chamber cover is closed

Film advance	Film automatically advances one frame when shutter is released (film rewinds automatically at the end of a film roll)
Frame counter	Digital display in LCD panel; countback type
Film rewind	Film automatically starts to rewind at the end of the film roll; rewind speed is approx. 20 sec. for 40-exposure film roll; mid-roll rewind possible; automatically advances to the frame immediately after the last exposed frame when partially exposed film is loaded
Data imprint function	<ul style="list-style-type: none"> • Built-in clock: 24-hour type with timing accuracy within ± 90 seconds a month; leap year adjustment until 2029 • Date/time data, title: magnetically recorded • Data recorded (Front print): Year/Month/Day, Month/Day/Year, Day/Month/Year, Day/Hour/Minute and No Imprint (Backprint): Day/Hour/Minute, Year/Month/Day, Month/Day/Year and Day/Month/Year, or one of date with hour minute when No Imprint is selected • 30 titles in 12 languages can be backprinted • Power: from the camera body, data remain in memory for approx. 5 minutes without batteries
LCD panel information	Shutter speed, aperture, date/time, flash sync mode, exposure compensation, frame counter/compensation value, Err warning, Err warning, F - warning, film cartridge, self-timer, battery power, data recording, language/title and remote control
Number of film rolls per set of fresh CR2 batteries	<p>Without flash (With flash for half of all exposures)</p> <p>40-exposure: approx. 30 (13) at 20°C (68°F), approx. 17 (7) at -10°C (14°F)</p> <p>25-exposure: approx. 41 (19) at 20°C (68°F), approx. 20 (11) at -10°C (14°F)</p> <p><i>* For autofocus operation using an IX-Nikkor 30-60mm f/4-5.6 lens, covering the full range from infinity (∞) to the closest distance and back to infinity (∞) with exposure meter activated for 5 sec. before each shot, with a shutter speed of 1/125 sec.</i></p>
Power source	Two CR2-type lithium batteries; four AA-type alkaline manganese or lithium batteries with Power Pack MB-11
Battery power confirmation	<p> for sufficient power;  indicates batteries are nearing exhaustion; blinking  indicates batteries are exhausted; no indication/symbol appears when batteries are completely exhausted or improperly installed (with exposure meter on)</p>
Tripod socket	1/4 inch diameter
Dimensions (WxHxD)	Approx. 116 x 87 x 57mm (4.6 x 3.4 x 2.2 in.)
Weight (without batteries)	Approx. 325g (11.5 oz.)

All specifications apply when fresh CR2-type batteries are used at normal temperature (20°C/68°F).

Specifications and design are subject to change without notice.

Index

A

AF-Assist Illuminator	40
Aperture-Priority Auto exposure mode	25, 46
Autofocus	22, 40
Auto-Multi Program	25, 44
Auto-Servo AF	40

B

Built-in Speedlight	30, 63-67
---------------------------	-----------

C

Close-Up Program	25, 48
Continuous Servo AF	40
CPU Nikkor lens	18, 34, 63
C print type	8, 26, 52

D

Depth of field	32, 46, 48
Dioptr adjustment	62
Distance information	49
D-type Nikkor lens	32, 34, 49

E

Exposure compensation	51
Exposure metering system	49
Exposure mode	24-25, 43-46
Eyepiece cap	62

F

Flash Cancel	63-64
Flash shooting distance range	67
Flash sync mode	63-65
Flexible Program	49
Focus Lock	42
Focus mode	22, 40-41

G

General-Purpose Program	24-25, 43
Guide number	31, 67

H

H print type	8, 26, 52
--------------------	-----------

I

Index print	9
IX-Nikkor lens	18, 34, 49
IX240 film	20, 37
IX240 system	8-9

L

Landscape Program	25, 48
Long Time Exposure	50, 61

M

Manual focus	41
Matrix Balanced Fill-Flash	30, 63
Matrix Metering	32, 49
Mid-Roll Change	39
Mid-roll rewind	38
Minimum aperture	18-19

N

Night Scene Program	25, 48
Normal Sync flash	30, 63-64

P

Portrait Program	25, 48
P print type	8, 26, 52
Print type.....	8, 26, 52

R

Red-Eye Reduction	63
Red-Eye Reduction with Slow Sync ..	63
Remote control	60-61

S

Self-timer.....	59
Shutter-Priority Auto exposure mode	25, 45
Single Servo AF	40
Slow Sync flash	63
Standard TTL flash.....	63
Sync shutter speed	65

T

3D Matrix Metering	32, 49
--------------------------	--------

V

Vari-Program.....	25, 47-48
-------------------	-----------