

**1855**  
**Capacitor Leakage Current/IR Meter**  
**Instruction Manual**  
Form 150767/**A4**

©QuadTech, Inc., 2004  
5 Clock Tower Place, 210 East  
Maynard, Massachusetts, U.S.A. 01754  
October 2006

Telephone	978-461-2100
Sales	800-253-1230
Facsimile	978-461-4295
Website	<a href="http://www.quadtech.com">www.quadtech.com</a>

The material in this manual is for informational purposes only and is subject to change, without notice. QuadTech assumes no responsibility for any error or for consequential damages that may result from the misinterpretation of any procedures in this publication.

**CAUTION**

Voltage may be present on front and rear panel terminals. Follow all warnings in this manual when operating or servicing this instrument. Substantial levels of energy may be stored in capacitive devices tested by this unit.



Product will be marked with this symbol (ISO#3864) when it is necessary for the user to refer to the instruction manual in order to prevent injury or equipment damage.



Product marked with this symbol (IEC417) indicates presence of direct current.



Product will be marked with this symbol (ISO#3864) when voltages in excess of 1000V are present.



---

# Contents

---

<b>Warranty</b>	.....	<b>5</b>
<b>Specifications</b>	.....	<b>7</b>
<b>Accessories</b>	.....	<b>11</b>
<b>Safety Precautions</b>	.....	<b>13</b>
<b>Condensed Operating Instructions</b>	.....	<b>15</b>
<b>Introduction - Section 1</b>		
1.1	Unpacking and Inspection.....	19
1.2	Product Overview .....	19
1.3	Controls and Indicators .....	20
1.3.1	Front Panel Controls and Indicators .....	20
1.3.2	Rear Panel Controls and Connectors .....	21
1.4	Installation .....	22
1.4.1	Dimensions .....	22
1.4.2	Instrument Positioning.....	22
1.4.3	Power Requirements .....	22
1.4.4	Safety Inspection.....	23
<b>Operation - Section 2</b>		
2.1	Terms and Conventions .....	25
2.2	Start-Up.....	27
2.3	SYSTEM SETUP .....	27
2.3.1	Calibration .....	27
2.3.2	Memory Manage .....	27
2.3.3	System Configuration .....	28
2.3.3.1	Test Parameter .....	29
2.3.3.2	Beeper .....	29
2.3.3.3	Sound Mode .....	29
2.3.3.4	Alarm Mode .....	30
2.3.3.5	Trig Delay .....	30
2.3.3.6	Trig Edge .....	30
2.3.3.7	Handler Mode .....	31
2.3.3.8	Contrast .....	31
2.3.3.9	GPIB Address .....	31
2.3.3.10	RS232 Baud Rate .....	32
2.3.3.11	Key Lock .....	32
2.3.3.12	Line Frequency .....	33
2.3.3.13	Charge Time .....	33
2.3.3.14	Range Dwell .....	33
2.3.3.15	Average .....	34
2.3.3.16	EXT Vm Display .....	34

---

# Contents

---

**Operation - Section 2 – Continued**

2.4	MAIN INDEX .....	35
2.4.1	Sequence Test .....	35
2.4.2	Step Test .....	36
2.4.3	Null .....	36
2.4.4	W.V. Test .....	38
2.4.5	Compare .....	39
2.5	MEAS DISPLAY .....	41
2.5.1	Test Voltage .....	42
2.5.2	Constant Current .....	42
2.5.3	Range .....	43
2.5.4	Charge Time .....	44
2.5.5	Dwell Time .....	44
2.5.6	Speed.....	45
2.5.7	Trigger .....	45
2.5.8	Rated Withstand Voltage (Vf) .....	46
2.5.9	Measurement Time (Tend) .....	46
2.5.10	Maximum Charge Time (CHG Tend) .....	47
2.6	Connection to Device under Test.....	48
2.7	Measurement Procedure.....	49

**Interface - Section 3**

3.1	RS-232 Interface .....	51
3.1.1	RS232 Pin Configuration .....	51
3.1.2	RS232 Specifications .....	51
3.1.3	RS232 Commands .....	52
3.2	IEEE-488 Interface .....	53
3.2.1	Pin Configuration.....	53
3.2.2	IEEE-488 Interface Function Codes and Messages.....	55
3.2.3	IEEE-488 Interface Commands .....	57
3.2.4	IEEE-488 Command Format .....	59
3.2.5	IEEE-488 Commands - Detailed .....	60
3.2.6	Error Messages .....	71
3.3	Handler Interface .....	72
3.3.1	Trigger .....	73
3.3.2	Handler Pin Assignments for Compare Operation .....	74

**Service & Calibration - Section 4**

4.1	General .....	75
4.2	Instrument Return .....	75
4.3	Calibration .....	75
4.3.1	1855 Verification Procedure .....	76
4.3.2	1855 Verification Data Sheet .....	76

---

## Warranty

---



QuadTech warrants that Products are free from defects in material and workmanship and, when properly used, will perform in accordance with QuadTech's applicable published specifications. If within one (1) year after original shipment it is found not to meet this standard, it will be repaired, or at the option of QuadTech, replaced at no charge when returned to a QuadTech service facility.

**Changes in the Product not approved by QuadTech shall void this warranty.**

**QuadTech shall not be liable for any indirect, special or consequential damages, even if notice has been given of the possibility of such damages.**

**This warranty is in lieu of all other warranties, expressed or implied, including, but not limited to any implied warranty or merchantability of fitness for a particular purpose.**

### SERVICE POLICY

QuadTech's service policy is to maintain product repair capability for a period of at least five (5) years after original shipment and to make this capability available at the then prevailing schedule of charges.



---

## Specifications

---

**Leakage Current Test:**

<b>Leakage Current:</b>	0.001uA – 20.0mA
<b>Accuracy:</b>	$\pm(0.3\% + 0.005\mu\text{A})$
<b>Test Voltage:</b>	1.0V – 650V DC, 0.1V/Step
<b>Voltage Accuracy:</b>	$\pm(0.5\% + 0.2\text{V})$
<b>Test Current:</b>	0.5mA – 500mA, 0.5mA/Step for DCV $\leq$ 100V 0.5mA – 150mA, 0.5mA/Step for DCV $>$ 100V
<b>Charge Current Accuracy:</b>	$\pm(3\% + 0.05\text{mA})$

**Insulation Resistance Test:**

<b>Insulation Resistance:</b>	10Ω – 99.99GΩ
<b>IR Accuracy:</b>	$\pm \left[ \left[ 0.6 + \frac{20\text{V}}{\text{Vm}} + \frac{0.5\mu\text{A}}{\text{Im}} \right] \times \left[ 1 + \frac{0.005\mu\text{A}}{\text{Im}} \right] \right] \%$

Where Vm and Im are measured voltage & current for a given load.

<b>Test Voltage:</b>	1.0V – 650V DC, 0.1V/Step
<b>Voltage Accuracy:</b>	$\pm(0.5\% + 0.2\text{V})$
<b>Test Current:</b>	0.5mA – 500mA, 0.5mA/Step for DCV $\leq$ 100V 0.5mA – 150mA, 0.5mA/Step for DCV $>$ 100V
<b>Charge Current Accuracy:</b>	$\pm(3\% + 0.05\text{mA})$

**Withstand Voltage Test:**

<b>Rise Time (Tr):</b>	0.05s – 120s
<b>Withstand Voltage (Vf):</b>	1.0V – 650V DC, 0.1V/Step
<b>Test Current:</b>	0.5mA – 150mA, 0.5mA/Step
<b>Charge Current Accuracy:</b>	$\pm(3\% + 0.05\text{mA})$
<b>Measure Time:</b>	30s – 600s
<b>MAX Charge Time:</b>	5s – 600s

---

## Specifications (Continued)

---

### General Features

<b>Test Types:</b>	Automatic Sequence Test Manual Step Test
<b>Null:</b>	Correction for Lead Leakage
<b>Monitored Voltage (Vm):</b>	1.0V – 650V DC (Voltage across DUT)
<b>Charge Time:</b>	0 – 999seconds in 1s/10s increments <100s; 100s increments >100s
<b>Delay Time:</b>	0.2 – 999seconds in 0.1s increments <100s; 10s increments >100s
<b>Discharge:</b>	65 Watt Discharge Circuit
<b>Trigger:</b>	Delay: 0 – 9.995 seconds in 0.1s increments Edge: Falling or Rising
<b>Measurement Mode:</b>	Continuous or Trigger (INT, EXT or Manual)
<b>Measurement Rate:</b>	Fast: 18 measurements/second Medium: 14 measurements/second Slow: 7 measurements/second
<b>Ranging:</b>	Automatic or Hold
<b>Averaging:</b>	1-8 measurements
<b>Compare:</b>	Set Upper & Lower Limits for LC and IR Tests
<b>Display:</b>	240 x 64 LCD Graphic display
<b>Indication:</b>	Audible alarm programmable HI, LOW or OFF for Pass or Fail
<b>Standard Interface:</b>	RS232
<b>Optional Interfaces:</b>	IEEE-488 & Handler
<b>Connectors:</b>	1 BNC terminal: Input 2 Banana terminals: HV (+), HV (-) 1 Banana Socket: Chassis Ground
<b>Front Panel Lockout:</b>	Keypad Lock

---

## Specifications (Continued)

---

<b>Mechanical:</b>	Bench Mount Dimensions: (w x h x d): 12.50 x 4.00 x 13.50 inches 317.2 x 101.5 x 342.6 mm	
<b>Weight:</b>	18 lbs (8.2kg) net, 22 lbs (10kg) shipping	
<b>Environmental:</b>	Operating: 10°C to 40°C Storage: -10°C to 50°C Humidity: <90% Pollution Degree 2 Installation Category I	
<b>Power:</b>	• 90-125VAC • 50 or 60Hz	• 190-250VAC • 400W max
<b>Supplied:</b>	• Instruction Manual • Calibration Certificate	• Power Cable • Lead Set
<b>Ordering Information:</b>	<u>Description</u> Capacitor Leakage Current/IR Meter	<u>Catalog No.</u> 1855



## Accessories

## Accessories Included

Item	Quantity	QuadTech P/N
AC Power Cord	1	4200-0300
Power Line Fuse: 4A 250V SB for 115V operation	1	520149
Power Line Fuse: 2A 250V SB for 230V operation	1	520148
Test Leads: Banana to Alligator Clip & BNC to Alligator Clip	1	1855-01
Instruction Manual	1	150767
Calibration Certificate	1	N/A

## **Accessories/Options Available**



---

## Safety Precautions

---

### CAUTION

The 1855 Capacitor Leakage Current/IR Meter can provide an output voltage of 650V DC to the device under test (DUT). Although the 1855 unit is a low voltage instrument, some devices (especially capacitors) can store charge when tested. If not discharged properly, these devices may cause serious hazards. Follow these safety instructions.

1. Operate the 1855 unit with its chassis connected to earth ground. The instrument is shipped with a three-prong power cord to provide this connection to ground. This power cord should only be plugged in to a receptacle that provides earth ground. Serious injury can result if the 1855 unit is not connected to earth ground.
2. Tightly connect BNC cable to the silver INPUT terminal. If this is not done, the DUT's casing can be charged to the high voltage test level and injury or electrical shock hazards could result if the DUT is touched.
3. Never touch the test leads, test fixture or DUT in any manner (this includes insulation on all wires and clips) when [TRIGGER] has been pressed and the output is applied.
4. Before turning on the 1855 instrument, make sure there is no device (DUT) or fixture connected to the test leads.
5. Make sure any capacitive device has been **discharged fully** before touching the test lead wires or output terminals.
6. **In the case of an emergency**, turn OFF the POWER switch using a "hot stick" and disconnect the AC power cord from the wall. Do not touch the 1855 instrument.
7. Be wary when the 1855 instrument is used in remote control mode. The voltage/current output is being turned on and off with an external signal.]
8. Do not exceed the 1A Maximum Input Current.



---

# Condensed Operating Instructions

---

## General Information

The 1855 Capacitor Leakage Current/IR Meter is an instrument for measuring the parameters of leakage current (LC), insulation resistance (IR), withstand voltage (WV) and rise time (Tr). The 1855 instrument functions mainly as a leakage current and withstand voltage tester for aluminum foil electrolytic capacitors and high dielectric ceramic capacitors. The 1855 instrument is useful in testing any components for which leakage current is a major factor including Zener diodes, absorbers, etc. For production testing, the 1855 instrument has a Compare function and Pass/Fail indication. Connection to device under test is through BNC/Banana terminals on the front panel.

## Start-Up

The 1855 Capacitor Leakage Current/IR Meter can be operated from a power source between 90-125V or 190-250V AC at a power line frequency of 50 or 60Hz. The standard 1855 unit is shipped from QuadTech with a 4A fuse in place for AC 90-125V operation. (A 2A fuse is included for AC 190-250V operation). The 1855 unit is shipped with the line voltage selector set for 115V. Refer to paragraph 1.4.3 for instructions on changing the fuse or line voltage selector.

Connect the 1855 Capacitor Leakage Current/IR Meter's AC power cord to the source of proper voltage. Operate the 1855 instrument with its chassis connected to earth ground. The 1855 instrument is shipped with a three-prong power cord to provide this connection to ground. This power cord should only be plugged into a receptacle that provides earth ground. Serious injury may result if the 1855 instrument is not connected to earth ground.

To turn the 1855 instrument ON, press the power button on the front panel. To switch the power OFF, press the button again or if measurements are to be made proceed with the Test Parameter Setup in Table COI-1. The 1855 instrument should warm up for 15 minutes prior to use.

**Table COI-1: Test Parameter Setup**

Test	LC/IR	WV/Tr
Parameter		
Test V	1.0V – 650V DC	N/A
C.C.	0.5mA – 500mA	N/A
Range	2uA-20uA-200uA-2mA-20mA	N/A
CHG T	0s – 999s	N/A
DWELL T	0.2s – 999s	N/A
Speed	Fast – Medium – Slow	N/A
Vf	N/A	1.0 – 650V DC
C.C.	N/A	0.5mA – 150mA
Tend	N/A	30s – 600s
CHG Tend	N/A	5s – 600s

**NOTE**

Refer to paragraphs 2.3.3 through 2.4 for a full description of programming test parameters. Test parameters must be set before the 1855 instrument can be zeroed.

## Condensed Operating Instructions (Continued)

There are three main menus within the 1855 instrument software. Familiarize yourself with these menus prior to programming a test. Figure COI-1 illustrates the MEAS DISPLAY screen and lists the functions that can be accessed by pressing the [MAIN INDEX] and [SYSTEM SETUP] keys.




Figure COI-1: 1855 Instrument Menus

### NOTE:

The function keys [F1 – F4] are used to select the parameter to change and in some menus to change the value of that selected parameter.

The function of UP/DOWN depends on the menu. In some menus, the LEFT/RIGHT keys are used to select a digit by moving the underscored cursor left or right.

# Condensed Operating Instructions (Continued)

## 1. Set Test Parameters

- Press [POWER] ON.
- Allow the instrument to warm up for 15 minutes.
- Press [MEAS DISPLAY]
- Set test parameters (voltage, current, range, etc.) using the function & arrow keys.

## 2. Null

After setting your test parameters, use the Null function of the 1855 instrument to zero the test leads. With no device connected, connect the appropriate cable to the front panel BNC/Banana connectors. Refer to paragraph 2.6 for cable connections.

With the instrument in MEAS DISPLAY status:

1. Press [MAIN INDEX]
2. Press [F3] = NULL
3. Press [TRIGGER] button.
4. Wait while instrument cycles through NULL test.
5. Press [MAIN INDEX] to return to MEAS DISPLAY status.
6. Choose Test: [SEQ Test], [STEP Test] or [Next Page] to select [WV Test]





Figure COI-2: NULL OPEN Configuration

## Condensed Operating Instructions (Continued)

### 3. Connection to Device under Test (DUT)

Figure COI-3 illustrates the connection of the 1855 instrument to a DUT using the 1855-01 Lead Set. For Leakage Current, Insulation Resistance and Withstand Voltage Tests, the red alligator clip/BNC cable is connected between the silver INPUT terminal on the 1855 unit and the high side of the device under test. The black alligator clip/banana cable is connected between the white HV (-) terminal on the 1855 unit and the low side of the DUT.



**COI-3: Connection to DUT for LC Test**

### 4. Make a Measurement

1. Press [MEAS DISPLAY]
2. Connect device under test (DUT) to test leads.
3. Press [TRIGGER].
4. Record measurement.

#### NOTE

Please read this instruction manual in its entirety before operating this instrument. These condensed operating instructions are not a substitute for all the information provided in the remainder of this manual.

# Section 1: Introduction

## 1.1 Unpacking and Inspection

Inspect the shipping carton before opening. If damaged, contact the carrier agent immediately. Inspect the 1855 Capacitor Leakage Current/IR Meter for any damage. If the instrument appears damaged or fails to meet specifications notify QuadTech (refer to instruction manual front cover) or its local representative. Retain the original shipping carton and packing material for future use such as returning the instrument for recalibration or service.

## 1.2 Product Overview

The 1855 Capacitor Leakage Current/IR Meter is a compact yet powerful LC Tester and IR meter for production or laboratory testing of aluminum electrolytic capacitors, resistors and other passive components. The 1855 instrument measures 4 parameters: Leakage Current (LC), Insulation Resistance (IR), Rise Time (Tr) and Withstand Voltage (Vf) and displays two simultaneously. Basic accuracy is  $\pm 0.3\%$ . From 1-8 measurements can be made, averaged and the result displayed with the Averaging function. Ranging is automatic or user selectable. Measurement rate is also selectable (Slow, Medium or Fast) with rates up to 18 measurements per second. Measurements can be made continuously or triggered with a programmable delay time up to 10 seconds. The 1855 comes standard with an RS-232 interface. An optional IEEE-488 and Handler interface is also available. Voltage across the DUT can be monitored and displayed. Zero the effects of stray leakage in the test leads with the Null function. The Compare function on the 1855 instrument has programmable upper and lower limits and displays Pass/Fail in addition to the measurement value. Connection to the device under test is through 1 BNC INPUT terminal and 2 Banana HV terminals on the front panel.





Figure 1-1: 1855 Capacitor Leakage Current/IR Meter

## 1.3 Controls and Indicators

### 1.3.1 Front Panel Controls and Indicators

Figure 1-2 illustrates the controls and indicators on the front panel of the 1855 Capacitor Leakage Current/IR Meter instrument. Table 1-1 identifies them with description and function.




**Figure 1-2: 1855 Front Panel Controls & Indicators**

**Table 1-1: 1855 Front Panel Controls & Indicators**

Reference # Figure 1-2	Name	Type	Function
1		Green Push Button	Apply AC POWER: 1=ON, 0=OFF
2		Silver Banana Jack	Chassis ground connection
3a	INPUT	Silver BNC terminal	Current Drive Terminal, High (+)
3b	HV (+)	Red Banana Jack	Voltage Sense Terminal, High (+)
3c	HV (-)	White Banana Jack	Voltage Sense Terminal, Low (-)
4	F1, F2, F3 and F4	4 gray push buttons	Select Instrument Functions Keys perform different functions under different menus. Right side of display shows corresponding key function.
5	◀, ▼, ▶, ▲	4 gray push buttons	Move backlit box around display to choose parameter Change parameter value (increase/decrease)
6	TRIGGER	Gray push button	Initiate measurement
7	DISCHARGE		STOP measurement in progress & initiate discharge time
8	SYSTEM SETUP	Gray push button	View, Select or Change System Parameters: Parameter, Beeper, Sound, Alarm, Trigger, Handler, Contrast, GPIB, RS-232, Key Lock, Line Frequency, Charge, Dwell, Average & EXT Vm Display
9	MAIN INDEX	Gray push button	View, Select or Change Setup & Result Parameters: Sequence, Step, Null, WV Test & Compare
10	MEAS DISPLAY	Gray push button	View, Select or Change Measurement Parameters: Voltage, Current, Range, Charge, Dwell, Speed & Trigger
11		240 x 64 LCD display	Show measurement results as value or pass/fail. Show programming instructions

### 1.3.2 Rear Panel Controls and Connectors

Figure 1-3 illustrates the controls and connectors on the rear panel of the 1855 Capacitor Leakage Current/IR Meter instrument. Table 1-2 identifies them with description and function.



**Figure 1-3: Rear Panel 1855 Instrument**


**Table 1-2: 1855 Rear Panel Controls & Connectors**

Reference # Figure 1-3	Name	Type	Function
1	HANDLER INTERFACE	Blue 24-pin connector	Handler Interface connector for remote operation
2	IEEE-488 INTERFACE	Blue 24-pin connector	IEEE-488 Interface connector for data transfer
3	FUSE	Black screw cap fuse holder	Short circuit protection T 4A 250V fuse for 115V operation T 2A 250V fuse for 230V operation
4	LINE VOLTAGE SELECTED	2 Red 2-position Slide Switches	Select Voltage Level corresponding to AC Source 90V – 125V: T4.0A 250V fuse 190V – 250V: T 2A 250V fuse
5	AC Line Input	Black 3-wire inlet module	Connection to AC power source
6	RS-232 INTERFACE	Black 9-pin	RS-232 interface for serial communication

## 1.4 Installation

### 1.4.1 Dimensions

The 1855 Capacitor Leakage Current/IR Meter unit is supplied in a bench configuration, i.e., in a cabinet with resilient feet for placement on a table. Flip feet are attached under the front feet so that the 1855 instrument can be tilted up for convenient operator viewing.



**Figure 1-4: 1855 Instrument Dimensions**

### 1.4.2 Instrument Positioning

The 1855 instrument contains one (1) graphic display for direct readout of measured parameters. The optimum angle for viewing is slightly down and about 10 degrees either side of center. For bench operation the front flip feet should always be used to angle the instrument up. In bench or rack mount applications the instrument should be positioned with consideration for ample air flow around the rear panel fan ventilation hole. An open space of at least 3 inches (75mm) is recommended behind the rear panel. Testing should be performed on a non-conductive surface. An ESD mat is not a recommended test platform.

### 1.4.3 Power Requirements

The 1855 can be operated from a power source of 90 to 125V AC or 190 to 250V AC. Power connection is via the rear panel through a standard receptacle. Before connecting the 3-wire power cord between the unit and AC power source, make sure the voltage selection switches on the rear panel (Figure 1-5) are in accordance with the power source being used. For a 90-125V source, use a 4A 250V fuse. For a 190-250V source, use a 2A 250V fuse. Always use an outlet that has a properly connected protection ground.

### CAUTION

Make sure the unit has been disconnected from its AC power source for at least five minutes before proceeding.

### Procedure for Changing an 1855 Instrument Fuse

**Unscrew the fuse cap on the rear panel of the 1855 and pull fuse holder outward.**

Once the fuse holder has been removed from the instrument snap the fuse from the holder and replace. Make sure the new fuse is of the proper rating.


Install the fuse back into the cap holder by pushing in until it locks securely in place.

**! WARNING:** FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE AND RATING OF FUSE AS SPECIFIED FOR THE LINE VOLTAGE BEING UTILIZED.

**! CAUTION:** NO OPERATOR SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.

POLLUTION DEGREE 2  
INSTALLATION CATEGORY I

115V ~/230V~  
50/60Hz 400VA MAX



FUSE

LINE VOLTAGE  
SELECTED



115V  
90V-125V~  
T4.0AL 250V

230V  
190V-250V~  
T2.0AL 250V

**Figure 1-5: Close-Up of 1855 Rear Panel**

#### 1.4.4 Safety Inspection

Before operating the instrument inspect the fuse holder on the rear of the 1855 instrument to ensure that the properly rated fuse is in place, otherwise damage to the unit is possible. Make sure that the voltage selector switches are set in accordance with the power source in use. Refer to paragraph 1.4.3 and Figure 1-5.

The 1855 instrument is shipped with a standard U.S. power cord, QuadTech P/N 4200-0300 (with Belden SPH-386 socket or equivalent, and a 3-wire plug conforming to IEC 320). Make sure the instrument is only used with these cables (or other approved international cord set) to ensure that the instrument is provided with connection to protective earth ground.

The surrounding environment should be free from excessive dust to prevent contamination of electronic circuits. The surrounding environment should also be free from excessive vibration. Do not expose the 1855 instrument to direct sunlight, extreme temperature or humidity variations, or corrosive chemicals.



---

## Section 2: Operation

---

### 2.1 Terms and Conventions

**Table 2-1: Measurement Unit Prefixes**

<u>Multiple</u>	<u>Scientific</u>	<u>Engineering</u>	<u>Symbol</u>
1000000000000000	$10^{15}$	Peta	P
1000000000000	$10^{12}$	Tera	T
1000000000	$10^9$	Giga	G
1000000	$10^6$	Mega	M
1000	$10^3$	Kilo	k
.001	$10^{-3}$	milli	m
.000001	$10^{-6}$	micro	$\mu$
.00000001	$10^{-9}$	nano	n
.0000000001	$10^{-12}$	pico	p
.000000000001	$10^{-15}$	femto	f

Capacitor:	Abbreviated C. A capacitor is passive component comprised of two conductors separated by a dielectric. A capacitor stores charge blocks DC flow and allows AC flow based on frequency and capacitor design.
Capacitance:	The measure of the ratio of charge on either plate of a capacitor to the potential difference (voltage) across the plates. Unit of measure is the Farad (F).
Compare:	Procedure for sorting components by comparing the measured value against a known standard.
DC:	Direct Current. Non-reversing polarity. The movement of charge is in one direction. Used to describe both current and voltage. Batteries supply direct current (DC).
Dielectric:	A material which is an electrical insulator or in which an electric field can be sustained with a minimum dissipation of power.
Dielectric Absorption:	The physical phenomenon of insulation appearing to absorb and retain an electrical charge slowly over time. Apply a voltage to a capacitor for an extended period of time and then quickly discharge it to zero voltage. Leave the capacitor open circuited for a period of time then connect a voltmeter and measure the residual voltage. The residual voltage is caused by the dielectric absorption of the capacitor.
Dielectric Constant:	Abbreviated K, relative dielectric constant. The dielectric constant of a material is the ratio of the capacitance of a capacitor filled with a given dielectric to that same capacitor having only a vacuum as a dielectric.
Discharge:	The act of draining off an electrical charge to ground. Devices that retain charge should be discharged after an IR test or DC hipot test.

DUT:	Device Under Test. (i.e. the product being tested).
Ground:	The base reference from which voltages are measured, nominally the same potential as the earth. Ground is also the side of a circuit that is at the same potential as the base reference.
Insulation Resistance:	Measures the total resistance between any two points separated by electrical insulation. The IR test determines how effective the dielectric (insulation) is in resisting the flow of electrical current.
<b>Interface:</b>	
Handler:	Device for remote control of test instrument in component handling operations.
IEEE-488:	General Purpose Interface Bus (GPIB). GPIB is an industry standard definition of a Parallel bus connection for the purpose of communicating data between devices.
RS232:	An industry standard definition for a Serial line communication link or port.
Range:	The resistance ranges the instrument uses for reference in making the measurement.
Speed:	The rate at which the instrument makes a measurement in measurements per second. Speed is inversely proportional to accuracy.
<b>Trigger:</b>	
External:	The test is initiated via an external source such as a computer with an IEEE-488 or Handler interface. One measurement is made each time the external trigger is asserted on the handler.
Internal:	The instrument continuously makes measurements.
Manual:	The operator initiates the test by pressing the [START] button. One measurement is made each time the trigger is pressed.
Withstand Voltage:	Voltage at which the product's insulation begins to break down. There are many definitions for Withstand Voltage. This manual uses the terminology from the EIAJ RC-2364A standard, "Test Methods of Electrode Foils for Aluminum Electrolytic Capacitors".

Term	Symbol	Definition
Formation Voltage	V <sub>fe</sub>	The final applied voltage
Standard Dielectric Withstand Voltage	V <sub>f</sub>	The withstand voltage of formed foil
Rise Time	T <sub>r</sub>	The time between when the current is applied and the voltage reaches 90% of the rated withstand voltage, V <sub>f</sub> .
Withstand Voltage	V <sub>t</sub>	T <sub>r</sub> + 3minutes $\pm$ 10seconds (formed foils) T <sub>r</sub> + 1minute $\pm$ 10seconds (unformed foils)
Rated Voltage	WV	Rated working voltage of a capacitor

## 2.2 Startup

Check to make sure the red Line Voltage Selector switch on the rear panel agrees with the power source available. Depending on the power source the switch position should be in the up or down position as shown in Figure 1-5 (Close-Up of 1855 Rear Panel).

**CAUTION**


USE ALL PRECAUTIONS NECESSARY TO AVOID TOUCHING THE DEVICE UNDER TEST WHEN THE **TRIGGER** BUTTON HAS BEEN PRESSED.

Connect the instrument power cord to the source of proper voltage. **The instrument is to be used only with three-wire grounded outlets.**

Power is applied to the 1855 instrument by pressing the green power switch on the front panel to the ON (1 position). The 1855 unit should warm up for a period of at least 15 minutes prior to measurements being made.

## 2.3 SYSTEM SETUP

System Setup contains the 1855 instrument setup functions: Calibration, Memory Manage and System Configuration. Press [SYSTEM SETUP] to access these functions.



**Figure: 2-1: System Setup**

### 2.3.1 Calibration

The Calibration menu is to be [accessed by Qualified Service Personnel Only](#). Altering the 1855 instrument calibration will void the instrument warranty. The Calibration function is used to verify the resistance measurement ranges. To access the calibration function, press [SYSTEM SETUP] then press [F1] = [CALIBRATION]. Enter the password. [▲] [▼] [►] [◀] [TRIGGER]. Select cal range 20V or 200V. Refer to paragraph 4.3 Calibration for procedure.

### 2.3.2 Memory Manage

The Memory Manage menu is to be [accessed by Qualified Service Personnel Only](#). Altering the 1855 instrument memory will void the instrument warranty. The memory manage function is used to verify the setup of the 1855 unit with a Function Test and a Handler Test. To access the memory manage function, press [SYSTEM SETUP] then press [F2] = [MEM MANAGE]. Enter the password. [▲] [▼] [►] [◀] [TRIGGER].

### 2.3.3 System Configuration

Prior to programming a test or measuring a device, set up the system controls of the 1855 instrument. To access the system controls, press [SYSTEM SETUP] then press [F3] = [SYSTEM CONFIG]. Table 2-2 lists the contents of SYSTEM CONFIG.

< SYSTEM SETUP >		CALIBRATION	F1	Enter Calibration
		MEM MANAGE	F2	Enter Memory Manage
		SYSTEM CONFIG	F3	Enter System Configuration
< SYSTEM CONFIG >				
TEST PARAMETER	: L.C.	I.R.	F1	Set Test Parameter to IR
BEEPER	: LOW	L.C.	F2	Set Test Parameter to LC
SOUND MODE	: FAIL		F3	
ALARM MODE	: PULSE		F4	
TRIG DELAY	: 0000 mS			
TRIG EDGE	: FALLING			
HANDLER MODE	: CLEAR			
< SYSTEM CONFIG >		DIGIT UP	F1	Increase brightness: 00 - 15
CONTRAST	: 07	DIGIT DOWN	F2	Decrease brightness: 15 - 00
GPIB ADDRESS	: 17		F3	
RS232 BAUD RATE	: 19200		F4	
KEY LOCK	: OFF			
LINE FREQUENCY	: 60Hz			
CHARGE TIME	: $V_m = V_s$			
RANGE DWELL	: 0.0 S			
< SYSTEM CONFIG >		DIGIT UP	F1	Increase # to Average: 1 - 8
AVERAGE	: 1	DIGIT DOWN	F2	Decrease # to Average: 8 - 1
EXT $V_m$ DISPLAY	: OFF		F3	
			F4	

Figure 2-2: System Configuration

Table 2-2: SYSTEM CONFIG

Parameter	Function	Range
Test Parameter	Set the parameter to be tested	LC, IR
Beepers	Set beeper loudness	OFF, LOW or HIGH
Sound Mode	Set when the buzzer to sounds	PASS/FAIL
Alarm Mode	Set type of alarm signal	PULSE/CONTINUOUS
Trigger Delay	Set external trigger time	0000 – 9999 ms
Trigger Edge	Set trigger mode	FALLING/RISING
Handler Mode	Set handler interface mode	CLEAR/HOLD
Contrast	Set display contrast	00 – 15
GPIB Address Code	Set interface address	00 – 30
RS-232 Baud Rate	Set baud rate	600, 1200, 4800, 9600, 19200, 28800
Key Lock	Lock out front panel programming	OFF/ON
Line Frequency	Set line input frequency	50Hz/60Hz
Charge Time	Set time for unit to charge DUT	0 – 999seconds
Range Dwell	Set time for unit to stabilize at test level	0.2 – 999seconds
Average Time	Set measurement average	1 – 8
EXT $V_m$ Display	Display output voltage	OFF/ON

### 2.3.3.1 Test Parameter

The 1855 Capacitor Leakage Current/IR Meter can function as a Leakage Current tester or as an Insulation Resistance meter. The instrument default setting is L.C. To change the function of the 1855 Capacitor Leakage Current/IR Meter press [SYSTEM SETUP] then [SYSTEM CONFIG] The box next to TEST PARAMETER is highlighted. Press [F1] = I.R. to select an Insulation Resistance test or press [F2] = L.C. to select the Leakage Current test.

< SYSTEM CONFIG >		
TEST PARAMETER	:	L.C.
BEEPER	:	LOW
SOUND MODE	:	FAIL
ALARM MODE	:	PULSE
TRIG DELAY	:	0000 mS
TRIG EDGE	:	FALLING
HANDLER MODE	:	CLEAR

I.R.

L.C.

F1 Set Test Parameter to IR  
F2 Set Test Parameter to LC  
F3  
F4

### 2.3.3.2 Beeper

The volume of the beeper or audible alarm can be set to OFF, LOW or HIGH. The instrument default setting is LOW. To change the beeper loudness press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [↓] until the box next to BEEPER is highlighted, then press [F1] = OFF, [F2] = LOW or [F3] = HIGH.

< SYSTEM CONFIG >		
TEST PARAMETER	:	L.C.
BEEPER	:	LOW
SOUND MODE	:	FAIL
ALARM MODE	:	PULSE
TRIG DELAY	:	0000 mS
TRIG EDGE	:	FALLING
HANDLER MODE	:	CLEAR

OFF

LOW

HIGH

F1 Turn Beeper OFF  
F2 Set Beeper to Low  
F3 Set Beeper to High  
F4

### 2.3.3.3 Sound Mode

The audible alarm can be set to sound on PASS or to sound on FAIL under high or low limit judgment in the measure display. The instrument default setting is FAIL. To change the sound mode press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [↓] until the box next to SOUND MODE is highlighted, then press [F1] = PASS for the alarm to sound on a pass result or [F2] = FAIL for the alarm to sound on a fail result.

< SYSTEM CONFIG >		
TEST PARAMETER	:	L.C.
BEEPER	:	LOW
SOUND MODE	:	FAIL
ALARM MODE	:	PULSE
TRIG DELAY	:	0000 mS
TRIG EDGE	:	FALLING
HANDLER MODE	:	CLEAR

PASS

FAIL

F1 Alarm will sound on PASS  
F2 Alarm will sound on FAIL  
F3  
F4

### 2.3.3.4 Alarm Mode

The type of audible alarm can be set to PULSE or CONTINUOUS during judgment in the measure display. The instrument default setting is PULSE. To change the alarm mode press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to ALARM MODE is highlighted, then press [F1] = PULSE for the alarm to sound in a pulse tone or [F2] = CONTINUOUS for the alarm to sound continuously.

< SYSTEM CONFIG >	
TEST PARAMETER	: L.C.
BEEPER	: LOW
SOUND MODE	: FAIL
ALARM MODE	: <b>PULSE</b>
TRIG DELAY	: 0000 mS
TRIG EDGE	: FALLING
HANDLER MODE	: CLEAR

PULSE  
CONTINUOUS

**F1** Alarm will Pulse\*  
**F2** Alarm will Continuously sound\*  
\*(Until Discharge is pressed)

### 2.3.3.5 Trigger Delay

The trigger delay is the amount of time between the activation of a trigger (via IEEE, Handler or front panel) and the 1855 making the measurement. The delay time can be programmed from 0000 to 9995 seconds. The instrument default value is 0000 seconds. To change the TRIGGER DELAY press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to TRIGGER DELAY is highlighted, then press [F1] = DIGIT UP to increase the delay time, [F2] = DIGIT DOWN to decrease the delay time or [F3] = DIGIT to move over a decimal place.

< SYSTEM CONFIG >	
TEST PARAMETER	: L.C.
BEEPER	: LOW
SOUND MODE	: FAIL
ALARM MODE	: PULSE
TRIG DELAY	: <b>0000 mS</b>
TRIG EDGE	: FALLING
HANDLER MODE	: CLEAR

DIGIT UP  
DIGIT DOWN  
DIGIT

**F1** 0 - 9995 mS  
**F2** 9995 - 0 mS  
**F3** Move cursor to next digit  
**F4**

### 2.3.3.6 Trigger Edge

Select on which edge the measurement is triggered: FALLING or RISING. The instrument default setting is FALLING. To change the TRIGGER EDGE press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to TRIGGER EDGE is highlighted, then press [F1] = FALLING or [F2] = RISING.

< SYSTEM CONFIG >	
TEST PARAMETER	: L.C.
BEEPER	: LOW
SOUND MODE	: FAIL
ALARM MODE	: PULSE
TRIG DELAY	: 0000 mS
TRIG EDGE	: <b>FALLING</b>
HANDLER MODE	: CLEAR

FALLING  
RISING

**F1** Initiate Trigger on Falling Edge  
**F2** Initiate Trigger on Rising Edge  
**F3**  
**F4**

### 2.3.3.7 Handler Mode

The handler interface mode can be set to CLEAR or HOLD. The instrument default setting is CLEAR. When set to CLEAR, the handler interface will clear the last test result prior to each subsequent measurement. When set to HOLD, the handler interface will hold the last test result until the next measurement is made and displayed. To change the handler mode press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to HANDLER MODE is highlighted, then press [F1] = CLEAR or [F2] = HOLD.

< SYSTEM CONFIG >				
TEST PARAMETER	: L.C.	CLEAR	F1	Clear Test Results
BEEPER	: LOW	HOLD	F2	Hold Test Results
SOUND MODE	: FAIL		F3	
ALARM MODE	: PULSE		F4	
TRIG DELAY	: 0000 mS			
TRIG EDGE	: FALLING			
HANDLER MODE	: CLEAR			

### 2.3.3.8 Contrast

The display contrast can be set from 00 to 15. The instrument default setting is 07. The darkest contrast is 00 the brightest is 15. To change the display contrast press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to CONTRAST is highlighted, then press [F1] = DIGIT UP to brighten the contrast or [F2] = DIGIT DOWN to darken the contrast.

< SYSTEM CONFIG >				
CONTRAST	: 07	DIGIT UP	F1	Increase brightness: 00 - 16
GPIB ADDRESS	: 17	DIGIT DOWN	F2	Decrease brightness: 16 - 00
RS232 BAUD RATE	: 19200		F3	
KEY LOCK	: OFF		F4	
LINE FREQUENCY	: 60Hz			
CHARGE TIME	: $V_m = V_s$			
RANGE DWELL	: 0.0 S			

### 2.3.3.9 GPIB Address Code

The IEEE-488 interface address can be programmed from 00 to 30. The instrument default setting is 17. To change the GPIB ADDRESS press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to GPIB ADDRESS is highlighted, then press [F1] = DIGIT UP to increase the address, or [F2] = DIGIT DOWN to decrease the address.

< SYSTEM CONFIG >				
CONTRAST	: 07	DIGIT UP	F1	Increase address: 00 - 30
GPIB ADDRESS	: 17	DIGIT DOWN	F2	Decrease address: 30 - 00
RS232 BAUD RATE	: 19200		F3	
KEY LOCK	: OFF		F4	
LINE FREQUENCY	: 60Hz			
CHARGE TIME	: $V_m = V_s$			
RANGE DWELL	: 0.0 S			

### 2.3.3.10 RS-232 Baud Rate

The baud rate of the RS-232 interface can be programmed from 600 to 28800 bps. The instrument default setting is 9600bps. To change the RS-232 BAUD RATE press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow  $\downarrow$  until the box next to RS-232 BAUD RATE is highlighted, then press [F1] = 600, [F2] = [1200], [F3] = 4800, [F4] = NEXT to go to the next page and select [F1] = 9600, [F2] = 19200, [F3] = 28800 or [F4] = NEXT to return to first RS232 baud rate selection page.

< SYSTEM CONFIG >			
CONTRAST	: 07	600	<b>F1</b> Select 600 bps
GPIB ADDRESS	: 17	1200	<b>F2</b> Select 1200 bps
RS232 BAUD RATE	: 19200	4800	<b>F3</b> Select 4800 bps
KEY LOCK	: OFF	9600	<b>F4</b> Go to 2 <sup>ND</sup> RS232 page
LINE FREQUENCY	: 60Hz	19200	
CHARGE TIME	: Vm = Vs	28800	
RANGE DWELL	: 0.0 S	NEXT PAGE 1/2	

< SYSTEM CONFIG >			
CONTRAST	: 07	9600	<b>F1</b> Select 9600 bps
GPIB ADDRESS	: 17	19200	<b>F2</b> Select 19200 bps
RS232 BAUD RATE	: 19200	28800	<b>F3</b> Select 28800 bps
KEY LOCK	: OFF	19200	<b>F4</b> Go back to 1 <sup>ST</sup> RS232 page
LINE FREQUENCY	: 60Hz		
CHARGE TIME	: Vm = Vs		
RANGE DWELL	: 0.0 S	NEXT PAGE 2/2	

### 2.3.3.11 Key Lock

To lock out the front panel operations with the exception of the [TRIGGER] key, set the key lock function to ON. Press [SYSTEM SETUP], [SYSTEM CONFIG],  $\downarrow$  until OFF is highlighted next to KEY LOCK, then press [F1] = ON. The backlit LOCK block will appear in the top right hand corner of the measure display. To turn the key lock function OFF: press [F1], [F4] and then [SYSTEM SETUP]. Key lock can be set ON or OFF. The instrument default setting is OFF.

< SYSTEM CONFIG >			
CONTRAST	: 07	ON	<b>F1</b> ON= Front panel locked out
GPIB ADDRESS	: 17	OFF	<b>F2</b> OFF = Front panel operational
RS232 BAUD RATE	: 19200		<b>F3</b>
KEY LOCK	: OFF		<b>F4</b>
LINE FREQUENCY	: 60Hz		
CHARGE TIME	: Vm = Vs		
RANGE DWELL	: 0.0 S		

< MEAS DISPLAY: SEQ. TEST >		TEST V. : <b>LOCK</b> 1.0V	
Lc :	3.65 mA	C.C. : 0.5mA	
Vm = 0.0V		RANGE : A 2uA	
CHARGE TEST	DISCHARGE	NEXT PAGE 1/2	

NOTE: Key Lock is disabled when the 1855 instrument is shut down.

### 2.3.3.12 Line Frequency

In accordance with the AC power source, the frequency of the line voltage can be set to 50Hz or 60Hz. The instrument default setting is 60Hz. To change the line frequency press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow  $\downarrow$  until the box next to LINE FREQUENCY is highlighted, then press [F1] = 50Hz or [F2] = 60Hz.

< SYSTEM CONFIG >		
CONTRAST	:	07
GPIB ADDRESS	:	17
RS232 BAUD RATE	:	19200
KEY LOCK	:	OFF
LINE FREQUENCY	:	60Hz
CHARGE TIME	:	V <sub>m</sub> = V <sub>s</sub>
RANGE DWELL	:	0.0 S

F1 Line Frequency = 60Hz  
F2 Line Frequency = 50Hz  
F3  
F4

### 2.3.3.13 Charge Time

Charge Time is defined as when the 1855 instrument will start charging the device under test. Select V<sub>m</sub> = V<sub>s</sub> to have the 1855 instrument start charging when monitored voltage reaches the set (programmed) voltage. Select V<sub>m</sub> = 0V to have the instrument start charging the device when the [TRIGGER] button is pressed. The instrument default value is V<sub>m</sub> = V<sub>s</sub>. To change the CHARGE TIME press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow  $\downarrow$  until the box next to CHARGE TIME is highlighted, then press [F1] = V<sub>m</sub>=V<sub>s</sub> or [F2] = V<sub>m</sub>=0V.

< SYSTEM CONFIG >		
CONTRAST	:	07
GPIB ADDRESS	:	17
RS232 BAUD RATE	:	19200
KEY LOCK	:	OFF
LINE FREQUENCY	:	60Hz
CHARGE TIME	:	V <sub>m</sub> = V <sub>s</sub>
RANGE DWELL	:	0.0 S

F1 Start Charge Time when V<sub>monitored</sub> = V<sub>set</sub>  
F2 Start Charge Time when [TRIGGER] is pressed  
F3  
F4

### 2.3.3.14 Range Dwell

The range dwell is the amount of time the instrument holds at the programmed test voltage before the 1855 makes the measurement. The range dwell is in addition to, and occurs after, the charge time. The range dwell can be programmed from 0 to 9.9 seconds. The instrument default value is 0 seconds. To change the RANGE DWELL press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow  $\downarrow$  until the box next to RANGE DWELL is highlighted, then press [F1] = DIGIT UP to increase the delay time, [F2] = DIGIT DOWN to decrease the delay time or [F3] = DIGIT to move over a decimal place.

< SYSTEM CONFIG >		
CONTRAST	:	07
GPIB ADDRESS	:	17
RS232 BAUD RATE	:	19200
KEY LOCK	:	OFF
LINE FREQUENCY	:	60Hz
CHARGE TIME	:	V <sub>m</sub> = V <sub>s</sub>
RANGE DWELL	:	0.0 S

DIGIT UP  
DIGIT DOWN  
F1 Increase dwell time 0.0 - 9.9S  
F2 Decrease dwell time 9.9 - 0.0S  
F3  
F4

**Note:** Refer to paragraph 2.5.5 to program Dwell Time in a Sequence Test.


### 2.3.3.15 Average

The 1855 instrument can make many measurements then display the average based on what average number was selected. The range is 1 – 8 and the instrument default setting is 1. To change the number to average press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to AVERAGE is highlighted, then press [F1] = DIGIT UP to increase then number of measurements to take before displaying the average or [F2] = DIGIT DOWN to decrease the number.



### 2.3.3.16 EXT VM Display

The voltage across the DUT can be displayed along with the measured value when EXT Vm DISPLAY is set to ON. EXT Vm DISPLAY can be selected OFF/ON. The instrument default setting is OFF. To change the EXT Vm Display press [SYSTEM SETUP], [SYSTEM CONFIG] and the down arrow [ $\downarrow$ ] until the box next to EXT Vm DISPLAY is highlighted, then press [F1] = ON to display the voltage across the DUT, or [F2] = OFF.



When selected ON, the measured voltage (Vm) will be displayed in the bottom left-hand corner of the display.

#### Note:

For Faster test speed during production testing, EXT Vm should be set to OFF.

## 2.4 MAIN INDEX

Within the 1855 instrument's MAIN INDEX are the Sequence Test, Step Test, Null, Withstand Voltage Test and Compare functions. To access these functions, press [MAIN INDEX] and the display should look as shown in Figure 2-3.




Figure 2-3: MAIN INDEX

### 2.4.1 Sequence Test

The Sequence Test automatically cycles through the test when [TRIGGER] is pressed. To access the Sequence Test, press [MAIN INDEX] and [F1] = SEQ. TEST. The MEAS DISPLAY menu will appear. Program the Test Voltage, Constant Current, Range, Charge Time, Dwell Time and Speed. Refer to paragraphs 2.5.1 through 2.5.6 for programming details.





Figure 2-4: Sequence Test Parameters

## 2.4.2 Step Test

The Step Test manually cycles through the test when [TRIGGER] is pressed. To access the Step Test, press [MAIN INDEX] and [F2] = STEP TEST. The MEAS DISPLAY menu will appear. Program the Test Voltage, Constant Current, Range, Trigger and Speed. Refer to paragraphs 2.5.1 through 2.5.7 for programming details.




**Figure 2-5: Step Test Parameters**

## 2.4.3 Null

During the 1855 instrument Null process a correction is made (subtracted out) as the result of lead leakage current and stored in instrument memory to be applied to ongoing measurements. For maximum measurement accuracy it is recommended that the NULL function be performed on the 1855 instrument after power up, any time the test parameters are changed and any time the test leads or fixture is changed.

Using the output voltage set in the SEQ or STEP test, the Null function measures the leakage current of each range (20mA – 2mA – 200uA – 20uA – 2uA) under open circuit conditions. After setting test parameters in the SEQ or STEP tests, connect the test leads to the 1855 output connectors. Do not connect the device under test. Press [MAIN INDEX] and [F3] = NULL TEST. There are no settings for NULL TEST. Press [TRIGGER] and the 1855 instrument will complete the null function.


Connection of test leads for Null function:



**Figure 2-6: Null Connection**

#### 2.4.4 Withstand Voltage Test

To access the Withstand Voltage Test, press [MAIN INDEX] and [F4] = NEXT PAGE 1/2 and then press [F1] = W.V. TEST. The MEAS DISPLAY menu will appear. Program the Test Voltage, Constant Current, Measurement Time and maximum Charge Time. Refer to paragraphs 2.5.8 through 2.5.10 for programming details.



**Figure 2-7: Withstand Voltage Parameters**

Withstand Voltage is the voltage at which the product's insulation begins to break down. There are however many definitions for Withstand Voltage. The 1855 instrument and this manual use the WV terminology from the EIAJ RC-2364A standard, "Test Methods of Electrode Foils for Aluminum Electrolytic Capacitors".

- Vf: The standard dielectric withstand voltage
- CC: The constant charge current for the WV test
- Tend: The measurement time for the WV test.  $T_{end} = T_r +$  the programmed test time.
- CHG. Tend: The maximum charge time for the WV test.
- Tr: The time between the start of the current application and the voltage reaching 90% of rated withstand voltage (Vf).
- Vt: The measured voltage at the end of the WV test.

Figure 2-7 illustrates a Withstand Voltage test. The following parameters were set:  $V_f=50V$ ,  $CC=2mA$ ,  $T_{end}=30$  seconds and  $CHG\ Tend=5$  seconds. After [TRIGGER] is pressed, the results shown in Figure 2-7 are Rise Time ( $T_r$ ) = 0.15 seconds and Measured Voltage ( $V_t$ ) = 58.00V. In the bottom left-hand corner above the test status boxes (CHARGE – TEST – DISCHARGE) are two results:  $V_m=0.0V$  and  $58.0V/30.15S$ . The  $V_m=0.0V$  box is the monitor of the output voltage during the test. The  $58.0V/30.15S$  box is the last measured voltage and time when the test ended.

## 2.4.5 Compare

The Compare function provides the capability to set an upper and/or lower limit for a leakage current or insulation resistance test and to display Pass/Fail with the measured result. To access the Compare function, press [MAIN INDEX] and [F4] = NEXT PAGE 1/2 then press [F2] = COMPARE. Select the Parameter (L.C. or IR) and program the Upper and Lower limits.

The Upper Limit is the high limit or upper value for a test to be considered a pass. If the measured value is higher than the upper limit the test is considered a fail. The Lower Limit is the lower value for a test to be considered a pass. If the measured value is lower than the low limit the test is considered a fail.

In an LC test, the range for Upper Limit is 0.000uA – 999.999mA and the Lower Limit range is 0.000uA to the Upper Limit. In an IR test, the range of the Upper Limit is 0.01kΩ – 99.99GΩ and the Lower Limit is 0.01kΩ – the Upper Limit.




Figure 2-8: Compare Function

To set up and display PASS/FAIL on the MEAS DISPLAY screen, use the COMPARE function. Example: Parameter = Leakage Current. Upper Limit = 15mA, Lower Limit = 0.





Figure 2-9: Compare Example

## 2.5 MEAS DISPLAY

The 1855 instrument's stand-by display is the MEAS DISPLAY. After power has been applied to the instrument and it cycles quickly through the information screen, the instrument reverts to the MAIN INDEX. Once [SEQ. TEST] or [STEP TEST] is selected the instrument enters the MEAS DISPLAY. To view the instrument information screen as illustrated in Figure 2.10, press [SYSTEM SETUP] then [ $\Leftarrow$ ].



**Figure 2.10: Instrument Information Screen**

< MEAS DISPLAY: SEQ. TEST >			TEST V. : 1.0V
Lc :	A	C.C. :	0.5mA
Vm = 0.0V		RANGE :	A 2uA
CHARGE	TEST	DISCHARGE	NEXT PAGE 1/2
< MEAS DISPLAY: SEQ. TEST >			CHG T. : 0 S
Lc :	A	DWELL T:	0.2 S
Vm = 0.0V		SPEED :	MEDIUM
CHARGE	TEST	DISCHARGE	NEXT PAGE 2/2

**Figure 2.11: MEAS DISPLAY- SEQUENCE TEST**

< MEAS DISPLAY: STEP TEST >			TEST V. : 1.0V
Lc :	A	C.C. :	0.5mA
Vm = 0.0V		RANGE :	A 2uA
CHARGE	TEST	DISCHARGE	NEXT PAGE 1/2
< MEAS DISPLAY: STEP TEST >			TRIGGER : INT
Lc :	A	SPEED :	MEDIUM
Vm = 0.0V			
CHARGE	TEST	DISCHARGE	NEXT PAGE 2/2

**Figure 2-12: MEAS DISPLAY – STEP TEST**

Figure 2.11 illustrates the two pages of parameters that can be programmed within the MEAS DISPLAY for a SEQUENCE TEST. Figure 2.12 illustrates the two pages of parameters that can be programmed within the MEAS DISPLAY for a STEP TEST. The two tests have the similar programmable parameters with the exception of Charge Time, Range Dwell and Trigger. All programmable parameters are explained in Paragraphs 2.5.1 through 2.5.8.

### 2.5.1 Test Voltage


The test voltage can be programmed from 1.00V to 650V. In MEAS DISPLAY press [F1] = TEST V so that the **1.00** V box is highlighted. Use the up arrow or down arrow keys to in/increase the voltage in multi-V increments. The left and right arrows will increase/decrease the voltage in 1V increments. The instrument default setting is 1.00V.

UP arrow [ $\uparrow$ ] key: 6.3  $\rightarrow$  10.0  $\rightarrow$  16.0  $\rightarrow$  25.0  $\rightarrow$  35.0  $\rightarrow$  50.0  $\rightarrow$  63.0  $\rightarrow$  100.0  $\rightarrow$  160.0  $\rightarrow$  200.0  $\rightarrow$  250.0  $\rightarrow$  350.0  $\rightarrow$  400.0  $\rightarrow$  450.0  $\rightarrow$  500.0  $\rightarrow$  550.0  $\rightarrow$  600.0  $\rightarrow$  630.0.

DOWN arrow [ $\downarrow$ ] key: 630.0  $\rightarrow$  600.0  $\rightarrow$  550.0  $\rightarrow$  500.0  $\rightarrow$  450.0  $\rightarrow$  400.0  $\rightarrow$  350.0  $\rightarrow$  250.0  $\rightarrow$  200.0  $\rightarrow$  160.0  $\rightarrow$  100.0  $\rightarrow$  63.0  $\rightarrow$  50.0  $\rightarrow$  35.0  $\rightarrow$  25.0  $\rightarrow$  16.0  $\rightarrow$  10.0  $\rightarrow$  6.3.


RIGHT arrow [ $\Rightarrow$ ] key: increase voltage in 1V increments.

LEFT arrow [ $\Leftarrow$ ] key: decrease voltage in 1V increments.



### 2.5.2 Constant Charge Current

The test current can be programmed from 0.5mA to 500mA. In MEAS DISPLAY press [F2] = C.C so that the **0.5** mA box is highlighted. Use the up arrow [ $\uparrow$ ] key to increase the current or use the down arrow [ $\downarrow$ ] key to decrease the current in 5/50mA increments. The left and right arrows will increase/decrease the current in 1mA increments. The instrument default setting is 0.5mA.



#### NOTE:

For the WV test, the range of C.C. is from 0.5mA to 150mA.

UP arrow [ $\uparrow$ ] key: increase current by 5mA from 0.5mA to 100mA then by 50mA from 100mA to 500mA

DOWN arrow [ $\downarrow$ ] key: decrease current by 50mA from 500mA to 100mA then by 5mA from 100mA to 0.5mA


RIGHT arrow [ $\Rightarrow$ ] key: increase current in 1mA increments.

LEFT arrow [ $\Leftarrow$ ] key: decrease current in 1mA increments.

### 2.5.3 Range

The 1855 instrument's measurement range can be selected as AUTO or HOLD. The instrument current measurement ranges are 20mA, 2mA, 200uA, 20uA and 2uA. In MEAS DISPLAY, press [F3] = RANGE so that the **A** box is highlighted\*. The instrument default setting is A (Auto Range).

\* Use the up arrow [ $\uparrow$ ] key to toggle between A (Auto) and H (Hold).




Press [F3] = RANGE a second time to select the value of the range.

UP arrow [ $\uparrow$ ] key: increase range: 2uA  $\rightarrow$  20uA  $\rightarrow$  200uA  $\rightarrow$  2mA  $\rightarrow$  20mA

DOWN arrow [ $\downarrow$ ] key: decrease range: 20mA  $\rightarrow$  2mA  $\rightarrow$  200uA  $\rightarrow$  20uA  $\rightarrow$  2uA

## 2.5.4 Charge Time

The charge time can be programmed from 0 to 999seconds. In MEAS DISPLAY press [F4] = NEXT PAGE 1/2. Press [F1] = CHG T so that the **0** s box is highlighted. Use the up or down arrow keys to in/decrease the charge time by base-10 second increments. The left and right arrows will increase/decrease the time in 1second increments. The instrument default setting is 0s.



UP arrow [ $\uparrow$ ] key: 0 → 10 → 20 → 30 → 40 → 50 → 60 → 70 → 80 → 90 → 100 → 200 → 300 → 400 → 500 → 600 → 700 → 800 → 900.


RIGHT arrow [ $\Rightarrow$ ] key: increase charge time in 1 second increments. (example: 900 to 999)

DOWN arrow [ $\downarrow$ ] key: 999 → 899 → 799 → 699 → 599 → 499 → 399 → 299 → 199 → 99 → 89 → 79 → 69 → 59 → 49 → 39 → 29 → 19 → 9.

LEFT arrow [ $\Leftarrow$ ] key: decrease charge time in 1 second increments. (example: 9 to 0)

## 2.5.5 Dwell Time

The dwell time can be programmed from 0.2 to 999seconds. In MEAS DISPLAY press [F4] = NEXT PAGE 1/2. Press [F2] = DWELL T so that the **0.2** s box is highlighted. Use the up or down arrow keys to in/decrease the dwell time by base-10 second increments. The left and right arrows will increase/decrease the time in 1second increments. The instrument default setting is 0s.



UP arrow [ $\uparrow$ ] key: 0.2 → 10 → 20 → 30 → 40 → 50 → 60 → 70 → 80 → 90 → 100 → 200 → 300 → 400 → 500 → 600 → 700 → 800 → 900.


RIGHT arrow [ $\Rightarrow$ ] key: increase dwell time in 1 second increments. (example: 900 to 999)

DOWN arrow [ $\downarrow$ ] key: 999  $\rightarrow$  899  $\rightarrow$  799  $\rightarrow$  699  $\rightarrow$  599  $\rightarrow$  499  $\rightarrow$  399  $\rightarrow$  299  $\rightarrow$  199  $\rightarrow$  99  $\rightarrow$  89  $\rightarrow$  79  $\rightarrow$  69  $\rightarrow$  59  $\rightarrow$  49  $\rightarrow$  39  $\rightarrow$  29  $\rightarrow$  19  $\rightarrow$  9.

LEFT arrow [ $\leftarrow$ ] key: decrease dwell time in 1 second increments. (example: 9 to 0)


## 2.5.6 Speed

Program the measurement speed of the 1855 instrument to Slow (7measurements/second), Medium (14 measurements/second) or Fast (18 measurements/second). In MEAS DISPLAY, press [F4] = NEXT PAGE 1/2 and then press [F3] = SPEED so that the **MEDIUM** box is highlighted. Press [F3] = SPEED to toggle through and select the measurement rate: SLOW, MEDIUM or FAST. The instrument default setting is MEDIUM (14 meas/second).




## 2.5.7 Trigger

In the **Step Test only**, the 1855 instrument can be triggered manually, internally or externally. In MEAS DISPLAY, press [F4] = NEXT PAGE 1/2 and then press [F1] = TRIGGER so that the **INT** box is highlighted. Press [F1] = TRIGGER to change the trigger. The instrument default setting is INT (internal trigger). When MANUAL trigger is selected, one measurement will be made each time the trigger is pressed. When EXTERNAL trigger is selected, one measurement will be made each time the external trigger is asserted by the handler. When INTERNAL trigger is selected, measurements are performed continuously when in [MEAS DISPLAY].



## 2.5.8 Rated Withstand Voltage (Vf)

In the **W.V. Test only**, the rated withstand voltage (Vf) can be programmed from 1.00V to 650V. In MEAS DISPLAY press [F1] = Vf so that the **1.00** V box is highlighted. Use the up arrow or down arrow keys to in/decrease the voltage in multi-V increments. The left and right arrows will increase/decrease the voltage in 1V increments. The instrument default setting is 1.00V.



UP arrow [ $\uparrow$ ] key: 6.3  $\rightarrow$  10.0  $\rightarrow$  16.0  $\rightarrow$  25.0  $\rightarrow$  35.0  $\rightarrow$  50.0  $\rightarrow$  63.0  $\rightarrow$  100.0  $\rightarrow$  160.0  $\rightarrow$  200.0  $\rightarrow$  250.0  $\rightarrow$  350.0  $\rightarrow$  400.0  $\rightarrow$  450.0  $\rightarrow$  500.0  $\rightarrow$  550.0  $\rightarrow$  600.0  $\rightarrow$  630.0.


DOWN arrow [ $\downarrow$ ] key: 630.0  $\rightarrow$  600.0  $\rightarrow$  550.0  $\rightarrow$  500.0  $\rightarrow$  450.0  $\rightarrow$  400.0  $\rightarrow$  350.0  $\rightarrow$  250.0  $\rightarrow$  200.0  $\rightarrow$  160.0  $\rightarrow$  100.0  $\rightarrow$  63.0  $\rightarrow$  50.0  $\rightarrow$  35.0  $\rightarrow$  25.0  $\rightarrow$  16.0  $\rightarrow$  10.0  $\rightarrow$  6.3.

RIGHT arrow [ $\Rightarrow$ ] key: increase voltage in 1V increments.

LEFT arrow [ $\Leftarrow$ ] key: decrease voltage in 1V increments.

## 2.5.9 Measurement Time (Tend)

In the **W.V. Test only**, the measurement time can be programmed from 30 to 600seconds. In MEAS DISPLAY press [F3] = Tend so that the **30** s box is highlighted. Use the up or down arrow keys to in/decrease the measure time by 10 second increments. The left and right arrows will increase/decrease the time in 1second increments. The instrument default setting is 30s.



UP arrow [ $\uparrow$ ] key: 30  $\rightarrow$  40  $\rightarrow$  50  $\rightarrow$  60  $\rightarrow$  70  $\rightarrow$  80  $\rightarrow$  90  $\rightarrow$  100  $\rightarrow$  200  $\rightarrow$  300  $\rightarrow$  400  $\rightarrow$  500  $\rightarrow$  600.


RIGHT arrow [ $\Rightarrow$ ] key: increase measurement time in 1 second increments.

DOWN arrow [ $\downarrow$ ] key: 600  $\rightarrow$  500  $\rightarrow$  400  $\rightarrow$  300  $\rightarrow$  200  $\rightarrow$  100  $\rightarrow$  90  $\rightarrow$  80  $\rightarrow$  70  $\rightarrow$  60  $\rightarrow$  50  $\rightarrow$  40  $\rightarrow$  30.

LEFT arrow [ $\Leftarrow$ ] key: decrease measurement time in 1 second increments.

## 2.5.10 Maximum Charge Time (CHG Tend)

In the **W.V. Test only**, the charge time can be programmed from 5 to 600seconds. In MEAS DISPLAY press [F4] = CHG Tend so that the **5** s box is highlighted. Use the up or down arrow keys to in/decrease the charge time by 10 second increments. The left and right arrows will increase/decrease the time in 5 second increments. The instrument default setting is 5s.



UP arrow [ $\uparrow$ ] key: 5 → 15 → 25 → 35 → 45 → 55 → 65 → 75 → 85 → 95 → 105 → 205 → 305 → 405 → 505.

RIGHT arrow [ $\Rightarrow$ ] key: increase charge time in 1 second increments. (example: 505 to 600)

DOWN arrow [ $\downarrow$ ] key: 600 → 500 → 400 → 300 → 200 → 100 → 90 → 80 → 70 → 60 → 50 → 40 → 30 → 20 → 10.

LEFT arrow [ $\Leftarrow$ ] key: decrease charge time in 1 second increments. (example: 10 to 5)

## 2.6 Connection to Device under Test

Figure 2-13 illustrates the connection of the 1855 instrument to a DUT using the 1855-01 Lead Set. For Leakage Current, Insulation Resistance and Withstand Voltage Tests, the red alligator clip/BNC cable is connected between the silver INPUT terminal on the 1855 unit and the high side of the device under test. The black alligator clip/banana cable is connected between the white HV (-) terminal on the 1855 unit and the low side of the DUT.




Figure 2-13: Connection for Leakage Current Test

## 2.7 Measurement Procedure

Before a measurement is made verify the following:

1. 1855 instrument [POWER] ON.
2. 15-minute warm-up.
3. Test parameters programmed and shown on MEAS DISPLAY.
4. Test cables or fixture connected.
5. NULL function initiated.
6. Device under test connected.

**To initiate a test:**

- Press [TRIGGER].
- The test voltage is shut **off** when all test steps are completed,
- **OR** when a test result is judged a FAIL per programmed test limits.
- The test result is displayed on MEAS DISPLAY

**NOTE:**

If for any reason the output must be terminated during a test, press the right arrow marked “DISCHARGE”.

The 1855 instrument judges the measurement value based on the COMPARE function set up previously. Refer to paragraph 2.4.5 for instructions on setting the COMPARE Pass/Fail judgment parameter. Upon completion of the test the output voltage is terminated and the display shows the test result.

**CAUTION:**

Before touching the DUT or the 1855 instrument, make sure all capacitive devices have been fully discharged.



## Section 3: Interface

### 3.1 RS-232 Interface

#### 3.1.1 RS-232 Pin Configuration

The 1855 instrument comes standard with an RS232 Interface for remote operation. Connection is through the black/silver 9-pin connector labeled 'RS232' on the rear panel of the 1855 instrument. Figure 3-1 illustrates the designation of the pins on the RS232 connector. The connection cable must be a 'straight through' cable for the 1855 unit to communicate.




Figure 3-1: RS-232 Interface Pin Configuration

#### 3.1.2 RS232 Specifications

Data Bits:	8
Stop Bits:	1
Parity:	None
Baud Rate:	600, 1200, 4800, 9600, 19200 or 28800bps, Software selectable
EOS:	CR + LF
Echo:	Off

Refer to paragraph 2.3.3.10. Setting the Baud Rate is done in the SYSTEM CONFIGURATION function under SYSTEM SETUP settings:

- From the MEAS DISPLAY, press [SYSTEM SETUP]
- Press [F3] = SYSTEM CONFIG.
- Press  $\downarrow$  = until the box next to BAUD RATE is highlighted.
- Press [F1] = INCREASE or [F2] = DECREASE to select baud rate.
- Press [F4] to EXIT

### 3.1.3 RS232 Commands

The command set for the RS232 interface is the same as the IEEE-488 interface command set listed in paragraphs 3.2.3 through 3.2.5 of this instruction manual.

**NOTE**


CR + LF is the necessary end code for the RS232 commands.

## 3.2 IEEE-488 Interface

### 3.2.1 Pin Configuration

The 1855 instrument has an optional IEEE-488 interface as illustrated in Figure 3-2. Connection is through the blue 24-pin connector labeled 'IEEE-488 INTERFACE' on the rear panel of the 1855 instrument. This interface can be used to connect a system containing a number of instruments and a controller in which each meets IEEE Standard 488.2 (Standard Digital Interface for Programmable Instrumentation).

1855 IEEE-488 Interface PIN Configuration: Rear Panel View



1855 IEEE-488 Interface PIN Designation




Figure 3-2: IEEE-488 Interface Pin Configuration

Table 3-1 lists the IEEE-488 Interface pin designations by pin number, signal name and pin function. Bus and driver information is also listed.

**Table 3-1: IEEE-488 Interface Pin Designations**

Bus	Driver	Signal Name	Pin Number	Function
Handshake	3 States	DAV	6	Low State: “Data is Available” and valid on DI01 through DI08
	Open Collector	NRFD	7	Low State: At least one Listener on the bus is “Not Ready For Data”
	Open Collector	NDAC	8	Low State: At least one Listener on the bus is “Not Accepting Data”
Control	3 States	ATN	11	“Attention” specifies 1 of 2 uses for the DI01 through DI08 lines: Low State: Controller command messages High State: Data bytes from the Talker device
	3 States	IFC	9	“Interface Clear” Low State: Returns portion of interface system to a known quiescent state
	Open Collector	SRQ	10	“Service Request” Low State: A Talker or Listener signals (to the controller) need for attention in the midst of the current sequence of events.
	3 States	REN	17	“Remote Enable” Low State: Enables each device to enter remote mode when addressed to listen. High State: All devices revert to Local control.
	3 States	EOI	5	“End of Identify” If ATN is in HIGH state, then EOI LOW state indicates the end of a multiple-byte data transfer sequence. If ATN is in LOW state, then EOI LOW state indicates a parallel poll.
Data	Open Collector	DI01	1	The 8-Line Data Bus.  If ATN is in LOW state, then the bus conveys interface messages. If ATN is in HIGH state, then the bus conveys device-dependent messages. (Example: carries remote control commands from the controller or from a talker device)
		DI02	2	
		DI03	3	
		DI04	4	
		DI05	13	
		DI06	14	
		DI07	15	
		DI08	16	

### 3.2.2 IEEE-488 Interface Function Codes and Messages

The IEEE-488 (GPIB) address is defined under the SYSTEM SETUP in the SYSTEM CONFIG menu. Press [SYSTEM SETUP], then the numerical key [F3] to enter the SYSTEM CONFIG menu. Press down arrow [ $\downarrow$ ] to enter the GPIB ADDRESS code. To select a new IEEE-488 address, use the function keys. Refer to paragraph 2.3.2 for more information. The default setting for the IEEE address is 17.

Table 3-2 defines the IEEE-488 interface codes and their function. Table 3-3 defines the IEEE-488 interface messages the 1855 instrument responds to and their function.

**Table 3-2: IEEE-488 Interface Functions**

<b>Code</b>	<b>Function</b>
SH1	Source Handshake (Talker)
AH1	Acceptor Handshake (Listener)
T6	Basic Talker Function
	Serial Poll Function
	Listener-specified Talker Release Function
	No TALK-ONLY Function
L4	Basic Listener Function
	Talker-specified Listener Release Function
SR1	Service Request Function
RL1	All Remote/Local Functions
PP0	No Parallel Poll Function
DC1	Device Clear Function
DT1	Device Trigger Function
C0	No Controller Functions

**Table 3-3: IEEE-488 Interface Messages**

<b>Interface Message</b>	<b>Function</b>	<b>Description</b>
GTL	Go To Local	Only addressed devices that receive this command are set to local mode. Cancels the remote control mode, making the front panel switches operative.


Table 3-4 lists the IEEE-488 interface commands the 1855 instrument accepts to set or query a parameter value. Paragraphs 3.2.3 through 3.2.5 detail the function, format, return value and description of the IEEE-488 commands.

**Table 3-4: IEEE-488 Commands**

<b>Command</b>	<b>Name</b>	<b>Function</b>	<b>Output Format</b>
*CLS	Clear Status	Clear standard event status register. Clear status bit group register except for bit 4 (MAV)	
*ESE	Event Status Enable	Enable standard event status register value.	0 – 255
*ESE?	Event Status Enable	Query standard event status of device enable register	0 – 255
*ESR?	Event Status Register	Query standard event register value of device. After this command, the standard register is cleared to 0.	0 – 255
*IDN?	Identification	Query/Read basic device data. (A comma separates the identification fields.)	4 ID: Manufacturer, Device Model, Serial Number, Firmware Version
*OPC	Operation Complete	Operation is complete.	0
*OPC?	Operation Complete	Query operation complete.	1
*RST	Reset	Reset Device.	
*SRE	Service Request Enable	Enable service request register value.	0 – 255
*SRE?	Service Request Enable	Query/Read service request register value.	0 – 255
*TRG	Trigger Bus	Trigger the 1730 instrument	
*TST?	Self Test	Perform self test & report error	0 = no error 1 = RAM 2 = EEPROM 4 = CPLD 8 = Calibration Data
*LRN?	Null	Perform Null	
*SAV	Save	Save current status to memory.	1 – 50
*RCL	Recall	Recall saved status from memory.	1 – 50


### 3.2.3 IEEE-488 Commands

Figure 3-3 illustrates the programming commands accepted by the IEEE-488 interface of the 1855 instrument. The commands are written in tabular format as a single reference to view all the commands. The command format and examples are detailed in paragraphs 3.2.4 – 3.2.5.



**Figure 3-3a: IEEE-488 Commands**

### Tabular Format IEEE-488 Commands – continued



**Figure 3-3b: IEEE-488 Commands**

### 3.2.4 IEEE-488 Command Format

The IEEE-488 commands are configured in Root format. There are six levels of the instruction from top to bottom. Follow the specific path (as illustrated in Figure 3.3) to configure a specific command. The colon at the beginning of each line denotes that all line signals are root. Use a colon (:) to separate levels. Use the semicolon (;) to separate two commands on the same line.

For example, to format the command for the LC function, use this path:

```
:CALCulate:LIMIT:FORMAT:LC
```

If the command is a setting, then put the parameter after the instruction. If the command is an inquiry, then put a question mark (?) after the instruction.

For example, to set the beeper to sound on Fail:

```
:CALCulate:LIMIT:BEEPer:CONDition:FAIL
```

To inquire what the beeper is set to:

```
:CALCulate:LIMIT:BEEPer:CONDition?
```


The Ending Code can be any type in Table 3-5.

**Table 3-5: IEEE-488 Interface Ending Codes**

Ending Code
[CR] (0Dh)
[LF] (0Ah)
[CR] (0Dh) + [LF] (0Ah)

### 3.2.5 IEEE-488 Commands - Detailed

The IEEE commands listed in Figure 3-3 are detailed in paragraphs 3.2.5.1 – 3.2.5.39 including command, parameter, return value, function, and description. **Note:** Numerical data is transferred via one of three methods: integer format, fixed decimal format or floating point decimal format. Refer to Figure 3-4.



**Figure 3-4: Numerical Data Transfer**

#### 3.2.5.1 ABOR

Instruction: ABOR  
 Parameter: None  
 Return Value: None  
 Function: Terminate Trigger in process and initiates Discharge.

#### 3.2.5.2 CALC:LIM:FORM

Instruction: CALC:LIM:FORM  
 Parameter: {IR | LC}  
 Return Value: {IR | LC}  
 Function: Set or Query the measurement parameter for the Compare function.  
 Description: IR Insulation Resistance  
                   LC Leakage Current

#### 3.2.5.3 CALC:LIM:BEEP:COND

Instruction: CALC:LIM:BEEP:COND  
 Parameter: {FAIL | PASS}  
 Return Value: {FAIL | PASS}  
 Function: Set or Query the condition on which the beeper sounds.  
 Description: FAIL Beeper sounds on FAIL result  
                   PASS Beeper sounds on PASS result

### 3.2.5.4 CALC:LIM:BEEP:STAT

Instruction: CALC:LIM:BEEP:STAT  
Parameter: {OFF | ON | 0 | 1}  
Return Value: {0 | 1}  
Function: Set or query the status of the beeper.  
Description: OFF (0) Beeper sound is set to OFF  
ON (1) Beeper sound is set to ON

### 3.2.5.5 CALC:LIM:FAIL?

Instruction: CALC:LIM:FAIL?  
Parameter: {0 (FAIL) | 1 (PASS)}  
Return Value: {0 | 1}  
Function: Query the result of the Compare function.  
Description: 0 FAIL result  
1 PASSL result

### 3.2.5.6 CALC:LIM:LOW[:DATA]

Instruction: CALC:LIM:LOW[:DATA]  
Parameter: {The lower limit value | MAX | MIN}  
Return Value: The lower limit value, the format is <NR3> (Floating point)  
Function: Set or query the lower limit value.  
Description: MINimum 000.000kΩ  
MAXimum 9.999E14

### 3.2.5.7 CALC:LIM:STAT

Instruction: CALC:LIM:STAT  
Parameter: {OFF | ON | 0 | 1}  
Return Value: {0 | 1}  
Function: Set or query the state of the Compare Function.  
Description: 0 Compare Function is OFF  
1 Compare Function is ON

### 3.2.5.8 CALC:LIM:UPP[:DATA]

Instruction: CALC:LIM:UPP[:DATA]  
Parameter: {The upper limit value | MAX | MIN}  
Return Value: The upper limit value, the format is <NR3> (Floating point)  
Function: Set or query the upper limit value.  
Description: MINimum 000.001kΩ  
MAXimum 9.999E14

### 3.2.5.9 CALC:LIM:ONOF

Instruction: CALC:LIM:ONOF  
Parameter: {0 | 1 | 2 | 3}  
Return Value: {0 | 1 | 23 | 3}  
Function: Set or query the status of the Compare function.  
Description: 0 Compare function is OFF  
1 Compare Upper Limit is ON  
2 Compare Lower Limit is ON  
3 Compare Upper and Lower Limits are ON

### 3.2.5.10 CALC:NULL:[IMM]

Instruction: CALC:NULL:[IMM]  
Parameter: None  
Return Value: None  
Function: Initiate NULL.  
Description: No data. Instrument performs Null function

### 3.2.5.11 CALC:NULL:DATA?

Instruction: CALC:NULL:DATA?  
Parameter: None  
Return Value: The Null value in <NR3> format (-20.0E6 to 20.0E6)  
Function: Query the Null leakage current reading for each current range.  
Description: \_\_\_\_\_ Null value of 20mA range  
\_\_\_\_\_ Null value of 2mA range  
\_\_\_\_\_ Null value of 200uA range  
\_\_\_\_\_ Null value of 20uA range  
\_\_\_\_\_ Null value of 2uA range

### 3.2.5.12 DISP:STAT?

Instruction: DISP:STAT?  
Parameter: {ON (1) | OFF (0)}  
Return Value: {LCTEST | WVTEST | NULL | MAIN | SYSTEM}  
Function: Query the status of the LCD display.  
Description: LCTEST Display is in LCTEST mode  
WVTEST Display is in WVTEST mode  
NULL Display is in NULL mode  
MAIN Display is in MAIN mode  
SYSTEM Display is in SYSTEM mode

### 3.2.5.13 DISP: | WVT, L CT, null, main, system |

Instruction: DISP: WVT  
DISP: LCT  
DISP: NULL  
DISP: MAIN  
DISP: SYSTem  
Parameter: None  
Return Value: None  
Function: Set the Display to WV Mode, L CT mode, null, main or system mode.  
Description: Set the Display to WV Mode

### 3.2.5.14 LCT:SOUR:VOLT

Instruction: LCT:SOUR:VOLT  
Parameter: {Test Voltage | MIN | MAX}  
Unit: Volts  
Return Value: {Test Voltage} in {NR3} format  
Function: Set or query the test voltage for the LC Test.  
{Voltage} 1.0 -650V  
MIN 1.0V  
MAX 650V

### 3.2.5.15 LCT:SOUR:CURR

Instruction: LCT:SOUR:CURR  
Parameter: {Test Current | MIN | MAX}  
Unit: Milliamps  
Return Value: {Test Current} in {NR3} format  
Function: Set or query the test current for the LC Test.  
{current} 0.5mA – 500mA  
MIN 0.5mA  
MAX 500mA (150mA for V>100V)

### 3.2.5.16 LCT:CONF:FUNC

Instruction: LCT:CONF:FUNC  
Parameter: {SEQ | STEP}  
Return Value: {SEQ | STEP}  
Function: Set or query the configuration of the LC Test.  
Description: SEQ LC Test is a Sequence Test  
STEP LC Test is a Single Manual Test

### 3.2.5.17 LCT:CONF:SPE

Instruction: LCT:CONF:SPE  
Parameter: {FAST | MEDIUM | SLOW}  
Return Value: {FAST | MEDIUM | SLOW}  
Function: Set or query the Measurement Speed.  
Description: FAST 18 measurements/second  
MEDIUM 14 measurements/second  
SLOW 7 measurements/second

### 3.2.5.18 LCT:CONF:RANG

Instruction: LCT:CONF:RANG  
Parameter: {<range> | MIN | MAX}  
Return Value: {<range>}  
Function: Set or query the measurement range for the LC Test.  
Description: 4 20mA  
3 2mA  
2 200uA  
1 20uA  
0 2uA  
MIN 2uA  
MAX 20mA

### 3.2.5.19 LCT:CONF:RANG:AUTO

Instruction: LCT:CONF:RANG:AUTO  
Parameter: {OFF | ON | 0 | 1}  
Return Value: {0 | 1}  
Function: Set or query if the Auto Range function is OFF or ON.  
Description: 0 Auto Range is OFF  
1 Auto Range is ON

### 3.2.5.20 LCT:CONF:CHGT

Instruction: LCT:CONF:CHGT  
Parameter: {<numeric value> | MIN | MAX}  
Return Value: {<numeric value>}  
Function: Set or query the charge time for the LC Test.  
Description: <numeric value> 0 – 999seconds  
MIN 0seconds  
MAX 999seconds

### 3.2.5.21 LCT:CONF:DWEL

Instruction: LCT:CONF:DWEL  
Parameter: {<numeric value> | MIN | MAX}  
Return Value: {<numeric value>}  
Function: Set or query the dwell time for the LC Test.  
Description: <numeric value> 0.2 – 999seconds  
MIN 0.2seconds  
MAX 999seconds

### 3.2.5.22 LCT:MEAS:STAT?

Instruction: LCT:MEAS:STAT?  
Parameter: None  
Return Value: {CHG | TEST | DCHG}  
Function: Query the test status of the LC Test.  
Description: CHG Instrument is in Charge mode  
TEST Instrument is in Test mode  
DCHG Instrument is in Discharge mode

### 3.2.5.23 LCT:MEAS:FETC?

Instruction: LCT:MEAS:FETC?  
Parameter: None  
Return Value: {0 | 1}, {ON | PASS | HIGH | LOW}  
Function: Query the test result of the LC Test.  
Description: 0 Okay  
1 Error  
ON Instrument in Test mode  
PASS Test Passed  
HIGH Test Failed – result above High Limit  
LOW Test Failed – result below Low Limit

### 3.2.5.24 LCT:MEAS:IR?

Instruction: LCT:MEAS:IR?  
Parameter: None  
Return Value: {Measured value} in <NR3> format  
Function: Query the IR measurement value.  
Description: IR measurement value

### 3.2.5.25 LCT:MEAS:LC?

Instruction: LCT:MEAS:LC?  
Parameter: None  
Return Value: {Measured value} in <NR3> format  
Function: Query the LC measurement value.  
Description: LC measurement value

### 3.2.5.26 LCT:MEAS:VMON?

Instruction: LCT:MEAS:VMON?  
Parameter: None  
Return Value: {Measured value} in <NR3> format  
Function: Query the value of the monitored voltage (voltage across DUT).  
Description: VMON value

### 3.2.5.27 WVT:SOUR:VOLT

Instruction: WVT:SOUR:VOLT  
Parameter: {<numeric value> | MIN | MAX}  
Unit: Volts  
Return Value: {Test Voltage} in <NR3> format  
Function: Set or query the test voltage for the Withstand Voltage Test.  
Description: <numeric value> 1.0 – 650volts  
MIN 1.0volt  
MAX 650volts

### 3.2.5.28 WVT:SOUR:CURR

Instruction: WVT:SOUR:CURR  
Parameter: {<numeric value> | MIN | MAX}  
Unit: Milliamps  
Return Value: {Test Current} in <NR3> format  
Function: Set or query the test current for the Withstand Voltage Test.  
Description: <numeric value> 0.5 – 150mA  
MIN 0.5mA  
MAX 150mA

### 3.2.5.29 WVT:CONF:TEND

Instruction: WVT:CONF:TEND  
Parameter: {<numeric value> | MIN | MAX}  
Unit: seconds  
Return Value: {Measurement Time} in <NR3> format  
Function: Set or query the measurement time for the WV Test.  
Description: <numeric value> 30 – 600seconds  
MIN 30seconds  
MAX 600seconds

### 3.2.5.30 WVT:CONF:CHGTEND

Instruction: WVT:CONF:CHGTEND  
Parameter: {<numeric value> | MIN | MAX}  
Unit: seconds  
Return Value: {Maximum Charge Time} in <NR3> format  
Function: Set or query the maximum charge time for the WV Test.  
Description: <numeric value> 5 – 600seconds  
MIN 5seconds  
MAX 600seconds

### 3.2.5.31 WVT:MEAS:STAT?

Instruction: WVT:MEAS:STAT?  
Parameter: None  
Return Value: {CHG | TEST | DCHG}  
Function: Query the test status of the WV Test.  
Description: CHG Instrument is in Charge mode  
TEST Instrument is in Test mode  
DCHG Instrument is in Discharge mode

### 3.2.5.32 WVT:MEAS:VT?

Instruction: WVT:MEAS:VT?  
Parameter: None  
Return Value: {Test Voltage} in <NR3> format  
Function: Query the Test Voltage at the Termination of the WV Test.  
Description: <numeric value> 1.0 – 650volts

### 3.2.5.33 WVT:MEAS:TE?

Instruction: WVT:MEAS:TE?  
Parameter: None  
Return Value: {Measurement Time} in <NR3> format  
Function: Query the total Measurement Time of the WV Test (Tr + Test Time).  
Description: <numeric value> 30 – 600seconds

### 3.2.5.34 TRIG[:IMM]

Instruction: TRIG[:IMM]  
Parameter: None  
Return Value: None  
Function: Initiate the Trigger function.

### 3.2.5.35 TRIG:SOUR

Instruction: TRIG:SOUR  
Parameter: {BUS | EXT | INT | MAN}  
Return Value: {BUS | EXT | INT | MAN}  
Function: Set or query the trigger mode.  
Description: BUS Bus trigger  
EXTernal External trigger  
INTernal Internal trigger  
MANual Manual trigger

### 3.2.5.36 TRIG:DEL

Instruction: TRIG:DEL  
Parameter: {<numeric value> | MIN | MAX}  
Unit: milliseconds  
Return Value: {Trigger Delay Time} in <NR3> format  
Function: Set or query the trigger delay time.  
Description: <numeric value> 0 – 9999milliseconds  
MIN 0milliseconds  
MAX 9999milliseconds

### 3.2.5.37 TRIG:EDGE

Instruction: TRIG:EDGE  
Parameter: {FALL | RISI}  
Return Value: {FALL | RISI}  
Function: Set or query the edge on which to initiate the trigger.  
Description: FALL Measurement is triggered on falling edge  
RISI Measurement is triggered on rising edge

### 3.2.5.38 SYST:BEEP[:IMM]

Instruction: SYST:BEEP[:IMM]  
Parameter: None  
Return Value: None  
Function: Set the beeper to sound immediately.

### 3.2.5.39 SYST:BEEP:STAT

Instruction: SYST:BEEP:STAT  
Parameter: {OFF (0) | ON, LOW (1) | ON, HIGH (2)}  
Return Value: {0 | 1 | 2}  
Function: Set the loudness of the beeper.  
Description: 0 Turn Beeper OFF  
1 Set Beeper sound to LOW  
2 Set Beeper sound to HIGH

### 3.2.5.40 SYST:ALAR

Instruction: SYST:ALAR  
Parameter: {PULS | CONT}  
Return Value: {PULS | CONT}  
Function: Set the mode the alarm will sound in.  
Description: PULS The alarm sound will pulse  
CONT The alarm will continuously sound

### 3.2.5.41 SYST:LFR

Instruction: SYST:LFR  
Parameter: {50 | 60}  
Unit: Hz  
Return Value: {50 | 60}  
Function: Set or query the Line Frequency.  
Description: 50Hz AC Power Line Source is 50Hz  
60Hz AC Power Line Source is 60Hz

### 3.2.5.42 SYST:HAND

Instruction: SYST:HAND  
Parameter: {CLEA | HOLD}  
Return Value: {CLEA | HOLD}  
Function: Set the Handler to clear result or hold result for each test  
Description: CLEA Handler will clear result after each test  
HOLD Handler will hold result after each test

### 3.2.5.43 SYST:CONT

Instruction: SYST:CONT  
Parameter: {<numeric value>}  
Return Value: {Contrast} in <NR1> format  
Function: Set or query the contrast of the display.  
Description: <numeric value> 1-16

### 3.2.5.44 SYST:RANGED

Instruction: SYST:RANGED  
Parameter: {<numeric value> | MIN | MAX}  
Return Value: {Dwell Time} in <NR3> format  
Function: Set or query the range dwell time.  
Description: <numeric value> 0 – 9.9seconds  
MIN 0seconds  
MAX 9.9seconds

### 3.2.5.45 SYST:AVER

Instruction: SYST:AVER  
Parameter: {<numeric value> | MIN | MAX}  
Return Value: {Average} in <NR1> format  
Function: Set or query the number of measurements made & averaged before result shown.  
Description: <numeric value> 1-8  
MIN 1  
MAX 8

### 3.2.5.46 SYST:PRES

Instruction: SYST:PRES  
Parameter: None  
Return Value: None  
Function: Set the instrument to initial default values.

### 3.2.5.47 SYST:ERR?

Instruction: SYST:ERR?  
Parameter: None  
Return Value: Error message  
Function: Query if there are any system errors.  
Description: <numeric value>, <string>

### 3.2.6 Error Messages

Table 3-6 lists the Error Messages for the IEEE-488 interface of the 1855 instrument. In response to the command “SYSTem:ERRor?”, the 1855 unit responds with the error message number and an error message string of up to 80 characters in length.


**Table 3-6: Error Messages**

Code	Type	Message
0	No error	There is no error in the error queue
-102	Syntax error	Invalid character exists in the command string.
-104	Data error	Parameter is not defined in the command string.
-106	Illegal parameter	Parameter is not a valid command.
-202	Conflicting Settings	Command conflicts with instrument settings. Example: Send ‘Trigger’ when mode is external.
-203	Data range	Data exceeds the valid range.
-211	Data stale	No resent measurement result. Example: Send ‘Read?’ when in Standby status.
-224	Self-Test failed	Self-test via remote interface (*TST) failed.
-225	Excess errors	The error queue is full (more than 20 errors). Queue cleared after power down or *CLS command.
-226	Query interrupted	Device status changed after query sent. Output buffer will be cleared

### 3.3 Handler Interface

There is an available Handler interface for the 1855 instrument as illustrated in Figure 3-4. [The IEEE-488 and HANDLER interfaces come together as an optional accessory]. Connection to the Handler interface is through the blue 24-pin connector labeled HANDLER on the rear panel of the 1855 instrument.

1855 HANDLER Interface PIN Configuration: Rear Panel View




1855 HANDLER Interface: PIN Designation

/EXT	1	<input type="checkbox"/>	13	N.C.
N.C.	2	<input type="checkbox"/>	14	N.C.
/TEST	3	<input type="checkbox"/>	15	/PASS
FAIL HI	4	<input type="checkbox"/>	16	/CHARGE
GND	5	<input type="checkbox"/>	17	/FAIL
GND	6	<input type="checkbox"/>	18	EOT
GND	7	<input type="checkbox"/>	19	/HI
COM	8	<input type="checkbox"/>	20	/TEST
N.C.	9	<input type="checkbox"/>	21	/LO
VEXT	10	<input type="checkbox"/>	22	ACQ
VINT	11	<input type="checkbox"/>	23	/FAIL_CHARGE
N.C.	12	<input type="checkbox"/>	24	N.C.

Figure 3-4: Handler Interface Pin Configuration

### 3.3.1 Trigger

Paragraph 2.3.16 contains the instructions for changing the Handler mode. Paragraphs 2.3.3 and 2.3.4 contain instructions for setting the Trigger Delay time and selecting the Trigger Edge. Figure 3-5 illustrates the Trigger function.



**Figure 3-5: Trigger**

### Output Signals

The output lines of the 1855 Handler interface are open collector drivers that pull each signal line to a low voltage, signal ground when the signal is active (true). Each external line should be pulled up (with a resistor) to a positive voltage between 5V and 24V. The pull-up resistor must limit the current to  $< 6mA$  for a signal of a comparison function and to  $< 5mA$  for a control signal (EOT).

### Input Signal

The input signal to the 1855 Handler interface is active low and requires a positive external voltage to pull the signal down below 0.4V, ground.

### 3.3.2 Handler Pin Assignments for Compare Operation

Table 3-7 lists the pin assignments when the handler interface on the 1855 instrument is performing a Compare operation. The device under test is being compared against a standard of known value. High and low limits can be defined as absolute value or percent value.

**Table 3-7: Handler Pin Assignments for Compare**

<b>Pin</b>	<b>Name</b>	<b>Description</b>
1	/EXT	External trigger
2	X	No connection
3, 20	/TEST	Instrument is in Test mode
4, 24	X	No connection
5 - 7	GND	Ground external DC
8	COM	Common Ground
9, 13	X	No connection
10	VEXT	External DC voltage: 5V ~ 24V
11	VINT	Internal DC voltage: +5V
12	X	No connection
14	X	No connection
15	/PASS	Measured Result is within the upper/lower limit(s) (PASS)
16	/CHARGE	Instrument is in Charge mode
17	/FAIL	Measured Result is outside the upper/lower limit(s) (FAIL)
18	/EOT	End of Test
19	/HI	For LC: Measured Result is > Upper Limit For IR: Measured Result is < Lower Limit
21	/LO	For LC: Measured Result is < Lower Limit For IR: Measured Result is > Upper Limit
22	ACQ	Received data, ready to accept next
23	EOT	End of Test
45 – 46	/FAIL, CHARGE	Instrument is in Discharge mode

**NOTE:**

When using External DC Voltage (VEXT), Pins 5, 6 & 7 (GND) must be connected to Pin 8 (COM).

---

## Section 4: Service & Calibration

---

### 4.1 General

The warranty (at the front of this manual) attests to the quality of materials and workmanship in QuadTech products. If malfunction should be suspected, or other information desired, applications engineers are available for technical assistance. Applications assistance is available in the U.S. by calling (978) 461-2100 and asking for Applications Support. For support outside of the United States please contact your local QuadTech Distributor.

### 4.2 Instrument Return

Before returning an instrument to QuadTech for service please call our **Customer Care Center (CCC)** at **800-253-1230** for Return Material Authorization (RMA). It will be necessary to include a Purchase Order Number to insure expedient processing, although units found to be in warranty will be repaired at no-charge. For any questions on repair costs or shipping instructions please contact our CCC Department at the afore-mentioned number. To safeguard an instrument during storage and shipping, please use packaging that is adequate to protect it from damage, i.e. equivalent to the original packaging, and mark the box "Delicate Electronic Instrument". Return material should be sent freight prepaid to:

QuadTech, Inc.  
5 Clock Tower Place, 210 East  
Maynard, Massachusetts 01754

Attention: RMA#

Shipments sent collect cannot be accepted.

### 4.3 Calibration

Calibration of the 1855 Capacitor Leakage Current/IR Meter is completed at the factory and includes a NIST calibration certificate. Verification of the instrument is recommended on an annual basis. Accurate operation of the 1855 instrument is confirmed using the 1855-TP Test Procedure.

### 4.3.1 1855 Verification Procedure

This section outlines the relevant information to verify performance of the 1855 Meter. It is recommended that performance be performed at least once a year using this outline procedure. Instrument should be warmed up for a minimum of 15 minutes prior to verification. Verification should be performed under the following conditions: Temperature equal to  $23^{\circ}\text{C} \pm 1.2^{\circ}\text{C}$  and Relative Humidity (RH) between 35% and 55%.

Recommended standards are listed below. All standards should be traceable to a National Laboratory (such as NIST) and have calibrated values for primary and secondary parameters at the required test frequencies. QuadTech's verification conforms to ANSI Z540 and QuadTech recommends that the calibrated values for the primary and secondary standards have an uncertainty 4 times better than the primary and secondary accuracy specified in the Verification Data Sheet. If the calibrated values for the standards used do not have an uncertainty of 4 times better than the specified accuracy of the 1855 the uncertainty of the standard should be added to the specified accuracy of the 1855.

### 4.3.2 1855 Verification Data Sheet

#### Out Voltage: @ 10mA

(Verify Display & Measured Values are within high and low limits)

(Note: MEASURE between RED (+) and WHITE (-) mounting jacks)

Voltage Setting (V)	Measured Voltage (Fluke)	Displayed Voltage (1855)	Low Limit Voltage	High Limit Voltage
1			795mV	1.205V
50			49.55V	50.45V
200			198.8V	201.2V
400			397.8V	402.2V
600			596.8V	603.2V

#### IR Measurement: @ .5mA

(Note: MEASURE between BNC jack and WHITE (-) mounting jacks)

Voltage Setting (V)	Nominal Resistance ( $\Omega$ )	Actual Resistance ( $\Omega$ )	Before	After	Test Specifications
			Displayed Value ( $\Omega$ )	Displayed Value ( $\Omega$ )	
100V	10M				0.805%
100V	100M				0.854%
200V	1G				0.973%
500V	1G				0.747%