Copy Operating Instructions Printer Reference **Scanner**

For safe and correct use of this machine, please be sure to read the Safety Information in this manual before you use it.

About the Operating Instructions

Your machine comes with the two References:

Copy/Printer/Scanner Reference provides information you need for setting up your machine and installing the supplied software. It also provides all of the detailed instructions for using your machine as a printer, a scanner and a copier and information for maintaining and troubleshooting the machine.

Facsimile Reference provides information for using your machine as a fax machine. You can find how to send and receive a fax, and how to set fax-related options.

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, incidental or consequential damages as a result of handling or operating the machine.

Copyright © 2004.

- Centronics is a trademark of Centronics Data Computer Corporation.
- IBM and IBM PC are trademark of International Business Machines Corporation.
- TrueType is a trademark of Apple Computer, Inc.
- Microsoft, Windows, Windows 9x, Window Me, Windows 2000, Windows NT 4.0 and Windows XP are registered trademarks of Microsoft Corporation.
- All other brand or product names are trademarks of their respective companies or organisations.

Safety Information

When using this machine, the following safety precautions should always be followed.

Safety During Operation

In this manual, the following important symbols are used:



MARNING:

Indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

! CAUTION:

Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

MARNING:

- Connect the power cord directly into a wall outlet and never use an extension cord.
- Disconnect the power plug (by pulling the plug, not the cable) if the power cable or plug becomes frayed or otherwise damaged.
- To avoid hazardous electric shock or laser radiation exposure, do not remove any covers or screws other than those specified in this manual.
- Turn off the power and disconnect the power plug (by pulling the plug, not the cable) if any of the following occurs:
 - You spill something into the machine.
 - You suspect that your machine needs service or repair.
 - The external housing of your machine has been damaged.
- Do not incinerate spilled toner or used toner. Toner dust might ignite when exposed to an open flame.
- Disposal can take place at our authorized dealer.
- Dispose of the used toner bottle in accordance with the local regulations.

A CAUTION:

- Protect the machine from dampness or wet weather, such as rain and snow.
- Unplug the power cord from the wall outlet before you move the machine. While moving the machine, you should take care that the power cord will not be damaged under the machine.
- When you disconnect the power plug from the wall outlet, always pull the plug (not the cable).
- Do not allow paper clips, staples, or other small metallic objects to fall inside the machine.
- Keep toner (used or unused) and toner bottle out of the reach of children.
- Be careful not to cut yourself on any sharp edges when you reach inside the product to remove misfed sheets of paper or masters.
- For environmental reasons, do not dispose of the machine or expended supply waste at household waste collection points. Disposal can take place at an authorized dealer.
- The inside of the machine could be very hot. Do not touch the parts with a label indicating the "hot surface". Otherwise, an injury might occur.

Power Supply

The socket-outlet shall be in stalled near the product and shall be easily accessible.

Ozone Safety (if applicable)

Some product (see specification in the Operating Instructions) generates ozone during operation.

Normally, the ozone level is safe for operators. If ozone odor may appear, ventilate the room.

For Fax or Telephone

Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool. Avoid using a telephone during an electrical storm. There may be a remote risk of electric shock from lightning. Do not use a telephone in the vicinity of a gas leak to report the leak.

Laser Safety:

This product (see specification in the Operating Instructions) is considered a class 1 laser device. Safety precautions and interlock mechanisms have been designed to prevent any possible laser beam exposure to the operator. The following label is attached to the back of European and Asian specification machines only.



For North America

CDRH Regulations

This equipment complies with requirements of 21 CFR subchapter J for class 1 laser products. This equipment contains a 5 milliwatt, 760–800 nanometer wavelength, AlGaAs laser diode. This equipment does not emit hazardous radiation, since the beam is totally enclosed during all customer modes of operation and maintenance.

Caution:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.



Declaration of Conformity

Notice to Users in EEA Countries

This product complies with the essential requirements and provisions of Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

Notice to Users Accessing Analog PSTN in EEA Countries


This product is designed to be able to access analog PSTN in all EEA countries. Local PSTN compatibility is dependent on software switch settings. Please contact your service representative if relocating this product to another country. In the event of problems, please contact your service representative in the first instance.

DSm516pf/AC016/Aficio FX16: The CE declaration of Comformity is available on the Internet at URL: http://www.ricoh.co.jp/fax/ce_doc

IS 2016: The CE declaration of Comformity is available on the Internet at URL: http://jboard.danka.de/jboard/produkte/index.htmlo

Positions of Labels and Hallmarks for N WARNING and N CAUTION Labels

This machine has labels for \triangle WARNING and \triangle CAUTION at the positions shown below. For safety, please follow the instructions and handle the machine as indicated.



In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- means POWER ON.
- means POWER OFF.

NOTICE

Note to users in the United States of America

Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio /TV technician for help.

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice about the Telephone Consumer Protection Act (Valid in USA only).

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including FAX machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided may not be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

In order to program this information into your FAX machine, you should complete the following steps: Follow the FAX HEADER programming procedure in the Programming chapter of the operating instructions to enter the business identification and telephone number of the terminal or business. This information is transmitted with your document by the FAX HEADER feature. In addition to the information, be sure to program the date and time into your machine.

♦ FCC Requirements

- 1. This equipment complies with Part 68 of the FCC rules and requirements adopted by the ACTA. On the cover of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXXX. If requested, this number must be provided to the telephone company.
- 2. This equipment uses the RJ11C USOC jack.
- 3. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for detail.
- 4. The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. The REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3).
- 5. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
- 6. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- 7. If trouble is experienced with this equipment, for repair or warranty information, please contact RICOH CORP. CUSTOMER SUPPORT DEPT. at 1-800-FASTFIX. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.
- 8. In the event of operation problems (document jam, copy jam, communication error indication), refer to the solving problems section in this manual.
- 9. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

♦ WHEN PROGRAMMING EMERGENCY NUMBERS AND/OR MAKING TEST CALLS TO EMERGENCY NUMBERS:

- 1. Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
- 2. Perform such activities in the off-peak hours, such as early morning hours or late evenings.

CANADA

The Ringer Equivalence Number is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

This product meets the applicable Industry Canada technical specifications.

Note:

This Class B digital apparatus complies with Canadian ICES-003.

Differences Between British and American English

British English	American English
(Re)dialling	(Re)dialing
Colour	Color
Emphasise	Emphasize
Recognise	Recognize
Organise	Organize
Authorise	Authorize
Cancelling	Canceling
Customise	Customize

CONTENTS

Chapter 1:	GETTING STARTED	
	, ,	1.2 1.4
	Understanding the Component Location	1.5 1.5
	Rear View	
	Installing the Toner Cartridge	11
	Making Connections	17
	Setting the Paper Type and Size	18 19 19
	CCD Power Save Mode 1.	20
Chapter 2:	Installing Software	
	About the Software	
	System Requirements 2 Installing Software in Windows 2 Repairing Software 2 Removing Software 2.	2.5 2.8

Chapter 3: PAPER HANDLING Selecting Print Materials 3.2 Size, Input Sources and Capacities 3.2 Guidelines for Paper and Special Materials 3.3 Printing to the Front Output Tray (Face down) 3.5 Printing to the Rear Output Slot (Face up) 3.5 Loading Paper in the Paper Tray 3.7 Using the Bypass Tray 3.8 Setting the Paper Type and Size for the Bypass Tray 3.10 Chapter 4: COPYING Loading Paper for Copying 4.2 Making Copies on the Document Glass 4.2 Making Copies from the Automatic Document Feeder 4.4 Setting Copy Options 4.6 Contrast 4.6 Image 4.6 Reduced/Enlarged Copy 4.7 Using Special Copy Features 4.8 Auto Fit Copying 4.8 Clone Copying 4.9 Collation Copying 4.10 2-side Copying 4.10 2-up or 4-up Copying 4.11 Poster Copying 4.12 Changing the Default Settings 4.13 Setting the Time Out Option 4.14

Chapter 5: PRINTING

	Printing a Document	
	Cancelling a Print Job	5.5
	Using a Favorite Setting	5.6
	Using Help	5.6
	Setting Paper Properties	5.7
	Printing Multiple Pages on One Sheet of Paper (N-Up Printing)	5.10 5.11 5.12 5.13 5.14 5.15 5.15 5.16 5.16
	Deleting a Page Overlay	
	Setting Graphic Properties	
	Setting Up the Locally Shared Printer	5.22
Chapter 6:	SCANNING	
	Scanning Basics Scanning Process with TWAIN-enabled Software	

Chapter 7: MAINTENANCE

	Clearing the Memory	
	Cleaning Your Machine	
	Cleaning the Outside	
	Cleaning the Scan Unit	
	Maintaining the Toner Cartridge	
	Redistributing Toner	
	Replacing the Toner Cartridge	
	Setting the Notify Toner Option	
	Cleaning the Drum	
	Setting the machine to be Checked by Phone	7.11
	Replacing the ADF Rubber Pad	
	Table	
Chapter 8:	TROUBLESHOOTING	
	Clearing Document Jams	
	Input Misfeed	
	Exit Misfeed	
	Roller Misfeed	
	Clearing Paper Jams	
	In the Paper Feed Area In the Paper Exit Area	
	In the Fuser Area or Around the Toner Cartridge .	
	In the Bypass Tray	
	Tips for Avoiding Paper Jams When Printing	0.0
	on the A5-sized Paper	8.9
	Tips for Avoiding Paper Jams	
	Clearing LCD Error Messages	
	Solving Problems	
	Paper Feeding Problems	8.14
	Printing Problems	8.15
	Printing Quality Problems	8.18
	Fax Problems	
	Copying Problems	
	Scanning Problems	8.25

Chapter A: SPECIFICATIONS

General Specifications	A.2
Scanner and Copier Specifications	A.3
Printer Specifications	A.4
Facsimile Specifications	
Paper Specifications	A.6
Overview	A.6
Supported Sizes of Paper	A.6
Guidelines for Using Paper	A.7
Paper Specifications	A.8
Paper Output Capacity	A.8
Printer and Paper Storage Environment	A.9



GETTING STARTED

Thank you for purchasing this multifunctional product. Your machine provides printing, copying, scanning, and faxing functions!


This chapter gives you step-by-step instructions for setting up your machine.

This chapter includes:

- Unpacking
- Understanding the Component Location
- Installing the Toner Cartridge
- Loading Paper
- Making Connections
- Turning the Machine On
- Changing the Display Language
- Setting the Paper Type and Size
- Using the Save Modes

Unpacking

Remove the machine and all accessories from the packing carton. Make sure that the machine has been packed with the following items:



Key layout sheet

(May already be affixed to the machine in some regions)


- * The appearance of the power cord may differ according to your country's specifications.
- ** The CD-ROM contains the Type 101 driver, the Operating Instructions and the Adobe Acrobat Reader program.
- *** Peel off the brand plaque's backing, and then stick down the plaque in the control panel's left corner.



CAUTION:

- You should use the telephone line cord which is supplied with your machine. If you use it with another vendor's, it should be AWG #26 or lower gage.
- Power cord must be plugged into a grounded power socket.

Remove the packing tape from the front, back and sides of the machine.



Selecting a Location

Select a level, stable place with adequate space for air circulation. Allow extra space for opening covers and trays. The area should be well-ventilated and away from direct sunlight or sources of heat, cold and humidity. Do not set the printer close to the edge of your desk or table.

Clearance Space


Front: 482.6 mm (enough space so that the paper tray can be

removed)

Back: 100 mm (enough space for ventilation)

Right: 100 mm


Left: 100 mm (enough space for ventilation)




Understanding the Component Location

These are the main components of your machine:


Front View




Rear View



Control Panel Functions






4	4 b	Scrolls through the options available for the selected menu item.
	Enter	Confirms the selection on the display.
	Menu	Enters Menu Mode and scrolls through the menus available.
	Upper Level	Sends you back to the upper menu level.
5	Redial/Pause	Redials the last number in Standby Mode or inserts a pause into a fax number in edit mode.
	On Hook Dial	Engages the telephone line.
6		Dials a number or enters alphanumeric characters.
7	Clear / Stop	Stops an operation at any time. In Standby Mode, clears/cancels the copy options, such as the contrast, the image setting, the copy size and the number of copies.
	Start	Starts a job.

Installing the Toner Cartridge

Open the front cover.




2 Remove the starter toner cartridge from its bag. Gently roll the cartridge to distribute the toner.



Thoroughly rolling the cartridge will assure the maximum copies per cartridge.

Slide the toner cartridge into the machine until it locks into place completely.



4 Close the front cover.






Note: When the toner cartridge needs to be replaced, the $\frac{1}{8}$ indicator turns on and the "Toner Empty" message appears on the display. To replace the toner cartridge, see page 7.8.

Loading Paper


The paper tray can hold a maximum of 250 sheets of 20 lb plain paper.

To load a stack of Letter-sized paper:


1 Pull open the paper tray.




Push down on the pressure plate until it locks into place.



Fan the edges of the paper stack to separate the pages. Then tap the stack on a flat surface to even it up.




4 Insert the paper stack into the paper tray.




If you want to load a different sized paper, you need to adjust the paper guides. For details, see page 1.13.

Pay attention to the paper limit mark on the left inside wall of the tray. Paper overloading may cause paper jams.



6 Slide the paper tray back in.




After you load paper, you need to set up your machine for the paper type and size you loaded. See page 1.18 for copying and faxing, or page 5.7 for PC-printing.


Changing the Paper Size in the Paper Tray

To load longer sizes of paper, such as Legal-sized paper, you need to adjust the paper guides to extend the paper tray.


Pressing and unlatching the guide lock, slide the paper length guide out completely to extend the paper tray to its full length.



2 After inserting paper into the tray, slide in the guide until it lightly touches the end of the paper stack.



Pinching the paper width guide as shown, move it toward the stack of paper until it lightly touches the side of the stack.





Notes:

- Do not push the paper width guide far enough to cause the materials to warp.
- If you do not adjust the paper width guide, it may cause paper jams.










Making Connections


1 Plug the telephone line cord into the **LINE** jack and the other end into the wall jack.




If you want to use your machine for receiving both faxes and voice calls, you will need to connect a telephone and/or answering machine to your machine.








2 Connect the USB cable which comes with your machine.



If you want to use a parallel printer cable, only use a IEEE 1284 compliant cable and connect it to the parallel connector on your machine.






Notes:

- You only need to connect one of the cables mentioned above. Do not use the parallel and the USB cables at the same time.
- If you are using a USB cable, you must be running Windows 98/ Me/2000/XP.
- When using the USB connection, your machine provides two USB modes; Fast and Slow. Fast is the default mode. Some PC users may experience poor USB function in the default mode. If this occurs, select the Slow mode to achieve successful results. For details about changing the USB mode, see page 8.17.

Turning the Machine On

- Plug one end of the supplied three-pronged electrical type cord into the AC socket on the machine and the other end into a properly grounded AC outlet.
- 2 Press the power switch to turn the machine on. "Warming Up Please Wait" appears on the display indicating that the machine is now on.



To view your display text in another language, see below.

Changing the Display Language

To change the language that displays on the display of the control panel, follow these steps:

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- 2 Press the scroll button (< or ▷) until "Language" appears on the bottom line of the display.
- 3 Press **Enter**. The current setting appears on the bottom line of the display.
- 4 Press the scroll button (< or ▷) until the language you want appears on the display.
- 5 Press Enter to save the selection.
- **6** To return to Standby Mode, press **Clear/Stop**.

Setting the Paper Type and Size

After loading paper in the paper tray, you need to set the paper type and size using the control panel buttons. These settings will apply to copy mode. For PC-printing, you need to select the paper type and size in the application program you use.

1 Press Menu.

The display shows "Paper Setting" on the top line and the first menu item, "Paper Type," on the bottom line.

- 2 Press Enter to access the menu item.
- 3 Use the scroll button (\triangleleft or \triangleright) to find the paper type you are using and press **Enter** to save it.
- 4 Press the ▷ button to scroll to "Paper Size" and press **Enter** to access the menu item.
- 5 Press **Enter** when "Tray Paper" displays on the bottom line.
- 6 Use the scroll button (⊲ or ▷) to find the paper size you are using and press Enter to save it.
- 7 To return to Standby Mode, press **Clear/Stop**.

Using the Save Modes

Power Save Mode

The power save mode allows your machine to reduce power consumption when it is not in actual use. You can turn this mode on by selecting the length of time for which the machine waits after a job is printed before it switches to a reduced power state.

- Press **Menu** until "Machine Setup" appears on top line of the display.
- 2 Press the scroll button (< or ▷) until "Power Save" appears on the bottom line. Press **Enter**.
- 3 Press the scroll button (< or ▷) to display "On" on the bottom line and press Enter.
 - Selecting "Off" means that the power save mode turns off.
- 4 Press the scroll button (< or ▷) until the time settings you want appears.

The available options are 5, 10, 15, 30 and 45 (minutes).

- Press **Enter** to save the selection.
- **6** To return to Standby Mode, press **Clear/Stop**.

CCD Power Save Mode

The scan lamp under the document glass automatically turns off when it is not in actual use to reduce power consumption and extend the lamp life. The lamp automatically wakes up after some warm-up time when you start scanning.

You can set the length of time for which the scan lamp waits after a scan job is completed before it switches to the power save mode.

- Press Menu until "Machine Setup" appears on top line of the display.
- Press the scroll button (dor ▷) until "CCD Power Save" appears on the bottom line. Press Enter.
- 3 Press the scroll button (< or ▷) until the time setting you want appears on the bottom line.
 - The available time options are 1, 4, 8 and 12 (hours).
- 4 Press **Enter** to save the selection.
- 5 To return to Standby Mode, press Clear/Stop.





INSTALLING SOFTWARE

This chapter gives you information for installing the supplied software. You must install the software to use your machine as a printer and a scanner.

This chapter includes:

- About the Software
- System Requirements
- Installing Software in Windows
- Repairing Software
- Removing Software

About the Software

You must install software using the supplied CD-ROM after you have set up your machine and connected it to your computer. The CD-ROM includes:

- The software for this machine
- Operating Instructions
- Adobe Acrobat Reader

The CD-ROM provides you with the following software:

Type 101 Driver

To use your machine as a printer and scanner in Windows, you must install the Type 101 driver. For information about installing the Type 101 driver in Windows, see page 2.5.

Remote Control Panel

It is automatically installed when you install the Type 101 driver. For information about using the program, refer to the Facsimile Reference.

Printer Driver Features

Your printer drivers will support the following standard features:

- Paper source selection
- Paper size, orientation and media type
- number of copies

Table below lists a general overview of features supported by your printer drivers.

Feature	Printer Driver		
	Win9x/Me	Win2000/XP	NT4.0
Print quality option	Y	Y	Υ
Poster printing	Y	Y	Υ
Multiple pages per sheet (N-up)	Y	Y	Y
Fit to page printing	Y	Y	Y
Scale printing	Y	Y	Y
Watermark	Y	Y	Y
Overlay	Y	Y	Y

System Requirements

Before you begin, ensure that your system meets the minimum requirements.

Supported Operating System

- Windows 95 OSR2
- Windows 98/Windows 98 SE
- Windows Me
- Windows NT 4 Workstation or Server with Service Pack 3
- Windows 2000 Professional or Advanced Server
- Windows XP Home edition or Professional.

Minimal Requirements

- Disk space: 120 MB for installation
- Memory: 64 MB
- CPU: Pentium II 233 or higher
- Required software: Internet Explorer 5.0

Recommended

- Disk space: 220 MB for installation
- Memory: 128 MB
- CPU: Pentium II 400 or higher
- Required software: Internet Explorer 5.5



- For Windows NT 4.0/2000/XP, the system administrator should install the software.
- Windows 95 versions prior to OSR2 are not recommended due to incompatibility with OLE/COM libraries.

Installing Software in Windows




- Cancel the "New Hardware Found" window when your computer boots up.
- Make sure that your machine is plugged in and connected to your computer's parallel port or USB port before installing **software**. Windows 95 and Windows NT 4.0 do not support the USB connection.
- Insert the supplied CD-ROM into your CD-ROM drive.

The CD-ROM should automatically run and an maintenance window appears.

If the maintenance window does not appear, click **Start** and then **Run**. Type **X:\Setup.exe**, replacing "**X**" with the letter of your drive and click OK.




NOTE: If your machine is not connected to the computer, the following window will appear.



- After connecting the machine, click Next.
- If you want to skip the connection status, click **Next**, and **No** to the following screen. Then the installation will start and the test page will not be printed at the end of the installation.

2 Choose the installation type.




- Typical: Installs the common software for your printer, such as printer driver, Twain driver, Remote Control Panel. This is recommeded for most users.
- Custom: Allows you to choose the language of the software and the components you want to install. After selecting the language and the component(s), click **Next**.



- •View Operating Instructions: Allows you to view this Operating Instructions. If your computer doesn't have Adobe Acrobat, click on this option and it will automatically install Adobe Acrobat for you.
- **3** After the installation is finished, the window asking you to print a test page appears. If you choose to print a test page, select the check box and click **Next**.
- 4 When the test page prints out correctly, click **Yes**. If not, click **No** to reprint it.

5 Click Finish.



6 The message box recommends you restart your computer. Click **OK**, then restart Windows.



Notes:

- When you want to use your machine with the parallel cable, remove the USB cable and connect the parallel cable. Then reinstall the printer driver; select **Start** → **Programs** → **Type 101** → **Maintenance** → **Repair** → **Printer**. If you have replaced the parallel cable with the USB cable, do the same to reinstall the driver.
- If your printer doesn't work properly, reinstall the printer driver.

Repairing Software

Repairing is required if your installation fails or the software does not work properly.

You can select Start → Programs → Type 101 → Maintenance.

Otherwise, insert the supplied CD-ROM into your CD-ROM


The CD-ROM should automatically run and an maintenance window appears.

If the maintenance window does not appear, click **Start** and then **Run**. Type **X:\Setup.exe**, replacing "**X**" with the letter of your drive and click **OK**.

2 Click Repair.




NOTE: If your machine is not connected to the computer, the following window will appear.



- After connecting the machine, click Next.
- If you want to skip the connection status, click **Next**, and **No** to the following screen. Then the installation will start and the test page will not be printed at the end of the installation.

Select the components you want to reinstall and click **Next**.



- 4 After the installation is finished, the window asking you to print a test page appears. If you choose to print a test page, select the check box and click Next.
- 5 When the test page prints out correctly, click **Yes**. If not, click **No** to reprint it.
- 6 When the reinstallation is done, click **Finish**.
- The message box recommends you restart your computer. Click **OK**, then restart Windows.

Removing Software

Uninstall is required if you are upgrading the software or if your installation fails.

1 You can select Start → Programs → Type 101 → Maintenance.

Otherwise, insert the supplied CD-ROM into your CD-ROM drive.

The CD-ROM should automatically run and an maintenance window appears.

If the maintenance window does not appear, click **Start** and then **Run**. Type **X:\Setup.exe**, replacing "**X**" with the letter of your drive and click **OK**.

2 Click Remove.

Then you will see a component list so that you can remove any of them individually.

If you want to uninstall the printer driver, check **Printer**.

If you want to uninstall the Twain driver, check **Twain**.

If you want to uninstall the Remote Control Panel, check **Remote Control Panel**.

- **3** After selecting items you wish to remove, click **Next**.
- 4 When your computer asks you to confirm your selection, click **Yes**.

The selected driver and all of its components are removed from your computer.

- 5 When the uninstallation is done, click **Finish**.
- **6** The message box recommends you restart your computer. Click **OK**, then restart Windows.





PAPER HANDLING

This chapter introduces you to the basics of selecting print materials and loading them into your machine.

This chapter includes:

- Selecting Print Materials
- Selecting an Output Location
- Loading Paper in the Paper Tray
- Using the Bypass Tray

Selecting Print Materials

Always use print materials that meet the guidelines for use with this machine. Using print materials that are not recommended may cause paper jams or print quality problems.

Size, Input Sources and Capacities

Size (mm/in.)	Input Source/Capacity*	
3/20 (11111)	Paper Tray	Bypass Tray
Plain paper Letter (215.9 x 279/8.5 x 11) A4 (210 x 297/8.27 x 11.69) Folio (215.9 x 330.2/8.5 x 13) Legal (215.9 x 355.6/8.5 x 14) Executive (184.2 x 266.7/7.25 x 10.5) B5 (182 x 257/7.2 x 10) A5 (148 x 210/5.83 x 8.27) A6 (105 x 148/4.13 x 5.88)	YES/250 YES/250 YES/250 YES/250 YES/250 YES/250 YES/250 YES/250	YES/1 YES/1 YES/1 YES/1 YES/1 YES/1 YES/1 YES/1
Envelopes No.9 (98.4 x 225.4/3.88 x 8.88) No.10 (104.8 x 241.3/4.13 x 9.5) DL (110 x 220/4.33 x 8.66) C5 (162 x 229/6.38 x 9.02) C6 (114 x 162/4.49 x 6.38) B5 (176 x 250/6.93 x 9.84) No.7 3/4 (98.4 x 190.5/3.88 x 7.5)	NO/0 NO/0 NO/0 NO/0 NO/0 NO/0 NO/0	YES/1 YES/1 YES/1 YES/1 YES/1 YES/1 YES/1
Labels** Letter (215.9 x 279/8.5 x 11) A4 (210 x 297/8.27 x 11.69)	NO/0 NO/0	YES/1 YES/1
Transparency films** Letter (215.9 x 279/8.5 x 11) A4 (210 x 297/8.27 x 11.69)	NO/0 NO/0	YES/1 YES/1
Card stocks** A6 card (105 x 148/4.13 x 5.88) Post Card (101.6 x 152.4/4 x 6) Hagaki (100 x 148/3.94 x 5.83)	NO/0 NO/0 NO/0	YES/1 YES/1 YES/1

Maximum capacity may be reduced depending on paper thickness.

^{**} If you experience excessive jamming, load one sheet at a time through the Bypass tray.

Guidelines for Paper and Special Materials

When selecting or loading paper, envelopes, or other special materials, keep these guidelines in mind:

- Attempting to print on damp, curled, wrinkled, or torn paper can cause paper jams and the poor print quality.
- Use only high quality copier grade paper. Avoid paper with embossed lettering, perforations, or texture that is too smooth or too rough. Paper jams may occur.
- Store paper in its ream wrapper until ready to use. Place cartons on pallets or shelves, not on the floor. Do not place heavy objects on top of the paper, whether it is packaged or unpackaged. Keep it away from moisture, or other conditions that can cause it to wrinkle or curl.
- During storage, you should use moisture-proof wrap, such as any plastic container or bag, to prevent dust and moisture from contaminating your paper.
- Always use paper and other materials that conform with the specifications listed under "Paper Specifications" on page A.6.
- Use only well-constructed envelopes with sharp, well creased folds.
 - DO NOT use envelopes with clasps and snaps.
 - DO NOT use envelopes with windows, coated lining, self-adhesive seals, or other synthetic materials.
 - DO NOT use damaged or poorly made envelopes.
- Load special paper types one sheet at a time.
- Only use materials specifically recommended for use in laser printers.
- To prevent special materials, such as transparencies and label sheets from sticking together, remove them as they prints out.
- Place transparencies on a flat surface after removing them from the machine.
- Do not leave transparencies in the paper tray for long periods of time. Dust and dirt may accumulate on them resulting in spotty printing.
- To avoid smudging caused by fingerprints, handle transparencies and coated paper carefully.
- To avoid fading, do not expose the printed transparencies to prolonged sunlight.
- Store unused materials at temperatures between 15 °C and 30 °C (59 °F to 86 °F). The relative humidity should be between 10 % and 70 %.
- Verify that your labels' adhesive material can tolerate fusing temperature of 200 °C (392° F) for 0.1 second.


- Make sure that there is no exposed adhesive material between labels. Exposed areas can cause labels to peel off during printing, which can cause paper jams. Exposed adhesive can also cause damage to machine components.
- Do not load a sheet of labels through the machine more than once. The adhesive backing is designed for one pass through the machine.
- Do not use labels that are separating from the backing sheet or are wrinkled, bubbled, or otherwise damaged.



NOTE: Do not use **Carbonless** paper and **Tracing** paper. They could make smell of chemicals and damage your printer.

Selecting an Output Location

The machine has two output locations; the rear output slot (face up) and the front output tray (face down).



To use the front output tray, make sure that the rear cover is closed. To use the rear output slot, open the cover.



Notes:

- If paper coming out of the front output tray has problems, such as excessive curl, try printing to the rear output slot.
- To avoid paper jams, do not open or close the rear cover while the machine is printing.


Printing to the Front Output Tray (Face down)

The front output tray collects printed paper face-down, in correct order. The tray should be used for most print jobs.



Printing to the Rear Output Slot (Face up)

Using the rear output slot, paper comes out of the machine face up.




Printing from the Bypass tray to the rear output slot provides the straight paper path. Using the rear output slot might improve the output quality with the following:

- envelopes
- labels
- small custom-sized paper
- postcards
- transparencies

To use the rear output slot:


Open the rear cover by pulling it upward.





WARNING: The fusing area at the rear part of the inside of your machine is hot when powered. Be careful not to be burned when you access this area.

If you do not want to stack the printed pages on the rear output slot, close the rear cover. The pages stack on the front output tray.






NOTE: Printed paper might fall, because the rear output slot is short.


Loading Paper in the Paper Tray

The paper tray can hold a maximum of 250 sheets of 20 lb plain paper.


The paper level indicator on the front of the paper tray shows the amount of paper currently left in the tray. When the tray is empty, the indicator of the bar is lowered.



To load paper, pull open the paper tray and load paper with the print side face down.



You can load letterhead paper with the design side face down. The top edge of the sheet with the logo should be placed at the front side of the tray.



For details about loading paper in the paper tray, see "Loading Paper" on page 1.11.



Notes:

- If you experience problems with paper feed, place the paper in the Bypass tray.
- You can load up to 150 sheets of previously printed paper. The printed side should be facing up with an uncurled edge at the top side. If you experience problems with paper feed, turn the paper around. Note that the print quality is not guaranteed.



Using the Bypass Tray

Use the Bypass tray to print transparencies, labels, envelopes or postcards in addition to making quick runs of paper types or sizes that are not currently loaded in the paper tray.


Postcards, 3.5 by 5.83 in. (index) cards and other custom-sized materials can be printed with this printer. The minimum size is 76 by 127mm(3.0 by 5.0 in.) and the maximum size is 216 by 356mm(8.5 by 14 in.)

Acceptable print materials are plain paper with sizes ranging from 100 x 148 mm (3.9 x 5.8 in.) to Legal 216 x 356 mm (8.5 x 14 in.), the largest size acceptable, and weighing between 16 lb and 43 lb.



Notes:

- Always load only the print materials specified in the Specifications on page A.6 to avoid paper jams and print quality problems.
- Flatten any curl on postcards, envelopes and labels before loading them into the Bypass tray.
- When you print on 76mm X 127mm (3 X 5 in.) sized media with loading into the tray, open the rear output tray.
- Load a sheet of the print material with the print side face up and into the center of the tray.



For transparencies, hold the transparencies by the edges and avoid touching the print side. Oils from your fingers that are deposited on them can cause print quality problems.




NOTE: Make sure to open the rear output slot when you print on transparencies. If not, they may tear while exiting the machine.

For envelopes, load a sheet with the flap side face down and with the stamp area on the top left side.



Adjust the paper guide to the width of the print material.




The machine picks up the material from the tray and begins printing.



NOTE: When printing on previously printed paper from the Bypass tray, the printed side should be facing down with an uncurled edge to the machine. If you experience problems with paper feed, turn the paper around.



3 Open the rear cover to use the rear output slot.



4 After printing, close the rear cover.

Setting the Paper Type and Size for the Bypass Tray

After loading paper in the Bypass tray, you need to set the correct paper type and size using the control panel buttons. These settings will apply to copy mode. For PC-printing, you need to select the paper size in the application program you use.

To set the paper size for the Bypass tray:

1 Press Menu.

The display shows "Paper Setting" on the top line and the first item, "Paper Type," on the bottom line.

- **2** Press **Enter** to access the menu item.
- 3 Use the scroll button (\triangleleft or \triangleright) to find the paper type you are using and press **Enter** to save it.
- 4 Press the ▷ button to scroll to "Paper Size" and press **Enter** to access the menu item.
- 5 Use the scroll button (dor) to display "Bypass Paper" on the bottom line. Press Enter to access the menu item.
- 6 Use the scroll button (

 or

) to find the paper size you are using and press Enter to save it.
- **7** To return to Standby Mode, press **Clear/Stop**.



4

COPYING

This chapter gives you step-by-step instructions for copying documents.

This chapter includes:


- Loading Paper for Copying
- Making Copies on the Document Glass
- Making Copies from the Automatic Document Feeder
- Setting Copy Options
- Using Special Copy Features
- Changing the Default Settings
- Setting the Time Out Option

Loading Paper for Copying


The instructions for loading print materials are the same whether you are printing, faxing or copying. For further details, see page 1.11 for loading in the paper tray and page 3.8 for loading in the Bypass tray.

Making Copies on the Document Glass

1 Lift and open the document cover.



Place the document face down on the document glass and align it with the registration guide on the top left corner of the glass.





NOTE: Make sure that no other documents are in the ADF (Automatic Document Feeder). If a document is detected in the ADF, it has priority over the document on the document glass.

Close the document cover.



Notes:

- Leaving the cover open while copying may affect the copy quality and toner consumption.
- If you are copying a page from a book or magazine, lift the cover until its hinges are caught by the stopper and then close the cover. If the book or magazine is thicker than 30 mm, start copying with the cover open.
- Enter the number of copy when you make more than two copies, and then press **Enter**.
- Customise the copy settings including copy size, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.

To clear the settings, use the **Clear/Stop** button.

- 6 If necessary, you can use special copy features, such as Auto Fit, Clone and 2-side copying.
- Press **Start** to begin copying. The display shows the copy processing.



Notes:

- You can cancel the copy job during an operation. Press Clear/ **Stop**, and the copying will stop.
- Dust on the document glass may cause black spots on the printout. Keep it always clean.
- To get the best scan quality, especially for coloured or gray scaled images, use the document glass.

Making Copies from the Automatic Document Feeder


Using the ADF (Automatic Document Feeder), you can load up to 30 documents (75 g/m^2 , 20lb) in one job.

When you use the ADF:


- Do not load documents smaller than 142 x 148 mm or larger than 216 x 356 mm.
- Do not attempt to feed the following types of documents:
 - carbon-paper or carbon-backed paper
 - coated paper
 - onion skin or thin paper
 - wrinkled or creased paper
 - curled or rolled paper
 - torn paper
- Remove all staples and paper clips before loading documents.
- Make sure any glue, ink or correction fluid on the paper is completely dry before loading documents.
- Do not load documents containing different sizes or weights of paper.

If you want to make copies from booklet, pamphlet, transparencies or documents having other unusual characteristics, use the document glass to load the document; see page 4.2.

1 Load the documents up to 30 pages **face up** into the ADF and adjust the document guides to the document size.



2 Make sure that the bottom of the document stack matches the paper size marked on the document tray.



- 3 Enter the number of copy when you make more than two copies, and then press **Enter**.
- 4 Customise the copy settings including copy size, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.

To clear the settings, use the **Clear/Stop** button.

- 5 If necessary, you can use special copy features, such as Collation and 2 or 4 up-copying.
- 6 Press **Start** to begin copying. The display shows the copy processing.



NOTE: Dust on the ADF glass may cause black lines on the printout. Keep it always clean.

Setting Copy Options

The buttons on the control panel let you make all the basic copy options; contrast, image, copy size and number of copies. Set the following options for the current copy job before pressing **Start** to make copies.



NOTE: If you press **Clear/Stop** while you set the copy options, all of the options you have set for the current copy job will be canceled and return to their default status. Or, they automatically returns to their default status after copying.

Contrast

If you have an original document containing faint markings and dark images, you can adjust the brightness to make a copy that is easier to read.

To adjust the contrast, press **Contrast** (O Darken).

Each time you press the button, the LED labeled with the selected mode turns on.

You can choose from the following contrast modes:

- Lighten: works well with dark print.
- Normal: works well with standard typed or printed documents.
- Darken: works well with light print or faint pencil markings.

Image

The Image setting is used to improve the copy quality by selecting the document for the current copy job.

To select the image type, press \mathbf{Image} ($^{\circ}_{\circ}$ $^{\text{Text}}_{\text{Nixed}}$).



Each time you press the button, the LED labeled with the selected mode turns on.

You can choose from the following image modes:

- **Text**: Use for documents containing mostly text.
- Mixed: Use for documents with mixed text and graphics.
- Photo: Use when the originals are photographs.



NOTE: When you copy a document containing color on the background, such as a newspaper or a catalog, you can get the background on your copy.

If you want to reduce the background, change the **Contrast** setting to **Lighten** and/or the **Image** setting to **Text**.

Reduced/Enlarged Copy

Using the **Reduce/Enlarge** button, you can reduce or enlarge the size of a copied image, from 25% to 400% when you copy original documents from the document glass or from 25% to 100% from the ADF. Note that the zoom rate available is different depending on the document loading method.

To select from the predefined copy sizes:

1 Press Reduce/Enlarge.

The default setting appears on the bottom line of the display.

- 2 Use **Reduce/Enlarge** or the scroll button (< or ▷) to find the size setting you want.
- 3 Press **Enter** to save the selection.

To fine-tune the size of copies:

- 1 Press Reduce/Enlarge.
- Press Reduce/Enlarge or the scroll button (< or ▷)</p> until "Custom: 25-100%" or "Custom: 25-400%" displays on the bottom line. Press Enter.
- 3 Press the scroll button (< or ▷) until the copy size you want appears on the display.

Pressing and holding the button allows you to guickly scroll to the number you want.

You can enter the value using the number keypad.

4 Press **Enter** to save the selection.



NOTE: When you make a reduced copy, black lines may appear at the bottom of your copy.

Using Special Copy Features

You can use the following copy features using the **Special** button on the control panel:

- **Auto Fit**: Automatically reduces or enlarges the original image to fit on the paper currently loaded in the machine. See below.
- **Clone**: Prints multiple image copies from the original document on a single page. The number of images is automatically determined by the original image and paper size. See page 4.9.
- **Collation**: Sorts the copy job. For example, if you make 2 copies of 3 page documents, one complete 3 page document will print followed by the second complete document. See page 4.10.
- **2-Side**: Prints 2-sided original document on one sheet of paper. See page 4.10.
- **2/4-Up**: Prints 2/4 original images reduced to fit onto one sheet of paper. See page 4.11.
- **Poster**: Prints an image onto 9 sheets of paper (3x3). You can paste the printed pages together to make one poster-size document. See page 4.12.



NOTE: Some features may not be available depending on where you loaded the document, on the document glass or in the Automatic Document Feeder.

Auto Fit Copying



This special copy mode can be applied when you load document only using the document glass. If a document is detected in the ADF, the Auto Fit does not work.

- 1 Load the document to be copied on the document glass, and close the cover.
- 2 Press Special.
- 3 Press **Special** or the scroll button (< or ▷) until "Autofit" appears on the bottom line.
- 4 Press Enter to save the selection.

5 If necessary, customise the copy settings including number of copies, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.



Note: You cannot adjust the copy size using the **Reduce/ Enlarge** button while the Auto Fit copying is enabled.

6 Press Start to begin copying.

Clone Copying








- This special copy mode can be applied when you load document only using the document glass. If a document is detected on the ADF, the Clone copying feature does not work.
- Load the document to be copied on the document glass, and close the cover.
- 2 Press Special.
- 3 Press **Special** or the scroll button (< or ▷) until "Clone" displays on the bottom line.
- 4 Press **Enter** to save the selection.
- 5 If necessary, customise the copy settings including number of copies, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.



NOTE: You cannot adjust the copy size using the **Reduce**/ **Enlarge** button while making a clone copy.

Press **Start** to begin copying.


Collation Copying



The Collation copying feature is available only when you load documents in the ADF.

- Load the documents to be copied in the ADF.
- 2 Press Special.
- 3 Press **Special** or the scroll button (⟨ or ▷) until "Collation" displays on the bottom line.
- 4 Press **Enter** to save the selection.
- If necessary, customise the copy settings including number of copies, copy size, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.
- 6 Press **Start** to begin copying.

2-side Copying



You can copy a 2-sided document on one page of A4, Letter or Legal-sized paper.

When you copy using this feature, the machine prints one side on the upper half of the paper and the other side on the lower half without reducing the original. This feature is helpful for copying a small-sized document, such as a name card.

If the original document is larger than the printable area, some portions may not be printed.

This special copy mode can be applied when you load document only using the document glass. If a document is detected in the ADF, the 2-side copying feature does not work.

- Load the document to be copied on the document glass, and close the cover.
- 2 Press Special.
- 3 Press Special or the scroll button (dor ▷) until "2-Side" displays on the bottom line.
- 4 Press **Enter** to save the selection.
- If necessary, customise the copy settings including number of copies, copy size, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.

Press **Start** to begin copying.

Your machine begins scanning the front side.

When "Set Backside" displays on the bottom line, open the document cover and flip the document over. Close the cover.



NOTE: If you press the **Clear/Stop** button or if no buttons are pressed for about 30 seconds, the machine cancels the copy job and returns to Standby Mode.

Press **Start** again.



NOTE: You cannot adjust the copy size using the **Reduce/ Enlarge** button for making a 2-side Copying.

2-up or 4-up Copying

The 2 or 4-up copying feature is available only when you load documents in the ADF.

- Load the documents to be copied in the ADF.
- 2 Press **Special**.
- Press **Special** or the scroll button (⊲ or ▷) until "2-Up" or "4-Up" displays on the bottom line.
- Press **Enter** to save the selection.
- If necessary, customise the copy settings including number of copies, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.



▲ 2-up copying

▲ 4-up copying




NOTE: You cannot adjust the copy size using the **Reduce/ Enlarge** button for making a 2 or 4-up copy.

Press **Start** to begin copying.



NOTE: 2-up copy reduces your original document by 50 %. 4-up copy reduces the document by the following rates depending on the paper loaded: 76 % for Letter, 81 % for A4 and 95 % for Legal.

Poster Copying



This special copy mode can be applied when you load document only using the document glass. If a document is detected in the ADF, the Poster copying feature does not work.

- 1 Load the documents to be copied on the document glass and close the cover.
- 2 Press Special.
- 3 Press **Special** or the scroll button (< or ▷) until "Poster" displays on the bottom line.
- 4 Press **Enter** to save the selection.
- If necessary, customise the copy settings including number of copies, contrast, image by using the control panel buttons. See "Setting Copy Options" on page 4.6.



NOTE: You cannot adjust the copy size using the **Reduce/ Enlarge** button for making a poster.

6 Press Start to begin copying.

Your original document is divided into 9 portions. Each portion is scanned and printed one by one in the following order:

1	2	3
4	5	6
7	8	9

Changing the Default Settings

The copy options, including contrast, image, copy size and number of copies, can be set to the most frequently used modes. When you copy a document, the default settings are used unless they are changed by using the corresponding buttons on the control panel.

To create your own default settings:

- 1 Press **Menu** on the control panel until "Copy Setup" appears on the top line of the display.
 - The first menu item, "Change Default", appears on the bottom line.
- 2 Press **Enter** to access the menu item. The first setup option, "Contrast" appears on the bottom line.
- 3 Press the scroll button (⊲ or ▷) to scroll through the setup options.
- **4** When the option you want to set appears, press **Enter** to access the option.
- 5 Change the setting using the scroll button (⟨⟨ or ⟩) or enter the value using the number keypad.
- 6 Press Enter to save the selection.
- **7** Repeat steps 3 through 6, as needed.
- 8 To return to Standby Mode, press **Clear/Stop**.



NOTES: While you set copy options, pressing **Clear/Stop** cancels the changed settings and restores their default status.

Setting the Time Out Option

You can set the time the machine waits before it restores the default copy settings, if you do not start copying after changing them on the control panel.

- 1 Press **Menu** on the control panel until "Copy Setup" appears on the top line of the display.
- Press the scroll button (< or ▷) to display "Timeout" on the bottom line.</p>
- 3 Press **Enter** to access the menu item.
- 4 Press the scroll button (\triangleleft or \triangleright) until the status you want appears on the display.

You can select from 15, 30, 60 and 180 (seconds). Selecting "Off" means that the machine does not restore the default settings until you press **Start** to begin copying, or **Clear/Stop** to cancel.

- 5 Press Enter to save the selection.
- **6** To return to Standby Mode, press **Clear/Stop**.



5

PRINTING

This chapter explains how to print your documents in Windows and how to use the print settings.

This chapter includes:

- Printing a Document
- Setting Paper Properties
- Printing Multiple Pages on One Sheet of Paper (N-Up Printing)
- Printing a Reduced or Enlarged Document
- Fitting Your Document to a Selected Paper Size
- Printing Posters
- Using Watermarks
- Using Overlays
- Setting Graphic Properties
- Setting Up the Locally Shared Printer


Printing a Document

The following procedure describes the general steps required for printing from various Windows applications. The exact steps for printing a document may vary depending on the application program you are using. Refer to your software application's Operating Instructions for the exact printing procedure.

- Open the document you want to print.
- Select Print from the File menu.

The Print window displays. It may look slightly different depending on your application.

The basic print settings are selected within the Print window. These settings include the number of copies and print range.



- ▲ Windows 98
- 3 To take advantage of the printer features provided by your machine, click **Properties** in the application's print window and go to Step 4.
 - If you see **Setup**, **Printer** or **Options**, click that button instead. Then click **Properties** on the next screen.
- 4 Now you see the Printer driver Type 101 Properties window, which allows you to access all of information you need when using your machine.


The **Layout** tab first displays.



If necessary, select the **Orientation** option.

The **Orientation** option allows you to select the direction in which information is printed on a page.

- Portrait prints across the width of the page, letter style.
- Landscape prints across the length of the page, spreadsheet style.
- If you want to turn the page upside down, select **180** from the **Rotate** drop-down list.



- From the **Paper** tab, select the paper source, size and type. For further details, see page 5.7.
- If necessary, you can set in what sequence the pages will be printed from the **Extra** tab. Select the required print order from the **Print Order** drop-down list.
 - Normal: Your machine prints in normal order.

- Reverse All Pages: Your machine prints all of the pages in reverse. This setting is helpful when you are using the rear output slot.
- **Print Odd Pages**: Your machine prints only the odd pages of the document.
- **Print Even Pages**: Your machine prints only the even pages of the document.
- Click other tabs on the top of the Properties window to access other features, if needed.
- When you finish setting the properties, click **OK** until the Print window displays.
- 9 Click **OK** to start printing.



- Most Windows applications overrides settings you specified in the printer driver. Change all of the print settings available in the software application first, and change any remaining settings using the printer driver.
- The settings you change remain in effect only while you are using the current program. To make your changes permanent, make them in the **Printers** folder. Follow these steps:
 - 1. Click the Windows Start menu.
 - 2. For Windows 95/98/Me/NT 4.0/2000, select **Settings** and then Printers.

For Windows XP, select **Printers and Faxes**.

- 3. Select the **Printer driver Type 101** printer.
- 4. Click the right mouse button on the printer icon and:
 - For Window 95/98/Me, select **Properties**.
 - For Windows 2000/XP, select **Printing Preferences**.
 - For Windows NT 4.0, select **Document Default**.
- 5. Change the settings on each tab and click **OK**.

Cancelling a Print Job

There are two ways to cancel a print job:

To stop a print job from the control panel:


Press the **Clear/Stop** button.

Your machine finishes printing the page that is moving through the machine and delete the rest of the print job. Pressing the button cancels only the current job. If more than one print job is in the machine's memory, you need to press the button once for each job.



To stop a print job from the Printers folder:

- 1 From the Windows **Start** menu, select **Settings**.
- Select **Printers** to open the Printers window and double-click the **Printer driver Type 101** icon.
- From the **Document** menu, select **Cancel Printing** (Windows 9x/Me) or **Cancel** (Windows NT 4.0/2000/XP).



▲ Windows 98




NOTE: You can access this window simply by double-clicking the printer icon at the bottom right corner of the Windows desktop.

Using a Favorite Setting

The **Favorites** option, which is visible on each properties tab, allows you to save the current properties settings for future use.

To save a Favorites item:

- 1 Change the settings on each tab, as needed.
- 2 Enter a name for the item in the **Favorites** input box.



3 Click Save.

To use a saved setting, select it from the **Favorites** drop-down list.

To delete a favorite setting item, select it from the list and click **Delete**.

You can also restore the printer driver's default settings by selecting **<Printer Default>** from the list.

Using Help


Your machine has a help screen that can be activated by the **Help** button in the printer's properties window. These help screens give detailed information about the printer features provided by the printer driver.


You can also click from the upper right hand corner, and then click on any setting.

Setting Paper Properties

Use the following options to set the paper handling needs when you access the printer properties. See page 5.2 for more information about accessing printer properties.

Click the **Paper** tab to access many paper properties.





Property	Description
3 Source	Make sure that Source is set to the corresponding paper tray.
	The Manual Feed source is used when printing to special materials. You need to load one sheet at a time into the Bypass Tray. See page 3.8.
	If the paper source is set to Auto Select , the machine automatically picks up print materials according to the following order: the Bypass tray and the paper tray.
4 Type	Make sure that Type is set to Printer Default . If you load a different type of print material, select the corresponding paper type. For more information about print materials, refer to Chapter 3, "Paper Handling."
	If you use cotton paper, set the paper type to Thick for the best printing.
	To use recycled paper, which weights from 75g/m ² to 90g/m ² (20lb to 24lb), or other coloured paper, select Color Paper .


Printing Multiple Pages on One Sheet of Paper (N-Up Printing)




You can select the number of pages to print on a single sheet of paper. To print more than one page per sheet, the pages will appear decreased in size and arranged on the sheet. You can print up to 16 pages on one sheet.

- To change the print settings from your software application, access the printer properties. See page 5.2.
- From the **Layout** tab, choose **Multiple Pages per Side** on the **Type** drop-down list.

Select the number of pages you want to print per sheet (1, 2, 4, 9 or 16) on the **Pages per Side** drop-down list.



Select the page order on the Page Order drop-down list, if necessary.



Check **Print Page Border** to print a border around each page on the sheet. Print Page Border is enabled only, if the pages per sheet is 2, 4, 9 or 16.

- Click the Paper tab and select the paper source, size and type.
- Click **OK** and print the document.

Printing a Reduced or Enlarged Document






You can scale your print job on a page.

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the Layout tab, select Reduce/Enlarge on the Type drop-down list.
- **3** Enter the scaling rate in the **Persentage** input box.

You can also click the ▲ or ▼ button.




- 4 Click the **Paper** tab and select the paper source, size and type.
- 5 Click **OK** and print the document.

Fitting Your Document to a Selected Paper Size




You can scale your print job to any selected paper size regardless of the digital document size. This can be useful when you want to check fine details on a small document.

- When you change the print settings from your software application, access the printer properties. See page 5.2.
- From the Layout tab, select Fit to Page on the Type drop-down list.
- Select the correct size from the **Target Page** drop-down list.




- Click the Paper tab and select the paper source, size and type.
- Click **OK** and print the document.

Printing Posters




You can print a single-page document onto 4, 9 or 16 sheets of paper, for the purpose of pasting the sheets together to form one poster-size document.


- When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the Layout tab, select Poster on the Type drop-down list.




3 Configure the poster option:

You can select the page layout from 2x2, 3x3 or 4x4. If you select 2x2, the output will be automatically stretched to cover 4 physical pages.





Specify an overlap in millimeters or inches to make it easier to reconstruct the resulting poster.



- Click the **Paper** tab and select the paper source, size and type.
- Click **OK** and print the document. You can complete the poster by reconstructing the results.

Using Watermarks




The Watermark option allows you to print text over an existing document. For example, you may want to have large gray letters reading "DRAFT" or "CONFIDENTIAL" printed diagonally across the first page or all pages of a document.

There are several predefined watermarks that come with your machine, and they can be modified or you can add new ones to the list.

Using an Existing Watermark


- When you change the print settings from your software application, access the printer properties. See page 5.2.
- Click the **Extras** tab and select a watermark on the **Watermark** drop-down list. It appears in the preview image window.



3 Click Ok and start printing.

Creating a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- Click the Extras tab and click the Edit button in the Watermark section. The Edit Watermarks window appears.



3 Enter the text message you want to print in the Watermark Message box.

The message displays in the preview image window. The preview image is provided so that you can see how the watermark will appear on the printed page.

When the **First Page Only** box is checked, the watermark is printed on the first page only.

4 Select the watermark options.

You can select the font name, style and size and gray scale level from the **Font Attributes** section and set the angle of the watermark from the **Message Angle** section.

- 5 Click Add to add a new watermark to the list.
- 6 When you finish creating, click **Ok** and start printing.

To stop printing the watermark, select **<No Watermark>** on the **Watermark** drop-down list.

Editing a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- Click the Extras tab and click the Edit button in the Watermark section. The Edit Watermarks window appears.
- 3 Select the watermark you want to edit on the **Current Watermarks** list, and change the watermark message and the options. Refer to "Creating a Watermark" on page 5.14.
- 4 Click **Update** to save the changes.
- 5 Click **Ok**.

Deleting a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the Extras tab, click the Edit button in the Watermark section. The Edit Watermarks window appears.
- 3 Select the watermark you want to delete on the **Current Watermarks** list and click **Delete**.
- 4 Click Ok.

Using Overlays

What is an Overlay?




An overlay is text and/or images stored in the computer hard disk drive (HDD) as a special file format that can be printed on any document. Overlays are often used to take the place of preprinted forms and letterhead paper. Rather than using preprinted letterhead, you can create an overlay containing the exact same information that is currently on your letterhead. To print a letter with your company's letterhead, you do not need to load preprinted letterhead paper in the machine. You need only tell the machine to print the letterhead overlay on your document.

Creating a New Page Overlay




To use a page overlay, you must create a new page overlay containing your logo or image.


- Create or open a document containing text or an image for use in a new page overlay. Position the items exactly as you wish them to appear when printed as an overlay. If needed, save the file for later use.
- When you change the print settings from your software application, access the printer properties. See page 5.2.
- 3 Click the **Extras** tab and click **Edit** button in the **Overlay** section.



4 In the Edit Overlays window, click **Create Overlay**.



In the Create Overlay window, type a name of up to eight characters in the File name box. Select the destination path, if necessary. (The default is C:\FormOver).



- Click **Save**. You can see the name on the **Overlay List**.
- Click **OK** or **Yes** until you complete creating.

The file is not printed out. Instead it is stored in your computer HDD disk.




NOTE: The overlay document size must be the same as documents you will print with the overlay.

Using a Page Overlay


After an overlay has been created, it is ready to be printed with your document. To print an overlay with a document:

- 1 Create or open the document you want to print.
- When you change the print settings from your software application, access the printer properties. See page 5.2.
- 3 Click the Extras tab.
- 4 Select the overlay you want to print from the **Overlay** drop-down list box.
- When the overlay file doesn't appear on the Overlay List, click the Edit button and Load Overlay, and select the overlay file.



If you have stored the overlay file you want to use into an external source, you can also load the file when you access this Load Overlay window.

After you select the file, click **Open**. The file is now shown in the **Overlay List** box and is available for printing. Select the overlay from the **Overlay List** box.



6 If necessary, click Confirm Page Overlay When **Printing**. When this box is checked, a message window appears each time you submit a document for printing, asking you to confirm your wish to print an overlay on your document.

Answering **Yes** to the window means that the selected overlay will be printed with your document. Answering No to the window cancels overlay printing.

If this box is empty and an overlay has been selected, the overlay will be automatically printed with your document.

Click **OK** or **Yes** until the printing starts.

The overlay is downloaded with your print job and printed on your document.



Note: The resolution of the overlay document must be the same as that of the document you will print with the overlay.

Deleting a Page Overlay


You can delete page overlays that are no longer used.

- In the printer properties window, click the **Extras** tab.
- 2 Click Edit in the Overlay section.
- 3 Select the overlay you want to delete from the **Overlay** List box.
- 4 Click **Delete Overlay**.
- 5 Click **OK** until you exit the Print window.


Setting Graphic Properties

Use the following graphic options to adjust the print quality for your specific printing needs. See page 5.2 for more information about accessing printer properties.

Click the **Graphics** tab to display the properties shown below.



Property	Description
Resolution	You can select the printing resolution by choosing from 600 dpi (Normal) or 300 dpi (Draft) . The higher the setting, the sharper the clarity of printed characters and graphics. Higher settings may increase time it takes to print a document.
2 Toner Save	Selecting this option extends the life of your toner cartridge and reduces your cost per page without a significant reduction in the print quality. • On: Select this option to allow the printer to use less toner on each page. • Off: When you do not need to save toner to print a document, select this option.



Property	Description
S Advanced Options (continued)	True Type Options (Win 95/98/Me) This option determines what the driver tells the machine about how to image the text in your document. Select the appropriate setting according to the status of your document. • Download as Bit Image: When this option is selected, the driver downloads the font data as bitmap images. Documents with complicated fonts, such as Korean or Chinese, or various types of fonts print faster in this setting. • Print as Graphics: When this option is selected, the driver downloads any fonts as graphics. When printing documents with high graphic content and relatively few TrueType fonts, printing performance (speed) may be enhanced in this setting.

Setting Up the Locally Shared Printer

You can connect the machine directly to a selected computer, which is called "host computer," on the network. Your machine can be shared by other users on the network through a Windows 9x, Me, 2000, XP or NT 4.0 network printer connection.



NOTE: Whether the printer is locally connected or network-connected, you need to install the printer software on each computer that will print documents to the printer.

In Windows 9x/Me

Setting Up the Host Computer

- 1 Start Windows.
- 2 From the Start menu, select Control Panel and double-click on the Network icon.

- 3 Check the **File and Print Sharing** box and click **OK**.
- 4 Click **Start** and select **Printers** from **Settings**. Double-click your printer name.
- 5 Select **Properties** in the **Printer** menu.
- 6 Click the **Sharing** tab and check the **Shared As** box. Fill in the **Shared Name** field and then click **OK**.

Setting Up the Client Computer

- 1 Right-click **Start** and select **Explorer**.
- 2 Open your network folder in the left column.
- 3 Right-click the shared name and select **Capture Printer Port**.
- 4 Select the port you want, check the **Reconnect at log on** box and then click **OK**.
- 5 From the **Start** menu, select **Settings** and then **Printers**.
- 6 Double-click your printer icon.
- **7** From the **Printer** menu, select **Properties**.
- **8** From the **Details** tab, select the printer port and click **OK**.

In Windows NT 4.0/2000/XP

Setting Up the Host Computer

- 1 Start Windows.
- 2 For Windows NT 4.0/2000, from the **Start** menu, select **Settings** and then **Printers**.
 - For Windows XP, from the **Start** menu, select **Printers and Faxes**.
- 3 Double-click your printer icon.

- 4 From the **Printer** menu, select **Sharing**.
- 5 For Windows NT 4.0, check the **Shared** box.

For Windows 2000, check the **Shared As** box.

For Windows XP, check the **Share this printer** box.

For Windows NT 4.0, fill in the Share Name field and click OK.

For Windows 2000/XP, fill in the **Shared Name** field and click **OK**.

Setting Up the Client Computer

- 1 Right-click Start and select Explorer.
- Open your network folder in the left column.
- 3 Click the shared name.
- 4 For Windows NT 4.0/2000, from the **Start** menu, select **Settings** and **Printers**.

For Windows XP, from the **Start** menu, select **Printers and Faxes**.

- 5 Double-click your printer icon.
- **6** From the **Printer** menu, select **Properties**.
- 7 Press the Ports tab and click Add Port.
- 8 Select Local Port and click New Port.
- **9** Fill in the **Enter a port name** field and enter the shared name.
- 10 Click OK and click Close.
- **11** For Windows NT 4.0, click **OK**.

For Windows 2000/XP, click **Apply** and click **OK**.



6

SCANNING

Scanning with your machine lets you turn pictures and text into digital files on your computer. Then you can fax or e-mail the files, display them on your web site or use them to create projects.

This chapter includes:

- Scanning Basics
- Scanning Process with TWAIN-enabled Software

Scanning Basics

Your machine offers a following way to begin scanning:

• From TWAIN-compliant software: You can use other software including Adobe PhotoDeluxe and Adobe Photoshop. See page 6.2.



Notes:

- To scan with your machine, you must install the Type 101 driver.
- Scanning is done through the same LPT or USB port currently assigned for your printer port.

Scanning Process with TWAIN- enabled Software

If you want to scan documents using other software, you will need to use TWAIN-compliant software, such as Adobe PhotoDeluxe or Adobe Photoshop. The first time you scan with your machine, select it as your TWAIN source in the application you use.

The basic scanning process involves a number of steps:

- Place your photograph or page on the document glass or in the ADF.
- Open an application, such as PhotoDeluxe or Photoshop.
- Open the TWAIN window and set the scan options.
- Scan and save your scanned image.

You need to follow the program's instructions for acquiring an image. Please refer to the Operating Instructions of the application.





MAINTENANCE

This chapter provides information for maintaining your machine and the toner cartridge.

This chapter includes:

- Clearing the Memory
- Cleaning Your Machine
- Maintaining the Toner Cartridge
- Setting the machine to be Checked by Phone
- Replacing the ADF Rubber Pad

Clearing the Memory

You can selectively clear information stored in your machine's memory.

- Press **Menu** on the control panel until "Maintenance" appears on the top line of the display.
- Press the scroll button (< or ▷) until you see "Clear Memory" on the bottom line and press **Enter**.

The first available menu item, "Paper Setting," displays on the bottom line.

- 3 Press the scroll button (< or ▷) until you see the item you want to clear.
 - Paper Setting: Restores all of the Paper Setting options to the factory default.
 - Copy Setup: Restores all of the Copy Setup options to the factory default.
 - Fax Setup: Restores all of the Fax Setup options to the factory default.
 - Fax Feature: Cancels all of the scheduled fax jobs in the machine's memory.
 - Advanced Fax: Restores all of the Advanced Fax setting options to the factory default.
 - Sound/Volume: Resets the sound and volume settings to the factory default.
 - Machine Setup: Resets all of the system settings, such as the machine ID, date and time, display language and save modes, to the factory default.
 - Sent Report: Clears all of records of your faxes sent.
 - RCV Report: Clears all of records of your faxes received.
 - Phone Book: Clears the speed dial or group dial numbers stored in the memory.
- Press **Enter**. The selected memory is cleared and the display asks you to continue clearing the next item.
- Repeat steps 2 and 3 to clear another item.

OR

To return to Standby Mode, press **Clear/Stop**.

Cleaning Your Machine

To maintain the print quality, follow the cleaning procedures below each time the toner cartridge is replaced or if print quality problems occur.



Notes:

- While cleaning the inside of the printer, be careful not to touch the transfer roller (located underneath the toner cartridge). Oil from your fingers can cause print quality problems.
- Cleaning the cabinet of the printer with surfactants containing large amounts of alcohol, solvent or other strong substances can discolour or crack the cabinet.

Cleaning the Outside

Clean the cabinet of the printer with a soft, lint-free cloth. You can dampen the cloth slightly with water, but be careful not to be let any water drip onto the printer or inside of it.

Cleaning the Inside

During the printing process, paper, toner and dust particles can accumulate inside the machine. This buildup can cause print quality problems, such as toner specks or smearing. Cleaning the inside of the machine clears or reduces these problems.

- 1 Turn the machine off and unplug the power cord. Wait for the machine to cool down.
- 2 Open the front cover and pull the toner cartridge out, lightly pushing it down.



With a dry and lint-free cloth, wipe away any dust and spilled toner from the toner cartridge area and the toner cartridge cavity.






NOTE: To prevent damage to the toner cartridge, do not expose it to light for more than a few minute. Cover it with a piece of paper, if necessary. Do not touch the black transfer roller inside the machine.

- Reinsert the toner cartridge and close the cover.
- 5 Plug in the power cord and turn the machine on.

Cleaning the Scan Unit

Keeping the scan unit clean helps ensure the best possible copies. We suggest that you clean the scan unit at the start of each day and during the day, as needed.

- 1 Slightly dampen a soft lint-free cloth or paper towel with water.
- Open the document cover.
- Wipe the surface of the document glass and ADF glass until it is clean and dry.



- 4 Wipe the underside of the white document cover and white sheet until it is clean and dry.
- Close the document cover.

Maintaining the Toner Cartridge

Toner cartridge storage

To get the most from the toner cartridge, keep the following quidelines in mind:

- Do not remove the toner cartridge from its package until ready for use.
- Do not refill the toner cartridge. The machine warranty does not cover damage caused by using a refilled cartridge.
- Store toner cartridges in the same environment as your machine.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minute.


Expected Cartridge Life

The life of the toner cartridge depends on the amount of toner that print jobs require. When printing text at IDC 5% coverage, a new toner cartridge lasts an average of 3,500 pages. (The original toner cartridge supplied with the printer lasts an average of 2,000 pages.) The actual number may be different depending on the print density of the page you print. If you print a lot of graphics, you may need to change the cartridge more often.


Redistributing Toner

When the toner cartridge is near the end of its life, white streaks or light print occurs. The LCD displays the warning message, "Toner Low." You can temporarily reestablish the print quality by redistributing the remaining toner in the cartridge.

1 Open the front cover.



2 Pull the toner cartridge out and gently roll the cartridge to distribute the toner evenly inside the cartridge.





NOTE: If the toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets the toner into fabric.

3 Reinstall the cartridge and close the front cover.

Replacing the Toner Cartridge

When the toner eventually runs out, only blank pages print when a print job is sent or when a fax is received. At this stage, the toner cartridge needs to be replaced. The display shows the warning message, "Toner Empty," and the 🕍 indicator on the control panel turns on.

Open the front cover.




Lightly pushing the used cartridge down, pull it out.






NOTE: Help the environment by recycling your used toner cartridge. Refer to the recycling brochure packed with the toner cartridge for details.

3 Unpack the new toner cartridge and gently shake it horizontally four or five times to distribute the toner evenly inside the cartridge.



Save the box and the cover for shipping.

Slide the new toner cartridge in until it locks into place.



Close the front cover.



Setting the Notify Toner Option

If you have set the Notify Toner menu option to "On", your machine automatically sends a fax to your service company or the dealer to notify them that your machine requires a new toner cartridge when the toner cartridge needs to be replaced. The fax number is preset by your dealer when you bought your machine.

- 1 Press **Menu** on the control panel until "Maintenance" appears on the top line of the display.
 - The first available menu item, "Clean Drum," displays on the bottom line.
- Press the scroll button (

 or

) to display "Notify Toner" on the bottom line and press Enter.
- 3 Press the scroll button (

 or

) to change the setting.
 Select "On" to enable this feature. Selecting "Off" disables this feature.
- 4 Press **Enter** to save the selection.

Cleaning the Drum

If there are streaks or spots on your print, the OPC drum of the cartridge may require cleaning.

- **1** Before setting the cleaning procedure, make sure that paper is loaded in the machine.
- 2 Press **Menu** on the control panel until "Maintenance" appears on the top line of the display. The first available menu item, "Clean Drum," displays on the bottom line.
- 3 Press Enter.

The display confirms your selection.

The machine prints out a cleaning page. Toner particles on the drum surface are affixed to the paper.

4 If the problem remains, repeat steps 1 through 3.

Setting the machine to be Checked by Phone

The Remote Test feature allows your machine to be checked out by a service company at a remote place by phone.

- Press **Menu** on the control panel until "Maintenance" appears on the top line of the display.
 - The first available menu item, "Clean Drum," displays on the bottom line.
- 2 Press the scroll button (⊲ or ▷) to display "Remote Test" on the bottom line and press Enter.
- **3** Press the scroll button (\triangleleft or \triangleright) to change the setting.
 - Select "On" to enable this feature. Selecting "Off" disables this feature.
 - If you want to protect your machine from being opened by an unauthorized person, select "Off".
- 4 Press **Enter** to save the selection.



Note: This feature is not available in some areas.


Replacing the ADF Rubber Pad

You can purchase an ADF Rubber Pad from an authorized service center.

- 1 Open the ADF Top Cover.
- 2 Pull the white plastic hook out of the hole and rotate it up as shown.
- 3 Put up that end of the shaft and then slide the ADF Roller Assembly to the right to remove it.



- 4 Pull up on the white end of the ADF Rubber Pad.
- 5 Slide the pad to one side and then lift up to remove.



- 6 Set the new ADF Rubber Pad. Make sure that the spring is in the right position when the ADF Rubber Pad is set.
- 7 Place the ADF Roller Assembly back.
- 8 Close the ADF Top Cover.



8

TROUBLESHOOTING

This chapter gives helpful information for what to do if you encounter an error.

This chapter includes:

- Clearing Document Jams
- Clearing Paper Jams
- Clearing LCD Error Messages
- Solving Problems

Clearing Document Jams


When a document jams while it passes through the ADF (Automatic Document Feeder), "Document Jam" appears on the display.

Input Misfeed

- Remove the remaining documents from the ADF.
- Open the ADF cover.



Rotate the bushing on one end of the ADF roller toward the ADF ((a)) and remove the roller from the slot((b)). Pull the document gently to the right and out of the ADF.




Close the ADF cover. Then load the documents back into the ADF.



NOTE: To prevent document jams, use the document scanner glass for thick, thin or mixed documents.

Exit Misfeed


- Remove the remaining documents from the ADF.
- 2 Open the document cover and turn the release knob to remove the misfed documents from the document output tray.



3 Close the document cover. Then load the documents back into the ADF.

Roller Misfeed

- 1 Remove the remaining documents from the ADF.
- 2 Open the document cover.
- 3 Turn the release knob so that you can easily seize the misfed document, and remove the document from the roller or the feed area by carefully pulling it to the right using both hands.



4 Close the document cover. Then load the documents back into the ADF.

Clearing Paper Jams

When a paper jam occurs, "Paper Jam" appears on the display. Refer to the table below to locate and clear the paper jam.

Message	Location of Jam	Go to
Paper Jam 0	In the paper feed area.	below
	In the Bypass tray	page 8.8
Paper Jam 1	In the fuser area or around the toner cartridge.	page 8.7
	In the Bypass tray	page 8.8
Paper Jam 2	In the paper exit area	page 8.5


To avoid tearing the paper, pull the jammed paper out gently and slowly. Follow the steps below to clear the jam.

In the Paper Feed Area


Open and close the front cover. The jammed paper automatically exits the machine.

If the paper does not exit, continue to Step 2.

Pull the paper tray open.



Remove the jammed paper by gently pulling it straight out.



If there is any resistance and the paper does not move when you pull or if you cannot see the paper in this area, skip to the fuser area around the toner cartridge. See page 8.7.

Insert the paper tray into the machine until it snaps into




Open and close the front cover to resume printing.

In the Paper Exit Area


Open and close the front cover. The jammed paper automatically exits the machine.

If the paper does not exit, continue to Step 2.


Gently pull the paper out of the front output tray. Skip to Step 6.



If there is any resistance and the paper does not move when you pull or if you cannot see the paper in the front output tray, open the rear cover.



Remove the jammed paper by gently pulling it straight out.




- 5 Close the rear cover.
- 6 Open and close the front cover to resume printing.

In the Fuser Area or Around the Toner Cartridge




WARNING: The fuser area is hot. Take care when removing paper from the machine.


Open the front cover and pull the toner cartridge out, lightly pushing it down.



Remove the jammed paper by gently pulling it straight out.




Replace the toner cartridge and close the front cover. Printing automatically resumes.



In the Bypass Tray

"Paper Jam 0", "Paper Jam 1" appears on the display when you try to print using the Bypass tray and the machine does not detect paper, due to no paper or improper paper loading.


"Paper Jam 0", "Paper Jam 1" also may occur when the paper is not properly fed into the machine through the Bypass tray. In that case, pull the paper out of the machine.




Tips for Avoiding Paper Jams When Printing on the A5-sized Paper

If paper jams frequently occur when you print on the A5-sized paper:

1 Open the input tray and load paper into the tray as shown below.



- 2 Open the Printer driver Type 101 Properties window, set the paper size to **A5(5.8x8.3 in.)** from the **Paper** tab.
- **3** From the **Orientation** option of the **Layout** tab, set the Rotate option to 90°.



4 Click **OK** to start printing.

Tips for Avoiding Paper Jams

By selecting the correct paper types, most paper jams can be avoided. When a paper jam occurs, follow the steps outlined in "Clearing Paper Jams" on page 8.4.

- Follow the procedures in "Loading Paper" on page 1.11. Ensure that the adjustable guides are positioned correctly.
- Do not overload the paper tray. Ensure that the paper is below the paper capacity mark on the inside wall of the paper tray.
- Do not remove the paper from the tray while your machine is printing.
- Flex, fan and straighten the paper before loading.
- Do not use creased, damp or highly curled paper.
- Do not mix paper types in the paper tray.
- Use only recommended print materials. See "Paper Specifications" on page A.6.
- Ensure that the recommended print side of print materials is facing down in the paper tray and facing up in the Bypass tray.

Clearing LCD Error Messages

Display	Meaning	Suggested solutions
Cancel ? 1:Yes 2:No	Your machine's memory is full during the machine stores the document into the memory.	To cancel the fax job, press the 1 button to accept "Yes." If you want to send the pages were stored, press the 2 button to accept "No." You should send the remaining pages later when the memory is available.
Comm. Error	The machine has a communication problem.	Ask the sender to try again.
Document Jam	The loaded document has jammed in the ADF (Automatic Document Feeder).	Clear the document jam. See page 8.2.
Door Open	The front or rear cover is not securely latched.	Close the cover until it locks into place.
CRU Fuser Error		
Heating Error	There is a problem in the	Unplug the power cord and plug it
Open Heat Error	fuser unit.	back in. If the problem persists, please call for service.
Over Heat		·
Group Not Available	You have tried to select a group location number where only a single location number can be used, such as when adding locations for a broadcasting operation.	Just use a speed dial number or dial a number manually using the number keypad.
	The remote machine did not have the requested feature, such as a delayed transmission.	Reconfirm the remote machine's features.
Incompatible	It also occurs if the remote machine does not have enough memory space to complete the operation you are attempting.	
Invalid Cartridge	You have used unauthorised cartridge.	You must use an approved cartridge.

Display	Meaning	Suggested solutions
Line Busy	The remote party did not answer or the line is already engaged.	Try again after a few minutes.
Line Error	Your machine cannot connect with the remote machine or has lost contact because of a problem with the phone line.	Try again. If the problem persists, wait an hour or so for the line to clear and try again. Or, turn the ECM mode on. See the Facsimile Reference.
Load Document	You have attempted to set up a copy or fax operation with no document loaded.	Load a document and try again.
LSU Error	A problem has occurred in the LSU (Laser Scanning Unit).	Unplug the power cord and plug it back in. If the problem persists, please call for service.
Memory Full	The memory is full.	Delete unnecessary documents, retransmit after more memory becomes available or split the transmission into more than one operation.
No Answer	The remote fax machine has not answered after several redial attempts.	Try again. Make sure that the remote machine is operational.
No Cartridge	The toner cartridge is not installed.	Install the toner cartridge. See page 1.9.
No. Not Assigned	The speed dial location you tried to use has no number assigned to it.	Dial the number manually using the number keypad or assign the number. See the Facsimile Reference.
No Paper	The paper in the paper tray has run out.	Load paper in the paper tray. See page 1.11.
Operation Not Assigned	You are doing in the Add/ Cancel operation, but there is no jobs waiting.	Check the display to see if there is any scheduled job. The display should indicate them in Standby Mode, for example, Delay Fax.

Display	Meaning	Suggested solutions
Paper Jam Ø	Paper has jammed in the feeding area of the paper tray. Your machine detects non feeding from the Bypass tray.	Clear the jam. See page 8.4. Load paper in the Bypass tray. Or remove the jammed paper from the Bypass tray.
Paper Jam 1	Paper has jammed in the paper exit area. Your machine detects non feeding from the Bypass tray.	Clear the jam. See page 8.7. Load paper in the Bypass tray. Or remove the jammed paper from the Bypass tray.
Paper Jam 2	Paper has jammed in the fuser area.	Clear the jam. See page 8.5.
Power Failure	Power has turned off then on and the machine's memory has not been saved.	You need to start again the job which you were trying to do before the power failure.
Retry Redial?	The machine is waiting for a specified time interval to redial a previously busy station.	You can press Enter to immediately redial, or Clear/Stop to cancel the redial operation.
Stop Pressed	The Clear/Stop button is pressed during a copy or fax operation.	Try again.
Toner Empty	The toner cartridge has run out. The machine stops.	Replace with a new toner cartridge. See page 7.8.
Toner Low	The toner is almost empty.	Take out the toner cartridge and gently shake it. By doing this, you can temporarily reestablish printing operations.

Solving Problems

The following chart lists some conditions that may occur and the recommended solutions. Follow the suggested solutions until the problem is corrected. If the problem persists, please call for service.

Paper Feeding Problems

Condition	Suggested solutions
Paper is jammed during printing.	Clear the paper jam. See page 8.4.
Paper sticks together.	 Ensure that there is not too much paper in the paper tray. The paper tray can hold up to 250 sheets of paper, depending on the thickness of your paper. Make sure that you are using the correct type of paper. See "Paper Specifications" on page A.6. Remove paper from the paper tray and flex or fan the paper. Humid conditions may cause some paper to stick together.
Multiple sheets of paper do not feed.	 Different types of paper may be stacked in the paper tray. Load the paper of only one type, size and weight. If multiple sheets have caused a paper jam, clear the paper jam. See page 8.4.
Paper does not feed into the machine.	 Remove any obstructions inside the machine. Paper has not been loaded correctly. Remove paper from the tray and reload it correctly. There is too much paper in the paper tray. Remove excess paper from the tray. The paper is too thick. Use only paper that meets the specifications required by the machine. See "Paper Specifications" on page A.6.
The paper keeps jamming.	 There is too much paper in the paper tray. Remove excess paper from the tray. If you are printing on special materials, use the Bypass tray. An incorrect type of paper is being used. Use only paper that meets the specifications required by the machine. See "Paper Specifications" on page A.6. There may be debris inside the machine. Open the front cover and remove the debris.
Transparencies stick together in the paper exit.	Use only the transparencies specifically designed for a laser printer. Remove each transparency as it exits from the machine.
Envelopes skew or fail to feed correctly.	Ensure that the paper guides are against both sides of the envelopes.

Printing Problems

Condition	Possible cause	Suggested solutions
The machine does not print.	The machine is not receiving power.	Check the power cord connections. Check the power switch and the power source.
	The machine is not selected as the default printer.	Select Printer driver Type 101 as your default printer in your Windows.
	Check the machine for the following:	 The front or rear cover is not closed. Paper is jammed. No paper is loaded. The toner cartridge is not installed.
		If a printer system error occurs, contact your service representative.
	The connection cable between the computer and the machine is not connected properly.	Disconnect the printer cable and reconnect it.
	The connection cable between the computer and the machine is defective.	If possible, attach the cable to another computer that is working properly and print a job. You can also try using a different printer cable.
	The port setting is incorrect.	Check the Windows printer setting to make sure that the print job is sent to the correct port, for example, LPT1. If the computer has more than one port, make sure that the machine is attached to the correct one.
	The machine may be configured incorrectly.	Check the printer properties to ensure that all of the print settings are correct.
	The printer driver may be incorrectly installed.	Remove the printer driver and then reinstall it; see page 2.10 and page 2.5 respectively.
	The machine is malfunctioning.	Check the display message on the control panel to see if the machine is indicating a system error.
The machine selects print materials from the wrong paper source.	The paper source selection in the printer properties may be incorrect.	For many software applications, the paper source selection is found under the Paper tab within the printer properties. Select the correct paper source. See page 5.8.

Condition	Possible cause	Suggested solutions
A print job is extremely slow.	The job may be very complex.	Reduce the complexity of the page or try adjusting the print quality settings.
		The maximum print speed of your machine is 17 PPM for Letter-sized paper.
	If you are using Windows 9x/Me, the Spooling Setting may be set incorrectly.	From the Start menu, choose Settings and Printers . Right-click this machine's printer icon, choose Properties , click the Details tab, and then choose the Spool Settings button. Select the desired spool setting.
Half the page is blank.	The page orientation setting may be incorrect.	Change the page orientation in your application. See page 5.3.
	The paper size and the paper size settings do not match.	Ensure that the paper size in the printer driver settings matches the paper in the tray.
The machine prints, but the text is wrong, garbled, or incomplete.	The printer cable is loose or defective.	Disconnect the printer cable and reconnect. Try a print job that you have already printed successfully. If possible, attach the cable and the machine to another computer and try a print job that you know works. Finally, try a new printer cable.
	The wrong printer driver was selected.	Check the application's printer selection menu to ensure that your machine is selected.
	The software application is malfunctioning.	Try printing a job from another application.
	The operating system is malfunctioning.	Exit Windows and reboot the computer. Turn the machine off and then back on again.
Pages print, but are blank.	The toner cartridge is defective or out of toner.	Redistribute the toner. if necessary. See page 7.7.
		If necessary, replace the toner cartridge.
	The file may have blank pages.	Check the file to ensure that it does not contain blank pages.
	Some parts, such as the controller or the board, may be defective.	Contact a service representative.

Condition	Possible cause	Suggested solutions
The illustrations print incorrectly in Adobe Illustrator.	The setting in the software application is wrong.	Print the document with selecting Download as Bit Image in the Advanced Options window of the Graphic properties.
An error occurs repeatedly	When the USB mode is set to "Fast," some PC	Change the USB mode to "Slow." To do so, follow these steps:
when you are printing with the USB connection.	users may experience poor USB communication.	Press Menu on the control panel until "Machine Setup" appears on the top line of the display.
		2. Press the scroll button (< or ▷) until "USB Mode" appears on the bottom line, and press Enter .
		3. Press the scroll button (⊲ or ▷) to select "Slow."
		4. Press Enter to save the selection.
		5. Press Clear/Stop to return to Standby Mode.

Printing Quality Problems

The dirty inside of the machine or improper paper loading may reduce the print quality. See the table below to clear the problem.

Condition	Suggested solutions
Light or faded print AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 If a vertical white streak or faded area appears on the page: The toner supply is low. You may be able to temporarily extend the toner cartridge life. See "Redistributing Toner" on page 7.7. If this does not improve the print quality, install a new toner cartridge. The paper may not meet paper specifications; for example, the paper is too moist or too rough. See "Paper Specifications" on page A.6. If the entire page is light, the print resolution setting is too low. Adjust the print resolution and turn the toner save mode off. See page 5.20 respectively. A combination of faded or smeared defects may indicate that the toner cartridge needs cleaning. See "Cleaning the Drum" on page 7.10.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 The paper may not meet specifications; for example, the paper is too moist or too rough. See "Paper Specifications" on page A.6. The transfer roller may be dirty. Clean the inside of your machine. See page 7.3. The paper path may need cleaning. See "Cleaning the Drum" on page 7.10.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 If faded areas, generally rounded, occur randomly on the page: A single sheet of paper may be defective. Try reprinting the job. The moisture content of the paper is uneven or the paper has moist spots on its surface. Try a different brand of paper. See "Paper Specifications" on page A.6. The paper lot is bad. The manufacturing processes can cause some areas to reject toner. Try a different kind or brand of paper. The toner cartridge may be defective. Vertical repetitive defects on the next page. If these steps do not correct the problems, contact a service representative.

Condition	Suggested solutions
Vertical lines AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	If black vertical streaks appear on the page: • The drum inside the toner cartridge has probably been scratched. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.9.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 If the amount of background shading becomes unacceptable: Change to a lighter weight pages. See "Paper Specifications" on page A.6. Check the machine's environment; very dry (low humidity) or high humidity (higher than 80% RH) conditions can increase the amount of background shading. Remove the old toner cartridge and install a new one. See "Installing the Toner Cartridge" on page 1.9.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 Clean the inside of the machine. See page 7.3. Check the paper type and quality. See "Paper Specifications" on page A.6. Remove the toner cartridge and install a new one. See "Installing the Toner Cartridge" on page 1.9.
Vertical repetitive defects AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	If marks repeatedly appear on the printed side of the page at even intervals: • The toner cartridge may be damaged. If a repetitive mark occurs on the page, print a cleaning sheet several times to clean the cartridge; see "Cleaning the Drum" on page 7.10. After the printout, if you still have the same problems, install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.9. • Parts of the machine may have toner on them. If the defects occur on the back of the page, the problem will likely correct itself after a few more pages. • The fusing assembly may be damaged. Contact a service representative.

Condition	Suggested solutions
Background scatter	 Background scatter results from bits of toner distributed on the printed page. The paper may be too damp. Try printing with a different batch of paper. Do not open packages of paper until necessary so that the paper does not absorb too much moisture. If background scatter occurs on an envelope, change the printing layout to avoid printing over areas that have overlapping seams on the reverse side. Printing on seams can cause problems. If background scatter covers the entire surface area of a printed page, adjust the print resolution through your software application or the printer properties.
Misformed characters AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 If characters are improperly formed and producing hollow images, the paper stock may be too slick. Try a different paper. See "Paper Specifications" on page A.6. If characters are improperly formed and producing a wavy effect, the scanner unit may need service. For service, contact a service representative.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 Ensure that the paper is loaded properly. Check the paper type and quality. See "Paper Specifications" on page A.6. Ensure that the paper or other material is loaded correctly and the guides are not too tight or too loose against the paper stack.
Curl or wave AaBbCC AaBbCC AaBbCC AaBbCC AaBbCC AaBbCC	 Ensure that the paper is loaded properly. Check the paper type and quality. Both high temperature and humidity can cause paper curl. See "Paper Specifications" on page A.6. Turn over the stack of paper in the paper tray. Also try rotating the paper 180° in the tray.

Condition	Suggested solutions
Wrinkles or creases Aal bCc Aal bCc AabbCc AabbCc AabbCc AabbCc AabbCc	 Ensure that the paper is loaded properly. Check the paper type and quality. See "Paper Specifications" on page A.6. Turn over the stack of paper in the paper tray. Also try rotating the paper 180° in the tray.
Back of printouts are dirty AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	Check for leaking toner. Clean the inside of the machine. See page 7.3.
Black pages	 The toner cartridge may not be installed properly. Remove the cartridge and reinsert. The toner cartridge may be defective and need replacing. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.9. The machine may require repair. Contact a service representative.
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 Clean the inside of the machine. See page 7.3. Check the paper type and quality. See "Paper Specifications" on page A.6. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.9. If the problem persists, the machine may require repair. Contact a service representative.
Character Voids	Character voids are white areas within the parts of characters that should be solid black: • If you are using transparencies, try another type of transparency. Because of the composition of the transparency, some character voids are normal. • You may be printing on the wrong surface on the paper. Remove the paper and turn it around. • The paper may not meet paper specifications. See "Paper Specifications" on page A.6.

Condition	Suggested solutions
AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc AaBbCc	 If horizontally aligned black streaks or smears appear: The toner cartridge may be installed improperly. Remove the cartridge and reinsert. The toner cartridge may be defective. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.9. If the problem persists, the machine may require repair. Contact a service representative.
AaBbCc AaBbCc AaBbCc	If the printed paper is curl or paper does not feed into the printer: • Turn over the stack of paper in the input tray. Also try rotating the paper 180° in the input tray.

Fax Problems

Condition	Suggested solutions		
The machine is not working, there is no display and the buttons are not working.	 Unplug the power cord and plug it in again. Ensure that there is power to the electrical receptacle. 		
No dial tone sounds.	 Check that the phone line is connected properly. Check that the phone socket in the wall is working by plugging in another phone. 		
The numbers stored in the memory do not dial correctly.	Make sure that the numbers are stored in the memory correctly. Print a Phone Book list, referring to the Facsimile Reference.		
The document does not feed into the machine.	 Make sure that the document is not wrinkled and you are putting it in correctly. Check that the document is the right size, not too thick or thin. Make sure that the ADF (Automatic Document Feeder) cover is firmly closed. 		
Faxes are not received automatically.	 The FAX mode should be selected. Make sure that there is paper in the tray. Check to see if the display shows "Memory Full." 		

Condition	Suggested solutions		
The machine does not send.	 Make sure that the document is loaded in the ADF or on the document glass. "TX" should show up on the display. Check the other fax machine you are sending to, to see if it can receive your fax. 		
The incoming fax has blank spaces or is received with a poor-quality.	 The fax machine sending you the fax may be faulty. A noisy phone line can cause line errors. Check your machine by making a copy. The toner cartridge may be empty. Replace the toner cartridge, referring to page 7.8. 		
Some of the words on a incoming fax are stretched.	The fax machine sending you the fax had a temporary document jam.		
There are lines on the documents you send.	Check your scan glass for marks and clean it. See page 7.5.		
The machine dials a number, but a connection with another fax machine fails.	The other fax machine may be turned off, out of paper, or cannot answer incoming calls. Speak with the other machine operator and ask her/him to sort out the problem.		
Documents are not stored in the memory.	There may not be enough memory to store the document. If the display shows a "Memory Full" message, delete any documents you no longer need from the memory and then restore the document.		
Blank areas appear at the bottom of each page or on other pages, with a small strip of text at the top.	You may have chosen the wrong paper settings in the user option setting. See page 1.18 for the paper tray and page 3.10 for the Bypass tray.		

Copying Problems

Condition	Suggested solutions		
Copies are too light or too dark.	Use the Contrast button to darken or lighten the background of the copies.		
Smears, lines, marks or spots appears on copies.	 If defects are on the original, press the Contrast button to lighten the background of your copies. If no defects are on the original, clean the document glass and underside of the document cover. See page 7.5. 		
Copy image is skewed.	 Ensure that the original is positioned correctly on document glass. Check that the copy paper is loaded correctly. 		
Blank copies print out.	Ensure that the original is face down on the document glass or face up in the Automatic Document Feeder.		
Image rubs off the copy easily.	 Replace the paper in the paper tray with paper from a new package. In high humidity areas, do not leave paper in the machine for the extended periods of time. 		
Frequent copy paper jams occurs.	 Fan the stack of paper, then turn it over in the paper tray. Replace the paper in the tray with a fresh supply. Check/adjust the paper guides, if necessary. Ensure that the paper is the proper paper weight. 75 g/m² (20 lb) bond paper is recommended. Check for copy paper or pieces of copy paper remaining in the machine after a paper jam has been cleared. 		
Fewer copies from the toner cartridge than expected prints out.	 Your originals may contain pictures, solids or heavy lines. For example, your originals may be forms, newsletters, books or other documents that use more toner. The machine may be turned frequently on and off. The document cover may be left open while copies are being made. 		

Scanning Problems

Condition	Suggested solutions
The scanner does not work.	 Make sure that you place the document to be scanned face down on the document glass, or face up in the Automatic Document Feeder. There may not be enough available memory to hold the document you want to scan. Try the Prescan function to see if that works. Try lowering the scan resolution rate. Check that the USB or parallel cable is connected properly. Make sure that the USB or parallel cable is not defective. Switch the cable with a known good cable. If necessary, replace the cable. If you are using a parallel cable, ensure that it is compliant with the IEEE 1284 standard. Check that the scanner is configured correctly or the application you want to use to make certain that the scanner job is being sent to the correct port, for example, LPT1.
The unit scans very slowly.	 Check if the machine is printing received data. Scan the document after the current job is completed. Graphics are scanned more slowly than text. Communication speed becomes slow in scan mode because of the large amount of memory required to analyse and reproduce the scanned image. Set your computer to the ECP printer mode through BIOS setting. It will help to increase the speed. For details about how to set BIOS, refer to your computer's Operating Instructions.

Condition	Suggested solutions
Message appears on your computer screen: • "Device can't be set to the H/W mode you want." • "Port is being used by another program." • "Port is Disabled. • "Scanner is busy receiving or printing data. When the current job is completed, try again." • "Invalid handle." • "Scanning has failed."	 There may be a copying or printing job in progress. When the current job is complete, try the job again. The Selected port is currently being used. Restart your computer and try again. The printer cable may be improperly connected or the power may be off. You must use a parallel cable that supports IEEE 1284 bi-directional communications. The scanner driver is not installed or an operating environment is not set up properly. Ensure that port is properly connected and power is on, Then restart your computer. Check, The USB cable may be improperly connected or the power may be off. Do not use the parallel and the USB cables at the same time.





SPECIFICATIONS

This chapter includes:

- General Specifications
- Scanner and Copier Specifications
- Printer Specifications
- Facsimile Specifications
- Paper Specifications

General Specifications

Item	Description		
Automatic document feeder	Up to 30 sheets (20 lb, 75 g/m²)		
ADF Document size	Width: 142 to 216 mm (5.6 to 8.5 inches) Length: 148 to 356 mm (5.8 to 14 inches)		
Paper input capacity	Paper tray: 250 sheets (weight: 75 g/m ² , 20 lb) Bypass tray: 1 sheet (weight: 60 \sim 163 g/m ² , 16 \sim 43 lb)		
Paper output capacity	Front output tray: 150 sheets (face down) Rear output slot: 1 sheet (face up)		
Paper type	Paper tray: Plain paper ($60 \sim 90 \text{ g/m}^2$, $16 \sim 24 \text{ lb}$) Bypass tray: Plain paper, Transparencies, Labels, Card, Post card, Envelopes ($60 \sim 163 \text{ g/m}^2$, $16 \sim 43 \text{ lb}$)		
Consumables	1-piece toner cartridge system		
Power requirements	100 ~ 127 VAC, 50/60 Hz, 4.5A 220 ~ 240 VAC, 50/60 Hz, 2.5A		
Power consumption	Sleep mode: 19 W Standby mode: 85 W(100 ~ 127 VAC) / 95 W(220 ~ 240 VAC Average: 350 W		
Noise	Warm-up: 50 dB Standby mode: 35 dB Printing: 55 dB		
Warm-up Time	42 seconds		
Operating conditions	Temperature: 50 °F to 89 °F (10 °C to 32 °C) Humidity: 20 % to 80 % RH		
LCD	16 characters x 2 lines		
Toner cartridge life	3,500 pages (for starter, 2,000 pages) @ IDC 5 % coverage		
SET dimension (W x D x H)	474 x 436 x 417 mm		
Weight	Net: 13 Kg (including consumables)		

Item	Description	
Package Weight	Paper: 2.7 Kg Plastic: 0.7 Kg	

Scanner and Copier Specifications

Item	Description		
Compatibility	TWAIN standard		
Scanning method	ADF and Flat-bed CCD (Charge Coupled Device) module		
Resolution	Optical: 600 dpi (Mono and colour)		
Effective scanning length	Platen: 293 mm (11.5 in.) ADF: 356 mm (14 in.)		
Effective scanning width	8.2 inches (208 mm)		
colour bit depth	Internal: 24 bit External: 24 bit		
Mono bit depth	1 bit for Text mode 8 bit for Gray mode		
Scan speed (Text mode)	Platen: 23 seconds ADF: 25 seconds		
Copy speed	Letter: 17 copies per minute A4: 16 copies per minute		
Copy resolution	Platen: 600 x 300 (Text, Mixed) / 600 x 600 (Photo) ADF: 600 x 300 (Text, Mixed, Photo)		
Zoom rate	Platen: 25 ~ 400 % ADF: 25 ~ 100 %		
Multiple copies	99 pages		
Gray scale	256 levels		

Printer Specifications

Item	Description		
Printing method	Laser Beam Printing		
Printing speed	Letter: 17 copies per minute		
Trinking opecu	A4: 16 copies per minute		
	Paper tray: Letter, A4, Legal, Folio, Executive, A5, B5, A6		
Paper size	Bypass tray: Letter, Legal, A4, Folio, Executive, A5, B5, A6, A6 card, Post Card 4x6, HagaKi, Envelope 7-3/4, Envelope 9, Envelope 10, Envelope DL, Envelope C5, Envelope C6, Envelope B5		
	* Min.: 76 x 127 mm (3 x 5 in.) Max.: 216 x 356 mm (8.5 x 14 in.)		
Print resolution	600 x 600 dpi		
Emulation	SPL (GDI)		
PC Interface	IEEE 1284 (ECP Only), USB 1.1		
Compatibility	Windows 95/98/2000/NT 4.0/Me/XP		
First printing time	Standby mode: 12 seconds		
	Power save mode: 54 seconds		

Facsimile Specifications

Item	Description		
Compatibility	ITU-T Group 3, ECM		
Applicable line	Public Switched Telephone Network (PSTN) or behind PABX		
Data coding	MH/MR/MMR (ECM Mode) and JPEG for colour fax transmission		
Modem speed	33600/31200/28800/26400/24000/21600/19200/ 16800/14400/12000/9600/7200/4800/2400 bps with fall back		
	Approx. 3 seconds/page		
Transmission speed	* Transmission time applies to memory transmission of text data with ECM compression using only ITU-T No.1 Chart.		
Scanning speed	Platen: approx. 6 seconds/A4 (at standard fax resolution mode)		
	ADF: approx. 8 seconds/A4 (at standard fax resolution mode)		
Maximum document length	Platen: 297 mm		
Traximani document length	ADF: 1.5 m		
Paper size	Letter, A4, Legal, Folio, Executive, B5		
	Standard: 203 x 98 dpi		
	Fine: 203 x 196 dpi		
Resolution	Super Fine: 300 x 300 dpi / 203 x 392 dpi		
	Photo: 203 x 196 dpi		
	Colour: 200 x 200 dpi		
User Memory	4 MB (320 pages)		
Halftone	256 levels		
Auto dialer	Speed dialling (registration for 100 numbers)		



Paper Specifications

Overview

Your machine accepts a variety of print materials, such as cut-sheet paper (including up to 100% recycled fiber content paper), envelopes, labels, transparencies and custom-size paper. Properties, such as weight, composition, grain and moisture content, are important factors affecting the machine's performance and the output quality. Paper that does not meet the guidelines outlined in this Reference can cause the following problems:

- · Poor print quality
- Increased paper jams
- Premature wear on the machine.



Notes:

- Some paper may meet all of the guidelines in this guide and still not produce satisfactory results. This may be the result of improper handling, unacceptable temperature and humidity levels, or other variables over which the manufacturer has no control.
- Before purchasing large quantities of paper, insure the paper meets the requirements specified in this Operating Instructions.



CAUTION: Using paper that does not meet these specifications may cause problems, requiring repairs. These repairs are not covered by the manufacturer's warranty or service agreements.

Supported Sizes of Paper

Paper	Dimensions*	Weight	Capacity**
Letter	8.5 X 11 in. (216 X 279 mm)	 60 to 90 g/m² bond (16 to 24 lb) for the paper tray 60 to 163 g/m² bond (16 to 43 lb) for the Bypass tray 	 250 sheets of 75 g/m² bond (20 lb) paper for the paper tray 1 sheet of paper for the Bypass tray
A4	210 X 297 mm (8.3 X 11.7 in.)		
Executive	7.25 X 10.5 in. (191 X 267 mm)		
Legal	8.5 X 14 in. (216 X 356 mm)		
B5	7.2 X 10 in. (182 X 257 mm)		
Folio	216 X 330 mm (8.5 X 13 in.)		
A5	148 X 210 mm (5.83 X 8.27 in.)		

Paper	Dimensions*	Weight	Capacity**
Minimum size (custom)	76 x 127 mm (3 x 5 in)	60 to 120 g/m ² bond (16 to 32 lb)	a 1 cheet of paper
Maximum size (Legal)	216 x 356 mm (8.5 x 14 in)		
Transparency	Same minimum and maximum paper sizes as listed above.	138 to 146 g/m ²	• 1 sheet of paper for the Bypass
Labels		120 to 150 g/m ²	tray
Cards		90 to 163 g/m ²	
Envelopes		75 to 90 g/m ²	

The machine supports a wide range of media sizes. See "Size, Input Sources and Capacities" on

^{**} Capacity may vary depending on print materials' weight and thickness, and environmental conditions.



NOTE: You may experience jams when using print materials with a length of less than 127 mm (5 in.). For optimum performance, ensure that you are storing and handling the paper correctly. Please refer to "Printer and Paper Storage Environment" on page A.9.

Guidelines for Using Paper

For the best result, use conventional 75 g/m 2 (20 lb) paper. Ensure that the paper is of good quality, and free of cuts, nicks, tears, spots, loose particles, dust, wrinkles, voids, and curled or bent edges.

If you are unsure of what type of paper you are loading, such as bond or recycled paper, check the label on the package.

The following problems may cause print quality deviations, jamming or even damage to the printer:

Symptom	Problem with Paper	Solution
Poor print quality or toner adhesion, problems with feeding	Too moist, too rough, too smooth or embossed; faulty paper lot	Try another kind of paper, between $100 \sim 400$ Sheffied, $4 \sim 5$ % moisture content.
Dropout, jamming, curl	Stored improperly	Store paper flat in its moisture-proof wrapping.
Increased gray background shading/printer wear	Too heavy	Use lighter paper, use the rear output slot.
Excessive curl problems with feeding	Too moist, wrong grain direction or short-grain construction	Use the rear output slot. Use long-grain paper.
Jamming, damage to printer	Cutouts or perforations	Do not use paper with cutouts or perforations.
Problems with feeding	Ragged edges	Use good quality paper.



Notes:

- Do not use letterhead paper printed with low-temperature inks, such as those used in some types of thermography.
- Do not use raised or embossed letterhead.
- The printer uses heat and pressure to fuse toner to the paper. Insure that any coloured paper or preprinted forms use inks that are compatible with this fusing temperature (200 °C or 392 °F for 0.1 second).

Paper Specifications

Category	Specifications
Acid Content	5.5 pH or lower
Caliper	0.094 ~ 0.18 mm (3.0 ~ 7.0 mils)
Curl in Ream	Flat within 5 mm (0.02 in.)
Cut Edge Conditions	Cut with sharp blades with no visible fray.
Fusing Compatibility	Must not scorch, melt, offset or release hazardous emissions when heated to 200 °C (392 °F) for 0.1 second.
Grain	Long Grain
Moisture Content	4 % ~ 6 % by weight
Smoothness	100 ~ 400 Sheffied

Paper Output Capacity

Output Location	Capacity
Face-down output tray	150 sheets of 75 g/m ² bond (20 lb) paper
Face-up output slot	1 sheet of 75 g/m² bond (20 lb) paper

Printer and Paper Storage Environment

Paper storage environmental conditions directly affect the feed operation.

Ideally, the machine and paper storage environment should be at or near room temperature, and not too dry or humid. Remember that paper is hygroscopic; it absorbs and loses moisture rapidly.

Heat works with humidity to damage paper. Heat causes the moisture in paper to evaporate, while cold causes it to condense on the sheets. Heating systems and air conditioners remove most of the humidity from a room. As paper is opened and used, it loses moisture, causing streaks and smudging. Humid weather or water coolers can cause the humidity to increase in a room. As paper is opened and used it absorbs any excess moisture, causing light print and dropouts. Also, as paper loses and gains moisture it can become distorted. This can cause paper jams.

Care should be taken not to purchase more paper than can be used in a short time (about 3 months). Paper stored for long periods may experience heat and moisture extremes, which can cause damage. Planning is important to prevent damage to large supplies of paper.

Unopened paper in sealed reams can remain stable for several months before use. Opened packages of paper have more potential for environment damage, especially if they are not wrapped with a moisture-proof barrier.

The paper storage environment should be properly maintained to ensure optimum performance. The required condition is 20 to 24 °C (68 to 75 °F), with a relative humidity of 45 % to 55 %. The following guidelines should be considered when evaluating the paper's storage environment:

- Paper should be stored at or near room temperature.
- The air should not be too dry or too humid.
- The best way to store an opened ream of paper is to rewrap it tightly in its moisture-proof wrapping. If the machine environment is subject to extremes, unwrap only the amount of paper to be used during the day's operation to prevent unwanted moisture changes.



INDEX

Numerics	load in ADF 4.4
2/4-up, special copy 4.11 2-side, special copy 4.10	load on document glass 4.2 document glass clean 7.5
A	load 4.2
ADF, load 4.4	drum, clean 7.10
auto fit, special copy 4.8	_
duto ne, special copy 4.0	E
В	error messages 8.11
bypass tray, use 3.8	F
C cancel	Favorite setting, use 5.6 fit to page copy 4.8
copy 4.3 print 5.5	print 5.11 front output tray, use 3.5
CCD power save mode, use 1.20 clone, special copy 4.9 collation, special copy 4.10 connection AC power 1.17	G graphic properties, set 5.20
parallel 1.16 telephone line cord 1.14 control panel 1.7	H help, use 5.6
copy contrast 4.6 default setting, change 4.13 from ADF 4.4 from document glass 4.2 resolution 4.6 special features 4.8	I install toner cartridge 1.9 Windows software 2.5 Installing 2.5
time out, set 4.14	J
display language, change control panel 1.18 document jam, clear 8.2	jam, clear document 8.2 paper 8.4

M	install in Windows 2.5	
memory, clear 7.2	printing	
- ,, · · · · ·	fitting to a selected paper size 5.11	
N	from Windows 5.2	
	multiple pages on one sheet 5.8	
network printer, set 5.22	posters 5.12	
n-up (multiple pages per sheet)	reduced or enlarged document	
copy 4.11	5.10	
print 5.8	using overlays 5.16	
	watermarks 5.13	
0	problem, solve	
orientation, print 5.3	copying 8.24	
output location, select 3.4	error messages 8.11	
overlay, use 5.16	fax 8.22	
0.0.0.0,7, 0.00 0.10	paper feeding 8.14	
P	printing 8.15	
	printing quality 8.18	
paper guidelines 3.3	scanning 8.25	
paper jam, clear 8.4		
paper level indicator 3.7	R	
paper load	rear output slot, use 3.5	
in bypass tray 3.8	reduced/enlarged	
in paper tray 1.11	copy 4.7	
paper load capacity 3.2	print 5.10	
paper properties, set 5.7	·	
paper size, set	S	
bypass tray 3.10		
paper tray 1.18	Safety information 1.ii	
print 5.7	scan driver	
paper source, set 5.8 paper type 3.2	install 2.5	
paper type, set	specifications facsimile A.5	
bypass tray 3.10	general A.2	
paper tray 1.18	_	
print 5.8	paper A.6 printer A.4	
parallel, connect 1.16	scanner and copier A.3	
poster	system requirements	
copy 4.12	Windows 2.4	
print 5.12	Willdows 2. I	
power save mode, use 1.19	T	
print order, set 5.3	Т	
print resolution 5.20	tel line, connect 1.14	
printer driver	toner cartridge	

install 1.9 life 7.6 redistribute 7.7 replace 7.8 TWAIN, scan 6.2 Type 101 driver install 2.5 U

USB connect 1.16 mode, change 8.17

W

watermarks, use 5.13

Z

zoom rate, copy 4.7

Operating Instructions **Facsimile Reference**

For safe and correct use of this machine, please be sure to read the Safety Information in this manual before you use it.

CONTENTS

GETTING STARTED
Control Panel Functions 1.2 Setting the Machine ID 1.4 Entering Characters Using the Number Keypad 1.5 Setting the Date and Time 1.7 Changing the Clock Mode 1.8 Setting Sounds 1.8 Speaker, Ringer, Key Sound and Alarm Sound 1.9 Speaker Volume 1.9 Setting the Dial Mode 1.10 Setting up the Fax System 1.11 Changing the Fax Setup options 1.11 Available Fax Setup Options 1.12
GENERAL FAX FUNCTIONS Sending a Fax

Chapter 3: AUTOMATIC DIALLING

	Sending a Fax using a Speed Number	
	Group Dialling	3.4 3.4
	(Multi-address Transmission)	3.7 3.7 3.7
Chapter 4:	OTHER WAYS TO FAX	
	Redialling Sending Broadcasting Faxes Sending a Delayed Fax Sending a Priority Fax Adding Documents To a Scheduled Fax Cancelling a Scheduled Fax	4.2 4.3 4.5 4.7
Chapter 5:	ADDITIONAL FEATURES	
	Using the Secure Receiving Mode	5.3 5.5 5.5 5.6




GETTING STARTED

The following topics are included:

- Control Panel Functions
- Setting the Machine ID
- Setting the Date and Time
- Setting Sounds
- Setting the Dial Mode
- Setting up the Fax System

Control Panel Functions



1	Facsimile	Allows you to enter fax number, and shows memory status and fax reception mode.
F A	Resolution	Adjusts the resolution of the documents for the current fax job.
C S I M	Broadcasting	Allows you to send a fax to multiple destinations.
I L E	Phone Book	 Allows you to store frequently-dialed fax numbers using a one or two-digit speed dial or group number for automatic dialling and edit the stored numbers. Allows you to print a Phone Book list.
	- *1	, ' '
	O Lighten O Normal O Darken	Adjusts the brightness of the documents for the current copy job. *1 This button is called "Contrast" in this manual.
2 C O	O Text O Mixed O Photo	Selects the document type for the current copy job. *2 This button is called "Image" in this manual.
P Y *3	Special	Allows you to use special copy features, such as Clone, Collation, Auto fit, 2-side, N-up (multiple pages on a sheet) and Poster copying.
	Reduce/Enlarge	Makes a copy smaller or larger than the original.

3	Displays the current status and prompts during an operation.				
	*	Turns on when the toner cartridge is empty.			
	4 6	Scrolls through the options available for the selected menu item.			
4	Enter	Confirms the selection on the display.			
_	Menu	Enters Menu Mode and scrolls through the menus available.			
	Upper Level	Sends you back to the upper menu level.			
5	Redial/Pause	Redials the last number in Standby Mode or insert a pause into a fax number in the edit mode.			
	On Hook Dial	Engages the telephone line.			
6		Dials a number or enters alphanumeric characters.			
7	Clear / Stop	Stops an operation at any time. In Standby Mode, clears/cancels the copy options, such as the contrast, the image setting, the copy size and the number of copies.			
	Start	Starts a job.			

 $^{^{\}ast 3}$ For details about copy features, refer to the Copy/Printer/Scanner Reference.

Setting the Machine ID

In some countries, you are required by law to indicate your fax number on any fax you send. The Machine ID, containing your telephone number and name (or company name), will be printed at the top of each page sent from your machine.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display. The first available menu item, "Machine Id" displays on the bottom line.
- 2 Press **Enter**. The display asks you to enter the fax number.



If there is a number already set, the number appears.

3 Enter your fax number using the number keypad.



NOTE: If you make a mistake while entering numbers, press the □ button to delete the last digit.

4 Press **Enter** when the number on the display is correct. The display asks you to enter the ID.



5 Enter your name or company name using the number keypad.

You can enter alphanumeric characters using the number keypad, and include special symbols by pressing the 0 button.

For details on how to use the number keypad to enter alphanumeric characters, see "Entering Characters Using the Number Keypad" on page 1.5.



Note: When "Id" is printed at the top of each page you transmit, only the first 20 digits can be printed on the pages received at the other end.

If you want to enter the same letter or number in succession (e.g. SS, AA, 777), enter one digit, move the cursor by pressing the ▷ button and enter the next digit.

If you want to insert a space in the name, you can also use the ▷ button to move the cursor to skip the position.

- **6** Press **Enter** when the name on the display is correct.
- **7** Press **Clear/Stop** to return to Standby Mode.


Entering Characters Using the Number Keypad

As you perform various tasks, you need to enter names and numbers. For example, when you set up your machine, you enter your name (or your company's name) and telephone number. When you store one or two digit speed dial or group dial numbers, you may also enter the corresponding names.

To enter alphanumeric characters:

When you are prompted to enter a letter, locate the button labeled with the character you want. Press the button until the correct letter appears on the display.

For example, to enter the letter O, press 6, labeled with "MNO."





You can enter special characters (space, plus sign, etc.). For details, see "Keypad Letters and Numbers" on page 1.6.

2 To enter additional letters, repeat Step 1.

If the next letter is printed on the same button, move the cursor by pressing the ▷ button and then press the button labeled with the letter you want. The cursor will move to the right and the next letter will appear on the display.

You can enter a space by pressing the # button.

3 When you finish entering letters, press **Enter**.

Keypad Letters and Numbers

Key	Ass	igne	ed n	umb	ers	let	ters	or	chai	racte	ers
1	1	Spa	ice								
2	Α	В	С	2							
3	D	Е	F	3							
4	G	Н	I	4							
5	J	K	L	5							
6	М	N	0	6							
7	Р	Q	R	S	7						
8	Т	U	V	8							
9	W	Х	Υ	Z	9						
0	+	-	,		`	/	*	#	&	0	

Changing Numbers or Names

If you make a mistake while entering a number or name, press the d button to delete the last digit or character. Then enter the correct numbers or characters.

Inserting a Pause

With some telephone systems, you must dial an access code (9, for example) and listen for a second dial tone. In such cases, you must insert a pause in the telephone number. You can insert a pause while you are setting up speed dial numbers.

To insert a pause, press **Redial/Pause** at the appropriate place while entering the telephone number. A "-" appears on the display at the corresponding location.

Setting the Date and Time

All of your faxes will have the date and time printed on them.



NOTE: If power to the machine is cut off, you need to reset the correct time and date once the power is restored.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- Press the scroll button (< or ▷) to display "Date & Time"</p> on the bottom line and press **Enter**.
- **3** Enter the correct time and date using the number keypad.

 $= 01 \sim 12$ Month $= 01 \sim 31$ Dav

Year = requires the four digits Hour $= 01 \sim 12 (12-hour mode)$ 00 ~ 23 (24-hour mode)

 $= 00 \sim 59$ Minute



NOTE: The date format may differ from each country.

You can also use the scroll button (\triangleleft or \triangleright) to move the cursor under the digit you want to correct and enter a new number.

4 To select "Am" or "Pm" for 12-hour format, press the * or # button.

When the cursor is not under the AM or PM indicator, pressing the * or # button immediately moves the cursor to the indicator.

You can change the clock mode to 24-hour format (e.g. 01:00 PM as 13:00). For details, see "Changing the Clock Mode" on page 1.8.

5 Press **Enter** when the time and date on the display is correct.

When you enter a wrong number, the machine beeps and does not proceed to the next step. If this happens, just reenter the correct number.

Changing the Clock Mode

You can set your machine to display the current time using either a 12-hour or 24-hour format.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- Press the scroll button (< or >) until you see "Clock Mode" on the bottom line and press Enter.

The clock mode currently set for the machine displays.

- **3** Press the scroll button (< or ▷) to select the other mode and then press **Enter** to save the selection.
- **4** To return to Standby Mode, press **Clear/Stop**.

Setting Sounds

You can control the following sounds:

- Ringer: You can adjust the ringer volume.
- Key Sound: With this option set to "On," a key tone sounds each time any key is pressed.
- Alarm Sound: You can turn the alarm sound on or off. With this option set to "On," an alarm tone sounds when an error occurs or fax communication ends.
- Speaker: You can turn on or off the sounds from the telephone line through the speaker, such as a dial tone or a fax tone. With this option set to "Comm.," the speaker is on until the remote machine answers.
- You can adjust the volume level using the On Hook Dial button.

Speaker, Ringer, Key Sound and **Alarm Sound**

- 1 Press **Menu** until "Sound/Volume" appears on the top line of the display.
- 2 Press the scroll button (< or ▷) to scroll through the options. Press **Enter** when you see the desired sound option.
- **3** Press the scroll button (\triangleleft or \triangleright) to display the desired status or loudness for the option you have selected.

You will see the selection on the bottom line of the display.

For the ringer volume, you can select from "Off", "Low", "Med" and "High". Setting "Off" means that the ringer turns off. The machine works normally even if the ringer is turned

- 4 Press **Enter** to save the selection. The next sound option appears.
- 5 If necessary, repeat steps 2 through 4.
- To return to Standby Mode, press Clear/Stop.

Speaker Volume

- 1 Press **On Hook Dial**. A dial tone sounds from the speaker.
- 2 Press the scroll button (< or ▷) until you hear the loudness you want. The display shows the current volume level.
- 3 Press **On Hook Dial** to save the change and return to Standby Mode.



NOTE: You can adjust the speaker volume only when the telephone line is connected.

Setting the Dial Mode

You can select the type of the telephone dial system where your machine is connected.



NOTE: The Dial Mode setting may be unavailable depending on your country.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- Press the scroll button (dor b) until you see "Dial Mode" on the bottom line and press Enter.
- **3** Press the scroll button (⊲ or ▷) to select the desired dial mode.

Select "Tone" if your machine is connected to a tone dial line.

Select "Pulse" if the machine is connected to a pulse dial line.

- **4** Press **Enter** to save the selection.
- 5 To return to Standby Mode, press **Clear/Stop**.

Setting up the Fax System

From the Fax Setup menu, you can configure many settings for the fax system.

Changing the Fax Setup options

- Press Menu until "Fax Setup" appears on the top line of the display.
 - The first available menu item, "Receive Mode," displays on the bottom line.
- 2 Press the scroll button (< or ▷) until you see the desired menu item on the bottom line and press Enter.
- 3 Use the scroll button (\triangleleft or \triangleright) to find the status or use the number keypad to enter the value for the option you have selected.
- 4 Press **Enter** to save the selection. The next Fax Setup option appears.
- 5 If necessary, repeat steps 2 through 4.
- **6** To return to Standby Mode, press **Clear/Stop**.

Available Fax Setup Options

Option	Description
Receive Mode	 You can select the default fax receiving mode. In the Fax mode, the machine answers an incoming call and immediately goes into the fax reception mode. In Tel mode, you can receive a fax by picking up the handset of the extension phone and then pressing the remote receive code (see page 2.9), or press On Hook Dial (you can hear voice or fax tone from the remote machine) and then pressing Start on the control panel of your machine. In Ans/Fax mode, the answering machine answers an incoming call, and the caller can leave a message on the answering machine. If the fax machine senses a fax tone on the line, the call automatically switches to Fax mode. In DRPD mode, you can receive a call using the Distinctive Ring Pattern Detection (DRPD) feature. This option is available only when you set up the DRPD Mode. For further details, see page 2.10.
Ring To Answer	You can specify the number of times the machine rings, 1 to 7, before answering an incoming call.
Contrast	You can select the default contrast mode to fax your documents lighter or darker. • Lighten works well with dark print. • Normal works well with standard typed or printed documents. • Darken works well with light print or faint pencil markings.
Redial Term	Your machine can automatically redial a remote fax machine if it was busy. Intervals from 1 to 15 minutes can be entered.
Redials	You can specify the number of redial attempts, 0 to 13. If you enter 0 , the machine will not redial.

Option	Description
MSG Confirm	You can set your machine to print a report showing whether the transmission was successful, how many pages were sent, and more. The available options are On , Off and On-Err , which prints only when a transmission is not successful.
Auto Report	A report with detailed information about the previous 50 communications operations, including time and dates. The available options are On or Off .
Auto Reduction	When receiving a document as long as or longer than the paper loaded in the paper tray, the machine can reduce the size of the document to fit the size of paper loaded in the machine. Select On if you want to automatically reduce an incoming page. With this feature set to Off , the machine cannot reduce the document to fit onto one page, the document is divided and printed in actual size on two or more pages.
Discard Size	When receiving a document as long as longer than the paper installed in your machine, you can set the machine to discard any excess at the bottom of the page. If the received page is outside the margin you set, it will print on two sheets of paper at the actual size. When the document is within the margin and the Auto Reduction feature is turned on, the machine reduces the document to fit it onto the appropriate sized paper and discard does not occur. If the Auto Reduction feature is turned off or fails, the data within the margin will be discarded. Settings range from 0 to 30 mm.

Option	Description
Receive Code	The Receive Code allows you to initiate fax reception from an extension phone plugged into the EXT jack on the back of the machine. If you pick up the extension phone and hear fax tones, enter the Receive Code. The Receive Code is preset to *9* at the factory. Settings range from 0 to 9. See page 2.9
DRPD Mode	You can receive a call using the Distinctive Ring Pattern Detection (DRPD) feature which enables a user to use a single telephone line to answer several different telephone numbers. In this menu, you can set the machine to recognize the ring patterns to answer. For details about this feature, see page 2.10.





GENERAL FAX FUNCTIONS

The following topics are included:

- Sending a Fax
- Receiving a Fax

Sending a Fax

Preparing Documents for Faxing

Use the following guidelines to prepare your documents for faxing:

- Do not load documents smaller than 142 x 148 mm or larger than 216 x 356 mm in the Automatic Document Feeder (ADF).
- Do not attempt to load the following types of documents into the ADF:
 - carbon-paper or carbon-backed paper
 - coated paper
 - onion skin or thin paper
 - wrinkled or creased paper
 - curled or rolled paper
 - torn paper
- Remove all staples and paper clips before loading documents in the ADF.
- Make sure any glue, ink or correction fluid on the paper is completely dry before loading documents in the ADF.
- Do not load documents containing different sizes or weights of paper in the ADF.
- If you want to make copies from booklets, pamphlets, transparencies or documents having other unusual characteristics, use the document glass to load the document.


Loading an Original Document

To fax a document using the Automatic **Document Feeder (ADF):**

1 Slide the document **face up** into the ADF. You can insert up to 30 sheets at a time.




2 Adjust the document guide on the ADF to match the width of the document.




To fax a document from the document glass:

1 Open the document cover.



2 Place the document face down on the document glass and align it with the registration guide on the top left corner of the glass.



3 Close the document cover.



Notes:

- If you are copying a page from a book or magazine, lift the cover until its hinges are caught by the stopper and then close the cover. If the book or magazine is thicker than 30 mm, start copying with the cover open.
- Make sure that no document is in the ADF. If any document is detected in the ADF, it has priority over the document on the document glass.
- To get the best scan quality, especially for coloured or gray scaled images, use the document glass.

Adjusting the Document Resolution

The default document settings produce good results when setting typical text based documents.

However, if you send documents that are of a poor quality, or contain photographs, you can adjust the resolution to produce a higher quality fax.

- 1 Press Resolution.
- **2** By pressing **Resolution** or the scroll button (< or >), you can choose from Standard, Fine, Super Fine, Photo and Color(Colour).
- **3** When the mode you want to use displays, press **Enter** to save the selection.

The document types recommended for the resolution settings are described in the table below.

Mode	Recommended for:
Standard	Documents with normal sized characters.
Fine	Documents containing small characters or thin lines or documents printed using a dot-matrix printer.
Super Fine	Documents containing extremely fine detail. The super fine mode is enabled only if the remote machine also supports the Super Fine resolution. See the notes below.
Photo	Documents containing shades of gray or photographs.

Mode	Recommended for:
Color(Colour)	Documents with colours. Sending a colour fax is enabled only if the remote machine supports colour fax reception and you send the fax manually. In this mode, the memory transmission is not available.



Notes:

- For the memory transmission, the super fine mode is not available. The resolution setting is automatically changed to Fine.
- When your machine is set to Super Fine resolution and the remote fax machine does not support the Super Fine resolution, the machine transmits using the highest resolution mode supported by the remote fax machine.

Sending a Fax Automatically

Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass. For details about loading a document, see page 2.2.

- 2 Press the Facsimile button.
- 3 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

4 Enter the remote fax phone number using the number keypad.

You can use one or two-digit speed or group dial numbers. For details, see Chapter 3, "Automatic Dialling."

- 5 Press Start.
- 6 When the document is loaded on the document glass, the display shows "Another Page?" on the top line after the document is scanned into the memory. If you have the next page, remove the scanned page and load the next page on the glass and select "1.Yes." Repeat as necessary.

After all of the pages are scanned, select "2.No" when the display shows "Another Page?."

7 The number is dialed and then the machine begins sending the fax when the remote fax machine is ready.



Note: When you want to cancel the fax job, press **Clear/Stop** at any time while sending the fax.

Sending a Fax Manually

Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

- 3 Press On Hook Dial. You hear a dial tone.
- 4 Enter the remote fax machine's fax number using the number keypad.
- 5 When you hear a high-pitched fax signal from the remote fax machine, press Start.



NOTE: When you want to cancel the fax job, press **Clear/Stop** at any time while sending the fax.

Confirming Transmission

When the last page of your document has been sent successfully, the machine beeps and returns to Standby Mode.

If something goes wrong while sending your fax, an error message appears on the display. For a listing of error messages and their meanings, see the Copy/Printer/Scanner Reference.

If you receive an error message, press **Clear/Stop** to clear the message and try to send the document again.

You can set your machine to print a confirmation report automatically each time sending a fax is completed. For further details, see the MSG Confirm item in "Available Fax Setup Options" on page 1.12.

Automatic Redialling

If the number you have dialed is busy or there is no answer when you send a fax, the machine will automatically redial the number every three minutes up to seven times by the factory default settings.

When the display shows "Retry Redial?," press **Enter** to redial the number without waiting. To cancel the automatic redialling, press Clear/Stop.

To change the time interval between redials and the number of redial attempts. See page 1.11.

Receiving a Fax

About Receiving Modes

- In the **Fax** mode, the machine answers an incoming fax call and immediately goes into the fax reception mode.
- In **Tel** mode, you can receive a fax by picking up the handset of the extension phone and then pressing the remote receive code (see page 2.9), or press **On Hook Dial** (you can hear voice or fax tone from the remote machine) and then pressing **Start** on the control panel of your machine.
- In **Ans/Fax** mode, the answering machine answers an incoming call, and the caller can leave a message on the answering machine. If the fax machine senses a fax tone on the line, the call automatically switches to Fax mode.
- In **DRPD** mode, you can receive a call using the Distinctive Ring Pattern Detection (DRPD) feature. "Distinctive Ring" is a telephone company service which enables a user to use a single telephone line to answer several different telephone numbers. For further details, see page 2.10.

When the memory is full, the receiving mode automatically switches to Tel.

For details about changing the receiving mode, see page 1.11.



Notes:

- To use the Ans/Fax mode, attach an answering machine to the EXT jack on the back of your machine.
- If you do not want other people to view your received documents, you can use the secure receiving mode. In this mode, all received faxes are stored in the memory. For further details, see page 5.2.

Loading Paper for Receiving Faxes

The instructions for loading paper in the paper tray are the same whether you are printing, faxing, or copying, except that faxes can only be printed on Letter-, A4- or Legal-sized paper. For details about loading paper and setting the paper size in the tray, refer to the Copy/Printer/Scanner Reference.

Receiving Automatically in the Fax Mode

Your machine is preset to the fax mode at the factory.

When you receive a fax, the machine answers the call on a specified number of rings and automatically receives the fax.

To change the number of rings, see "Available Fax Setup Options" on page 1.12.

If you want to adjust the ringer volume, see "Setting Sounds" on page 1.8.

Receiving Manually in the Tel Mode

You can receive a fax by picking up the handset of the extension phone and then pressing the remote receive code (see page 2.9), or press **On Hook Dial** (you can hear voice or fax tone from the remote machine) and then pressing **Start** on the control panel of your machine.

The machine begins receiving a fax and returns to Standby Mode when the reception is completed.

Receiving Automatically in the Ans/Fax Mode

For this mode, you must attach an answering machine to the EXT jack on the back of your machine.

If the caller leaves a message, the answering machine stores the message as it would normally. If your machine hears a fax tone on the line, it automatically starts to receive fax.



Notes:

- If you have set your machine to Ans/Fax mode and your answering machine is switched off, or no answering machine is connected to your machine, your machine will automatically go into Fax mode after a predefined number of rings.
- If your answering machine has a 'user-selectable ring counter', set the machine to answer incoming calls within 1 ring.
- If you are in Tel mode (manual reception) when the answering machine is connected to your machine, you must switch off the answering machine, or the outgoing message from the answering machine will interrupt your phone conversation.

Receiving Manually Using an Extension Telephone

This features works best when you are using an extension telephone connected to the EXT jack on back of your machine. You can receive a fax from someone you are talking to on the extension telephone without having to go to the fax machine.

When you receive a call on the extension phone and hear fax tones, press the keys "*9*" (star nine star) on the extension telephone.

The machine receives the document.

Press the buttons slowly in sequence. If you still hear the fax tone from the remote machine, try pressing "*9*" once again.

"*9*" is the remote receive code preset at the factory. The first and the last asterisks are fixed, but you can change the middle number to whatever you choose. For details on changing the code, see page 1.14.

Receiving Faxes Using the DRPD Mode

"Distinctive Ring" is a telephone company service which enables a user to use a single telephone line to answer several different telephone numbers. The particular number someone uses to call you on is identified by different ringing patterns, which consist of various combinations of long and short ringing sounds. This feature is often used by answering services who answer telephones for many different clients and need to know which number someone is calling in on to properly answer the phone.

Using the Distinctive Ring Pattern Detection feature, your fax machine can "learn" the ring pattern you designate to be answered by the FAX machine. Unless you change it, this ringing pattern will continue to be recognised and answered as a FAX call, and all other ringing patterns will be forwarded to the extension telephone or answering machine plugged into the EXT. jack. You can easily suspend or change Distinctive Ring Pattern Detection at any time.

Before using the Distinctive Ring Pattern Detection option, Distinctive Ring service must be installed on your telephone line by the telephone company. To set up Distinctive Ring Pattern Detection, you will need another telephone line at your location, or someone available to dial your FAX number from outside.

To set up the DRPD mode:

- 1 Press **Menu** until "Fax Setup" appears on the top line of the display.
 - The first available menu item, "Receive Mode," displays on the bottom line.
- Press the scroll button (dor b) until you see "DRPD Mode" on the bottom line and press Enter.
- 3 When "Set" displays on the bottom line, press **Enter**.
 - The LCD displays 'Waiting Ring."
- 4 Call your fax number from another telephone. It is not necessary to place the call from a fax machine.
- When your machine begins to ring, do not answer the call. The machine requires several rings to learn the pattern.
 - When the machine completes learning, the LCD displays "End DRPD Setup".
 - If the DRPD setup fails, "DRPD Ring Error" appears. Press **Enter** when "DRPD Mode" displays and retry from Step 3.

6 To return to Standby Mode, press **Clear/Stop**.

When the DRPD feature is set up, the DRPD option is available in the Receive Mode menu. To receive faxes in the DRPD mode, you need to set the menu to **DRPD**; see page 1.14.



Notes:

- DRPD must be set up again if you re-assign your fax number, or connect the machine to another telephone line.
- After DRPD has been set up, call your fax number again to verify that the machine answers with a fax tone. Then have a call placed to a different number assigned to that same line to be sure the call is forwarded to the extension telephone or answering machine plugged into the EXT. jack.

Receiving Faxes in the Memory

Since your machine is a multi-tasking device, it can receive faxes while you are making copies or printing. If you receive a fax while you are copying or printing, your machine stores incoming faxes in the memory. Then, as soon as you finish copying or printing, the machine automatically prints the faxes.





3

AUTOMATIC DIALLING

The following topics are included:

- Speed Dialling
- Group Dialling
- Searching for a Number in the Memory
- Printing a Phone Book List

Speed Dialling

You can store up to 100 frequently dialed numbers in one or two-digit speed dial locations (0-99).

Storing a Number for Speed Dialling

- 1 Press **Phone Book** on the control panel.
- **2** Press **Phone Book** or the scroll button $(\triangleleft \text{ or } \triangleright)$ to display "Store/Edit" on the bottom line of the display. Press **Enter**.
- 3 Press **Enter** when "Speed Dials" appears on the display.
- 4 Enter a one or two-digit speed dial number between 0 and 99, using the number keypad and press **Enter**.
 - If a number is already stored in the location you chose, the display shows the number to allow you to change it. To start over with another speed-dial number, press **Upper Level**.
- 5 Enter the number you want to store using the number keypad and press **Enter**.
 - To insert a pause between numbers, press **Redial/Pause** and a "-" appears on the display.
- **6** To assign a name to the number, enter the name. For details about how to enter names, see "Entering Characters Using the Number Keypad" on page 1.5.

OR

If you do not want to assign a name, skip this step.

- 7 Press **Enter** when the name appears correctly or without entering a name.
- 8 To store more fax numbers, repeat steps 4 through 7.

OR

To return to Standby Mode, press **Upper Level**.

Sending a Fax using a Speed Number

1 Feed the document(s) face up into the ADF.

Or

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

- 3 Enter the speed dial number.
 - For a one-digit speed dial number, press and hold the appropriate digit button.
 - For a two-digit speed dial number, press the first digit button and hold the last digit button.

The corresponding entry's name briefly displays.

4 The document scans into the memory.

When the document is loaded on the document glass, the LCD display asks if you want to send another page. Select "1.Yes" to add more documents or "2.No" to begin sending the fax immediately.

5 The fax number stored in the speed dial location is automatically dialed. The document is sent when the remote fax machine answers.

Group Dialling

If you frequently send the same document to several destinations, you can create a group of these destinations and set them under a one or two-digit group dial location. This enables you to use a group dial number setting to send the same document to all the destinations in the group.

Setting Group Dial

- 1 Press **Phone Book** on the control panel.
- 2 Press **Phone Book** or the scroll button (< or ▷) to display "Store/Edit" on the bottom line of the display. Press **Enter**.
- 3 Press the scroll button (< or ▷) to display "Group Dials" on the bottom line and press **Enter**.
- 4 Press **Enter** when "New" displays on the bottom line.
- 5 Enter a group number between 0 and 99 and press **Enter**.
- 6 Enter a one or two-digit speed number you want to include in the group and press **Enter**.
 - For a one-digit speed dial number, press and hold the appropriate digit button.
 - For a two-digit speed dial number, press the first digit button and hold the last digit button.
- 7 Repeat Step 6 to enter other speed dial numbers into the group.
- 8 Press **Upper Level** button when you have entered all of the desired numbers. The display prompts you to enter a group ID.
- 9 To assign a name to the group, enter the name.

OR

If you do not want to assign a name, skip this step.

- **10** Press **Enter** when the name appears correctly or without entering a name.
- 11 If you want to assign another group, repeat from Step 4.

OR

To return to Standby Mode, press **Clear/Stop**.



NOTE: You cannot include one group dial number in another group dial number.

Editing Group Dial Numbers

You can delete a specific speed dial number from a selected group or add a new number to the selected group.

- 1 Press **Phone Book** on the control panel.
- **2** Press **Phone Book** or the scroll button (\triangleleft or \triangleright) to display "Store/Edit" on the bottom line of the display. Press **Enter**.
- 3 Press the scroll button (< or ▷) to display "Group Dials" on the bottom line and press **Enter**.
- 4 Press the scroll button (< or >) to display "Edit" on the bottom line and press Enter.
- **5** Enter the group number you want to edit and press **Enter**. The display prompts you to enter a speed dial number.
- **6** Enter a speed dial number to be added or deleted.
- **7** When you enter the specific number from the group, the display shows "Delete?."

When you enter a new number, the display shows "Add?."

8 Press Enter.

Or

If you want to edit another group, repeat from Step 4.

To return to Standby Mode, press **Upper Level**.

Sending a Fax Using Group Dialling (Multi-address Transmission)

You can use group dialling for Broadcasting or Delayed transmissions.

Follow the procedure of the desired operation (Broadcasting transmission; see page 4.2, Delayed transmission; see page 4.3). When you come to a step in which the display asks you to enter the remote fax number:

- For a one-digit group number, press and hold the appropriate digit button.
- For a two-digit group number, press the first digit button and hold the last digit button.

You can use only one group number for one operation. Then continue the procedure to complete the desired operation.

Your machine automatically scans the document loaded in the Automatic Document Feeder or on the document glass into the memory. The machine dials each of the numbers included in the group.

Searching for a Number in the Memory

There are two ways to search for a number in the memory. You can either scan from A to Z sequentially, or you can search using the first letter of the name associated with the number.

Searching Sequentially through the Memory

- 1 Press Phone Book.
- 2 Press **Enter** when "Search/Dial" appears on the display.
- **3** Press the scroll button (< or ▷) to scroll through the memory until the name and number you want to dial display. You can search upwards or downwards through the entire memory in alphabetical order, from A to Z.
 - While searching through the machine's memory, you can see that each entry is preceded by one of two letters; "S" for speed dial or "G" for group dial number. These letters tell you how the number is stored.
- 4 When the name and/or the number you want displays, press **Start** or **Enter** to dial.

Searching with a Particular First Letter

- 1 Press Phone Book.
- Press Enter when "Search/Dial" appears on the display.
- 3 Press the button labeled with the letter you want to search for. A name beginning with the letter displays.
 - For example, if you want to find the name "MOBILE," press the **6** button, which is labeled with "MNO."
- **4** Press the scroll button (\triangleleft or \triangleright) to display the next name.
- 5 When the name and/or the number you want displays, press **Start** or **Enter** to dial.

Printing a Phone Book List

You can check your automatic dial setting by printing a Phone Book list.

- 1 Press Phone Book.
- 2 Press **Phone Book** or the scroll button (⊲ or ▷) until "Print" appears on the bottom line and press **Enter**.

A list showing your speed dial and group dial entries prints out.



OTHER WAYS TO FAX

The following topics are included:

- Redialling
- Sending Broadcasting Faxes
- Sending a Delayed Fax
- Sending a Priority Fax
- Adding Documents To a Scheduled Fax
- Cancelling a Scheduled Fax

Redialling

To redial the number you last called:

Press Redial/Pause.

When a document is loaded in the ADF (Automatic Document Feeder; see page 2.2), the machine automatically begins to send.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

Sending Broadcasting Faxes

Using the **Broadcasting** button on the control panel, you can use the broadcasting fax feature, which allows you to send a document to multiple locations. Documents are automatically stored in the memory and sent to a remote station. After transmission, the documents are automatically erased from the memory.

Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

- 3 Press Broadcasting on the control panel.
- 4 Enter the number of the remote machine using the number keypad.

You can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialling." 5 Press **Enter** to confirm the number. The display asks you to enter another fax number to send the document.



NOTE: Your machine can send one broadcasting fax to multiple destinations. The "Enter Number" prompt does not appear if a broadcast is set up and not completed. You must wait until the current broadcast is completed.

6 If you want to enter more fax numbers, repeat steps 4 and 5. You can add up to 10 destinations.

Note that you cannot use group dial numbers for another fax number.

7 When you finish entering fax numbers, press **Start**.

The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

8 The machine begins sending the document in order of the numbers you entered.

Sending a Delayed Fax

You can set your machine to send a fax at a later time when you will not be present.

Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.


- 3 Press **Menu** until "Fax Feature" appears on the top line of the display. The first available menu item, "Delay Fax," displays on the bottom line.
- 4 Press Enter.
- 5 Enter the number of the remote machine using the number keypad.

To enter the number, you can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialling."

- 6 Press **Enter** to confirm the number on the display. The display asks you to enter a name.
- **7** If you want to assign a name to the transmission, enter the name. If not, skip this step.

For details on how to enter the name using the number keypad, see "Entering Characters Using the Number Keypad" on page 1.5.

8 Press **Enter**. The display shows the current time and asks you to enter the start time when the fax is to be sent.



9 Enter the time using the number keypad.

To select "Am" or "Pm" for 12-hour format, press the \star or \sharp button.

If you set a time earlier than the current time, the document will be sent at that time on the following day.

- **10** Press **Enter** when the start time displays correctly.
- 11 The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

12 The machine returns to Standby Mode. The display reminds you that you are in Standby Mode and that a delayed fax is set.



NOTE: If you want to cancel the delayed transmission, see "Cancelling a Scheduled Fax" on page 4.8.

Sending a Priority Fax

Using the Priority Fax feature, a high priority document can be sent ahead of reserved operations. The document is scanned into the memory and transmitted when the current operation is finished. In addition, the priority transmission interrupts a broadcast operation between stations (i.e., when the transmission to station A ends, before transmission to station B begins) or between redial attempts.

1 Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

- 3 Press **Menu** until "Fax Feature" appears on the top line of the display.
- 4 Press the scroll button (< or ▷) to display "Priority Fax" on the bottom line and press **Enter**.
- 5 Enter the number of the remote machine using the number keypad.

To enter the number, you can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialling."

- 6 Press **Enter** to confirm the number. The display asks you to enter a name.
- 7 If you want to assign a name to the transmission, enter the name. If not, skip this step.

For details on how to enter a name using the number keypad, see "Entering Characters Using the Number Keypad" on page 1.5.

8 Press Enter.

The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

9 The machine shows the number being dialed and begins sending the document.

Adding Documents To a Scheduled Fax

You can add documents to the delayed transmission previously reserved in your machine's memory.

Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.12.

- 3 Press **Menu** until "Fax Feature" appears on the top line of the display.
- 4 Press the scroll button (< or ▷) to display "Add/Cancel" on the bottom line and press **Enter**.
- 5 Press **Enter** when "Add Page" displays on the bottom line. The display shows the last job reserved in the memory.
- 6 Press the scroll button (< or >) until you see the fax job to which you want to add documents and press **Enter**.

The machine automatically stores the documents in the memory, and the display shows the memory capacity and the number of pages.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

7 After storing, the machine displays the numbers of total pages and added pages and then returns to Standby Mode.

Cancelling a Scheduled Fax

- 1 Press **Menu** until "Fax Feature" appears on the top line of the display.
- 2 Press the scroll button (⊲ or ▷) to display "Add/Cancel" on the bottom line and press **Enter**.
- 3 Press the scroll button (⊲ or ▷) to display "Cancel Job" and press **Enter**. The display shows the last job reserved in the memory.
- **4** Press the scroll button (⊲ or ▷) until you see the fax job you want to cancel, and press **Enter**.
 - The selected job is canceled and the machine returns to Standby Mode.



ADDITIONAL FEATURES

The following topics are included:

- Using the Secure Receiving Mode
- Printing Reports
- Using Advanced Fax Settings
- Using the Remote Control Panel

Using the Secure Receiving Mode

You may need to prevent your received faxes from being accessed by unauthorised people. You can turn on the secure fax mode using the Secure Receive option to restrict printing out all of the received faxes when the machine is unattended. In the secure fax mode, all incoming faxes will go in the memory. When the mode turns off, any faxes stored will be printed.

To turn the secure receiving mode on:

- 1 Press **Menu** until "Advanced Fax" appears on the top line of the display.
- Press the scroll button (

 or

) until "Secure Receive" appears on the bottom line and press **Enter**.
- 3 Press the scroll button (< or ▷) to display "On" on the</p> bottom line and press Enter.
- 4 Enter a four-digit passcode you want to use, using the number keypad and press Enter.



NOTE: You can use the secure receiving mode without setting a passcode, but cannot protect your faxes.

5 To return to Standby Mode, press Clear/Stop.

When a fax is received in the secure receiving mode, your machine stores it into the memory and displays "Secure Receive" to let you know that there is a fax stored.

To print received documents:

- 1 Access the **Secure Receive** menu by following steps 1 and 2 above.
- 2 Press the scroll button (< or ▷) to display "Print" on the bottom line and press Enter.
- **3** Enter the four-digit passcode and press **Enter**.

The faxes stored in the memory are printed all together.

To turn the secure receiving mode off:

- 1 Access the **Secure Receive** menu by following steps 1 and 2 in "To turn the secure receiving mode on:" on page 5.2.
- 2 Press the scroll button (< or ▷) to display "Off" on the bottom line and press Enter.
- 3 Enter the four-digit passcode and press **Enter.**
 - The mode is deactivated and the faxes stored in the memory are printed all together.
- 4 To return to Standby Mode, press **Clear/Stop**.

Printing Reports

Your machine can print reports containing useful information. The following reports are available:

Phone Book List

This list shows all of the numbers currently stored in the machine's memory as speed dial and group dial numbers.

You can print this Phone Book list using the **Phone Book** button; see page 3.8.

Sent Fax Report

This report shows information of the faxes you recently sent.

Received Fax Report

This report shows information of the faxes you recently received.

System Data List

This list shows the status of the user-selectable options. You may print this list to confirm your changes after changing any settings.

Scheduled Job Information

This list shows the document currently stored for Delayed faxes. The list shows the starting time and type of operation.

Message Confirmation

This report shows the fax number, the number of pages, the elapsed time of the job, the communication mode, and the communication results.

You can set up your machine to automatically print the message confirmation report after each fax job. See page 1.13.

Junk Fax Number List

This list shows up to 10 fax numbers specified as the junk fax numbers by using the **Junk Fax Setup** menu; see page 5.6. When the Junk Fax Barrier feature is turned on, incoming faxes from those numbers will be blocked.

This feature recognise the last 6 digits of the fax number set as a remote fax machine's ID.

Multi-Communication Report

This report is printed automatically after sending documents from more than one location.

Power Failure Report

This report is printed out automatically when power is restored after a power failure, if there occurs any data loss due to the power failure.



NOTE: The lists you have set to print out automatically don't print out when there is no paper loaded or a paper jam has occurred.

Printing a Report

- 1 Press **Menu** until "Reports" appears on the top line of the display. The first available menu item, "Phone Book" displays on the bottom line.
- Press the scroll button (

 or

) to display the report or list you want to print on the bottom line.
 - Phone Book: Phone Book list.

• Sent Report: Sent fax report

• RCV Report: Received fax report

System Data: System data list

Scheduled Jobs: Scheduled job information

• MSG Confirm: Message confirmation

• Junk Fax List: Junk fax number list

3 Press Enter.

The selected information prints out.

Using Advanced Fax Settings

Your machine has various user-selectable setting options for sending or receiving faxes. These options are preset at the factory, but you may need to change them. To find out how the options are currently set, print the System Data list. For details about printing the list, see "Printing Reports" on page 5.3.

Changing Setting Options

- 1 Press **Menu** until "Advanced Fax" appears on the top line of the display. The first available menu item, "Send Forward," displays on the bottom line.
- 2 Press the scroll button (< or ▷) until you see the desired menu item on the bottom line and press **Enter**.
- **3** When the option you want appears on the display, choose the desired status by pressing the scroll button (\triangleleft or \triangleright) or enter the desired value using the number keypad.
- 4 Press **Enter** to save the selection.
- 5 You can exit from the setup mode at any time by pressing Clear/Stop.

Advanced Fax Setting Options

Option	Description
Send Forward	You can set the machine to always forward all of the outgoing faxes to the specified destination besides the fax numbers you entered. Select Off to turn this feature off. Select On to turn this feature on. You can set the number of the remote fax machine to which faxes are forwarded.
RCV Forward	You can set your machine to forward incoming faxes to another fax number during a specified time period. When a fax arrives at your machine, it is stored in the memory. Then, the machine dials the fax number that you have specified and sends the fax. Select Off to turn this feature off. Select On to turn this feature on. You can set the fax number to which faxes are forwarded. Then, you can enter the start time and/or the end time. The Print Local Copy option allows you to set the machine to print the fax, if fax forwarding is completed with no error.
Junk Fax Setup	Using the Junk Fax Barrier feature, the system will not accept faxes sent from remote stations of which their numbers are stored in the memory as junk fax numbers. This feature is useful for blocking any unwanted fax. Select Off to turn the feature off. Anybody can send you a fax. Select On to turn the feature on. You can set up to 10 fax numbers as junk fax numbers. After storing numbers, you do not receive any faxes from the registered stations.
Secure Receive	You can keep your received faxes from being accessed by unauthorised people. For further details about setting this mode, see page 5.2.
Prefix Dial	You can set a prefix dial number of up to five digits. This number dials before any auto dial number is started. It is useful for accessing the PABX exchange.

Option	Description
Stamp RCV Name	This option allows the machine to automatically print the page number, and the date and time of the reception at the bottom of each page of a received document. Select Off to turn this feature off. Select On to turn this feature on.
ECM Mode	The Error Correction Mode helps with poor line quality and makes sure any fax you send are sent smoothly to any other ECM-equipped fax machine. If the line quality is poor, it takes more time to send a fax when you are using the ECM mode. Select Off to turn this feature off. Select On to turn this feature on.

Using the Remote Control Panel

Using the Remote Control Panel, you can set up fax system data options, create and edit Phonebook entries or view information of your machine on the desktop window of your computer.


When you install the software, the Remote Control Panel program is automatically installed.

For information about installing the software, please refer to the Copy/Printer/Scanner Reference.

To open the Remote Control Panel:

- **1** Start your Windows.
- 2 Click the Start button on your desktop computer.

3 From **Programs**, select **Type 101** and then **Remote Control Panel.**



Then the Remote Control Panel program opens.


4 The Remote Control Panel window provides five tabs; Settings, Advanced, Phonebook, Information, and Firmware Update.

To exit, click the **Exit** button at the bottom of each tab.

For further details, click the **Help** button at the bottom of each tab.

The Settings Tab

Click the **Settings** tab to configure fax system settings.




Reads the current settings in your machine and refreshes the Remote Control Panel with them.

Downloads the settings made in Remote Control Panel to your machine.

The Advanced Tab

Click the **Advanced** tab to configure advanced fax system settings.




Reads the current settings in your machine and refreshes the Remote Control Panel with them.

Downloads the settings made in Remote Control Panel to your machine.


The Phonebook Tab

Click the **Phonebook** tab to create and edit Phonebook entries.



The Information Tab


Click the **Information** tab to view the software version information and many counters which allow you to check how many scanning, printing, and jamming are made in your machine.



Reads the current information in your machine and refreshes the Remote Control Panel.

The Firmware Update Tab

Click the **Firmware Update** tab to update the firmware of your machine. This feature should be used by an authorized technician. Please consult with the purchase point.





INDEX

A	editing 3.5
add documents 4.7	setting 3.4
ADF, load 2.2	
automatic dialling	M
group 3.4	machine ID, set 1.4
speed 3.2	
automatic redialling 2.7	P
В	paper, load 2.8
_	print
broadcasting faxes 4.2	Phone Book list 3.8
	reports 5.3
C	priority fax 4.5
cancelling	_
fax 2.6	R
scheduled faxes 4.8	receive a fax
characters, enter 1.5	in Ans/Fax mode 2.9
contrast, set 1.12	in fax mode 2.8
control panel 1.2	in secure receiving mode 5.2
_	in tel mode 2.8
D	in the memory 2.11
date and time, set 1.7	receive mode, set 1.12 redial, last number 4.2
delayed fax 4.3	Remote Control Panel 5.7
document	reports, print 5.3
load	resolution, set 2.4
ADF 2.2 document glass 2.3	·
prepare 2.2	S
document glass, load 2.3	
<i>5</i> ,	search, a number 3.7 secure receiving mode, use 5.2
F	send a fax
	automatically 2.5
fax system, set advanced settings 5.5	manually 2.6
options 1.12	sounds, set 1.8
Option3 1:12	speed dial
G	dialling 3.3
	storing 3.2
group dial	
dialling 3.6	

