

Operating Instructions **General Settings Guide**



- 1 Getting Started
- 2 Combined Function Operations
- 3 Document Server
- 4 User Tools (System Settings)
- 5 Troubleshooting
- 6 Remarks
- 7 Entering Text
- 8 Security
- 9 Specifications

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Notes:

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Operator Safety:

This machine is considered a Class 1 laser device, safe for office/EDP use. The machine contains five AlGalnp laser diodes, 7-milliwatt, 645-660 nanometer wavelength for each emitter. Direct (or indirect reflected) eye contact with the laser beam might cause serious eye damage. Safety precautions and interlock mechanisms have been designed to prevent any possible laser beam exposure to the operator.

The following label is attached on the back side of the machine.



Laser Safety:

The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified customer engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

Warning:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Notes:

The model names of the machines do not appear in the following pages. Check the type of your machine before reading this manual. (For details, see P.14 "Machine Types".)

- Type 1: Aficio 2232C
- Type 2: Aficio 2238C

Certain types might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

For good copy quality, Ricoh recommends that you use genuine Ricoh toner.

Ricoh shall not be responsible for any damage or expense that might result from the use of parts other than genuine Ricoh parts with your Ricoh office products.

Power Source

220-240V, 50/60Hz, 8A or more

Please be sure to connect the power cord to a power source as shown above. For details about power source, see P.141 "Power Connection".

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1 "Operating Instructions for Printer/Scanner"
 - CD-ROM 2 "Scanner Driver & Document Management Utilities"

General Settings Guide (this manual)

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

♦ Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference < Basic Features >

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference <Advanced Features>

Describes advanced functions, and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] display when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview
 of its functions. This guide is added to the [Start] menu when DeskTop Binder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] display when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an
 overview of ScanRouter V2 Lite functions. This guide is added to the [Start]
 menu when ScanRouter V2 Lite is installed.

Other manuals


- PS3 Supplement (PDF file CD-ROM1)
- Unix Supplement (Available from an authorized dealer, or as a PDF file on our Web site.)

What You Can Do with This Machine

The following introduces the functions of this machine, and the relevant manuals containing detailed information about them.

Products marked with * are optional. For details about optional products, see p.165 "Options", or contact your local dealer.


Copier, Facsimile, Printer, and Scanner Functions



This machine provides copier, facsimile*, printer, and scanner functions.

- You can make copies of originals.
 With a finisher*, you can sort and staple copies. See Copy Reference.
- You can send originals by fax and receive faxes from other parties.
 See Facsimile Reference <Basic Features> , and Facsimile Reference <Advanced Features>.
- You can print documents created using applications. See *Printer Reference 1*, *Printer Reference 2*.
- You can scan originals and send the scan file to a computer. See Scanner Reference.


Utilizing Stored Documents



- You can store file from originals scanned by this machine, or file sent from other computers, into the machine's hard disk. You can print and fax stored documents as required. You can also change print settings and print multiple documents (Document Server).
 See p.33 "Using the Document Server".
- With DeskTopBinder V2 Professional*/Lite, you can search, check, print, and delete stored documents using your computer. You can also retrieve stored documents scanned in scanner mode. With File Format Converter*, you can even download documents stored in copy and printer functions to your computer. See Network Guide.


Paperless Fax Transmission and Reception

Reception




You can store received fax messages on the machine's hard disk, instead of printing them onto paper. You can use DeskTopBinder V2 Professional*/Lite or a Web browser to check, print, delete, retrieve, or download documents using your computer (Storing received documents). See Facsimile Reference < Advanced Features>.

Transmission



 You can send documents created using applications to another party's fax machine directly, without performing a print job (LAN-Fax).
 See Facsimile Reference < Advanced Features>.


Fax Transmission and Reception Through the Internet



You can send fax documents through e-mail by specifying the recipient's email address (Internet Fax Transmission).

You can receive sent documents via Internet Fax, or from computers (Internet Fax Reception). See Facsimile Reference <Basic Features>.


Using the Scanner in a Network Environment



 You can send scanned documents to other network computers using e-mail (Sending stored scan file by e-mail). See Scanner Reference.

- With ScanRouter V2 Professional*/Lite, you can save scanned documents in specified destinations on network computers (File storage). See Scanner Reference.
- You can send scanned documents to other network folders (Scan to Folder). See Scanner Reference

Administrating the Machine/Protecting Documents (Security Functions)



The security functions protect documents from being copied without permission or unauthorized access via the network. See p.155 "Security".


Security Functions

- Protecting stored documents (setting passwords)
- Protecting file remaining in memory
- Protecting against unauthorized access via phone line
- Authenticating administrator (setting the key operator code).
 See p.58 "Key Operator Code".

Extended Security Function

By setting a password, documents are protected against unauthorized access. See p.59 "Extended Security".

Monitoring the Machine Via Computer



You can monitor machine status and change settings using a computer.

- Using SmartNetMonitor for Admin, SmartNetMonitor for Client, or a Web browser, you can use a computer to view the machine's status, such as to check on paper quantities, or misfeeds, etc. See Network Guide.
- You can also use a Web browser to make network settings. See Network Guide.
- You can also use a Web browser to register and manage items such as user codes, fax numbers, e-mail addresses, and folders in the Address Book. See the Web browser's Help.

TABLE OF CONTENTS

| Manuals for This Machine | i |
|--|----------|
| What You Can Do with This Machine | iii |
| Copier, Facsimile, Printer, and Scanner Functions | iii |
| Utilizing Stored Documents | iii |
| Paperless Fax Transmission and Reception | iv |
| Fax Transmission and Reception Through the Internet | iv |
| Using the Scanner in a Network Environment | |
| Administrating the Machine/Protecting Documents (Security Functions) | v |
| Monitoring the Machine Via Computer | v |
| Notice | 1 |
| Copyrights and Trademarks | 2 |
| Trademarks | |
| Information about Installed Software | 3 |
| How to Read This Manual | |
| Safety Information | |
| Safety During Operation | |
| Positions of Labels and Hallmarks for ⚠WARNING and ⚠CAUTION | |
| | |
| ENERGY STAR Program | |
| Machine Types | 14 |
| 1 Calling Started | |
| 1. Getting Started | |
| Guide to Components | 15 |
| External Options | |
| Internal Options | |
| Control Panel | 19 |
| Display Panel | |
| Turning On the Power | |
| Turning On the Main Power | |
| Turning On the Power | |
| Turning Off the Power | |
| Turning Off the Main Power | |
| Saving Energy | |
| 3 3, | |
| 2. Combined Function Operations | |
| Changing Modes | |
| Changing Modes | ∠ə 27 |
| MIIITI-ACCESS | 7/ |

3. Document Server

| Relationship between Document Server and Other Functions | 31 |
|--|-------------------------------------|
| Document Server Display | 32 |
| Using the Document Server | 33 |
| Storing Data | |
| Changing a Stored Document's File Name, User Name, or Password | |
| Selecting a Document | 36 |
| Searching for Stored Documents | 37 |
| Printing Stored Documents | |
| Deleting Stored Documents | |
| Viewing Stored Documents Using a Web Browser | |
| Downloading Stored Documents | |
| Settings for the Document Server | 43 |
| 4. User Tools (System Settings) | |
| User Tools Menu (System Settings) | 45 |
| Accessing User Tools (System Settings) | 48 |
| Changing Default Settings | 48 |
| Exiting User Tools | |
| Settings You Can Change with User Tools | 49 |
| General Features | |
| Tray Paper Settings | |
| Timer Settings | |
| Key Operator Tools | |
| Address Book | 66 |
| User Name | |
| | |
| Registering a User Name | |
| Changing a User Name | 70 |
| Changing a User Name Deleting a User | 70 70 |
| Changing a User Name Deleting a User User Code | 70 70 71 |
| Changing a User Name Deleting a User User Code Registering a New User Code | 70 70 71 71 |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code | 70 7 0 71 71 |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code | 70 71 7172 |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code | 70 71 717273 |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code | 7071717373 |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code Clearing the Number of Prints | |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code Clearing the Number of Prints Fax Destination | |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code Clearing the Number of Prints Fax Destination Registering a Fax Destination | |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code Clearing the Number of Prints Fax Destination Registering a Fax Destination Changing a Registered Fax Destination | |
| Changing a User Name Deleting a User User Code Registering a New User Code Changing a User Code Deleting a User Code Displaying the Counter for Each User Code Printing the Counter for Each User Code Clearing the Number of Prints Fax Destination Registering a Fax Destination Changing a Registered Fax Destination Deleting a Registered Fax Destination | |
| Changing a User Name Deleting a User User Code | |
| Changing a User Name Deleting a User User Code | |
| Changing a User Name Deleting a User | |
| Changing a User Name Deleting a User | |
| Changing a User Name Deleting a User | |
| Changing a User Name Deleting a User | |

| Registering a Protection Code | |
|---|------------|
| Registering a Protection Code To a Single User | |
| Registering a Protection Code To a Group User | |
| Registering Destinations to a Group | |
| Registering a New Group | |
| Registering Destinations to a Group | |
| Removing a Destination from a Group | |
| Displaying Destinations Registered in Groups | |
| Deleting a Group Marie | |
| Registering the Transfer Request | |
| Registering a Transfer Station/Receiving Station | |
| Changing a Registered Transfer Station/Receiving Station | |
| Deleting a Registered Transfer Station/Receiving Station | 99 |
| Programming/Changing LDAP Server | |
| Programming an LDAP Server | 101 101 |
| Changing an LDAP Server | |
| Changing an ED/a Convolument | |
| 5. Troubleshooting | |
| If Vous Machine Dace Not Onesete As Vou Wort | 105 |
| If Your Machine Does Not Operate As You Want | |
| Document Server | |
| Maintenance | _ |
| Loading Paper | |
| Loading Paper into Paper Trays and Paper Tray Unit | 109 |
| Loading Paper into Large Capacity Tray (optional) | |
| Adding Toner | |
| Inserting Toner | |
| % Clearing Misfeeds | |
| Changing the Paper Size | |
| Changing the Paper Size of the Paper Tray | |
| If you load a paper size that is not selected automatically | 123 |
| Adding Staples | |
| 2 Tray Finisher | |
| Booklet Finisher | |
| Removing Jammed Staples | 127 |
| 2 Tray Finisher | |
| Booklet Finisher | |
| ■ Removing Punch Waste | |
| 2 Tray Finisher | |
| Booklet Finisher | 130 |
| Adjusting the Colour Registration | 131 |
| Auto Colour Registration | 131 |
| Fuser Adjustment for Thick Paper | 132 |
| Checking the Fuser Adjustment Sheet | 134 |
| Auto Colour Calibration | 135 |
| | |

6. Remarks

| Dos and Don'ts | 137 |
|---|-----|
| Saving Colour Copies | 138 |
| Toner | 139 |
| Handling Toner | |
| Toner Storage | 139 |
| Used Toner | 139 |
| Where to Put Your Machine | 140 |
| Machine Environment | |
| Moving | |
| Power Connection | |
| Access to the Machine | |
| Maintaining Your Machine | |
| Cleaning the Exposure Glass | |
| Cleaning the Exposure Glass Cover | |
| Cleaning the Auto Document Feeder | |
| Cleaning the Dustproof Glass | 144 |
| Replacing the Fuser Oil Unit | 145 |
| Replacing the Waste Toner Bottle | |
| Other Functions | |
| | |
| Counter | |
| Displaying the Total Counter | |
| Displaying the Total Odditel | 102 |
| 7. Entering Text | |
| Entering Text | 153 |
| Available Characters | |
| Keys | 153 |
| How to Enter Text | |
| 8. Security | |
| Security | 155 |
| Primary Security Functions | |
| Extended Security Function | |
| Temporarily Disabling Document Security | |
| Operating Environment and Notes | |
| Operating Environment | |
| For Administrator | |
| For User | |

9. Specifications

| Main Unit | 161 |
|-----------------------------------|-----|
| Options | 165 |
| Exposure Glass Cover | 165 |
| Auto Document Feeder | 165 |
| 2 Tray Finisher | |
| Punch Kit (2 tray finisher) | |
| Booklet Finisher | 168 |
| Punch Kit (Booklet finisher) | 169 |
| 1 Tray Paper Unit | 170 |
| 2 Tray Paper Unit | 170 |
| Large Capacity Tray | 171 |
| Copy Paper | 172 |
| Recommended Paper Sizes and Types | 172 |
| Unusable Paper | 174 |
| Paper Storage | 175 |
| NDEX | 176 |

Notice

Notice To Wireless LAN Interface (optional) Users

((0)

Notice to Users in EEA Countries

This product complies with the essential requirements and provisions of Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

The CE Declaration of Conformity is available on the Internet at URL:

http://www.ricoh.co.jp/fax/ce_doc/.

This product is only for use in EEA or other authorized countries. Outdoor use of this product in Belgium, France, Germany, Italy, or the Netherlands is prohibited.

Copyrights and Trademarks

Trademarks

Microsoft®, Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Acrobat® is a registered trademark of Adobe Systems Incorporated.

Bluetooth $^{\text{TM}}$ is a trademark of the Bluetooth SIG, Inc. (Special Interest Group) and is used by RICOH Company Limited under license.

Copyright ©2001 Bluetooth SIG, Inc.

The Bluetooth Trademarks are owned by Bluetooth SIG, Inc. USA

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

The proper names of the Windows operating systems are as follows:

- The product name of Windows® 95 is Microsoft® Windows® 95
- The product name of Windows® 98 is Microsoft® Windows® 98
- The product name of Windows® Me is Microsoft® Windows® Millennium Edition (Windows Me)
- The product names of Windows[®] 2000 are as follows: Microsoft[®] Windows[®] 2000 Advanced Server Microsoft[®] Windows[®] 2000 Server Microsoft[®] Windows[®] 2000 Professional
- The product names of Windows[®] XP are as follows: Microsoft[®] Windows[®] XP Professional Microsoft[®] Windows[®] XP Home Edition
- The product names of Windows ServerTM 2003 are as follows: Microsoft[®] Windows ServerTM 2003 Standard Edition Microsoft[®] Windows ServerTM 2003 Enterprise Edition Microsoft[®] Windows ServerTM 2003 Web Edition
- The product names of Windows[®] NT are as follows: Microsoft[®] Windows NT[®] Server 4.0 Microsoft[®] Windows NT[®] Workstation 4.0

Information about Installed Software

Expat

- The software including controller, etc. (hereinafter "software") installed on this product uses the expat Version 1.95.2 (hereinafter "expat") under the conditions mentioned below.
- The product manufacturer provides warranty and support to the software of the product including the expat, and the product manufacturer makes the initial developer and copyright holder of the expat, free from these obligations.
- Information relating to the expat is available at: http://expat.sourceforge.net/

Copyright © 1998, 1999, 2000 Thai Open Source Software Centre, Ltd. and Clark Cooper.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

NetBSD

1. Copyright Notice of NetBSD

For all users to use this product:

This product contains NetBSD operating system:

For the most part, the software constituting the NetBSD operating system is not in the public domain; its authors retain their copyright.

The following text shows the copyright notice used for many of the NetBSD source code. For exact copyright notice applicable for each of the files/binaries, the source code tree must be consulted.

A full source code can be found at http://www.netbsd.org/.

Copyright © 1999, 2000 The NetBSD Foundation, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- ① Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- ② Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- ③ All advertising materials mentioning features or use of this software must display the following acknowledgment: This product includes software developed by The NetBSD Foundation, Inc. and its contributors.
- Neither the name of The NetBSD Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE NETBSD FOUNDATION, INC. AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

2. Authors Name List

All product names mentioned herein are trademarks of their respective owners. The following notices are required to satisfy the license terms of the software that we have mentioned in this document:

- This product includes software developed by the University of California, Berkeley and its contributors.
- This product includes software developed by Jonathan R. Stone for the NetB-SD Project.
- This product includes software developed by the NetBSD Foundation, Inc. and its contributors.
- This product includes software developed by Manuel Bouyer.
- This product includes software developed by Charles Hannum.
- $\bullet\,\,$ This product includes software developed by Charles M. Hannum.
- This product includes software developed by Christopher G. Demetriou.
- $\bullet\,\,$ This product includes software developed by TooLs GmbH.
- This product includes software developed by Terrence R. Lambert.
- This product includes software developed by Adam Glass and Charles Hannum.

- This product includes software developed by Theo de Raadt.
- This product includes software developed by Jonathan Stone and Jason R. Thorpe for the NetBSD Project.
- This product includes software developed by the University of California, Lawrence Berkeley Laboratory and its contributors.
- This product includes software developed by Christos Zoulas.
- This product includes software developed by Christopher G. Demetriou for the NetBSD Project.
- This product includes software developed by Paul Kranenburg.
- This product includes software developed by Adam Glass.
- This product includes software developed by Jonathan Stone.
- This product includes software developed by Jonathan Stone for the NetBSD Project.
- This product includes software developed by Winning Strategies, Inc.
- This product includes software developed by Frank van der Linden for the NetBSD Project.
- This product includes software developed for the NetBSD Project by Frank van der Linden
- This product includes software developed for the NetBSD Project by Jason R. Thorpe.
- The software was developed by the University of California, Berkeley.
- This product includes software developed by Chris Provenzano, the University of California, Berkeley, and contributors.

Sablotron

Sablotron (Version 0.82) Copyright © 2000 Ginger Alliance Ltd. All Rights Reserved

- a) The application software installed on this product includes the Sablotron software Version 0.82 (hereinafter, "Sablotron 0.82"), with modifications made by the product manufacturer. The original code of the Sablotron 0.82 is provided by Ginger Alliance Ltd., the initial developer, and the modified code of the Sablotron 0.82 has been derived from such original code provided by Ginger Alliance Ltd.
- b) The product manufacturer provides warranty and support to the application software of this product including the Sablotron 0.82 as modified, and the product manufacturer makes Ginger Alliance Ltd., the initial developer of the Sablotron 0.82, free from these obligations.
- c) The Sablotron 0.82 and the modifications thereof are made available under the terms of Mozilla Public License Version 1.1 (hereinafter, "MPL 1.1"), and the application software of this product constitutes the "Larger Work" as defined in MPL 1.1. The application software of this product except for the Sablotron 0.82 as modified is licensed by the product manufacturer under separate agreement(s).
- d) The source code of the modified code of the Sablotron 0.82 is available at: http://support-download.com/services/device/sablot/notice082.html

- e) The source code of the Sablotron software is available at: http://www.ginger-all.com
- f) MPL 1.1 is available at: http://www.mozilla.org/MPL/MPL-1.1.html

JPEG LIBRARY

• The software installed on this product is based in part on the work of the Independent JPEG Group.

SASL

CMU libsasl

Tim Martin

Rob Earhart

Rob Siemborski

Copyright © 2001 Carnegie Mellon University. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- ① Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- ② Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name "Carnegie Mellon University" must not be used to endorse or promote products derived from this software without prior written permission. For permission or any other legal details, please contact:

Office of Technology Transfer Carnegie Mellon University 5000 Forbes Avenue Pittsburgh, PA 15213-3890 (412) 268-4387, fax: (412) 268-7395 tech-transfer@andrew.cmu.edu

Redistributions of any form whatsoever must retain the following acknowledgment:

"This product includes software developed by Computing Services at Carnegie Mellon University (http://www.cmu.edu/computing/)."

CARNEGIE MELLON UNIVERSITY DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS, IN NO EVENT SHALL CARNEGIE MELLON UNIVERSITY BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

MD4

Copyright © 1990-2, RSA Data Security, Inc. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD4 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

MD₅

Copyright © 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing this software or this function.

License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

How to Read This Manual

Symbols

This manual uses the following symbols:

↑ WARNING:

This symbol indicates a potentially hazardous situation that might result in death or serious injury if you misuse the machine by not following the instructions under this symbol. Be sure to read the instructions, all of which are included in the Safety Information section in the *General Settings Guide*.

↑ CAUTION:

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage not involving bodily injury, if you misuse the machine by not following these instructions under this symbol. Be sure to read the instructions, all of which are included in the Safety Information section in the *General Settings Guide*.

* WARNINGS and CAUTIONS are notes for your safety.

#Important

If these instructions are not followed, paper might be misfed, originals damaged, or data lost. Be sure to read these instructions.

Preparation

This symbol indicates the prior knowledge or preparation required before operation.

∅ Note

This symbol indicates precautions for operation, or actions to be taken following user error.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions under which a particular function cannot be used.

This symbol indicates where further relevant information can be found.

[]

Keys that appear on the machine's display panel.

Keys built into the machine's control panel.

Safety Information

When using this machine, the following safety precautions should always be followed.

Safety During Operation

In this manual, the following important symbols are used:

↑ WARNING:

Indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

↑ CAUTION:

Indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury or damage to property.

↑ WARNING:


- Connect the power cord directly into a wall outlet and never use an extension cord.
- Disconnect the power plug (by pulling the plug, not the cable) if the power cable or plug becomes frayed or otherwise damaged.
- To avoid hazardous electric shock or laser radiation exposure, do not remove any covers or screws other than those specified in this manual.
- Turn off the power and disconnect the power plug (by pulling the plug, not the cable) if any of the following occurs:
 - · You spill something into the machine.
 - You suspect that your machine needs service or repair.
 - The external housing of your machine has been damaged.
- Do not incinerate spilled toner or used toner. Toner dust might ignite when exposed to an open flame.
- Disposal can take place at our authorized dealer.
- Dispose of the used toner bottle in accordance with the local regulations.

A CAUTION:

- Protect the machine from dampness or wet weather, such as rain and snow.
- Keep the machine away from humidity and dust. Otherwise a fire or an electric shock might occur.
- Do not place the machine on an unstable or tilted surface. If it topples over, an injury might occur.
- If you use the machine in a confined space, make sure there is a continuous air turnover.
- Unplug the power cord from the wall outlet before you move the machine.
 While moving the machine, you should take care that the power cord will not be damaged under the machine.
- When you disconnect the power plug from the wall outlet, always pull the plug (not the cable).
- Do not allow paper clips, staples, or other small metallic objects to fall inside the machine.
- Keep toner (used or unused) and toner bottle out of the reach of children.
- For environmental reasons, do not dispose of the machine or expended supply waste at household waste collection points. Disposal can take place at an authorized dealer.
- The inside of the machine could be very hot. Do not touch the parts with a label indicating "hot surface". Otherwise, an injury might occur.
- The fusing section of this machine might be very hot. Caution should be taken when removing misfed paper.
- The fusing unit becomes very hot. When installing a new fuser oil unit, turn
 off the machine and wait about an hour. After that, install the new fuser oil
 unit. Not waiting for the unit to cool could result in a burn.
- Keep the fuser oil unit away from flames. There is a risk of fire or burns.
- Keep the waste oil bottle away from flames. There is a risk of fire or burns.
- Do not use aluminum foil, carbon paper, or similar conductive paper to avoid a fire or machine failure.

Positions of Labels and Hallmarks for MARNING and MCAUTION

This machine has labels for <u>MARNING</u> and <u>MCAUTION</u> at the positions shown below. For safety, please follow the instructions and handle the machine as indicated.









KVH040J

ENERGY STAR Program



As an ENERGY STAR Partner, we have determined that this machine model meets the ENERGY STAR Guidelines for energy efficiency.

The ENERGY STAR Guidelines intend to establish an international energy-saving system for developing and introducing energy-efficient office equipment to deal with environmental issues, such as global warming.

When a product meets the ENERGY STAR Guidelines for energy efficiency, the Partner shall place the ENERGY STAR logo onto the machine model.

This product was designed to reduce the environmental impact associated with office equipment by means of energy-saving features, such as Low-power mode.

Low-Power mode

• Low Power Mode

This product automatically lowers its power consumption 15 minutes after the last copy or print job has finished. Printing is still possible in Low Power Mode, but if you wish to make copies press the [Energy Saver] key first.

P Reference

For details about how to change the default interval, see p.56 "Energy Saver Timer".

Sleep Mode

This product automatically lowers its power consumption even further 60 minutes after the last copy or print job has finished. This function is called "Sleep Mode". Printing from computer or fax is possible in this mode, but if you wish to make copies, press the operation switch first.

For details about how to change the default interval, see p.56 "Auto Off Timer".

Duplex Priority

The ENERGY STAR Program recommends the duplex function. By conserving paper resources this function reduces a burden to the environment. For applicable machines, duplex function (one-sided originals—) two-sided copies) can be selected preferentially when the operation switch or the main power switch is turned on, the **[Energy Saver]** key is pressed, or the machine resets automatically.

To change the settings of the Duplex Priority mode, see "Duplex Mode Priority" in "General Features 2/5", Copy Reference.

Specifications

| | | Type 1 | Type 2 |
|-----------------|-------------------|-------------|--------|
| Low- Power mode | Power consumption | 173.2W | 196.3W |
| Sleep mode | Power consumption | 80W or less | |
| | Default interval | 60 minutes | |
| | Recovery time | 101 seconds | |

| Duplex Priority | 1 Sided→1 Sided |
|-----------------|-----------------|
| | |

♦ Recycled Paper

In accordance with the ENERGY STAR Program, we recommend use of environmentally friendly recycled paper. Please contact your sales representative for recommended paper.


Machine Types

This machine comes in two models which vary in copy speed. To confirm which model you have, see the inside front cover.

| | Type 1 | Type 2 |
|------------------------|--|--|
| Copy speed/B&W | 32 copies/minute (A4 \square , $8^1/2^{"}$ × 11" \square) | 38 copies/minute (A4 \square , $8^1/2^{"}$ × 11" \square) |
| Copy speed/Full Colour | 24 copies/minute (A4 \square , $8^1/2^{"}$ × 11" \square) | 28 copies/minute (A4 \square , $8^1/2^{"}$ × 11" \square) |

1. Getting Started

Guide to Components



1. Exposure glass cover (optional) or Auto Document Feeder (ADF) (optional)

Lower the exposure glass cover over originals placed on the exposure glass. If you have the ADF, load a stack of originals here. They will be fed automatically, one by one.

(The illustration shows the ADF.)

2. Exposure glass

Place originals face down.

3. External tray

Copied, printed paper or fax messages are delivered here.

4. Duplex reversal unit

Open this to remove misfed paper. The upper left cover can be opened by first opening the duplex reversal unit.

5. Ventilation holes

Prevents overheating. Do not obstruct the ventilation holes by placing anything near it or leaning objects against it. If the machine overheats, an error might occur.

6. Main power switch

If the machine does not operate after turning on the operation switch, check the main power switch is turned on. If it is off, turn it on.

7. Operation switch

Press this switch to turn the power on (the **On** indicator lights up). To turn the power off, press this switch again (the **On** indicator goes off).

8. Control panel

See p.19 "Control Panel".

9. Standard tray

Copied, printed paper or fax messages are delivered here.

10. Front cover


Open to access the inside of the machine.

11. Paper tray

Load paper here. See p.109 "**≜** Loading Paper".

12. Paper tray unit (optional)

Load paper here. See p.109 "Loading Paper", p.17 "External Options".



1. Upper right cover

Open this cover to replace the toner cartridge.

2. Ventilation holes

3. Optional connectors

Use to connect options such as Bluetooth.

4. Bypass tray extension

Pull out this extension to load paper in the bypass tray when its length is longer than that of A4D size.

AAE020S


5. Bypass tray

Use to print on thick paper, OHP transparencies, custom size paper, as well as plain paper.

6. Lower right cover

Open this cover to remove misfed paper.

External Options



1. Left tray

If you select this as the output tray, copies will be delivered face down.

2. Exposure glass cover

Lower this cover over originals before copying.

3. ADF

Load a stack of originals here. They will be fed in automatically.

4. 2 Tray finisher

Sorts, stacks, staples, and punches copies.

*1 Finisher Shift Tray 1

*2 Finisher Shift Tray 2

5. Booklet finisher

Sorts, stacks, and staples copies. The saddle stitch function can staple the copies in the centre and folds them like a booklet.

6. 1 Tray paper unit

Consists of 1 paper tray.

7. 2 Tray paper unit

Consists of 2 paper trays.

8. Large Capacity Tray (LCT)

Holds up to 2000 sheets of A4 \square paper.

Internal Options


① Fax unit

Allows you to use the facsimile function.

- ② IEEE 1394 interface board *1 Connects to an IEEE 1394 cable.
- 3 Bluetooth *1 Allows you to expand the interface.
- ④ File Format Converter Allows you to download documents from the Document Server stored by copier and printer functions. See p.42 "Downloading Stored Documents".
- ⑤ IEEE 802.1b Wireless LAN Board *1 You can install a wireless LAN interface.
- USB 2.0 Interface Board *1
 Allows you to connect a variety of external devices.
- *1 You cannot install two or more of the options below: IEEE 1394 interface board, IEEE 802.1b Wireless LAN Board, USB 2.0 Interface Board, Bluetooth

Control Panel

This illustration shows the control panel of a machine with options fully installed.



1. Screen contrast knob

Adjusts display panel brightness.

2. [User Tools/Counter] key

- User Tools
 Press to change defaults and conditions to meet your requirements. See p.48 "Accessing User Tools (System Settings)".
- Counter
 Press to check or print the counter value. See p.152 "Counter".
- Inquiry
 Press to find out where to order expendable supplies and where to call when a malfunction occurs. You can also print these details. See p.151 "Inquiry"

3. Indicators

Display the status of the machine or indicate errors.

- 📥: Add Staple indicator. See p.125 "🛓 Adding Staples".
- 🖾: Add Toner indicator. See p.112 "🚨 Adding Toner".
- Load Paper indicator. See p.109 "Loading Paper".
- 1: Service Call indicator
- []*: Open Cover indicator
- **%r**: Misfeed indicator. See p.114 "**%r** Clearing Misfeeds".

- **\$**: Data In indicator. See "Control Panel", *Printer Reference* 1.
- Communicating: Communicating indicator. See "Control Panel", Facsimile Reference < Basic Features>.
- **\Pi**: Confidential File indicator. See "Control Panel", Facsimile Reference <Basic Features>.
- Receiving File: Receiving File indicator. See "Control Panel", Facsimile Reference < Basic Features>.

4. [Adjust/Program Colour] key (copy mode)

Use this key to adjust and register colours. See "Colour Adjustment", "User Colour", Copy Reference.

Note

☐ When image quality is adjusted, the lamp in the [Adjust/Program Colour] key is lit.

5. Colour circle

Refer to this when adjusting colours. See "Colour Adjustment", Copy Reference.

6. Display panel

Displays operation status, error messages, and function menus. See p.21 "Display Panel".

7. [Check Modes] key

Press to check the entered copy job settings.

8. [Program] key (copier/facsimile/scanner mode)

Press to register frequently used settings, or recall registered settings.

9. [Clear Modes] key

Press to clear previous copy job settings.

10. [Energy Saver] key

Press to switch into and out of Energy Saver mode. See p.23 "Energy Saver Mode".

11. [Interrupt] key (copier mode)

Press to make interrupt copies during copying or scanning. See "Interrupt Copy", Copy Reference.

12. Main power indicator and On indicator

The main power indicator turns on when you turn on the main power. The On indicator lights when the power is on.

#Important

☐ Do not turn off the main power switch while the **On** indicator is turning on or is flashing. The hard disk may malfunction.

13. Operation switch

Press to turn the power on (the **On** indicator goes on). To turn the power off, press again (the On indicator goes off). See p.22 "Turning On the Power"

14. [Sample Copy] key

Press to make a single set of copies or prints to check print quality before making multiple sets. See "Sample Copy" Copy Reference.

15. (Start) key

Press to start copying. Press to start scanning or printing documents stored using the Document Server function.

16. [Clear/Stop] key

Clear

Press to delete a number entered.

Press to stop a job in progress.

17. [#] key

Press to enter a numerical value.

18. Number keys

Press to enter the number of copies and data for a selected function.

19. [Start Manual RX] key, [On Hook Dial] key, [Pause/Redial] key, and Tone key

₽ Reference

Facsimile Reference <Basic Features> and Facsimile Reference < Advanced Features>

20. Colour Selection keys (copy mode)

Switch keys depending on the type of original, or the copying purpose:

[Auto Colour Selection] : @ .../ .../ ...

[Full Colour]: 🖧

[Black & White]: ...

[Single Colour]: 🐣 [Two-colour]: 🐣

See "Colour Functions", Copy Reference.

21. Function keys

Press to select one of the following functions:

Copy:

• Document Server: 🗗



• Facsimile: (

 Printer: Scanner:

22. Function status indicators.

Display the status of the above functions:

- Green: active.
- Red: interrupted.

23. Sindicator

The data indicator shows the status of data reception. See "Control Panel", Printer Reference 1.

Display Panel


The display panel shows machine status, error messages, and function menus.

∰Important

□ A force or impact of more than 30 N (about 3 kgf) will damage the display panel.

The copying screen is displayed as default after power on.

The following display shows a machine with options fully installed.



The function items displayed serve as selector keys. You can select or specify an item by lightly pressing them.

When you select or specify an item on the display panel, it is highlighted thus Reys appearing as OK cannot be used.

Common key operations

The following keys are common to all screens:

♦ Key list

| [OK] | Acknowledges a selected function or entered values, and then returns to the previous display. |
|------------------|---|
| [Cancel] | Deletes a selected function or entered values, and then returns to the previous display. |
| [▲Prev.] [▼Next] | Moves to the previous or next display when all items cannot be shown on the same display. |
| [OK] [Yes] | Closes displayed messages. |
| [Clear] | Cancels entered values but does not change the settings. |
| [Exit] | Returns to the previous display. |

Turning On the Power

This machine has two power switches.

Operation switch (right side of the control panel)

Press to activate the machine. When the machine has finished warming up, you can make copies.

Main power switch (left side of the machine)

Turning off this switch will turn off the main power indicator on the right side of the control panel. After this is done, machine power is completely off.

When the fax unit (optional) is installed, fax files in memory may be lost if you turn this switch off. Use this switch only when necessary.


Note

☐ This machine automatically enters Energy Saver mode or turns itself off if you do not use it for a while. See p.56 "Auto Off Timer", "Energy Saver Timer".

Turning On the Main Power

- 1 Make sure that the power cord is firmly plugged into the wall outlet.
- Open the switch cover, and then turn on the main power switch.

The main power indicator turns on.




∰Important

☐ Do not turn off the main power switch immediately after turning it on. Doing so may result in damage to the hard disk or memory, leading to malfunction.

Turning On the Power

1 Press the operation switch.

The **On** indicator turns on.




Note

☐ If the power does not turn on when the operation switch is pressed, check the main power switch is on. If it is off, turn it on.

Turning Off the Power

- 1 Make sure the exposure glass cover or the ADF is in the right position.
- **2** Press the operation switch.

The **On** indicator turns off.



𝒯 Note

- ☐ Even if you press the operation switch, and the indicator does not turn off, it will blink in the following cases:
 - When the exposure glass cover or ADF is open.
 - During communication with external equipment.
 - When the hard disk is active.

Turning Off the Main Power

#Important

- Do not turn off the main power switch when the **On** indicator is lit or blinking. Doing so may result in damage to the hard disk or memory.
- Be sure to turn off the main power switch before pulling out the power plug. Not doing this may result in damage to the hard disk or memory.
- 1 Make sure the On indicator is not lit.
- 2 Open the switch cover, and then turn off the main power switch.

The main power indicator turns off.

When the fax unit (optional) is installed

When the main power switch is turned off while using the facsimile function, waiting fax and print jobs may be canceled, and incoming fax documents not received. If you have to turn off this switch for some reason, follow the procedure below.

Important

- ☐ Make sure 100% is shown as available memory on the display before turning off the main power switch or unplugging the power cord. Fax files in memory are deleted an hour after you turn off the main power switch or unplug the power cord. See "Power Failure Report", Facsimile Reference < Advanced Features>.
- ☐ The **On** indicator will not turn off, but will blink in dial-in mode even if you press the operation switch. When this happens, check the explanations below, and turn off the main power switch.
 - The computer is not controlling the machine.
 - The machine is not receiving a fax.

Saving Energy

Energy Saver Mode

If you do not use the machine for a certain period after an operation, or when you press the **[Energy Saver]** key, the display disappears and the machine goes into Energy Saver mode. When you press the **[Energy Saver]** key again, the machine returns to the ready condition. The machine uses less electricity in Energy Saver mode.

Note

☐ You can change the amount of time the machine waits before switching to Energy Saver mode after copying has finished or the last operation is performed. See p.56 "Energy Saver Timer".

.



The machine automatically turns itself off when the job is finished, after a certain period of time has elapsed. This function is called "Auto Off".

Note

- ☐ You can change the Auto Off time. See p.56 "Auto Off Timer".
- ☐ The Auto Off Timer function will not operate in the following cases:
 - When a warning message appears
 - When the service call message appears
 - When paper is jammed
 - When the cover is open
 - When the "Add Toner" message appears
 - When toner is being replenished
 - When the User Tools/Counter screen is displayed
 - When fixed warm-up is in progress
 - When the facsimile, printer or other functions are active
 - When operations were suspended during printing
 - When the handset is in use
 - When the On-hook dialing function is in use
 - When a recipient is being registered in the address list or group dial list
 - When the Data In indicator is on or blinking
 - When the sample print or locked print screen is displayed


2. Combined Function Operations

Changing Modes

𝒯 Note

- ☐ You cannot switch modes in any of the following situations:
 - When scanning in a fax message for transmission
 - During immediate transmission
 - When accessing User Tools
 - During interrupt copying
 - During On hook dialing for fax transmission
 - While scanning an original

☐ The copying screen is displayed as default after power on. You can change this default setting. See p.49 "Function Priority".



System Reset

The machine returns automatically to its initial condition when the job is finished, after a certain period of time has elapsed. This function is called "System Reset". See p.49 "Function Priority".

Note

☐ You can change the System Reset time. See p.56 "System Auto Reset Timer".

Multi-Access

You can carry out another job using a different function while the current job is being performed. Performing multiple functions simultaneously in this manner is called "Multi-accessing".

This allows you to handle jobs efficiently, regardless of how the machine is being used. For example:

- While making copies, you can scan documents to store in the Document Server.
- While printing documents stored in the Document Server, the machine can receive print data.
- You can make copies while receiving fax data.
- While printing print data, you can make operations for copying.

Note

- ☐ See p.50 "Print Priority" for setting function priority. As default, **[Display mode]** is set to first priority.
- □ When the 2 tray finisher or booklet finisher is installed on the machine, you can specify the output tray where documents are delivered. For details about how to specify the output tray for each function, see the following descriptions:
 - p.51 "Output: Copier (copier)"
 - p.51 "Output: Document Server (Document Server)"
 - p.51 "Output: Facsimile (facsimile)"
 - p.52 "Output: Printer (printer)"

Function Compatibility

The chart shows Function Compatibility when print priority is set to "Interleave". See p.50 "Print Priority".

- \triangle : Simultaneous operations are possible.
- Operation is enabled when the relevant function key is pressed and remote switching (of the scanner/external extension) is done.
- O: Operation is enabled when the **[Interrupt]** key is pressed to interrupt the preceding operation.
- \rightarrow : Operation is performed automatically once the preceding operation ends.
- ×: The operation must be started once the preceding operation ends. (Simultaneous operations are not possible.)

| Mode after you select | | Сору | | | ρΰ | | Fac | csin | ile | | | | Pri | nte | r | | | | | | 72 | | |
|-----------------------|----------------|---|------------------------|---------------|-------------|------------------------|---------|---|--|---------------------|-----------------------|------------------|------------------------|----------------|---------------------------|---------------------------|-------------------------|---------------|--------------------------------|---|-------------------------------|---------------------------------|--|
| | | | | | | Interrupt Copying | 1 | tion | Transmission | 1 | 1 | Reception | | | Print | | Scanner | 1 | Document Server | 12 | | DeskTopBinder V2 | Professional/Lite |
| Mode before y | 70 0. | select | Operations for Copying | Stapling | Sort | Operations for Copying | Copying | Fransmission Operation/Manual Reception Operation | Scanning an Original for Memory Transmission | Memory Transmission | mmediate Transmission | Memory Reception | Printing Received Data | Data Reception | ▶ Printing | Stapling | Operations for Scanning | Scanning | Operations for Document Server | Scanning a Document to Store in Document Server | Printing from Document Server | ▶ Printing from Document Server | Sending a Facsimile from Document Server |
| Copy | ou : | Operations for | × | × | × | 0 | 0 | • | • s | Δ | • | Δ | Δ | Δ | <u>I</u> △ | Δ | ĕ | • s | ĕ | S | • | Δ | Δ |
| | | Copying Stapling | Δ *1 | → *1 | → *1 | 0 | O *5 | • | *2 | Δ | *2 | Δ | Δ | Δ | Δ | \rightarrow | • | *2 | • | *2 | △ *4 | Δ *4 | Δ |
| | | Sort | ∆ *1 | → *1 | → *1 | 0 | 0 | • | *2 | Δ | • *2 | Δ | Δ | Δ | Δ | Δ | • | *2 | • | *2 | Δ | Δ | Δ |
| Interrupt Copy | ing | Operations for Copying | 0 | 0 | 0 | × | × | × | × | Δ | × | Δ | Δ | Δ | Δ | Δ | × | × | × | × | × | Δ | Δ |
| Facsimile | Ma | Copying nsmission Operation/ nual Reception eration | • | • | • | × | × | × | × | Δ | × | Δ | \rightarrow | Δ | \rightarrow \triangle | \rightarrow \triangle | × | × | × | × | × | \rightarrow | Δ |
| | 1 | Scanning an original for Memory Transmission | × | × | × | × | × | × | × | Δ | × | Δ | Δ | Δ | Δ | Δ | × | × | × | × | × | Δ | Δ |
| | nissio | Memory Transmis- sion | Δ | Δ | Δ | Δ | Δ | Δ | Δ | ∆ *3 | ∆ *3 | ∆ *3 | Δ *9 | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | \rightarrow |
| | Transmission | Immediate Trans- mission | × | × | × | × | × | × | × | ∆ *3 | × | ∆ *3 | Δ | Δ | Δ | Δ | × | × | × | × | × | Δ | \rightarrow |
| | _ | Memory Reception | Δ | Δ | Δ | Δ | Δ | Δ | Δ | ∆ *3 | ∆ *3 | ∆ *3 | ∆ *9 | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ |
| | Reception | Printing Received Data | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ *9 | Δ | ∆ *9 | × | Δ | Δ | Δ | Δ | ∆ *10 | Δ | Δ | Δ | Δ | Δ |
| Printer | | ta Reception Sort Print | Δ | Δ | Δ | Δ Ο | Δ Ο | Δ | Δ | Δ | Δ | Δ | Δ | \rightarrow | \rightarrow | \rightarrow | Δ | Δ Δ *10 | Δ | Δ | Δ | Δ | Δ |
| | Print | Stapling | Δ | \rightarrow | Δ | 0 | O *5 | Δ | Δ | Δ | Δ | Δ | Δ | Δ | \rightarrow | \rightarrow | Δ | Δ *10 | Δ | Δ | ∆ *4 | ∆ *4 | Δ |
| Scanner | I _C | Operations for scanning | • | • | • | 0 | 0 | • | • | Δ | • | Δ | Δ | Δ | Δ | Δ | × | × | • | • | • | Δ | Δ |
| | | Scanning | × | × | × | × | × | × | × | Δ | × | Δ | ∆ *9 | Δ | ∆ *9 | ∆ *9 | × | × | × | × | ∆ *9 | ∆ *9 | Δ *9 |

| Mode after you select | | Co | ру | | ao. | | Fac | sin | ile | | | | Pri | nte | r | | | | | | 72 | |
|-----------------------------------|---|------------------------|----------|------|------------------------|---------|---|--|---------------------|------------------------|-----------|------------------------|----------------|------------|----------|-------------------------|----------|--------------------------------|---|---------------------------------|-------------------------------|--|
| | | | 1 | | Interrupt Copying | 1 | ion | Transmission | | | Reception | 1 | | Print | 1 | Scanner | 1 | Document Server | 1. | - | DeskTopBinder V2 | Professional/Lite |
| Mode before you | | Operations for Copying | Stapling | Sort | Operations for Copying | Copying | Transmission Operation/Manual Reception Operation | Scanning an Original for Memory Transmission | Memory Transmission | Immediate Transmission | | Printing Received Data | Data Reception | ▶ Printing | Stapling | Operations for Scanning | Scanning | Operations for Document Server | Scanning a Document to Store in Document Server | × Printing from Document Server | Printing from Document Server | Sending a Facsimile from Document Server |
| Document Server | Operations for Document Server | • | • | • | 0 | 0 | • | • | Δ | • | Δ | Δ | Δ | Δ | Δ | • | • | × | × | × | Δ | Δ |
| | Scanning a Document to Store in Document Server | • | × | × | 0 | 0 | • | × | Δ | × | Δ | Δ | Δ | Δ | Δ | • | × | × | × | × | Δ | Δ |
| | Printing from Document Server | • | ∆ *4 | Δ | 0 | 0 | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | ∆ *10 | ∆ *6 | Δ *6 | Δ *6 | Δ | Δ |
| DeskTopBinder V2 Professional/ | Printing from Document Server | Δ | ∆ *4 | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ *10 | Δ | Δ | Δ | × | Δ |
| Lite | Sending a Facsimile from Document Server | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | Δ | × |

^{*1} Simultaneous operations are only possible after the preceding job documents are all scanned and the [Next Job] key appears.

*2 You can scan a document after the preceding job documents are all scanned.

*3 Operation is possible when extra lines are added.

*4 During stapling, printing automatically starts after the current job.

*5 Stapling is not available.

*6 Simultaneous operation become possible after you press the **[Next Job]** key.

- *7 While printing is in progress, scanning using another function may require more time than usual.
- *8 During parallel reception, any subsequent job is suspended until the receptions are completed.

'9 Becomes an → only when scanning colour.

*10 Becomes an interrupt operation by changing the function key only when scanning colour. (However, it becomes an → when the network Twain scanner is scanning colour.)

Limitation

☐ Stapling cannot be used at the same time for multiple functions.

3. Document Server

Relationship between Document Server and Other Functions

The following table describes the relationship between the Document Server and other functions.

| function | Where to store documents | Displaying a list | Printing stored documents | Sending documents |
|-----------|--------------------------|-------------------|---------------------------|-------------------|
| Сору | Copy/ Document Server | Available | Available | Not Available |
| Printer | Document Server | Available | Available | Not Available |
| Facsimile | Facsimile | Available | Available | Available *1 |
| Scanner | Scanner | Not Available *2 | Not Available | Available *3 |

^{*1} You can send stored documents using the facsimile function. See "Sending a Stored File", Facsimile Reference < Advanced Features>.

𝒯 Note

☐ The following table shows the capacity of the Document Server.


| | Number of pages for each file | Number of files | Number of pages in total |
|-----------|-------------------------------|-----------------|--------------------------|
| Сору | | | |
| Printer | 1,000 pages | 2,000 files | 9,000 pages |
| Scanner | 1,000 pages | 2,000 mes | 9,000 pages |
| Facsimile | | | |

^{*2} You can display stored documents using the scanner function. See *Scanner Reference*.

^{*3} You can send stored documents using the scanner function. See *Scanner Reference*.

Document Server Display

Document Server Main Display



- 1. Operating status and messages.
- 2. The title of the currently selected screen.
- 3. The numbers of originals, copies, and printed pages.
- 4. The operation keys.
- 5. The functions under which the documents were stored.

The icons below show the functions active when the documents were stored in the Document Server.

| Function | Copier | Facsimile | Printer |
|----------|--------|-----------|---------|
| Icon | | © | 臣 |

Using the Document Server

Storing Data

File name

Stored documents are automatically named "COPY0001", "COPY0002". You can change assigned file names.

User name

You can register a user name to identify the user or user group that stored the documents. To assign it, you can register the user name using the name assigned to the user code, or by entering the name directly.

For details about the user name, see p.69 "User Name".

Password

You can set a password for stored documents, and use it to prevent others printing them. When a password is set for the documents, 1 appears next to the documents.

To store documents without using Document Server function, see the manuals for those modes.


#Important

☐ Data stored in the machine might be lost if some kind of failure occurs. The manufacture shall not be responsible for any damage resulting from loss of data.

Note

- Data stored in the Document Server is set to be deleted after three days (72 hours) by default. You can specify the period after which stored data is automatically deleted. See p.64 "Auto Delete File".
- ☐ If you do not want stored data to be automatically deleted, select [No] in Auto Delete File before storing a document. If you select [Yes] later, data stored afterward will be automatically deleted.
- ☐ When the machine is printing a document stored using the copier function, wait until printing has finished before you store a document in the Document Server.

Press the [Document Server] key.



2 Press [Scan Original].



Enter a user name, file name, or password if necessary.

Note

☐ If you do not enter a file name, one is automatically assigned.

p.34 "To register or change a user name"

p.35 "To change a file name" p.35 "To set or change a password"

4 Place originals either on the exposure glass or in the ADF.

For information about types of originals and how to place them, see "Placing Originals" Copy Reference.

5 Make any required settings.



For details, see Copy Reference.

6 Press the [Start] key.

The document is stored in the Document Server.

Note

- ☐ To stop scanning, press the **[Clear/Stop]** key. To restart a paused scanning job, press **[Continue]** in the confirmation display. To delete saved images and cancel the job, press the **[Stop]** key.
- ☐ When a password is set, ♣ appears on the left side of the file name.

☐ If you placed originals on the exposure glass, press [Scanning Finished] after all the originals have been scanned. The Select Files to Print display appears.

To register or change a user name

1 Press [Scan Original].

The Scan Original display appears.

2 Press [User Name].



If user names are already registered, the Change User Name display appears. To use an unregistered user name, press [Non-programmed Name].

When no user names are registered in the Address Book, the User (Destination) Name entry display appears.

₽ Reference

p.71 "User Code"

When using a registered user name in the Address Book

Select a registered user name from the list, and then press [OK].



To change your user name to an unregistered user name, proceed to the next step.

₽ Reference

p.71 "Registering a New User Code"

When using an unregistered user name in the Address Book

- To enter an unregistered user name, press [Non-programmed Name].
- 2 Enter a new user name, and then press [OK].

p.153 "Entering Text"

When no user names are registered in the Address Book

1 Enter a new user name, and then press [OK].



p.153 "Entering Text"

To change a file name

1 Press [Scan Original].

The Scan Original display appears.

2 Press [File Name].



The Change File Name display appears.

- Press [Delete All] to delete the old file name.
 - Note
 - ☐ You can also use [Backspace] to delete unnecessary characters.
- Enter a new file name, and then press [OK].
 - Note
 - ☐ Up to 20 characters can be entered as a file name. Note that only 16 characters of each file name appear in the document list.

p.153 "Entering Text"

To set or change a password

1 Press [Scan Original].

The Scan Original display appears.


2 Press [Password].



- Enter a password using the number keys (four digits), and then press the [#] key.
- Reenter the password (four digits) for verification, and then press the [#] key.
- 5 Press [OK].

Changing a Stored Document's File Name, User Name, or Password

- 1 Press the [Document Server] key.
- 2 Select the document with the user name, file name, or password you want to change.



Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- 3 Press [File Management].



- Press [Change User Name], [Change File Name], or [Change Password].
- Enter the new user name, file name, or password using the letter keys or number keys and then press [OK].

p.34 "To register or change a user name"

p.35 "To change a file name"

p.35 "To set or change a password"

6 Press [OK].

Selecting a Document

- 1 Press the [Document Server] key.
- Select a document you want to print.



∅ Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- ☐ You can search for the document using [Search by User Name] or [Search by File Name] at the left top of the display. See p.37 "Searching for Stored Documents".
- ☐ You can sort document names in the list by user name, file name, or date. To sort documents, press [User Name], [File Name], or [Date].
- ☐ If you cannot determine document content from the file name, you can print just the first page of the document for checking purposes. See p.40 "Printing the first page".
- ☐ To cancel document selection, press it again.

To print multiple documents, repeat step 2 in the order you want to print.

𝒯 Note

- ☐ You can select up to 30 documents.
- ☐ If the sizes or resolution of selected documents are not the same, it may not be possible to print them.
- If you want to change the printing order, cancel the selection, and select documents again, this time in the order you want.
- ☐ If you press the 【Clear Modes】 key, selection of all documents will be canceled.
- ☐ If you press [Printg Odr], the documents in print order.


To check the details of stored documents

1 Select a document to display its detailed information.



∅ Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- 2 Press [Detail].



Detailed information about the document appears.

- ☐ If you selected several documents, use [▲] and [▼] to view the details of each.
- ☐ Press **[OK]**. The Select Files to Print display reappears.

Searching for Stored Documents

You can use either [Search by File Name] or [Search by User Name] to search for documents stored in the Document Server. You can also list stored documents in a preferred order.

Note

☐ If you install DeskTopBinder V2 Professional or DeskTopBinder V2 Lite on your computer, you can search for and rearrange documents using your computer.

Manuals for DeskTopBinder V2 Professional/Lite or Help

To search by file name

- Press the [Document Server] key.
- 2 Press [Search by File Name].



Enter the file name using the letter keys, and then press [OK].

Only files beginning with the name entered appear in the Select Files to Print display.

p.153 "Entering Text".

Note

☐ To display all files stored in the Document Server, press [File List].

To search by user name

1 Press the [Document Server] key.

2 Press [Search by User Name].



To specify a registered user name, select the user name from the displayed list, and then press [OK].

Note

- To specify an unregistered user name, follow the procedure below.
- To specify an unregistered user name, press [Non-programmed Name]. Enter a user name, and then press [OK].



p.153 "Entering Text"

Press [OK].

Only files beginning with the name entered appear in the Select Files to Print display.

∅ Note

 To display all files stored in the Document Server, press [File List].

Printing Stored Documents

Note

- ☐ You can print stored documents from a network computer using a Web browser. For details about how to start the Web browser, see Network Guide.
- Select a document you want to print.

∅ Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- ☐ You can print multiple documents. See p.36 "Selecting a Document".
- 2 If you need to change print settings, press [Print Settings].

The Print Settings display appears. User names, file names, and print order of documents appear.



- Note
- Print settings made for printing in copier or printer function remain after printing and applied to the next job. Print settings made in facsimile mode, however, do not remain.
- If you select multiple documents, the print settings will remain applied to the first document, but not to other documents.
- Print setting items are listed below. For details about print results of each setting, see Copy Reference.

Binding format

- 2 Sided Copy Top to Top
- 2 Sided Copy Top to Bottom
- Magazine

Cover handling

- · Cover/Slip Sheet
- Edit/Stamp

Finish

- Sort
- Stack
- Staple
- Punch
- ☐ If you print more than one set using the Sort function, you can check the print result by printing out only the first set. See p.40 "Sample copy".
- ☐ When multiple documents are printed at the same time, you can combine them into a single set by adjusting the print order.
- When multiple documents are printed at the same time, print settings made for the document printed first are applied to all other documents.
- □ If you select multiple files, you can check file names or print order selected in step ① by scrolling the list using [▼] and [▲].
- ☐ Press [Select File] to return to the Select Files to Print display.
- ☐ The preset stamp function is not available for documents stored in facsimile mode.

Enter the required number of prints using the number keys.



- Note
- ☐ Up to 999 can be entered.
- Press the [Start] key.
 Printing starts.

To stop printing

- 1 Press the [Clear/Stop] key.
- 2 Press [Stop].

Changing the number of copies during printing

Limitation

- ☐ The number of copies can only be changed when the Sort function is selected in the print settings.
- 1 Press the [Clear/Stop] key.
- 2 Press [Change Quantity].
- Enter a new number of copies using the number key.
- 4 Press the [#] key.
- 5 Press [Continue].

Printing restarts.

Sample copy

If you print multiple sets using the Sort function, you can check the print order or print settings are correct by printing only the first set using the [Sample Copy] key.

Limitation

☐ This function can only be used when the Sort function is selected.

1 Select the document.



𝚱 Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- ☐ You can search for the document by using [Search by User Name] or [Search by File Name] at the left top of the display. See p.37 "Searching for Stored Documents".
- You can sort document names in the list by user name, file name, or date. To sort documents, press [User Name], [File Name], or [Date].
- ☐ To cancel a document selection, press it again.

2 Press the [Sample Copy] key.

The first set prints out.

If the sample is acceptable, press [Print].

𝚱 Note

 Press [Suspend] to cancel printing and return to the Print Settings menu to change settings.

Printing the first page

You can print the first page of the document selected in the Select Files to Print display to check its content.

If more than one document selected, the first page of each is printed.

1 Select the document.

Note

- ☐ If a password is already set for the document, enter that password, and then press [OK].
- ☐ You can search for the document by using [Search by User Name] or [Search by File Name] at the left top of the display. See p.37 "Searching for Stored Documents".
- ☐ You can sort document names in the list by user name, file name, or date. To sort documents, press [User Name], [File Name], or [Date].
- ☐ To cancel a document selection, press it again.

2 Press [Print 1st Page].



3 Press the [Start] key.

Deleting Stored Documents

∰Important

☐ You can store up to 2,000 documents in the Document Server. No more documents can be stored when the total is 2,000. You should delete unnecessary documents to increase available memory.

𝚱 Note

- ☐ You can delete all stored documents at once with User Tools. See p.64 "Delete All Files".
- ☐ You can delete stored documents from a network computer using the Web browser. For details about how to start the Web browser, see Network Guide.
- 1 Press the [Document Server] key.
- **2** Select the document to delete.

Note

- If a password is already set for the document, enter that password, and then press [OK].
- ☐ You can delete multiple documents at once. See p.36 "Selecting a Document".
- ☐ You can search for a document by using [Search by User Name] or [Search by File Name] at the left top of the display. See p.37 "Searching for Stored Documents".
- ☐ You can sort document names in the list by the user name, file name, or date. To sort documents, press [User Name], [File Name], or [Date].
- ☐ If you cannot find the document by name, you can print the first page of a document to check its contents. See p.40 "Printing the first page".

- ☐ Press the selected line again to cancel the print job.
- Press [Delete File].



Press [Delete] to delete the document.

Viewing Stored Documents Using a Web Browser

The Web browser's Help

- 1 Start a Web browser.
- 2 Enter "http:// (IP address of this machine) /" in the [Address] box.

The top page appears on the Web browser.

Click [Document Server].

The [Document Server File List] appears.

- Note
- ☐ To switch the display format, click [Details], [Thumbnails] or [Icons] from the [Display method] list.
- 4 Click the properties button of the document you want to check.

Information about that document appears.

5 Check the document's content.

☐ To enlarge the document preview, click [Enlarge Image].

Downloading Stored Documents

𝚱 Note

- ☐ File Format Converter is required when downloading documents stored in copier or printer mode.
- 1 Start a Web browser.
- Enter "http:// (IP address of this machine) /" in the [Address] box.

The top page appears on the Web browser.

Click [Document Server].

The [Document Server File List] appears.

- ☐ To switch the display format, click [Details], [Thumbnails] or [Icons] from the [Display method] list.
- 4 Click the properties button of the document you want to download.
- Select [PDF], [JPEG], or [Multi-page TIFF] in the [File format] list.

Ø Note

- ☐ [JPEG] can only be selected for documents stored in scanner mode.
- [Multi-page TIFF] is available when file format converter is installed.
- [Multi-page TIFF] cannot be selected for documents stored in copier or printer mode.
- 6 Click [Download].
- 7 Click [OK].

Settings for the Document Server

Copier/Document Server Features (See "General Features 4/5", Copy Reference.)

| Items | | Default |
|------------------|------------------------------------|--------------------------------------|
| General Features | Document Server Storage Key: F1 | 2 Sided Original Top to top |
| | Document Server Storage Key: F2 | 1 Sided→1 Sided Combine |
| | Document Server Storage Key: F3 | 1 Sided→1 Sided Combine: 4 originals |
| | Document Server Storage Key: F4 | 1 Sided→1 Sided Combine: 8 originals |
| | Document Server Storage Key: F5 | Create Margin |

♦ System Settings (See p.49 "General Features", p.53 "Tray Paper Settings", p.56 "Timer Settings", and p.58 "Key Operator Tools".)

| • | , | |
|---------------------|--|--------------------|
| | Items | Default |
| General Features | Warm Up Notice | ON |
| | Copy Count Display | Up |
| | Output: Document Server | Standard tray |
| Tray Paper Settings | Paper Tray Priority: Copier | Tray 1 |
| | Cover Sheet Tray | Off |
| | Slip Sheet Tray | Off |
| Timer Settings | Copier/Document Server Auto Reset Timer | 60 seconds |
| Key Operator Tools | Auto Delete File | Yes After 3 day(s) |
| | Delete All Files | |
| | Password Management for Stored Files | Do not Unlock |

4. User Tools (System Settings)

User Tools Menu (System Settings)

For details about Interface Settings and File Transfer, see "User Tools Menu (System Settings)", *Network Guide*.

For details about parallel interface, see "System Settings (Parallel Connection)", *Printer Reference* 2.

◆ General Features (See p.49 "General Features".)

| | Default |
|---------------------------|--------------------------------------|
| Panel Tone | ON |
| Warm Up Notice | ON |
| Copy Count Display | Up |
| Function Priority | Copier |
| Print Priority | Display mode |
| Function Reset Timer | 3 seconds |
| Output: Copier | Standard tray |
| Output: Document Server | Standard tray |
| Output: Facsimile | Standard tray |
| Output: Printer | Standard tray |
| <f f4="">Size Setting</f> | 8 ¹ / ₂ "×13"□ |

❖ Tray Paper Settings (See p.53 "Tray Paper Settings".)

| | Default |
|--------------------------------|--|
| Paper Tray Priority: Copier | Tray 1 |
| Paper Tray Priority: Facsimile | Tray 1 |
| Paper Tray Priority: Printer | Tray 1 |
| Tray Paper Size: Tray 2 | Auto Detect |
| Tray Paper Size: Tray 3 | Auto Detect |
| Tray Paper Size: Tray 4 | Auto Detect |
| Paper Type: Bypass tray | No display |
| Paper Type: Tray 1 | No display/2 Sided Copy/Auto Paper Select on |
| Paper Type: Tray 2 | No display/2 Sided Copy/Auto Paper Select on |
| Paper Type: Tray 3 | No display/2 Sided Copy/Auto Paper Select on |
| Paper Type: Tray 4 | No display/2 Sided Copy/Auto Paper Select on |
| Cover Sheet Tray | Off |
| Slip Sheet Tray | Off |

♦ Timer Settings (See p.56 "Timer Settings".)

| | Default |
|---|--------------|
| Auto Off Timer | 60 minute(s) |
| Energy Saver Timer | 15 minute(s) |
| Panel Off Timer | 1 minute(s) |
| System Auto Reset Timer | 60 seconds |
| Copier/Document Server Auto Reset Timer | 60 seconds |
| Facsimile Auto Reset Timer | 30 seconds |
| Scanner Auto Reset Timer | 60 seconds |
| Set Date | |
| Set Time | |

Interface Settings

- For details about network settings, see "User Tools Menu (System Settings)", Network Guide.
- For details about parallel interface, see "System Settings (Parallel Connection)", *Printer Reference 2*.

File Transfer

• For details about network settings, see "User Tools Menu (System Settings)", Network Guide.

♦ Key Operator Tools (See p.58 "Key Operator Tools".)

| | Default |
|--|------------------------|
| User Code Management | Printer:PC Control: ON |
| Key Counter Management | |
| External Charge Unit Management | |
| Key Operator Code | OFF |
| Extended Security | OFF |
| Display/Print Counter | |
| Display/Clear/Print Counter per User Code | |
| Print Address Book: Destination List | |
| Panel Off Level | Level 1 |
| Address Book Management | |
| Address Book: Program/Change/Delete Group | |
| Address Book: Program/Change/Delete Transfer Request | |
| Address Book: Change Order | |
| Address Book: Edit Title | |

| | Default |
|--------------------------------------|--------------------|
| Address Book: Select Title | Title 1 |
| Auto Delete File | Yes After 3 day(s) |
| Delete All Files | |
| Password Management for Stored Files | Do not Unlock |
| AOF (Always ON) | ON |
| Program/Change LDAP Server | |
| Use LDAP Server | OFF |

Accessing User Tools (System Settings)

This section is for key operators in charge of this machine.

User Tools allow you to change or set defaults.


Note

- Operations for system settings differ from normal operations. Always quit User Tools when you have finished. See p.48 "Exiting User Tools".
- Any changes you make with User Tools remain in effect even if the main power switch or operation switch is turned off, or the [Energy Saver] or [Clear Modes] key is pressed.

Changing Default Settings

Note

- ☐ If a key operator code is already set, the key operator code entry display appears. Enter the key operator code, and then press [OK]. See p.58 "Key Operator Code".
- 1 Press the [User Tools/Counter] key.



- 2 Press [System Settings].
- Select the menu, and then press the appropriate key.

₽ Reference

p.45 "User Tools Menu (System Settings)"

4 Change settings by following instructions on the display panel, and then press [OK].

Note

☐ To cancel changes made to settings and return to the initial display, press the 【User Tools/Counter】 key.

Exiting User Tools

Press the [User Tools/Counter] key.



Note

☐ You can also exit User Tools by pressing **[Exit]**.



Settings You Can Change with User Tools

To access User Tools, see p.48 "Accessing User Tools (System Settings)".

General Features

Panel Tone

The beeper (key tone) sounds when a key is pressed.



☐ Default: ON

♦ Warm Up Notice (copier/Document Server)

You can set the beeper to sound when the machine becomes ready to copy after switching out of Energy Saver mode, or when the power is turned on.

- ☐ If the Panel Tone setting is "OFF", the beeper does not sound, regardless of the Warm Up Notice setting.
- ☐ Default: ON

Copy Count Display (copier/Document Server)

The copy counter can be set to show the number of copies made (count up) or the number of copies yet to be made (count down).

Note

☐ Default: *Up* (count up)

Function Priority

You can specify the mode to be displayed immediately after the operation switch is turned on, or when System Reset mode is turned on.

Note

☐ Default: Copier

Print Priority

Print Priority is given to the mode selected.

p.27 "Multi-Access"

Note

- ☐ Default: *Display mode*
- ☐ When [Interleave] is selected, the current print job will be interrupted after a maximum of five sheets.
- ☐ When the left tray, 2 tray finisher, or booklet finisher is installed on the machine, you can specify an output tray for each document to be delivered. For details about how to specify an output tray for each function, see the following sections:
 - p.51 "Output: Copier (copier)"
 - p.51 "Output: Document Server (Document Server)"
 - p.51 "Output: Facsimile (facsimile)"
 - p.52 "Output: Printer (printer)"

Function Reset Timer


You can set the length of time the machine waits before changing modes when using the multi-access function (see p.27 "Multi-Access"). This is useful if you are making many copies and have to change settings for each copy. If you set a longer reset period, you can prevent interruption from other functions.

𝒯 Note

- □ Default: 3 seconds
- ☐ The Function Reset Timer setting is ignored if [Interleave] is set for Print Priority (see p.50 "Print Priority").
- ☐ When you select **[Set Time]**, enter the time (3–30 seconds, in 1 second increments) using the number keys.

Output: Copier (copier)

You can specify a tray to which documents are delivered.



- Standard tray
- External tray
- Finisher Shift Tray
- Finisher Shift Tray 1
- Finisher Shift Tray 2
- Left tray 1
- Left tray 2

Note

- ☐ Default: Standard tray
- ☐ Paper will be delivered to the standard tray when making a 2 Sided copy, even if you have specified the external tray.
- ☐ Paper will be delivered to the external tray when copying onto OHP transparencies, thick paper, thick paper (back side) or 12" × 18"paper from the bypass tray, even if you have specified not to use the external tray as the output tray.

Output: Document Server (Document Server)

You can specify the tray to which documents are delivered.

Note

- □ Default: Standard tray
- ☐ For details about output trays, see p.51 "Output: Copier (copier)".

Output: Facsimile (facsimile)

You can specify the tray to which documents are delivered.

⊘ Note

- □ Default: Standard tray
- ☐ For details about output trays, see p.51 "Output: Copier (copier)".

Output: Printer (printer)

You can specify the tray to which documents are delivered.

Note

- ☐ Default: Standard tray
- ☐ The output trays set on the printer driver have priority over the output tray specified above.
- ☐ You cannot use the external tray as the output tray when making a 2 Sided copy.
- ☐ For details about output trays, see p.51 "Output: Copier (copier)".

◆ <F/F4>Size Setting

Currently three types of F size are available: $8^1/2"\times13"\Box$, $8^1/4"\times13"\Box$ and $8"\times13"\Box$. The ADF or exposure glass cover sensor cannot distinguish these three types of originals. This function sets the F size from the ADF or exposure glass cover sensor. Auto Paper Select or Auto Reduce/Enlarge can be used for F size originals based on this setting.

 \square Default: $8^1/2" \times 13" \square$

Output tray settings

Limitation

- ☐ You cannot interrupt the current stapling job even if a stapling job is specified by a different function.
- □ When the 2 tray Finisher or booklet finisher is installed and stapling or shiftsorting is specified for a job, the job will be delivered to the finisher shift tray, finisher shift tray 1 or finisher shift tray 2 regardless of the output tray specified.
- ☐ If you use the bypass tray as the output tray, you cannot use the finisher output tray, left tray 1 or left tray 2 as output trays.

Tray Paper Settings

Paper Tray Priority: Copier (copier/Document Server)

You can specify the tray to supply paper for output.

- ☐ Default: Tray 1
- □ When optional paper tray unit is installed, "Tray3" and "Tray4" is displayed.
- ☐ When optional LCT is installed, "LCT" is displayed.

❖ Paper Tray Priority: Facsimile (facsimile)

You can specify the tray to supply paper for output.

- ☐ Default: *Tray 1*
- □ When optional paper tray unit is installed, "Tray3" and "Tray4" is displayed.
- ☐ When optional LCT is installed, "LCT" is displayed.

Paper Tray Priority: Printer (printer)

You can specify the tray to supply paper for output.

Ø Note

- ☐ Default: *Tray 1*
- ☐ When optional paper tray unit is installed, "Tray3" and "Tray4" is displayed.
- ☐ When optional LCT is installed, "LCT" is displayed.

❖ Tray Paper Size:Tray 2–4

Select the size of the paper loaded in the paper tray.

𝒯 Note

☐ Tray 1 uses A4☐ paper exclusively. You cannot specify any other paper size.

The paper sizes you can set for trays are as follows:

- Auto Detect, A3, B4 JIS, A4, A4, B5 JIS, A5
- 11"×17" \square , 81/2"×14" \square , 81/2"×11" \square , 81/2"×11" \square , 81/2"×11" \square , 8"×13" \square , 81/2"×13" \square , 81/4"×13" \square , 71/4"×101/2" \square

#Important

☐ If the specified paper size differs from the actual size of the paper loaded in the paper tray, a misfeed might occur because the correct paper size was not detected.

Note

☐ The paper guide for the optional LCT is fixed for A4 \square , $8^1/2"\times11"$ \square size paper. Contact your service representative if you need to change the paper size.

☐ Default:

- Tray 2: Auto Detect
- Tray 3: Auto Detect
- Tray 4: Auto Detect

₽ Reference

p.122 "Changing the Paper Size"

Paper Type: Bypass tray

Sets the display so you can see what type of paper is loaded in the bypass tray.

The paper types you can set for the bypass tray are as follows:

 No Display, Recycled Paper, Special Paper, Colour Paper, Letterhead, Preprinted Paper, Thick Paper, OHP, Plain: Dup.Back, Thick: Dup.Back

Note

☐ Default: *No display*

◆ Paper Type: Tray 1–4

Sets the display so you can see what type of paper is loaded in each paper tray. The print function uses this information to automatically select the paper tray.

The paper types you can set for trays are as follows:

 No Display, Recycled Paper, Special Paper, Colour Paper, Letterhead, Preprinted Paper

Note

☐ Default:

• Paper Type: No Display

• Copying Method in Duplex: 2 Sided Copy

• Apply Auto Paper Select: Yes

- □ When paper of the same type and size is loaded in two different paper trays and you want to specify tray for 2 Sided Copy and tray for 1 Sided Copy, specify the upper tray for 2 Sided Copy. If one of the trays is specified as the default in Paper Tray Priority, assign 2 Sided Copy to that tray.
- \square A \blacksquare appears next to the paper tray if **[No]** is selected in Auto Paper Select.

Limitation

□ [Auto Paper Select] can only be selected for the copier function if [No display] and [Recycled paper] are selected. If [No] is selected, Auto Paper Select is not valid for the tray.

Cover Sheet Tray

Allows you to specify and display the paper tray that is setting cover sheets. After selecting the paper tray, you can also specify the display timing and copy method for two-sided copying.

Note

- ☐ Default:
 - Tray to Program: Off
- ☐ Functions using the cover sheet tray setting are the front cover function and front/back cover function.
- □ When [At Mode Selected] is selected, cover sheet tray settings only appear when the cover function or slip sheet function is selected.
- ☐ When **[Full Time]** is selected, the cover sheet tray is always displayed.
- ☐ You can set Copying Method in Duplex only when [At Mode Selected] is selected.

"Covers", Copy Reference

Slip Sheet Tray

Allows you to specify and display the paper tray that will be inserting slip sheets. After selecting the paper tray, you can also specify the display timing and copy method.

𝚱 Note

- ☐ Default:
 - Tray to Program: Off
- ☐ When [At Mode Selected] is selected, slip sheet tray settings only appear when the cover function or slip sheet function is selected.

"Slip Sheets", Copy Reference

Timer Settings

Auto Off Timer

After a specified time has elapsed following job completion, the machine automatically turns off in order to conserve energy. This function is called "Auto Off".

The machine status after the Auto Off operation is referred to as "Sleep mode". For the Auto Off Timer, specify the time to elapse before Auto Off.

✔ Note □ Default: 60 minute(s) □ Enter a time interval between 10 seconds and 240 minutes, using the number keys □ From "Sleep mode", the machine is ready to use within 101 seconds. □ Auto Off may not work when error messages appear.

Energy Saver Timer

Set the amount of time the machine waits before switching to lower-power mode after copying has finished or the last operation is performed. The time can be set from 1 minute to 240 minutes using the number keys.

✓ Note☐ Default: 15 minute(s)

Panel Off Timer

Set the amount of time the machine waits before switching the panel off after copying has finished or the last operation is performed.

✓ Note □ The warm up time for making a copy from standby mode is 3 seconds for Panel off Level 1 and 15 seconds for Panel off Level 2. □ Default: 1 minute

☐ Enter a time interval between 10 seconds and 240 minutes, using the

number keys. System Auto Reset Timer

The System Reset setting automatically switches the screen to that of the function set in Function Priority, when no operations are in progress, or when an interrupted job is cleared. This setting determines the system reset interval. See p.49 "Function Priority".

| Se | e p.49 "Function Priority". |
|----|--|
| 8 | Note |
| | Default: ON, 60 seconds |
| | The time can be set from 10 to 999 seconds, using the number keys. |
| | |

| * | Copier/Document Server Auto Reset Timer (copier/Document Server) Specifies the time to elapse before copier and Document Server modes reset | |
|---|---|--|
| | ∅ Note | |
| | ☐ If [OFF] is selected, the machine does not automatically switch to the user code entry screen. | |
| | ☐ Default: ON, 60 Seconds | |
| | \Box The time can be set from 10 to 999 seconds, using the number keys. | |
| * | Facsimile Auto Reset Timer (facsimile) Specifies the time to elapse before the facsimile mode resets. | |
| | ✓ Note□ Default: 30 seconds | |
| | \square The time can be set from 30 to 999 seconds, using the number keys. | |
| * | Scanner Auto Reset Timer (scanner) Specifies the time to elapse before the scanner function resets. | |
| | ✓ Note □ If [OFF] is selected, the machine does not automatically switch to the user code entry screen. □ Default: ON, 60 seconds □ The time can be set from 10 to 999 seconds, using the number keys. | |
| * | Set Date Set the date for the copier's internal clock using the number keys. | |
| | Note □ To change between year, month, and day, press [←] and [→]. | |
| * | Set Time Set the time for the copier's internal clock using the number keys. | |

 \square To change between hours, minutes and seconds, press [\leftarrow] and [\rightarrow].

☐ Enter the time using the 24–hour format (in 1 second increments).

Key Operator Tools

The key operator must set the following items. For settings or more information, contact the key operator.

The key operator is recommended to program a key operator code when performing the settings. See p.58 "Key Operator Code".

User Code Management

Allows you to control who uses the machine by setting codes for users. User codes must be registered for user code management. See p.71 "User Code".

∅ Note

☐ Default: Printer: PC Control: ON

☐ By using "PC Control: ON" for the printer, you can keep a print log for each user code entered from the driver.

Key Counter Management

Select the functions and colour modes that you want to manage using the Key Counter Management.

External Charge Unit Management

Select the functions and colour modes that you want to manage using the External Charge Unit Management.

Key Operator Code

Specifies whether or not to use passwords (max. eight digits) to control Key Operator Tools settings for key operator codes.

☐ Default: OFF

☐ If you select [ON], enter the key operator code (max. eight digits) using the number keys, and then select [Partial] or [All Initial Settings] to set the access limit.

• If you selected [Partial]

A key operator code is only required for the Timer Setting, Key Operator Tools for System Settings, and Key Operator Tools for Facsimile Features. [Menu Protect] can be set for [Maintenance] in Printer Features. If you set [Menu Protect], you can set the key operator code for some Printer Features. See "Printer Features Parameters", Printer Reference 2.

• If you selected [All Initial Settings]:

A key operator code is required to access all items in System Settings, Copier/Document Server Features, Facsimile Features, Printer Features, and Scanner Features.

☐ If you select [All Initial Settings], you must enter a key operator code to access the Key Operator Code display.

Extended Security

Specify whether or not to use the security function.

Note

- ☐ Default: OFF
- ☐ You have to set a 6-digit key operator code to enable Extended Security. See p.58 "Key Operator Code".
- □ When the Extended Security function is on, a security mark ‡ appears on the left side of the date, in the upper right of the display panel.

For details about security, see p.155 "Security".

Display/Print Counter

Allows you to view and print the number of prints.

- Display/Print Counter
 Displays the number of prints for each function (Total, Copier, Facsimile, Printer, A3/DLT, Duplex, and Staple).
- Print Counter List
 Prints out a list of the number of prints made under each function.
- To print the counter list:
 - ① Press the [User Tools/Counter] key.
 - 2 Press [System Settings].
 - ③ Press [Key Operator Tools].
 - **4** Press [Display/Print Counter].
 - ⑤ Press [Print Counter List].



- 6 Press the [Start] key.
- ⑦ Press [Exit].

Display/Clear/Print Counter per User Code

Allows you to view and print the numbers of prints accessed with user codes, and to set those values to 0.

Note

- □ Press [♠] and [▼] to show all the numbers of prints.
- ☐ The number of prints may differ from the counter value shown in Display/Print Counter.
 - Print counter per user code
 Prints the number of prints made under each user code
 - Clear counter per user code
 Sets the number of prints made under each user code to 0.

- Print list for each user code, see p.73 "Printing the Counter for Each User Code".
 - Print counter for all user codes
 Prints the number of prints made under all user codes.
 - Clear counter for all user codes
 Sets the number of prints made under all user codes to 0.

Print Address Book: Destination List

You can print the destination list registered in the Address Book.

- Print in Title 1 Order
 Prints the Address Book in Title 1 order.
- Print in Title 2 Order
 Prints the Address Book in Title 2 order.
- Print in Title 3 Order
 Prints the Address Book in Title 3 order.
- Print Group Dial List Prints the group Address Book.
- ① Select the print format.
- ② To print the list on two-sided pages, select [Print on 2 Sides].
- ③ Press the [Start] key. The list prints out.

Panel Off Level

Specifies the panel off level.

| Level | Warm-up time |
|---------|------------------|
| Level 1 | about 3 seconds |
| Level 2 | about 15 seconds |

Note

☐ Default: Level 1

Address Book Management

You can add, change, or delete user information in the Address Book and facsimile/scanner functions destinations.

For details about these operations, seep.69 "User Name", p.71 "User Code", p.76 "Fax Destination", and p.81 "E-mail Destination", p.84 "Registering Folders", p.91 "Registering a Protection Code".

• [Program/Change]

This registers new user codes. You can register and change the items below:

- User Name
 - User (destination) name, key display, registration number, title selection
- User Code

User code, available functions

• Fax Dest.

Fax number, international TX mode, fax header, label insertion

• E-mail

E-mail address, sender registration

- Folder
 - Protocol, path, user name, password, port no., server name
- Protect Dest.

Sender's name, folder, protection code

• Group

• [Delete]

Deletes a user.

- \square You can register up to 500 user codes.
- ☐ You can also register user codes using SmartNetMonitor for Admin.
- ☐ You can also register user codes using a Web browser.

♦ Address Book: Program/Change/Delete Group

You can register multiple users in a group.

This allows you to easily control registered users in each group.

For details about operations, see p.93 "Registering Destinations to a Group".

• [Program/Change]

This registers new groups, or changes the group name, key display, title selection, registration number or protection code. You can also secure e-mail destinations and folders.

• [Delete]

Deletes a group.

Note

- \square You can register up to 100 groups.
- ☐ You can also group users (destinations) using a Web browser. See the Web browser's Help.

Address Book: Program/Change/Delete Transfer Request

You can register fax destinations for the Transfer Request function in facsimile mode.

For details about operations, see p.97 "Registering the Transfer Request".

• [Program/Change]

This registers new transfer requests and receiving stations, or changes the transfer request name, key name, title selection, registration number, fax destination, or e-mail address.

• [Delete]

Deletes a transfer request.


☐ You can register up to 100 transfer requests.

Address Book: Change Order

Changes the order of registered users (destinations).

Note

- ☐ You can rearrange the order of items on the same page, but you cannot move items to another page. For example, you cannot move an item from "PLANNING" ([OPQ]) to "DAILY" ([CD]).
- ① Press the [User Tools/Counter] key.
- ② Press [System Settings].
- ③ Press [Key Operator Tools], and then press [▼Next].
- Press [Address Book: Change Order].



⑤ Press the user (destination) key you want to move.






 \square You can select a user using the number key.

Press the user (destination) key that is in the place you want to move to.



The user (destination) moves to the selected place, and the other users' keys will shift also.




☐ You can select a user using the number key.

Address Book: Edit Title

You can edit the title to easily find a user.

- ① Press the [User Tools/Counter] key.
- ② Press [System Settings].
- 4 Press [Address Book: Edit Title].



⑤ Press the title key you want to change.



- Enter the new name, and then press [OK].
- ⑦ Press [OK].
- Press [Exit].

♦ Address Book: Select Title

Specifies the title to select a user.

Note

☐ Default: Title 1

Auto Delete File

Specifies whether documents stored in the Document Server are to be deleted or not after a specified period of time elapses.

▶ Note □ Default: Yes After 3 days □ If you select [Yes], documents stored subsequently are deleted after the specified period. □ If you select [No], documents are not automatically deleted. □ If you select [Yes], enter a number of days from of 1 to 180 (in 1 day increments). □ The default is three days, meaning that documents are deleted three days

Delete All Files

Deletes all documents stored in the Document Server.

- ☐ Even if a password is already set, all documents are deleted.
- ☐ A confirmation message appears. To delete all documents, select **[Yes]**.

Password Management for Stored Files

(72 hours) after they are stored.

- Unlocking a locked document
 When a document is locked due to a wrong password being entered, this function unlocks the document, allowing access.
- Temporarily disabling document security
 Password-protected documents can be temporarily accessed, without entering the password.

- □ Default: Do not Unlock
- ☐ Select [Unlock] only when you forget the password. After accessing the document, be sure to select [Do not Unlock].

p.157 "Unlocking a locked document"

p.157 "Temporarily Disabling Document Security"

◆ AOF (Always ON)

Specify whether or not to use Auto Off.

Note

☐ Default: ON

Program/Change LDAP Server

Programming an LDAP server allows you to look up e-mail destinations from the LDAP server Address Book directly. This function is available when you send scan files by e-mail in scanner mode.

You can program and change the identification name, server name, search base, port no., authentication, user name, password, and search options.

₽ Reference

For details about these operations, see p.101 "Programming/Changing LDAP Server".

Use LDAP Server

Specify whether or not to use the LDAP server.

☐ Default: OFF

☐ If you select [OFF], [Search LDAP] will not appear on the searching display.

Address Book

Registering user information, such as fax number and e-mail address, in the Address Book allows you to manage them together.

∰Important

Address Book data is stored on the hard disk. It can be lost if there is some kind of hard disk failure. The manufacturer shall not be responsible for any damages resulting data loss.

𝒯 Note

☐ Using [Address Management Tool] in SmartNetMonitor for Admin, you can backup Address Book data. We recommend backing up data when using the Address Book.

For details about SmartNetMonitor for Admin and how to install it, see *Printer Reference* 1.

For operating instructions, see SmartNetMonitor for Admin Help.

You can register and manage the following items in the Address Book:


User Name

Register the destination name and key display. This is the basic information required for managing destinations.



User Code

Register user codes to restrict particular functions to certain users, and check their use of each function.



Fax Dest.

Register fax numbers, line, fax header and select label insertion.



E-mail

Register e-mail addresses in the Address Book.



Folder

Register the protocol, path name, user name, password, and server name.

SMB



FTP



Protect Dest.

Set a protection code to stop sender's names or folders being accessed.



Group

Group registered fax destinations, e-mail destinations and folders to manage them better.



Managing user (destination) names

Register the user (destination) name and the key display beforehand so you can specify the destination simply by selecting the user (destination) key for fax, e-mail and folder.

See p.69 "User Name".

Sending fax by Quick Dial

Register a fax number in the Address Book so you can specify it only by selecting the fax destination, shown on the fax initial display when sending a fax. When label insertion is set to "ON", the receiver's name and standard messages are printed on the fax message when it is received at the other end.

See p.76 "Fax Destination".

Sending e-mail by Quick Dial

Register e-mail addresses in the Address Book, so you can specify e-mail destinations simply by selecting them from the fax initial display when sending by internet fax.

You can also specify an e-mail address by selecting the destination shown on the initial scanner display when sending a document using the scanner function.

Registered e-mail address can be used as the sender's address, and the sender's address are automatically entered in the "From" field of an e-mail header.

See p.81 "E-mail Destination".

Sending scanned files to a shared folder directly

After registering the path name, user name and password, you can connect to a shared folder simply by selecting the destination shown on the initial scanner display whenever sending files using the scanner function to a shared folder.

To share the folder using Windows, select the SMB protocol.

To register the folder to the FTP server, select the FTP protocol.

See p.84 "Registering Folders".

Preventing unauthorized user access to shared folders from the machine

Designate a destination as "Protect" when registering a protection code to prevent that e-mail destination, sender's name, and folder destination from being accessed.

You can prevent unauthorized access to registered folders. See p.91 "Registering a Protection Code".

Managing users and machine usage

Register user codes to limit users to the following functions and check their use of each function:

- Copier
- Document Server
- Facsimile
- Scanner
- Printer


See p.71 "User Code".

User Name

The user name is useful for selecting a destination when sending faxes or email. You can also use it as a folder destination.

Registering a User Name

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- 5 Press [New Program].
- Press [Change] on the right of the user (destination) name.

The user (destination) name entry display appears.

p.153 "Entering Text"

Enter the user (destination) name, and then press [OK].

☐ The user name can be used for documents in the Document Server. For details about the Document Server, see p.33 "Using the Document Server".

To select the title

Press the key for the classification you want to use under Select Title.



- Note
- ☐ The keys you can select are as follows:
 - [Freq.]... Added to the page that is displayed first.
 - [AB],[CD],[EF],[GH],[IJK],[LMN],[OPQ],[RST],[UVW],[XYZ], [1] to [10]...
 Added to the list of items in the title selected.
- ☐ You can select **[Freq.]** and one more page for each title.
- To continue registering the user name, press [Continue to Program], and then repeat the procedure from step 6.
- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Changing a User Name

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- Select the registered user (destination) you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.

To change the user (destination) name or key display

- Press [Change] on the right of the user (destination) name or key display.
- Enter the user (destination) name or key display, and then press [OK].

p.153 "Entering Text"

To change the title

- Press the key for the classification you want to use from Select Title.
- 6 Press [OK].
- 7 Press [Exit].
- 8 Press the [User Tools/Counter] key.

Deleting a User

- Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- 4 Press [Address Book Management].
- Press [Delete].
- **6** Select the user (destination) you want to delete.

Press the user (destination) key, or enter the registered number using the number keys.

- 7 Press [Yes].
- 8 Press [Exit].
- 9 Press the [User Tools/Counter] key.

User Code

Register user codes to limit users to the following functions and check their use of each function:

- Copier
- Document Server
- Facsimile
- Scanner
- Printer

- ☐ The number of copies made of documents stored in the Document Server using the facsimile function is counted for each user code. This allows you to check each user's usage.
- ☐ The number of copies scanned using the scanner function is counted for each user code. This allows you to check each user's usage.
- □ To automatically register the printer driver user code, select [PC Control: ON] for the printer in User Code Management. To use the user code set in User Tools, select [PC Control: OFF], and then select [Black & White] or [Colour]. Set the user codes registered in User Tools for the printer driver. See p.58 "User Code Management".


For details about setting user codes for the printer driver, see *Printer Reference 1* or the printer driver Help.

#Important

☐ The functions associated with each user code are the same. If you change or delete user codes, management data and limits associated with that code become invalid.

Registering a New User Code


Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- Press the user (destination) whose code is registered, or enter the registered number using the number key.
 - Note
 - ☐ To register the user (destination) name, see p.69 "Registering a User Name".
- 6 Press [User Code].
- **7** Enter the user code using the number keys, and then press [#].



Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then enter the code again.
- 8 Select the functions to be used with the user code from Available Functions.



- 9 Press [OK].
 - **∅** Note
 - ☐ To continue registering user codes, repeat the procedure from step ⑤
- Press [Exit].
- Press the [User Tools/Counter] key.

Changing a User Code

- **∅** Note
- ☐ Even if you change a user code, the counter value will not be cleared.
- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- 4 Press [Address Book Management].
- Select the registered user code you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

- Note
- ☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.
- ☐ To change the user (destination) name, key display and title, see p.70 "Changing a User Name".
- 6 Press [User Code].
- Press [Change], and then enter the new user code using the number keys.



8 Press [#].

To change the available functions

- Press the key to select the functions to enable them.
 - Note
 - Press the key to highlight it, and then the function is enabled.
- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a User Code

Note

- ☐ After clearing the user code, the counter is automatically cleared.
- ☐ To delete a user entirely, see p.70 "Deleting a User".
- Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- 4 Press [Address Book Management].
- **5** Select the user (destination) whose code is to be deleted.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [User Code].
- Press [Change] to delete the user code, and then press [#].



- 8 Press [OK].
- 9 Press [Exit].
- Press the [User Tools/Counter] key.

Displaying the Counter for Each User Code

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools].
- 4 Press [Display/Clear/Print Counter per User Code].
- Select [Copy Counter], [Print Counter], [Transmission Counter] or [Scanner Counter].

Counters for individual function usage under each user code appear.

Printing the Counter for Each User Code

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- 3 Press [Key Operator Tools].
- Press [Display/Clear/Print Counter per User Code].
- Select a user code from the left side of the display.



- ☐ Press [Select all on the page] to select all user codes on the page.

Press [Print Counter List] under Per User Code.



- Note
- ☐ Enter the user code, and then press [#] if the user code is registered.
- Select the function usage you want to print from [Copy Counter], [Print Counter], [Transmission Counter], and [Scanner Counter].
- 8 Press [Print].

To print the number of prints for all user codes

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools].
- Press [Display/Clear/Print Counter per User Code].
- Press [Print Counter List] under All User Codes.



- Note
- ☐ Enter the user code, and then press [#] if the user code is registered.

- 6 Select the function usage you want to print from [Copy Counter], [Print Counter], [Transmission Counter], and [Scanner Counter].
- **7** Press [Print].

Clearing the Number of Prints

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools].
- Press [Display/Clear/Print Counter per User Code].
- **5** Select the user code to clear.

To clear the number of prints made under a user code

• Select the user code from the left side of the display.



- Note
- ☐ Press [Select all on the page] to select all user codes on the page.
- Press [Clear] under Per User Codes.



- Select the function usage you want to clear from [Copy Counter], [Print Counter], [Transmission Counter], and [Scanner Counter].
- 4 Press [OK].

To clear the number of prints for all user codes

• Press [Clear] under All User Codes.



- Select the function usage you want to clear from [Copy Counter], [Print Counter], [Transmission Counter], and [Scanner Counter].
- 3 Press [OK].
- 6 Press [Exit].
- **7** Press the [User Tools/Counter] key.

Fax Destination

Register a fax destination so you do not need to enter fax numbers each time, and can send documents that have been scanned in using the facsimile function.

- It is easy to select the fax destination if you register a "User (Destination) Name" and "Key Display" for the fax destination.
- You can register fax destinations as a group.

You can program the following items in a fax destination:

Fax number

Registers the destination's fax number. You can enter a fax number using up to 128 digits. You must include every digit in the number.

SUB Code

Registering a SUB Code allows you to use Confidential Transmission to send messages to the other fax machines which support a similar function called "SUB Code". See "SUB Code", Facsimile Reference < Advanced Features>.

SEP Code

Registering a SEP Code allows you to use Polling Reception to receive faxes from the other fax machines which support Polling Reception. See "SEP Code", Facsimile Reference <Advanced Features>.

Line

If the optional extra G3 interface unit is installed, you can select the line type per destination.

Fax header

You can select to print a fax header on fax messages the other party receives. The default is "1st Name". See Facsimile Reference < Advanced Features>.

Label insertion

With this function you can have the receiver's name printed on the message when it is received at the other end. The name is printed at the top of the page and will be preceded by "To". You can also have a standard message stamped on the second and third lines after that.

∅ Note

- ☐ Fax header and label insertion are also printed when sending by e-mail using the fax function.
- ☐ You can program a standard message other than those registered in the machine. See "Programming, Changing, and Deleting Standard Messages", Facsimile Reference <Advanced Features>.

International TX mode

When setting the International TX mode to **[ON]**, the machine transmits more carefully by lowering transmission speed. However, communication times increase.

Registering a Fax Destination

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- Press the user (destination) you want to register or enter the registered number using the number keys.
 - **𝚱** Note
 - ☐ To register the user (destination) name, see p.69 "Registering a User Name".
- 6 Press [Fax Dest.].
- 2 Enter the fax number using the number keys, and then press [OK].



To select the line

1 Press [Select Line].



2 Select the line, and then press [OK].

To program the SUB Code

- Press [Adv. Features], and then select [SUB Code].
- **2** Press [Change] under TX SUB Code.
- Tenter a SUB Code using the number keys, and then press [OK].
- To enter a password, press [Change] under Password (SID).
- **5** Enter a password using the number keys, and then press [OK].
- 6 Press [OK].

To program the SEP Code

- Press [Adv. Features], and then select [SEP Code].
- **2** Press [Change] under RX SEP Code.
- Senter a SEP Code using the number keys, and then press [OK].
- 4 To enter a password, press [Change] under Password (PWD).
- **6** Enter a password using the number keys, and then press [OK].
- 6 Press [OK].

To set the International TX Mode

- Press [Change] under International TX Mode.
- 2 Select [OFF] or [ON], and then press [OK].

To select the fax header

Note

- ☐ You can register the fax header name in Program Fax Information in the system settings for Facsimile Features. See "Programming", Facsimile Reference < Basic Features>.
- 1 Press [Change] under Fax Header.
- 2 Select [1st Name] or [2nd Name], and then press [OK].

To set label insertion

When Label Insertion is set to ON, the receiver's name and standard messages are printed on the fax message when it is received at the other end.

- Press [Change] under Label Insertion.
- 2 Select [ON].
- 3 Press [Change] under Line 2.
- 4 Select a standard message to print on the second line. To stamp a customized message, press [Custom Message].



6 Enter a message, and then press [OK].

p.153 "Entering Text"

- 6 Press [OK].
- Press [Change] under Line 3.
- **3** Select a standard message, and then press [OK].
- Press [OK].
- 8 Press [OK].

- ☐ When a group is registered, you can also set label insertion to the group. See p.93 "Registering Destinations to a Group".
- 9 Press [Exit].
- Press the [User Tools/Counter] key.

Changing a Registered Fax Destination

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- **5** Select the registered fax destination user you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

- ☐ If you press ⑤, you can search for a user by user name/index, user code, fax number, or e-mail address.
- ☐ To change the user (destination) name, key display and title, see p.70 "Changing a User Name".
- 6 Press [Fax Dest.].

7 Change the settings.

To change the fax number

1 Press [Change] under Facsimile No..



2 Enter the new fax number using the number keys, and then press [OK].

To change the line

1 Press [Select Line].



- 2 Select the line.
- 3 Press [OK].

To change the SUB Code

- Press [Adv. Features].
- Press [SUB Code].
- 3 Press [Change] under TX SUB Code.
- 4 Enter the new SUB Code, and then press [OK].
- **(SID).** To change the password, press [Change] under Password (SID).
- 6 Enter the new password, and then press [OK].
- Press [OK].

To change the SEP Code

- Press [Adv. Features].
- 2 Press [SEP Code].
- 3 Press [Change] under RX SEP Code.
- 4 Enter the new SEP Code, and then press [OK].
- **(5)** To change the password, press [Change] under Password (PWD).
- 6 Enter the new password, and then press [OK].
- Press [OK].

To change the fax header

- 1 Press [Change] under Fax Header.
- Select the new fax header, and then press [OK].

To change the label insertion

- Press [Change] under Label Insertion.
- **2** Press [Change] under Line 2.
- 3 Select the new standard message or press [Custom Message] to enter the new message.
- 4 Press [OK].
- **6** Press [Change] under Line 3.
- **6** Select the new standard message, and then press [OK].
- Press [OK].
- 8 Press [OK].
 - Note
 - ☐ To change the user (destination) name, key display and title, see p.70 "Changing a User Name".

- 9 Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a Registered Fax Destination

- ☐ If you delete a destination that is a specified delivery destination, messages to its registered Personal Box, for example, cannot be delivered. Be sure to check the settings in the fax function before deleting any destinations.
- ☐ To delete a user entirely, see p.70 "Deleting a User".
- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- **5** Select the fax destination user you want to delete.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [Fax Dest.].
- Press [Change] under Facsimile No..
- Press [Delete All], and then press [OK].



- 9 Press [OK].
- 10 Press [Exit].
- Press the [User Tools/Counter] key.

E-mail Destination

Register e-mail destinations so you do not need to enter an e-mail address every time, and can send scan files from scanner or fax function by email.

- It is easy to select the e-mail destination if you register "User (Destination) Name" and "Key Display" as the e-mail destination.
- · You can register e-mail destinations as a group.
- You can use the e-mail address as the sender's address when sending scan files in scanner mode. If you want to do this, set a protection code on the sender address to prevent unauthorized access. See p.91 "Registering a Protection Code".

Note

- ☐ You can select an e-mail address from an LDAP server, and then register it in the Address Book. "Sending Scan File by E-mail", Scanner Reference.
- ☐ You can set the machine to send a transmission result e-mail whenever a user transmission is sent. See Facsimile Reference < Advanced Features>.

Registering an E-mail **Destination**

Press the [User Tools/Counter] key.



2 Press [System Settings].




- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- **5** Press the user (destination) you want to register, or enter the registered number using the number keys.
 - Note
 - ☐ To register the user (destination) name, see p.69 "Registering a User Name".
- 6 Press [E-mail].
- Press [Change] under E-mail Address.



Enter the e-mail address.

Entering the e-mail address

• Enter the e-mail address.



2 Press [OK].

Using the e-mail address as the sender

When an e-mail address is entered, it can be used as the sender's address.

- 1 Press [ON] under Register as Sender.
- 9 Press [OK].
 - Note
 - ☐ When a group is registered, other e-mail destinations can be added to the group. See p.93 "Registering Destinations to a Group".
- 10 Press [Exit].
- Press the [User Tools/Counter] key.

Changing a Registered E-mail Destination

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- Select the registered e-mail address user you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

Note

- ☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.
- ☐ To change the user (destination) name, key display, and title, see p.70 "Changing a User Name".

- 6 Press [E-mail].
- Press [Change] under E-mail Address.



- Enter the e-mail address, and then press [OK].

p.153 "Entering Text"

- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a Registered E-mail Destination

To delete a user entirely, see p.70 "Deleting a User".

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- 4 Press [Address Book Management].
- **5** Select the e-mail address user you want to delete.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [E-mail].
- Press [Change] under E-mail Address.
- 8 Press [Delete All], and then press [OK].

- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Registering Folders

By registering a shared folder, you can send scan files to it directly.

There are two types of protocol you can use:

- SMB
 For sending files to shared Windows folders
- FTP
 Use when sending files to an FTP
 server.

Ø Note

- ☐ For details about protocols, server names, and folder levels, ask your network administrator.
- ☐ You can prevent unauthorized users from accessing folders from the machine. See p.91 "Registering a Protection Code".
- You can only select either SMB or FTP. If you change protocol after finishing your settings, all previous entries are cleared.
- ☐ You can register up to 50 folders per group. Files cannot be sent to a group with over 50 folders registered.

For details about network settings, see *Network Guide*.

For details about Scan to Folder, see *Scanner Reference*.

Using SMB to Connect

Note

☐ To register a folder in an FTP server, see p.88 "Using FTP to Connect".

To register an SMB folder

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- Press the user (destination) you want to register or enter the registered number using the number keys.

Note

- ☐ To register the user (destination) name, see p.69 "Registering a User Name".
- 6 Press [Folder].

7 Press [SMB].



Note

☐ To specify a folder, you can either enter the path manually or locate the folder by browsing the network.

p.85 "To locate the folder manually"

p.85 "Using Browse Network to locate the folder"

To locate the folder manually

- 1 Press [Change] under Path.
- 2 Enter the path where the folder is located.

- ☐ Enter the path using this format: "\\ServerName\\Share-Name\\Path\\Name".
- ☐ You can also enter an IP address.
- ☐ You can enter a path using up to 128 characters.
- 3 Press [OK].

Note

- ☐ If the format of the entered path is not correct, a message appears. Press [Exit], and then enter the path again.
- 4 Press [Change] under User Name.

5 Enter the user name, and then press [OK].

Note

- This is a user name which is authorized to access the folder.
- **6** Press [Change] under password.
- The Enter the user's password, and then press [OK].


Using Browse Network to locate the folder

• Press [Browse Network].

The client computers sharing the same network as the machine appear.

Note

- ☐ You can enter your user name and password before pressing [Browse Network]. If you do, the Browse Network display only lists client computers you are authorized to access.
- **2** Select a client computer.



Shared folders under it appear.

Note

☐ You can press [Up One Level] to switch between levels.

3 Select the folder you want to register.

The Logon display appears.

Note

- ☐ If you have already entered an authorized user name and password, the Logon display will not appear. Proceed to step ⑥.
- 4 Enter the user name.

- This is a user name which is authorized to access the folder.
- **5** Enter the user's password, and then press [OK].

The Browse Network display reappears.

𝒯 Note

- ☐ If the entered user name or password is not correct, a message appears. Press [Exit], and then enter the user name and password again.
- 6 Press [OK].
- Press [Connection Test] to check the path is set correctly.
- 9 Press [Exit].

- ☐ If the connection test fails, check the settings, and then try again.
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Changing a registered folder

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- **5** Select the user of the registered folder you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

- ☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.
- ☐ To change the user (destination) name, key display, and title, see p.70 "Changing a User Name".
- 6 Press [Folder].
- Select the items you want to change.

To change the protocol

1 Press [FTP].



2 A confirmation message appears. Press [Yes].

☐ Changing the protocol will clear all settings made under the previous protocol.

3 Enter each item again.

p.88 "To register an FTP folder".

Changing items under SMB

- 1 Press [Change] under Path.
- Enter the new path where the folder is located, and then press [OK].

- ☐ You can also use Browse Network to specify a new folder. For details, see p.85 "Using Browse Network to locate the folder".
- 3 Press [Change] under User Name.
- 4 Enter the new user name, and then press [OK].

This is a user name which is authorized to access the folder.

- **6** Press [Change] under Password.
- 6 Enter the new password, and then press [OK].
- Press [Connection Test] to check the path is set correctly.
- 9 Press [Exit].

Note

- ☐ If the connection test fails, check the settings, and then try again.
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a registered folder

Note

- ☐ To delete a user entirely, see p.70 "Deleting a User".
- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- **5** Select the user of the folder you want to delete.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [Folder].
- Press the protocol which is not currently selected.

A confirmation message appears.

- 8 Press [Yes].
- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Using FTP to Connect

Note

☐ To register a shared folder configured in Windows, see p.84 "Using SMB to Connect".

To register an FTP folder

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- Press the user (destination) you want to register, or enter the registered number using the number keys.

Note

- ☐ To register the user (destination) name, see p.69 "Registering a User Name".
- 6 Press [Folder].

7 Press [FTP].



p.85 "To locate the folder manually"

p.85 "Using Browse Network to locate the folder"

Press [Change] under Server Name.



- Enter the server name, and then press [OK].
 - Note
 - ☐ You can enter a server name using up to 64 characters.
- Press [Change] under Path.
- 11 Enter the path.

Note

- ☐ You can enter an absolute path, using this format: "/user/home/username"; or a relative path, using this format: "directory/sub-directory".
- ☐ If you leave the path blank, the login directory is assumed to be the current working directory.
- ☐ You can also enter an IP address.
- ☐ You can enter a path using up to 128 characters.

Press [OK].

- Note
- ☐ To change the port number, press [Change] under Port No.. Enter the port number using the number keys, and then press [#].
- \square You can enter 1 to 65535.
- Press [Change] under User Name.
- Enter the user name, and then press [OK].
 - **𝚱** Note
 - ☐ This is a user name which is authorized to access the folder.
- Press [Change] under Password.
- Enter the user's password, and then press [OK].
- Press [Connection Test] to check the path is set correctly.
- 18 Press [Exit].
 - Note
 - ☐ If the connection test fails, check the settings, and then try again.
- Press [OK].
- 20 Press [Exit].
- Press the [User Tools/Counter] key.

Changing a registered folder

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].

5 Select the user of the registered folder you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

- ☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.
- ☐ To change the user (destination) name, key display, and title, see p.70 "Changing a User Name".
- 6 Press [Folder].
- Select the items you want to change.

To change the protocol

• Press [SMB].



- **2** A confirmation message appears. Press [Yes].
 - Note
 - ☐ Changing the protocol will clear all settings made under the previous protocol.
- 3 Enter each item again.

p.84 "To register an SMB folder".

Changing items under FTP

- 1 Press [Change] under Port No.
- 2 Enter the new port number, and then press [#].
- 3 Press [Change] under Server Name.
- 4 Enter the new server name, and then press [OK].
- 6 Press [Change] under Path.
- **6** Enter the new path, and then press [OK].
- Press [Change] under User Name.
- 8 Enter the new user name, and then press [OK].

This is a user name which is authorized to access the folder.

- **9** Press [Change] under Password.
- Enter the new password, and then press [OK].
- 8 Press [Connection Test] to check the path is set correctly.
- 9 Press [Exit].

 - ☐ If the connection test fails, check the settings, and then try again.
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a registered folder

Note

- ☐ To delete a user entirely, see p.70 "Deleting a User".
- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- **5** Select the user of the folder you want to delete.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [Folder].
- Press the protocol which is not currently selected.

A confirmation message appears.

- 8 Press [Yes].
- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Registering a Protection Code

You can stop sender's names or folders being accessed by setting a protection code.

You can use this function to protect the following:

- Folders You can prevent unauthorized access to folders.
- · Sender's names (when sending emails)
 - You can prevent misuse of sender's names.

 - \square This function is not available when using Internet Fax to send e-mails.

Registering a Protection Code To a Single User

1 Press the [User Tools/Counter] key.




7FI S110F

2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].

- **5** Press the user (destination) key you want to register or enter the registered number using the number keys.
- 6 Press [Protect Dest.].



To protect the sender name

• Press [Protect] under Sender's Name.




To protect the folder

- Press [Protect] under Folder.
- Press [Change] under Protection Code.
- 8 Enter a protection code using the number keys, and then press [#].
 - Note
 - ☐ You can enter up to eight digits.
- 9 Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Registering a Protection Code To a Group User

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- Press [Address Book: Program/Change/Delete Group].
- Press the group key you want to register or enter the registered number using the number keys.
- 6 Press [Protect Dest.].



- **7** Press [Protect] under Folder.
- 8 Press [Change] under Protection Code.
- **9** Enter a protection code using the number keys, and then press [#].
 - **𝒯** Note
 - ☐ You can enter up to eight digits.
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Registering Destinations to a Group

Register destinations to a group to easily control registered fax, e-mail and folders for each group.

To group destinations, the groups must be registered beforehand.

- Note
- ☐ You can register up to 500 groups.
- When using Scan to Folder function, you cannot send scan files to a group with over 50 folders registered.
- ☐ You can set a protection code to prevent unauthorized access to the folders registered in a group. For details, see p.91 "Registering a Protection Code".

Registering a New Group

1 Press the [User Tools/Counter] key.




2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next].
- Press [Address Book: Program/Change/Delete Group].
- Press [New Program].

6 Press [Change] under Group Name.



Enter the group name, and then press [OK].

The Key Display name sets automatically.

- PReference p.153 "Entering Text"
- Press the title key under Select Title, if necessary.
 - **∅** Note
 - ☐ The keys you can select are as follows:
 - [Freq.]... Added to the page that is displayed first.
 - [AB], [CD], [EF], [GH], [IJK], [LMN], [OPQ], [RST], [UVW], [XYZ], [1] to [10]...
 Added to the list of items in the selected title.
 - ☐ You can select [Freq.] and one more page for each title.
- When you want to change the key display, press [Change] under Key Display. Enter the key display, and then press [OK].
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Registering Destinations to a Group

You can register destinations to a group.


When registering new destinations, you can also register groups at the same time.

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- 4 Press [Address Book Management].
- Select the user (destination) to register in a group.

Press the user (destination) key, or enter the registered number using the number keys.

∅ Note

- ☐ If you press ☒, you can search for a user by user name/index, user code, fax number, or e-mail address.
- 6 Press [Group].
- Select a group to which you want to register the destinations.



- Note
- ☐ If you press ⑤, you can search for a group by entering the group name.
- 8 Press [OK].


- 9 Press [Exit].
- Press the [User Tools/Counter] key.

Removing a Destination from a Group

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- 4 Press [Address Book Management].
- **5** Select the user (destination) to remove from a group.

Press the user (destination) key, or enter the registered number using the number keys.

- 6 Press [Group].
- **7** Press the highlighted group key.



- 8 Press [OK].
- 9 Press [Exit].
- Press the [User Tools/Counter] key.

Displaying Destinations Registered in Groups

You can check the user (destination) of each group.

- Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- Press [Address Book: Program/Change/Delete Group].
- **5** Select the group where the data you want to check is registered.
- 6 Press [Programed Users].

All the user (destination) names appear.



- 7 Press [OK].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.


Changing a Group Name

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext].
- Press [Address Book: Program/Change/Delete Group].

- Press the group key you want to change.
- 6 Enter the items.

To change the group name and key display

1 Press [Change] under Group Name or Key Display.



2 Enter the new group name or key display, and then press [OK].

To change the title

• Press the title key under Select Title.

To change the registration number

- Press [Change] under Registration No..
- Enter the new registration number using the number keys.
- **3** Press [#].
- 7 Press [OK].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a Group

- 1 Press the [User Tools/Counter] key.
- **2** Press [System Settings].
- Press [Key Operator Tools], and then press [▼Next].
- Press [Address Book: Program/Change/Delete Group].
- 5 Press [Delete].
- 6 Press a group key you want to delete.
- 7 Press [Yes].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.

Registering the Transfer Request

This section describes how to register the Transfer Station and Receiving Station used in the fax function's Transfer Request.

Note

☐ Before you can use Transfer Request, you must program the Polling ID and set the Transfer Report. See "Programming a Polling ID"and "Transfer Report", Facsimile Reference <Advanced Features>.

❖ Transfer Station

Refers to the machine that receives the Transfer Request to forward incoming messages to another destination.

Receiving Station

Refers to the facsimile or computer that receives messages from the Transfer Station.

Limitation

- When messages are transferred by fax, Transfer Stations must be machines of the same make as this one, and have the Transfer Station function.
- When messages are transferred by e-mail, Transfer Stations must be machines of the same make as this one, and have both the Transfer Station and Internet Fax functions.
- ☐ You cannot use Transfer Request without programming the fax number or e-mail address of the Requesting Party in the Address Book (Quick Dial) of the Transfer Stations.

Note


- Polling ID's of the Requesting Party (this machine) and Transfer Stations must be identical.
- ☐ You can have up to 30 Receiving Stations per Transfer Station. If you specify a Transfer Station Group, the Group counts as a single receiver.

Registering a Transfer Station/Receiving Station

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [VNext].
- Press [Address Book: Program/Change/ Delete Transfer Request].
- Press [New Program].
- 6 Set the Transfer Request's information.

To register the Transfer Request name and key display

• Press [Change] under Transfer Request Name or Key Display.

The user (destination) name or key display entry display appears.

2 Enter the Transfer Request name or key display, and then press [OK].

₽ Reference

p.153 "Entering Text"

To select the title

■ To associate a Transfer Request name with a title, press the title key under Select Title.



Note

- ☐ The keys you can select are as follows:
 - [Freq.]... Added to the page that is displayed first.
 - [AB], [CD], [EF], [GH], [IJK], [LMN], [OPQ], [RST], [UVW], [XYZ], [1] to [10]... Added to the list of items in the selected title.
- ☐ You can select [Freq.] and one more page for each title.
- 7 Press [Fax].
- Enter the items. See step 7 on p.77 "Registering a Fax Destination".
- 9 Press [E-mail].

- Enter the items. See steps 7 and 8 on p.81 "Registering an E-mail Destination".
- Press [Receiving Station].
- Specify the Receiving Stations.
 - Note
 - ☐ When specifying the Receiving Stations, use the numbers stored in Quick Dial keys, or Groups in the Transfer Station.

Quick Dial

- Press [#Quick Dial].
- 2 Enter the number stored in the Quick Dial of the Transfer Station using the number keys.

For example, to select the destination stored in Quick Dial 01 of the Transfer Station, enter [0][1].

3 To specify an additional Receiving Station, press [Add].

Group Dial

- Press [#XXGroup Dial].
- **2** Enter the Group number using the number keys.

For example, to select the destinations stored in Group 04 of the Transfer Station, enter [0][4].

- **3** To specify an additional Receiving Station, press [Add].
- When you have specified all the Receiving Stations, press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

Changing a Registered Transfer Station/Receiving Station

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- Press [Address Book: Program/Change/ Delete Transfer Request].
- **5** Select the registered Transfer Station/Receiving Station user you want to change.

Press the user (destination) key, or enter the registered number using the number keys.

𝒜 Note

- ☐ If you press ☒, you can search for a user by Transfer Request name, fax number, or e-mail address.
- **6** Enter the items.

To change the Transfer Request name and key display

- Press [Change] under Transfer Request Name or Key Display.
- 2 Enter the new Transfer Request Name or key display, and then press [OK].

To change the title

• Press the title key under Select Title.

To change the Transfer Station

1 Press [Fax].

Proceed to step 3 when messages are transferred by e-mail.

- 2 Change the Transfer Station's information. See step 7 on p.78 "Changing a Registered Fax Destination".
- 3 Press [E-mail].
- 4 Change the Transfer Station's information. See steps 7 and 8 on p.82 "Changing a Registered E-mail Destination".

To change the Receiving Station

- Press [Receiving Station].
- **2** Select the Receiving Station you want to change.
- Press [Clear] to clear the number, and then enter the new number using the number keys.
- 7 Press [OK].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.

Deleting a Registered Transfer Station/Receiving Station

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [Next].
- Press [Address Book: Program/Change/ Delete Transfer Request].
- **5** Press [Delete].

6 Select a Transfer Request you want to delete.

Press the Transfer Request key, or enter the registered number using the number keys.

- 7 Press [Yes].
- 8 Press [Exit].
- **9** Press the [User Tools/Counter] key.

Programming/Changing LDAP Server

Programming an LDAP server allows you to look up e-mail destinations from the LDAP server Address Book directly. This function is available when you send scan files by e-mail using scanner function.

- ☐ Select [ON] in the Use LDAP Server setting to use this function. See p.65 "Use LDAP Server".
- ☐ This function supports LDAP Version 2 and 3.
- To ensure successful searching, make sure the server name and port number are entered correctly. For details, ask your network administrator.

Programming an LDAP Server

1 Press the [User Tools/Counter] key.



2 Press [System Settings].



- Press [Key Operator Tools], and then press [▼Next] twice.
- Press [Program/Change LDAP Server].
- **5** Enter the items.

To enter an identification name

● Press [Change] under Identification Name.



- 2 Enter the server's identification name.
- 3 Press [OK].

To enter a server name

- Press [Change] under Server Name.
- 2 Enter the LDAP server name.
- 3 Press [OK].

To enter the search base

- 1 Press [Change] under Search Base.
- 2 Enter the search base.
 - Note
 - ☐ For example, if you enter "ou=sales department, o=ABC", searching will start below the sales department level of ABC company (here, "ou" stands for organization unit, and "o" stands for company).
- 3 Press [OK].

To enter a port number

- 1 Press [Change] under Port No..
- Enter the port number using the number keys, and then press [#].

To set authentication

- Press [▼Next].
- 2 Press [ON] or [High Security] under Authentication.



- ☐ [High Security] is not available with LDAP Version 2.
- □ When [ON] or [High Security] is selected, the administrator account name and password is required to access the LDAP server.
- □ When [High Security] is selected, you can use a generic password unique to the network. If you do this, the server also requires the same setting. For details, ask your network administrator.

To enter the user name and password

Note

☐ To use the administrator account for authentication, enter the account name and password here.

- ☐ If you leave the user name and password blank, users will be prompted for the password every time they attempt to connect to the LDAP server.
- Press [▼Next].
- Press [Change] under User Name.
- 3 Enter the user name, and then press [OK].
- 4 Press [Change] under Password.
- **5** Enter the password, and then press [OK].

To test the connection

1 Press [Connection Test].

A connection test is carried out.

- 2 Press [Exit].
- Note
 - ☐ If the connection test fails, check your settings, and then try again.

To set search options

Note

- ☐ You can search the LDAP server data using keywords below: Name, E-mail Address, Fax Destination, Company Name, Department Name. You can specify an additional keyword. This must be predefined in your LDAP database.
- **1** Press [▼Next] twice.
- 2 Press [Change] under Attribute.
- 3 Enter the attribute you want to use for searching e-mail addresses, and then press [OK].

- 4 Press [Change] under Key Display.
- **6** Enter the attribute's display name, and then press [OK].
 - Note
 - ☐ For example, if you want to sort e-mail addresses by employees' number, enter "employeeNo" in the Attribute field, and "Employee No." in the Key Display field.
- 6 Press [OK].
- **7** Press the [User Tools/Counter] key.

Changing an LDAP Server

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- Press [Key Operator Tools], and then press [VNext] twice.
- 4 Press [Program/Change LDAP Server].
- **5** Change the items.

To change an identification name

• Press [Change] under Identification Name.



- **2** Enter a new identification name for the server.
- 3 Press [OK].

To change the server name

- 1 Press [Change] under Server Name.
- 2 Enter the new LDAP server name.
- 3 Press [OK].

To change the search base

- 1 Press [Change] under Search Base.
- 2 Enter the new search base.
- 3 Press [OK].

To change a port number

- 1 Press [Change] under Port No..
- 2 Enter the new port number using the number keys, and then press [#].

To change authentication

- Press [▼Next].
- Select [ON] or [High Security] if you want to activate authentication. Select [OFF] to cancel it.
 - Note
 - ☐ [High Security] is not available when the LDAP Version is 2.
 - □ When [ON] or [High Security] is selected, the administrator account name and password is required to access the LDAP server.
 - □ When [High Security] is selected, you can use a generic password unique to the network. If you do this, the server also requires the same setting. For details, ask your network administrator.

To change the user name and password

- Press [▼Next].
- 2 Press [Change] under User Name.
- 3 Enter the new user name, and then press [OK].
- 4 Press [Change] under Password.
- **6** Enter the new password, and then press [OK].

Note

- ☐ The user name and password are of a user who is authorized to access the LDAP server.
- ☐ You can press [Connection Test] to check if the new settings work.

To change search options

- Press [▼Next] twice.
- 2 Press [Change] under Attribute.
- **3** Enter a new attribute, and then press [OK].
- 4 Press [Change] under Key Display.
- 6 Enter the attribute's new display name, and then press [OK].
- 6 Press [OK].
- **7** Press the [User Tools/Counter] key.

5. Troubleshooting

If Your Machine Does Not Operate As You Want

The following chart contains explanations of common problems and messages. If other messages appear, follow the instructions displayed.

☐ If you cannot make copies as you want because of the paper type, paper size or paper capacity problems, use recommended paper. See p.172 "Copy Paper".

General

| Problem | Causes | Solutions | |
|---|--|--|--|
| "Please wait." appears | This message appears when you turn on the operation switch or change the toner bottle. | If the power does not come on even after 2 minutes have elapsed, contact your service representative. | |
| The display is off. | The screen contrast knob is turned to the dark position. | Set the screen contrast knob to the light position to see the display panel properly. | |
| | The machine is in Energy Saver mode. | Press the [Energy Saver] key to cancel Energy Saver mode. | |
| | The operation switch is turned off. | Turn on the operation switch. | |
| Nothing happens when the operation switch is turned on. | The main power switch is turned off. | Turn on the main power switch. | |
| Memory is full. | There are too many scanned pages or stored files: hard disk capacity is exceeded. | Press [Delete File] to delete unnecessary documents. | |
| The function status indicator is red. | The function associated with the red indicator was interrupted. | Press the function key corresponding to the indicator. Follow the instructions that appear on the control panel. | |
| The user code entry display appears. | Users are restricted by user management. | Enter the user code (up to 8 digits), and then press [#]. | |

| Problem | Causes | Solutions | |
|---|--|---|--|
| The main power indicator continues blinking and does not turn off when pressed. | This occurs in the following cases: The exposure glass cover or the ADF is open. The machine is communicating with external equipment. The hard disk is active. | Close the exposure glass cover or ADF, and check if the machine communicating with a computer. | |
| "Self checking.", "Colour is being adjusted." appears. | The machine is preforming image adjustment operations. | The machine may perform periodic maintenance during operations. The frequency and duration of maintenance depends on the humidity, temperature, and printing factors such as number of prints, paper size, and paper type. Wait for the machine to get ready. | |
| Original images are printed on the reverse side of the paper. | You may have loaded the paper incorrectly. | Load paper correctly. Load paper into Tray 1-4 with the print side up, and into the LCT or bypass tray with the print side down. See p.111 "Orientation-Fixed Paper or Two-Sided Paper". | |
| Misfeeds occur frequently. | The tray's side guides may not be locked. | Check the side guides are locked. See p.122 "Changing the Paper Size". | |
| | The tray's end guide may not be set properly. | Check the end guide is set properly. See p.122 "Changing the Paper Size". | |
| | You may have loaded paper of a size not shown on the paper size selector. | When using paper of a size that cannot be detected automatically, use Tray Paper Settings to set the paper size. See p.53 "Tray Paper Size:Tray 2–4" and p.172 "Copy Paper". | |
| An error message remains, even if misfed paper is removed. | When a misfeed message appears, it remains until you open and close the cov- er as required. | Clear misfed paper, and then open and close the front cover. See p.114 "% Clearing Misfeeds". | |
| Cannot print in duplex mode. | You cannot use paper in the bypass tray for duplex printing. | For duplex printing, select Tray 1-4 in copier mode or with the printer driver. | |
| | [1 Sided Copy] is selected for Paper Type: Tray 1-4. | Select [2 Sided Copy] for Paper Type: Tray 1-4. See p.54 "Paper Type: Tray 1–4" | |
| You forgot your key operator code | _ | Contact your service representative. | |

Document Server

| Problem | Solutions |
|--|---|
| "Scanned pages exceeded max. number. Do you want | The number of scanned pages exceeds the capacity per file of the Document Server. |
| to store the scanned pages as a file?" appears. | To store scanned pages as a file, press [Store File]. Scanned data is stored as a file in the Document Server. If you do not want to store scanned pages, press [No]. Scanned data is deleted. |
| You forgot your password. | You can temporarily access password-protected files. |
| | Press [Unlock] in Password Management for Stored Files in User Tools. See p.157 "Temporarily Disabling Document Security". |
| | You can delete all stored documents at once with User Tools. See p.64 "Delete All Files". |
| | Make sure no important documents are stored in the Document Server before deleting all stored documents. |
| You cannot find out what is stored in a file. | Check the date or time column in the Document Server: Select Files to Print display. |
| | Check document content by printing it's first page. Press the line of the document in the Document Server: Select Files to Print display, and then press [Print 1st Page] followed by the [Start] key. |
| Memory frequently becomes full. | Press [Delete File] to delete selected documents to increase available memory. |
| | Delete documents stored using the scanner function. See <i>Scanner Reference</i> . |
| You want to check print quality before making a large print run. | Check print quality by printing out only the first set using the [Sample Copy] key. |
| "Original is being scanned by another function." appears. | The copier or scanner function is in use. To cancel a job in progress, first press [Exit], and then press the [Copy] key or [Scanner] key. Next, press the [Clear/Stop] key. When the message "[Stop] key was pressed. Stop printing?" appears, press [Stop]. |

Maintenance

| Problem | Causes | Solutions |
|---|--|--|
| Fuser Oil Unit Replacement. Fusing oil is empty. Please replace | It is time to replace the fuser oil unit. | Check your maintenance service contract. |
| Fuser Oil Unit. | | |
| Waste Toner Bottle Replacement. | The waste toner bottle is full and it is time to replace | Check your maintenance service contract. |
| Waste Toner Bottle is full. | it. | |
| Please replace Waste Toner Bot- tle. | | |

Loading Paper Loading Paper

#Important

- ☐ Tray 1 and LCT use A4 ☐ paper exclusively. Load only A4 paper at all times.
- □ If you want to load Letter- sized paper (8 ¹/2"×11" □) paper in Tray
 1 or LCT, contact your sales or service representative.

For paper types and sizes, see p.172 "Copy Paper".

To load paper in the bypass tray, see "Copying from the Bypass Tray", Copy Reference.

- ☐ Fan the paper before loading.
- ☐ Straighten curled or warped paper before loading.


Loading Paper into Paper Trays and Paper Tray Unit

Tray 1 uses only A4 \square paper. If you want to load 8 $^1/_2$ " × 11" \square , contact your sales or service representative.


The position of the side and end guides can be changed in tray 2, 1 tray paper unit, and 2 tray paper unit. Paper of various sizes can then be loaded in them.

This section describes loading paper in tray 2.

1 Pull out the paper tray until it stops.



- Note
- ☐ You can change the paper size, see p.122 "Changing the Paper Size".
- 2 Load paper into the tray with the print side down.



∰Important

☐ Do not stack paper over the limit mark.

Push in the paper tray slowly until it stops.

If a tray is pushed forcefully, the position of its side guide may shift.

If you load a paper size that is not selected automatically, you will need to specify the paper size with the control panel.

The following paper sizes are not selected automatically:


- B5 JIS□
- 8¹/₂"×14"□
- 8¹/₂"×11"□

p.123 "If you load a paper size that is not selected automatically".


Loading Paper into Large Capacity Tray (optional)

LCT(optional) uses A4 paper exclusively. Only load A4 paper. If you want to load 8¹/₂"×11" , contact your sales or service representative.

Pull out the LCT, slowly until it stops.



With the print side down, align all four sides of two paper stacks, and then load them next to each other in the tray. Each side has a limit of 1,000 sheets.



#Important

- Align the paper stacks and load them against the left and right walls, or a paper misfeed might occur.
- ☐ Do not stack paper over the limit mark.
- Push the paper tray slowly in until it stops.

Orientation-Fixed Paper or Two-Sided Paper

Orientation-fixed (top to bottom) or two-sided paper (for example, letterhead paper, punched paper, or copied paper) might not print correctly, depending on how the originals and paper are placed. Select **[Yes]** in Letterhead Setting under Copier/Document Server Features, and then place the original and paper as shown below (see "Letterhead Setting" *Copy Reference*). When printing with the printer function, placement orientation is the same.

| | | | | Bypass Tray | |
|-------------------------------|---------|------------|-----|--------------------------------|------------------------|
| Copy Mode | | Paper Tray | LCT | Original on the exposure glass | Original on the ADF |
| Paper placing direction | 1 Sided | | | R | R |
| _ | 2 Sided | R | R | | |
| Paper placing direction | 1 Sided | | | E ., | E .1 |
| | 2 Sided | Œ | | | |

^{*1} When specifying the paper size.

111

When **\(\Ldots\)** appears, it is time to add toner.

⚠ WARNING:

 Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of used toner containers in accordance with local regulations.

⚠ CAUTION:

𝒜 Note

• Keep toner (used or unused) and toner containers out of reach of children.

If the message "No toner:xxxx, xxxx" is shown on the display, replace the applicable colour-toner.

| | "xxxx,xxxx" is shown as the colour of toner is almost empty, and the combination of 1-4 of Yellow, Magenta, Cyan, and Black is displayed. |
|---|--|
| 4 | fImportant |
| | Fault may occur if you use toner other than the recommended type. |
| | When adding toner, do not turn off the operation switch. If you do, settings will be lost. |
| | Always add toner when the machine instructs you. |
| Ø | Note |
| | The message "LaToner is almost empty." on the display shows a toner name and the telephone number for ordering. |
| | The consumption of toner depends on the humidity, temperature and printing factors such as image size, density, number of prints, paper size, and paper type. Moreover, to preserve print quality, this machine automatically performs periodic maintenance using the toner. |
| | Change all four colour-toner cartridges in the same way. |
| O | Defevence |


For details about toner storage, see p.139 "Toner Storage".

5

Inserting Toner



1. Open the upper right cover. 2. Unhook the hook on the toner cartridge with one hand.



3. Holding the toner cartridge with the other hand, pull the cartridge up and out slowly.

Important

Do not shake the removed toner cartridge. The remaining toner might scatter.



4. Take out the new toner cartridge from the box.




5. Shake the toner cartridge back and forth 5-6 times.



6. Hold the toner cartridge with the metal contact area in front, and attach it observing the direction of the arrow.

Important

Do not touch the metal contact point with your fingers.



7. Insert the toner cartridge slowly until the hook snaps on the metal contact area.

Important

 Do not install and remove the toner cartridges over and over. This could result in a toner leak.

8. Close the upper right cover.

When toner remains

Toner can remain inside the toner cartridge in certain environments. If this happens, set the toner cartridge again. Toner will be supplied automatically, and you can then continue to use it.

% Clearing Misfeeds

↑ CAUTION:

 The fusing section of this machine might be very hot. Caution should be taken when removing misfed paper.

#Important

- ☐ When clearing misfeeds, do not turn off the operation switch. If you do, your copy settings will be lost.
- ☐ To prevent misfeeds, do not leave any torn scraps of paper inside the machine.
- ☐ If paper misfeeds occur frequently, contact your service representative.

Note

- ☐ More than one misfed area may be indicated. When this happens, check all the areas indicated. See the following charts:
 - A, B, Y, Z1⇒ p.116
 - R (2 Tray Finisher) \Rightarrow p.119
 - R (Booklet Finisher)⇒ p.118
 - P⇒ p.120
- ☐ Inside the finisher, or inside the front cover, there is a sticker explaining how to remove misfed paper.

(**B**)



 Open the Duplex Reversal Unit.



2. Hold up lever B1, and then gently pull out the upper left cover.



3. Hold up lever B2, and then open the r. upper left cover.



4. Turn knob **B3**, and then remove the misfed paper.

If you can not remove the misfed paper Contact your service representative.

(Z1)



Open the Duplex
 Reversal Unit cover.



2. Remove the misfed paper.



Open the Duplex Reversal Unit.



Remove the misfed paper.


(Y)




 Open the lower right cover.



Remove the misfed paper.





You can make an enlarged copy of this page and stick it on walls in the proximity of the machine.

AAE032S



Booklet finisher

When R1 is displayed



 Hold the release lever, and then remove the finisher.



Remove the misfed paper.



3. Open the upper cover.



- Remove the misfed paper.
- Close the upper cover.
- 6. Attach the finisher.

When R2-R4 are displayed



 Hold the release lever, and then remove the finisher.



Open the front cover.



3. Make sure the blue marker is visible. If not, turn knob R2 until it is visible.



Remove the misfed paper.



then open the cover.

6. Remove the misfed paper.



7. Turn knob R4, and then remove the misfed paper.

$\widehat{\mathbb{R}}$

2 Tray finisher



- 1. Open the upper cover.
- 2. Remove the misfed paper.



7. Lower R2 lever, and then remove the misfed paper.



3. If you cannot remove the paper, open the cover next to the upper cover.



5. Check the position of R1 lever.




4. Open the front cover. 6. Hold up lever R1,



and then remove the misfed paper.








right, and then remove the front, and then the misfed paper.



remove the misfed paper.

11. Close the front cover.




You can make an enlarged copy of this page and stick it on walls in the proximity of the machine.

AAE015S





 Pull up the lever, and then open the upper cover.



2. Lift the lever.

3. Remove the misfed paper.



4. Turn the dial in the direction of the arrow, and then slowly remove the paper.



5. Move the panel in the direction of the arrow.




6. Remove the misfed paper.



 Hold the ADF external cover, and then slowly remove the misfed paper.



- 8. Close the upper cover.
- Open the ADF, and then move the blue hook to the left and loosen the white cover.
- 10. Remove the misfed paper.



You can make an enlarged copy of this page and stick it on walls in the proximity of the machine.

AAE016S

Changing the Paper Size

Preparation

Be sure to select the paper size with User Tools and the paper size selector. If you do not, misfeeds might occur. See p.53 "Tray Paper Size:Tray 2–4".


- ☐ Tray 1 and LCT (optional) use only A4 ☐ paper. To load 8 ¹/2" × 11" ☐, contact your service representative.
- ☐ Procedures for changing the paper size differ depending on the tray (tray 1 or other optional paper tray units). Make sure you are following the appropriate procedure before you begin.

₽ Reference

For details about paper sizes and types, see p.172 "Copy Paper".


Changing the Paper Size of the Paper Tray

1 Make sure the paper tray is not in use. Then, pull the paper tray out slowly.




2 If paper is loaded in the tray, remove it.


Set the paper guide lock to the "unlocked" position.




While pressing the release lever, adjust the side guides to the paper size.



Adjust the end guide to the paper size.



Square the paper, and then load it in the tray with the copying face down.




#Important

- ☐ Do not stack paper over the limit mark.
- ☐ Check the top of the paper is aligned to the right side.

𝚱 Note

- ☐ If there is space between the side guide and paper, bring the side guide flash against the edge of the paper.
- **1** Lock the side guide.



- Gently push the paper tray in until it stops.
- Check the paper size shown on the display panel.

If you load a paper size that is not selected automatically

If you load a paper size that is not selected automatically, you need to specify the paper size with the control panel.

Following paper sizes that are not selected automatically.

- B5 JIS□
- $8^{1}/_{2}" \times 14" \square$
- $8^{1/2}$ " × 11" \square
- 1 Press the [User Tools/Counter] key.




2 Press [System Settings].




Press [Tray Paper Settings].




- Select the tray for which you want to change the paper settings.
 - Note
 - ☐ Press either of [Tray Paper Size: Tray 2] to [Tray Paper Size: Tray 4].



Select the loaded paper size and feed direction, and then press [OK].



The set paper size and feed direction is displayed.



- 6 Press the [User Tools/Counter] key.
 The initial display is shown.
 - **∰**Important
 - □ If you want to print on paper that is selected automatically after printing on a paper size that is not selected automatically, you must return the setting to "Auto Detect". Reload the paper, repeat step ① to ②, and select "Auto Detect" in step ⑤. The setting is returned to "Auto Detect".

Adding Staples


∰Important

☐ Stapling failures or jams may occur if you use a staple cartridge other than that recommended.

₽ Reference

For details about the type of finisher, see p.17 "External Options".


2 Tray Finisher




1. Open the front cover of the finisher.




2. Hold the green lever, and then gently pull out the cartridge.



3. Hold both sides of the cartridge, and then raise the upper unit.




4. Remove the empty refill in the direction of the arrow.



5. Push in the new cartridge until it clicks.



6. Gently push down the upper unit.



7. Pull out the ribbon.




- 8. Hold the green lever while pushing in the cartridge until it clicks.
- 9. Close the front cover of the finisher.

AAE009S

Booklet Finisher




 Open the front cover.
 Hold the lever, and then pull out the Staple unit.




3. Push the cartridge button, and then pull out the cartridge while lifting the cartridge.



 Hold both sides of the cartridge, and then pull up the upper unit of the cartridge.



Remove the empty refill in the direction of the arrow.



Push in the new cartridge until it clicks.



7. Gently push down the upper unit.



8. Pull out the ribbon.



- 9. Push in the cartridge until it clicks.
- 10. Close the front cover of the finisher.

AAE010S

Removing Jammed Staples


Note

- ☐ Curled paper may cause staples to jam. To avoid this, turn copy paper over in the tray. If there is no improvement, change to a stiffer copy paper.
- ☐ When the booklet finisher is installed, after removing jammed staples, staples will not be ejected the first few times you try to use the stapler.

₽ Reference

For types of finisher, see p.17 "External Options".

2 Tray Finisher




1. Open the front cover of the finisher.



2. Hold the green lever, and then gently pull out the cartridge.



3. Open the faceplate of the cartridge.



4. Remove any jammed staples.




5. Close the faceplate. pushing until it clicks.



- 6. Hold the green lever, and then push in the cartridge until it clicks.
- 7. Close the front cover of the finisher.

AAE011S

Booklet Finisher




- Open the front cover of the finisher.
- 2. Hold the lever, and then pull out the staple unit.




3. Turn knob R5 until the cartridge moves to the front.




4. Push the cartridge button, and lift up while removing.



Open the cartridge's faceplate.



Remove any jammed staples.



7. Close the cartridge's faceplate.



- Push in the cartridge until it clicks.
- Close the front cover of the finisher.

AAE012S


Removing Punch Waste

Note


While "Punch Receptacle Full" is displayed, you cannot use the Punch function.

2 Tray Finisher


1 Open the front cover of the 2 tray finisher.



Pull out the punch waste box, and then remove punch waste.



3 Reinstall the punch waste box.



Note


☐ If you do not, "Punch Receptacle Full" will remain displayed.

Close the front cover of the 2 tray finisher.


"Punch Receptacle Full" disappears.

Note


- ☐ If the message is still displayed, reinstall the punch waste box.
- ☐ The message "Punch Receptacle Full" may appear even when the punch waste box is not yet full. If this happens, the position of the punch waste box (indicated by the arrow as shown) may be blocked by punch waste. Remove the punch waste.




1 Hold the release lever, and then pull out the booklet finisher.



2 Pull out the punch waste box, and then remove the paper chips.



3 Reinstall the punch waste box.



Note

☐ If the message does not disappear, reinstall the punch waste box.

Adjusting the Colour Registration

When the machine is moved, the Fusing Unit is replaced, or after printing repeatedly for some time, registration shifting might occur. By performing colour registration adjustment, you can maintain optimum print results.

Auto Colour Registration

If the colour documents show registration shifting, perform automatic colour registration.

1 Press the [User Tools/Counter] key.



"User Tools/Counter" appears on the panel display.

2 Press [Maintenance].



Press [Colour Registration].



4 Press [Auto Colour Registration].



Press [OK].



Auto colour registration will be started.



Auto colour registration takes about fifty seconds. When it is completed, the display returns to the colour registration menu.

When you have made all the settings, press the [User Tools/Counter] key.

The initial display is shown.

Fuser Adjustment for Thick Paper

When colour shifting occurs using thick paper

Follow the procedure below if colour shifting occurs when you use the thick paper of A4 size or larger.

∰Important

☐ When the toner cartridge is almost empty, "Fuser Adjustment: Thick Paper" is not available. Replace the toner cartridge before the adjustment.

Note

- ☐ Thick paper is needed for the adjustment. Prepare thick paper similar to what you normally use.
- 1 Load the A4□ or larger thick paper in the Bypass Tray.

For details about paper size and the procedure for loading paper in the Bypass tray, see "Copying from the Bypass tray", Copy Reference

2 Press the [User Tools/Counter]key.



Press [Maintenance].



4 Press [Colour Registration].



Press [Fuser Adjustment: Thick Paper].



#Important

When the toner cartridge is almost empty "Fuser Adjustment cannot be performed. Replace Toner cartridge." appears on the panel display.

6 Press [OK].

Auto Colour Registration begins.





5

Make sure that following message appears on the display, and then press [Start Printing].

Fuser Adjustment Sheet II is printing. See p.134 "Checking the Fuser Adjustment Sheet".





Compare the sample with the printed pattern box in the printed Fuser Adjustment Sheet II. Specify which square in the box matches the sample.



If you specify "0", setting is finished and the display that appeared in step returns.

If you specify "-1" or "+1", the following display appears.



Press [Start Printing]. An adjusted Fuser Adjustment Sheet II is printed and the display that appeared in Step [3] reappears. Keep adjusting until the printed pattern looks the same as the printed pattern, and then specify "0".

After making all the settings, press the [User Tools/Counter] key.
The initial display is shown.

Checking the Fuser Adjustment Sheet

Following image is sample of the test sheet.

♦ Fuser Adjust Sheet II

Fuser Adjust Sheet II


Sample



Auto Colour Calibration

If a certain colour is strong or the colour of the copy differs from the original, adjust the yellow, magenta, cyan and black balance.

- ☐ If "Later Toner is almost empty." is shown on the display panel, the test pattern cannot be printed.
- 1 Press the [User Tools/Counter] key.



2 Press [Maintenance].



- Press [Auto Colour Calibration].
- Press [Start] on the "Copier Function".



Note

□ When performing the auto colour calibration from the copy function, press [Start] under Copier Function. When performing from the printer function, press [Start] under Printer Function.

Press [Start Printing] and a test pattern will be printed.

Note


- ☐ When performing the auto colour calibration from the printer function, select test patterns from [600 x 600 dpi], [1800×600 dpi] and [1200 x 1200 dpi] and then press [Start Printing]
- ☐ The test pattern will be printed on an A4 ☐, 8¹/2″× 11″ ☐ size page (If A4 ☐ is not available then A3 ☐, B4 JIS ☐ will be used.). Make sure to check the paper set in the paper tray.
- ☐ The counter will not proceed when the test pattern is printed.

6 Place the test pattern on the exposure glass and press [Start Scanning].

The image will be corrected after "Please wait." disappears.

Note

- ☐ The test pattern will not be read if it is set in the ADF.
- ☐ Set the test pattern in the following way:




☐ When the ADF is installed, make sure to set the test pattern on the exposure glass, and then 2 or 3 white sheets, same size as the test pattern, above the test pattern.

Returning to the previous setting

Note

- "Previous Setting" means to return to the previous status before any changes.
- **1** Press [Previous Setting] in the "Auto Colour Calibration.

When returning the auto colour calibration of the copy function, press [Previous Setting] of the Copier Function. If returning the auto colour calibration of the printer function, press [Previous Setting] of the Printer Function.



2 Press [Yes].

The settings return to the previous contents.

6. Remarks

Dos and Don'ts

⚠ CAUTION:

 Unplug the power cord from the wall outlet before you move the machine. While moving the machine, you should take care that the power cord will not be damaged under the machine.

#Important

- Do not turn the power off while the On indicator is lit or blinking. Doing so may damage the hard disk.
- ☐ Before unplugging the power cord or turning off the main power switch, make sure remaining memory space is at 100%, as shown on the display. See p.22 "Turning Off the Power" and p.23 "Turning Off the Main Power".
- When you use this machine for a long time in a confined space without good ventilation, you may detect an odd smell. To keep the workplace comfortable, we recommend that you keep it well ventilated.
- Do not touch areas on or around the fusing unit. These areas may become hot.
- After making copies continuously, the exposure glass may become warm—this is not a malfunction.
- The area around the ventilation hole might feel warm. This is caused by exhaust air and is not a malfunction.

- When the machine is not in use and in stand-by mode, you may hear a small noise inside. This is caused by the image stabilization process and is not a malfunction.
- Do not turn off the operation switch while copying or printing. Make sure that all copying and printing has finished first.
- The machine might not produce good copy images if condensation forms inside as a result of rapid temperature change.
- Do not open the covers of the machine during copying or printing.
 If you do, misfeeds might occur.
- Do not move the machine during copying or printing.
- The machine might not produce good copy images if condensation forms inside as a result of rapid temperature change. To avoid possible condensation, this machine is equipped with anti-condensation heaters. Even when the main power switch is off, the machine continues to maintain a stable temperature when the anti-condensation heaters are on.
- If you operate the machine improperly or a machine failure occurs, settings might be lost. Be sure to make a note of your machine settings.
- The supplier shall not be liable for any loss or damage resulting from mechanical failure, loss of settings, or use of the machine.

Saving Colour Copies

- There is no difference between colour prints and colour copies in terms of fading. However, for long-term storage, make sure to store them in a binder away from direct sunlight.
- Toner may melt if a print and a half-dried print are put on top of each other.
- Toner may also melt when using solvent type adhesive agents for pasting prints.
- When folding prints, toner in the folds will come off.
- Toner may melt if it is placed on mats made of chlorinated plastic in locations of high temperature for long periods of time.
- Toner may melt if prints are placed in places of extremely high temperatures, such as near heaters.

Toner

Handling Toner

MARNING:

 Do not incinerate used toner or toner containers. Toner dust might ignite when exposed to an open flame. Dispose of used toner containers in accordance with local regulations.

⚠ CAUTION:

• Keep toner (used or unused) and toner containers out of reach of children.

#Important

☐ Fault may occur if you use toner other than the recommended type.

To add toner, see p.112 " Adding Toner".

Toner Storage

When storing toner, the following precautions should always be followed:

- Store toner containers in a cool, dry place free from direct sunlight.
- Store on a flat surface.

Used Toner



☐ Toner cannot be re-used.

6

Where to Put Your Machine

Machine Environment

Choose your machine's location carefully. Environmental conditions greatly affect its performance.

Optimum environmental conditions

A CAUTION:

- Keep the machine away from humidity and dust. Otherwise a fire or an electric shock might occur.
- Do not place the machine on an unstable or tilted surface. If it topples over, an injury might occur.

↑ CAUTION:

- If you use the machine in a confined space, make sure there is a continuous air turnover.
- Temperature: 10-32 °C (50-89.6 °F) (humidity to be 54% at 32 °C, 89.6 °F)
- Humidity: 15-80% (temperature to be 27 °C, 80.6 °F at 80%)
- A strong and level base.
- The machine must be level within 5 mm, 0.2 inches: both front to rear and left to right.
- To avoid possible buildup of ozone, be sure to locate this machine in a large well ventilated room that has an air turnover of more than 30 m³/hr/person.

Environments to avoid

- Locations exposed to direct sunlight or other sources of strong light (more than 1,500 lux).
- Locations directly exposed to cool air from an air conditioner or heated air from a heater. (Sudden temperature changes can cause condensation to form inside the machine.)
- Locations close to machines generating ammonia, such as a diazo copy machine.
- Places where the machine will be subject to frequent strong vibration.
- Dusty areas.
- Areas with corrosive gases.

Moving

A CAUTION:

 Unplug the power cord from the wall outlet before you move the machine. While moving the machine, you should take care that the power cord will not be damaged under the machine.

∰Important

- Be careful when moving the machine. Take the following precautions:
 - Turn off the main power. See p.23 "Turning Off the Main Power".
 - Unplug the power cord from the wall outlet. When you pull out the plug from the socket, grip the plug to avoid damaging the cord, thereby reducing the risk of fire or electric shock.
 - Close all covers and trays, including the front cover and bypass tray.
- Move the machine carefully. If you do not, it could result in damage and stored files might be lost.
- \square Do not take off the holding stand.
- ☐ Protect the machine from strong shocks. Impact can damage the hard disk and cause stored files to be lost. As a precautionary measure, files should be copied to another computer.

Power Connection

↑ WARNING:

- Connect the machine only to the power source described on the inside front cover of this manual. Connect the power cord directly into a wall outlet and do not use an extension cord.
- Do not damage, break or make any modifications to the power cord. Do not place heavy objects on it. Do not pull it hard nor bend it more than necessary. These actions could cause an electric shock or fire.


⚠ CAUTION:

 Unplug the power cord from the wall outlet before you move the machine. While moving the machine, you should take care that the power cord will not be damaged under the machine.

↑ CAUTION:

- When you disconnect the power plug from the wall outlet, always pull the plug (not the cable).
- When the main power switch is in the stand-by position, the optional anti-condensation heaters are on. In an emergency, unplug the machine's power cord.
- When you unplug the power cord, the anti-condensation heaters turn off.
- Make sure the plug is inserted firmly in the wall outlet.
- Voltage must not fluctuate by more than 10%.
- The wall outlet shall be installed near the machine and shall be easily accessible.

Place the machine near the power source, providing the clearance areas shown.



- 1. Rear: more than 10 cm (4")
- 2. Right: more than 55 cm (21.7")
- 3. Front: more than 70 cm (27.6")
- 4. Left: more than 46 cm (18.2")
- Note
- ☐ For the required space when options are installed, contact your service representative.

b

Maintaining Your Machine

If the exposure glass, exposure glass cover, or ADF belt is dirty, copy clarity may be reduced. Clean these parts if they are dirty.


Cleaning the machine

Wipe the machine with a soft, damp cloth, and then wipe it with a dry cloth to remove the water.

#Important

- Do not use chemical cleaners or organic solvents, such as thinner or benzene. If such substances get inside the machine or melt plastic parts, a failure might occur.
- ☐ Do not clean parts other than those explicitly specified in this manual. Other parts should be cleaned only by your service representative.

Cleaning the Exposure Glass Cover




Cleaning the Auto Document Feeder

Cleaning the Exposure Glass



Clean 1 and 2.




Clean 1 and 2.


Cleaning the Dustproof Glass

The dustproof glass may require cleaning if white lines appear on the print side of the document.


- 1 Turn off the power switch, and then unplug the power cable.
- Open the front cover and remove the cleaning brush.



There are four holes for cleaning the dustproof glass.



3 Slide the cleaning brush in and out slowly 2 to 3 times to clean all four areas.



∰Important

- Do not insert the brush forcefully, or the machine might be damaged.
- A Return the cleaning brush to its original position.
- **5** Plug in the power cable, and then turn on the power switch.

Replacing the Fuser Oil Unit

⚠ WARNING:

 Do not incinerate spilled toner or used toner. Toner dust might ignite when exposed to an open flame.

↑ CAUTION:

- The inside of the machine becomes very hot. Do not touch the parts with a label indicating a "hot surface". Otherwise, an injury might occur.
- Keep toner (used or unused) and the toner cartridge out of reach of children.
- The fusing unit becomes very hot. When installing a new fuser oil unit, turn off the machine and wait about an hour. After that, install the new fuser oil unit. Not waiting for the unit to cool could result in a burn.
- Keep the fuser oil unit away from flames. There is a risk of fire or burns.

If the message "Fuser Oil Unit Replacement.", "Fusing oil is empty.", and "Please replace Fuser Oil Unit." are displayed, either replace it on your own by following the procedure below or call your service representative.

Note

- ☐ Service differ depending on the maintenance service contract.
- 1 Turn off the power, and then unplug the power cable.


#Important

☐ Be sure to wait about an hour to avoid burns.


- 2 If the finisher is installed, detach it from the machine.
- 3 Open the duplex reversal unit.




4 Slowly pull out the left cover.



5 Open the upper left cover.




Pull the lever down slightly, and then remove the grip securing the fuser oil unit.



∰Important

☐ Do not touch any area other than the green felt parts.


Hold the fusing unit handle using one hand, and then slowly pull the fuser oil unit out horizontally. Put the unit in the bag that comes with the new fuser oil unit, and then seal the bag.



#Important

☐ Do not touch the inside of the fusing unit.

Take the fuser oil unit out of the bag. Hold the green upper part of seal (①), and then slowly peel the seal off. Position the fuser oil unit as shown, and then slowly pull seal (①) out. Finally, hold the upper part of the seal (②), and then slowly peel it off.





ZHXHK041J


Note

☐ Be sure to remove seal (①), and then pull it out horizontally.

#Important


- ☐ Be sure to remove the seals to avoid malfunction.
- ☐ Be sure to remove seal (①) first, and then seal (②) to avoid oil leakage.
- ☐ Be sure to put the fuser oil unit in a stable and level place to avoid oil leakage.
- ☐ After removing the seals, be careful not to let oil from oil-supplying parts, or the seals come into contact with your body or clothes.

As shown, hold the fuser oil unit using one hand, hold the green handle with the other, and then slowly insert the unit horizontally, in the direction of the arrow.




∰Important

- Be careful not to get oil on the top metal part of the fuser oil unit.
- ☐ Insert the fuser oil unit firmly, until it stops.
- Slowly turn the fuser oil unit handle in the direction of the arrow, until it clicks.



Close the upper left cover (①), and then push the part labeled "PUSH" next to the handle at the bottom rear, until it clicks (②).



- Close the duplex reversal unit.
- If the finisher is installed, reattach it to the machine.
- Plug in the power cable, and then turn on the power.

☐ If you dispose of used fuser oil unit by yourself, dispose according to local regulations.

Replacing the Waste Toner Bottle

⚠ WARNING:

 Do not incinerate spilled toner or used toner. Toner dust might ignite when exposed to an open flame.

↑ CAUTION:


- The inside of the machine becomes very hot. Do not touch the parts with a label indicating a "hot surface". Otherwise, an injury might occur.
- Keep toner (used or unused) and the toner cartridge out of reach of children.

If the message "Waste Toner Bottle Replacement.", "Waste Toner Bottle is full.", and "Please replace Waste Toner Bottle." are displayed, either replace it on your own by following the procedure below or call your service representative.


Ø Note

- ☐ Service differ depending on the maintenance service contract.
- 1 Turn off the power, and then unplug the power cable.

2 Slowly open the front cover by pulling down from the two areas on the left and right.




Carefully pivot the waste oil bottle outward, in the direction of the arrow.




A CAUTION:

 Keep the waste oil bottle away from flames. There is a risk of fire or burns.

Take the new waste toner bottle out of the bag.




5 Slowly remove the used waste toner bottle from inside the machine.



∰Important


- ☐ Be sure to remove the waste toner bottle horizontally.
- Remove the lid (1), and then put it in the position shown in the illustration (2).




Put the used waste toner bottle into the bag that contained the new waste toner bottle, and then seal the bag.

#Important

- ☐ Be sure to handle the bottle carefully so waste toner does not spill.
- Insert the new waste toner bottle as shown.




9 Push it in until it stops.




∰Important

☐ Be sure to firmly insert the waste toner bottle to avoid toner leakage inside the machine.



Slowly close the front cover by pushing the two areas on the left and right.



Plug in the power cable, and then turn on the power.

Other Functions

Inquiry

The inquiry function lets you check the telephone numbers to contact for repairs or ordering toner. Be sure to contact your service engineer to verify the following:

Consumables

- Telephone No. to order
- Toner
- Staple
- TX Stamp Name

Machine Maintenance/Repair

- Telephone No.
- Serial No. of Machine

Sales Representative

• Telephone No.

1 Press the [User Tools/Counter] key.



2 Press [Inquiry].



Inquiry information appears.

Printing inquiry information

• Press [Print Inquiry List].



2 Press the [Start] key.

Inquiry information is printed.

- 3 Press [Exit].
- 4 Press [Exit].

Changing the Display Language


You can change the language used on the display. English is set as default.

1 Press the [User Tools/Counter] key.



ZFLS110E

2 Press [Français].



The language is changed to French.

3 Press [Exit].

The menu appears in French.

Counter

Displaying the Total Counter

You can display the total counter value used for all functions.

1 Press the [User Tools/Counter] key.



2 Press [Counter].



To print a counter list, press [Print Counter List].



4 Press the [Start] key.

A counter list prints out.

7. Entering Text


Entering Text

This section describes how to enter characters. When you enter a character, it appears at the position of the cursor. If there is a character already at the cursor position, the entered character appears before it.

Available Characters

- Alphabetic characters
 ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijklmnopqrstuvwxyz
- Symbols
- Numerals 0123456789

Keys



Note

☐ When entering uppercase or lowercase letters continuously, use [Shift Lock] to lock the case.

How to Enter Text

Entering letters

- 1 Press [Shift] to switch between uppercase and lowercase.
- **2** Press the letters you want to enter.

Deleting characters

1 Press [Backspace] or [Delete All] to delete characters.

8. Security

Security

Confidential information is always at risk of being copied without permission or subject to unauthorized access through the network. To protect documents from such intrusion, not only can passwords be set, but the Extended Security function can also be used to strengthen security.

For those who require increased document protection, we recommend using the Extended Security function.

Primary Security Functions

Protecting Stored Documents

Protects documents with a password when using Document Server or Locked Print. Furthermore, the Extended Security function can protect against password-generating cracking. See p.155 "Extended Security Function".

Protecting Image Data Remaining in Memory

Protects image data remaining in memory. When a copy or print job is completed, or a job is canceled, the data is secure.

Protecting against Unauthorized Access Via Phone Line Accepts only faccimile calls

Accepts only facsimile calls.

Authenticating Administrator

Protects essential functions for administrating document security using an access code. See p.58 "Key Operator Code".

Extended Security Function

By setting a password, document operations such as printing, deleting, or delivering can be restricted to authorized users and denied to others. However, passwords can be cracked. When the Extended Security function is used, entering the wrong password 10 times will lock that document, protecting it from unauthorized access.

To unlock documents, see p.157 "Unlocking a locked document".

The following documents can be protected by the Extended Security function (all documents must be set with a password to be protected using this function):

♦ Documents stored in the Document Server by the following functions

- Document Server
- Copier function

- Fax transmission
- Scanner function
- Printer driver

Documents stored from the printer driver using the Locked Print function

For information about Document Server, see p.31 "Document Server". For information about Locked Print, see "Locked Print", *Printer Reference*, or the printer driver Help.

Note

- Once a document is locked, it will reject the correct password until it is unlocked.
- □ When the Extended Security function is on, delivery server settings cannot be changed. Turn the function off to change the settings.

Setting Extended Security

Preparation

The Extended Security setting is not available unless the key operator code set in the Key Operator Code settings of the System Settings has six or more digits. See p.58 "Key Operator Code".

Note

- ☐ To ensure increased document protection under the Extended Security setting, we recommend you select [All Initial Settings] when programming a key operator code.
- 1 Press the [User Tools/Counter] key.
- On the display panel, press [System Settings], and then press [Key Operator Tools].
- 3 Press [Extended Security]. Press [On], and then [OK].

The Extended Security function is enabled, and the security mark [appears in the upper right of the display panel.



4 Press the [User Tools/Counter] key to finish.

Unlocking a locked document

Unlock a document that was locked because a wrong password was entered multiple times, making it available for authorized users to access again.

- 1 Press the [User Tools/Counter] key.
- 2 On the display panel, press [System Settings], [Key Operator Tools], [▼Next] and then press [Password Management for Stored Files].
- **3** Press [OK] under Unlock Files.

The document is unlocked.

4 Press the [User Tools/Counter] key to finish.

Temporarily Disabling Document Security

If you forget a password, you can temporarily disable document protection, making documents available for operations such as setting new passwords or deletion.

∰Important

☐ When operations are complete, be sure to press **[Do not Unlock]** under Temporarily Unlock Files, protecting the document by password again.

∅ Note

- ☐ For a document stored using Locked Print, only document deletion is available when protection is disabled.
- 1 Press the [User Tools/Counter] key.
- 2 On the display panel, press [System Settings], [Key Operator Tools], [▼Next] and then press [Password Management for Stored Files].
- Press [Unlock] under Temporarily Unlock Files.
 - Note
 - Protection can be disabled for only three minutes. Access the document, set a new password, and perform any other necessary operations to the document within that time. Documents will automatically return to the password-protected condition after three minutes.
- 4 Press the [User Tools/Counter] key to finish.

Operating Environment and Notes

Security for this machine is assured on the premises that the machine is used under the following conditions:

Operating Environment

- The condition of the machine is normal. (For example, it is not damaged, modified, or lacking components.)
- When the machine is connected to a network, the machine is protected from illegitimate access including unauthorized packet sniffing.
- The machine is managed by an administrator with thorough knowledge of the machine and capable of providing the proper conditions under which users can use the machine safely.

For Administrator

- This machine does not protect against illegitimate actions on the network. To avoid any risks on the network, further security is required.
- Security of this machine cannot be assured if any hardware component is detached or replaced with an inappropriate component. If there is any possibility of this occurring, other security measures are necessary.
- Regularly check that the Extended Security function is on. While the machine
 is in this mode, the security mark is displayed at the upper right of the display panel. Be sure to check it particularly after the machine is moved or a
 power failure occurs. See p.156 "Setting Extended Security".
- Avoid using a single number or consecutive numbers for an key operator code such as "00000000" or "12345678". Since the numbers like this are easy to guess, using them will not provide the appropriate level of security.
- Remote document management using SmartNetMonitor for AdminSmart-NetMonitor for Admin is not available when the Extended Security function is on.
- User code is a function to help manage the use of the machine. It is not to protect confidential documents from others. See p.71 "User Code".
- As for using the delivery function, the security of this machine can assure
 only the protection of documents having a password set and stored in the
 Document Server. Be sure to select the destination correctly when delivering
 documents.

For User

- Be careful not to let anyone know your password, especially when entering a
 password or recording it. Keep any record of your password in a secure place.
- Avoid using a single number or consecutive numbers for a password such as "0000" or "1234", since the numbers like this are easy to guess, so using them will not provide a worthwhile level of security.
- A document accessed with a correct password remains selected even after operations are complete, and it can be accessed by other users. To stop this, be sure to press the [Clear Modes] key to cancel the document selection.
- The user name used when adding a document to the Document Server is to identify the document creator and type. It is not to protect confidential documents from others.
- Before scanning documents using the scanner function, make sure all other operations are complete.

9. Specifications

Main Unit

Configuration:

Desktop

Photosensitivity type:

OPC drum

Original scanning:

One-dimensional solid scanning system through CCD

Copy process:

Dry electrostatic transfer system

Development:

Dry two-component magnetic brush development system

Fusing:

Heating roll pressure system

Resolution:

600 dpi

Exposure glass:

Stationary original exposure type

Original reference position:

Rear left corner

♦ Warm-up time:

101 seconds or less (23 °C)

Originals:

Sheet/book/objects

♦ Maximum original size:

A3□, 11" × 17"□

Copy paper size:

- Trays: A3 \Box A5 \Box , 11" × 17" \Box 5¹/₂" × 8¹/₂" \Box
- Bypass: A3 \Box A6 \Box , 11" × 17" \Box 5¹/₂" × 8¹/₂" \Box
- Bypass (custom size):

Vertical: 90.0 – 305.0 mm, 3.55" – 12.00" Horizontal: 148.0 – 457.2mm, 5.83" – 18.00"

- Duplex: A3 \square A5 \square , 11" × 17" \square 5¹/₂" × 8¹/₂" \square (except A5 \square , 5¹/₂" × 8¹/₂" \square)
- LCT: A4 \square , $8^1/2'' \times 11'' \square$

◆ Paper weight:

- Paper tray: $60 105 \text{ g/m}^2$, 16 28 lb.
- Bypass tray: $60 163 \text{ g/m}^2$, 16 43.6 lb.
- Duplex: $60 105 \text{ g/m}^2$, 16 28 lb.

Non-reproduction area:

- Leading edge: 1.5–5.0mm
- Trailing edge: 0.5–6.0mm
- Left edge: 0.5-4.0mm
- Right edge: 0.5-4.0 mm

First copy time:

- Colour: 10 seconds or less
- B&W: 8 seconds or less

♦ Copying speed: (Type 1) Full Colour / B&W

- 14/18 copies/minute (A3 \square , $11" \times 17" \square$)
- 24/32 copies/minute (A4 \square , $8^1/2$ "×11" \square)

Copying speed: (Type 2) Full Colour / B&W

- 14/18 copies/minute (A3□, 11" × 17"□)
- 28/38 copies/minute (A4 \square , 8¹/₂"×11" \square)

Reproduction ratio:

Preset reproduction ratios:

| | Metric version | Inch version |
|-------------|----------------|--------------|
| Enlargement | 400% | 400% |
| | 200% | 200% |
| | 141% | 155% |
| | 122% | 129% |
| | 115% | 121% |
| Full size | 100% | 100% |
| Reduction | 93% | 93% |
| | 82% | 85% |
| | 75% | 78% |
| | 71% | 73% |
| | 65% | 65% |
| | 50% | 50% |
| | 25% | 25% |

Zoom: From 25 to 400% in increments of 1%.

❖ Maximum continuous copy run:

999 sheets

◆ Paper capacity:

 Tray 1, 2: 500 sheets (80 g/m^2 , 20 lb.)

• Bypass tray: 100 sheets (80 g/m², 20 lb.)

♦ Power consumption:

• Main unit only

| | Type 1 | Type 2 |
|-----------------|------------------|------------------|
| Warm-up | about 1.25 kw | about 1.25 kw |
| Stand-by | about 0.22 kw | about 0.22 kw |
| During printing | about 1.35 kw | about 1.35 kw |
| Maximum | less than 1.5 kw | less than 1.5 kw |

• Complete system *1

| | Type 1 | Type 2 |
|-----------------|------------------|------------------|
| Warm-up | about 1.3 kw | about 1.3 kw |
| Stand-by | about 0.27 kw | about 0.27 kw |
| During printing | about 1.5 kw | about 1.5 kw |
| Maximum | less than 1.5 kw | less than 1.5 kw |

^{*1} The complete system consists of the main unit, ADF, finisher and LCT.

\bullet Dimensions (W \times D \times H up to exposure glass):

 $670 \times 698 \times 859$ mm, $26.4'' \times 27.5'' \times 33.9''$

♦ Space for main unit (W × D):

Type 1, 2: 1285×698 mm, $50.6" \times 27.5"$ (Bypass tray extender is used for large size paper)

♦ Noise emission *1:

Sound power level:

· Main unit only

| | Type 1 | Type 2 |
|----------|---------------------|---------------------|
| Stand-by | Less than 40 dB (A) | Less than 40 dB (A) |
| Copying | Less than 66 dB (A) | Less than 66 dB (A) |

Complete system *3

| | Type 1 | Type 2 |
|----------|---------------------|---------------------|
| Stand-by | Less than 40 dB (A) | Less than 40 dB (A) |
| Copying | Less than 72 dB (A) | Less than 72 dB (A) |

Sound pressure level *2

Main unit only

| | Type 1 | Type 2 |
|----------|---------------------|---------------------|
| Stand-by | Less than 26 dB (A) | Less than 26 dB (A) |
| Copying | Less than 53 dB (A) | Less than 53 dB (A) |

• Complete system *3

| | Type 1 | Type 2 |
|----------|---------------------|---------------------|
| Stand-by | Less than 26 dB (A) | Less than 26 dB (A) |
| Copying | Less than 61 dB (A) | Less than 61 dB (A) |

^{*1} The above measurements, made in accordance with ISO 7779 are actual values.

♦ Weight:

Type 1, 2: Approx. 120 kg, 264.6 lb.

♦ HDD:

 $40 \text{ GB} \times 2$

- Capacity for Document Server 37.5 GB
- Capacity for memory sorting 14.4–17.2 GB
- Capacity for others 8 GB or more

^{*2} Measured at the position of the bystander.

^{*3} The complete system consists of the main unit, ADF, finisher and LCT.

Options

Exposure Glass Cover

Lower this over originals for copying.

Auto Document Feeder

Mode:

ADF mode, Batch mode, SADF mode, Mixed Size mode, Custom Size Originals mode Auto detect (A4, $8^1/2^{"} \times 11"$)

Original size:

- $11" \times 17" \square 5^1/2" \times 8^1/2" \square \square$

Original weight:

- One-sided originals: 40–128 g/m² (11–34 lb.)
- Two-sided originals: 52–105 g/m² (14–28 lb.)

Maximum number of originals:

80 sheets (80 g/m^2 , 20 lb.) or less than 11 mm, 0.43"

♦ Maximum power consumption:

Less than 60 W (power is supplied from the main unit)

♦ Dimensions (W×D×H):

 $570 \times 518 \times 150 \text{ mm}, 22.5" \times 20.4" \times 6.0"$

Weight:

Approx. 12 kg, 26.5 lb.

Note

☐ Specifications are subject to change without notice.

 $^{^{*1}}$ While using the fax function, it can read a maximum of 1260mm.

9

2 Tray Finisher

Finisher Shift Tray 1:

❖ Paper size:

A3\$\,\text{D}\$, B4 JIS\$\,\text{D}\$, A4\$\,\text{D}\$\,\text{D}\$, B5 JIS\$\,\text{D}\$\,\text{D}\$, A5\$\,\text{D}\$, 11" \times 17"\$\,\text{D}\$, 8\$^1/2" \times 14"\$\,\text{D}\$, 8\$^1/2" \times 11"\$\,\text{D}\$\,\text{D}\$

Paper weight:

 $60 - 105 \text{ g/m}^2$, 16 - 28 lb.

Stack capacity:

- 500 sheets (A4 $\square \square$, B5 JIS $\square \square$, A5 \square , 8¹/₂" × 11" $\square \square$) (80 g/m², 20 lb.)
- 250 sheets (A3 \square , B4 JIS \square , $8^{1}/_{2}$ " × 14" \square , 11" × 17" \square) (80 g/m², 20 lb.)

Finisher Shift Tray 2:

Paper size:

A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square \square , A5 \square , 11" × 17" \square , 8 $^1/_2$ " × 14" \square , 8 $^1/_2$ " × 11" \square \square

Paper weight:

 $60 - 105 \text{ g/m}^2$, 16 - 28 lb.

Stack capacity:

No Staple:

- 2,000 sheets (A4 \square , $8^1/2$ " × 11" \square) (80 g/m², 20 lb.)
- 750 sheets (A3 \square , B4 JIS \square , A4 \square , B5 JIS \square \square , 11" × 17" \square , 8¹/₂" × 14" \square , 8¹/₂" × 11" \square) (80 g/m², 20 lb.)
- 500 sheets (A5 \square) (80 g/m², 20 lb.)

Staple:

- 1,500 sheets (A4 \square , $8^1/_2$ " × 11" \square) (80 g/m 2 , 20 lb.)
- 750 sheets (A3 \square , B4 JIS \square , A4 \square , B5 JIS \square , 11" × 17" \square , 8¹/₂" × 14" \square , 8¹/₂" × 11" \square) (80 g/m², 20 lb.)

Staple capacity:

- 2–50 sheets (A4 $\square \square$, B5 JIS $\square \square$, 8¹/₂" × 11" $\square \square$) (80 g/m², 20 lb.)
- 2–30 sheets (A3 \square , B4 JIS \square , 11" × 17" \square , 8¹/₂" × 14" \square) (80 g/m², 20 lb.)

Staple paper size:

A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square \square , 11"×17" \square , 8¹/₂"×14" \square , 8¹/₂"×11" \square \square

Staple paper weight:

 $64 - 90 \text{ g/m}^2$, 17 - 24 lb.

Staple position:

- 1 staple 3 positions
- 2 staples 2 positions

Power consumption:

Less than 60 W (power is supplied from the main unit)

ightharpoonup Dimensions (W imes D imes H):

 $680 \times 620 \times 1,030$ mm, $26.8" \times 24.5" \times 40.6"$ (including trays)

♦ Weight:

Approx. 55 kg, 121.3 lb.

Punch Kit (2 tray finisher)

Paper size

- 2 holes: A3 \Box A5 \Box \Box , 11" × 17" \Box , 8¹/₂" × 14" \Box
- 3 holes: A3 \square , B4 JIS \square , A4 \square , B5 JIS \square , 11" × 17" \square , 8¹/₂" × 11" \square
- 4 holes:
 - Metric version: A3 \square , B4 JIS \square , A4 \square , B5 JIS \square , 11"×17" \square , 8¹/₂"×11" \square
 - Narrow 2×2 version: A3 \square A5 \square , $11" \times 17" \square$, $8^1/2" \times 14" \square$

Paper weight:

- 4 holes: 52 163 g/m², 14 lb. 43 lb.
- 2 or 3 holes: $52 163 \text{ g/m}^2$, 14 lb. 43 lb.

Power consumption:

26.4 W (power is supplied from the main unit.)

ightharpoonup Dimensions (W \times D \times H):

 $142 \times 456 \times 92 \text{ mm}, 55.9 \times 179.5 \times 36.2 \text{ in}$

Weight:

Approx. 2.9 kg, 6.4 lb

Note

☐ Specifications are subject to change without notice.

Booklet Finisher

Finisher Shift Tray:

❖ Paper size:

A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square \square , 11"×17" \square , 8 $^{1}/_{2}$ "×11" \square \square , 8 $^{1}/_{2}$ "×14" \square

Paper weight:

 $60 - 128 \text{ g/m}^2$, 16 - 34 lb.

Stack capacity:

No Staple:

- 1,000 sheets (A4 \square , B5 JIS $\square \square$, $8^{1}/_{2}$ " × 11" $\square \square$) (80 g/m², 20 lb.)
- 500 sheets (A3 \square , B4 JIS \square , 11" × 17" \square , 8¹/₂" × 14" \square) (80 g/m², 20 lb.) Staple:
- 1000 sheets (A4 $\square \square$, B5 JIS $\square \square$, $8^1/2" \times 11" \square \square$) (80 g/m², 20 lb.)
- 500 sheets (A3 \square , B4 JIS \square , 11" × 17" \square , 8¹/₂" × 14" \square) (80 g/m², 20 lb.)

Staple capacity:

- 50 sheets (A4 \square , B5 JIS \square , $8^1/2" \times 11" \square \square$) (80 g/m², 20 lb.)
- 25 sheets (A3 \square , B4 JIS \square , 11" × 17" \square , 8 $^{1}/_{2}$ " × 14" \square) (80 g/m 2 , 20 lb.)

Staple paper size:

A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square , 11" × 17" \square , 8 $^1/_2$ " × 14" \square , 8 $^1/_2$ " × 11" \square \square

♦ Staple paper weight:

 $64 - 80 \text{ g/m}^2$, 17 - 21 lb.

Staple position:

- 1 staple 2 positions
- 2 staples 1 position

Saddle stitch

• Paper size:

A3 \square , B4 JIS \square , A4 \square , 11" × 17" \square , 8¹/₂" × 11" \square , 8¹/₂" × 14" \square (80 g/m², 20 lb.)

- Saddle stitching capacity: 10 sheets
- Stack capacity:

1–5 sheets: 20 sets

6-10 sheets: 10 sets

- Folding: Centre folding
- Paper weight: $64 80 \text{ g/m}^2$, 17 20 lb.
- Saddle Stitch 1 position

Q

Power consumption:

Less than 60 W (power is supplied from the main unit)

ightharpoonup Dimensions (W imes D imes H):

- 1 Tray Paper Unit 695 × 603 × 834 mm, 27.4" × 23.8" × 32.9"
- 2 Tray Paper Unit 695 × 603 × 932 mm, 27.4" × 23.8" × 36.7"

♦ Weight:

Approx. 38 kg, 83.8 lb. (main unit only)

Punch Kit (Booklet finisher)

Paper size

- 2 holes: A3□, A4□□, B4 JIS□, B5 JIS□□, 11" × 17"□, 8¹/2" × 14"□, 8¹/2" × 11"□□
- 4 holes: A3, A4,

Paper weight:

 $64 - 128 \text{ g/m}^2 (16-34 \text{ lb.})$

Power consumption:

60 W (power is supplied from the main unit.)

\clubsuit Dimensions (W \times D \times H):

 $137 \times 560 \times 170 \text{ mm}, 5.4" \times 22.1" \times 6.7"$

♦ Weight:

Approx. 3.0 kg, 6.7 lb

Note

☐ Specifications are subject to change without notice.

1 Tray Paper Unit

Paper weight:

 $60-105 \text{ g/m}^2 (16-28 \text{ lb.})$

Paper size:

A3\$\,\text{D}, B4 JIS\$\,\text{D}, A4\$\,\text{D}\$\,\text{D}, B5 JIS\$\,\text{D}\$\,\text{D}, A5\$\,\text{D}, 11" \times 17"\$\,\text{D}, 8\$^1/2" \times 14"\$\,\text{D}, 8\$^1/2" \times 13"\$\,\text{D}, 8\$^1/2" \times 10\$^1/2"\$\,\text{D}, 8\$^1/4" \times 13"\$\,\text{D}, 7\$^1/4" \times 10\$^1/2"\$\,\text{D}, 8\$^1/4" \times 14"\$\,\text{D}, 5\$^1/2" \times 8\$^1/2"\$\,\text{D}\$

Maximum power consumption:

Less than 50 W (power is supplied from the main unit)

Paper capacity:

550 sheets (80 g/m^2 , 20 lb.)

♦ Dimensions (W × D × H):

 $578 \times 648 \times 876$ mm, $22.8'' \times 25.6'' \times 34.5''$

♦ Weight:

Approx. 18 kg, 39.7 lb.

Note

☐ Specifications are subject to change without notice.

2 Tray Paper Unit

Paper weight:

 $60-105 \text{ g/m}^2 (16-28 \text{ lb.})$

Paper size:

A3\$\oplus, B4 JIS\$\oplus, A4\$\oplus, B5 JIS\$\oplus, A5\$\oplus, 11" \times 17"\$\oplus, 8\$^1/2" \times 14"\$\oplus, 8\$^1/2" \times 13"\$\oplus, 8\$^1/2" \times 13"\$\oplus, 8\$^1/4" \times 13"\$\oplus, 7\$^1/4" \times 10\$^1/2"\$\oplus, 8\$^1/4" \times 14"\$\oplus, 5\$^1/2" \times 8\$^1/2"\$\oplus, 8\$\oplus, 2\$\oplus, 2\$\oplus, 2\$\oplus, 3\$\oplus, 2\$\oplus, 3\$\oplus, 3

Maximum power consumption:

Less than 50 W (power is supplied from the main unit)

♦ Paper capacity:

1,100 sheets (80 g/m², 20 lb.) \times 2 trays

♦ Dimensions (W × D × H):

 $578 \times 648 \times 974$ mm, $22.8" \times 25.6" \times 38.4"$

♦ Weight:

Approx. 25 kg, 55.2 lb.

9

Large Capacity Tray

❖ Paper size:

$$A4 \square$$
, $8^1/2$ " × 11" \square

◆ Paper weight:

$$60 - 105 \text{ g/m}^2$$
, $16 - 28 \text{ lb}$.

❖ Paper capacity:

 $2,000 \text{ sheets } (80 \text{ g/m}^2, 20 \text{ lb.})$

♦ Power consumption:

Maximum 50 W (power is supplied from the main unit)

\clubsuit Dimensions (W \times D \times H, option unit):

 $578 \times 648 \times 974$ mm, $22.8" \times 25.6" \times 38.4"$

♦ Weight:

Approx. 25 kg, 55.2 lb.

𝒜 Note

☐ Specifications are subject to change without notice.

Copy Paper

Recommended Paper Sizes and Types

The following limitations apply to each tray:

| Tray type | Paper type and weight | Metric version | Inch version | Paper capacity |
|--|--|--|---|----------------|
| Tray 1 | 60-105 g/m ² (16-28 lb.) | $A4 \square, 8^{1}/_{2}" \times 11" \square$ | | 500 sheets |
| Tray 2 Paper Tray Unit (Tray 3–4) (option) | 60-105 g/m ² (16-28 lb.) | A3D, B4 JISD, A4 DD, 17"D, 8 ¹ / ₂ " × 14"D, 8 ¹ / ₂ 8 ¹ / ₂ "D, 7 ¹ / ₄ " × 10 ¹ / ₂ "D, 8 ¹ / ₄ " × 13"D, 8 ¹ / ₄ " × 14"I | "×11" $\square \square$, $5^1/2$ " × 8"×13" \square , $8^1/2$ " × 13" \square , | 500 sheets |
| Bypass tray *1 | Standard paper 60-90.2 g/m ² (16-24 lb.) | A3D, B4JISD, A4DD, A6D, B5JISDD, A5DD, B6JISD, 11"× 17"D, 8 ¹ / ₂ "×11"DD, 8 ¹ / ₂ "×14"D, 5 ¹ / ₂ "× 8 ¹ / ₂ "D, 12"×18"D B4JISD, A4DD, B5 JISD, A6D, PostcardD, 8 ¹ / ₂ "×14"D, 7 ¹ / ₄ "× 10 ¹ / ₂ "DD, 8 ¹ / ₂ "×13" D, 8 ¹ / ₄ "×13"D, 11"× 14"D | | 100 sheets |
| | | Custom size | Custom size | |
| | | Vertical: 90-305 mm | Vertical: 3.6"-12.0" | |
| | | Horizontal: 148-457.2 mm | Horizontal: 5.8"-18.0" | |
| | Thick paper *3 *5 *6 105-163 g/m ² (24-43.5 lb.) | A3 \square , B4 JIS \square , A4 \square \square , A6 \square , B5 JIS \square 0, A5 \square 0, B6 JIS \square 0, 11" × 17" \square 0, 8 1 /2" × 11" \square 10, 8 1 /2" × 14" \square 0, 5 1 /2" × 8 1 /2" \square 0, 12" × 18" \square 0 | A3D,11"×17"D,8 ¹ / ₂ "× 11"DD,5 ¹ / ₂ "×8 ¹ / ₂ "D | *3 |
| | | Custom size | Custom size | |
| | | Vertical: 90-305 mm | Vertical: 3.6"-12.0" | |
| | | Horizontal: 148-457.2 mm | Horizontal: 5.8"-18.0" | |
| | Translucent paper | A3D, B4JISD, A4DD, B5JISDD | $A3\Box$, 11"×17" \Box , 8 ¹ / ₂ "× 11" \Box D \Box , 5 ¹ / ₂ "×8 ¹ / ₂ " \Box | 10 sheets |
| | OHP transpar- encies *7 *2 | A4 🕽 🗗 | 8 ¹ / ₂ "×11"□ | 50 sheets |
| | Label paper (adhesive labels) *2 *3 *6 | B4□, A4□□ | A3 \Box ,11"×17" \Box ,8 ¹ / ₂ "× 11" \Box \Box ,5 ¹ / ₂ "×8 ¹ / ₂ " \Box | 30 sheets |
| LCT (optional) *3 *4 | Standard paper 60-105 g/m² (16- 28 lb.) | A4♥,8¹/2"×11"♥ | - | 2000 sheets |

q

- *1 When copying onto custom size paper, you need to specify vertical and horizontal dimensions. See "Copying from the Bypass Tray", Copy Reference.
- *2 Placing one sheet at a time is recommended. See "Copying from the Bypass Tray", Copy Reference.
- *3 When loading paper, make sure the top of the stack is not higher than the limit mark of the paper tray.
- *4 The paper guide is immovable. If you want to change the size of paper placed in this tray, contact your service representative.
- *5 If you want to use thick (128–163 g/m², 34 lb.–43.5 lb.) paper, select [**Thick Paper**] on the display panel. See "Copying from the Bypass Tray", *Copy Reference*.
- *6 When copying onto label paper from the bypass tray, select [Thick Paper] on the display panel. See "Copying from the Bypass Tray", Copy Reference.
- *7 When copying onto OHP transparencies from the bypass tray, select [OHP Sheet] on the display panel. See "Copying from the Bypass Tray", Copy Reference.

| - | | | | |
|-----|---|--------|-----|----|
| 糠 | m | nn | rta | nt |
| 7:1 | | \sim | | |

| $\operatorname{\beth}$ If you use damp or curled paper, a misfeed may o | ccur. |
|---|-------|
|---|-------|

- $\hfill\Box$ Load paper into the paper tray, the paper tray unit and the LCT with the print side facing down.
- ☐ Place paper in the bypass tray with the print side facing up.
- \square When using the bypass tray, it is recommended that you set the paper orientation to \square .
- □ When loading OHP transparencies, check the front and back of the sheets, and place them correctly, or a misfeed might occur. Set the paper orientation to \Box and select A4 \Box , 8 $^{1}/_{2}$ "×11" \Box as paper size.
- ☐ When using OHP transparencies, fan them for each use. If you store the sheets in the tray, they may stick together and may cause feeding problems.
- ☐ When copying onto OHP transparencies, remove copied sheets one by one.
- ☐ If multiple-sheet jams occur, load the paper sheet by sheet.
- ☐ Postcards should be fed using the bypass tray. Select [Thick Paper] on the display panel. See "Copying from the Bypass Tray", Copy Reference.
- ☐ When copying onto letterhead paper, placing orientation differs according to the function you are using. See p.111 "Orientation-Fixed Paper or Two-Sided Paper".
- □ If you load paper of the same size in the same orientation in two or more trays, the machine automatically shifts to the other tray when the first tray in use runs out of paper. This function is called "Auto Tray Switching". (However, if one tray has recycled or special paper, the settings of the other trays must be the same for Auto Tray Switching to work.) This saves interrupting a copy run to replenish paper when making a large number of copies. See "General Features 1/5 Auto Tray Switching", *Copy Reference* and p.53 "Tray Paper Size:Tray 2–4".
- ☐ The paper types you can select in System Settings are only general classifications. Copy quality for every kind of paper in a classification is not guaranteed. See p.111 "Orientation-Fixed Paper or Two-Sided Paper" for details.

Unusable Paper

A CAUTION:

• Do not use aluminum foil, carbon paper, or similar conductive paper to avoid a fire or machine failure.

∰Important

- ☐ To prevent faults, do not use any of the following kinds of paper:
 - Paper for inkjet printers
 - Thermal fax paper
 - Art paper
 - Aluminum foil
 - Carbon paper
 - Conductive paper
 - Coloured OHP transparencies
 - Paper with perforated lines
 - Hemmed-edge paper
- ☐ Do not use paper designed for inkjet printers, as these may stick to the fusing unit and cause a misfeed.
- ☐ Do not use copy paper that has been already copied onto, faults could occur if you do.

Note

- ☐ To prevent misfeeds, do not use the following kinds of paper:
 - Bent, folded, or creased paper
 - Torn paper
 - Slippery paper
 - Perforated paper
 - Rough paper
 - Thin paper with little stiffness
 - Paper with a dusty surface
- ☐ If you copy onto rough grain paper, the image might be blurred.

q

Paper Storage

- ☐ When storing paper, the following precautions should always be followed:
 - Do not store paper where it will be exposed to direct sunlight.
 - Avoid storing paper in humid areas (humidity: 70% or less).
 - Store on a flat surface.
- \square Do not store paper vertically.
- $\hfill\Box$ Under high temperature and humid conditions, or low temperature and humid conditions, store paper in vinyl bags.

INDEX

| 1 Tray paper unit, 17 2 Tray Finisher, 166 2 Tray finisher, 17 2 Tray paper unit, 17 A Adding staples, 125 Adding toner, 112 Address book, 66 change order, 62 | Changing the language, 151 Changing the paper size, 122 Check Modes key, 20 Cleaning the Dustproof Glass, 144 Clear counter per user code, 60 Clearing misfeeds, 114 Clearing the number of prints, 74 Clear Modes key, 20 Clear/Stop key, 20 Colour circle, 19 Colour selection keys, 20 Combined function operations, 25 |
|---|---|
| edit title, 63 program/change/delete group, 61 program/change/delete transfer request, 62 select title, 63 Address Book Management, 61 ADF, 17 Adjusting the Colour Registration, 131 | Common key operations, 21 Control panel, 15, 19 Copy Count Display, 49 Copy paper, 172 Cover sheet tray, 55 |
| Auto Colour Registration, 131 Fuser Adjustment for thick paper, 132 Adjust/Program Colour key, 19 Auto colour calibration, 135 Auto Delete File, 64 Auto Document Feeder, 15, 165 cleaning, 143 Auto Off, 24 Auto off timer, 56 Auto reset timer copier/Document Server, 57 facsimile, 57 scanner, 57 system, 56 B | Delete all files, 64 Deleting a group, 96 Deleting a registered e-mail destination, 82 Deleting a registered fax destination, 80 Deleting a registered folder, 87, 90 Deleting a registered Transfer Station/ Receiving Station, 99 Deleting a user, 70 Deleting a user code, 73 Display counter, 59 counter per user code, 60 Displaying destinations registered in groups, 95 |
| Booklet finisher, 17, 168 Browse network, 85 C Changing a group name, 95 Changing an LDAP server, 103 Changing a registered e-mail destination, 82 Changing a registered fax destination, 78 Changing a registered folder, 86, 89 Changing a registered Transfer Station/ | Displaying the Counter for each user code, 73 Displaying the Total Counter, 152 Display panel, 19, 21 Document Server, 31 Deleting, 41 Downloading, 42 Printing, 38 Selecting, 36 Using the Document Server, 33 Viewing, 41 Do's and Don'ts, 137 |
| Receiving Station, 99 Changing a user code, 72 Changing a user name, 70 Changing paper size of the paper tray, 122 | Duplex reversal unit, 15 |

| E | М |
|--|--|
| E-mail destination, 81 Energy Saver key, 20 Entering text, 153 Environment, 140 Exposure glass, 15 cleaning, 143 Exposure glass cover, 17 cleaning, 143 | Machine environment, 140 Main power indicator, 20 Main power switch, 15, 22 Maintaining Your Machine, 143 Main Unit, 161 Misfeeds, 114 Moving, 141 Multi-Access, 27 |
| Extended security, 59 Extended Security function, 155 External charge unit management, 58 External options, 17 External tray, 15 | Number keys, 20 |
| Fax destination, 76 | Operation switch, 20, 22 Options, 165 |
| Finisher, 17 Front cover, 16 FTP, 88 Function keys, 20 Function Priority, 49 Function reset timer, 50 Function status indicators, 20 Fuser Adjustment Sheet II, 134 | Panel off timer, 56 Panel Tone, 49 Paper changing, 122 loading, 109 Paper tray, 16 Paper tray priority copier, 53 |
| Indicators, 19 Inquiry, 151 Internal options, 18 Interrupt key, 20 | facsimile, 53 printer, 53 Paper type bypass tray, 54 tray 1–4, 54 Password management for stored files, 64 |
| # key, 20 Key counter management, 58 Key Operator Code, 58 | Power connection, 141 Power indicator, 20 Print address book, 60 counter, 59 counter per user code, 60 |
| Large Capacity Tray, 171 Large Capacity Tray (LCT), 17 LDAP server, 101 Left tray, 17 Loading Paper Large Capacity Tray, 110 Loading paper, 109 paper size, 122 paper tray, 109 | Printing the Counter for each user code, 73 Print Priority, 50 Program/change LDAP server, 65 Program key, 20 Programming an LDAP server, 101 Protection code, 91, 92 destination, 91 Punch kit (2 tray finisher), 167 Punch kit (Booklet finisher), 169 |

| R | <u>T</u> |
|--|--|
| Receiving Station, 97 Registering a fax destination, 77 Registering an e-mail destination, 81 Registering a new user code, 71 Registering a protection code, 91 Registering a protection code to a group user, 92 Registering a protection code to a single user, 91 Registering a Transfer Station/ Receiving Station, 97 Registering a user name, 69 Registering destinations to a group, 93 Registering Folders, 84 Registering the Transfer Request, 97 Remarks, 137 | Toner, 139 adding, 112 storage, 139 To register an FTP folder, 88 To register an SMB folder, 84 Transfer Station, 97 Tray paper size, 53 U Upper right cover, 16 Use LDAP server, 65 User Code, 71 User code management, 58 |
| Removing a destination from a group, 94 Removing jammed staples, 127 Removing punch waste, 129 Replacing the Fuser Oil Unit, 145 Replacing the Waste Toner Bottle, 148 S | User name, 69 User Tools/Counter key, 19 User Tools (System Settings), 45 Using FTP to Connect, 88 Using SMB to Connect, 84 |
| Safety information, 9 Sample Copy key, 20 Saving Colour Copies, 138 Saving energy, 23 | Ventilation holes, 15 |
| Screen contrast knob, 19 Security, 155 Set date, 57 Set time, 57 size setting, 52 Slip sheet tray, 55 SMB, 84 Specification 2 Tray Paper Unit, 170 Specifications, 161 1 tray paper unit, 170 2 Tray Finisher, 166 Auto Document Feeder, 165 booklet finisher, 168 Large Capacity Tray (LCT), 171 main unit, 161 punch kit, 167, 169 Standard Tray, 16 Staples adding, 125 removing jammed staples, 127 Start key, 20 System Reset, 26 | Warm Up Notice (copier/Document Server), 49 Web browser, 41 |



Declaration of Conformity

"The Product complies with the requirements of the EMC Directive 89/336/EEC and its amending directives and the Low Voltage Directive 73/23/EEC and its amending directives."

In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- I means POWER ON.
- O means POWER OFF.
- () means STAND BY.



RICOH COMPANY, LTD.

15-5, Minami Aoyama 1-chome, Minato-ku, Tokyo 107-8544, Japan

Phone: +81-3-3479-3111



Overseas Affiliates

U.S.A.

RICOH CORPORATION 5 Dedrick Place West Caldwell, New Jersey 07006 Phone: +1-973-882-2000

The Netherlands

RICOH EUROPE B.V. Groenelaan 3, 1186 AA, Amstelveen Phone: +31-(0)20-5474111

United Kingdom

RICOH UK LTD. Ricoh House. 1 Plane Tree Crescent, Feltham, Middlesex, TW13 7HG Phone: +44-(0)20-8261-4000

Germany

RICOH DEUTSCHLAND GmbH Mergenthalerallee 38-40, 65760 Eschborn Phone: +49-(0)6196-9060

France

RICOH FRANCE S.A. 383. Avenue du Général de Gaulle BP 307-92143 Clamart Cedex Phone: +33-(0)-821-01-74-26

Spain

RICOH ESPAÑA S.A. Avda. Litoral Mar, 12-14, Blue Building, Marina Village, 08005 Barcelona Phone: +34-(0)93-295-7600

Italy

RICOH ITALIA SpA Via della Metallurgia 12, 37139 Verona Phone: +39-045-8181500

China

RICOH CHINA CO.,LTD 29/F., Lippo Plaza, No.222 Huai Hai Zhong Road, Lu Wan District, Shanghai P.C.:200021 Phone: +86-21-5396-6888

Singapore

RICOH ASIA PACIFIC PTE.LTD. 260 Orchard Road, #15-01/02 The Heeren, Singapore 238855 Phone: +65-6830-5888

Printed in The Netherlands GB (GB) B149-7500



Operating Instructions Copy Reference



- Placing Originals
- 2 Copying
- (3) Colour Adjustment/ Program
- **4** Troubleshooting
- 5 User Tools (Copier/Document Server Features)
- 6 Specifications

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.



Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Warning:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Notes:

The model names of the machines do not appear in the following pages. Check the type of your machine before reading this manual. (For details, see P.3 "Machine Types".)

- Type 1: Aficio 2232C
- Type 2: Aficio 2238C

Certain types might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

For good copy quality, Ricoh recommends that you use genuine Ricoh toner.

Ricoh shall not be responsible for any damage or expense that might result from the use of parts other than genuine Ricoh parts with your Ricoh office products.

Power Source

220-240V. 50/60Hz. 8A or more

Please be sure to connect the power cord to a power source as shown above. For details about power source, see "Power Connection" in the General Settings Guide.

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1 "Operating Instructions for Printer/Scanner"
 - CD-ROM 2 "Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference (this manual)

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference < Basic Features >

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference <Advanced Features>

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] display when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview
 of its functions. This guide is added to the [Start] menu when DeskTop Binder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] display when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an
 overview of ScanRouter V2 Lite functions. This guide is added to the [Start]
 menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- Unix Supplement (Available from an authorized dealer, or as a PDF file on our Web site.)

What You Can Do with This Machine <Colour Functions/Colour Adjustments>

Colour Copying (see p.29)

You can switch the colour copy mode depending on the type of originals used and the desired finish.



Copies using four colours: yellow, magenta, cyan and black.




Copies in black and white, even when the original is in colour.




Single Colour Copy (see p.29)

Copies in the designated colour.



2-Colour Copy (see p.29)

Colour: Copies using 2 registered colours.








Colour Copying (see p.29)

Convert Colours (see p.31)

Copies by changing a specific colour in the original to another colour.




Erase Specified Colour (see p.32)

Copies by deleting a specific colour in the original.




Colour Background (see p.32)


Copies by adding a colour to the whole page.



Stamping on Copies (see p.70)

Copies with the date, page numbers, etc. The stamp colour can be yellow, red, cyan, magenta, green, blue, and black.






Printed inserts types:

- Preset Stamp (p.70)
- User Stamp (p.72)
- Date Stamp (p.75)
- Page Numbering (p.77)

GCMO026e

Adjusting Colours (see p.87)






Colours can be created by combining the 3 primary colours: yellow, magenta and cyan. Black can be made by combining yellow, magenta and cyan, however, as there might be some slight differences, "black" will be expressed using a black toner.


Adjust Colour (see p.87)

Adjusts the specific colours (yellow, red, magenta, blue, cyan and green) by mixing them with adjacent colours in the colour circle.



Adjusts the overall colour tone of copies.





Adjusting Images (see p.90)

Sharp/Soft (see p.90)

Adjusts the outline of the image.





Contrast (see p.90)

Adjusts the shades of the image.





Background Density (see p.91)

Adjusts the background density of the





Other Adjustments (see p.91)

♦ Adjust U.C.R (see p.91)

◆ Text/Photo Sensitivity (see p.91)


♦ A.C.S. Sensitivity (see p.125)

♦ Colour Sensitivity (see p.125)

GCMO0236


What You Can Do with This Machine

Functions differ depending on machine type and options. See p.4 "Functions Requiring Optional Configurations".




Copying Book Originals

1-sided → Magazine (see p.61 " ❖ 1 Sided → Magazine")



2-sided → Magazine (see p.62 " ❖ 2 Sided → Magazine")




Combining Multiple Pages onto a Single Page (see p.57 " One-Sided Combine")


1-sided 2 Pages → 1-sided 1 Page



1-sided 4 Pages → 1-sided 1 Page



1-sided 8 Pages → 1-sided 1 Page




Copying Originals Such as Books (see p.60 "Series Copies")

Bound Originals → 1-sided Pages



Bound Originals → 2-sided Pages



Front/Back Bound Originals


→ 2-sided Pages




2-sided 1 Page → 1-sided 1 Page



2-sided 2 Pages → 1-sided 1 Page



2-sided 4 Pages → 1-sided 1 Page



Copying 2-Sided Pages onto 1-Sided Pages (see p.55 "2 Sided→1 Sided")

2-sided 1 Page → 1-sided 2 Pages



Copying onto Envelopes (see p.26)



TABLE OF CONTENTS

| Manuals for This Machine | i |
|---|----------|
| What You Can Do with This Machine < Colour Functions/Colour Adjustm | ents>iii |
| What You Can Do with This Machine | |
| Notice | |
| How to Read This Manual | |
| | |
| Machine Types | |
| Functions Requiring Optional Configurations | |
| Control Panel | |
| Display Panel | 7 |
| 1 Placing Originals | |
| 1. Placing Originals | |
| Originals | 9 |
| Sizes and Weights of Recommended Originals | 9 |
| Sizes Detectable by Auto Paper Select | |
| Missing Image Area | 12 |
| Placing Originals | 13 |
| Original Orientation | |
| Placing Originals on the Exposure Glass | |
| Placing Originals in the Auto Document Feeder | 15 |
| 2. Copying | |
| z. copying | |
| Basic Procedure | 19 |
| Interrupt Copy | 20 |
| Left Original Beeper | |
| Job Preset | 21 |
| Copying from the Bypass Tray | |
| When copying onto OHP Transparencies or Thick Paper | |
| When Copying on the Back Side of the Paper | |
| When copying onto envelopes | |
| Making A3, 11" × 17" Full Bleed Copies | 28 |
| Colour Functions | 29 |
| Selecting a Colour Mode | 29 |
| Convert Colours | _ |
| Erase Colour | |
| Colour Background | 32 |

| L | opier Functions | |
|----|--|-----|
| | Adjusting Copy Image Density | |
| | Selecting the Original Type | |
| | Selecting Copy Paper | |
| | Preset Reduce/Enlarge | |
| | Zoom | |
| | Auto Reduce/Enlarge | 40 |
| | Size Magnification | |
| | Directional Magnification (%) | |
| | Directional Size Magnification (mm) | |
| | Sort | |
| | Stack | |
| | Staple | |
| | Punch | |
| | Duplex | |
| | 1 Sided Combine | |
| | 2 Sided Combine | |
| | Series Copies | |
| | Copying Book Originals | |
| | Image Repeat | |
| | Double Copies | |
| | Centring | |
| | Positive/Negative | |
| | Mirror | |
| | Erase | |
| | Margin Adjustment | |
| | Preset Stamp | |
| | User Stamp | |
| | Date Stamp | |
| | Page Numbering | |
| | Covers | |
| | Slip Sheets | |
| | toring Data in the Document Server | |
| P | rograms | 85 |
| | Storing a Program | 85 |
| | Changing a stored program | 86 |
| | Deleting a Program | 86 |
| | Recalling a Program | 86 |
| 2 | Colour Adiustra ant / Draguerra | |
| J | . Colour Adjustment/ Program olour Adjustment | |
| | | |
| C | olour Balance | |
| | Colour Balance Program | |
| lr | nage Adjustment | 90 |
| | ser Colour | |
| _ | Adjusting Colours Based on the Selected Colour | |
| | Mixing Colours Manually with the Number Keys | 92 |
| | Deleting User Colours | |
| | Sampling the User Colours | |
| | r J | . • |

4. Troubleshooting

| If Your Machine Does Not Operate As You Want | |
|--|-----|
| When a Message Is Displayed | |
| If You Cannot Make Clear Copies | |
| If You Cannot Make Copies As You Want | |
| When Memory Is Full | 101 |
| 5. User Tools (Copier/Document Server Features) | |
| User Tools Menu (Copier/Document Server Features) | 103 |
| Accessing User Tools (Copier/Document Server Features) | |
| Changing Default Settings | |
| Exiting User Tools | |
| Settings You Can Change with User Tools | |
| General Features ¹ / ₅ | |
| General Features ² / ₅ | |
| General Features ³ / ₅ | 114 |
| General Features ⁴ / ₅ | 115 |
| General Features ⁵ / ₅ | 115 |
| Reproduction Ratio ¹ / ₂ | 116 |
| Reproduction Ratio ² / ₂ | 116 |
| Edit ¹ / ₂ | 117 |
| Edit ² / ₂ | 118 |
| Stamp | |
| Input/Output | |
| Adjust Colour Image | 125 |
| 6. Specifications | |
| Combination Chart | |
| Supplementary Specifications | 128 |
| INDEX | 139 |

Notice

Do not copy any item for which copying is prohibited by law.

Copying the following items is generally prohibited by local law:

bank notes, revenue stamps, bonds, stock certificates, bank drafts, checks, passports, and driver's licenses.

The colour samples in this manual may differ slightly from the colours of actual copies.

This machine has a function that prevents making counterfeit bank notes. This function may prevent originals similar to bank notes from being copied properly.

How to Read This Manual

Symbols

This manual uses the following symbols:

↑ WARNING:

This symbol indicates a potentially hazardous situation that might result in death or serious injury if you misuse the machine by not following the instructions under this symbol. Be sure to read the instructions, all of which are included in the Safety Information section in the General Settings Guide.

↑ CAUTION:

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in the Safety Information section in the General Settings Guide.

• WARNINGS and CAUTIONS are notes for your safety.

∰Important

If these instructions are not followed, paper might misfeed, originals might be damaged, or data might be lost. Be sure to read these instructions.

Preparation

This symbol indicates prior knowledge or preparations are required before operation.

∅ Note

This symbol indicates precautions for operation, or actions to be taken following user error.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates where further relevant information can be found.

[]

Keys that appear on the machine's display panel.

Keys built into the machine's control panel.

Machine Types

This machine comes in two models which vary by copy speed. To confirm which model you have, see the inside front cover of this manual.

| | Type 1 | Type 2 |
|------------------------|---|--|
| Copy speed/B&W | 32 copies/minute $(A4 \ \square, 8^1/_2" \times 11" \ \square)$ | 38 copies/minute $(A4 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$ |
| Copy speed/Full Colour | 24 copies/minute $(A4 \square, 8^1/2" \times 11" \square)$ | 28 copies/minute $(A4 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$ |

Functions Requiring Optional Configurations

Certain functions require special machine configuration and extra options. See the table below.


ORequired options

| Function | Batch | SADF | Mixed Size | Shift Sort | Stack | Staple | Staple (Saddle Stitch) | Punch |
|----------------------------|-------|------|------------|------------|-------|--------|------------------------|-------|
| Auto Document Feeder (ADF) | О | О | О | | | | | |
| 2 tray finisher *1 | | | | О | О | 0 | | О |
| Booklet finisher *1 | | | | 0 | О | О | О | О |

 $^{^{*1}}$ The paper tray unit is required in order to install the finisher.

Control Panel

This illustration shows the control panel of a machine with options fully installed.



1. Screen Contrast knob

Adjusts display panel brightness.

2. [User Tools/Counter] key

• User Tools

Press to change the defaults and conditions to meet your requirements. See p.103 "User Tools (Copier/Document Server Features)".

Counter

Press to check or print the counter value.

See "Counter", General Settings Guide.

Inquiry

Press to find out where to order expendable supplies and where to call when a malfunction occurs. You can also print these details.

See "Inquiry", General Settings Guide.

3. Indicators

Display the status of the machine or indicate errors.

- 📥: Add Staple indicator
- 🕍: Add Toner indicator
- Load Paper indicator
- 1: Service Call indicator
- []*: Open Cover indicator
- **%**: Misfeed indicator

See "Control Panel", General Settings Guide.

4. [Adjust/Program Colour] key

Use this key to adjust and register colours. See p.87 "Colour Adjustment/ Program", p.92 "User Colour".

☐ When image quality is adjusted, the lamp in the [Adjust/Program Colour] key is lit.

5. Colour Circle

Refer to this when adjusting colours. See p.87 "Colour Adjustment".

6. Display panel

Displays operation status, error messages, and function menus.

See "Display Panel", General Settings Guide.

7. [Check Modes] key

Press to check the entered copy job settings.

8. [Program] key

Press to register frequently used settings, or recall registered settings. See p.85 "Programs".

9. [Clear Modes] key

Press to clear the previous copy job settings.

10. [Energy Saver] key

Press to switch into and out of Energy Saver mode. See "Saving Energy", General Settings Guide.

11. [Interrupt] key

Press interrupt a long copy job to make copies during copying or scanning. See p.20 "Interrupt Copy".

12. Main power indicator and On indicator

The main power indicator turns on when you turn on the main power. The **On** indicator lights when the power is on.

∰Important

Do not turn off the main power switch while the **On** indicator is turning on or is flashing. The hard disk may malfunction.

13. Operation switch

Press to turn the power on (the **On** indicator turns on). To turn the power off, press again (the **On** indicator turns off). See "Turning On the Power", *General Settings Guide*.

14. [Sample Copy] key

Press to make a single set of copies or prints to check print quality before making multiple sets. See p.45 "Sample copy".

15. [Start] key

Press to start copying. Press to start scanning or printing documents stored using the Document Server function.

16. [Clear/Stop] key

- Clear Press to delete a number entered.
- Stop Press to stop a job in progress.

17. [#] key

Press to enter a numerical value.

18. Number keys

Press to enter the number of copies and data for a selected function.

19. Colour Selection Key (Copy mode)

Switch keys depending on the type of original, or the copying purpose:

[Auto Colour Selection] : @ .../ .../

[Full Colour]: ♣ [Black & White]: ♣ [Single Colour]: ♣ [Two-colour]: ♣

See p.29 "Colour Functions"

20. Function keys

• Document Server: 🗗

Press to select one of the following functions:

- Copy:
- Scanner:

21. Function status indicators

Display the status of the above functions:

- Green: active
- Red: interrupted

Display Panel


The function items displayed serve as selector keys. You can select or specify an item by lightly pressing them.

When you select or specify an item on the display panel, it is highlighted like this: Total . Keys appearing as OK cannot be used.

Note

☐ The following illustration is an example of the panel display when the booklet finisher and 2 tray paper unit installed.

Initial copy display



AAE013

- 1. Original function, Image Density and Special Original function.
- 2. Operational status and messages.
- 3. You can register up to three frequently used reduce/enlarge ratios other than the fixed reduce/enlarge ratios. See p.116 "Shortcut R/E".
- 4. Numbers of originals scanned into memory, copies set, and copies made.
- 5. Sort, Stack, Staple, Punch functions.

- 6. Displays contents of the Shortcut keys. You can register frequently used functions in these keys. See p.114 "Copy Function Key: F1-F5".
- 7. Displays available functions. Press a function name to display its menu. For example, press [Reduce/Enlarge] to bring up the Reduce/Enlarge menu.
- 8. A clip mark indicates the currently selected function.

1. Placing Originals

Originals

𝒯 Note

☐ Highlighter pen colours are difficult to reproduce. Depending on the colour used, they may not come out on copies, or may come out as a different colour.

Sizes and Weights of Recommended Originals

Metric version

| Where original is placed | Original size | Original weight |
|--------------------------|---|-------------------------|
| Exposure glass | Up to A3 | |
| ADF | One-sided originals: A3□ – B6 JIS (Japanese Industrial Standard) □□ | 40–128 g/m ² |
| | Two-sided originals: A3□ – A5□□ | 52–105 g/m ² |

Inch version

| Where original is placed | Original size | Original weight |
|--------------------------|---|-----------------|
| Exposure glass | Up to 11" × 17" | |
| ADF | One-sided originals: $11" \times 17" \square - 5^1/2" \times 8^1/2" \square \square$ | 11–34 lb. |
| | Two-sided originals: $11" \times 17" \square - 5^1/2" \times 8^1/2" \square \square$ | 14–28 lb. |

Note

- \square The maximum number of originals that can be placed in the ADF is about 80.
- \Box The weight range for originals when using the Mixed Size function is 52–81 g/m², 13.8–21.5 lb.

Originals not recommended for the Auto Document Feeder (ADF)

Placing the following types of originals in the ADF can cause paper misfeeds or result in damage to the originals. Place these originals on the exposure glass instead.

- Originals other than those specified on p.9 "Sizes and Weights of Recommended Originals".
- Stapled or clipped originals
- Perforated or torn originals
- Curled, folded, or creased originals
- · Pasted originals
- Originals with any kind of coating, such as thermal fax paper, art paper, aluminum foil, carbon paper, or conductive paper
- · Originals with perforated lines
- Originals with indexes, tags, or other projecting parts
- Sticky originals such as translucent paper
- Thin originals that have low stiffness
- Thick originals such as postcards
- Originals of inappropriate weight
- Bound originals such as books
- Transparent originals such as OHP transparencies or translucent paper

Note

☐ The original might become dirty if it is written on with a pencil or a similar instrument.

Sizes Detectable by Auto Paper Select

O: Detectable size ×: Undetectable size

Metric version


| Size Location of the original | A3 | B4 JIS□ | A4 | B5 JIS DD | A5 | B6 JIS D | 11"× 17" □ | 8 ¹ / ₂ " × 14" □ | 8 ¹ / ₂ " × 11" □ □ | 5 ¹ / ₂ " × 8 ¹ / ₂ " | 8 ¹ / ₂ " × 13" □ *1 |
|-------------------------------------|----|------------|----|-----------------|----|-------------|------------------|--|---|---|---|
| Exposure glass | 0 | 0 | 0 | 0 | × | × | × | × | × | × | 0 |
| ADF | О | 0 | О | О | О | O *2 | О | × | О | × | 0 |

 $^{^{*1}}$ You can select from $8^1/{}_2"\times 13", 8^1/{}_4"\times 13", 8"\times 13"$ with User Tools (System Settings). The machine cannot detect two-sided originals of B6 JIS size.


Inch version

| Size Location of the original | A3 | B4 JIS□ | A4 | B5 JIS 🔽 | A5 | 11"× 17" □ | 8 ¹ / ₂ " × 14" □ | 8 ¹ / ₂ " × 11" □ □ | 5 ¹ / ₂ " × 8 ¹ / ₂ " | 8 ¹ / ₂ " × 13" □ | 10"× 14" |
|-------------------------------------|----|------------|----|-------------|----|------------------|--|---|---|--|-------------|
| Exposure glass | × | × | × | × | × | 0 | 0 | 0 | × | × | × |
| ADF | О | × | О | × | × | О | О | О | × | × | × |

Exposure glass



◆ ADF



Note

☐ When copying custom size originals, make sure you specify the size of the originals. If not, the image may not be copied properly. See p.17 "Placing custom size originals".


Sizes difficult to detect

It is difficult for the machine to automatically detect the sizes of the following types of originals, so select the paper size manually.

- Originals with indexes, tags, or other protrusions
- Transparent originals such as OHP transparencies or translucent paper
- Text or picture dense original
- · Originals containing solid images
- Originals containing solid images around their edges

Missing Image Area

Even if you correctly place originals in the ADF or on the exposure glass, margins of a few millimeters on all four sides of the original might not be copied.



1. 0.5 - 4.0 mm, 0"- 0.16"

3. 0.5 - 4.0 mm, 0"- 0.16"

2. 0.5 - 6.0 mm, 0"- 0.24"

4. 1.5 - 5.0 mm, 0.06"- 0.20"

Placing Originals

☐ Place originals only when all correction fluid and ink has completely dried. Not taking this precaution could dirty the exposure glass, thus resulting in blemished copies.

₽ Reference

For original sizes you can set, see p.9 "Originals".

Original Orientation

This function is useful for copying torn originals or large originals.


You can set the original orientation in the following ways.

♦ Standard orientation R 🗷

Select this function when original orientation is the same as copy paper orientation.

♦ 90° turn 🖳 🖭

Use this to copy A3 □, B4 JIS □ or 11" × 17" □ size originals. The machine rotates the copy image by 90°. This is useful for copying large originals using the Staple, Duplex, Combine, or Stamp functions. For example, to copy A3 □ or 11" × 17" □ originals with the Staple function selected:



Note

☐ It is recommended that you use the Original Orientation function with the Auto Paper Select or Preset Reduce/Enlarge function.


1 Press [Special Original].



2 Select the original orientation.


Standard orientation

● Make sure 🖭 is selected.



90° turn

● Place the original in the landscape orientation, and then press ☑☑.




3 Press [OK].

Placing Originals on the Exposure Glass

- 1 Lift the exposure glass cover or the ADF.
 - **#**Important
 - Do not lift the exposure glass cover or the ADF forcefully.
 Otherwise, the ADF cover might open or be damaged.

 - ☐ Be sure to lift the exposure glass cover or ADF more than 30°. Otherwise, the size of the original might not be detected correctly.
- Place the original face down on the exposure glass. It should be aligned with the rear left corner.



- 1. Positioning mark
- 2. Scale
 - **𝚱** Note
 - ☐ Start with the first page to be copied.
- Lower the exposure glass cover or ADF.

Placing Originals in the Auto Document Feeder

Settings should be made accordingly in the following situations:


- When placing originals consisting of more than 80 pages: p.15 "Batch"
- When placing originals one by one: p.16 "SADF"
- When placing originals of the same width but different sizes:

p.17 "Placing originals of mixed sizes"


When placing custom size originals: p.17 "Placing custom size originals"



- Do not stack originals above the limit mark on the side guide of the ADF.
- ☐ The last page should be on the bottom.
- ☐ Do not place objects on the sensors or cover them with your hands, or the original size may not be detected properly. Also, do not place anything on the exposure glass cover as this could cause a malfunction.



- 1 Set the document guide to the original size.
- 2 Place the aligned originals face up into the ADF.



1. Limit mark

2. Document guide

- Straighten any curls in the originals before placing them in the ADF.
- To prevent multiple sheets from being fed at once, fan the originals before placing them in the ADF.
- ☐ Place the originals squarely.

Batch


The Batch mode enables you to copy originals of more than 80 pages as a single document, even if you place the originals into the ADF in instalments.

#Important

☐ Place special originals, such as translucent paper, one by one.

1. Sensors

1 Press [Special Original].



- 2 Press [Batch], and then press [OK].

 - ☐ If **[SADF]** is displayed, change the settings. See p.124 "Switch to Batch (SADF)".
- Place the first instalment of the originals, and then press the [Start] key.
- After the originals has been fed, place the next instalments.
- When the Sort, Combine, or Duplex function is set, press the [#] key after all originals have been scanned.
- 6 Press the [Start] key.

SADF

In SADF mode, even when an original is placed one page at a time into the ADF, each page is automatically fed as it is placed.

Preparation

To use the SADF function, set the User Tools (Copier/Document Server Features) such that [SADF] is displayed when you press [Special Original]. See p.124 "Switch to Batch (SADF)".

For related default settings, see p.116 "Shortcut R/E".

1 Press [Special Original].



- 2 Press [SADF], and then press [OK].
- Place one page of an original, and then press the [Start] key.
- When the machine instructs you to place another original, place the next page.

The second and subsequent pages will feed in automatically without a need to press the **[Start]** key.

Note

- ☐ When the Sort, Combine or Duplex function is set, press the 【#】 key after all originals have been scanned.
- ☐ You can adjust the time the machine waits before becoming ready for the next original. See p.124 "SADF Auto Reset".


Placing originals of mixed sizes

When placing different size originals of the same width in the ADF together, the machine automatically checks the sizes of the originals and makes copies.

- ☐ When placing same width originals of different sizes in the ADF and making copies without using the Mixed size function, parts of the original image might not be copied, or the paper might jam.
- ☐ Copy speed and scanning speed may slow down.
- ☐ You can place originals of two different sizes at once.
- ☐ Sizes of originals that can be placed together using this function are as follows:


| Metric | A3□, B4 JIS □, A4 □□, B5 |
|-----------------|--|
| version | JIS □□ |
| Inch version | $11" \times 17" \square, 8^1/_2" \times 14" \square, 8^1/_2" \times 11" \square \square$ |

1 Press [Special Original].



Press [Mixed Size], and then press [OK].

Align the rear and left edges of the originals as shown.



- 1. Place the originals into the ADF
- 2. Vertical size
- 4 Adjust the guide to the size of the widest original.
- Place the aligned originals face up in the ADF.
- 6 Press the (Start) key.

Placing custom size originals

When placing custom size originals in the ADF, specify the size of the originals.

- ☐ Paper with a vertical size of 128–297 mm (5.1"–11.6") and a horizontal size of 128–432 mm (5.1"–17") can be placed with this function.
- 1 Press [Special Original].



Press [Custm Size Origi.].

- Enter the horizontal size of the original using the number keys, and then press [#].
 - **𝚱** Note
 - ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then enter the value again.
- 4 Enter the vertical size of the original using the number keys, and then press [#].
- **5** Press [OK].
- Place the originals, and then press the [Start] key.

2. Copying

Basic Procedure

When the machine is set for user codes, enter a user code (up to eight digits) using the number keys, and then press the [#] key.

The machine is now ready to copy.

For users codes, see "Key Operator Tools", General Settings Guide.

2 Make sure "O Ready" is shown on the display.

If any other function is displayed, press the **[Copy]** key.

Initial copy display



- Make sure no previous settings remain.
 - **𝒜** Note
 - When there are previous settings remaining, press the [Clear Modes] key before entering your settings.
- 4 Place the originals.
 - Reference p.13 "Placing Originals"
- **5** Make the necessary settings.
- 6 Enter the required number of copies using the number keys.

- ☐ The maximum copy quantity that can be set is between 1 and 999.
- Press the [Start] key.

Copying starts.

- Note
- □ When placing originals on the exposure glass, press the [#] key after all the originals are scanned.
- ☐ Copies are delivered face down.

How to operate

To stop the machine during a multicopy run

Press the [Clear/Stop] key.

- To return the machine to the initial condition after copying Press the [Clear Modes] key.
- When clearing entered values Press the [Clear/Stop] key or [Clear] on the display.
- ◆ To check the settings Press the [Check Modes] key.

Interrupt Copy

Use this function to interrupt a long copy job to make urgently needed copies.

Limitation

- You cannot use Interrupt Copy when fax originals are being scanned.
- 1 Press the [Interrupt] key.
 The Interrupt indicator lights.

When scanning is interrupted

- Remove the originals that were being copied, and then place the originals you want to copy.
- **2** Press the [Start] key. Copying starts.
- **3** When copying is complete, remove the originals and copies.
- Press the [Interrupt] key again. The Interrupt indicator turns off.
- **6** When the display prompts you to do so, place the former set of originals again.
- 6 Press the [Start] key.

Note

☐ The previous copy job's settings are restored and the machine continues copying from where it left off.

When the machine continues copying

- Place the originals you want to copy.
- 2 Press the [Start] key.

The machine stops the previous job and starts copying the new originals.

- **3** When copying is complete, remove originals and copies.
- 4 Press the [Interrupt] key again.

The **Interrupt** indicator goes out.

The previous copy job's settings are restored and the machine continues copying from where it left off.

Left Original Beeper

The beeper sounds and an error message is displayed if you leave originals on the exposure glass after copying.

∅ Note


☐ See p.114 "Tone: Original remains".

Job Preset

You can make settings for the next copy job while copying is in progress.

If a long copy job is in progress and you do not want to wait for it to finish, you can use this function to make settings for the next copy job in advance. When the current copy job finishes, the next job begins automatically.

1 Press [Next Job] when "Copying" is displayed.



- 2 Make settings for the next copy job.
- Place the originals in the ADF, and then press the [Start] key.

All originals are scanned.

Press [To "Printing"].

Returns to the initial copy display. After the current copy job, the next job starts automatically.

Note

☐ You can switch the display to the current copy job by pressing [To "Printing"]. You can switch the display to the preset job by pressing [To "Reserving"].

Copying from the Bypass Tray

Use the bypass tray to copy onto special paper such as OHP transparencies, thick paper, thin paper, and copy paper that cannot be loaded in the paper trays.

Preparation

When copying from the bypass tray, select [1 Sided] for copying in [Dup./Combine/Series] (for example [1 Sided] \rightarrow [1 Sided].)

Note

The machine can automatically detect the following sizes as standard size copy paper:


| Metric | A3□, A4□, A5□, B4 JIS□, |
|---------|---|
| version | B5 JIS□, B6 JIS□ |
| Inch | $11" \times 17" \square, 8^1/_2" \times 11" \square,$ |
| version | $5^1/_2" \times 8^1/_2" \square$ |

- ☐ Select the paper size when making horizontal copies.
- ☐ If you use non-standard size copy paper or special paper, you should input its vertical and horizontal dimensions directly. See p.17 "Placing custom size originals". The sizes you can input are as follows:


| Metric version | Vertical: 90.0 – 305.0 mm Horizontal: 148.0 – 457.2 mm |
|-------------------|---|
| Inch version | Vertical: 3.55" – 12.00" Horizontal: 5.83" – 18.00" |

- □ When copying onto OHP transparencies or paper heavier than 128 g/m² (about 34 lb.), you need to specify the paper type. See p.24 "When copying onto OHP Transparencies or Thick Paper".
- ☐ You must specify the paper size when using paper (tracing paper, etc.) of less than 59g/m² thickness.
- ☐ The maximum number of sheets you can load at one time depends on paper type. The maximum number of sheets should not exceed the upper limit.
- ☐ Some kinds of envelopes might cause misfeed and wrinkle. If this happens, push down the fusing unit's green lever. See p.26 "When copying onto envelopes". Also, be sure to place the front face of the envelope downward.
- ☐ Paper of 433 mm in length, or larger, is likely to jam, crease, or not feed in properly.

1 Open the bypass tray.



Insert the paper with the side you want to copy facing up until you hear the beep, and align the paper guide to the paper size.



1: Extender

#Important

If the guides are not flush against the copy paper, image skewing or misfeeds might occur.

Note

- ☐ Do not stack paper over the limit mark, if you do image skewing or misfeeds might occur.
- □ Swing out the extender to support paper sizes larger than $A4\square$, $8^1/_2$ " × 11" □.
- Fan paper to get air between the sheets and avoid multi-sheet feeds.
- 3 Select the paper type and size.

Ø Note

- When copying onto OHP transparencies or thick paper, see p.24 "When copying onto OHP Transparencies or Thick Paper".
- ☐ When copying on the back side of paper, see p.25 "When Copying on the Back Side of the Paper".

When copying onto standard size paper

• Press the [#] key.

The "Bypass Tray Paper" screen is displayed.

2 Press [Select Size].



- 3 Select the paper size.
- 4 Press [OK] twice.

When copying onto custom size paper

- Press the [#] key.
- 2 Press [Custom Size].




3 Enter the vertical size of the paper using the number keys, and then press [#].

4 Enter the horizontal size of the paper using the number keys, and then press [#].

Note

- ☐ If [Horiz mm] is not highlighted, press [Horiz mm].
- ☐ To register the custom size entered, press [Program], and then press [Exit].



- 6 Press [OK].
- Place the originals, and then press the [Start] key.

∅ Note

- ☐ When the Sort function is set, press the [#] key after all originals have been scanned.
- When your copy job is finished, press the [Clear Modes] key to clear the settings.

When copying onto OHP Transparencies or Thick Paper

To make copies onto OHP transparencies or thick paper, you need to specify the paper type and size. See p.23 "When copying onto standard size paper", p.23 "When copying onto custom size paper".

#Important

☐ We recommend you use OHP transparencies made by this manufacturer.

Note

- ☐ Paper will be delivered to external tray when copying onto OHP transparencies or thick paper from the bypass tray, even if you have specified not to use the external tray as the output tray.
- 1 Open the bypass tray, and then adjust the guides to the paper size.
- **2** Gently insert the OHP transparencies or thick paper face up until the beeper sounds.

#Important

- ☐ When copying onto OHP transparencies, make sure that the cut positions are set properly.
- ☐ To avoid paper misfeeds, fan the paper before loading it in the tray.
- Press the [#] key.

4 Select [OHP Sheet] or [Thick Paper].



- **5** Select the paper size.
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

∰Important

- When copying onto OHP transparencies, remove copied sheets one by one.
- When your copy job is finished, press the [Clear Modes] key to clear the settings.

When Copying on the Back Side of the Paper

Using the bypass tray, you can make copies on the back of paper which has already been copied on the other side.


Note

- Do not use paper that has already been copied onto by other equipment.
- Copies made on the back side of the paper should be originals with very little image area, such as text originals.
- ☐ If the paper is curled, straighten it out, and then insert it. If the paper is not straightened out, it can cause paper jams.


Original and paper orientations

Pay attention to the orientation of paper and originals.

Top to top



Top to bottom



- Open the bypass tray, and then adjust the guides to the paper size.
- 2 Gently insert the copied paper with the side you want to copy face up until the beeper sounds.
- Press the [#] key.
- 4 Select the paper size.
- Select [Plain: Dup.Back] or [Thick: Dup.Back].




- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

When copying onto envelopes

Note

- ☐ When placing an original on the exposure glass, place the original with the bottom line aligned to the left scale.
- ☐ When placing originals in the ADF, place the originals with the bottom line inserted in the ADF.
- When inserting envelopes, be sure to unfold the flaps and position them opposite to the paper feed direction.




For more information about supported size of envelope, see "Recommended Paper Sizes and Types", General Settings Guide.

- 1 Open the bypass tray, and then insert the envelopes with the side you want to copy face up until the beeper sounds.
- 2 Align the paper guide to the envelope side.
- Press the [#] key.
- 4 Select the paper size, and then select [Thick Paper] for the paper type.
- Press [OK].

- 6 Place the originals, and then press the [Start] key.
- When your copy job is finished, press the [Clear Modes] key to clear the settings.

Making A3, 11" × 17" Full Bleed Copies

You can make A3, $11" \times 17"$ full bleed copies with $12" \times 18"$ paper. This is useful for making A3, $11" \times 17"$ size copies with a coloured background (e.g. catalogues).



- 1. A3, 11" × 17" size Original
- 2. In standard copy mode, margins appear on copies
- 3. 12" \times 18" Full Bleed Copy
- 4. Cut around the margins to produce a full image

𝒯 Note

- \square You can use this function with 12" × 18" paper.
- \square When A3, 11" \times 17" full bleed copying is made, the original image is copied onto the center.
- ☐ You can only use this function with the bypass tray.

Colour Functions

Selecting a Colour Mode

Select a Colour mode that best suits your originals and copying requirements.

For colour images, see p.iii "What You Can Do with This Machine <Colour Functions/Colour Adjustments>"

The following basic functions are explained in this section.

Auto Colour Selection

Judges the colour of the original automatically, and copies either in full colour or black/white.

Full Colour Copy

Copies by overlaying yellow, magenta, cyan, and black.

Black/White Copy

Copies in black regardless of the colour of the original.

Single Colour Copy

Copies in one designated colour.

Note

☐ Yellow, magenta, and cyan will be copied with one toner colour, but beige, orange, red, light green, pink, green, marine blue, blue and purple uses 2 toner colours to copy.

Two Colour Copy

Two Colour Copy (Normal)
 Copies black and other parts in
 two specified colours.


Note

- ☐ You can select from basic colours and registered colours.
- Two Colour Copy (Red & Black) Copies the red part in red, and all the other parts in black or white.

Note


☐ When the width of the colour is set to "Wider", colours close to orange and purple will be recognized as red. This adjustment will be valid in "Erase Colour" and "Convert Colours". See p.125 "Colour Sensitivity"

1 Select the type of colour key.



When the [Single Colour] key is selected

Select designation method of colour ([Basic Colour], [User Colour]).




2 Select the colour, and then press [OK].

𝚱 Note

- When copied using the registered colour, the original will be copied lighter than the registered colour.
- Press [Lighter] or [Darker], and you can adjust the density in 4 steps.

When the **[Two-colour]** key is selected

Select either [Two-colour] or [Red & Black].




When [Red & Black] is pressed

• Press [OK].

When [Two-colour] is pressed

- Press [Change Colour Setting].
- Press [Black Portion], and then select the colour to be replaced by black.
 - Ø Note
 - When selecting a colour from the user colours, press [User Colour].
- Press [Non-black Portion], and then select the colour to replace the black colour of the original.




4 Press [OK] twice.

Convert Colours


Copies by changing the colour in the original to a different colour.

Note

- ☐ It is possible to specify up to 4 colours.
- ☐ The width of the colour to be converted can be adjusted in 5 levels. If the colour width is set to "Wider" and red has been specified, colours which are close to magenta or orange, will also be converted. The colour width can be adjusted in the "User Tools". See p.125 "Colour Sensitivity"
- 1 Press the [Full Colour] key.
- Press [Edit/Colour Creation].



- Press [Colour Creation].
- 4 Press [Convert Colour].
- Select any one item from [Conversion 1] to [Conversion 4].



6 Select the colour to be converted.

- Select the new colour to be converted.
 - Note
 - ☐ You can adjust the density of each colour in 4 levels.
 - ☐ When you want to change the converted colour, press from [Conversion 1] to [Conversion 4] and make the selection again.
 - ☐ When changing between more than two colours, repeat steps **5** to **7**.

Selecting from [User Colour]


- 1 Press [User Colour].
- 2 Select from the registered colours, then press [OK].
- After selecting all the colours to be converted, press [OK].
- 9 Press [OK] 3 times.
- Place the originals, and then press the [Start] key.

Erase Colour

You can erase a certain colour in the image of the original.

𝒯 Note

- ☐ It is possible to select up to 4 col-
- ☐ The width of the colour to be deleted can be adjusted in 5 levels. If the colour width is set to "Wider" and red has been specified, colours which are close to magenta or orange, will also be deleted. The colour width can be adjusted in the "User Tools". See p.125 "Colour Sensitivity"
- 1 Press [Edit/Colour Creation].



- 2 Press [Colour Creation].
- Press [Erase Colour].
- 4 Select the colour to be erased.


Ø Note

- You can cancel the selection by pressing the selected (highlighted) key.
- ☐ You can erase 4 colours at once.
- Press [OK] after selecting all the colours to be deleted.
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Colour Background

Copies by adding a colour in the whole page.

- Since the Colour Background function overprints the entire original, the colour of the image may change.
- 1 Press [Edit/Colour Creation].



- 2 Press [Colour Creation].
- 3 Press [Colour Background].
- Select the background colour, then press [OK].

- ☐ You can adjust the density of each colour in 4 levels.
- ☐ You can cancel the selection by pressing the selected (highlighted) key.

Selecting from the [User Colour]

- Press [User Colour].
- 2 Select a registered colour, and then press [OK].
- **5** Press [OK] twice.
- 6 Place the originals, and then press the [Start] key.

Copier Functions

Adjusting Copy Image Density

There are three types of adjustment available:

♦ Auto Image Density

The machine automatically adjusts image density.

Manual image density

You can adjust the general density of the original in nine increments.

Combined auto and manual image density

Use when copying originals with dirty backgrounds (such as newspapers). You can adjust foreground density while leaving the background unchanged.

Auto image density

1 Make sure [Auto Image Density] is selected.




Manual image density

- Press [Auto Image Density] to cancel it.
- 2 Press [Lighter] or [Darker] to adjust image density.



Combined auto and manual image density

- 1 Make sure [Auto Image Density] is selected.
- Press [Lighter] or [Darker] to adjust image density.



Selecting the Original Type

Select one of the following six types to match originals:

Text

When originals contain only text (no pictures).

Text/Photo

When originals contain photographs or pictures alongside the text.

Photo

When you need to reproduce delicate tones of photographs and pictures.

Note

- ☐ If you select "Text/Photo" or "Photo" as the original type, select the photo type from among the three options below:
 - Glossy Photo
 Use when copying developed photographs.
 - Printed Photo
 Use when copying photographs or pictures that are printed on paper (e.g. magazines).
 - Copied Photo
 Use when copying copies or originals generated by printers.

Generation Copy

When originals are copies (generation copies), the copy image can be reproduced sharply and clearly.

Pale


When you need to reproduce originals that have lighter lines in pencil, or faintly copied slips. Faint lines are copied with greater clarity.

Map

You can configure the machine to scan Map originals. If "Original Type Display" has been set to "Display" (from Copier/Document Server Features on the User Tools menu), select "Map" from the "Others" menu. If "Original Type Display" has been set to "Hide", select "Map" from the "Original Type" menu.

p.112 "Original Type Display" p.112 "Original Photo Type Priority"

1 Press the appropriate key to select the original type.



If the original type keys are not displayed

- Press [Original Type].
- 2 Select the original type, and then press [OK].

Selecting Copy Paper

There are two ways to select copy paper:

Auto Paper Select

The machine selects a suitable size of copy paper automatically based on original size and reproduction ratio.

Manual Paper Select

Choose the paper you want to copy onto from a paper tray, bypass tray, or Large Capacity Tray (LCT).

p.12 "Sizes difficult to detect" p.112 "Paper Display"

☐ See the following table for copy paper sizes and orientations that can be used with Auto Paper Select (when copying at a ratio of 100%).

Metric version

| Where original is placed | Paper size and orientation |
|--------------------------|--|
| Exposure glass | A3□, B4 JIS□, A4□□, B5 JIS□□ |
| ADF | A3D, B4 JISD, A4DD, B5 JISDD, A5D, 11"× 17"D, 8 ¹ / ₂ "×11"DD |


Inch version

| Where original is placed | Paper size and orientation |
|--------------------------|---|
| Exposure glass | $11" \times 17" \square$, $8^{1}/_{2}" \times 14" \square$, $8^{1}/_{2}" \times 11" \square$ |
| ADF | A3\$\bigcup\$, A4\$\bigcup\$\bigcup\$, 11" \times 17"\$\bigcup\$, 8\bigcup\$_2" \times 14"\$\bigcup\$, 8\bigcup\$_1/2" \times 14"\$\bigcup\$_1. |

- □ Only the paper trays set to [No display] or [Recycled paper] in Paper Type and also set to [Yes] in Apply Auto Paper Select can be selected for the Auto Paper Select function. See "Paper Type: Tray 1–4" in "Tray Paper Settings", General Settings Guide.
- ☐ Auto Paper Select cannot be used if all the paper trays are set to other than [No display] or [Recycled paper].

Auto Paper Select

1 Make sure [Auto Paper Select] is selected.




☐ Trays with a key mark are not automatically selected. See "Paper Type" in "Tray Paper Settings", *General Settings Guide*.

Manual Paper Select

1 Select the paper tray, bypass tray or LCT.

The selected paper tray is highlighted.




p.22 "Copying from the Bypass Tray"

If the paper type keys are not displayed

- 1 Press [Auto Paper Select].
- 2 Select the paper type.

Rotated copy

If the orientation of the original (\square or \square) is different to that of the paper you are copying onto, this function rotates the original image by 90°, fitting it onto the copy paper. This function works when [Auto Paper Select] or [Auto Reduce/Enlarge] is selected. See p.35 "Auto Paper Select", p.40 "Auto Reduce/Enlarge".



Note


- ☐ The default setting for Auto Tray Switching is [With Image Rotation]. You cannot use the Rotated Copy function if this setting is changed to [Without Image Rotation] or [Off]. See p.113 "Auto Tray Switching".
- \square You cannot use the Rotated Copy function when enlarging onto A3, B4 JIS or $11" \times 17"$, $8^1/_2" \times 14"$ size paper. To do this, place the original in the \square orientation.

| | Origina orienta | nl size and tion | | Copy p | aper size and tion |
|-----------------------|-------------------------|---------------------|---------------------|-----------------|-----------------------|
| You cannot rotate: | A4, B5 JIS, or A5 | GCROTA1E | When enlarging to → | B4 JIS or A3 | GCROTAZE |
| However, you can use: | A4, B5 JIS, or A5 | R | When enlarging to → | B4 JIS or A3 | R |

- □ When using the 2 tray finisher, you cannot use the Rotated Copy function when [Left 2], [Top 2] or [Punch] is selected for stapling. See p.47 "Staple", p.51 "Punch".
- ☐ When using the booklet finisher, you cannot use the Rotated Copy function when [Left 2], [Top 2] or [Saddle Stitch] is selected for stapling.


Preset Reduce/Enlarge

You can select a preset ratio for copying.



Base Point


The base point of Reduce/Enlarge differs depending on how the original was scanned. When the original is placed on the exposure glass, the upper left corner is the base point. When placed in the ADF, the bottom left corner is the base point.



- 1. Base point when placed on the exposure glass.
- 2. Base point when placed in the ADF.

Related default settings: p.116 "Shortcut R/E" p.117 "R/E Priority"

1 Press [Reduce/Enlarge].




- ☐ To select a preset ratio on the initial display, press the shortcut reduce/enlarge key, and then proceed to step ♣.
- 2 Press [Enlarge] or [Reduce].
- 3 Select a ratio, and then press [OK].
- Place originals, and then press the [Start] key.

Create margin function

Use Create Margin to reduce the image to 93% of original size using the centre as reference. You can assign this function to a shortcut key on the initial display. By combining it with the Reduce/Enlarge function, you can also provide the Reduce/Enlarge copy with a margin.


Related default settings: p.114 "Copy Function Key: F1-F5" p.117 "Ratio for Create Margin" ① Press [Create Margin] on the initial display.




② If you do not want to combine it with the Reduce/Enlarge function, place originals, and then press the [Start] key.

Zoom

You can change the reproduction ratio in increments of 1%.



- ☐ You can select a preset ratio close to the ratio using [Reduce] or [Enlarge], and then adjust it further, using [♣] or [—].
- 1 Press [Reduce/Enlarge].



2 Enter the ratio.

To select the ratio using [+] and [-]

- Select a preset ratio close to the ratio using [Reduce] or [Enlarge].
- Adjust the ratio further, using [+] or [−].


 - □ Pressing [+] or [-] changes the ratio in increments of 1%. Pressing and holding down [+] or [-] changes it in increments of 10%.
 - ☐ If you have incorrectly entered the ratio, readjust it using [♣] or [—].

To enter the ratio using the number keys

- 1 Press [Mag. Ratio].
- 2 Enter the ratio using the number keys.
- **3** Press [#].
- 4 Press [OK].
- Place the originals, and then press the [Start] key.

Auto Reduce/Enlarge

The machine can choose an appropriate reproduction ratio based on the paper and original sizes you select.



Note

- ☐ You cannot use the bypass tray with this function.
- When using Auto Reduce/Enlarge, see the following table for original sizes and orientations you can use:

Metric version

| Where original is placed | Original size and orientation |
|--------------------------|---|
| Exposure glass | A3□, B4 JIS□, A4 □□, B5 JIS□□ |
| ADF | A3□, B4 JIS□, A4 □□, B5 JIS □□, A5 □□, B6 JIS □□, 11"×17"□, 8¹/2"×11"□□ |

Inch version


| Where original is placed | Original size and orientation |
|--------------------------|--|
| Exposure glass | 11"×17"□,8 ¹ / ₂ "× 14"□,8 ¹ / ₂ "×11 □□ |
| ADF | $\begin{array}{c} \text{A3D, A4D} \ \square \ , 11" \\ \times 17" \ \square \ , 8^1/_2" \times 14" \\ \square \ , 8^1/_2" \times 11" \ \square \ \square \ , \\ 5^1/_2" \times 8^1/_2" \ \square \ \square \ , \\ 10" \times 14" \ \square \ , 7^1/_4" \times \\ 10^1/_2" \ \square \ \square \end{array}$ |

☐ You cannot use the Rotated Copy function when enlarging to B4 JIS, A3 or 8¹/₂" × 14", 11" × 17". When enlarging to B4 JIS, A3 or 8¹/₂" × 14", 11" × 17" size copy paper, place the original in the ☐ orientation.

p.12 "Sizes difficult to detect"

You can place originals of different sizes in the ADF at the same time. See p.17 "Placing originals of mixed sizes".


1 Press [Auto Reduce/Enlarge].




- **2** Select the paper tray.
- Place the originals, and then press the [Start] key.

Size Magnification

You can calculate an enlargement or reduction ratio based on the lengths of the original and copy.



- Note
- ☐ Measure and specify the lengths of the original and copy by comparing "A" with "a".
- 1 Press [Reduce/Enlarge].



- 2 Press [Specifd. Ratio].
- Make sure [Size Magnificatn] is highlighted.
- 4 Enter the length of the original using the number keys, and then press [#].

 - ☐ You can enter sizes within the following ranges:


| Metric | 1–999 mm |
|---------|----------------------|
| version | (increments of 1 mm) |
| Inch | 0.1"–99.9" |
| version | (increments of 0.1") |

Enter the length of the copy using the number keys, and then press [#].


- Note
- ☐ To change the length after pressing [#], select [Original] or [Copy], and then enter the length.
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Directional Magnification (%)

Copies can be reduced or enlarged at different reproduction ratios, horizontally and vertically.



- a: Horizontal ratio
- b: Vertical ratio
- Note
- □ You can also select a preset ratio close to the ratio using [Reduce] or [Enlarge], and then adjust it further, using [+] or [-].
- 1 Press [Reduce/Enlarge].



- 2 Press [Specifd. Ratio].
- Press [Direct. Mag.%].

To enter the ratio using the number keys

- 1 Press [Horizontal].
- Enter the ratio using the number keys, and then press [#].
- 3 Press [Vertical].
- Enter the ratio using the number keys, and then press [#].
- 6 Press [OK].

To specify a ratio using [+] and [-]


- **●** Press [With **+-**].
- 2 Press [Horizontal].
- **3** Adjust the ratio using [**+**] or [**−**].

𝒜 Note

- □ Pressing [+] or [-] changes the ratio in increments of 1%.
 Pressing and holding down [+] or [-] changes it in increments of 10%.
- ☐ If you have incorrectly entered the ratio, readjust it using [♣] or [—].
- 4 Press [Vertical].
- 6 Adjust the ratio using [+] or [−].
- 6 Press [OK].
- 4 Press [OK].
- Place the originals, and then press the [Start] key.

Directional Size Magnification (mm)

A suitable reproduction ratio is automatically selected when you enter the horizontal and vertical lengths of the original and copy image you require.



- 1. Horizontal original size
- 2. Vertical original size
- 3. Horizontal copy size
- 4. Vertical copy size

Preparation


Specify the vertical and horizontal size of the original and that of the copy, as shown.

Note

☐ You can enter sizes within the following ranges:

| Metric version | Vertical: 1–999 mm (increments of 1 mm) Horizontal: 1–999 mm (increments of 1 mm) |
|-------------------|--|
| Inch version | 0.1"–99.9" (increments of 0.1") |

1 Press [Reduce/Enlarge].



- 2 Press [Specifd. Ratio].
- Press [Dir. Size Mag mm].
- Enter the horizontal size of the original using the number keys, and then press [#].
- Enter the horizontal size of the copy using the number keys, and then press [#].
- 6 Enter the vertical size of the original using the number keys, and then press [#].
- Tenter the vertical size of the copy using the number keys, and then press [#].

𝒯 Note

- ☐ To change the length, press the key you want to change, and then enter the new value.
- 8 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Sort

The machine can scan originals into memory and automatically sort copies.

Related default settings:

p.124 "Select Stack Function"


p.124 "Memory Full Auto Scan Restart"

p.124 "Rotate Sort: Auto Paper Continue"

p.113 "Auto Tray Switching"


Sort

Copies are assembled as sequentially-ordered sets.



Rotate Sort

Every other copy set is rotated by $90^{\circ}\square\square$ and delivered to the copy tray.




Note


- ☐ To use the Rotate Sort function, two paper trays with paper of the same size and type, but different orientation (☐☐), are required. See "Paper Type: Tray1-4", General Settings Guide.
- ☐ You cannot use the bypass tray with this function.

Shift Sort


When a finisher is installed:
 Each time the copies of one set or a job are delivered, the next copy is shifted to separate each set or job.




- Note
- ☐ You cannot use the bypass tray with this function.
- 1 Press [Sort] or [Rotate Sort].
 - When a finisher is not installed



When the 2 tray finisher is installed



When the booklet finisher is installed



- ☐ When the optional finisher is installed, use the User Tools to display [Rotate Sort]. See p.124 "Select Stack Function".
- 2 Enter the number of copy sets using the number keys.
 - Limitation
 - ☐ The maximum number of sets is 999.
 - Note
 - ☐ To confirm the type of finishing, press the **[Sample Copy]** key. See p.45 "Sample copy".
- **3** Place the originals.

 - ☐ When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top.
 - When placing originals on the exposure glass or in the ADF using the Batch function, press the [#] key after all the originals have been scanned.
- 4 Press the [Start] key.

Sample copy

You can use this function to check copy settings before making a long copy run.

- Note
- ☐ This function can be used only when the Sort function is turned on.
- Select Sort and any other necessary functions, and then place the originals.
- **2** Press the [Sample Copy] key.



One copy set is delivered as a sample.

If the sample is acceptable, press [Print].

The specified number of copies is made, minus one for the proof copy.

- **𝒯** Note
- ☐ If you press [Suspend] after checking the results, return to step ① to adjust the copy settings as necessary. You can change the settings for Staple, Duplex, Copy Orientation, Stamp, Margin Adjust., and Cover/Slip Sheet. However, depending on the combination of functions, you may not be able to change certain settings.

Changing the number of sets

You can change the number of copy sets during copying.

- Note
- ☐ This function can only be used when the Sort function is turned on.
- While "Copying" is displayed, press the [Clear/Stop] key.
- 2 Press [Change Quantity].



- Enter the number of copy sets using the number keys, and then press the [#] key.

 - ☐ The number of sets you can enter differs depending on when the [Clear/Stop] key is pressed.
- 4 Press [Continue].


Copying starts again.

Stack


Copies can be assembled with each page shifted.

When a finisher is installed

This function groups together copies of each page in a multi-page original. Every other page stack is shifted for ease of separation.



- **𝚱** Note
- ☐ You cannot use the bypass tray with this function.
- 1 Press [Stack].




2 Enter the number of copies using the number keys.

- Place the originals, and then press the [Start] key.
 - Note
 - ☐ When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top.
 - When placing originals on the exposure glass or in the ADF using the Batch function, press the [#] key after all the originals have been scanned.

Staple

Individual copy sets can be stapled.



Note

 \square You cannot use the bypass tray with this function.

p.125 "Select Stapling Position"

Stapling position and original setting

Place all the originals in an orientation in which they can be read. They will be automatically rotated for copying. When copy paper is identical in size and orientation to the original, staple positions are as follows:

2 tray finisher

| | | Origin | al location | | Stapling | |
|----|-----------|----------|----------------|-----|----------------|--|
| | | | Exposure glass | ADF | position *1 | |
| RE | Top | D | | R | R | |
| | Ţ | - | | R | [®] R | |
| Ŕĸ | Top Slant | Ū | | R | R | |
| | Top | ₽ | 19 | R | © R | |

| | | Original location | | | Stapling |
|-----|--------|-------------------|----------------|-------------|----------------|
| | | | Exposure glass | ADF | position *1 |
| RR | Bottom | D | | R | R |
| | Bott | D | | R | B |
| RE | | D | | R | *2 R |
| | Left 2 | D | | R | ₽R |
| RR | Top 2 | D | | R | ⊕ ⊕ R |
| loT | | Paj | R | *2 R | |


Booklet finisher

| | | Original location | | | Stapling |
|----|---------------|-------------------|----------------|-----|------------------|
| | | | Exposure glass | ADF | position *1 |
| RR | Top | D | | R | R |
| | L | □ | 9 | R | [©] R |
| RR | mo: | D | <u>a</u> | R | R |
| | Bottom | | R. | R | _© R |
| RE | Left 2 | D | A | R | *2 • R |
| | | ₽ | | R | ₽ R |
| Ŕĸ | Top 2 | D | A S | R | e e |
| | | □ | PAT | R | *2 R |
| :R | Saddle Stitch | D | | P | 3 |


 $^{^{*1}}$ This table shows the stapling positions, not the orientation of delivery. *2 Not available for A3, B4 JIS or 11" \times 17", $8^1/_2$ " \times 14" size paper.

1 Select one of the stapling positions.

2 tray finisher



Booklet finisher



Note

□ When you select the stapling position, the Sort function is automatically selected.

p.47 "Stapling position and original setting" p.132 "Staple"

- **2** Enter the number of copy sets using the number keys.
- Place the originals, and then press the [Start] key.


Note

- ☐ When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top.
- □ When placing originals on the exposure glass or in the ADF using the Batch function, press the [#] key after all the originals have been scanned.


Punch

You can make punch holes in copies.


❖ 2 holes



3 holes



4 holes



Note

- $\hfill \square$ 3 holes is only available with the 2 tray finisher.
- $\hfill \square$ You cannot use the bypass tray with this function.
- ☐ The relationship between the orientation in which you place the original and the punch hole positions is as follows:

Punch hole positions

❖ 2 tray finisher

| | | | Original lo | Punch hole positions | |
|----------|---------|----|----------------|----------------------|------------|
| | | | Exposure glass | ADF | *1 |
| | 2 holes | Ū | R | R | åR |
| | | D | A | R | ° R |
| Standard | 3 holes | D | g. | R | :R |
| Stan | | D. | R | R | : R |
| | 4 holes | D | 9 | R | :R |
| | | ┏ | 9 | R | : R |


| | | | Original lo | cation | Punch hole positions |
|----------|---------|---|----------------|----------|----------------------|
| | | | Exposure glass | ADF | *1 |
| | 2 holes | D | | <u>«</u> | Ř |
| | | D | Œ | <u>«</u> | Ř |
| 90° Turn | 3 holes | D | | <u>«</u> | Ř |
| 06، ا | | ₽ | | <u>a</u> | Ř |
| | 4 holes | Ū | | <u>«</u> | Ř |
| | | ₽ | | <u>«</u> | R |

Booklet finisher

| | | | Original lo | Punch hole positions | |
|----------|---------|----|----------------|----------------------|------------|
| | | | Exposure glass | ADF | *1 |
| | 2 holes | D | R | R | åR |
| Standard | | D | A | R | ₿R |
| Stan | 4 holes | D | 8 | R | ₿R |
| | | D' | A | R | ₿ R |
| | 2 holes | D | Œ | <u>«</u> | Ř |
| mı | | D. | Œ | <u>«</u> | °° R |
| 90° Turn | 4 holes | D | <u> </u> | <u>«</u> | °°°° R |
| | | D | Œ | <u>«</u> | R |

^{*1} This table shows the punch hole positions, not the orientation of delivery.

1 Select one of the punch hole positions.




- **2** Enter the number of copy sets with the number keys.
- Place the originals, and then press the [Start] key.

Duplex

There are three types of duplex copies:


♦ 1 Sided→2 Sided

Copies 2 one-sided pages onto a two-sided page.




♦ 2 Sided→2 Sided

Copies 1 two-sided page onto a two-sided page.




♦ 2 Sided→1 Sided

Copies each side of a two-sided original onto two separate pages.



Original orientation and completed copies

Copy images differ according to the orientation in which you place originals (vertical \square or horizontal \square).



*1 This table shows the orientation of images on the front and back of copies, not the orientation of delivered copies.

Note


- ☐ You cannot use the bypass tray with this function.
- ☐ The maximum paper weight that can be used with duplex copying is $60-105 \text{ g/m}^2$, 16-28 lb.

p.69 "Margin Adjustment" Related default settings: p.117 "Front Margin: Left/Right" p.117 "Back Margin: Left/Right"

p.117 "Front Margin: Top/Bottom"


p.117 "Back Margin: Top/Bottom"

1 Press [Dup./Combine/Series].



Note

- ☐ You can also select "1 Sided to 2 Sided" or "2 Sided to 2 Sided" directly, by pressing the Copy Function Key. If you do this, proceed to step 4.
- 2 Select [1 Sided] or [2 Sided] for Original, and then select [1 Sided] or [2 Sided] for Copy.



Note

- ☐ To change the copy orientation, press [Orientation]. See p.56 "Originals and copy orientation".
- Press [OK].
- Place the originals, and then press the [Start] key.


Note

□ When placing originals on the exposure glass, start with the first page to be copied. When placing originals in the ADF, set the first page on top. ☐ When placing originals on the exposure glass or in the ADF using the Batch function, press the 【#】 key after all the originals have been scanned.


Originals and copy orientation

You can select the orientation.

• Top to Top




Top to Bottom



Duplex

Note

- ☐ You can change the default orientation with User Tools. See p.113 "Copy Orientation in Duplex Mode" and p.113 "Original Orientation in Duplex Mode".
- 1 Press [Dup./Combine/Series].
- Press [Orientation], select the orientation (Original/Copy), and then press [OK].




- Press [OK].
- Place originals, and then press the [Start] key.

1 Sided Combine


Combine several pages onto one side of a sheet.


◆ 1 Sided 2 Pages → Combine 1 Side Copies 2 one-sided originals onto one side of a sheet.



- ◆ 1 Sided 4 Pages → Combine 1 Side Copies 4 one-sided originals onto one side of a sheet.
- ◆ 1 Sided 8 Pages → Combine 1 Side Copies 8 one-sided originals onto one side of a sheet.
- ◆ 2 Sided 1 Page → Combine 1 Side Copies 1 two-sided original onto one side of a sheet.
- ◆ 2 Sided 2 Pages → Combine 1 Side Copies 2 two-sided originals onto one side of a sheet.
- ◆ 2 Sided 4 Pages → Combine 1 Side Copies 4 two-sided originals onto one side of a sheet.
- ◆ 2 Sided 8 Pages → Combine 1 Side Copies 8 two-sided originals onto one side of a sheet.

- Orientation of the original and combine image position
 - Open to left ☐ originals






- Placing originals (originals placed in the ADF)
 - Originals read from left to right



Combine5

Originals read from top to bottom



Combine



☐ You cannot use the bypass tray with this function.


Related default settings:

p.118 "Erase Original Shadow in Combine"

p.119 "Copy Order in Combine"


p.120 "Separation Line in Combine"

1 Press [Dup./Combine/Series].



𝚱 Note

- ☐ You can select "1 Sided 2 Pages → Combine 1 Side" or "1 Sided 4 Pages → Combine 1 Side" by using Copy Function key. In this case, proceed to step **[6]**.
- Press [1 Sided] or [2 Sided] for Original, and then press [Combine 1 Side] for Copy.



p.56 "Originals and copy orientation"


- Select the number of originals to combine, and then press [OK].
- 4 Select the paper size.

- Press [OK].
- Place the originals, and then press the [Start] key.


2 Sided Combine

Combines various pages of originals onto a two-sided sheet.

♦ 1 Sided 4 Pages → Combine 2 Side Copies 4 one-sided originals onto a sheet, two pages per side.




◆ 1 Sided 8 Pages → Combine 2 Side Copies 8 one-sided originals onto a sheet, four pages per side.




- 1. Front
- 2. Back


◆ 1 Sided 16 Pages → Combine 2 Side Copies 16 one-sided originals onto a sheet, eight pages per side.




- 1. Front
- 2. Back
- ◆ 2 Sided 4 Pages → Combine 2 Side Copies 2 two-sided originals onto a sheet, two pages per side.



◆ 2 Sided 8 Pages → Combine 2 Side Copies 4 two-sided originals onto a sheet, four pages per side.



◆ 2 Sided 16 Pages → Combine 2 Side Copies 8 two-sided originals onto a sheet, eight pages per side.



☐ You cannot use the bypass tray with this function.

Related default settings:


p.57 "Orientation of the original and combine image position"

p.118 "Erase Original Shadow in Combine"


p.119 "Copy Order in Combine"

p.120 "Separation Line in Combine"

1 Press [Dup./Combine/Series].



Press [1 Sided] or [2 Sided] for Original, and then press [Combine 2 Side] for Copy.



p.56 "Originals and copy orientation"

- Select the number of originals to combine, and then press [OK].
- 4 Select the paper size.
- 5 Press [OK].
- 6 Place the originals, and then press the [Start] key.

Series Copies


This function copies the front and back of a two-sided original separately, or two facing pages of a bound original, onto two sheets.

Limitation

☐ You cannot use the Series Copies function with the ADF.


♦ Book→1 Sided

Copies a two-page spread original onto two separate pages.




♦ Book→2 Sided

Copies a two-page spread original onto a sheet, one page per side.



♦ Front&Back→2 Sided

Copies both sides of a two-page spread original onto both sides of a sheet.



Note

☐ See the following table for original and copy paper sizes when using a 100% ratio.


Metric version

| Original | Paper for one-sided copy | Paper for two-sided copy |
|----------|--------------------------|--|
| A3□ | A4 🗸 × 2 sheets | A4 $\square \times 1$ sheet (two- sided) |
| B4 JIS□ | B5 JIS 🗸 × 2 sheets | B5 JIS □ × 1 sheet (two-sided) |
| A4D | A5 □ × 2 sheets | A5 $\square \times 1$ sheet (two-sided) |

Inch version

| Original | Paper for one-sided copy | Paper for two-side copy |
|--|--|---|
| 8 ¹ / ₂ "× 11" □ | $5^{1}/2$ " × $8^{1}/2$ " \square × 2 sheets | $5^{1}/2$ " × 11" \square × 1 sheet (two-sided) |

- ☐ You cannot use the bypass tray with Book→2 Sided or Front&Back→2 Sided.
- 1 Press [Dup./Combine/Series].



- 2 Press [Series/Book].
- 3 Press [Series].
- Select [Book→1 Sided], [Book→2 Sided], or [Front&Back→2 Sided], and then press [OK].
- Press [OK].
- Make sure [Auto Paper Select] is selected.
- Place the original on the exposure glass, and then press the [Start] key.

 - ☐ Press the [#] key after all originals have been scanned.


Copying Book Originals

Copies two or more originals in page order.


♦ 1 Sided→Magazine

Copies two or more originals into magazine page order copies (when folded and stacked).

Open to left




Open to right




◆ 2 Sided→Magazine

Copies two or more two-sided originals into magazine page order copies (when folded and stacked).

Open to left




Open to right




How to fold and unfold copies to make a magazine

Open to left



Open to right



Note

- ☐ You cannot use the bypass tray with this function.
- ☐ The machine sets the reproduction ratio automatically to fit the paper size.

Related default settings:

p.118 "Erase Original Shadow in Combine"

Select [Open to Left] or [Open to Right] with User Tools.

p.120 "Orientation: Magazine"


- Press [Dup./Combine/Series].
- Press [Series/Book].
- 4 Press [Book].
- Select [1 Sided→Magazine], or [2 Sided→Magazine], and then press [OK].
- 6 Press [OK].
- **7** Select the paper.
- Place the originals, and then press the [Start] key.

Note

☐ When placing originals on the exposure glass or in the ADF using the Batch function, press the 【#】 key after all the originals have been scanned.

Image Repeat

The original image is copied repeatedly.



There are two types of designation methods for Image Repeat.

♦ Whole Area Repeat

Repeatedly copies the entire image.

Specified Area Repeat

Repeatedly copies a specified portion of the image. Decide the base point of the area, specify the length and the width, and then specify the location of the area.


Related Initial Settings See p.119 "Image Repeat Separation Line"

Whole Area Repeat


Note

☐ The number of repeated images depends on the original size, copy paper size, and reproduction ratio. See the following table.


◆ Original: A5 □/Copy paper: A4 □ or Original: A5 □/Copy paper A4 □



♦ Original: A5 □/Copy paper: A4□ or Original: A5□/Copy paper A4□



- Select the size of the copy paper and the reproduction ratio.
- 2 Press [Edit/Colour Creation].



- Press [Edit Image].
- 4 Press [Image Repeat].
- Make sure that [Whole Area] is selected, then press [OK].
- 6 Press [OK] twice.
- Place the original, and then press the [Start] key.

Specified Area Repeat


You can use this function only when you are making a copy from the Exposure Glass.

Note

☐ The base point X1, Y1, and the length set by point X2, Y2 determines the area of an image repeatedly copied.

Limitation

☐ You cannot use the specified area repeat from ADF.



1. Set on the exposure glass

1 Specify the location of the area's base point (X1, Y1), and its length and width (X2, Y2).


𝚱 Note

- □ You can set any value in the range of X1: $0 \sim 412 \,\mathrm{mm}$ (0"~16.2"), X2: $20 \sim 432 \,\mathrm{mm}$ (0.8"~17.0"), Y1: $0 \sim 277 \,\mathrm{mm}$ (0"~10.8"), and Y2: $20 \sim 297 \,\mathrm{mm}$ (0.8"~11.6").
- 2 Select the size of the copy paper and the reproduction ratio.
- 3 Press [Edit/Colour Creation].
- 4 Press [Edit Image].
- 5 Press [Image Repeat].
- 6 Press [Specified Area].

- Enter the length of [X1] with the number keys, then press [#].
- 8 Enter the length of [Y1] with the number keys, then press [#].
- Enter the length of [X2] with the number keys, then press [#].
- Enter the length of the [Y2] by number keys, then press [#].
- 11 Press [OK] three times.
- Place the original on the exposure glass, and then press the [Start] key.

Double Copies

One original image is copied twice onto one sheet, as shown.



- ☐ You cannot use the bypass tray with this function.
- ☐ See the following table for original and copy paper sizes and orientations when using a 100% ratio:

Metric version

| Original size and orientation | Copy paper size and orientation |
|-------------------------------|---------------------------------|
| A5₽ | A4 🗸 |
| B6 JIS⊡ | B5 JIS □ |
| A4 🗸 | A3□ |
| A5 🗸 | A4D |
| B5 JIS □ | B4 JIS□ |
| B6 JIS □ | B5 JIS□ |

Inch version


| Original size and orientation | Copy paper size and orientation |
|--------------------------------------|--|
| $5^1/_2$ " × $8^1/_2$ " \square | $8^{1}/_{2}" \times 11" \Box$ |
| $5^1/_2$ " × $8^1/_2$ " \Box | 8 ¹ / ₂ "×11" □ |
| 8 ¹ / ₂ "×11"□ | 11"×17"□ |

☐ Originals with a size of A5 ☐ ☐, B6 JIS ☐ ☐, 5¹/₂" × 8¹/₂" ☐ cannot be detected properly on the exposure glass. Be sure to select the copy paper manually or place the originals in the ADF.

Related default settings:

p.119 "Double Copies Separation Line"

1 Press [Edit/Colour Creation].




- 2 Press [Edit Image].
- Press [Double copies].
- 4 Press [OK] twice.

- **5** Select the paper.
- 6 Place the originals, and then press the [Start] key.

Centring

You can make copies with the image moved to the centre.



Note

- ☐ You cannot use the bypass tray with this function.
- ☐ Original sizes and orientations for centring are listed below.


Metric version

| Original placed on: | Original size and orientation |
|---------------------|---|
| Exposure glass | A3□, B4 JIS□, A4 □□, B5 JIS □□ |
| ADF | A3D, B4 JISD, A4 DD, B5 JISDD, A5 DD, B6 JISDD, 11"×17"D, 8 ¹ / ₂ "× 11"DD |

Inch version

| Original placed on: | Original size and orientation |
|---------------------|--|
| Exposure glass | $11" \times 17" \square, 8^{1}/_{2}" \times 14" \square, 8^{1}/_{2}" \times 11" \square \square$ |
| ADF | A3 \square , A4 \square \square , 11"×17" \square , 8 ¹ / ₂ "×14" \square , 8 ¹ / ₂ "×11" \square , 5 ¹ / ₂ "×8 ¹ / ₂ " \square \square , 10"× 14" \square |


- 1 Select the paper.
- 2 Press [Edit/Colour Creation].



- Press [Edit Image].
- 4 Press [Centring].
- Press [OK] twice.
- 6 Place the originals, and then press the [Start] key.

Positive/Negative


If your original is black and white, copy images are inverted.



Note

- ☐ If your original is black and white, copy images are inverted. If your original is colour, the density, darkness and brightness of each colour will be reversed and inverted to complimentary colours.
- ☐ If the **(Single Colour)** key is selected, copy images are copied in white and specified colours.

- ☐ If [Two-colour] (normal) is selected, the white part of the original becomes black and the black part becomes white, and the coloured part is copied with the specified colour.
- ☐ If **[Red & Black]** is selected, the white part of the original becomes black, and the black part becomes white, but the red part is copied as red colour.
- 1 Press [Edit/Colour Creation].



- 2 Press [Edit Image].
- Press [Positive/Negative].
- 4 Press [OK] twice.
- **5** Select the paper.
- Place the originals, and then press the [Start] key.

Mirror

Copies by reversing the image from left to right, as reflected in a mirror.

- 1 Press [Edit/Colour Creation].
- 2 Press [Edit Image].
- Press [Mirror Image].
- 4 Press [OK] twice.
- 5 Place the originals, then press the [Start] key.


Erase

You can erase the centre and/or all four sides of the original image.

This function has three modes:


Border

Erases the original's edge margin from the copy.




Centre

Erases the original's centre margin from the copy.



Centre/Border

Erases both the original's centre and edge margins from the copy.




The erase width is set to 10 mm (0.4") as default. You can change this setting with User Tools.

p.118 "Erase Centre Width" p.118 "Erase Border Width"

Note


☐ The relationship between the original orientation and erased area is as follows:



- 1: Erased part
- 2: 2-99 mm (0.1"-3.9")

Border Erase


1 Press [Edit/Colour Creation].



- 2 Press [Erase/Margin Adj.].
- Press [Erase].
- 4 Set the erase border width.

Selecting [Same Width]


- 1 Press [Same Width].
- 2 Set the erase border width using [+] and [-].



- Note
- ☐ To change the value entered, press [♣] and [♣] to set the new value.
- 3 Press [OK].

Selecting [Diff. Width]


- 1 Press [Diff. Width].
- Press the key for the border you want to change, and then set the erase border width using [+] and [-].



- 3 Press [OK].
- Press [OK] twice.
- 6 Place the originals, and then press the [Start] key.

Centre erase


1 Press [Edit/Colour Creation].



- 2 Press [Erase/Margin Adj.].
- 3 Press [Erase].
- 4 Press [Centre].
- Set the erase centre width using [+] and [-], and then press [0K].
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Centre/border erase


1 Press [Edit/Colour Creation].



- 2 Press [Erase/Margin Adj.].
- Press [Erase].
- 4 Press [Centre/Border].
- 5 Set the centre and border to be erased.

Selecting [Same Width]


- 1 Press [Same Width].
- Press [Centre], and then set the erase centre width using [+] and [-].



- ③ Press [Border], and then set the erase border width using [+] and [-].
- 4 Press [OK].

Selecting [Diff. Width]


- 1 Press [Diff. Width].
- Press the key for the part you want to change, and then set the erase margin width using [+] and [-].



- 3 Press [OK].
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Margin Adjustment

You can make a binding margin.



Related default settings:

p.117 "Front Margin: Left/Right"

p.117 "Back Margin: Left/Right"

p.117 "Front Margin: Top/Bottom"


p.117 "Back Margin: Top/Bottom" p.118 "1 Sided→2 Sided Auto Margin: TtoT"

Note

☐ You can change the width of the binding margin as follows:

| Metric version | 0–30 mm (increments of 1 mm) |
|-------------------|------------------------------|
| Inch version | 0"-1.2" (increments of 0.1") |

Press [Edit/Colour Creation].



- 2 Press [Erase/Margin Adj.].
- 3 Press [Margin Adjustment].
- A Set a binding margin for the front pages. Press [←] and [→] when setting the left and right margins, and [↓] and [↑] when setting the top and bottom margins.


- □ To change the value entered, press $[\leftarrow]$, $[\rightarrow]$, $[\downarrow]$, $[\uparrow]$ to set it.
- ☐ If you do not need to specify margins for back side pages, proceed to step **G**.
- 5 Set a binding margin for back side pages. Press [←] and [→] when setting the left and right margins, and [↓] and [↑] when setting the top and bottom margins.

 Margins on the back side of the page are possible only when [2 Sided] or [Combine 2 Side] is selected.

- 6 Press [OK] 3 times.
- Place the originals, and then press the [Start] key.

Preset Stamp


Frequently used messages can be stored in memory and stamped on copies.




One of the following eight messages can be stamped on copies with a frame around it:

"COPY", "URGENT", "PRIORITY", "For Your Info.", "PRELIMINARY", "For Internal Use Only", "CONFIDENTIAL", "DRAFT".

Stamp position and original orientation



- Note
- ☐ You cannot use the bypass tray with this function.
- ☐ Only one message can be stamped at a time.
- \square The default stamp colour is black.
- - p.121 "Stamp Priority"
 - p.121 "Stamp Language"
 - p.121 "Stamp Position"
 - p.121 "Stamp Format"
 - p.121 "Stamp Colour"
- 1 Press [Edit/Colour Creation].




- 2 Press [Stamp].
- Press [Preset Stamp].
- 4 Select the message.
- Press [All Pages] or [1st Page only] to select the print page.
 - **∅** Note
 - ☐ You can change the colour, position, size, and density of the stamp. See p.71 "Changing the stamp colour". See p.71 "To change stamp position, size, and density".
- 6 After you have specified all necessary settings, press [OK].
- **7** Press [OK] twice.
- Place the originals, and then press the [Start] key.

Changing the stamp colour

- 1 Press [Stamp Colour].
- 2 Select the stamp colour, then press [OK].


To change stamp position, size, and density

- 1 Press [Change].
- 2 Select the position for print, size, and density, and then press [OK].



User Stamp

Prints a registered stamp onto copies.




GCSTMP0E

Preparation

You have to register a user stamp before using this function. See p.73 "To program the user stamp".

Stamp position and original orientation



GCSTMP6F

Note

- ☐ You cannot use the bypass tray with this function.
- ☐ Only one message can be stamped at a time.
- ☐ The default stamp colour is black.

₽ Reference


Related default settings:

p.122 "Stamp Position 1 - 4"


p.122 "Stamp Format 1 - 4"

p.122 "Stamp Colour: 1 - 4"

1 Press [Edit/Colour Creation].



- 2 Press [Stamp].
- Press [User Stamp].
- 4 Select the stamp number.
- Press [All Pages] or [1st Page only] to select the print page.



Note

- ☐ You can change the stamp colour and position. See p.73 "Changing the stamp colour". See p.73 "To change the stamp position".
- 6 After all settings are complete, press [OK].
- **7** Press [OK] twice.
- Place the originals, and then press the [Start] key.

Changing the stamp colour

- 1 Press [Stamp Colour].
- Select the stamp colour, then press [OK].

To change the stamp position

- 1 Press [Change].
- 2 Select the position, and then press [OK].




To program the user stamp

𝒜 Note

- ☐ The range of stamp images for readability is 10–297 mm high (0.4"–11.7") and 10–432 mm wide (0.4"–17.0"). However, if the value exceeds the maximum area (5,000 mm², 7.75 inch²), it is automatically adjusted to range.
- ☐ Up to four frequently used images can be stored in memory.
- 1 Make sure the machine's copier function is selected.
- 2 Press the [User Tools/Counter] key.



Press [Copier/Document Server Features].



- 4 Press [Stamp].
- 5 Press [User Stamp].
- 6 Press [Program/Delete Stamp].
- Press [Program], and then press the stamp number (1–4) you want to program.

Note

- ☐ Stamp numbers displayed with ❖ next to them already have settings.
- ☐ If the stamp number is already in use, the machine will ask you if you want to overwrite it. Press [Yes] or [No].
- **8** Enter the user stamp name using the letter keys on the display panel. You can register up to 10 characters.
- 9 Press [OK].

"Entering Text", General Settings Guide

Enter the horizontal size of the stamp using the number keys, and then press [#].

- Press [Vertical], and then enter the vertical size of the stamp using the number keys, and then press [#].
- Place the original for user stamp on the exposure glass, and then press [Start Scanning].

The original is scanned, and the stamp is registered.

- ☐ Originals cannot be scanned from the ADF when programming the user stamp.
- Press [Exit].
- 14 Press [Exit].

The Copier/Document Server Features main menu is displayed.


Press [Exit].

Exits settings and gets ready to copy.


To delete the user stamp

#Important

- ☐ You cannot restore a deleted stamp.
- 1 Make sure the machine's copier function is selected.
- 2 Press the [User Tools/Counter] key.



Press [Copier/Document Server Features].



- 4 Press [Stamp].
- 5 Press [User Stamp].
- 6 Press [Program/Delete Stamp].
- Press [Delete], and then press the stamp number you want to delete.
- Select [Delete], and then press [Exit].
- 9 Press [Exit].


The Copier/Document Server Features main menu is displayed.

Press [Exit].

Exits settings and gets ready to copy.

Date Stamp


You can use this function to print dates onto copies.



You can select from the following date formats:

- MM/DD/YYYY
- MM.DD.YYYY
- DD/MM/YYYY
- DD.MM.YYYY
- YYYY.MM.DD

Stamp position and original orientation




Note

- ☐ You cannot use the bypass tray with this function.
- $\hfill\Box$ The default stamp colour is black.


Related default settings:

- p.122 "Format"
- p.122 "Font"
- p.122 "Stamp Position"
- p.123 "Stamp Setting"
- p.123 "Size"
- p.123 "Superimpose"
- p.123 "Stamp Colour"
- "Timer Settings", General Settings Guide

1 Press [Edit/Colour Creation].



- 2 Press [Stamp].
- Press [Date Stamp].
- Press [All Pages] or [1st Page only] to select the print page.



Note


- ☐ You can change the colour, format and position of the date stamp. See p.76 "Changing the stamp colour", p.76 "To change the date format".
- After all settings are complete, press [OK].
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Changing the stamp colour

- 1 Press [Stamp Colour].
- 2 Select the stamp colour, then press [OK].

To change the date format


1 Press [Change Format].



2 Select the date format, and then press [OK].


To change the stamp position

- 1 Press [Change].
- 2 Select the date stamp position, and then press [OK].



Page Numbering


You can use this function to print page numbers onto copies.



There are six types of Page Numbering ("n" is the total number of pages in original):

- P1, P2,...Pn
- 1/n, 2/n,...n/n
- -1-, -2-,...-n-
- P.1, P.2,...P.n
- 1, 2...n
- 1-1, 1-2,..1-n

Stamp position and orientation of originals



Note

- ☐ You cannot use the bypass tray with this function.
- $\hfill \square$ The default stamp colour is black.

Related default settings:

p.123 "Stamp Format"

p.123 "Font"

p.123 "Size"

p.123 "Duplex Back Page Stamping Position"


p.123 "Page Numbering in Combine"

p.123 "Stamp Position"


p.123 "Superimpose"

p.123 "Stamp Colour"

1 Press [Edit/Colour Creation].



- 2 Press [Stamp].
- Press [Page Numbering].
- 4 Select the format.



𝒯 Note


- ☐ You can specify the Stamp Colour, position, pages to be stamped, and numbering. See "Changing the stamp colour", "To change the stamp position", "Specifying the first printing page and start number".
- After all settings are complete, press [OK].
- 6 Press [OK] twice.
- Place the originals, and then press the [Start] key.

Changing the stamp colour

- 1 Press [Stamp Colour].
- 2 Select the stamp colour, then press [OK].

To change the stamp position

- 1 Press [Change].
- 2 Select the position, and then press [OK].




Specifying the first printing page and start number

If you selected (P1, P2..., -1-,-2-..., P.1, P.2..., 1, 2...,)


Note

- ☐ The following explanation uses P1, P2... as an example. The steps are the same for other selections.
- 1 Press [Change] on the right side.


Press [First Printing Page], then enter the original page number from which to start printing using the number keys, and then press the [#] key.



- ☐ To change the number entered, press [Clear] or the [Clear/Stop] key, and then enter a new number.
- Press [Numbering from/to], enter the number of the page from which to start numbering using the number keys, and then press the [#] key.
 - Note
 - ☐ The example below shows the first printing page as "2" and the start number as "3".



Press [Last Number], enter the number of the page to stop numbering using the number keys, and then press the [#] key.



- Note
- ☐ If you want to number all pages to the end, press **[to the end]**.
- When page designation is complete, press [OK].
- 6 Press [OK] 3 times.

If you selected (1/5, 2/5...)

- 1 Press [Change] on the right hand side of the display.
- Press [First Printing Page], then enter the original page number from which to start printing using the number keys, and then press the [#] key.



𝒯 Note

- ☐ You can enter between 1 and 9999 for the original page number from which to start printing.
- ☐ To change the number entered, press [Clear] or the [Clear/Stop] key, and then enter a new number.
- Press [Numbering from/to], then enter the number of page from which to start numbering using the number keys, and then press the [#] key.
- 4 Press [Last Number], then enter the number of page at which to stop numbering using the number keys, and then press the [#] key.

Proceed to step **5** when not changing.

- ☐ To print on the last page, press **[to the end]**.
- ☐ The last number is the last page number printed. For example, if [Total Pages] is ten, if you want to print seven pages up to page 7, enter [7] as the [Last Number].
- ☐ Normally, you do not need to enter this number.
- Press [Total Pages], enter the total number of original pages using the number keys, and then press the [#] key.
- 6 When page designation is complete, press [OK].


Note

☐ To change the settings after pressing [OK], press [Change], and then enter the numbers again.

Press [OK] 3 times.

If you selected (1-1, 1-2,...)

- Press [Change] on the right hand side.
- Press [First Printing Page], and then enter the original page number from which to start printing using number keys, and then press the [#] key.



Note

- ☐ To change the number entered, press [Clear] or the [Clear/Stop] key, and then enter a new number.
- Press [First Chapter No.], enter the chapter number from which to start numbering using the number keys, and then press the [#] key.

Note

- ☐ You can enter between 1 and 9999 for the chapter number from which to start numbering.
- Press [Numbering from/to], and then enter the page number from which to start numbering using the number keys, and then press the [#] key.
- When page designation is complete, press [OK].
- 6 Press [OK] 3 times.

Covers

You can use this function to create cover sheets by adding additional pages of different paper, or copying existing pages onto different paper.

Preparation

Before selecting this function, set the tray for front cover sheets. See "Cover Sheet Tray" in "Tray Paper Settings", General Settings Guide.


Note

- ☐ The cover sheet should be the same size and orientation as the copy paper.
- ☐ You cannot use the bypass tray with this function.
- □ When selecting Copy, select whether the front and back covers are copied one-sided or two-sided. See "Cover Sheet Tray" in "Tray Paper Settings", General Settings Guide.


Front cover

The first page of originals is copied onto a specified cover sheet paper, or a cover sheet is inserted before the first copy page.

• Copy




• Blank




Front/Back covers

The first and last page of original is copied onto a specified cover sheet paper.

Copy




Blank



₽ Reference

p.118 "Front Cover Copy in Combine"


Press [Cover/Slip Sheet].



- Press [Front Cover] or [Front/Back Cover].
- Select [Copy] or [Blank] for the cover sheet.
- 4 Select the paper tray containing the paper to copy the originals onto, and then press [OK].
- Place the originals in the ADF, and then press the [Start] key.

Slip Sheets

Every time the originals' page changes, a slip sheet is inserted. This function can be used to automatically insert a slip sheet between OHP transparencies, or as a stacking function. You can also copy onto slip sheets.




Preparation


Before selecting this function, set the tray for slip sheets. See "Slip Sheet Tray" in "Tray Paper Settings", General Settings Guide.

Note

- ☐ Load slip sheets in the same size and orientation as copy paper or OHP transparencies.
- When using OHP transparencies from the bypass tray
 - Copy




• Blank



Note

- ☐ Press the **(#)** key and select **[OHP Sheet]** in Special paper. See p.24 "When copying onto OHP Transparencies or Thick Paper".
- ☐ Paper will be delivered to the external tray when copying onto OHP transparencies or thick paper from the bypass tray, even if you have specified not to use the external tray as the output tray.
- 1 Press [Cover/Slip Sheet].



- 2 Press [Slip Sheet].
- Select [Copy] or [Blank], and then press [OK].
- 4 Select the paper tray containing the sheet paper to copy the originals.

When using OHP transparencies, open the bypass tray.

Place the originals, and then press the [Start] key.

Storing Data in the Document Server


The Document Server enables you to store documents in memory and print them as you want.

#Important


☐ Machine failure can result in data loss. Important data stored on the hard disk should be backed up. The manufacturer shall not be responsible for any damage that might result from loss of data.

Note

- □ Data stored in the Document Server is deleted after three days by setting default. You can specify a period after which stored data is automatically deleted. For more information about settings, see "Auto Delete File" in "Key Operator Tools", General Settings Guide.
- 1 Press [Store File].



2 Enter a user name, file name, or password if necessary.



For details about how to register the user name, file name, or password, see "To register or change a user name", and "To set or change a password", *General Settings Guide*.

- Press [OK].
- 4 Place the originals.

For more information about the types of originals that can be placed and how to place them, see p.13 "Placing Originals".

Make the scanning settings for the originals.



6 Press the [Start] key.

Originals are scanned and stored in memory.

Ø Note

- ☐ To stop scanning, press the 【Clear/Stop】 key. To resume a paused scanning job, press [Continue] in the confirmation display. To delete saved images and cancel the job, press [Stop].
- When placing an original on the exposure glass, press the [#] key after all the originals have been scanned.

- ☐ To check that the document has been stored, press the **[Document Server]** key to display the document selection screen.
- ☐ When the machine is printing a document stored using the copier function, wait until printing has finished before you store another copy document.
- ☐ To print stored documents, see "Printing Stored Documents", *General Settings Guide*.

Programs

You can store frequently used copy job settings in machine memory and recall them for future use.

- ☐ You can store up to 10 programs.
- ☐ You can select the standard mode or Program No.10 as the default mode to be set when modes are cleared or reset, or immediately after the operation switch is turned on. See p.113 "Change Initial Mode".
- ☐ Paper settings are stored based on paper size. However, if you have more than one paper tray containing same size paper, the tray prioritized with User Tools (System Settings) is selected first. See "Paper Tray Priority" in "Tray Paper Settings", General Settings Guide.
- ☐ Programs are not deleted by turning the power off or pressing the **[Clear Modes]** key. They are canceled only when you delete or overwrite them with another program.

Storing a Program

- Edit the copy settings so all functions you want to store in this program are selected.
- 2 Press the [Program] key.



Press [Register].




- Press the program number you want to store.
 - **∅** Note
 - ☐ Program numbers displayed with � next to them already have settings.
 - **₽** Reference

p.86 "Changing a stored program"

5 Enter the program name using the letter keys on the display panel.

You can enter up to 40 characters.



For details about entering characters, see "Entering Text", *General Settings Guide*.

𝒯 Note

☐ If you do not want to enter a program name, proceed to step ☐.

6 Press [OK].

When the settings are successfully stored, the program name is displayed on the right side of the registered program number. The display returns to the initial copy display for a while.

Changing a stored program

1 Check the program settings.

- Note
- ☐ To check the contents of a program, recall it. See p.86 "Recalling a Program".
- Repeat steps 1 to 4 of "Storing a Program".
- Press [Register].

Repeat steps **5** and **6** of "Storing a Program".

- Ø Note
- ☐ When overwritten, the previous program is deleted.

Deleting a Program

- 1 Press the [Program] key.
- 2 Press [Delete].



Press the number of the program you want to delete.

4 Press [Yes].

The program is deleted, and the display returns to the initial copy display.

Recalling a Program

- 1 Press the [Program] key.
- 2 Press [Recall].



Press the number of the program you want to recall.

The stored settings are displayed.

- ☐ Program numbers displayed with � next to them already have settings.
- Place the originals, and then press the [Start] key.

3. Colour Adjustment/ Program

Colour Adjustment

This function lets you alter up to three single colours by mixing them with adjacent colours in the colour circle.

₽ Reference


For types and examples of image adjustment functions, see p.iii "What You Can Do with This Machine <Colour Functions/Colour Adjustments>".

- ☐ You can adjust up to 3 colours from yellow, red, magenta, blue, cyan, or green at the same time.
- ☐ This function is only available in Full Colour mode.
- Press the [Adjust/Program Colour] key.



- 2 Press [Adjust Colour].
 - The colour circle is displayed.
- Select the colours you want to adjust.

You can select up to 3 colours.



- Adjust the colour using [←] or [→].

 - ☐ Refer to the colour circle on the control panel.
- Press [OK].


 - ☐ The indicator of the [Adjust/Program Colour] key will light up when adjusting the colour.
 - ☐ The adjusted settings will be deleted and the initial values will be reset, when Auto Clear has been performed, when the [Clear Modes] key has been pressed or when the power has been turned off.

Colour Balance

You can adjust the overall colour tone when the overall copy is reddish or bluish.

For types and examples of the image adjustment functions, see p.iii "What You Can Do with This Machine <Colour Functions/Colour Adjustments>".

Press the [Adjust/Program Colour] key.



- 2 Make sure that [Colour Balance] is selected.
- Adjust by pressing [Lighter] or [Darker].

Note

- ☐ You can also register the adjusted settings. See p.88 "Colour Balance Program".
- 4 Press [OK].

Note

- ☐ The indicator of the [Adjust/Program Colour] key will light up when adjusting the colour balance.
- ☐ The adjusted settings will be deleted and the initial values will be reset when either Auto Clear has been performed, when the 【Clear Modes】 key has been pressed or when the power has been turned off.

Colour Balance Program

You can also store the colour balance setting in memory and recall it when you want to use it.

Note

- \square You can store up to 3 programs.
- To change the registered settings, register them again. Previously registered settings will be overwritten.

Storing the adjusted colour balance

- Press the [Adjust/Program Colour] Key.
 - Reference

See p.88 "Colour Balance".

- 2 Press [Program Colour Balance].
- 3 Press [Program].
- 4 Select a number (1–3) for this setting.

The colour balance setting will be registered in the selected number.

Note

- □ If you select the program number key where the � is displayed, the previously registered settings will be overwritten. See p.89 "Changing the registered settings".
- Press [OK].

Changing the registered settings

- Press the [Adjust/Program Colour] key.
- 2 Make sure that [Colour Balance] is selected, and then press [Program Colour Balance].



3 Select the program number (1-3) whose settings you want to change.

The registered colour balance is displayed.

- 4 Change the registered settings.
- After the registered settings are changed, press [Program Colour Balance].
- Press [Program], and then select the program number to be overwritten.
- Press [Register].
 The settings are changed.
- 8 Press [OK].

Copying with the registered settings

- Press the [Adjust/Program Colour] key.
- 2 Make sure that [Colour Balance] is selected, and then press [Program Colour Balance].
- Make sure that [Recall] has been selected, and then select the program that you want to use.
- 4 Press [OK].
- Place the originals, and then press the [Start] key.
 - Note
 - ☐ The adjusted settings will be deleted and the initial values will be reset when either Auto Clear has been performed, when the 【Clear Modes】 key has been pressed or when the power has been turned off.

Deleting the registered settings

- Press the [Adjust/Program Colour] key.
- 2 Make sure that [Colour Balance] has been selected, and then press [Program Colour Balance].
- Press [Delete], and then select the program that you want to delete.
- 4 Press [Yes].
- Press [OK].

Image Adjustment

For types and examples of the image adjustment functions, see p.iii "What You Can Do with This Machine <Colour Functions/Colour Adjustments>".

You can make the following types of image adjustments.

Sharp / Soft

Adjusts the outline of an image.

Contrast

Adjusts the shades of an image.

Background Density

Adjusts the background density of an image.

Adjust U.C.R.

Adjusts the amount of black toner used in order to vividly express the black areas in an image.

❖ Text/Photo Sensitivity

Adjusts the standard level in judging the image in the text and the photo part, when using "Text/Photo".

𝒯 Note

- ☐ "Sharp / Soft", "Contrast", "Background Density" can each be adjusted. However, their adjustments can affect the level of other adjustment functions.
- ☐ When adjusting the image quality, the indicator of the 【Adjust/Program Colour】 key will light up.


- ☐ The adjusted settings will be deleted and the initial values will be reset when either Auto Clear has been performed, when the 【Clear Modes】 key has been pressed or when the power has been turned off.
- Press the [Adjust/Program Colour] key.



- 2 Press [Copy Quality].
- 3 Adjust the settings.

Adjusting the sharpness/softness


• Adjust by pressing [Soft] or [Sharp].



2 Press [OK].

Adjusting the contrast


• Adjust by pressing [Low] or [High].



2 Press [OK].

Adjusting the background density


• Adjust by pressing [Lighter] or [Darker].



- Adjust to a lighter density when copying dark textured originals, such as newspaper or recycled paper.
- □ Adjust to a darker density when darkening the colour of markers or highlighters. However, highlighter pen colours are difficult to reproduce. Depending on the colour used, they may not come out on copies, or may come out as a different colour.
- 2 Press [OK].

Adjusting the U.C.R.

• Adjust by pressing [Lighter] or [Darker].



2 Press [OK].

Adjusting the text/photo sensitivity

- Press [▼Next].
- 2 Adjust by pressing [Text] or [Photo].



- **𝒯** Note
- ☐ Adjust toward "Text" if parts of the texts are faded or are not clear. Adjust toward "Photo" if the outline of photos becomes dark.
- 3 Press [OK].

User Colour

You can register colours created by adjusting the density of yellow, magenta, cyan, and black. You can also name the colours that you register, and print out registered colours.

For types and examples of the image adjustment functions, see p.iii "What You Can Do with This Machine <Colour Functions/Colour Adjustments>".

The following show you how to create colours:

- Adjust the density of each colour using the density of a chosen basic colour.
- Directly specify the density of each colour using the number keys.

Note

- ☐ Adjust the colours to be registered such that the total density of yellow, magenta, cyan, and black is under 255%.
- ☐ When the total density of a registered colour is over 256%, it will be corrected to 255%.
- When copying with user colours, the finer shades may vary depending on the condition of the machine.
- ☐ In order to correctly reproduce originals, the values entered are corrected by the machine, and copies are made using the optimum values. Therefore, there may be slight colour differences when copying using "Text" and when using "Photo".

- ☐ Up to 15 colours can be registered.
- ☐ Sample prints of user colours can also be made on an A4 \square , $8^1/2$ " × 11" \square size page or on an A3 \square , 11" × 17" \square size page.
- Printing out a user colour sample will be counted under the full colour counter.

Adjusting Colours Based on the Selected Colour

Press the [Adjust/Program Colour] key.



2 Press [User Colour].



Select the number (1–15) you want to store the user colour in.

☐ The settings of the user colour will change when selecting the number already displayed by the colour name.

Select the colour to be used as a base from [Basic Colour].

The density of each colour for the selected colour is displayed.



Note


Press [Custom Setting] to directly specify the density of each colour with the number keys. See p.94 "Mixing Colours Manually with the Number Keys"

Selecting from user colours

- 1 Press [User Colour].
- 2 Select from the registered colours.
- **5** Specify the colour density.

Using [+] [-]

● Specify the density in percentages (%) using [+] or [-].



Using [With Number keys]

- Press [With Number keys].
- Select the colour that you want to adjust.

3 Enter the density in percentages (%) using the number keys, and then press [#].



- Note
- ☐ If you want to use [+] or [-], press [With + -].
- ☐ If you enter the wrong density, press [Clear] or the [Clear/Stop] key, and then reenter the correct density.
- ☐ Repeat steps ② and ③ to specify the density of multiple colours.

When renaming a colour

- 1 Press [Change Name].
- 2 Enter the name of the colour (up to 16 characters), and then press [OK].

"Entering Text" General Settings Guide.

- 6 Check the density and the name of the colour, and then press [OK].
- **7** Press [Exit].

Mixing Colours Manually with the Number Keys

- Press the [Adjust/Program Colour] key.
- 2 Press [User Colour].
- Select the number (1–15) that you want to store the user colour in.

𝚱 Note

- ☐ The settings of the user colour will change when selecting the number already displayed by the colour name.
- 4 Press [Custom Setting].
- Select the colour that you want to adjust.
- 6 Enter the density in percentages (%) with the number keys, and then press [#].

When renaming a colour

- 1 Press [Change Name].
- 2 Enter the name of the colour (up to 16 characters can be used), and then press [OK].

"Entering Text" General Settings Guide.

Check the names of each colour, and then press [OK].

𝒯 Note

- Repeat steps 5 to 7 if you want to specify the density of multiple colours.
- 8 Press [Exit].

Deleting User Colours

Note

- ☐ You cannot delete colours registered in the program or registered colours currently in use.
- Press the [Adjust/Program Colour] key.
- 2 Press [User Colour].
- Press [Delete].
- Select the number of the user colour you want to delete.
- Press [Delete].
- 6 Press [Exit].

Sampling the User Colours

- Press the [Adjust/Program Colour] key.
- 2 Press [User Colour].
- Make sure that the paper is of the correct size, and then press [Print Sample of User Colour].

The sample of user colours is output to the standard tray.

Note

□ The user colours will be copied on a A4 □, 8¹/2"×11" □ sheet or a A3□, 11"×17" □ sheet.

4. Troubleshooting

If Your Machine Does Not Operate As You Want

When a Message Is Displayed

The following chart contains explanations of common messages. If other messages are displayed, then follow the instructions as displayed.

∅ Note

☐ For messages not listed here, see "Troubleshooting" *General Settings Guide*.

| O | | ě č |
|--|--|--|
| Message | Causes | Solutions |
| Cannot detect original size. | An irregular original is placed. See p.12 "Sizes difficult to detect". | Place custom size originals on the exposure glass. See p.14 "Placing Originals on the Exposure Glass". |
| | | Enter the horizontal and vertical size of the custom size original. See p.14 "Placing Originals on the Exposure Glass". |
| | | Select paper manually, not with the Auto Paper Select function. |
| | | Do not use the Auto Reduce/Enlarge function. |
| | Original is not placed. | Place originals. |
| Check original orientation. | There is no copy paper in the same orientation as the originals. | Place the original in the same orientation as the copy paper. |
| Check paper size. | An irregular paper size is set. | Press the [Start] key and copying will start on the selected paper. |
| Rotate Sort is not available with this image size. | A paper size for which Rotate Sort is not available is selected. | "Sort, Rotate Sort, Stack". |
| Cannot punch paper of this size. | The Punch function cannot be used with paper size selected. | The following paper sizes are available for Punch mode: A3□, B4 JIS□, A4□□, B5 JIS□□, A5□, 11"×17"□, 8¹/2"×14" □, 8¹/2"×11" □□. Select one of these sizes. |
| It is over stapling capacity. | The number of sheets per set is over the staple capacity. | Check the stapler capacity. See p.132 "Staple". |

| Message | Causes | Solutions |
|---|--|---|
| Cannot staple paper of this size. | The Staple function cannot be used with the paper size selected. | Select a paper size that can be used with the Staple function. See p.132 "Staple". |
| Duplex is not available with this paper size. | A paper size not available when using the Duplex function has been selected. | Select a proper paper size. See p.135 "Duplex". |
| Maximum number of sets is*. | The number of copies exceeds maximum copy quantity. | You can change the maximum copy quantity. See p.113 "Max. Copy Quantity". |
| Cannot copy. Original is being scanned by another function. | The Document Server function is in use. | To cancel a job being processed, press [Exit], and then press the [Document Server] key. Next, press the [Clear/Stop] key. When the message "[Stop] key was pressed. Stop storing?" is displayed, press [Stop]. |

Ĺ

If You Cannot Make Clear Copies

| Problem | Causes | Solutions |
|--|--|--|
| Copies appear dirty. | The image density is too dark. | Adjust the image density. See p.33 "Adjusting Copy Image Density". |
| | Auto Image Density is not selected. | Select Auto Image Density. See p.33 "Adjusting Copy Image Density". |
| The reverse side of an original image is copied. | The image density is too dark. | Adjust the image density. See p.33 "Adjusting Copy Image Density". |
| | Auto Image Density is not selected. | Select Auto Image Density. See p.33 "Adjusting Copy Image Density". |
| A shadow appears on copies if you use pasted originals. | The image density is too dark. | Adjust the image density. See p.33 "Adjusting Copy Image Density". Change the orientation of the original. Put tape over pasted parts. |
| The same copy area is dirty whenever making copies. | The exposure glass or ADF is dirty. | Clean them. See "Maintaining Your Machine" General Settings Guide. |
| Copies are too light. | The image density is too light. | Adjust the image density. See p.33 "Adjusting Copy Image Density". |
| | The paper size is not suitable. | Use a recommended paper size. |
| | The toner cartridge is almost empty. | Add toner. See "Adding Toner" General Settings Guide. |
| Parts of the image are not copied. | The original is not set correctly. | Place originals correctly. See p.13 "Placing Originals". |
| | An irregular paper size is selected. | Select a proper paper size. |
| Copies are blank. | The original is not placed correctly. | When using the exposure glass, place originals face down. When using the ADF, place them face up. See p.13 "Placing Originals". |
| A moiré pattern is produced on copies. □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ | Original has a dot pattern image, or too many lines. | Position the original on the exposure glass at a slight angle. |

If You Cannot Make Copies As You Want

This section explains causes of, and remedies for, unexpected copy results.

◆ Basic

| Problem | Causes | Solutions |
|--|--|--|
| Copies are not stapled. | There are jammed staples in the stapler. | Remove jammed staples. See "Removing Jammed Staples" General Settings Guide. |
| | | ✓ Note☐ After removing jammed staples, staples might not eject the first |
| | | few times you try to use the sta- pler. |
| | The number of copies exceeds stapler capacity. | Check the stapler capacity. See p.132 "Staple". |
| | Copy paper is curled. | Turn the copy paper over in the tray. |
| Staples are wrongly positioned. | Originals are not placed correctly. | Check originals are placed in the correct position. See p.47 "Staple". |
| You cannot combine several functions. | Selected functions cannot be used together. | Check the combination of functions and make the settings again. |
| | | See p.127 "Combination Chart". |
| When sorting, the pages are divided into two blocks. | The memory became full in the middle of sorting and the pages were delivered in two blocks. | You can interrupt copying when memory becomes full. See p.124 "Memory Full Auto Scan Restart". |
| Paper does not output during printing with stapling. | If you stop printing while using the staple function, sheets not stapled during printing may be left in the staple unit. | Press the [Clear Modes] key and cancel copy settings, including stapling. |
| Colours changed even though they were not selected. | If colour range is set to "Wider" and if red is selected, colours such as magenta and orange may change. | Adjust the colour range by setting the colour width. See p.125 "Adjust Colour Image". |
| Colours not selected will be erased when using Erase mode. | If colour range is set to "Wider" and if red is selected, colours such as magenta and orange may change. | Adjust the colour range by setting the colour width. See p.125 "Adjust Colour Image". |

Edit

| Problem | Causes | Solutions |
|--|---|--|
| When using the Double Copies function, parts of the original image are not copied. | The original and copy paper combination is not correct. | Select A3□ for A4 □ originals and A4 for A5 originals. See p.64 "Double Copies". |
| When using the Border, Centre, or Centre/Border function, parts of the origi- nal image are not copied. | You set a wide erased margin. | Make the margin width narrower. You can adjust it between 2-99 mm. See "Erase Border Width" and "Erase Centre Width" in p.117 "Edit ¹ / ₂ ". Place originals correctly. |
| | Originals are not scanned correctly. | Place originals correctly. |
| When using the Margin Adjustment function, parts | You set a wide erased margin. | Set a narrower margin with User Tools. You can set the width be- |
| of the original image are not copied. | There is a lack of margin space on the opposite side of the binding position. | tween 0–30 mm (0"–1.2"). See p.117 "Front Margin: Left/Right", p.117 "Front Margin: Top/Bottom", p.117 "Back Margin: Left/Right", and p.117 "Back Margin: Top/Bottom". |
| When using the Image Repeat function, the original | You selected copy paper of the same size as the origi- | Select copy paper of a larger size than the originals. |
| image is not copied repeatedly. | nals, or you did not select a proper reproduction ratio. | Select a proper reproduction ratio. |

◆ Stamp

| Problem | Causes | Solutions |
|------------------------------|--------|---|
| The stamp position is wrong. | 1 1 | Check the paper orientation and stamp position. |

♦ Combine

| Problem | Causes | Solutions |
|---|---|---|
| You cannot fold copies into a book using the Magazine function. | Combine Original Magazine Format is not set correctly. | Change the setting. See p.120 "Orientation: Magazine" |
| When using the Combine function, parts of the image are not copied. | You specified a reproduction ratio that does not match the sizes of originals and copy paper. | When you specify a reproduction ratio using the Manual Paper Select function, make sure the ratio matches originals and the copy paper. |
| | | ✓ Note□ Select the correct reproduction ratio before using the Combine function. |
| Copies are not in correct order. | You placed the originals in incorrect order. | When placing a stack of originals in the ADF, the last page should be on the bottom. |
| | | If you place an original on the exposure glass, start with the first page to be copied. |

❖ Duplex

| Problem | Causes | Solutions |
|--|--|---|
| When using Duplex, copy is made Top/Bottom even though Left/Right is selected. | You placed the originals in the wrong orientation. | Place the originals in the correct orientation. See p.13 "Original Orientation". |
| Copies are not in correct order. | You placed the originals in incorrect order. | When placing a stack of originals in the ADF, the first page should be on top. |
| | | If you place an original on the exposure glass, start with the first page to be copied. |

When Memory Is Full

Ø Note

☐ If you set [Memory Full Auto Scan Restart] in User Tools (see p.124 "Memory Full Auto Scan Restart") to [Yes], even if memory becomes full, the memory overflow message will not be displayed. The machine will make copies of scanned originals first, then automatically scan and copy remaining originals. When this happens, the resulting sorted pages will not be sequential.

| Message | Causes | Solutions |
|--|--|---|
| Memory is full.* originals have been scanned. | The scanned original exceeds the number of pages that can be stored in memory. | Press [Print] to print out already scanned originals and then delete scan data. |
| Press [Print] to copy scanned originals. Do not remove remaining originals. | | Or, press [Clear] to simply delete scan data. |
| ✓ Note□ Copying will stop and this message will be displayed when the memory is full. | | |
| Press [Resume] to scan and copy remaining originals. [Stop] [Resume] | The machine checks if the remaining originals should be copied, after the scanned original is printed. | To continue copying, remove all copies, and then press [Resume]. To stop copying, press [Stop]. |

5. User Tools (Copier/Document Server Features)

User Tools Menu (Copier/Document Server Features)

| User Tools Item Names | Default Settings |
|--|--|
| General Features 1/5 See p.112 "General Features 1/5" | |
| Auto Paper Select Priority | ON |
| Paper Display | Display |
| Original Type Display | Display |
| Original Type Priority | Full Colour/Two-colour: Text/Photo |
| | B & W/Single Colour: <i>Text/Photo</i> |
| Original Photo Type Priority | •Text/Photo: Printed Photo |
| | •Photo: Printed Photo |
| Auto Tray Switching | With image rotation |
| General Features 2/5 See p.113 "General Features ² / ₅ " | |
| Duplex Mode Priority | 1 Sided →1 Sided (metric) 1 Sided →2 Sided (inch) |
| Copy Orientation in Duplex Mode | Top to Top |
| Original Orientation in Duplex Mode | Top to Top |
| Change Initial Mode | Standard |
| Max. Copy Quantity | 999 Sheets |
| Tone: Original remains | ON |
| Job End Call | ON |
| General Features 3/5 See p.114 "General Features ³ / ₅ " | |
| Copy Function Key: F1~F5 | • F1: 1 Sided→2 Sided: T to T |
| | • F2: 2 Sided: T to T→2 Sided: T to T |
| | • F3: 1 Sided →1 Sided Combine |
| | • F4: 1 Sided →1 Sided Combine: 4 originals |
| | • F5: Create Margin |

| User Tools Item Names | Default Settings |
|---|---|
| General Features $4/5$ See p.115 "General Features $4/5$ ". | |
| Document Server Storage Key:F1~F5 | • F1: 2 Sided Original Top to top • F2: 1 Sided→1 Sided Com- bine • F3: 1 Sided→1 Sided Com- bine: 4 originals • F4: 1 Sided→1 Sided Com- bine: 8 originals • F5: Create Margin |
| General Features $5/5$ See p.115 "General Features $5/5$ ". | I |
| Clear Bypass Mode | Clear |
| Colour Mode Priority | Black & White |
| Two-colour Mode Priority | Red & Black |
| Auto Image Density Priority | Full Colour / Two-colour: OFF |
| | B & W / Single Colour: ON |
| Reproduction Ratio $1/2$ See p.116 "Reproduction Ratio $1/2$ ". | |
| Shortcut R/E | Metric version •Shortcut R/E 1: 71% •Shortcut R/E 2: 141% •Shortcut R/E 3: 93% Inch version •Shortcut R/E 1: 73% •Shortcut R/E 2: 155% •Shortcut R/E 3: 93% |
| Enlarge 1~5 | Metric version • Enlarge 1: 115% • Enlarge 2: 122% • Enlarge 3: 141% • Enlarge 4: 200% • Enlarge 5: 400% Inch version • Enlarge 1: 121% • Enlarge 2: 129% • Enlarge 3: 155% • Enlarge 4: 200% • Enlarge 5: 400% |
| Priority Setting: Enlarge | Metric version 141% Inch version 155% |

| User Tools Item Names | Default Settings |
|--|--|
| Reproduction Ratio 2/2 See p.116 "Reproduction Ratio ² / ₂ | 2". |
| Reduce1~6 | Metric version |
| | •Reduce1: 25% |
| | •Reduce2: 50% |
| | •Reduce3: 65% |
| | •Reduce4: 71% |
| | •Reduce5: 75% |
| | •Reduce6: 82% |
| | Inch version |
| | •Reduce1: 25% |
| | •Reduce2: 50% |
| | •Reduce3: 65% |
| | •Reduce4: 73% |
| | •Reduce5: 78% |
| | •Reduce6: 85% |
| Priority Setting: Reduce | Metric version: 71% |
| | Inch version: 73% |
| Ratio for Create Margin | 93% |
| R/E Priority | Reduce |
| Edit 1/2 See p.117 "Edit ¹ / ₂ ". | , |
| Front Margin: Left/Right | Metric version: <i>Left 5mm</i> Inch version: <i>Left 0.2"</i> |
| Back Margin: Left/Right | Metric version: <i>Right 5mm</i> Inch version: <i>Right 0.2"</i> |
| Front Margin: Top/Bottom | Metric version: <i>T/B 0mm</i> Inch version: <i>T/B 0"</i> |
| Back Margin: Top/Bottom | Metric version: T/B 0mm Inch version: T/B 0" |
| 1 Sided→2 Sided Auto Margin: TtoT | Metric version: <i>Right 5mm</i> Inch version: <i>Right 0.2"</i> |
| 1 Sided→2 Sided Auto Margin: TtoB | Metric version: <i>T/B 0mm</i> Inch version: <i>T/B 0"</i> |
| Erase Border Width | Metric version: 10mm Inch version: 0.4" |
| Erase Original Shadow in Combine | Yes |
| Erase Centre Width | Metric version: 10mm Inch version: 0.4" |

| User Tools Item Names | | Default Settings |
|---|----------------------|--|
| Edit 2/2 See p.118 "Edit ² / ₂ ". | | |
| Front Cover Copy in Combine | | Combine |
| Copy Order in Combine | | From left to right |
| Image Repeat Separation Line | | None |
| Double Copies Separation Line | | None |
| Separation Line in Combine | | None |
| Orientation: Magazine | | Open to left |
| Stamp See p.121 "Stamp". | | |
| Preset Stamp | Stamp Priority | Сору |
| | Stamp Language | English |
| | Stamp Position | Metric version |
| | | • Position: Top right |
| | | • Top Margin: 24mm |
| | | • Right Margin: 24mm |
| | | Inch version |
| | | Position: Top right |
| | | • Top Margin: 1.0" |
| | | • Right Margin: 1.0" |
| | Stamp Format: | Size: 1 X |
| | | Density: Normal |
| | | Page to Stamp: All pages |
| | Stamp Colour: | Black |
| User Stamp | Program/Delete Stamp | |
| | Stamp Position: 1~4 | Metric version |
| | | Position: Top right |
| | | • Top Margin: 24mm |
| | | • Right Margin: 24mm |
| | | Inch version |
| | | Position: Top right |
| | | • Top Margin: 1.0" |
| | | • Right Margin: 1.0" |
| | Stamp Format: 1~4 | All pages |
| | Stamp Colour: 1~4 | Black |
| | 1 | The state of the s |

| User Tools Item Names | | Default Settings |
|-----------------------|----------------|--|
| Date Stamp | Format | Metric version: DD/MM/YYYY Inch version: MM/DD/YYYY |
| | Font | Font 1 |
| | Stamp Position | Metric version • Position: Top left • Top Margin: 8mm • Right Margin: 32mm Inch version • Position: Top left • Top Margin: 0.3" • Right Margin: 0.8" |
| | Stamp Setting | All pages |
| | Size | Auto |
| | Superimpose | No |
| | Stamp Colour | Black |

| User Tools Item Names | | Default Settings |
|----------------------------------|---------------------------------------|---|
| Page Numbering | Stamp Format | P1, P2 |
| | Font | Font 1 |
| | Size | Auto |
| | Duplex Back Page Stamping Position | Opposite position |
| | Page Numbering in Combine | Per original |
| | Stamp Position: | Metric version |
| | | • Position P1, 1/5, P.1, 1: Top right -1-, 1-1: Bottom centre |
| | | • Top/Bottom Margin P1, 1/5, P.1, 1: 12mm -1-, 1-1: 8mm |
| | | • Left/Right Margin P1, 1/5, P.1, 1: 12mm -1-, 1-1: 0mm |
| | | Inch version |
| | | • Position P1, 1/5, P.1, 1: Top right -1-, 1-1: Bottom centre |
| | | • Top/Bottom Margin P1, 1/5, P.1, 1: 0.5" -1-, 1-1: 0.3" |
| | | • Left/Right Margin P1, 1/5, P.1, 1: 0.5" -1-, 1-1: 0.0" |
| | Superimpose | No |
| | Stamp Colour | Black |
| Input/Output See p.124 "Input/ | 'Output". | |
| Switch to Batch | | Batch |
| SADF Auto Reset | | 5 seconds |
| Rotate Sort: Auto Paper Continue | | No |
| Auto Sort | | No |
| Memory Full Auto Scan Restart | | No |
| Select Stack Function | | Stack |
| Select Stapling Position | | Top 2 |
| Letterhead Setting | | No |

| User Tools Item Names | Default Settings | |
|--|----------------------------------|--|
| Adjust Colour Image See p.125 "Adjust Colour Image". | | |
| Background Density of ADS(Full Colour / Two-colour) | Centre of the 5 level adjustment | |
| Colour Sensitivity | Centre of the 5 level adjustment | |
| A.C.S. Sensitivity | Centre of the 5 level adjustment | |
| A.C.S. Priority | Full Colour | |

Accessing User Tools (Copier/Document Server Features)

This section is for key operators in charge of this machine. With User Tools can change the machine's default settings.

Note

- Be sure to exit User Tools and return to the initial copy display after all settings are finished. This section describes system settings you can set for the copier function.
- ☐ The selected key is highlighted.
- Any changes you make with User Tools remain in effect even if the main power switch or operation switch is turned off, or the [Clear Modes] key is pressed.

For details, see "Changing Default Settings" in "User Tools (System Settings)", General Settings Guide.

Changing Default Settings

1 Press the [User Tools/Counter] key.

The User Tools main menu appears.



Note

- ☐ When the key operator code is set, the key operator code input display appears when changing the default settings. Enter the registered key operator code beforehand. For key operator codes, see "Key Operator Tools", General Settings Guide.
- Press [Copier/Document Server Features].

The Copier/Document Server Features menu is displayed.

3 Select the menu you want to set.

The setting display for each menu is displayed.

₽ Reference


See p.103 "User Tools Menu (Copier/Document Server Features)".

Change settings by following the instructions on the display panel, and then press [OK].

Exiting User Tools

After changing default settings, press [Exit] on the User Tools main menu.

Changes to User Tools are complete, and the machine is ready to copy.





☐ You can also exit User Tools by pressing the [User Tools/Counter] key.

Settings You Can Change with User Tools

General Features 1/5

Auto Paper Select Priority

Auto Paper Select is the default setting. You can cancel this setting. See p.35 "Selecting Copy Paper".

𝚱 Note

☐ Default: ON


Paper Display

You can choose to have the available paper trays and sizes shown on the initial display.

𝚱 Note

☐ Default: Display

☐ If you select [Hide], the display is shown as below. Press [Auto Paper Select] to display paper sizes.




Original Type Display

You can have the original types shown on the initial display.

☐ Default: Display

☐ If you select [Hide], the display is as below.



Original Type Priority

You can select the original type effective when the power is turned on, or modes cleared. See p.34 "Selecting the Original Type".

Note

☐ Default: Full Colour/Two-Colour: *Text/Photo*, B&W/Single Colour: *Text/Photo*

Original Photo Type Priority

When you select "Text/Photo" or "Photo" in "Original Type Priority", you can change the settings of the selected original type.

Note

☐ Default: Text/Photo: *Printed Photo*, Photo: *Printed Photo*

Auto Tray Switching

If you load paper of the same size in two or more trays, the machine automatically shifts to the other when the first tray runs out of paper (when Auto Paper Select is selected.) This function is called "Auto Tray Switching". This setting specifies whether to use Auto Tray Switching or not.

- **𝒯** Note
- ☐ Default: With Image Rotation
- ☐ [With Image Rotation] Use to copy when using the Auto Tray Switching function.
- □ [Without Image Rotation] Only copies with Auto Tray Switching if you load paper of the same size and in the same orientation in two or more trays. If the paper is not the same size or in the same orientation, copying is interrupted and the message "Load paper." is displayed.
- ☐ [Off] When a paper tray runs out of paper, copying is interrupted and the message "Load paper." is displayed.

General Features ²/₅

Duplex Mode Priority

You can select the type of the Duplex function effective when the power is turned on, or modes are cleared.

- ☐ Default:
 - Metric version: 1 Sided→1 Sided
 - Inch version: 1 Sided→2 Sided

Copy Orientation in Duplex Mode

You can set the copy orientation when making two-sided copies.

- Ø Note
- ☐ Default: Top to Top

Original Orientation in Duplex Mode

You can set the original orientation when making two-sided copies.

- Note
- □ Default: Top to Top

Change Initial Mode

You can select standard mode or Program No.10 as the mode effective when power is turned on, or modes are cleared.

- Note
- □ Default: Standard

Max. Copy Quantity

The maximum copy quantity can be set between 1 and 999.

- **𝒯** Note
- □ Default: 999 Sheets

Tone: Original remains

The beeper (key tone) sounds if you forget to remove originals after copying.

Note

- ☐ Default: ON
- ☐ If Panel Tone in User Tools (System Settings) is [OFF], the beeper does not sound, whatever the Tone: Original remains setting. See "Panel Tone" in "General Features", General Settings Guide.

Job End Call

You can choose to have the beeper sound when copying is complete.


∂ Note

- ☐ Default: ON
- ☐ If Panel Tone of User Tools (System Settings) settings is **[ON]**, the machine beeps to notify you that it did not complete a job for reasons such as: the paper tray ran out of paper, or a paper jam occurred.

General Features 3/5

❖ Copy Function Key: F1-F5


You can assign frequently used functions to function keys F1 to F5.



- ☐ Default:
 - Copy Function Key: F1: 1 Sided→2 Sided: T to T
 - Copy Function Key: F2:
 2 Sided: T to T→2 Sided: T to T
 - Copy Function Key: F3: 1 Sided→1 Sided Combine
 - Copy Function Key: F4: 1 Sided→1 Sided Combine: 4 originals
 - Copy Function Key: F5: Create Margin

General Features 4/5

❖ Document Server Storage Key: F1-F5 You can assign frequently used functions to function keys F1 to F5. You can also change assigned functions.



- ☐ Default:
 - Document Server Storage Key: F1: 2 Sided Original Top to top
 - Document Server Storage Key: F2: 1 Sided→1 Sided Combine
 - Document Server Storage Key: F3: 1 Sided→1 Sided Combine: 4 originals
 - Document Server Storage Key: F4: 1 Sided →1 Sided Combine: 8 originals
 - Document Server Storage Key: F5: *Create Margin*

General Features 5/5

Clear Bypass Mode

You can set whether to "Clear" or "Do not Clear" bypass tray settings when the machine is turned on, reset, or modes are cleared.

☐ Default: Clear

Colour Mode Priority

You can select to prioritize "Auto Colour Select", "Full Colour", or "Black & White" when the machine is turned on, reset, or modes are cleared.

Note

☐ Default: Black & White

Two-colour Mode Priority

You can set whether to prioritize "Red & Black" or "Two-colour" in Two-colour mode.

Note

□ Default: Red & Black

Auto Image Density Priority

You can set whether Auto Image Density is "ON" or "OFF" when the machine is turned on, reset, or modes are cleared.

𝒯 Note

- ☐ Default: Full Colour/Two-colour: *OFF*, B&W/Single Colour: *ON*
- ☐ When using the Auto Colour Select function, the settings of Full Colour/Two-colour will be effective.

Reproduction Ratio ¹/₂


Shortcut R/E

You can register up to three frequently used Reduce/Enlarge ratios other than the fixed Reduce/Enlarge ratio and have them shown on the initial display. You can also change registered Reduce/Enlarge ratios.

If no Reduce/Enlarge ratio has been set when selecting [Shortcut R/E 1], [Shortcut R/E 2], or [Shortcut R/E 3], enter the ratio using the number keys.

Enlarge 1-5

You can customize available enlargement ratios by pressing [Reduce/Enlarge], followed by [Enlarge].



Note

- ☐ Default:
 - Metric version:
 - Enlarge 1: 115%
 - Enlarge 2: 122%
 - Enlarge 3: 141%
 - Enlarge 4: 200%
 - Enlarge 5: 400%
 - Inch version:
 - Enlarge 1: 121%
 - Enlarge 2: 129%
 - Enlarge 3: 155%
 - Enlarge 4: 200%
 - Enlarge 5: 400%
- □ When selecting [User Enlrg. Ratio], enter a ratio using the number keys (in the range of 101 to 400%).

♦ Priority Setting: Enlarge

You can set the ratio with priority when [Reduce/Enlarge] is pressed, followed by [Enlarge].

Note

☐ Default:


• Metric version: 141%

• Inch version: 155%

Reproduction Ratio ²/₂

Reduce 1-6

You can customize available reduction ratios by pressing [Reduce/Enlarge], followed by [Reduce].



- ☐ Default:
 - Metric version:
 - Reduce 1: 25%
 - Reduce 2: 50%
 - Reduce 3: 65%
 - Reduce 4: 71%
 - Reduce 5: 75%
 - Reduce 6: 82%
 - Inch version:
 - Reduce 1: 25%
 - Reduce 2: 50%
 - Reduce 3: 65%
 - Reduce 4: 73%
 - Reduce 5: 78%
 - Reduce 6: 85%
- ☐ When selecting [User Redc.Ratio], enter a ratio using the number keys (in the range of 25 to 99%).

Priority Setting: Reduce

You can set the ratio with priority when [Reduce/Enlarge] is pressed, followed by [Reduce].

Note

☐ Default:

• Metric version: 71%

Inch version: 73%

Ratio for Create Margin

You can set a Reduce/Enlarge ratio when registering Create Margin in a shortcut key.

Ø Note

☐ Default: 93%

❖ R/E Priority

Specifies which tab has priority on the display panel when [Reduce/Enlarge] is pressed.

∅ Note

☐ Default: Reduce

Edit¹/₂

Note

- ☐ Enter the width of the binding margin using the number keys, as follows:
 - Metric version: 0–30 mm (1 mm increments)
 - Inch version: 0"-1.2" (0.1 in increments)
- Enter the width of the erased margin using the number keys as follows:
 - Metric version: 2–99 mm (1 mm increments)
 - Inch version: 0.1"–3.9" (0.1 in increments)

Front Margin: Left/Right

You can specify left and right margins on the front side of copies using the Margin Adjustment function.

Note

☐ Default:

• Metric version: *Left 5 mm*

• Inch version: *Left 0.2*"

♦ Back Margin: Left/Right

You can specify left and right margins on the back side of copies using the Margin Adjustment function.

☐ Default:

• Metric version: *Right 5 mm*

• Inch version: Right 0.2"

❖ Front Margin: Top/Bottom

You can specify top and bottom margins on the front side of copies using the Margin Adjustment function.

Note

☐ Default:

• Metric version: T/B 0 mm

• Inch version: T/B 0.0"

Back Margin: Top/Bottom

You can specify top and bottom margins on the back side of copies using the Margin Adjustment function.

Note

☐ Default:

• Metric version: T/B 0 mm

• Inch version: T/B 0.0"

♦ 1 Sided→2 Sided Auto Margin: TtoT

When using the 1 sided \rightarrow 2 sided Duplex function, you can specify margins on the back side.

The margin is set to the same value as "Back Margin: Left/Right".

𝚱 Note

☐ Default:

• Metric version: Right 5 mm

• Inch version: Right 0.2"

♦ 1 Sided→2 Sided Auto Margin: TtoB

When using the 1 sided \rightarrow 2 sided Duplex function, you can specify margins on the back side. The margin is set to the same value as "Back Margin: Top/Bottom".

Note

☐ Default:

• Metric version: *T/B 0 mm*

• Inch version: T/B 0.0"

Erase Border Width

You can specify the width of erased border margins using this function.

𝒯 Note

□ Default:

• Metric version: 10 mm

• Inch version: 0.4"

Erase Original Shadow in Combine

In Combine Copy or Magazine Copy mode, you can specify whether to erase a 3mm, 0.1" bounding margin around all four edges of each original.

□ Default: Yes

Erase Centre Width

You can specify the width of the erased centre margins using this function.

Note

☐ Default:

• Metric version: 10 mm

• Inch version: 0.4"

Edit ²/₂

Note

☐ An image of approximately 1.5 mm (0.06") will not be displayed as the width of the separation line, when specifying solid or broken lines.

Front Cover Copy in Combine

You can make a combined copy on the front cover sheet when you select the Front Cover function.

| Combine | Not Combined |
|---|--------------|
| 1 2 5 6 3 4 7 8 | 1 2 3 6 7 8 |

GCST019



☐ Default: Combine

Copy Order in Combine

You can set the copy order when using the Combine function to Left to Right or Top to Bottom.

| From Left to Right | From Top to Bottom | |
|--------------------|--------------------|--|
| 1 2 3 4 | 1 3 2 4 | |
| 1 2 3 4 5 6 7 8 | 1 3 5 7 2 4 6 8 | |

GCAH09



□ Default: *From left to right*

♦ Image Repeat Separation Line

You can select a separation line and colour using the Image Repeat function from: None, Solid, Broken A, Broken B, or Crop Marks.

- None
- Solid
- Broken A
- Broken B
- -----
- Crop Marks
- +

- Note
- ☐ Default: None
- ☐ Line colour (Full Colour): Yellow, Red, Cyan, Magenta, Green, Blue, Black
- ☐ Separation lines cannot be specified when using [None].
- ☐ In "Black and White", printing will be done in black; in "Single Colour", printing will be done in the specified colour; in "Two-Colour" (standard), printing will be done in the specified colour of the black area; and in "Two-Colour" (Red and Black), printing will be done in black.
- ☐ An image of approximately 1.5mm will not be displayed as the width of the separation line, when specifying solid or broken lines.

❖ Double Copies Separation Line

You can select a separation line using the Double Copies function from: None, Solid, Broken A, Broken B, or Crop Marks.

- None
- Solid
- Broken A
-
- Broken B
- ----
- Crop Marks



Note

- □ Default: None
- Line colour (Full Colour): Yellow, Red, Cyan, Magenta, Green, Blue, Black
- ☐ Separation lines cannot be specified when using [None].
- ☐ In "Black and White", printing will be done in black; in "Single Colour", printing will be done in the specified colour; in "Two-Colour" (standard), printing will be done in the specified colour of the black area; and in "Two-Colour" (Red and Black), printing will be done in black.
- ☐ Images of approximately 1.5mm will not be displayed as the width of the separation line when solid or broken lines have been specified.

Separation Line in Combine

You can select a separation line using the Combine function from: None, Solid, Broken A, Broken B, or Crop Marks. See p.57 "1 Sided Combine" and p.58 "2 Sided Combine".

None



Solid



• Broken A



Broken B



· Crop Marks



∅ Note

- ☐ Default: None
- Line colour (Full Colour): Yellow, Red, Cyan, Magenta, Green, Blue, Black
- ☐ Separation lines cannot be specified when using [None].
- ☐ In "Black and White", printing will be done in black; in "Single Colour", printing will be done in the specified colour; in "Two-Colour" (standard), printing will be done in the specified colour of the black area; and in "Two-Colour" (Red and Black), printing will be done in black.
- □ Images of approximately 1.5mm will not be displayed as the width of the separation line when solid or broken lines have been specified.

Orientation: Magazine

You can select the orientation of copies to open when using Magazine function.



☐ Default: Open to left

p.62 "How to fold and unfold copies to make a magazine"

Stamp

Preset Stamp 1/4-4/4

Stamp Priority

You can select the stamp type given priority when **[Preset Stamp]** is pressed. See p.70 "Preset Stamp".

Note

☐ Default: COPY

Stamp Language

You can select the language of the stamp.

Ø Note

□ Default: English

Stamp Position

You can set the position where the stamp is printed.

Press the arrow keys to adjust the position.

∅ Note

☐ Default:

Metric Version:

• Position: Top right

• Top Margin: 24 mm

• Right Margin: 24 mm

• Inch Version:

• Position: Top right

• Top Margin: 1.0"

• Right Margin: 1.0"

Stamp Format

You can adjust the stamp's size, density, and print page.

Size

You can set the size of the stamp.

𝚱 Note

□ Default: 1X

Density

You can set the pattern used to print the stamp.

☐ Default: Normal

- ☐ Normal: The stamp is printed on the image. You cannot check which parts will overlap.
- ☐ Lighter: The image can be seen through the stamp.
- ☐ Lightest: The image appears even clearer than in the Lighter setting.
- Page to Stamp

You can have the stamp printed on the first page or all pages.

Note

☐ Default: All Pages

Stamp Colour

Sets the stamp print colour.

Note

☐ Default: Black

User Stamp 1/2-2/2

Program/Delete Stamp

You can register, change, or delete these user stamp designs.

Note

☐ You can register up to four custom stamps with your favourite designs. See p.73 "To program the user stamp".

For how to delete the user stamp, see p.74 "To delete the user stamp".

Stamp Position 1 - 4

You can set the position where the stamp is printed.

Press the arrow keys to adjust the position.

Note

☐ Default:

Metric version:

• Position: Top right

• Top Margin: 24 mm

• Right Margin: 24 mm

Inch version:

• Position: Top right

• Top Margin: 1.0"

• Right Margin: 1.0"

♦ Stamp Format 1 - 4

You can adjust the print page for User Stamps 1 to 4 already registered.

Page to Stamp
 Sets whether to print the stamp
 on all pages or only the first
 page.



☐ Default: All Pages

Stamp Colour: 1 - 4

Sets the colour registered in User Stamp colour (1 to 4).

𝒯 Note

☐ Default: Black

Date Stamp

Format

You can select the date format for the Date Stamp function.

☐ Default:

• Metric version: *DD/MM/YYYY*

• Inch version: *MM/DD/YYYY*

Font

You can select the Date Stamp font.

☐ Default: Font 1

☐ This setting is linked to the Page Numbering function.

Stamp Position

You can set the position where the stamp is printed.

Press the arrow keys to adjust the position.

Note

☐ Default:

Metric version:

• Position: Top left

• Top Margin: 8 mm

• Left Margin: 32 mm

• Inch version:

• Position: Top left

• Top Margin: 0.3"

• Left Margin: 0.8"

Stamp Setting

You can have the date printed on the first page or all pages.

Note

□ Default: *All Pages*

Size

You can set the Date Stamp size.

Note

☐ Default: Auto

Superimpose

You can have the Date Stamp printed in white where it overlaps black parts of the image.

☐ Default: *No*

Stamp Colour

You can set the selected priority colour when printing the date.

Note

☐ Default: Black

Page Numbering ¹/₃-²/₃

Stamp Format

You can select the page number format given priority when [Page Numbering] is pressed.

𝒯 Note

□ Default: P1, P2

Font

You can select the page number font.

Note

☐ Default: Font 1

Size

You can set the size of the page number.

Note

☐ Default: Auto

Duplex Back Page Stamping Position

You can set the position of the duplex back page number printed using the Duplex function.

☐ Default: *Opposite position*

Page Numbering in Combine

You can set page numbering when using the Combine and Page Numbering function together.

Ø Note

☐ Default: Per original

Stamp Position

P1, P2... Stamp Position: 1/5, 2/5... Stamp Position: -1-, -2-... Stamp Position: P.1, P.2. Stamp Position: 1, 2... Stamp Position: 1-1, 1-2... You can set the position where the stamp is printed.

Press the arrow keys to adjust the position.

Superimpose

You can have page numbers printed in white where they overlap black parts of the image.

Note

☐ Default: No.

Stamp Colour

You can set the selected priority colour when printing the date.

𝒯 Note

□ Default: Black

Input/Output

Switch to Batch (SADF)

You can select to have the Batch or SADF function displayed when you press [Special Original]. See p.15 "Batch".

𝚱 Note

☐ Default: Batch

SADF Auto Reset

When you set one original at a time in the ADF, the Auto Feed indicator lights for a specified time after an original is fed, to show the ADF is ready for another original. You can adjust this time from 3 seconds to 99 in 1 second increments.

Note

☐ Default: 5 seconds

Rotate Sort: Auto Paper Continue

You can continue copying when paper of the required orientation has run out during rotate-sorting. See p.43 "Rotate Sort".

𝚱 Note

☐ If you select [No]:

 When paper of the required orientation runs out, the machine stops copying and prompts you to supply copy paper. When you load paper, the machine will continue copying.

 \square If you select **[Yes]**:

 Copying continues using copy paper of a different orientation. The copy job will finish even if the machine is left unattended.

☐ Default: No

Auto Sort

You can specify whether the Sort function is to be selected when the machine is turned on, or when the functions are cleared.

Note

☐ Default: No

Memory Full Auto Scan Restart

If memory becomes full while scanning originals, the machine will copy the scanned originals first, and then automatically proceed scanning remaining originals. You can enable or disable this function.

Note

☐ If you select [No]:

 When memory becomes full, the machine stops operation, allowing you to remove the copies on the output tray.

☐ If you select [Yes]:

 You can leave the machine unattended to make copies, but sorted pages will not be sequential.

☐ Default: No

Select Stack Function

Specify whether Stack or Rotate Sort has priority on the initial display.

☐ Default: Stack

☐ An 2 tray finisher or booklet finisher is required to use this function.

Select Stapling Position

Specify which Top 2 staples or Bottom shown on the initial display with priority.

Note

- ☐ Default: *Top 2*
- ☐ The 2 tray finisher or booklet finisher is required to use this function.

Letterhead Setting

If you select **[Yes]** for this function, the machine rotates images correctly.

Ø Note

- ☐ Default: No
- Orientation-fixed (top to bottom) or two-sided paper might not print correctly depending on how the originals and paper are placed.

When using letterhead paper, pay attention to the paper orientation. See "Orientation-Fixed Paper or Two-Sided Paper" in "Loading Paper", General Settings Guide.

Adjust Colour Image

Background Density of ADS(Full Colour / Two-colour)

The background density is adjusted to skip the texture and copy. You can adjust the background density up to 5 levels when in Full Colour or Two-colour.

☐ Default: Centre of the 5 level adjustment

Colour Sensitivity

You can adjust the tone of red in "Two colour (Red & Black)", the colour specified to convert in "Colour Convert" and the colour specified for "Erase Colour", in 5 levels.

Note

- ☐ Default: Centre of the 5 level adjustment
- ☐ When the colour width has been set to "Wider", and the colour to be deleted, for example is red, all the colours that are close to magenta and orange are deleted. If it's set to "Narrower" the colour red will be deleted.

A.C.S. Sensitivity

This 5-step setting determines the level of the standard used for discriminating between black & white originals and full colour originals when "Auto Colour Select" is selected.

∅ Note

☐ Default: Centre of the 5 level adjustment

A.C.S. Priority

This setting determines the copy priority between "Black & White" and "Full Colour" when "Auto Colour Select" is selected.

Note


☐ Default: Full Colour

6. Specifications

Combination Chart

The combination chart below shows which functions can be used together. The following tables explains the symbols used in the chart.

| | means that these functions can be used together. |
|---|---|
| | means that these functions cannot be used together. The second function selected will be the function you are working in. |
| × | means that these functions cannot be used together. The first function selected will be the function you are working in. |



^{*1} Combination is not available when the copied content is 2 sided.
*2 Combination with "2 Sided —1 Sided" is X with cover sheet.
*3 Combination with Staple Top 2 is X with Punch left.
Combination with Staple 1 position is X with Punch Top.

Supplementary Specifications

Mixed Size mode

- Since small originals may not be correctly aligned with the original guide, the copy image may be slanted.
- Copying speed and scanning speed will be reduced.
- You can place originals of two different sizes at a time.

Bypass Tray Copy

- The following paper sizes can be selected as the standard sizes: A3□, A4□□, A5□□, A6□, B4 JIS□, B5 JIS□□, B6 JIS□, Postcard□, 11"×17"□, 8¹/2"×14"□, 8¹/2"×11"□□, 5¹/2"×8¹/2"□, 7¹/4"×10¹/2"□□, 8"×13"□, 8¹/2"×13"□, 8¹/4"×13"□, 12"×18"□
- When the beeper is turned off, it will not sound when you insert paper into the bypass tray. See "Panel Tone" *General Settings Guide*.

Preset Enlarge/Reduce

- You can select one of 12 preset ratios (5 enlargement ratios, 7 reduction ratios).
- You can select a ratio regardless of the size of an original or copy paper.
 With some ratios, parts of the image might not be copied or margins will be displayed on copies.
- Copies can be reduced or enlarged as follows:

Metric version

| Ratio (%) | Original → Copy paper size |
|--|----------------------------|
| 400 (enlarge area by 16) | |
| 200 (enlarge area by 4) | A5→A3 |
| 141 (enlarge area by 2) | A4→A3, A5→A4 |
| 122 | F→A3, A4→B4 JIS |
| 115 | B4 JIS→A3 |
| 93 | |
| 82 | F→A4, B4 JIS→A4 |
| 75 | B4 JIS→F4, B4 JIS→F |
| 71 (reduce area by ¹ / ₂) | A3→A4, A4→A5 |
| 65 | A3→F |
| 50 (reduce area by ¹ / ₄) | A3→A5, F→A5 |
| 25 | |

6

Inch version

| Ratio (%) | Original → Copy paper size |
|--|---|
| 400 (enlarge area by 16) | |
| 200 (enlarge area by 4) | $5^1/_2$ " × $8^1/_2$ " → 11 " × 17 " |
| 155 (enlarge area by 2) | $5^1/2" \times 8^1/2" \rightarrow 8^1/2" \times 14"$ |
| 129 | $8^{1}/_{2}$ " × 11" \rightarrow 11" × 17" |
| 121 | $8^{1}/_{2}$ " × 14" \rightarrow 11" × 17" |
| 93 | |
| 85 | F->81/2" × 11" |
| 78 | $8^{1}/_{2}$ " × 14" \rightarrow $8^{1}/_{2}$ " × 11" |
| 73 | $11" \times 15" \rightarrow 8^{1}/_{2}" \times 11"$ |
| 65 | $11" \times 17" \rightarrow 8^{1}/_{2}" \times 11"$ |
| 50 (reduce area by ¹ / ₄) | $11" \times 17" \rightarrow 5^{1}/_{2}" \times 8^{1}/_{2}"$ |
| 25 | |

Zoom

- The reproduction ratios you can specify are 25–400%.
- You can select a ratio regardless of the size of an original or copy paper.
 With some ratios, parts of the image might not be copied or margins will be displayed on copies.

Size Magnification

- If the calculated ratio is over the maximum or under the minimum ratio, it
 is automatically adjusted to within available range. However, with some
 ratios, parts of the image might not be copied or margins will be displayed
 on copies.
- The reproduction ratios you can specify are 25–400%.

Directional Size Magnification

- The reproduction ratio you can specify are 25–400%.
- When entering a percentage ratio, you can specify any value in the permitted range, regardless of original or copy paper size. However, depending on settings and other conditions, part of the image may not be copied, or margins will be displayed on copies.
- When entering a size in millimeters or inches, and the calculated ratio is over the maximum or under the minimum ratio, it will be automatically adjusted to within available range. However, with some ratios, parts of the image might not be copied or margins will be displayed on copies.

Sort, Rotate Sort, Stack

• Paper sizes and orientations that can be used in the Shift Sort and Stack functions are as follows:

| | 2 tray finisher | Booklet finisher |
|----------------------------|--|---|
| Paper size and orientation | A3¬, B4 JIS¬, A4¬¬, B5 JIS¬¬, A5¬, 11"×17"¬, 81/2"× 14"¬¬, 81/2"×11"¬¬ | A3¬, B4 JIS¬, A4¬¬, B5 JIS¬, 11"×17"¬, 8¹/2"×14"¬, 8¹/2"× 11"¬¬ |

- Paper sizes and orientations that can be used in the Rotate Sort function are A4 \square \square , B5 JIS \square \square , $8^1/_2$ " \times 11" \square \square and $5^1/_2$ " \times $8^1/_2$ " \square \square .
- The number of copies that can be placed on the tray is as follows. When the number of copies exceeds capacity, remove copies from the tray.

| | Paper size and orientation | Paper capacity and weight |
|---------------|--|-------------------------------------|
| Standard tray | A4 □ or smaller 8¹/2" × 11" □ or smaller | 500 sheets (80 g/m²) (20 lb.) |
| | B4 JIS□ or larger 8¹/2" × 14"□ or larger | 250 sheets (80 g/m²) (20 lb.) |
| External tray | A3D, B4 JISD, A4 DD, B5 JIS DD, A5D, 11" × 17"D, 8 ¹ / ₂ " × 14"D, 8 ¹ / ₂ " × 11"DD, 5 ¹ / ₂ " × 8 ¹ / ₂ "D | 100 sheets |
| Left tray | Left tray 1 | |
| | A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square \square , A5 \square , 11" × 17" \square , 81/2" × 14" \square , 81/2" × 11" \square \square , 51/2" × 81/2" \square | 100 sheets |
| | Left tray 2 | |
| | A3D, B4 JISD, A4 DD, B5 JIS DD, A5D, 11" × 17"D, 8 ¹ / ₂ " × 14"D, 8 ¹ / ₂ " × 11"DD, 5 ¹ / ₂ " × 8 ¹ / ₂ "D | 250 sheets |

| | Paper size and orientation | Paper capacity and weight | | | |
|-----------------|---|--------------------------------------|--|--|--|
| 2 tray finisher | Finisher shift tray 1 | | | | |
| | A4 [] [], B5 JIS [] [], A5 [], 8 ¹ / ₂ " × 11" [] [] | 500 sheets (80 g/m²) (20 lb.) | | | |
| | A3□, B4 JIS□, 11" × 17"□, 8 ¹ / ₂ " × 14"□ | 250 sheets (80 g/m²) (20 lb.) | | | |
| | Finisher shift tray 2 (No staple) | | | | |
| | $A4 \square$, $8^1/_2$ " × 11" \square | 2000 sheets (80 g/m²) (20 lb.) | | | |
| | A3D, B4 JISD, A4D, B5 JIS DD, 11"×17"D, 8 ¹ / ₂ "× 14"D, 8 ¹ / ₂ "×11"D | 750 sheets (80 g/m²) (20 lb.) | | | |
| | A5 🖸 | 500 sheets (80 g/m²) (20 lb.) | | | |
| | Finisher shift tray 2 (staple) | | | | |
| | A4 \(\bigcip 8^1/_2" \times 11" \(\bigcip \) | 1500 sheets (80 g/m²) (20 lb.) | | | |
| | A3D, B4 JISD, A4D, B5 JIS DD, 11"×17"D, 8 ¹ / ₂ "×14"D, 8 ¹ / ₂ "×11"D | 750 sheets (80 g/m²) (20 lb.) | | | |
| Booklet finish- | Finisher shift tray | | | | |
| er | A4 □ □, B5 JIS □ □, 8 ¹ / ₂ " × 11" □ □ | 1000 sheets (80 g/m²) (20 lb.) | | | |
| | A3□, B4 JIS□, 11" × 17"□, 8 ¹ / ₂ " × 14"□ | 500 sheets (80 g/m²) (20 lb.) | | | |
| | Finisher booklet tray | | | | |
| | A3D, B4 JISD, A4D, 11"×17"D, 81/2"×14"D, 81/2" ×11"D | (80 g/m²) (20 lb.) | | | |
| | | • 2–5 sheets: 20 sets | | | |
| | | • 6–10 sheets: 10 sets | | | |

Note

 $\hfill\square$ When using the Rotate Sort or Staple functions, the capacity may be reduced.

Staple

- The following types of paper cannot be stapled:
 - Translucent paper
 - OHP transparencies
 - Label paper (adhesive labels)
 - Thick paper
 - Curled paper
 - Paper of low stiffness
 - Paper of mixed sizes
- In the following cases, copies will be delivered to the shift tray without stapling:
 - When the number of sheets for one set is over stapler capacity
 - When memory reaches 0% during copying
- When using Double Copies, or [1 Sided→1 Sided], [1 Sided→2 Sided], [2 Sided→1 Sided], or [2 Sided→2 Sided] in Combine mode, select □ paper for □ original and □ paper for □ original.
- When using Double Copies, or [1 Sided 2 Pages→ 1 Sided Combine] and [1 Sided 4 Pages→ 2 Sided Combine] in Combine mode, select
 □ paper for original and paper for original.
- When using [Left 2] or [Top 2] with Double Copies, or [1 Sided→1 Sided], [1 Sided→2 Sided], [2 Sided→1 Sided], or [2 Sided→2 Sided] in Combine mode, select paper for original and paper for original.
- When the finisher is installed, even if you place different size originals in the ADF, appropriate size of copy paper can be automatically selected and stapled using the Mixed Size mode and Auto Paper Select function. Load the paper you want to use in the paper trays beforehand. Paper sizes that can be stapled when using the Mixed Size mode are as follows:
 - A3□ and A4□
 - B4 JIS□ and B5 JIS□
 - $11" \times 17" \square$ and $8^1/_2" \times 11" \square$
- Paper sizes and orientation that can be used in the Staple function and the stapler capacity are as follows:

| | Paper size | Stapler capacity |
|------------------|--|------------------|
| 2 tray finisher | A4 □□, B5 JIS □□, 8 ¹ / ₂ " × 11" □□ | 2–50 sheets |
| | A3□, B4 JIS□, 11" × 17"□, 8 ¹ / ₂ " × 14"□ | 2–30 sheets |
| Booklet finisher | $A4 \square \square$, $B5 JIS \square$, $8^1/2" \times 11" \square \square$ | 2–50 sheets |
| | A3□, B4 JIS□, 11" × 17"□, 8 ¹ / ₂ " × 14"□ | 2–25 sheets |
| | When Saddle Stitch function is selected: A3 \square , B4 JIS \square , A4 \square , 11" × 17" \square , 8 $^{1}/_{2}$ " × | 2–10 sheets |
| | $11"\Box, 8^{1}/_{2}" \times 14"\Box$ | |
| | mixed size | 2–25 sheets |

Note

- \square When stapling B4 \square , A3 \square , $8^1/_2$ " \times 14" \square , 11" \times 17" \square , pull out the extender of the finisher tray.
- ☐ When the number of copies exceeds tray capacity, copying stops. If this happens, remove the copies from the shift tray, and then resume copying.
- The tray capacity for the stapled sheets is as follows: (paper weight: 80 g/m², 20 lb.)

| | Paper size and orientation | Tray capacity |
|------------------|---|--|
| 2 tray finisher | Finisher shift tray 1 | 1 |
| | A4 \(\bullet \), B5 JIS \(\bullet \bullet \), 8\(\lambda \), 8\(\lambda \) \(\tau \). | • 10–50 sheets: 50–10 sets |
| | | • 2–9 sheets: 50 sets |
| | A3D, B4 JISD, 11" × 17"D, 8 ¹ / ₂ " × 14"D | • 10–30 sheets: 25–8 sets |
| | | • 2–9 sheets: 25 sets |
| | mixed size | • 2–30 sheets: 8 sets |
| | Finisher shift tray 2 | I |
| | A4 \(\bigcip \), 8\(8^1/2 \)" \times 11" \(\bigcip \) | • 15–50 sheets: 100–30 sets |
| | | • 2–14 sheets: 100 sets |
| | A4□, B5 JIS □□, 8¹/2" × 11"□ | • 15–50 sheets: 50–15 sets |
| | | • 2–14 sheets: 50 sets |
| | A3\(\burder\), B4 JIS\(\burder\), 11"\(\times\)17"\(\burder\), 8\(^1/_2\)"\(\times\)14"\(\burder\) | • 15–30 sheets: 50–25 sets |
| | | • 2–14 sheets: 50 sets |
| | mixed size | • 2–30 sheets: 25 sets |
| Booklet finisher | Finisher tray | 1 |
| | A4 $\square \square$, B5 JIS \square , $8^1/_2$ " × 11" $\square \square$ | 1000 sheets or 30 sets |
| | A3\$\operatorname{\operatorname{\operatorname{A}}}\$, B4 JIS\$\operatorname{\operatorname{A}}\$, 11" \times 17"\$\operatorname{\operatorname{A}}\$, 8\frac{1}{2}" \times 14"\$\operatorname{\operatorname{A}}\$ | 500 sheets or 30 sets |
| | Finisher booklet tray | 1 |
| | A3D, B4 JISD, A4D, 11"×17"D, 8 ¹ / ₂ "× 11"D, 8 ¹ / ₂ "×14"D | 2–5 sheets: 20 sets6–10 sheets: 10 sets |

- You cannot change stapling positions during copying.
- When the original image is rotated, the staple orientation changes by 90°.
- The maximum original image size that can be rotated is as follows:

| Metric version | A4 |
|----------------|--------------------------|
| Inch version | $8^{1}/_{2}" \times 11"$ |

- When using [Top Slant], [Left 2] or [Top 2] with Combine, Double copies or Auto Reduce/Enlarge function, "Blank part will appear. Check orientation." message may appear depending on the orientation of originals and paper you placed. In this case, change the paper orientation.
- When [Left 2] or [Top 2] is selected, the following settings are useful to rotate images appropriately:
 - Auto Reduce/Enlarge or Auto Paper Select
 - With image rotation in Auto Tray Switching of User Tools
- If you select Saddle Stitch function with the booklet finisher, the machine staples and folds the paper in the centre, then delivers the paper folded.
- If you select Saddle Stitch function in Magazine mode, the machine staples the paper, and folds it like a book, then delivers the paper folded.

Punch

- When using Punch and Combine, Double Copies, or Auto Reduce/Enlarge, the message "Blank part will appear. Check orientation." may appear because of the orientation of the original and the copy paper. If this occurs, change the orientation of the copy paper.
- Since punch holes are made in each copy, the punch hole positions vary slightly.
- Punchable paper sizes are as follows:

| 2 tray finisher | | | |
|------------------|---------|-----|---|
| Punch kit type | | | |
| 2 & 4 holes type | 2 holes | D . | A3-B5 JIS, 11" × 17" |
| | | D | A4-A5, 8 ¹ / ₂ " × 11" |
| | 4 holes | ₽ | A3, B4 JIS, 11" × 17" |
| | | D | A4, B5 JIS, 8 ¹ / ₂ " × 11" |
| 4 holes type | 4 holes | ㅁ | A3-B5 JIS, 11" × 17" |
| | | D | A4-A5, 8 ¹ / ₂ " × 11" |
| 2 & 3 holes type | 2 holes | ㅁ | A3-B5 JIS, 11" × 17" |
| | | ₽ | A4-A5, 8 ¹ / ₂ " × 11" |
| | 3 holes | ┏ | A3, B4 JIS, 11" × 17" |
| | | D | A4, B5 JIS, 8 ¹ / ₂ "×11" |

| Booklet finisher | | | |
|------------------|---------|---|--|
| Punch kit type | | | |
| 2 holes type | 2 holes | ₽ | A3, A4, B4 JIS, B5 JIS, 11" × 17", 8 ¹ / ₂ " × 14", 8 ¹ / ₂ " × 11" |
| | | D | A4, B5 JIS, 8 ¹ / ₂ " × 11" |
| 4 holes type | 4 holes | ┏ | A3 |
| | | D | A4 |


 The punch hole positions change according to the orientation of the paper selected.

Duplex

- You cannot use the following copy paper with this function:
 - Paper smaller than A5, $5^{1}/_{2}$ " × $8^{1}/_{2}$ " (possible on A5 \square , $5^{1}/_{2}$ " × $8^{1}/_{2}$ " \square)
 - Paper thicker than 105 g/m², 28 lb.
 - Paper thinner than 60 g/m², 17 lb.
 - Translucent paper
 - OHP transparencies
 - Label paper (adhesive labels)
 - Postcards
- When an odd number of originals is placed in the ADF, the back of the last page of copied paper is blank.
- During copying, the image is shifted to allow for the binding margin.
- The following paper sizes can be duplexed: A3 \square , B4 JIS \square , A4 \square \square , B5 JIS \square , A5 \square , 11" × 17" \square , 8¹/₂" × 14" \square , 8¹/₂" × 11" \square \square

Combine

- In this mode, the machine selects the reproduction ratio automatically.
 This reproduction ratio depends on copy paper sizes and the number of originals.
- The reproduction ratios you can specify are 25–400%.
- If the calculated ratio is under the minimum ratio, it will be automatically
 adjusted to within acceptable range. However, with some ratios, parts of
 the image might not be copied.
- You cannot use custom size paper.
- If the orientation of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.
- If the number of originals placed is less than the number specified for combining, the last page segment will be left blank as shown.



6

Series Copies

- The machine sets the reproduction ratio automatically to meet the paper size and copies the originals together onto the paper.
- The reproduction ratios you can specify are 25–400%.
- If the calculated ratio is under the minimum ratio, it is automatically adjusted to within acceptable range. However, with some ratios, parts of the image might not be copied.
- If the orientation of originals is different from that of the copy paper, the machine will automatically rotate the image by 90° to make copies properly.
- You cannot copy with originals different in size and orientation.
- If the number of originals scanned is less than a multiple of 4, the last page is copied blank.
- In Magazine mode, the copying may take some time after scanning originals.
- When the booklet finisher is installed, if you select Saddle Stitch function in Magazine mode, the machine staples and folds the paper in the centre, then delivers the paper folded.

Image Repeat

Depending on the paper size, ratio, and orientation, parts of repeated images may not be copied.

Centring

Though the original is set to a different orientation from the paper loaded, the machine will not rotate the image by 90° (Rotate copy).

Erase

The width of the erased margin varies depending on the reproduction ratio. If the size of the original is different from sizes listed in the following chart, the erased margin might be shifted:

Metric version

| Where original is placed | Paper size and orientation |
|--------------------------|---------------------------------------|
| Exposure glass | A3□, B4 JIS□, A4□□, B5 JIS□□ |
| ADF | A3□, B4 JIS□, A4 □□, B5 JIS □□, A5 □□ |

Inch version

| Where original is placed | Paper size and orientation |
|--------------------------|--|
| Exposure glass | $11" \times 17" \square, 8^1/_2" \times 14" \square, 8^1/_2" \times 11" \square \square$ |
| ADF | $ \begin{array}{c ccccccccccccccccccccccccccccccccccc$ |

♦ Margin Adjustment

- If you set a binding margin that is too wide, part of the image may not be copied.
- When making copies in Combine mode, the binding margin is added to the copies after the combination is finished.

Preset Stamp

- You can change the size and density of the stamp with User Tools. Depending on the setting, density may change.
- Depending on paper size, if you change the stamp size, parts of the stamp might not be printed.

Date Stamp


When using Combine mode, the date stamp is printed as follows:




Page Numbering

When page numbering is used with Combine mode, page numbers are printed as follows:


• Page Numbering per original: Combined with 1 Sided / 2 Sided in the Combine function



 Page Numbering per copy: Combined with 1 Sided / 2 Sided in the Combine function



If you combine this function with the Duplex (Top to Top) function and select [P1, P2] or [1/n, 2/n], page numbers on the back are printed as follows:



- 1. Front
- 2. Back

Front Cover, Front/Back Cover

- If Blank mode is selected, the cover will not be counted as a copy.
- Front and back covers are two-sided copied depending on the settings made in Display Time in Cover Sheet Tray of User Tools (System Settings).
 - If Display Time is selected to the At Mode Selected, settings made in Cover Sheet Tray will take priority.
 - If Display Time is selected to Full Time, settings made in Paper Type will take priority.
 - See "Paper Type" and "Cover Sheet Tray" in "Tray Paper Settings", General Settings Guide.

Slip Sheets

If you do not copy onto slip sheets, they are excluded from the number of copies counted.

Earth Leakage Breaker

To prevent electric shock this machine has an earth leakage breaker. The earth leakage breaker is normally in the on position.


Once a month, check that it functions properly by following the procedure below.

#Important

- If the earth leakage breaker is not functioning normally, contact your sales or service representative.
- Make sure the exposure glass cover or the Automatic Document Feeder (ADF) (optional) is closed.
- Press the operation switch at the top right hand corner of the control panel and see that the On indicator turns off.


Note

- ☐ In the following cases, the indicator will not turn off but will instead blink when you press the operation switch.
 - When the exposure glass cover or ADF is open
 - During communication with external equipment
 - When the hard disk is active
- Make sure that the On indicator is not lit, and then turn off the main power switch of the machine.




Important

- ☐ Do not turn off the main power switch when the **On** indicator is lit or blinking. Otherwise, it may result in damage to the hard disk or memory.
- 4 If the finisher is installed, detach it from the machine.




Note


- ☐ The above illustration shows the 2 tray finisher. If you are using the Booklet finisher, detach it in the same way.
- Raise the metal bar below the duplex reversal unit.




Using the tip of a ball-point pen, press the test button of the earth leakage breaker.




Confirm that the earth leakage breaker switch moves to the off position.



8 Turn the switch to the on position.



If the finisher is installed, reattach it to the machine.



- Note
- ☐ The above illustration shows the 2 tray finisher. If you are using the Booklet finisher, reattach it in the same way.
- Turn on the main power switch of the machine.
 - Note
 - ☐ If the power does not come on, check if the earth leakage breaker is in the off position. If so, do not turn it to the on position. Contact your sales or service representative immediately.

⚠ WARNING:



Do not turn the earth leakage breaker from the off to the on position. Otherwise it might lead to an electric shock, fire or smoke, or cause the circuit breakers to trip.

INDEX

| $1 \text{ sided} \rightarrow 2 \text{ sided}, 55$ | C |
|---|--|
| $2 \operatorname{sided} \rightarrow 1 \operatorname{sided}, 55$ | 6 . /1 1 |
| $2 \text{ sided} \rightarrow 2 \text{ sided}, 55$ | Centre/border erase, 69 |
| 90° turn, 14 | Centre erase, 68 |
| | Change |
| A | date format, 76 |
| | stamp position, 73,76 |
| Accessing user tools | Changing |
| copier/document server features, 110 | number of sets, 45 |
| A.C.S. | registered settings, 89 |
| priority, 126 | stamp position, 78 |
| sensitivity, 125 | stamp position, size and density, 71 |
| Adjust Colour Image, 125 | stored program, 86 |
| Adjusting | Check Modes key, 5 |
| background density, 91 | Clear Modes key, 5 |
| colours based on selected colour, 92 | Clear/Stop key, 6 |
| contrast, 90 | Colour |
| copy image density, 33 | adjustment, 87 |
| sharpness/softness, 90 | adjustment/program, 87 |
| text/photo sensitivity, 91 | background, 32 |
| U.C.R., 91 | balance, 88 |
| Adjust/Program Colour key, 5 | balance program, 88 |
| Auto | circle, 5 |
| colour selection, 29 | functions, 29 |
| image density, 33 | mode priority, 115 |
| image density priority, 104 | selection key, 6 |
| paper select, 35 | Colour Adjustment, 87 |
| paper select priority, 103 | Colour functions |
| reduce/enlarge, 40 | convert colours, 31 |
| tray switching, 113 | erase colour, 32 |
| Auto paper select, 36 | selecting a colour mode, 29 |
| Target Part Control | Colour image setting |
| В | colour sensitivity, 125 |
| | Colours |
| Background density of ADS | mixing manually with number keys, 94 |
| (Full Colour/Two-colour), 125 | Combination chart, 127 |
| Basic procedure, 19 | Combined auto and manual image density, 33 |
| Batch, 15 | Control panel, 5 |
| Black/white copy, 29 | Copier/Document Server Features, 103 |
| Border erase, 68 | copier, Document berver reacutes, 100 |
| | |

| Copier functions, 33 | ט |
|---|---|
| 1 sided combine, 57 | D |
| 2 sided combine, 58 | Date stamp, 75, 122 |
| adjusting copy image density, 33 | Change colour, 76 |
| auto reduce/enlarge, 40 | change format, 76 |
| book originals, 61 | change position, 76 |
| centring, 65 | font, 122 |
| covers, 81 | format, 122 |
| date stamp, 75 | position, 122 |
| directional magnification (%), 41 | position and original orientation, 75 |
| directional size magnification (mm), 42 | size, 123 |
| double copies, 64 | stamp colour, 123 |
| duplex, 55 | stamp setting, 123 |
| margin adjustment, 69 | superimpose, 123 |
| page numbering, 77 | Deleting |
| preset reduce/enlarge, 38 | program, 86 |
| | registered settings, 89 |
| preset stamp, 70 | user colours, 94 |
| selecting copy paper, 35 | user stamp, 74 |
| selecting the original type, 34 | Display panel, 5 |
| series copies, 60 | Document server, 83 |
| size magnification, 41 | Bocument server, 66 |
| slip sheets, 82 | E |
| sort, 43 | |
| stack, 46 | Edit, 105, 117 |
| staple, 47 | 1 sided \rightarrow 2 sided auto margin – T to B, 118 |
| user stamp, 72 | 1 sided \rightarrow 2 sided auto margin – T to T, 118 |
| zoom, 39 | back margin – left/right, 117 |
| Copy functions | back margin – top/bottom, 117 |
| image repeat, 63 | copy order in combine, 119 |
| mirror, 66 | double copies separation line, 119 |
| positive/negative, 66 | erase border width, 118 |
| specified area repeat, 64 | erase centre width, 118 |
| Copying, 19 | erase original shadow in combine, 118 |
| back Side of the Paper,25 | front cover copy in combine, 118 |
| interrupt copy, 20 | front margin – left/right, 117 |
| job preset,21 | front margin – top/bottom, 117 |
| left original beeper, 21 | image repeat separation line, 119 |
| OHP Transparencies or Thick Paper, 24 | Orientation: Magazine, 120 |
| onto envelopes, 26 | separation line in combine, 120 |
| with registered settings, 89 | Energy Saver key, 6 |
| Copying from bypass tray | Erase, 67 |
| onto custom size paper, 23 | border, 67 |
| onto standard size paper, 23 | border width, 118 |
| Covers | centre, 67 |
| Front, 81 | centre/border, 67 |
| | |
| front/back, 81 | |
| front/back, 81 Create margin function, 38 | centre width, 118 |
| | centre width, 118 colour, 32 |
| | centre width, 118 |

| F | K |
|--|--|
| Font, 122 Format, 122 Full colour copy, 29 Function status indicators, 6 | Key adjust/program colour, 5 check modes, 5 clear modes, 5 clear/stop, 6 energy saver, 6 |
| General features, 103, 104, 112, 113, 115 auto image density priority, 115 auto paper select priority, 112 auto tray switching, 113 change initial mode, 113 clear bypass mode, 115 colour mode priority, 115 | interrupt, 6 program, 5 sample copy, 6 # (sharp), 6 start, 6 user tools/counter, 5 |
| copy function key, 114 copy orientation in duplex mode, 113 document server storage key, 115 duplex mode priority, 113 job end call, 114 max. copy quantity, 113 original orientation in duplex mode, 113 original photo type priority, 112 original type display, 112 original type priority, 112 | Left original beeper, 21 M Main power indicator, 6 Manual image density, 33 Manual paper select, 36 Map, 34 Messages, 95 |
| paper display, 112 tone – original remains, 114 two-colour mode priority, 115 | Missing image area, 12 Mixed size, 17 |
| Generation copy, 34 | N |
| <u> </u> | Number keys, 6 |
| Image adjustment, 90 background density, 90, 91 contrast, 90 sharpness/softness, 90 text/photo sensitivity, 90, 91 U.C.R., 90, 91 Image repeat specified area repeat, 64 whole area repeat, 63 | |

Indicators, 5

Interrupt key, 6

Input/Output, 108, 124 auto sort, 124 letterhead setting, 125

> SADF auto reset, 124 select stack function, 124 select stapling position, 125 switch to batch (SADF), 124

memory full auto scan restart, 124 rotate sort – auto paper continue, 124

| 0 | Preset stamp, 121 |
|--|--|
| OHP transparencies, 82 one-sided combine 1 sided 2 pages → combine 1 side, 57 1 sided 4 pages → combine 1 side, 57 1 sided 8 pages → combine 1 side, 57 2 sided 1 page → combine 1 side, 57 2 sided 2 pages → combine 1 side, 57 2 sided 4 pages → combine 1 side, 57 2 sided 8 pages → combine 1 side, 57 0 sided 8 pages → combine 1 side, 57 Operation switch, 6 Original combine, 57 copy orientation, 56 orientation, 13 | changing colour, 71 changing density, 71 changing position, 71 changing size, 71 colour, 121 format, 121 language, 121 position, 121 position and original orientation, 71 priority, 121 Program key, 5 Programs, 85 Punch, 51 |
| orientation, 13 orientation and completed copies, 55 | <u> </u> |
| orientation in duplex mode, 113 photo type priority, 112 type display, 112 type priority, 112 Originals, 9 Originals not recommended for Auto Document Feeder (ADF), 10 | Recalling a program, 86 Renaming a colour, 93, 94 Reproduction ratio, 104, 105, 116 enlarge, 116 priority setting – enlarge, 116 priority setting – reduce, 117 ratio for create margin, 117 reduce, 116 R/E priority, 117 |
| Page Numbering, 77, 123 Page numbering colour, 78 | shortcut R/E, 116 Rotated copy, 37 |
| duplex back page stamping position, 123 first printing page, 78 font, 123 page numbering in combine, 123 position, 78 position and orientation of originals, 77 size, 123 stamp colour, 123 stamp format, 123 stamp position, 123 start number, 78 superimpose, 123 Pale, 34 Photo, 34 Placing custom size originals, 17 originals, 9, 13, 14, 15, 17 originals in auto document feeder, 15 originals on exposure glass, 14 | SADF, 16 Sample copy, 45 Sample copy key, 6 Sampling user colours, 94 Screen contrast knob, 5 Selecting colour mode, 29 copy paper, 35 original type, 34 Series copies, 60, 136 book → 1 sided, 60 book → 2 sided, 60 front & back → 2 sided, 60 # (sharp) key, 6 Single colour copy, 29 Sizes detectable by auto paper select, 11 difficult to detect, 12 of recommended originals, 9 |

| Sort, 43 | I |
|--|--|
| rotate sort, 43 | T1 24 |
| shift sort, 44 | Text, 34 |
| Specifications, 127 | Text/Photo, 34 |
| Stack, 46 | Tone – original remains, 114 |
| Stamp, 121 | Troubleshooting, 95 |
| colour, 121, 122, 123 | memory is full, 101 |
| date stamp, 75 | problems operating the machine, 95 |
| format, 121, 122, 123 | you cannot make clear copies, 97 |
| language, 121 | you cannot make copies as you want, 98 |
| page numbering, 77 | Two colour copy, 29 |
| position, 121, 122, 123 | two-sided combine |
| position and original orientation, 72,75 | 1 sided 16 pages \rightarrow combine 2 side, 59 |
| preset stamp, 70 | 1 sided 4 Pages \rightarrow combine 2 side, 58 |
| priority, 121 | 1 sided 8 pages \rightarrow combine 2 side, 58 |
| setting, 123 | 2 sided 16 pages → combine 2 side, 59 |
| user stamp,72 | 2 sided 4 pages \rightarrow combine 2 side, 59 |
| Standard orientation, 14 | 2 sided 8 pages → combine 2 side, 59 |
| Stapling position and original setting, 47 | Types of duplex copies, vi |
| Start key, 6 | U |
| Storing | <u> </u> |
| adjusted colour balance, 88 | User colour, 92 |
| data, 83 | User stamp, 72, 122 |
| program, 85 | changing colour, 73 |
| Superimpose, 123 | changing position, 73 |
| Supplementary informations | colours, 122 |
| bypass tray copy, 128 | delete, 74 |
| centring, 136 | format, 122 |
| combine, 135 | position, 122 |
| date stamp,137 | position, 122 position and original orientation, 72 |
| directional size magnification, 129 | program, 73 |
| duplex, 135 | program/delete, 122 |
| erase, 137 | User tools, 103 |
| front/back cover, 138 | User Tools/Counter key, 5 |
| front cover, 138 | Oser roots/ Counter key, 3 |
| image repeat, 136 | W |
| margin adjustment, 137 | |
| mixed size mode, 128 | Weights of recommended originals, 9 |
| page numbering, 138 | What you can do with this machine, iii, vi |
| preset enlarge/reduce, 128 | |
| preset stamp, 137 | |
| punch, 134 | |
| rotate sort, 130 | |
| series copies, 136 | |
| size magnification, 129 | |
| slip sheets, 138 | |
| sort, 130 | |
| stack, 130 | |
| staple, 132 | |
| zoom, 129 | |
| Supplementary specifications, 128 | |



Declaration of Conformity

"The Product complies with the requirements of the EMC Directive 89/336/EEC and its amending directives and the Low Voltage Directive 73/23/EEC and its amending directives."

In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- I means POWER ON.
- O means POWER OFF.
- (I) means STAND BY.

Trademark

Acrobat® is a registered trademark of Adobe Systems Incorporated.



RICOH COMPANY, LTD.

15-5, Minami Aoyama 1-chome, Minato-ku, Tokyo 107-8544, Japan

Phone: +81-3-3479-3111



U.S.A.

RICOH CORPORATION 5 Dedrick Place West Caldwell, New Jersey 07006 Phone: +1-973-882-2000

The Netherlands

RICOH EUROPE B.V. Groenelaan 3, 1186 AA, Amstelveen Phone: +31-(0)20-5474111

United Kingdom

RICOH UK LTD. Ricoh House, 1 Plane Tree Crescent, Feltham, Middlesex, TW13 7HG Phone: +44-(0)20-8261-4000

Germany

RICOH DEUTSCHLAND GmbH Mergenthalerallee 38-40, 65760 Eschborn Phone: +49-(0)6196-9060

France

RICOH FRANCE S.A. 383. Avenue du Général de Gaulle BP 307-92143 Clamart Cedex Phone: +33-(0)-821-01-74-26

Spain

RICOH ESPAÑA S.A. Avda. Litoral Mar, 12-14, Blue Building, Marina Village, 08005 Barcelona Phone: +34-(0)93-295-7600

Italy

RICOH ITALIA SpA Via della Metallurgia 12, 37139 Verona Phone: +39-045-8181500

China

RICOH CHINA CO.,LTD 29/F., Lippo Plaza, No.222 Huai Hai Zhong Road, Lu Wan District, Shanghai P.C.:200021 Phone: +86-21-5396-6888

Singapore

RICOH ASIA PACIFIC PTE.LTD. 260 Orchard Road, #15-01/02 The Heeren, Singapore 238855 Phone: +65-6830-5888

Printed in The Netherlands GB (GB) B149-7501

Printer/Scanner Unit Type 2238

Operating Instructions Printer Reference 1



- 1 Getting Started
- 2 Preparing to Print

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Warning

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Trademarks

Microsoft®, Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe®, PostScript®, Acrobat®, PageMaker® and Adobe Type Manager are registered trademarks of Adobe Systems Incorporated.

PCL® is a registered trademark of Hewlett-Packard Company.

AppleTalk, Apple, Macintosh and Mac are registered trademarks of Apple Computer, Incorporated.

IPS-PRINT™ Printer Language Emulation Copyright[©] 2000, Oak Technology, Inc., All Rights Reserved.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Bluetooth is a Trademark of the Bluetooth SIG, Inc. (Special Interest Group) and licensed to RICOH company limited.

Copyright © 2001 Bluetooth SIG, Inc.

The Bluetooth Trademarks are owned by Bluetooth SIG, Inc. USA

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

The proper names of the Windows operating systems are as follows:

- The product name of Windows® 95 is Microsoft® Windows® 95
- The product name of Windows® 98 is Microsoft® Windows® 98
- The product name of Windows[®] Me is Microsoft[®] Windows[®] Millennium Edition (Windows Me)
- The product name of Windows® 2000 are as follows:

Microsoft® Windows® 2000 Professional

Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Advanced Server

The product name of Windows® XP are as follows:

Microsoft® Windows® XP Home Edition

Microsoft® Windows® XP Professional

The product names of Windows Server[™] 2003 are as follows:

Microsoft® Windows Server™ 2003 Standard Edition

Microsoft® Windows Server™ 2003 Enterprise Edition

Microsoft® Windows Server™ 2003 Web Edition

• The product name of Windows NT® 4.0 are as follows:

Microsoft® Windows NT® Workstation 4.0

Microsoft® Windows NT® Server 4.0

Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

TABLE OF CONTENTS

| Manuals for This Machine | |
|---|----|
| How to Read This Manual | 3 |
| 1. Getting Started | |
| Control Panel | 5 |
| 2. Preparing to Print | |
| Preparing the Machine | |
| Connecting the Machine | |
| Setting Paper on the Bypass Tray | 12 |
| Installing the Software | 16 |
| Auto Run | 16 |
| Quick Install | |
| Installing the PCL 5c and RPCS™ Printer Driver | |
| Setting Up Options - PCL 5c and RPCS | |
| Installing the PostScript 3 Printer Driver | |
| Mac OS - Installing the PostScript 3 Printer Driver and Utilities | |
| Mac OS X - Installing the PostScript 3 Printer Driver | |
| Installing the Printer Driver Using USB | |
| Installing the Printer Driver Using IEEE 1394 | |
| Installing SmartNetMonitor for Client/Admin | |
| Installing Font Manager 2000 | |
| Using Adobe PageMaker Version 6.0, 6.5, or 7.0 | |
| Software and Utilities Included on the CD-ROM | |
| Printer Drivers | |
| Software and Utilities | 42 |
| INDEX | 44 |

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

Note

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1"Operating Instructions for Printer/Scanner"
 - CD-ROM 2"Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine.

It also describes System Settings(such as paper trays and user codes settings), Document Server functions, and troubleshooting.

Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference < Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference<Advanced Features>

Describes advanced functions and settings for key operators.

❖ Printer Reference 1 (this manual)

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

❖ Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview
 of its functions. This guide is added to the [Start] menu when DeskTop Binder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an
 overview of ScanRouter V2 Lite functions. This guide is added to the [Start]
 menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- UNIX Supplement (available from an authorized dealer, or as a PDF file on our Web site)

How to Read This Manual

Symbols

In this manual, the following symbols are used:

↑ WARNING:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

↑ CAUTION:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury, or damage to property.

* The statements above are notes for your safety.

∰Important

If this instruction is not followed, paper might misfeed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates prior knowledge or preparation is required before operation.

This symbol indicates precautions for operation, or actions to take after mal-operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys and buttons that appear on the computer's display.


Keys that appear on the machine's display panel.

Keys built into the machine's control panel.

Keys on the computer's keyboard.

1. Getting Started

Control Panel



1. Indicators

Displays errors and machine status.

- : Service call indicator
- **%**: Misfeed indicator
- ☐ Open Cover indicator
- **≜**: Add Staple indicator
- : Add Toner indicator
- **!**: Load Paper indicator

See "Control Panel", General Settings Guide.

2. [User Tools/Counter] key

- User Tools
 Press to change default settings and
 conditions to your requirements.
- Counter
 Press to display or print the total number of copies made.

3. Display panel

Displays operation status, error messages, and function menus. See p.7 "Display Panel".

4. [Energy Saver] key

Press to switch to and from Energy Saver mode.

Note

☐ This key is ineffective during System Settings (User Tools) operations.

5. Main power indicator

This indicator lights when the main power switch is turned on.

#Important

Do not turn off the main power switch while the Power indicator is lit or blinking. Doing so may damage the hard disk.

6. Power indicator

This indicator lights when the operation switch is turned on.

7. Operation switch

Press this switch to turn the power on (the Power indicator goes on). To turn the power off, press this switch again (the Power indicator goes off).

8. [Clear/Stop] key

Press to cancel the entered data.

9. [#] key

Press after entering a value.

10. Number keys

Press to enter a value for various settings.

11. Function keys

Press to switch between the "Copy", "Document Server", "Facsimile", "Printer", and "Scanner" screens.

The indicator for the selected function lights.

12. Function status indicators

These show the status of the above functions:

- Green: the function is active.
- Red: the function has been interrupted.

13. Data In indicator

The Data In indicator shows the status of data reception from a computer.


- Blinks when data is being received.
- Lights when there is data remaining to be printed.

Display Panel

This section describes configuration using the display panel when the printer function is selected.

∰Important

- ☐ The machine switches to offline when you make settings when the machine is online. After you complete the setting, the machine switches to online automatically.
- ☐ If you make a setting when the machine is offline, it will stay offline afterward.
- ☐ The function items displayed serve as selector keys. You can select or specify an item by pressing it lightly.
- ☐ When you select or specify an item on the display panel, it becomes highlighted.
- ☐ Keys dimmed (for example, ○K) cannot be used.



1. Operational status or messages

Displays current machine status, such as "Ready", "Offline", and "Printing". Information about the print job (user ID and document name) appears in this section.

2. [→ Online] key/[]++Offline] key

When you press these keys, the machine switches between online and offline.

When the machine is online, it can receive data from the computer.

When the machine is offline, it cannot receive data from the computer.

3. [Form Feed] key

Press to print all the data left in the machine's input buffer.

Note

- ☐ When the machine is online, the status appears dimly.
- ☐ This function is not available with the RPCSTM printer language.

4. [Job Reset] key

Press to cancel the current print job.

If you press it when the machine is offline and Hex Dump is selected, Hex Dump is canceled. See "Printer Features Parameters", *Printer Reference* 2.

5. [Locked & Sample Print Job List]

Press to display Locked/Sample Print jobs sent from a computer.

6. [Error Log]

Press to display the error logs of Locked/Sample Print jobs sent from a computer.

7. [Spooling Job List]

Press to display spooled jobs.

8. [▶Paper Tray Status] key

The paper tray settings appear.

Ø Note

- □ When the power is turned on, the copier display is shown. This is a factory default. This initial setting can be changed. See "User Tools (System Settings)", General Settings Guide.
- ☐ If the machine cannot be switched offline, select [Printer] for [Print Priority] on [General Features] in the System Settings. For details about the setting, see "User Tools (System Settings)", General Settings Guide.

2. Preparing to Print

This section gives instructions for connecting the machine and computer, configuring the machine, and installing software.

When operating the machine with a parallel connection, USB connection, or IEEE 1394 (SCSI print) connection

 Connect the machine and computer using a parallel cable, a USB cable, or an IEEE 1394 (SCSI print) cable.

For more information, see p.10 "Connecting the Machine".

• Install a printer driver from the CD-ROM.

₽ Reference

For more information, see p.16 "Installing the Software".

Note

□ "Network environment" describes a situation where the machine is connected to a computer via Ethernet, wireless LAN, or IEEE 1394 (IP over 1394).

When operating the machine under a network environment

• Configure the network using the machine's control panel.

₽ Reference

For more information, see "Network Configuration", Network Guide.

• Install a printer driver and other utilities from the CD-ROM.

₽ Reference

For more information, see p.16 "Installing the Software".

Note

☐ The optional IEEE 802.11b interface unit, IEEE 1394 interface board, the USB 2.0 interface board, and the Bluetooth interface unit cannot be installed in the machine at the same time.

Preparing the Machine

Connecting the Machine

For information about connection using Ethernet and wireless LAN, see "Confirming the Connection", Network Guide.

For information about connection using BluetoothTM, see the manual that comes with the optional Bluetooth interface unit.

Requirements

Before using this machine, make sure all environmental and electrical requirements are met. Connect the machine to the host computer using the parallel port, network interface unit, or both.

Make sure all cables, connectors, and electrical outlets necessary to attach the machine to the host computer or network are at hand.

Connecting the Machine to the host using the parallel cable/IEEE 1394 (SCSI print) cable

Connect the machine to the host computer using the parallel port or optional IEEE 1394 interface board. This machine does not come with a parallel cable to connect the machine to the host computer.

The machine's parallel interface is a standard bidirectional interface. It requires a standard IEEE 1284 compliant 36-pin parallel cable and a parallel port on the host computer. Make sure you purchase the appropriate cable for the machine and your computer.

Note

- ☐ Do not use a parallel cable that is longer than 3 meters (10 feet).
- ☐ Rating voltage of the interface connector: Max. DC 5V

Follow the procedure below to connect the machine to the host computer using a parallel cable or IEEE 1394 interface cable.


#Important

- ☐ Before connecting the machine and a computer using an interface cable, make sure the machine is not operating, and then turn off the main power switches of the machine and computer.
- ☐ Be sure to use a specified interface cable. Other cables may cause radio interference.
- 1 Turn off the main power switches of the machine and computer.


∰Important

- ☐ Before turning off the main power switch, see "Turning Off the Power", General Settings Guide.
- 2 Plug the cable into the connector on the machine's interface.

Parallel Connection



♦ IEEE 1394 (SCSI print) Connection



- Plug the other end of the cable into the connector on the computer's interface.
- 4 Turn on the machine's main power switch.
- **5** Turn on the computer.

𝒯 Note

□ When using Windows 95/98/Me/2000/XP and Windows Server 2003, a printer driver installation screen might appear when the computer is turned on. If this happens, click [Cancel] on the screen. For more information, see p.16 "Auto Run".

The machine and computer are now connected. The printer driver must be installed next. For information about how to install the printer driver, see p.16 "Installing the Software".


Connecting the machine to the host using a USB cable

You can connect the machine to the host computer using a USB interface cable when the optional USB 2.0 interface board is installed in the machine.

This machine does not come with a USB interface cable. Make sure you purchase the appropriate cable for the machine and your computer.

Follow the procedure below to connect the machine to the host computer using a USB interface cable.

1 Connect the USB 2.0 interface cable to the USB port on the right side of the machine's back cover.



Connect the other end to the USB port on the host computer.

- ☐ The optional USB 2.0 interface board is supported by Windows 98 SE/Me/2000/XP, Windows Server 2003, Mac OS 9.x, and Mac OS X Classic mode.
 - For Windows 98 SE/Me: Make sure to install "USB Printing Support". If USB 2.0 is used with Windows 98 SE/Me, only a speed equal to that of USB 1.1 is possible.
 - For Mac OS: Mac OS supports only the standard USB port. If USB 2.0 is used with a Mac OS, only a speed equal to that of USB 1.1 is possible.

Setting Paper on the Bypass Tray

This section gives instructions for setting paper on the bypass tray. Use the bypass tray to print onto OHP transparencies, labels, thick paper, and envelopes that cannot be loaded in the paper tray.

₽ Reference

For details about setting paper in the regular paper tray, see *General Settings Guide*.

Ø Note

- When loading letterhead paper, pay attention to its orientation. See "Orientation-Fixed Paper or Two-Sided Paper", General Settings Guide.
- ☐ Paper within the following dimensions can be set in the bypass tray:
 - Vertical: 90.0-305.0 mm (3.54 in-12.01 in.)
 - Horizontal: 148.0-600.0 mm (5.83 in.-23.62 in.)
- Be sure to set the paper with the side you want to print facing down in the bypass tray.
- When loading OHP transparencies or thick paper in the bypass tray, make the paper setting using the control panel or printer driver.
- ☐ The number of sheets that can be loaded in the bypass tray depends on the paper type.


Limitation

- ☐ The following functions are disabled when printing from the bypass tray:
 - · Duplex printing
 - · Auto Tray Select
 - Auto Tray Switching
 - Rotating Collate
 - Staple (when the optional unit is installed)
 - Punch (when the optional unit is installed)

#Important

- □ When printing using the printer function, original images are always rotated by 180 degrees (the orientation of images to be printed is opposite to that of the copier function). When printing onto paper with specific orientation requirements, such as envelopes and letterheads, make sure to rotate the paper feed orientation to 180 degrees.
- ☐ Be sure to set the paper size using the printer driver when printing data from the computer. The paper size set using the printer driver has priority over the one set using the display panel.


1 Open the bypass tray.



Adjust the paper guides to the paper size.

#Important

- If the paper guides are not flush against the paper, skewed images or paper misfeeds might occur.
- Gently insert paper face up into the bypass tray until the beeper sounds.



ZKRH010.

1. Extender

2. Paper guides

𝒯 Note

- ☐ The beeper will not sound if it is turned off. Gently insert paper until it stops.
- ☐ Do not stack paper over the limit mark, otherwise a skewed image or misfeeds might occur.
- □ Open out the extender to support paper sizes larger than A4
 □ , 8¹/₂"×11" □.
- ☐ Fan the paper to get air between the sheets to avoid a multi-sheet feed.
- When setting an OHP transparency, make sure that its front and back sides are properly positioned.

☐ Select paper type when printing onto OHP transparencies or thick paper (over 105g/m²). For details, see p.15 "Setting thick paper or OHP transparencies".

4 Select the paper size.


Note

- ☐ You can set paper size using the printer driver. The following procedures are not necessary when setting paper size using the printer driver.
- ☐ The paper size set using the printer driver has priority over that set using the display panel.
- ☐ When the printer driver is not used, make settings using the display panel.
- Thick paper and OHP transparencies are delivered to the external tray.
- ☐ Thick paper and OHP transparencies are delivered face up on the top of the preceding page; therefore, the prints need to be rearranged into the correct order. To avoid this, select [Reverse order print] in the RPCS printer driver settings to deliver the prints in the correct page order.


For printer driver settings, see the printer driver Help.

For details about setting custom sizes, see p.14 "Setting custom size paper".

• Press the [User Tools/Counter] key on the control panel.



- 2 Press [Printer Features].
- 3 Press the [Paper Input] tab.



- 4 Press [Bypass Paper Size].
- **6** Select the paper size.
 - **∅** Note
 - ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - ☐ When printing onto thick paper or OHP transparencies, select paper type. For details, see p.15 "Setting thick paper or OHP transparencies".
- 6 Press [OK].
- Press the [User Tools/Counter] key.

Setting custom size paper

Note

- ☐ Custom sizes can also be set using the printer driver. The following procedures are not necessary when setting custom sizes using the printer driver.
- Custom size settings set using the printer driver have priority over those set using the machine's display panel.
- ☐ When the printer driver is not used, make settings using the display panel.

For printer driver settings, see the printer driver Help.

- 1 Press the [User Tools/Counter] key on the control panel.
- 2 Press [Printer Features].
- Press the [Paper Input] tab.
- 4 Press [Bypass Paper Size].
- Press [Custom Size].
- 6 Enter the vertical size of the paper using the number keys, and then press [#].



- Enter the horizontal size of the paper using the number keys, and then press [#].
- 8 Press [OK].

The paper sizes entered are displayed.

9 Press the [User Tools/Counter] key.

Setting thick paper or OHP transparencies

Note

- ☐ Paper settings can also be set using the printer driver. The following procedures are not necessary when setting paper sizes using the printer driver.
- Paper size settings set using the printer driver have priority over those set using the machine's display panel.
- ☐ When the printer driver is not used, make settings using the display panel.

For printer driver settings, see the printer driver Help.

- Press the [User Tools/Counter] key on the control panel.
- 2 Press [System Settings].
- 3 Press the [Tray Paper Settings] tab.
- Press [▼Next.] to scroll through the list.
- **5** Press [Paper Type: Bypass tray].



- 6 Select [OHP] or [Thick Paper]
- **7** Press [OK].

The paper type selected is displayed.

8 Press the [User Tools/Counter] key.

Note

☐ The settings made will remain valid until they are reset again. After printing on OHP transparencies or thick paper, make sure to clear settings for the next user.

Installing the Software

This manual assumes you are familiar with general Windows procedures and practices. If you are not, see the operating instructions that come with Windows for details.

The procedure for installing the printer driver depends on the connection with the computer. With a parallel or Ethernet connection, Quick Install is also available. With a wireless LAN connection, check the machine and computer are communicating properly and then install the printer driver by following the procedure used for an Ethernet connection.

- For details about the parallel/Ethernet connection, see p.17 "Quick Install" or p.19 "Installing the PCL 5c and RPCS™ Printer Driver".
- For details about the USB connection, see p.33 "Installing the Printer Driver Using USB".
- For details about the IEEE 1394 connection, see p.35 "Installing the Printer Driver Using IEEE 1394".

Auto Run

Inserting the CD-ROM into the CD-ROM drive starts the installer automatically. The installer helps you install the following printer drivers and software easily.

𝚱 Note

- ☐ If "plug and play" starts, click [Cancel] in [New Hardware Found], [Device Driver Wizard] or [Found New Hardware Wizard] dialog box, and then insert the CD-ROM. The [New Hardware Found], [Device Driver Wizard] or [Found New Hardware Wizard] dialog box appears depending on the system version of the Windows 95/98/Me/2000/XP, Windows Server 2003, or Windows NT 4.0.
- ☐ Auto Run might not work automatically with certain operating system settings. If this happens, launch "Setup.exe", located on the CD-ROM root directory.
- ☐ If you want to cancel Auto Run, hold down the 【SHIFT】 key (if your operating system is Windows 2000/XP and Windows Server 2003, hold down the left 【SHIFT】 key) while inserting the CD-ROM. Keep the 【SHIFT】 key held down until the computer has finished accessing the CD-ROM.

Limitation

☐ If your operating system is Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, installing software using Auto Run requires Administrator permission. When you install software using Auto Run, log on using an account that has Administrators permission.

The following table shows the printer drivers and software that can be installed using Auto Run:

| | Auto Run *1 | | |
|---|---|-----------------------------|-------------------------------------|
| | Quick Install | | Add |
| | Network connec- tion with TCP/IP | Parallel connec- tion | Printer and Utility Wizard |
| PCL 5c printer driver | 0 | 0 | 0 |
| RPCS TM printer driver | 0 | 0 | 0 |
| Post- Script 3 printer driver | | | 0 |
| LAN-Fax Driver | | | 0 |
| Font Manager 2000 | | | 0 |
| Smart- NetMoni- tor for Admin | | | О |
| Smart- NetMoni- tor for Client | 0 | | О |

Available operating systems are: Windows 95/98/Me/2000/XP, Windows Server 2003, Windows NT 4.0. Auto Run is unavailable with Mac OS.

Quick Install

Auto Run will start the installer automatically when you insert the CD-ROM into the CD-ROM drive. By selecting Quick Install, you can easily install the PCL 5c printer driver and the RPCS™ printer driver. SmartNet-Monitor for Client can also be installed provided the machine and computer are connected via the network.

Preparation

Before starting installation, close all documents and applications.

Limitation

- ☐ The following conditions are required:
 - Windows 95/98/Me/2000/XP, Windows Server 2003, or Windows NT 4.0

For Ethernet connections:

- The machine must be connected to the network using an Ethernet cable
- TCP/IP protocol must be configured.
- The IP address must be assigned to both machine and computer.
- The IEEE 802.11b interface unit is installed and the connection is properly made.
- The IEEE 1394 interface board (IP over 1394) is installed and the connection is properly made.

For parallel connections:

- The machine must be connected to the computer using a parallel cable.
- Bidirectional transmission must be enabled.

#Important

□ If your system is Windows NT 4.0, we recommend that you upgrade the Windows NT 4.0 operating system to Service Pack 4 or later before installing the PCL 5c or RPCSTM printer drivers. Contact your Windows retailer for more information about latest versions.

Note

- □ When the machine is connected to the computer using the IEEE 1394 interface or the USB 2.0 interface, Quick Install cannot be used. See p.33 "Installing the Printer Driver Using USB", p.35 "Installing the Printer Driver Using IEEE 1394".
- 1 Quit all applications running.
- Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish) The default interface language is

4 Click [Quick Install].

English.

The software license agreement appears in the [License Agreement] dialog box.

- After reading through the agreement, click [I accept the agreement] to agree, and then click [Next].
- Click the machine model you are using when the [Select Printer] dialog box appears.

- For TCP/IP network connection, select the machine whose IP address is displayed in the [Connect To] column.
- ☐ For parallel connection, select the machine whose printer port is displayed in the [Connect To] column.
- 7 Click [Install].
- Follow the instructions on the screen.

A message prompting you to restart your computer may appear. To complete installation, restart your computer.

#Important

☐ If the machine has options installed, you should make settings for them using the printer driver. See p.23 "Setting Up Options - PCL 5c and RPCS".

- ☐ If you want to change the printer name, follow the procedure below:
 - Windows 95/98/Me/2000, Windows NT 4.0
 On the [Start] menu, point to [Settings], and then click [Printers]. The [Printers] window appears. Right-click the machine icon, and then click [Rename].

- Windows XP Professional, Windows Server 2003
 On the [Start] menu, click [Printers and Faxes]. The [Printers and Faxes] window appears. Right-click the machine icon, and then click [Rename].
- Windows XP Home Edition
 On the [Start] menu,
 click[Control Panel]. Click
 [Printers and Other Hardware],
 and then click [Printers and
 Faxes]. The [Printers and Faxes] window appears. Right click the machine icon, and
 then click [Rename].

Installing the PCL 5c and RPCS™ Printer Driver

This section gives basic instructions for installing the PCL 5c printer driver and RPCSTM printer driver without using Quick Install. Follow the procedures below, as appropriate.

See p.17 "Quick Install" to install the PCL 5c printer driver or RPCSTM printer driver using Quick Install.

Limitation

☐ If your operating system is Windows 2000/XP, Windows Server 2003 or Windows NT 4.0, installing a printer driver using Auto Run requires Administrator permission. When you install a printer driver using Auto Run, log on using an account that has Administrator permission.

#Important

☐ If your operating system is Windows NT 4.0, we recommend that you upgrade the Windows NT 4.0 operating system to Service Pack 4 or later before installing the printer drivers. Contact your Windows retailer for more information about latest versions.

- ☐ If you want to share the machine on a Windows 2000/XP, Windows Server 2003, or Windows NT 4.0 platform, use the [Sharing] tab in the printer properties dialog box to specify the additional driver (alternate driver). For details, see the operating instructions that come with Windows 2000/XP, Windows Server 2003, or Windows NT 4.0.
- When prompted for the additional driver (alternate driver) location, select the following folders on the CD-ROM:
 - Windows 95/98/Me
 PCL 5c: \DRIVERS\PCL5c\
 WIN9X_ME\(Language)\DISK1\
 RPCSTM: \DRIVERS\RPCS\
 WIN9X_ME\(Language)\DISK1\
 - Windows 2000/XP, Windows Server 2003
 PCL 5c: \DRIVERS\PCL5c\ WIN2K_XP\(Language)\DISK1\ RPCSTM: \DRIVERS\RPCS\ WIN2K_XP\(Language)\DISK1\
 - Windows NT 4.0
 PCL 5c: \DRIVERS\PCL5c\
 NT4\(Language)\DISK1\
 RPCSTM: \DRIVERS\RPCS\
 NT4\(Language)\DISK1\

- 1 Quit all applications running.
- Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish) The default interface language is English.

4 Click [PCL/RPCS Printer Drivers].

The software license agreement appears in the [License Agreement] dialog box.

- After reading through the agreement, click [I accept the agreement] to agree, and then click [Next].
- 6 Select the printer drivers you want to install when the [Select Program] dialog box appears, and then click [Next].
- Select the model of the machine you are using.

To change the printer name, change it in the [Change settings for 'Printer Name'] box.

B Double-click the machine name to display the printer settings.

9 Select SmartNetMonitor.

SmartNetMonitor

- ① Click [Port:], and then click [Add].
- 2 Click [SmartNetMonitor], and then click [OK].
- **3** Select the machine you want to use.

◆ TCP/IP

- Click [TCP/IP], and then click [Search].
 Available machines will be listed.
- ② Select the machine you want to use, and then click [OK].

- ☐ Machines that respond to an IP broadcast from the computer will be displayed. To print to a machine not listed here, click [Specify Address], and then enter the IP address or host name.
- □ Under Windows 95/98/Me, avoid using an address that is partially similar to one already in use. For example, if "192.168.0.2" is already used, "192.168.0.2xx" cannot be used. Similarly, if "192.168.0.20" is already used, "192.168.0.2" cannot be used.

NetBEUI

- Click [NetBEUI], and then click [Search].
 A list of machines that can be used with NetBEUI appears.
- ② Select the machine you want to use, and then click [OK].

Note

- ☐ NetBEUI cannot be used under Windows XP and Windows Server 2003.
- ☐ Machines that respond to a broadcast from the computer will be displayed. To print to a machine not listed here, click [Specify Address], and then enter the NetBEUI address. Confirm the NetBEUI address on the network is on the configuration page. For more information about printing the configuration page, see "Printer Features Parameters". Printer Reference 2. The NetBEUI address appears as "\\RNPxxxx\xxx" on the configuration page. Enter the machine's network path name in the form of "%%Computer name\Share name". Do not enter "\\" but "%%" as head characters.
- ☐ You cannot print to machines beyond routers.

◆ IPP

- Click [IPP].
 The IPP setting dialog box appears.
- ② To specify the IP address of the machine, enter "http://machine's-ipaddress/printer" or "ipp://machine's-ip-address/printer" in the [Printer URL] box.

(Example: IP address is 192.168.15.16)

http://192.168.15.16/ printer ipp://192.168.15.16/ printer

- ③ If necessary, enter the names to distinguish the machine in the [IPP Port Name] box. Enter a different name to those of any existing port name. If you do not do this, the address entered in the [Printer URL] box will be set as the IPP port name.
- ④ If a proxy server and IPP user name are used, click [Detailed Settings], and then configure the necessary settings.

- ☐ For more information about these settings, see SmartNetMonitor for Client Help.
- ⑤ Click [OK].
- Make sure the location for the selected machine appears after [Port:].
- 11 Configure the user code and default printer as necessary.

User Code

User codes are eight digit codes that allow you to keep track of printing done under each code. To use this feature, the network administrator should assign user codes and inform users of them before they install the printer driver.

Use the following methods to enter a user code for registra-

- For the PCL 5c or PostScript 3 printer drivers, enter the user code on the [Statistics] tab in the printer properties dialog box.
- For the RPCSTM printer driver, click the [Printer Configuration] button on the [Print Settings] tab in the printer properties dialog box. Click the [User Code] button. A dialog box appears. Enter the user code in the dialog box.

Note

□ When using the RPCSTM printer driver on Windows 95/98/Me, the user code cannot be changed once it is entered. To change an entered user code, uninstall the printer driver, reinstall it, and then enter a new user code.

₽ Reference

For more information about user codes, see "User Codes", General Settings Guide.

Default Printer

Select the **[Default Printer]** check box to set the printer as the default printer.

- Click [Continue] to start printer driver installation.
- Follow the instructions on the screen.

Changing port settings

Follow these steps to change Smart-NetMonitor for Client settings, such as the proxy server settings or IPP URL.

- ☐ There are no settings for NetBEUI.
- In the [Printers] window, click the icon of the machine you want to use. On the [File] menu, click [Properties].

Note

- □ Under Windows XP and Windows Server 2003, click the icon of the machine you want to use in the [Printers and Faxes] window.
- 2 Click the [Details] tab, and then click [Port Settings].

The **[Port Settings]** dialog box appears.

Note

- ☐ Under Windows 2000/XP and Windows Server 2003, Windows NT 4.0 click the [Ports] tab, and then click [Configure Port]. The [Port Configuration] dialog box appears.
- For TCP/IP, you can configure Timeout Settings.

Note

☐ If you cannot set the items on the [Recovery/Parallel Printing] tab, follow the procedure below.

- ① Click [Cancel] to close the [Port Settings] dialog box.
- ② Start SmartNetMonitor for Client, and then right-click the SmartNetMonitor for Client icon on the taskbar.
- ③ Click [Extended Features Settings], and then select the [Set Recovery/Parallel Printing for each port] check box.
- 4 Click [OK] to close the [Extended Features Settings] dialog box.
- For IPP, you can configure IPP User Settings, Proxy Settings and Timeout Settings.

Note

☐ For more information about these settings, see SmartNet-Monitor for Client Help.

Setting Up Options - PCL 5c and RPCS

If the machine has options installed, you should set the options using the printer driver.

Limitation

☐ Under Windows 2000/XP and Windows Server 2003, changing printer settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.

☐ Under Windows NT 4.0, changing printer settings requires Full Control permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you set up options, log on using an account that has Full Control permission.

When setting up options, you should access the printer properties dialog box from Windows. You cannot set up options by accessing the printer properties dialog box from an application.

PCL 5c printer driver

1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- ☐ If using Windows XP Professional and Windows Server 2003, click the [Printers and Faxes] window on the [Start] menu.
- ☐ If using Windows XP Home Edition, access the [Printers and Faxes] window by clicking the [Start] button on the taskbar, click [Control Panel], click [Printers and Other Hardware], and then click [Printers and Faxes].
- 2 Click the icon of the machine you want to use.
- On the [File] menu, click [Properties].

 The printer properties dialog box appears.
- 4 Click the [Accessories] tab.
- **5** Select the options installed in the [Options] area.
- 6 Click [OK].

RPCS™ printer driver

1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

𝚱 Note

- ☐ If using Windows XP Professional and Windows Server 2003, click the [Printers and Faxes] window on the [Start] menu.
- ☐ If using Windows XP Home Edition, access the [Printers and Faxes] window by clicking the [Start] button on the taskbar, click [Control Panel], click [Printers and Other Hardware], and then click [Printers and Faxes].
- 2 Click the icon of the machine you want to use.
- 3 On the [File] menu, click [Properties].

 The printer properties dialog box appears.

- ☐ If the following message appears "Configure installed accessories in the [Accessories] tab of [Printer Configuration], which will open next.", click [OK], and then proceed to step [5].
- 4 Click the [Change Accessories] tab.

Note

- ☐ In Windows 95/98/Me, click [Printer Configuration] on the [Print Settings] tab, and then click [Change Accessories].
- Select the options installed in the [Select printer options:] list.
- 6 Click [OK].
- Click [OK], and then close the printer properties dialog box.

Installing the PostScript 3 Printer Driver

This section gives basic instructions for installing the PostScript 3 printer driver. Actual procedures may differ depending on the operating system. Follow the procedures below, as appropriate.

₽ Reference

To use the PostScript 3 printer driver, the optional PostScript 3 board must be installed on the machine. See *PostScript 3 Unit Type 2238 Operating Instructions Supplement* for details.

Windows 95/98/Me - Installing the PostScript 3 printer driver

- 1 Quit all applications running.
- 2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish)

The default interface language is English.

- ☐ The printer driver with the selected language will be installed.
- ☐ The printer driver will be installed in English if you select the following languages: Cestina, Magyar, Polski, Portugues, Suomi, Korean and Russian.
- 4 Click [PostScript 3 Printer Driver].
 Add Printer Wizard starts.
- 5 Click [Next].
- Click [Local Printer], and then click [Next].

A dialog box for selecting the printer appears.

- Select the model of the machine you are using, and then click [Next].
- In the [Available ports:] box, click [Printer Port], and then click [Next].
- Ochange the name of the machine if you want to, and then click [Next].

- ☐ Click **[Yes]** if you want to set the machine as the default printer.
- Follow the instructions on the screen.

Windows 95/98/Me - Setting up options

If the machine has options installed, you should make settings for them using the printer driver.

- On the [Start] menu, point to [Settings], and then click [Printers].
 - The [Printers] window appears.
- Click the icon of the machine you want to use.
- On the [File] menu, click [Properties].

 The printer properties dialog box appears.
- 4 Click the [Accessories] tab.
- Select the options you have installed in the [Options] area.
- 6 Click [OK].

Windows 2000/XP, Windows Server 2003
- Installing the PostScript 3 printer driver

Limitation

☐ Installing a printer driver requires Administrator permission. When you install a printer driver, log on using an account that has Administrator permission.

Note

☐ If you want to share the machine on a Windows 2000/XP and Windows Server 2003 platform, use the [Sharing] tab in the printer properties dialog box to specify the additional driver (alternate driver). For details, see the operating instructions that come with Windows 2000/XP and Windows Server 2003.

- When prompted for the additional driver (alternate driver) location, select the following folders on the CD-ROM:
 - Windows 95/98/Me: \DRIVERS\PS\ WIN9X_ME\(Language)\DISK1\
 - Windows NT 4.0: \DRIVERS\PS\ NT4\(Language)\DISK1\
- 1 Quit all applications that are running.
- 2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish)

The default interface language is English.

𝒯 Note

- ☐ The printer driver with the selected language will be installed.
- ☐ The printer driver will be installed in English if you select the following languages: Cestina, Magyar, Polski, Portugues, Suomi, Korean and Russian.
- 4 Click [PostScript 3 Printer Driver].
 Add Printer Wizard starts.
- 5 Click [Next].

6 Click [Local Printer], and then click [Next].

Note

☐ If using Windows XP and Windows Server 2003, click [Local printer attached to this computer], and then click [Next].

A dialog box for selecting the printer port appears.

Select the check box of the port you want to use, and then click [Next].

A dialog box for selecting the printer appears.

- Select the model of the machine you are using, and then click [Next].
- Change the name of the machine if you want to, and then click [Next].

Note

- ☐ Click **[Yes]** if you want to set the machine as the default printer.
- Select whether or not you want to share the machine, and then click [Next].

See *Network Guide* for information about setting up and using the machine in a network environment.

11 Follow the instructions on the screen.

Windows 2000/XP, Windows Server 2003 - Setting up options

If the machine has options installed, you should make settings for them using the printer driver.

Limitation

- ☐ Changing the printer settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

𝚱 Note

- ☐ In Windows XP Professional and Windows Server 2003, click the [Printers and Faxes] window on the [Start] menu.
- ☐ In Windows XP Home Edition, access the [Printers and Faxes] window by clicking the [Start] button on the taskbar, click [Control Panel], [Printers and Other Hardware], and then click [Printers and Faxes].
- 2 Click the icon of the machine you want to use.
- On the [File] menu, click [Properties].

 The printer properties dialog box appears.
- 4 Click the [Device Settings] tab.
- Select the options you have installed under [Installable Options].
- 6 Click [OK].

Windows NT 4.0 - Installing the PostScript 3 printer driver

Limitation

☐ Installing a printer driver requires Administrator permission. When you install a printer driver, log on using an account that has Administrator permission.

∰Important

- ☐ The CD-ROM containing Windows NT Server operating system version 4.0, or the Windows NT Workstation operating system is required to install the printer driver.
- □ We recommend that you upgrade Windows NT 4.0 operating system to Service Pack 6 or later before installing the printer driver. Contact your Windows retailer for more information about latest versions.

Note

- ☐ If you want to share the machine on a Windows NT 4.0 platform, use the [Sharing] tab in the printer properties dialog box to specify the additional driver (alternate driver). For details, see the operating instructions that come with Windows NT 4.0.
- When prompted for the additional driver (alternate driver) location, select the following folders on the CD-ROM:
 - Windows NT 4.0: \DRIVERS\ PS\NT4\(Language)\DISK1\
- 1 Quit all applications running.
- 2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish) The default interface language is

English. Note

- ☐ The printer driver with the selected language will be installed.
- ☐ The printer driver will be installed in English if you select the following languages: Cestina, Magyar, Polski, Portugues, Suomi, Korean and Russian.
- 4 Click [PostScript 3 Printer Driver].

Add Printer Wizard starts.

Confirm that the [My Computer] option is selected, and then click [Next].

A dialog box for selecting the printer port appears.

6 Select the check box of the port you want to use, and then click [Next].

A dialog box for selecting the printer appears.

- Select the model of the machine you are using, and then click [Next].
- Change the name of the machine if you want to, and then click [Next].

Note

- ☐ Click **[Yes]** if you want to set the machine as the default printer.
- 9 Select whether or not you want to share the machine, and then click [Next].

₽ Reference

See *Network Guide* for information about setting up and using the machine in a network environment.

Follow the instructions on the screen.

Windows NT 4.0 - Setting up options

If the machine has options installed, you should make settings for them using the printer driver.

Limitation

- ☐ Changing printer settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

- 2 Click the icon of the machine you want to use.
- On the [File] menu, click [Properties].

 The printer properties dialog box appears.
- 4 Click the [Device Settings] tab.
- Select the options you have installed under [Installable Options].
- 6 Click [OK].

Bidirectional transmission

When bidirectional transmission is enabled, information such as paper size and feed orientation is automatically sent to the computer. You can also check machine status from your computer.

- Bidirectional transmission is supported under Windows 95/98/Me, Windows 2000/XP, Windows Server 2003, and Windows NT 4.0.
- When bidirectional transmission is running, machine status and information can be viewed by opening the printer driver screen.

To support bidirectional transmission, the following conditions are required:

When connecting with a parallel cable

- The computer must support bidirectional transmission.
- The machine must be set to bidirectional transmission.
- The machine parallel port and computer parallel port must be connected using a parallel interface cable that supports bidirectional transmission.

- □ In Windows 95/98/Me, [Enable bi-directional support for this printer] must be selected in [Spool Settings] on the [Details] tab in RPCSTM printer driver.
- ☐ In Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Ports] tab in RPCS™ printer driver.

When connecting with the network

- The machine must be set to bidirectional transmission.
- SmartNetMonitor for Client included on the CD-ROM must be installed.

One of the following conditions must also be satisfied as well as the two requirements mentioned above:

- The port for SmartNetMonitor and TCP/IP must be used.
- The standard TCP/IP port is used without changing the port name (Windows 2000/XP, Windows Server 2003).
- The IP address specified in the Microsoft TCP/IP Print is used (Windows NT 4.0).
- The IP address is included in port name, if using IPP protocol.

Note

- ☐ In Windows 95/98/Me, [Enable bi-directional support for this printer] must be selected in [Spool Settings] on the [Details] tab in RPCSTM printer driver.
- ☐ In Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Ports] tab in RPCSTM printer driver.

♦ When connecting with IEEE 1394

 The port on the optional IEEE 1394 interface board and the IEEE 1394 port on the computer are connected using an interface cable (Windows Me/2000/XP, Windows Server 2003).

Note

- ☐ [SCSI print (SBP-2)] must be set to Active and [Bidirectional SCSI print] must be set to ON in [IEEE 1394] on the [Interface Settings] tab in the machine's System Settings.
- □ In Windows Me, [Enable bi-directional support for this printer] must be selected in [Spool Settings] on the [Details] tab in RPCSTM printer driver.
- □ In Windows 2000/XP and Windows Server 2003, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Ports] tab in RPCSTM printer driver.

♦ When connecting with USB 2.0

The port on the optional USB 2.0 interface board and the USB port on the computer are connected using a USB interface cable (Windows 98 SE/Me/2000/XP, Windows Server 2003).

Note

- □ In Windows 98 SE/Me, [Enable bi-directional support for this printer] must be selected in [Spool Settings] on the [Details] tab in RPCSTM printer driver.
- □ In Windows 2000/XP and Windows Server 2003, [Enable bidirectional support] must be selected, and [Enable printer pooling] must not be selected on the [Ports] tab in RPCSTM printer driver.

Mac OS - Installing the PostScript 3 Printer Driver and Utilities

It is necessary to install a printer driver and a PPD file to print from a Mac OS.

Follow this procedure to install a printer driver and a PPD file on Mac OS running OS 8.6 or later versions up to 9.2, and Mac OS X Classic mode.

Note

- ☐ For installation under Mac OS X (v10.1.x), see p.32 "Mac OS X Installing the PostScript 3 Printer Driver".
- Insert the CD-ROM into the CD-ROM drive.
- 2 Double-click the CD-ROM icon.
- Double-click the [Mac OS 8 and 9] folder.
- 4 Double-click the [PS Driver] folder.
- Double-click the folder of the language you use.
- Open [Disk 1], and then doubleclick the installer icon.

The PostScript 3 printer driver installer window appears.

- **7** Follow the instructions on the screen.
- B Double-click [Extensions] in [System Folder].
- 9 Double-click [Printer Descriptions].
- Double-click the CD-ROM icon on the desktop.

- Double-click the [Printer Descriptions] folder in the [Mac OS 8 and 9] folder.
- Double-click [Disk 1] in the folder of the language you use.
- Drag the PPD file and Plug-in file into [Printer Descriptions] in [Extensions] in [System Folder].
- 11 Restart the Mac OS.

Setting up the PPD file

Preparation

Make sure that the machine is connected to an AppleTalk network before performing the following procedure:

- 1 On the Apple menu, click [Chooser].
- 2 Click the [Adobe PS] icon.
- In the [Select a PostScript Printer:] list, click the name of the machine you want to use.
- 4 Click [Create].

The PPD file is set up, and the **[Adobe PS]** icon appears at the left of the machine name in the list. Next, follow the procedure on p.31 "Setting up options" to make the option settings, or close the **[Chooser]** dialog box.

Setting up options

- On the Apple menu, click [Chooser].
- 2 Click the [Adobe PS] icon.
- In the [Select a PostScript Printer:] list, click the name of the machine you want to use, and then click [Setup].
- 4 Click [Configure].

A list of options appears.

Select the option you want to set up, and then select the appropriate setting for it.

Note

- ☐ If the option you want to set up is not displayed, the PPD file might not be set up correctly. Check the name of the PPD file shown in the dialog box.
- 6 Click [OK].

The list of options closes.

7 Click [0K].

The [Chooser] dialog box appears.

8 Close the [Chooser] dialog box.

Installing Adobe Type Manager (ATM)

- Quit all applications running before installation. Install after restarting.
- 1 Start the Mac OS.
- 2 Insert the CD-ROM into the CD-ROM drive.
- **3** Double-click the CD-ROM icon.

- Double-click the [Mac OS 8 and 9] folder.
- **5** Double-click the [ATM] folder.
- Double-click the [ATM 4.6.2 installer] icon.
- **7** Follow the instructions on screen.
- 8 Restart the Mac OS.

Note

- ☐ Make sure to restart the computer. [ATM] will be completely installed only after restarting.
- 9 Select [Control Panel] from the Apple menu, and then click [~ATM].
- Open the ATM control panel.

Note

☐ For more information about installation, see the User's Guide in the ATM folder.

Installing screen fonts

- 1 Start the Mac OS.
- 2 Insert the CD-ROM into the CD-ROM drive.
- **3** Double-click the CD-ROM icon.
- Double-click the [Mac OS 8 and 9] folder.
- **5** Double-click the [Fonts] folder.
- **6** Copy the fonts you want to install into the [System] folder.

A confirmation dialog box appears.

7 Click [OK].

The fonts are installed.

8 Restart the Mac OS.

₽ Reference

For information about installing Printer Utility for Mac, see *Post-Script 3 Unit Type 2238 Operating Instructions Supplement*.

Mac OS X - Installing the PostScript 3 Printer Driver

It is necessary to install a PPD file to print from a Mac OS. Follow the procedures to install a PPD file on Mac OS running Mac OS X.

Printer driver is included in Mac OS. When printing under Mac OS X v10.1.x, use the printer driver included in Mac OS.

Preparation

You need an administrator name and a password (phrase). For more information, consult your administrator.

- **1** Insert the CD-ROM into the CD-ROM drive.
- **2** Double-click the CD-ROM icon.
- Double-click the [Mac OS X] folder.
- Double-click the [PPD Installer] folder, and then double-click the installer icon.
- **5** Follow the instructions on screen.

Setting up the PPD file

- 1 Run Print Center.
- 2 Click [Add Printer].
 - Note
 - ☐ Select [AppleTalk] in the first pop-up menu.
 - ☐ If the zone has been set, select the zone in the second pop-up menu.
- Select the PPD file for the model you are using from the [Printer Model:] pop-up menu.
- 4 Click [Add].

Setting up options

Limitation

☐ You can make settings for all printer features, even if the necessary option is not installed, due to Mac OS X Native mode limitations. Check which options are installed in the machine before you print.

Installing the Printer Driver Using USB

This section gives basic instructions for installing printer drivers using USB. The printer drivers can be installed from the CD-ROM that comes with this machine.

Preparation

Make sure that all other applications are closed and the computer is not printing before installation.

Windows 98 SE/Me - Installing the printer driver using USB

The procedure below uses Windows 98 SE as an example. The procedure for Windows Me may be slightly different.

When the USB interface cable is used for the first time, the "plug and play" function starts and [New Hardware Found] dialog box appears.

If printer drivers are already installed, "plug and play" appears, and the printer with its port directed to the USB interface cable is added to the [Printers] folder.

- 1 Click [Next].
- 2 Click [Search for the best driver for your device. {Recommended}.], and then click [Next].
- 3 Select the [Specify a location:] check box, and then click [Browse...].

The [Browse for Folder] dialog box appears.

Insert the CD-ROM provided into the CD-ROM drive.

Note

- ☐ When Auto Run starts, click [Ex-it].
- ☐ If you want to disable Auto Run, press [Shift] when inserting the CD-ROM into the drive and keep it pressed until the computer completes transmission to the drive.
- Select the drive where the printer driver is located according to your operating system, and then click [Next].

If the CD-ROM drive is D, the folder will be "D:\DRIVERS\USB-PRINT\WIN98ME".

6 Confirm the printer driver location, and then click [Next].

USB Printing Support will be installed.

- 7 Click [Finish].
- 8 Follow the "plug and play" on the screen to install the printer drivers.

𝒯 Note

- Each printer driver is stored in the following folders on the CD-ROM:
 - PCL 5c: \DRIVERS\PCL5c\ WIN9X_ME\(Language)\DISK1
 - RPCS™: \DRIVERS\RPCS\ WIN9X_ME\(Language)\DISK1
 - PostScript 3: \DRIVERS\PS\ WIN9X_ME\(Language)\DISK1

When installation is complete, the printer with its port directed to "USB00n" appears in the [Printers] folder. ("n" is the number of printers connected.)

Windows 2000/XP, Windows Server 2003 - Installing the printer driver using USB

Limitation

☐ Installing a printer driver requires the Administrators permission. When you install a printer driver, log on using an account that has Administrator permission.

When the USB interface cable is used for the first time, the **[Found New Hardware Wizard]** dialog box appears, and Windows 2000/XP and Windows Server 2003's USB Printing Support will be installed automatically.

If the printer driver is already installed, the "plug and play" is displayed, and the printer with its port directed to the USB interface cable is added to the **[Printers]** *1 folder.

- □ Under Windows XP and Windows Server 2003, even if the printer driver has already been installed, [Found New Hardware Wizard] may start when connecting the printer and the computer with the USB interface cable for the first time. If this happens, install the printer driver by following the procedure below:
- Install the printer driver by referring to the instructions for installation.

- Each printer driver is stored in the following folders on the CD-ROM:
 - PCL 5c: \DRIVERS\PCL5c\ WIN2K_XP\(Language\)\DISK1
 - RPCS™: \DRIVERS\RPCS\ WIN2K_XP\(Language)\DISK1
 - PostScript 3: \DRIVERS\PS\ WIN2K_XP\(Language)\DISK1

When installation is complete, the printer with its port directed to "USB00n" appears in the [Printers]

*1 folder. ("n" is the number of printers connected.)

*1 In Windows YP and Windows

In Windows XP and Windows Server 2003, the folder is [Printers and Faxes].

Mac OS - Creating a desktop printer icon

When you connect the machine and your computer using USB 2.0, create a Desktop Printer icon.

Limitation

- ☐ In Mac OS X Native mode, printing is disabled when connected to the machine using USB.
- 1 Double-click [Desktop Printer Utility] in the [AdobePS Components] folder.
- Select [AdobePS] in [With:] and [Printer (USB)] in [Create Desktop], and then click [OK].
- Click [Change] in [USB Printer Selection].
- 4 Select the model of the machine you are using in [Select a USB Printer:], and then click [OK].
- Click [Auto Setup] in [PostScript™ Printer Description (PPD) File].
- 6 Click [Create].
- 2 Enter the machine name, and then click [Save].

The printer icon appears on the desktop.

8 Close the Desktop Printer Utility.

Installing the Printer Driver Using IEEE 1394

Printing using a SCSI print device with the optional IEEE 1394 interface board is possible under Windows 2000/XP, or Windows Server 2003.

Preparation

Make sure that all other applications are closed and the computer is not printing before installation.

∰Important

- ☐ When the printer driver is being installed, do not turn on the power of other printers connected to the same bus, or connect another IEEE 1394 device.
- ☐ Before uninstalling the printer driver, be sure to disconnect the IEEE 1394 interface cable from the computer.
- ☐ SCSI print must be enabled using the display panel. See "Interface Settings/IEEE 1394", Network Guide.
- □ SCSI print using the optional IEEE 1394 interface board is not supported by Windows 95/98/Me, or Windows NT 4.0. If the "plug and play" function starts, click [Cancel] in the [New Hardware Found] or [Device Driver Wizard] dialog box.

Note

☐ If **[Found New Hardware Wizard]** appears every time the computer is started or the cable is connected with Windows 2000/XP or Windows Server 2003 when the printer function that uses SCSI print is not installed, disable the device. See p.37 "Disabling the Device" for more information.

- If you send data from your computer when data is being received from another client computer, your data will be printed after completing the print job for the other client computer.
- ☐ When the machine is connected to the computer properly via the 1394 interface, the appearance of the icon in the printer window changes.

Windows 2000

∰Important

- ☐ In Windows 2000, the optional IEEE 1394 interface board can only be used with Service Pack 1 or later. If the Service Pack is not installed, the connectable number of devices in an IEEE 1394 bus is only one, and the client cannot access the IEEE 1394 interface board without using an account that has Administrator permission.
- 1 Connect the machine and computer using the IEEE 1394 interface cable.

The [Found New Hardware Wizard] dialog box appears.

2 Click [Next].

"This wizard will complete the installation for this Device: Unknown" appears.

- Select [Optional search locations:], and then click [Next].
- When "Locate Driver Files" appears, select the [Optional search locations.] check box and the [Specify a location] check box, and then click [Next].

Hold down the left [SHIFT] key and insert the CD-ROM into the CD-ROM drive.

Keep the left **[SHIFT]** key held down until the computer has finished accessing the CD-ROM.

If the Auto Run program starts, click [Cancel], and then click [Exit].

- 6 Click [Browse].
- Select the printer driver you want to install. Each printer driver is stored in the following folders:
 - PCL 5c: \DRIVERS\PCL5c\ WIN2K_XP\(Language)\DISK1
 - RPCS™: \DRIVERS\RPCS\ WIN2K_XP\(Language)\DISK1
 - PostScript 3: \DRIVERS\PS\ WIN2K_XP\(Language)\DISK1
- 8 Click [Open].
- 9 Click [0K].

A printer model selection dialog box appears.

Follow the instructions on the screen.

□ When installation is complete, the printer with its port directed to "1394_00n" appears in the [Printers] folder. ("n" is the number of printers connected.)

Windows XP, Windows Server 2003

Connect the machine and the computer using the IEEE 1394 interface cable.

The **[Found New Hardware Wizard]** dialog box appears.

2 Confirm that "This wizard helps you install software for: (printer name)" is displayed, and click [Install from a list or specific location (Advanced)], and then click [Next].

"Please choose your search and installation option." appears.

- Select the [Search for the best driver in these locations.] check box, and [Include this location in the search:] check box.
- Install the printer driver following the same procedure as in steps to for Windows 2000.

Note

□ When installation is complete, a printer with its port directed to "1394_00n" appears in the **[Printers and Faxes]** folder. ("n" is the number of printers connected.)

Disabling the Device

- ♦ If [Add New Hardware Wizard] appears every time you restart the computer using an operating system that does not support SCSI print, or plug in/take out the cable, disable the device with the following procedure:
 - · Windows Me
 - ① In the [Add New Hardware Wizard] dialog box, confirm that [Windows has found the following new Hardware: IEEE SBP-2 Device] is displayed, and click [Recommended search for a better driver [Recommended]], and then click [Next].
 - When "Windows was unable to locate the software for this device." appears, click [Finish].
- If you do not want to install the printer when [Found New Hardware Wizard] starts when using an operating system that supports SCSI print, disable the device with the following procedure:
 - Windows 2000
 - ① In the [Found New Hardware Wizard] dialog box, click [Next].
 - When "This wizard will complete the installation for this Device: Unknown" appears, click [Search for a suitable driver for my device [recommended]], and then click [Next].
 - When "Locate Driver Files" appears, remove all selections from [Optional search locations.], and then click [Next].

- When "Driver Files Search Results" appears, click [Disable the device. The Add/Remove Hardware Wizard in the control panel can be used to complete the driver installations.], and then click [Finish].
- Windows XP, Windows Server 2003
 - ① In the [Found New Hardware Wizard] dialog box, confirm "This wizard helps you install software for: Unknown" is displayed, and click [Install from a list on specific location (Advanced)], and then click [Next].
 - When "Please choose your search and installation option." appears, remove all selections from [Search for the best driver in these locations.], and then click [Next].
 - When "The wizard could not find the software on your computer for.." appears, click [OK].
 - When "Cannot Install this Hardware" appears, select the [Don't prompt again to install the software] check box, and then click [Finish].

- If [Found New Hardware Wizard] appears every time you restart the computer when using an operating system that does not support IP over 1394, or plug in/take out the cable, disable the device with the following procedure:
 - Windows 2000
 - In [Found New Hardware Wizard] dialog box, click [Next].
 - When "This wizard will complete the installation for this Device:" and "IP over 1394" appear, click [Search for a suitable driver for my device [recommended]], and then click [Next].
 - ③ When "Locate Driver Files" appears, remove all selections from [Optional search locations.], and then click [Next].
 - When "Driver Files Search Results" appears, click [Disable the device. The Add/Remove Hardware Wizard in the Control Panel can be used to complete the driver installations.], and then click [Finish].

Installing SmartNetMonitor for Client/Admin

Limitation

- ☐ If your operating system is Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, installing software using Auto Run requires Administrator permission. When you install a printer driver using Auto Run, log on using an account that has Administrator permission.
- 1 Quit all applications running.
- 2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Suomi (Finnish), Svenska (Swedish), SMPCHINA (Chinese), TRDCHINA (Taiwanese)

The default interface language is English.

Click [SmartNetMonitor for Client/Admin].

The software license agreement appears in the [License Agreement] dialog box.

After reading through the agreement, click [I accept the agreement] to agree, and then click [Next].

- Select the program you want to install when the [Select Program] dialog box appears.
- **7** Follow the instructions on the screen.

Installing Font Manager 2000

Limitation

☐ If your operating system is Windows 2000/XP, Windows Server 2003, or Windows NT 4.0, installing software using Auto Run requires Administrator permission. When you install a printer driver using Auto Run, log on using an account that has Administrator permission.

Note

- ☐ Font Manager 2000 English version is provided.
- 1 Quit all applications running.
- 2 Insert the CD-ROM into the CD-ROM drive.

Auto Run will start the installer.

Select a language for the interface language, and then click [OK].

The following languages are available: Cestina (Czech), Dansk (Danish), Deutsch (German), English (English), Espanol (Spanish), Francais (French), Italiano (Italian), Korean (Korean), Magyar (Hungarian), Nederlands (Dutch), Norsk (Norwegian), Polski (Polish), Portugues (Portuguese), Russian (Russian), Suomi (Finnish), Svenska (Swedish)

The default interface language is English.

- 4 Click [Font Manager 2000].
- **5** Follow the instructions on the screen.

Using Adobe PageMaker Version 6.0, 6.5, or 7.0

If you use the machine under Windows 95/98/Me, Windows 2000/XP, Windows Server 2003, or Windows NT 4.0 with Adobe PageMaker, you need to copy the PPD file to the PageMaker folder.

The PPD file is the file with the extension ".ppd" in the folder "DRIV-ERS\PS\WIN9X_ME\(Language)\\ DISK1\" on the CD-ROM.

The **[WIN9X_ME]** folder, inside the **[PS]** folder is for Windows 95/98/Me. Use the folder at a level appropriate for the operating system you are currently using.

The third folder, "(Language)" may be renamed with an appropriate language name.

Copy the file with extension ".ppd" to the PageMaker folder.

For PageMaker 6.0 default installation

The directory is "C:\PM6\RSRC\PPD4".

• For PageMaker 6.5 default installation

The directory is "C:\PM65\RSRC\USENGLISH\PPD4".

"USENGLISH" may vary depending on your language selection.

 For PageMaker 7.0 default installation

The directory is "C:\PM7\RSRC\USENGLISH\PPD4".

"USENGLISH" may vary depending on your language selection.



- When using PageMaker, optional features that can be selected by the printer driver will not be active. The following procedure describes how to activate the optional printer features.
 - ① On the [File] menu, click [Print]. The [Print Document] dialog box appears.
 - ② Make the necessary settings in the [Features] box.

Software and Utilities Included on the CD-ROM

There are two CD-ROMs that come with the printer option of this machine.

- The Printer/Scanner Unit Type 2238 package contains the following CD-ROMs:
 - · Printer Drivers and Utilities
 - Operating Instructions for Printer/Scanner

The CD-ROM labeled "Printer Drivers and Utilities" is mainly used for machine printer functions. In this manual, "CD-ROM" refers to the "Printer Drivers and Utilities" CD-ROM, unless specified otherwise.

Printer Drivers

Printing requires installation of a printer driver for your operating system. The following drivers are included on the CD-ROM labeled "Printer Drivers and Utilities" that comes with the printer option of this machine.

| Printer Language | PCL 5c | RPCS TM | Post- Script 3 |
|---------------------------|--------|------------|-------------------|
| Windows 95 *1 | √ | √ | √ *12 |
| Windows 98 *2 | √ | √ | √ *12 |
| Windows Me *3 | √ | √ | √ *12 |
| Windows 2000 *4 | √ | √ | √ *13 |
| Windows XP *5 | √ | √ | √ *13 |
| Windows Server 2003 *6 | √ | √ | √*13 |
| Windows NT 4.0 *7 | √ *10 | √ *10 | √*11 *12 |
| Mac OS *8 | | | √ *12 |
| Mac OS X *9 | | | √ *14 |

- *1 Microsoft Windows 95 operating system
- *2 Microsoft Windows 98 operating system
- *3 Microsoft Windows Millennium Edition
- *4 Microsoft Windows 2000 Advanced Server
 - Microsoft Windows 2000 Server Microsoft Windows 2000 Professional
- *5 Microsoft Windows XP Professional Microsoft Windows XP Home Edition
- *6 Microsoft Windows Server 2003 Standard Edition Microsoft Windows Server 2003 Enterprise Edition

Microsoft Windows Server 2003 Web Edition

- *7 Microsoft Windows NT Server operating system version 4.0, Microsoft Windows NT Workstation operating system version 4.0 in a computer using x86 processors.
- *8 Versions 8.6 to 9.2 of the Mac OS (Mac OS X Classic mode is supported.)
- *9 Mac OS X 10.1 or later (Native mode)
- *10 Requires Service Pack 4 or later. *11 Requires Service Pack 6 or later.
- *12 The Adobe PostScript 3 printer drivers and PostScript Printer Description (PPD) files are included on the CD-ROM labeled "Printer Drivers and Utilities".
- *13 The PostScript Printer Description (PPD) files are included on the CD-ROM labeled "Printer Drivers and Utilities".
- *14 The Adobe PostScript Printer Description (PPD) installer is included on the CD-ROM labeled "Printer Drivers and Utilities".

PCL printer drivers

The PCL 5c printer drivers are included on the CD-ROM that comes with this machine. This printer driver allows the computer to communicate with the machine via a printer language.

See p.19 "Installing the PCL 5c and RPCSTM Printer Driver"

♣ RPCS™ printer driver

The RPCS™ printer drivers are included on the CD-ROM that comes with this machine. This printer driver allows the computer to communicate with the machine via a printer language. The preset type user interface is provided in addition to the usual one.

See p.19 "Installing the PCL 5c and RPCS™ Printer Driver".

Adobe PostScript 3 printer drivers and PPD files

The Adobe PostScript 3 printer drivers and the PPD files are included on the CD-ROM that comes with this machine. This printer driver allows the computer to communicate with the printer via a printer language. The PPD files allow the printer driver to enable printer specific functions.

See p.24 "Installing the PostScript 3 Printer Driver".

LAN-Fax Driver

The LAN-Fax Driver is included on the CD-ROM that comes with this machine. This driver allows you to use LAN-Fax functions. The LAN-Fax Driver, Address Book, and LAN-Fax Cover Sheet Editor can be installed using this driver.

Software and Utilities

SmartNetMonitor for Admin

This utility is for the system administrator to manage network printers.

See SmartNetMonitor for Admin online Help for more information about using SmartNetMonitor for Admin.

SmartNetMonitor for Client

This utility is for users to manage their own print status on the network.

₽ Reference

See SmartNetMonitor for Client online Help for more information about using SmartNetMonitor for Client.

♦ Font Manager 2000

This utility helps you install new screen fonts, or organize and manage fonts already installed on the system.

1394 Utility

This utility is for the IEEE 1394 interface board. For more information, see the Readme file or the manual that comes with the optional IEEE 1394 interface board.

❖ USB Printing Support

This utility is for the USB 2.0 interface board. Install this to use USB on computers running Windows 98 SE/Me. For information about installation, see p.33 "Installing the Printer Driver Using USB".

Acrobat Reader

This utility allows you to read PDF files (Portable Document Format).

Note

Documentation about using the machine is included on the CD-ROM in PDF format. See Acrobat Reader online Help for more information about using Acrobat Reader.

Printer Utility for Mac

This utility allows users to download and manage a variety of fonts as well as manage printers. For more information about this utility, see *PostScript 3 Unit Type 2238 Operating Instructions Supplement* which is provided as a PDF file on the CD-ROM labeled "Operating Instructions for Printer/Scanner".

∰Important

☐ Software and utilities must be uninstalled before installing newer versions of Windows. Reinstall software and utilities after upgrading Windows.

INDEX

| | М | | |
|--|--|--|--|
| Acrobat Reader, 43 ATM Mac OS, installing, 31 | Mac OS ATM, installing, 31 PostScript 3, installing, 30 Screen fonts, installing, 32 Mac OS X PostScript 3, installing, 32 Main power indicator, 5 | | |
| В | N | | |
| Bidirectional transmission, 29 Bypass tray, 12 | Number keys, 6 | | |
| С | 0 | | |
| CD-ROM, 41 Clear/Stop key, 6 Connection Ethernet board connection, 10 IEEE 1394 interface board connection, 10 | OHP Transparencies printing, bypass tray, 15 On indicator, 5 Operation switch, 5 | | |
| Parallel interface connection, 10 USB connection, 10 Control Panel, 5 Custom size paper, 14 printing, bypass tray, 12 D | PageMaker, 40 PCL, 41 PCL 5c Windows 2000/XP, installing, 19 Windows 95/98/Me, installing, 19 Windows NT 4.0, installing, 19 | | |
| Data In indicator, 6 Display panel, 5,7 | Windows Server 2003, installing, 19 PostScript 3, 42 Mac OS, installing, 30 Mac OS X, installing, 32 | | |
| <u>E</u> | Windows 2000/XP, Windows Server 2003, | | |
| Energy Saver key, 5 | installing, 25 Windows 95/98/Me, installing, 24 Windows NT 4.0, installing, 27 | | |
| Font Manager 2000, 42 installing, 39 Function keys, 6 Function status indicator, 6 I IEEE 1394 connection installing, printer driver, 35 IP over 1394, 35 | Printer driver Auto Run, 16 installing, IEEE 1394 connection, 35 installing, USB connection, 33 PCL 5c, 41 PostScript 3, 41 Quick Install, 17 RPCS, 41 Printer Utility for Mac, 43 | | |

Q

Ouick Install, 17

R

RPCS, 42

Windows 2000/XP, installing, 19 Windows 95/98/Me, installing, 19 Windows NT 4.0, installing, 19 Windows Server 2003, installing, 19

S

Screen fonts

Mac OS, installing, 32

SCSI print, 35

SmartNetMonitor for Admin, 39, 42

SmartNetMonitor for Client, 39, 42

Software

Quick Install, 17

Т

Thick Paper printing, bypass tray, 15

U

USB connection

printer driver, installing, 33
USB Printing Support, 42
User Tools/Counter, 5

W

Windows 2000/XP PCL 5c, installing, 19 RPCS, installing, 19 Windows 2000/XP, Windows Server 2003 PostScript 3, installing, 25 Windows 95/98/Me PCL 5c, installing, 19 PostScript 3, installing, 24 RPCS, installing, 19 Windows NT 4.0 PCL 5c, installing, 19 PostScript 3, installing, 27 RPCS, installing, 19 Windows Server 2003 PCL 5c, installing, 19 RPCS, installing, 19

((

Declaration of Conformity

"The Product complies with the requirements of the EMC Directive 89/336/EEC and its amending directives and the Low Voltage Directive 73/23/EEC and its amending directives."

|--|

Caution:

Network interface cables with ferrite core must be used for RF interference suppression.







- 1 Setting Up the Printer Driver and Canceling a Print Job
- 2 Using the Document Server
- 3 Sample Print/Locked Print
- 4 Troubleshooting
- 5 Printer Features
- 6 Appendix

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Warning

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Trademarks

Microsoft[®], Windows[®] and Windows NT[®] are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe®, PostScript®, Acrobat® are registered trademarks of Adobe Systems Incorporated.

PCL® is a registered trademark of Hewlett-Packard Company.

AppleTalk, Apple, Macintosh and Mac are registered trademarks of Apple Computer, Incorporated.

IPS-PRINT™ Printer Language Emulation Copyright©2000, Oak Technology, Inc., All Rights Reserved.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Bluetooth is a Trademark of the Bluetooth SIG, Inc. (Special Interest Group) and licensed to RICOH company limited.

Copyright © 2001 Bluetooth SIG, Inc.

The Bluetooth Trademarks are owned by Bluetooth SIG, Inc. USA

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

The proper names of the Windows operating systems are as follows:

- The product name of Windows® 95 is Microsoft®Windows® 95
- The product name of Windows® 98 is Microsoft®Windows® 98
- The product name of Windows[®] Me is Microsoft[®]Windows[®]Millennium Edition (Windows Me)
- The product names of Windows[®] 2000 are as follows:

Microsoft® Windows® 2000 Professional

Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Advanced Server

The product names of Windows® XP are as follows:

Microsoft®Windows® XP Home Edition

Microsoft®Windows® XP Professional

The product names of Windows Server[™] 2003 are as follows:

Microsoft® Windows Server™ 2003 Standard Edition

Microsoft® Windows Server™ 2003 Enterprise Edition

Microsoft® Windows Server™ 2003 Web Edition

• The product names of Windows NT® 4.0 are as follows:

Microsoft® Windows NT® Workstation 4.0

Microsoft® Windows NT® Server 4.0

Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

TABLE OF CONTENTS

| Manuals for This Machine How to Read This Manual | | |
|--|--------------|--|
| 1. Setting Up the Printer Driver and Canceling a Print Job | | |
| Accessing Printer Properties | 5 6 7 | |
| Windows - Canceling a Print Job Mac OS - Canceling a Print Job 2. Using the Document Server | 11 | |
| Accessing the Document Server | | |
| 3. Sample Print/Locked Print | | |
| Sample Print Printing a Sample Print File Deleting a Sample Print File Checking the Error Log Locked Print Printing a Locked Print File Deleting Locked Print Files Checking the Error Log Form Feed Print Using a Selected Tray Canceling Form Feed 4. Troubleshooting | 151719192021 | |
| Error & Status Messages on the Display Panel The Machine Does Not Print | 00 | |
| Other Printing Problems | | |
| 5. Printer Features | | |
| Printer Features Menu | | |
| Adjusting Printer Features | | |
| Printer Features Parameters | | |
| Paper Input | | |
| List/Test Print | | |
| System | | |
| Host Interface | | |
| PCL Menu | | |
| PS Menu | 52 | |

6. Appendix

| Finisher | 53 |
|---|----|
| Staple | 54 |
| Staple Position | |
| Stapling Precautions | |
| Punch | 58 |
| Punch Position | 58 |
| Punching Precautions | |
| Collate | 60 |
| Spool Printing | 62 |
| Covers | |
| Slip Sheets | |
| User Defined Pages | |
| System Settings (Parallel Connection) | |
| Precautions when using Windows Server 2003 | 71 |
| Precautions when using the Terminal Server mode | |
| Specifications | 72 |
| Options | |
| INDEX | 76 |

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

Note

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1"Operating Instructions for Printer/Scanner"
 - CD-ROM 2"Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine.

It also describes System Settings (such as paper trays and user codes settings), Document Server functions, and troubleshooting.

Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference < Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference<Advanced Features>

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1) (this manual)

Describes operations, functions, and troubleshooting for the machine's printer function.

♦ Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with
 DeskTopBinder V2 Lite. This guide is added to the [Start] menu when
 DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an overview of ScanRouter V2 Lite functions. This guide is added to the [Start] menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- UNIX Supplement (available from an authorized dealer, or as a PDF file on our Web site)

How to Read This Manual

Symbols

In this manual, the following symbols are used:

⚠ WARNING:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

↑ CAUTION:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury, or damage to property.

* The statements above are notes for your safety.

#Important

If this instruction is not followed, paper might misfeed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates prior knowledge or preparation is required before operation.

𝚱 Note

This symbol indicates precautions for operation, or actions to take after mal-operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys and buttons that appear on the computer's display.

Keys that appear on the machine's display panel.

Keys built into the machine's control panel.

Keys on the computer's keyboard.

1. Setting Up the Printer Driver and Canceling a Print Job

Accessing Printer Properties

Windows 95/98/Me - Accessing Printer Properties

Changing default settings

- 1 On the [Start] menu, point to [Settings], and then click [Printers].
 The [Printers] window appears.
- 2 Click the icon of the machine whose default you want to change.
- On the [File] menu, click [Properties].

The printer properties dialog box appears.

Make the settings you require, and then click [OK].

Note

☐ With some applications, printer driver settings are not used, and the application's own settings are applied.

Making settings from an application

To make settings for a specific application, open the printer properties dialog box from that application. The following example describes how to make settings for the WordPad application that comes with Windows 95/98/Me.

Note

- ☐ Actual procedures for opening the printer properties dialog box may vary depending on the application. For more information, see the operating instructions that come with the application you are using.
- ☐ Any setting you make in the following procedure is valid for the current application only:
- 1 On the [File] menu, click [Print]. The [Print] dialog box appears.
- In the [Name] list, select the machine you want to use, and then click [Properties].

The printer properties dialog box appears.

- Make the settings you require, and then click [OK].
- 4 Click [OK] to start printing.

Windows 2000/XP, Windows Server 2003 - Accessing Printer Properties

Changing default settings - Printer properties

Limitation

- ☐ Changing machine settings requires Manage Printers permission. Members of Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

Note

- ☐ In Windows XP Professional and Windows Server 2003, open the [Printers and Faxes] window on the [Start] menu.
- ☐ In Windows XP Home Edition, open the [Printers and Faxes] window by clicking [Control Panel] from the [Start] button on the taskbar, click [Printers and Other Hardware], and then click [Printers and Faxes].
- 2 Click the icon of the machine whose default you want to change.
- On the [File] menu, click [Properties].

The printer properties dialog box appears.

Make the settings you require, and then click [OK].

Note

- □ Normally you do not have to change the "Form to Tray Assignment" settings on the [Device Settings] tab in the PostScript 3 printer driver.
- ☐ Settings you make here are used as default for all applications.

Changing default settings - Printing preferences properties

Limitation

- ☐ Changing machine settings requires Manage Printers permission. Members of the Administrators and Power Users groups have Manage Printers permission by default. When you set up options, log on using an account that has Manage Printers permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].

The [Printers] window appears.

Note

- ☐ In Windows XP Professional and Windows Server 2003 open the [Printers and Faxes] window on the [Start] menu.
- ☐ In Windows XP Home Edition, open the [Printers and Faxes] window by clicking [Control Panel] from the [Start] button on the taskbar, click [Printers and Other Hardware], and then click [Printers and Faxes].
- 2 Click the icon of the machine whose default you want to change.
- On the [File] menu, click [Printing Preferences...].

The [Printing Preferences] dialog box appears.

Make the settings you require, and then click [OK].

Note

☐ Settings you make here are used as default for all applications.

Making settings from an application

To make settings for a specific application, open the **[Print]** dialog box from that application. The following example describes how to make settings for the WordPad application that comes with Windows 2000/XP and Windows Server 2003.

Ø Note

- □ Actual procedures for opening the [Print] dialog box vary depending on the application. For more information, see the operating instructions that come with the application you are using.
- ☐ Any setting you make in the following procedure is valid for the current application only.
- 1 On the [File] menu, click [Print...]. The [Print] dialog box appears.
- In the [Select Printer] list, select the machine you want to use, and then click the tab for which you want to change print settings.

Note

- ☐ In Windows XP and Windows Server 2003, click [Preference] to open the Printing Preferences dialog box.
- **3** Make the settings you require.
- 4 Click [Print] to start printing.
 Under Windows XP and Windows
 Server 2003, click [OK], and then
 click [Print] to start printing.

Windows NT 4.0 - Accessing Printer Properties

Changing default settings - Printer properties

Limitation

- ☐ Changing machine settings requires Full Control access permission. Members of Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you set up options, log on using an account that has Full Control permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].
 The [Printers] window appears.
- 2 Click the icon of the machine whose default you want to change.
- 3 On the [File] menu, click [Properties].

The printer properties dialog box appears.

Make the settings you require, and then click [OK].

Note

- □ Normally you do not have to change the "Form to Tray Assignment" settings on the [Device Settings] tab in the PostScript 3 printer driver.
- ☐ Settings you make here are used as default for all applications.

Changing the default settings - Default document properties

Limitation

- ☐ Changing machine settings requires Full Control access permission. Members of the Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you set up options, log on using an account that has Full Control permission.
- 1 On the [Start] menu, point to [Settings], and then click [Printers].
 The [Printers] window appears.
- 2 Click the icon of the machine whose default you want to change.
- On the [File] menu, click [Document Defaults].

The [Default] dialog box appears.

Make the settings you require, and then click [OK].

Note

☐ Settings you make here are used as default for all applications.

Making settings from an application

To make settings for a specific application, open the printer properties dialog box from that application. The following example describes how to make settings for the WordPad application that come with Windows NT 4.0.

Note

- □ Actual procedures for opening the printer properties dialog box vary depending on the application. For more information, see the operating instructions that come with the application you are using.
- ☐ Any setting you make in the following procedure is valid for the current application only.
- 1 On the [File] menu, click [Print]. The [Print] dialog box appears.
- In the [Name] list, select the machine you want to use, and then click [Properties].

The printer properties dialog box appears.

- Make the settings you require, and then click [OK].
- 4 Click [OK] to start printing.

Mac OS - Setting Up for Printing

Making paper settings from an application

- 1 Open the file you want to print.
- On the [File] menu, click [Page Setup].

Dialog box appears.

Make sure the machine you want to use is shown in the [Printer:] box.

Note

- ☐ In Mac OS X, this is called [Format For:].
- ☐ If the machine is not shown in the [Printer:] box, use the pop-up menu to display a list of available machines.

The actual appearance of Page Setup depends on the application you are using. See the operating instructions that come with the Mac OS for more information.

In the [Paper:] box, select the paper size.

𝚱 Note

- ☐ In Mac OS X, this is called [Page Size].
- Make the settings you require, and then click [OK].

Setting up for printing from an application

- 1 Open the file you want to print.
- On the [File] menu, click [Print].
 Dialog box appears.
- Make sure the machine is selected in the [Printer:] box.
- Make the settings you require, and then click [Print] to start printing.

Canceling a Print Job

Windows - Canceling a Print Job

1 Double-click the printer icon on the Windows taskbar.

A window appears, showing all print jobs currently queued for printing. Check the current status of the job you want to cancel.

- 2 Select the name of the job you want to cancel.
- On the [Document] menu, click [Cancel Printing].

 - ☐ In Windows XP, Windows Server 2003, and Windows NT 4.0, click [cancel] on the [Document] menu.
 - ☐ In Windows 95/98/Me/2000 or Windows NT 4.0, you can also open the print job queue window by double-clicking the machine icon in the [Printers] machine window (the [Printers and Faxes] window under Windows XP and Windows Server 2003).
- Press the [Printer] key on the machine's control panel.
- Press [Job Reset] on the display panel.



Press [Reset Current Job] or [Reset All Jobs].



- [Reset Current Job]: cancels the print job currently being processed.
- [Reset All Jobs]: cancels all jobs in the print queue.
- [Resume Printing]: resumes printing jobs.

A confirmation message appears.

Press [Yes] to cancel the print job.

Ø Note

☐ Press **[No]** to return to the previous display.

∰Important

- ☐ If the machine is shared by multiple computers, be careful not to accidentally cancel someone else's print job.
- □ If the machine is connected to the computer using a parallel cable, sent print jobs may be canceled if [Reset All Jobs] is pressed while "Waiting..." is on the display panel. After the interval set in [I/O Timeout] in Printer Features has passed, the next print job can be sent. A print job sent from a different client computer will not be canceled in this case.

Note

- ☐ You cannot stop printing data that has already been processed. For this reason, printing may continue for a few pages after you press [Job Reset].
- ☐ A print job containing a large volume of data may take considerable time to stop.

Mac OS - Canceling a Print Job

1 Double-click the printer icon on the desktop.


A window appears, showing all print jobs currently queued for printing. Check the current status of the job you want to cancel.

Ø Note

- ☐ In Mac OS X, start Print Center.
- 2 Select the name of the job you want to cancel.
- Click the pause icon, and then click the trash icon.

𝚱 Note

- ☐ In the Mac OS X, click [Stop jobs], and then [Delete].
- Press the [Printer] key on the machine's control panel.
- Press [Job Reset] on the display panel.



6 Press [Reset Current Job] or [Reset All Jobs].



- [Reset Current Job]: cancels the print job currently being processed.
- [Reset All Jobs]: cancels all jobs in the print queue.
- [Resume Printing]: resumes printing jobs.

A confirmation message appears.

7 Press [Yes] to cancel the print job.

Note

☐ Press [No] to return to the previous display.

#Important

☐ If the machine is shared by multiple computers, be careful not to accidentally cancel someone else's print job.

Note

- ☐ You cannot stop printing data that has already been processed. For this reason, printing may continue for a few pages after you press [Job Reset].
- ☐ A print job containing a large volume of data may take considerable time to stop.

K

2. Using the Document Server

Accessing the Document Server

The Document Server enables you to store documents on the machine's hard disk, allowing you to edit and print as and when you want.

Limitation

☐ Applications with their own drivers, such as PageMaker, do not support this function.

For more information about Document Server functions, see *General Settings Guide*.

For information about how to access Document Server from a client, see the printer driver Help.

𝚱 Note

- ☐ When you use the Document Server, the following functions can be selected using the machine's control panel:
 - Copies
 - Collate
 - Duplex
 - Staple
 - Punch
 - Paper selection: Paper source tray, paper type, paper output tray.
 - Functions related to paper selection: Cover sheets, slip sheets.
- ☐ The above items are dimmed, so you cannot set them from the printer properties dialog box when the Document Server is selected.
- ☐ You must enter a user ID, using up to eight alphanumeric characters.
- ☐ You should enter a Password and File Name to distinguish the job from others.
- □ Up to 2,000 files can be stored in the Document Server. No new files can be stored after 2,000 is reached. Even if less than 2,000 files are stored, new files cannot be stored when
 - a file to be stored contains more than 1,000 pages,
 - the total number of pages contained in files stored exceeds 9,000,
 - the hard disk is full.

- ☐ The Document Server also stores files scanned using the Automatic Document Feeder (ADF) or exposure glass. You should delete unnecessary stored files once in a while so as not to exceed the capacity of the hard disk. For how to delete stored files, see *General Settings Guide*.
- ☐ When using the hard disk for functions other than those of Document Server, you may be unable to store new files in the Document Server, even if there are less than 2,000 files stored.

3. Sample Print/Locked Print

Sample Print

Use this function to print only the first set of a multiple-set print job. After you have checked the result, remaining sets can be printed or canceled using the machine's control panel. This can reduce misprints due to mistakes in content or settings.

Ø Note

- ☐ If the application has a collate option, make sure it is not selected before sending a print job. By default, sample print jobs are automatically collated by the printer driver. If a collate option is selected from the application's [Print] dialog box, more prints than intended may be produced.
- ☐ You can identify the file you want to print by user ID and date and time when the job was stored.
- ☐ The number of pages the machine can save depends on the contents of the print image. For example, the machine can save up to 30 jobs or 1,000 pages, including locked print files, depending on data volume.
- ☐ If the first set of the sample print files is not as you expected and you do not want to print remaining sets, delete the sample print file using the display panel. If you print the remaining sets of the sample print file, the job in the machine is deleted automatically.

Printing a Sample Print File

The following procedure describes how to print a sample print file with the PCL 5c and the RPCS printer driver. For information about how to print a sample print file with the Post-Script 3 printer driver, see *PostScript 3 Unit Type 2238 Operating Instructions Supplement* included as a PDF file on the CD-ROM.

Limitation

- ☐ Applications with their own drivers, such as PageMaker, do not support this function.
- ☐ If you are using Mac OS X, this function cannot be used.
- 1 Configure the sample print in the printer driver's properties.

For details about configuring the printer drivers, see the relevant Help files.


2 Start printing from the application's [Print] dialog box.

Note

☐ Make sure to set more than two copies.

The sample print job is sent to the machine, and the first set is printed.

On the machine's control panel, press the [Printer] key to display the Printer screen.



Press [Locked & Sample Print Job List].



Press [Sample Print Job List].

A list of the sample print files stored in the machine appears.



The following items also appear:

- User ID: The user ID set up by the printer driver.
- Date/Time: The date and time when the job was sent from the computer.
- Qty.: The number of remaining sets.

6 Select the file you want to print by pressing it.

A list of the print files stored in the machine appears.

- Note
- ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
- ☐ Only one file can be selected at a time.
- **7** Press [Change Set Qty.] to change the number of sets to be printed.

If you do not want to change the set quantity, proceed to step **9**.

Enter the new number of sets using the number keys, and then press [OK].



The screen returns to the file list screen.

- Ø Note
- ☐ You can enter up to 999 sets.
- ☐ Press [Clear] to correct any entry mistakes.
- ☐ If you want to cancel changing the set quantity, press [Cancel].
- 9 Press [Print].

The print confirmation screen appears.

10 Press [Yes].

The remaining sets are printed.

- Note
- ☐ Press [No] to cancel printing.
- ☐ When printing is completed, the stored file will be deleted.
- ☐ If printing is stopped by pressing [Job Reset] after it has started, the file will be deleted.
- ☐ If there is a print job outstanding, this will be printed before the sample print job.

Deleting a Sample Print File

If you are not satisfied with the sample printout, you can delete the sample print file, revise it and print it again until the settings are suitable.

- Press the [Printer] key to display the Printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored in the machine appears.

Press [Sample Print Job List].

A list of sample print files stored in the machine appears.

- 4 Select the file you want to delete by pressing it.
 - Note
 - ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - ☐ Only one file can be selected at a time.
- **5** Press [Delete].

The delete confirmation screen will appear.

6 Press [Yes] to delete the file.


After the file has been deleted, the file list screen will return.

- Note
- ☐ If you do not want to delete the file, press [No].

Checking the Error Log


If a file could not be stored, you can check the error log on the control panel.

- Limitation
- ☐ The error log displays only the 20 most recent entries. If the power is turned off, the log is deleted.
- 1 Press the [Printer] key to display the Printer screen.
- 2 Press [Error Log].



Press [Sample Print Job List].

4 Press [Details].



An error log list appears.



𝚱 Note

- □ Press [▲Prev.] or [▼Next.] to scroll through the error files.
- ☐ Press **[Exit]** after checking the log.
- ☐ To print files that appear in the error log, resend them after stored files have been printed or deleted.

Locked Print

Use this function to maintain privacy when printing confidential documents on the machine over a shared network. Usually, it is possible to print data using the display panel once it is stored in this machine. When using Locked Print, it is not possible to print unless a password is entered on the machine's display panel. Your confidential documents will be safe from being viewed by other people.

Note

- ☐ If the application has a collate option, make sure it is not selected before sending a print job. Locked print jobs are automatically collated by the printer driver as default. If a collate option is selected in the application print dialog box, more sets than intended may be printed.
- ☐ You can identify the file you want to print by User ID, and date and time when the job was stored.
- ☐ The number of pages the machine can save depends on print image content. For example, the machine can save up to 30 jobs or 1,000 pages including sample print files, depending on data volume.
- ☐ After the locked print file is printed, the job is automatically deleted.
- ☐ Turning off the machine's main power switch deletes locked print files.

Printing a Locked Print File

The following procedure describes how to print a locked print file with the PCL 5c and the RPCS printer driver. For information about how to print a locked print file with the Post-Script 3 printer driver, see *PostScript 3 Unit Type 2238 Operating Instructions Supplement* included as a PDF file on the CD-ROM.

Limitation

- Applications with their own drivers, such as PageMaker, do not support this function.
- ☐ If you are using Mac OS X, this function cannot be used.
- 1 Configure the locked print in the printer driver's properties.

For details about configuring the printer drivers, see the corresponding Help files.

2 Start printing from the application's [Print] dialog box.

The locked print job is sent to the machine.

On the machine's control panel, press the [Printer] key to display the Printer screen.

Press [Locked & Sample Print Job List].



A list of the print files stored in the machine appears.

Press [Locked Print Job List].

A list of stored locked print files appears.



The following items also appear:

- User ID: The user ID set up by the printer driver.
- Date/Time: The date and time when the job was sent from the computer.
- **6** Select the file you want to print by pressing it.
 - Note
 - ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - Only one file can be selected at a time.
- **7** Press [Print].

The password screen appears.



Enter the password using the number keys, and then press [OK].

The print confirmation screen appears.

Ø Note

- ☐ A confirmation screen will appear if the password is not entered correctly. Press [OK] to enter the password again.
- 9 Press [Yes].

The locked file is printed.

- Note
- ☐ Press **[No]** to cancel printing.
- ☐ If printing is stopped by pressing [Job Reset] after it has started, the file will be deleted.

Deleting Locked Print Files

- 1 Press the [Printer] key to display the Printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored in the machine appears.

Press [Locked Print Job List].

A list of the locked print files stored appears.

4 Select the file you want to delete by pressing it.

Note

- ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
- ☐ Only one file can be selected at a time.

Press [Delete].

The password screen is displayed.

6 Enter the password using the number keys, and then press [OK].

The delete confirmation screen appears.

Note

☐ A confirmation screen will appear if the password is not entered correctly. Press [OK] to enter the password again.

Press [Yes].

After the file has been deleted, the file list screen returns.

Ø Note


- ☐ If you do not want to delete the file, press [No].
- ☐ If you forget your password, select [Unlock] from [►Temporarily Unlock Files] in [Password Management for Stored Files] on the [Key Operator Tools] tab of the System Settings screen. With this setting, the password screen is not displayed in the procedure above. For more information about [Display Password with Stored File], see General Settings Guide.

Checking the Error Log

If a file could not be stored in this machine, you can check the error log on the display panel.

Limitation

- ☐ The error log displays only the 20 most recent entries. If the power is turned off, the log will be deleted.
- 1 Press the [Printer] key to display the Printer screen.
- Press [Error Log].



- **3** Select [Locked Print Job List].
- 4 Press [Details].

An error log list appears.



Note

- ☐ Press [▲Prev.] or [▼Next.] to scroll through the error files.
- ☐ Press **[Exit]** after checking the log.
- ☐ To print files that appear in the error log, resend them after stored files have been printed or deleted.

Form Feed

This section gives instructions for operating the machine when there is no tray for the selected paper size or type, or when paper loaded in the machine has run out.

Limitation

- ☐ The tray cannot be changed if the following functions are set for it:
 - Staple
 - Punch
 - Duplex Print to a tray that does not support duplex printing
 - Cover Sheet
 - Front/Back Covers

Note

- ☐ If form feed is selected for a tray with the following settings, you can change the tray by canceling the settings:
 - Staple
 - Punch
- ☐ If Auto Continue is selected, form fed paper is printed after a set interval. See p.47 "System".

If the machine does not have a tray for the selected paper size or paper type, or if the selected paper loaded in the machine has run out, a caution message appears.

If this message appears, do one of the following:

Print Using a Selected Tray

1 Select the tray for form feed from those that appear on the display panel.

If you want to print after adding paper to the tray, select the tray after loading the correct paper.

☐ To load paper in the bypass tray, see "Setting Paper on the Bypass Tray", *Printer Reference* 1.

2 Press [Continue].

The machine prints using the selected tray.

Note

☐ If a tray with a smaller paper size is selected, the print job may be cut short, or other problems may occur.

Canceling Form Feed

1 Press [Reset].

Delete the stored print job, and then cancel form feed.

Press [Reset Current Job] or [Reset All Jobs].



- [Reset Current Job]: cancels the print job currently being processed.
- [Reset All Jobs]: cancels all jobs in the print queue.
- [Resume Printing]: resumes printing jobs.

A confirmation message appears.

3 Press [Yes] to cancel the print job.

𝚱 Note

☐ Press [No] to return to the previous display.

∰Important

- ☐ If the machine is shared by multiple computers, be careful not to accidentally cancel someone else's print job.
- □ Under Windows, If the machine is connected to the computer using a parallel cable, sent print jobs may be canceled if [Reset All Jobs] is pressed while "Waiting..." is on the display panel. After the interval set in [I/O Timeout] in Printer Features has passed, the next print job can be sent. A print job sent from a different client computer will not be canceled in this case.

- ☐ You cannot stop printing data that has already been processed. For this reason, printing may continue for a few pages after you press [Job Reset].
- ☐ A print job containing a large volume of data may take considerable time to stop.

p.10 "Canceling a Print Job"

4. Troubleshooting

Error & Status Messages on the Display Panel

This section describes the principal messages that appear on the panel display. If a message not described here appears, act according to the message.

Before turning the main power off, see 'Turning On the Power', General Settings Guide.

Status messages

| Message | Status |
|---------------|--|
| Hex Dump Mode | In Hex Dump mode, the machine receives data in hexadecimal format. Turn off the machine after printing, and then turn back on. |
| Offline | The machine is offline. To start printing, switch the machine online by pressing [Offline] on the display panel. |
| Please wait. | The machine is preparing the development unit. Wait a while. |
| Printing | The machine is printing. Wait a while. |
| Ready | This is the default ready message. The machine is ready for use. No action is required. |
| Resetting job | The machine is resetting the print job. Wait until "Ready" appears on the display panel. |
| Waiting | The machine is waiting for the next data to print. Wait a while. |

❖ Alert messages

| Messages/Second messages | Causes | Solutions |
|--|--|---|
| Cannot connect with the wireless card. | The IEEE 802.11b interface unit may have come off, or an error may have occurred in the IEEE 802.11b interface unit. | Turn off the main power switch, and check the IEEE 802.11b interface unit is installed correctly. If the message appears again, contact your sales or service representative. |
| Close duplex unit cover. | The cover of the duplex unit is open. | Close the cover of the duplex unit. |
| Collate has been cancelled. | The collate print function has been canceled. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. |

| Messages/Second messages | Causes | Solutions |
|---|--|---|
| Driver setting error. (Memory) | There is an error in the downloaded font(s). | Reset the parameter for downloading fonts. |
| | Insufficient memory or memory settings for the printer driver may not match memory actually installed. | Specify correct memory capacity on the [Change Accessories] tab in the RPCS TM printer driver. |
| | | To print the image correctly, increase memory capacity, or reduce resolution image. |
| Duplex has been cancelled. | Duplex printing has been canceled. | Check the paper used is suitable for duplex printing. Or, increase memory capacity. When installing a memory module in the machine, contact your sales or service representative. |
| Ethernet board has a problem. | An error has occurred in the Ethernet board. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. |
| Exceeded max capacity of document server. Cannot stored. | Hard disk drive capacity exceeded storing to the Document Server. | Delete some files stored in the Document Server or decrease the file size to be downloaded. |
| Exceeded max number of files of document server. Cannot stored. | The maximum number of files stored in the Document Server has been exceeded. | Delete some files stored in the Document Server. |
| Exceeded max number of pages of document server. Cannot stored. | The maximum number of pages stored in the Document Server has been exceeded. | Delete some pages stored in the Document Server or de- crease the number of pages to be downloaded. |
| Exceeded max. stored files in sample print and locked print. | The maximum number of stored files has been exceeded during Sample Print or Locked Print. | Delete some stored files or reduce file sizes. |
| Exceeded max. stored pages in sample print and locked print. | The maximum number of stored pages has been exceeded during Sample Print or Locked Print. | Reduce the number of pages to be printed. |
| Exceeded max. pages. Collate is incomplete. | The maximum number of pages has been exceeded for collation. | Turn off the main power switch, and back on again. Re- duce the number of pages to be printed. If the message ap- pears again, contact your sales or service representative. |

| Messages/Second messages | Causes | Solutions |
|--|--|--|
| Finisher is in use for another function. Please wait. | The finisher is in use by another function, such as the copier function. | Wait until the other function has finished using the finisher. |
| Following output tray is full. ### Remove the paper. ### | The indicated output tray is full. | Remove the paper. |
| | | |
| HDD has a problem. | An error has occurred in the hard disk drive. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. |
| HDD has not been installed. | Locked Print was performed without the hard disk installed, or the hard disk is damaged. | Contact your sales or service representative. |
| HDD is full. | The maximum hard disk area size for form/font has been exceeded. | Delete unused form / font types. |
| | An HDD overflow error oc- curred during Sample Print or Locked Print. | Delete some stored files, or reduce the size of the file to be downloaded. |
| Wireless LAN has a problem. | IEEE 802.11b interface unit was not inserted when the machine was turned on, or it was pulled out after the machine turned on. | Turn off the machine and check the IEEE 802.11b interface unit is inserted correctly. Then, turn the machine on again. If the message appears again, call your service center. |
| LCT has a problem. Turn Main Power Switch off then on. If the error appears again, call service representative. | An error has occurred in the Large Capacity Tray (LCT). | Turn off the main power switch, wait five minutes, and on again. If the message ap- pears again, call your sales or service representative. |
| Lower Staple is almost empty. | There are only a few staples left in the lower stapler. | Load more staples. |
| NV-RAM has a problem. | An error has occurred in the NV-RAM. | Turn off the main power switch, and back on again. If the message appears again, call your sales or service representative. |
| Output tray has been changed. | The output tray has been changed because of the paper size limitation of the selected tray. | Select the correct output tray. |

| Messages/Second messages | Causes | Solutions |
|--|--|---|
| Paper in duplex unit. Open cover and remove paper. | There is a misfeed in the duplex unit. | Open the cover of the duplex unit, and remove the misfed paper. |
| Paper in staple tray. Open finisher cover and remove paper. | There is paper remaining inside the finisher. | Open the cover of the finisher, and remove the paper. |
| Parallel I/F board has a problem. | An error has occurred in the parallel interface board. | Contact your sales or service representative. |
| Print overrun. | The image data has been thinned out due to image compression. | Increase memory capacity. When installing a memory module in the machine, contact your sales or service representative. |
| Problems with the wireless board. | An error may have occurred in the IEEE 802.11b interface unit. | Turn off the main power switch, and back on again. If the message appears again, |
| Problems with the wireless card. | An error may have occurred in the IEEE 802.11b interface unit. | contact your sales or service representative. |
| Punch has been cancelled. | Punch has been cancelled. | Check the paper feed direction, paper orientation, and punch position. |
| RPCS graphic error. | There is insufficient graphics memory to print the data. | Specify the correct memory capacity on the [Change Accessories] option in the RPCS TM printer driver. |
| | | To print the image correctly, install more memory in the machine, or reduce image resolution. |
| RPCS memory overflow. | A memory overflow occurred during the print job. After part of the data is printed, the print job is suspended. | To print the image correctly, install more memory in the machine, or reduce image resolution. |
| RPCS syntax error. | Bidirectional transmission may not be working properly, or the RPCS™ printer driver settings may not be correct. | Confirm the option settings for the printer driver match the options installed on the machine. |
| Selected paper tray is in use for another function. Please wait. | The specified paper tray is in use by another function, such as the copier function. | Wait until the other function has finished using the specified paper tray. |
| Shift tray has a problem. Call service representative. | A malfunction occurs when using the shift function. | Contact your sales or service representative. |

| Messages/Second messages | Causes | Solutions |
|--|--|---|
| Staple has been cancelled. | Staple printing has been canceled. | Check the paper feed direction, paper orientation and stapling position. |
| Staple unit is in use for another function. Please wait. | The staple unit is in use by another function, such as the copier function. | Wait until the other function has finished using the staple unit. |
| L Toner is almost empty. | The toner has almost run out. | Replace the toner cartridge with a new one. |
| Turn the main power switch off, then check the card. | The IEEE 802.11b interface unit may have come off, or an error may have occurred in the IEEE 802.11b interface unit. | Turn off the main power switch, and check the IEEE 802.11b interface unit is installed correctly. If the message appears again, contact your sales or service representative. |
| Unauthorized user access. Print job has been cancelled. | Print job canceled due to user restrictions. | Check the User Code permission status. |
| USB has a problem. | An error has occurred in the USB interface. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. |

The Machine Does Not Print

| Possible Cause | Solutions |
|---|---|
| Is the power on? | Check the cable is securely plugged into the power outlet and the machine. |
| | Turn on the main power switch. |
| Is the machine online? | If not, press [→ Online] on the display panel. |
| Does the printer function status indicator stay red? | If so, check the error message on the display panel and take required action. |
| Is there a warning status or error message on the display panel? | If so, check the error message or warning status on the display panel and take the required action. |
| Can you print a configuration page? | If you cannot print a configuration page, there maybe a machine malfunction. Contact your sales or service representative. See p.44 "Printing the configuration page" for printing a configuration page. |
| Is the interface cable connected securely to the machine and computer? | Connect the interface cable securely. If it has a fastener, fasten that securely as well. See "Connecting the Machine", Printer Reference 1. |
| Are you using the correct interface cable? | The type of interface cable you should use depends on the computer. Be sure to use the correct one. If the cable is damaged or worn, replace it. |
| | See "Connecting the Machine", Printer Reference 1. |
| Was the interface cable connected after the machine was turned on? | Connect the interface cable <i>before</i> turning on the machine. |
| Is the signal status satisfactory when using wireless LAN in infrastructure mode? | To check signal status, press [User Tools/Counter] on the display panel, and then press [System Settings] on the display panel. On the [Interface Settings] tab, select [IEEE 802.11b], and then press [Wireless LAN Signal]. If signal quality is poor, move the machine to a location where radio waves can pass or remove objects that might cause interference. |
| | ✓ Note☐ You can check signal status only when using wireless LAN in infrastructure mode. |
| When using wireless LAN, is the SSID correctly set? | Check using the machine's display panel that the SSID is correctly set. See "Interface Settings/IEEE 802.11b (Option)", General Settings Guide. |

| Possible Cause | Solutions |
|---|---|
| When using wireless LAN, is the access point correctly set? | Check access point settings when in infrastructure mode. Depending on the access point, client access may be limited by MAC address. |
| | Also, check there are no problems in transmission between access point and wired clients, and between access point and wireless clients. |
| When using wireless LAN, is the LED on the wireless LAN card lit or blinking? | Confirm the orange LED is lit, and the green LED is lit or blinks during transmission. |
| Is the wireless LAN being used in ad hoc mode? | Turn the main power off and back on. See "Turning On the Power", General Settings Guide. |
| | Otherwise, configure [Network] in [Interface Settings] in [System Settings]. See "Setting Up the Machine on a Network", Network Guide. |
| Did you change the option settings on the machine? | When using the RPCS™ printer driver on Windows 2000 and connecting with IEEE 1394, an error may occur if you change the option settings on the machine. In this case, follow the procedure below: |
| | ① Unplug the IEEE 1394 interface cables connected to the computer. |
| | ② Run the utility tool for the IEEE 1394 interface board, which is stored in the following path on the CD-ROM "Printer Drivers and Utilities". \UTILITY\1394\ |
| | ₽ Reference |
| | For more information about using the utility tool for IEEE 1394, see the README file in the same directory on the CD-ROM. |
| | ③ Restart the computer. |
| | ② Connect the computer to the machine using the IEEE 1394 interface cables. |

| Problem | Solutions |
|---|--|
| Is the Data In indicator | If not, data is not being sent to the machine. |
| blinking or lit after starting the print job? | ♦ When the machine is connected to the computer using |
| | the interface cable |
| | Check the machine port settings are correct. For parallel port connection, port LPT1 or LPT2 should be set. |
| | • Windows 95/98/Me |
| | ① Click the [Start] button, point to [Settings], and then click [Printers]. |
| | ② Click the icon of the machine. On the [File] menu, click [Properties]. |
| | ③ Click the [Details] tab. |
| | ④ In the [Print to the following port:] list, confirm the correct port is selected. |
| | • Windows 2000 |
| | ① Click the [Start] button, point to [Settings], and then click [Printers]. |
| | ② Click the icon of the machine. On the [File] menu, click [Properties]. |
| | ③ Click the [Ports] tab. |
| | ④ In the [Print to the following port(s)] list, confirm the correct port is selected. |
| | Windows XP Professional, Windows Server 2003 |
| | ① Click the [Start] button, and then click [Printers and Faxes]. |
| | ② Click the icon of the machine. On the [File] menu, click [Properties]. |
| | ③ Click the [Ports] tab. |
| | ④ In the [Print to the following port(s)] list, confirm the correct port is selected. |
| | Windows XP Home Edition |
| | ① Click the [Start] button, click [Control Panel], click [Printers and Other Hardware], and then click [Printers and Faxes]. |
| | ② Click the icon of the machine. On the [File] menu, click [Properties]. |
| | ③ Click the [Ports] tab. |
| | ④ In the [Print to the following port(s)] list, confirm the correct port is selected. |
| | • Windows NT 4.0 |
| | ① Click the [Start] button, point to [Settings], and then click [Printers]. |
| | ② Click the icon of the machine. On the [File] menu, click [Properties]. |
| | ③ Click the [Ports] tab. |
| | ④ In the [Print to the following port(s)] list, confirm the correct port is selected. |

| Problem | Solutions |
|---|---|
| Is the Data In indicator blinking or lit after starting the print job? | ♦ Network connection Contact your network administrator. |

Other Printing Problems

| Problem | Causes and Solutions |
|--------------------------------------|---|
| The print on the entire page is fad- | If the [Toner Saving] check box is selected in the printer driver settings, the entire page will be faded when printed. |
| ed. | For the RPCS printer driver, [Toner Saving] is located on the [Print Quality] tab. For the PostScript 3 printer driver, see <i>PostScript 3 Supplement</i> |
| | See the printer driver Help. |
| Print is smudges. | Settings for thick paper have not been made when printing on thick paper in the bypass tray. |
| | • PCL 5c and PostScript 3 Select [Thick] in the [Type:] list on the [Paper] tab. |
| | • RPCS TM |
| | Select [Thick] in the [Paper type:] list on the [Print Settings] tab. |
| When printing graphics, the out- | If the printer driver is configured to use the graphics command, the graphics command from the machine is used to print. |
| put and the screen are different. | If you want to print accurately, set the printer driver to print without using the graphics command. |
| | See the printer driver Help. |
| Page layout is not as expected. | Print areas differ depending on machine used. Information that fits on a single page on one machine may not fit on a single page of another machine. |
| | Adjust the [Printable area:] setting in the [Printer Configuration] dialog box on the [Print Settings] tab in the RPCS TM printer driver. |
| | See the printer driver Help. |
| printing is malfunctioning. | Duplex printing cannot be done with paper set in the bypass tray. When using duplex printing, make settings to use paper from a tray other than the bypass tray. |
| | • Duplex printing cannot be done with thick paper, OHP transparencies, or labels specified as the paper type. Specify another paper type. |
| | • Duplex printing cannot be done with a tray for which [1 Sided Copy] has been specified as Paper Type on the System Settings menu. Change the Paper Type setting for the tray to [2 Sided Copy] on the System Settings menu. See <i>General Settings Guide</i> . |

| Problem | Causes and Solutions |
|---|--|
| When using Windows 95/98/Me/2000/XP, Windows Server 2003, or Windows NT 4.0, either combined printing or booklet print does not come out as expected. | Make sure the application's paper size and orientation settings match those of the printer driver. If a different paper size and orientation are set, select the same size and orientation. |
| When using Windows 95/98/Me/2000/XP, Windows Server 2003, or Windows NT 4.0, Auto Reduce/Enlarge print does not come out as expected. | |
| A print instruction was issued from the computer, but printing did not start. | User code management may have been set. Ask the administrator about valid user codes. To print, the user code must be entered from the printer driver. |
| The print job is not canceled even when the machine is switched to offline status. | Even when the machine is offline, printing is performed when [Job acceptance priority] has been set in [Parallel Interface] in the [Interface Settings] in the Eystem Settings menu. Change the setting of Signal Control to Printer priority. See "User Tools (System Settings)", General Settings Guide. |
| Photo images are coarse. | Some applications reduce print resolution. |
| Fine dot pattern does not print. | Make the following settings with the printer driver: Change the [Dithering:] setting on the [Image Adjustments] tab in the [Change User Settings] dialog box on the [Print Quality] tab in the RPCS™ printer driver. Note To enable [Change User Settings], select the [User settings] check box. See the printer driver Help. |
| Images are cut off, or excess is printed. | You may be using paper smaller than the size selected in the application. Use the same size paper as that selected in the application. If you cannot load paper of the correct size, use the reduction function to reduce the image, and then print. See the printer driver Help. |

| Problem | Causes and Solutions | | | | |
|---|---|--|--|--|--|
| It takes a long time to complete a print job. | Photographs and other data intensive pages take a long time for the machine to process, so simply wait when printing such data. | | | | |
| | Changing the following settings with the printer driver may help speed up printing: | | | | |
| | ❖ PCL 5c Select the lowest value for [Resolution] on the [Print Quality] tab in the printer properties dialog box. | | | | |
| | PostScript 3 Set the lower value in [Resolution]. The location of this setting is given below. If your operating system is Windows, select [PostScript (optimize for speed)] in [PostScript Output Option]. [PostScript Output Option] is located as follows: Windows 95/98/Me [Print Quality] tab in the printer properties dialog box. Windows 2000/XP, Windows 2003 Server | | | | |
| | [Print Quality] in [Graphics] on [Advanced] on [Paper Quality] tab in the printer properties dialog box. Windows NT 4.0 [Graphics] on [Advanced] on [Paper Quality] tab in the printer properties dialog box. Mac OS 9.x [Printer Specifications] in the print dialog box. Mac OS X [Set 3] tab in [Printer Features] in the print dialog box. If you use Windows, select [PostScript (optimize for speed)] | | | | |
| | Windows 95/98/Me [PostScript output format:] on the [PostScript] tab in the printer properties dialog box. Windows 2000/XP, Windows Server 2003 [PostScript Output Option] in [PostScript Option] on [Advanced] on [Paper Quality] tab in the printer properties dialog box. | | | | |
| | Windows NT 4.0 [PostScript Output Option] in [PostScript Option] on [Document Options] on [Advanced] tab in the printer properties dialog box. RPCSTM Select the lowest value for [Resolution] on the [Image Adjustments] tab in the [Change User Settings] dialog box on the [Print Quality] tab in the printer properties dialog box. | | | | |
| | Note □ To enable [Change User Settings], select the [User settings] check box Select [Fast] for [Document type] list on the [Print Quality] tab in the printer properties dialog box. See the printer driver Help. | | | | |
| | The data is so large or complex that it takes time to process. If the Data In indicator is blinking, data is being processed. Simply wait until printing resumes. | | | | |

| Problem | Causes and Solutions | | | |
|--|--|--|--|--|
| It takes too much time to resume printing. | The data is so large or complex that it takes time to process. If the Data In indicator is blinking, data is being processed. Simply wait until printing resumes. | | | |
| | The machine was in Energy Saver mode. To resume from Energy Saver mode, it has to warm up, and this takes time. To disable Energy Saver mode, select [Off] for Energy Saver 1 in the System Settings menu. See <i>General Settings Guide</i> . | | | |
| Paper is not fed from the selected tray. | When you are using a Windows operating system, printer driver settings override those set using the display panel. Set the desired input tray using the printer driver. See the printer driver Help. | | | |
| Solid lines are printed as broken lines. | Make the following settings with the printer driver: Change the [Dithering:] setting on the [Image Adjustments] tab in the [Change User Settings] dialog box, on the [Print Quality] tab in the RPCS™ printer driver. See the printer driver Help. | | | |
| Optional components connected to the machine are not recognized when using Windows 95/98/Me, Windows 2000/XP, Windows Server 2003, and Windows NT 4.0. | You have to configure the option setup in printer properties when bidirectional transmission is not enabled. See the printer driver Help. | | | |
| Images are printed in the wrong orientation. | The feed orientation you selected and the feed orientation selected in the printer driver's option setup might not be the same. Set the machine's feed orientation and the printer driver's feed orientation accordingly. See the printer driver Help. | | | |
| The printed image is different from the image on the computer's display. | With certain functions, such as enlargement and reduction, image layout might be different to that on the computer display. | | | |
| | You might have selected to replace True Type fonts with machine fonts in the printing process. To print an image similar to that of the computer display, make settings to print True Type fonts as an image. See the printer driver Help. | | | |

| Problem | Causes and Solutions | | | |
|--|---|--|--|--|
| No transmission when using 1394 interface connec- tion | Check using the following procedure: Confirm the IEEE 1394 interface cable is connected securely. Restart the computer. If the error occurs even after executing the above operation, proceed to the following steps. Unplug the IEEE 1394 interface cable connected to the computer. Run the utility tool for the IEEE 1394 interface board, which is stored in the following path on the CD-ROM "Printer Drivers and Utilities": \UTILITY\1394\ | | | |
| | For more information about using the utility tool for IEEE 1394, see the README file in the same directory on the CD-ROM. (5) Restart the computer. | | | |
| When connecting the machine using USB 2.0, the first page of a print job that contains a large volume of data is printed, but the remaining pages are not. | Check that USB Printing Support is installed on your computer. Page Reference See "Installing the Printer Driver Using USB", Printer Reference 1. | | | |
| Black areas and lines are printed with an unnatural hue. | PCL 5c/PostScript 3 Select [CMY+K] for Gray Reproduction in the printer driver's [Advanced] dialog box under the [Print Quality] tab. RPCS Select [CMY+K] for Gray Reproduction under the [Image Adjustments] tab in the printer driver's [Change User Settings] dialog box. | | | |
| Color documents are printed in black and white. | The printer driver is not set up for color printing. PCL 5c/PostScript 3 Select [Color] for the Color/Black and White under the printer driver's [Setup] tab. RPCS Select [Color] for the Color/Black and White under the printer driver's [Print Settings] tab. For details, see the printer driver Help. | | | |
| Solid areas, lines, or text are shiny or glossy when printed as a mixture of cyan, magenta, yellow. | PCL 5c/PostScript 3 Select [K (Black)] for Gray Reproduction in the printer driver's [Advanced] dialog box under the [Print Quality] tab. RPCS Select [K (Black)] for Gray Reproduction under the [Image Adjustments] tab in the printer driver's [Change User Settings] dialog box. | | | |

| Problem | Causes and Solutions | | | |
|--|---|--|--|--|
| The color of the printout is different from the color on the computer display. | Toner based color settings under the printer driver produce unexpected printout colors. | | | |
| | Changing color settings using the printer driver produces unexpected printout colors. See the printer driver Help. | | | |
| Color registration shifts when printing in color on thick paper. | Press [User Tools/Counter], and then select [Color Registration] from the [Maintenance] menu. | | | |
| There are color differences in color documents. | Press [User Tools/Counter], and then select [Color Registration] from the [Maintenance] menu. | | | |

𝚱 Note

 $\hfill \square$ If the problem cannot be solved, contact your sales or service representative.

5. Printer Features

₽ Reference

For more information about copier features and system settings, see *Copy Reference* and *General Settings Guide*.

Printer Features Menu

There are seven menu items in the Printer Features menu:

- Paper Input
- List/Test Print
- Maintenance
- System
- Host Interface
- PCL Menu
- PS Menu (optional)

You can select the functions in the following table:

| Menu | Default | | |
|--------------------------------|--------------------------|--|--|
| Paper Input | Bypass Paper Size | | |
| See p.44 "Paper Input". | | | |
| List/Test Print | Multiple Lists | | |
| See p.44 "List/Test Print". | Config. Page | | |
| Time . | Error Log | | |
| | Menu List | | |
| | PCL Config. / Font Page | | |
| | PS Config./ Font Page *1 | | |
| | Hex Dump | | |
| Maintenance | Menu Protect | | |
| See p.46 "Maintenance". | 4 Color Graphic Mode | | |

| Menu | Default | | | |
|----------------------------|--------------------------|--|--|--|
| System | Print Error Report | | | |
| See p.47 "System". | Auto Continue | | | |
| | Memory Overflow | | | |
| | Job Separation *2 | | | |
| | Memory Usage | | | |
| | B&W Page Detect | | | |
| | Duplex | | | |
| | Copies | | | |
| | Printer Language | | | |
| | Sub Paper Size | | | |
| | Page Size | | | |
| | Letterhead Setting | | | |
| | Default Printer Language | | | |
| Host Interface | I/O Buffer | | | |
| See p.50 "Host Interface". | I/O Timeout | | | |
| PCL Menu | Orientation | | | |
| See p.50 "PCL Menu". | Form Lines | | | |
| | Font Source | | | |
| | Font Number | | | |
| | Point Size | | | |
| | Font Pitch | | | |
| | Symbol Set | | | |
| | Courier Font | | | |
| | Extend A4 Width | | | |
| | Append CR to LF | | | |
| | Resolution | | | |
| PS Menu (optional) *1 | Data Format | | | |
| See p.52 "PS Menu". | Resolution | | | |
| | Color Setting | | | |
| | Color Profile | | | |

^{*1} Appears when the PostScript 3 unit (optional) is installed.
*2 Appears when the finisher (optional) is installed.

Adjusting Printer Features

main menu.

Printer Features allows basic adjustment of operations when using the machine as a printer.

Although factory default settings are suitable for most printing jobs, Printer Features gives you access to a number of settings that control basic printer operations. Printer Features settings you make are retained even when you turn off the machine.

For more information about copier features and system settings, see *Copy Reference* and *General Settings Guide*.

Press the [User Tools/Counter] key on the control panel.
Press [Printer Features].
Select the desired item by pressing the tab, and then change its settings.
Note
[OK]: Press to make new settings and go back to previous menus.
[Cancel]: Press to return to a previous menu without changing any setting.
After changing Printer Features settings, press [Exit] to return to the User Tools/Counter menu.
Note
You can also exit from the User Tools/Counter menu by pressing the [User Tools/Counter] key.
Changes made to functions remain in effect even if the machine is turned off

☐ You can also exit from the Printer Features menu by pressing **[Exit]** in the

Printer Features Parameters

Paper Input

Bypass Paper Size

The size of the paper set in the bypass tray.

For more information about paper sizes that can be set in the bypass tray, see *General Settings Guide*.

For information about setting paper in the bypass tray, see *Printer Reference* 1.

□ Default:

• Metric version: A4 🗖

• Inch version: $11 \times 8\% \square$

List/Test Print

❖ Multiple Lists

You can print all types of the list such as an error log list.

Config. Page

You can print the machine's current configuration values.

p.44 "Printing the configuration page"

Error Log

You can print error logs listing all the errors that occurred during printing. Up to 30 errors for normal print jobs, and 50 errors for Sample Print jobs only, or Locked Print jobs only, can be printed. In addition to error logs, records of Auto Job Cancel and jobs canceled manually from the control panel can be printed.

Menu List

You can print a Menu List showing the machine's function menus.

❖ PCL Config./ Font Page

You can print the current configuration of installed PCL fonts.

PS Config./ Font Page

You can print the current configuration of installed PostScript fonts.

☐ This menu can be selected only when the optional PostScript 3 board is installed.

♦ Hex Dump

You can print the Hex Dump.


Printing the configuration page

1 Press the [User Tools/Counter] key on the control panel.

The User Tools/Counter menu appears.

2 Press [Printer Features].

The Printer Features menu appears.



Press [Config. Page] on the [List/Test Print] tab.

The configuration page is printed.

Interpreting the configuration page

System Reference

Unit Number

Displays the serial number assigned to the board by its manufacturer.

❖ Total Memory

Displays the total amount of memory (SDRAM) installed on the printer.

Firmware Version

Printer

Displays the version number of the printer firmware.

• System

Displays the version number of the system firmware.

• Engine

Displays the version number of the printer engine.

Panel

Displays the version number of the panel display.

NIB

Displays the version number of the Network interface.

Controller Option

This item(s) appears when the controller option(s) is installed.

HDD: Font/ Macro Download

Displays the capacity of the hard disk drive.

Printer Language

Displays the version number of the printer driver language.

Options

Displays the optional trays installed.

Consumption Status

Shows the amount of toner remaining.

Paper Input

Displays the settings made under the Paper Input menu.

p.44 "Paper Input"

System

Displays the settings made under the System menu.

p.47 "System"

PCL Menu

Displays the settings you made under PCL Menu.

p.50 "PCL Menu"

PS Menu

Displays the settings you made under PS Menu.

p.52 "PS Menu"

Host Interface

Displays the settings you made under the Host Interface menu.

When DHCP is active on the network, the actual IP address, subnet mask and gateway address appear in parentheses on the configuration page.

p.50 "Host Interface"

Interface Information

Displays the interface information.

Maintenance

Menu Protect

This procedure lets you protect menu settings from accidental change. It makes it impossible to change menu settings with normal procedures unless you perform the required key operations. In a network environment, only administrators can make changes to menu settings.

- Level 1
 You can protect "Maintenance",
 "System", "Host Interface" and
 "PCL Menu".
- Level 2
 You can protect "Paper Input",
 "Maintenance", "System",
 "Host Interface" and "PCL
 Menu".
- Off

Ø Note

- ☐ Default: *Off*
- ☐ You can protect menu settings using a Web browser.

❖ 4 Color Graphic Mode

- Photo Priority
 Use the optimum CMYK toner combination for photo printing.
- Text Priority
 Use the optimum CMYK toner combination for text printing.
- Note
- Default: Photo Priority

Setting Menu Protect

1 Press the [User Tools/Counter] key on the control panel.

The User Tools/Counter menu appears.

2 Press [Printer Features].

The Printer Features menu appears.

- Press [Maintenance].
- Enter an access code using the number keys, and then press [OK].
- **5** Press [Menu Protect].
- 6 Select a menu protect level, and then press [OK].
- **7** Press [Exit].

The User Tools/Counter menu appears.

8 Press [Exit].

𝚱 Note

☐ You can also exit the User Tools/Counter menu by pressing the [User Tools/Counter] key.

Canceling Menu Protect

- 1 Press the [User Tools/Counter] key on the control panel.
- 2 Press [Printer Features].
- 3 Press [Maintenance].

A screen for entering the access codes appears.

- 4 Enter an access code using the number keys, and then press [OK].
- Press [Menu Protect].
- 6 Select [Off], and then press [OK].
- 7 Press [Exit].

The User Tools/Counter menu appears.

8 Press [Exit].



☐ You can also exit the User Tools/Counter menu by pressing the [User Tools/Counter] key.

Temporarily canceling Menu Protect

When you select protected items in Printer Features, a screen for entering the access codes appears. When this happens, enter the correct access codes using the number keys, and then press **[OK]**. Menu Protect is then temporarily canceled.

Ø Note

☐ If you enter the correct access codes, Menu Protect remains canceled while the Printer Features menu is displayed.

System

Print Error Report

Select this to have an error report printed when a printer or memory error occurs.

- On
- Off
- Ø Note
- ☐ Default: Off

Auto Continue

You can select this to enable Auto Continue. When it is On, printing continues after a system error occurs.

- Off
- 0 minute
- 1 minute
- 5 minutes
- 10 minutes
- 15 minutes
- **𝚱** Note
- □ Default: Off

Memory Overflow

Select this to have a memory overflow error report printed.

- Not Print
- Error Report
- **𝒯** Note
- ☐ Default: Not Print

Job Separation

You can enable Job Separation.

- On
- Off

Note

- □ Default: *Off*
- ☐ This menu appears only when the optional finisher is installed.

Memory Usage

You can select the amount of memory used in Font Priority or Frame Priority, according to paper size or resolution.

- Font Priority
 This setting uses memory for registering fonts.
- Frame Priority
 This setting uses frame memory for high speed printing.

☐ Default: Frame Priority

❖ B&W Page Detect

- On
- Off

Ø Note

□ Default: On

❖ Duplex

You can select to have print on both sides of each page.

- Off
- Long Edge Bind
- Short Edge Bind

𝒯 Note

☐ Default: Off

Copies

You can specify the number of print sets. This setting is disabled if the number of pages to print has been specified with the printer driver or another command.

• 1 to 999 by 1

∅ Note

☐ Default: 1

Printer Language

Normally, the machine should be set to Auto. If the printer language cannot be detected in Auto, the language specified by Default Printer Language is selected.

- Auto
- PCL
- PS

Note

- □ Default: Auto
- ☐ PS appears only when the optional PostScript 3 board is installed.

Sub Paper Size

You can enable the Auto Substitute Paper Size (A4↔LT) feature.

- Auto
- Off



☐ Default: Off

◆ Page Size

You can select the default paper size.

- 12×18
- 11 × 17
- $8^1/_2 \times 14$
- $8^{1}/_{2} \times 11$
- $5^{1}/_{2} \times 8^{1}/_{2}$
- $7^1/_4 \times 10^1/_2$
- 8×13
- $8^{1}/_{2} \times 13$
- $8^{1}/_{4} \times 13$
- A3
- B4 JIS
- A4
- B5 JIS
- A5
- A6
- 8K
- 16K
- $4^{1}/_{8} \times 9^{1}/_{2}$
- $3^{7}/_{8} \times 7^{1}/_{2}$
- C5 Env
- C6 Env
- DL Env
- Custom Size

Note

- ☐ Default:
 - Metric version: A4 \(\bar{\pi} \)
 - Inch version: $8\% \times 11 \square$

Letterhead Setting

You can rotate original images when printing.

When printing, original images are always rotated by 180 degrees. Therefore, output might not be as expected when printing onto letterhead or preprinted paper requiring orientation. Using this function, you can specify image rotation.

- Off
- Auto Detect
- On (Always)

Note

- □ Default: Off
- ☐ When set to Off, original images are rotated by 180 degrees.
- ☐ When set to Auto Detect, the machine detects a letterhead or preprinted paper automatically, and does not rotate them.
- ☐ When set to On (Always), the machine does not rotate.
- ☐ This function reduces printing speed.

❖ Default Printer Language

You can set the default printer language if the machine cannot find the printer language automatically.

- PCL
- PS

Note

- ☐ Default: PCL
- ☐ PS appears only when the optional PostScript 3 board is installed.

Host Interface

I/O Buffer

You can set the size of the I/O Buffer. Normally it is not necessary to change this setting.

- 128 KB
- 256 KB
- 512 KB
- Note
- ☐ Default: 128 KB

♦ I/O Timeout

You can set how many seconds the machine should wait before ending a print job. If data from another port usually arrives in the middle of a print job, you should increase this timeout period.

- 10 seconds
- 15 seconds
- 20 seconds
- 25 seconds
- 60 seconds
- **Ø** Note
- □ Default: 15 seconds

PCL Menu

Orientation

You can set the page orientation.

- Portrait
- Landscape
- Note
- □ Default: Portrait

Form Lines

You can set the number of lines per page.

• 5 to 128 by 1

- Note
- □ Default:
 - Metric version: 64
 - Inch version: 60

Font Source

You can set the storage location of the default font.

- Resident
- RAM
- HDD
- Note
- □ Default: Resident
- ☐ RAM and HDD can be selected only when fonts have been downloaded to the machine.

Font Number

You can set the ID of the default font you want to use.

- 0 to 50 by 1
- **𝚱** Note
- □ Default: 0

Point Size

You can set the point size you want to use for the selected font.

• 4.00 to 999.75 by 0.25



- ☐ Default: 12.00
- ☐ This setting is effective only with variable-space fonts.

Font Pitch

You can set the number of characters per inch for the selected font.

• 0.44 to 99.99 by 0.01

𝚱 Note

- ☐ Default: 10.00
- ☐ This setting is effective only with fixed-space fonts.

Symbol Set

You can specify the set of print characters for the selected font. The available options are as follows:

Roman-8, ISO L1, ISO L2, ISO L5, PC-8, PC-8 D/N, PC-850, PC-852, PC8-TK, Win L1, Win L2, Win L5, Desktop, PS Text, VN Intl, VN US, MS Publ, Math-8, PS Math, VN Math, Pifont, Legal, ISO 4, ISO 6, ISO 11, ISO 15, ISO 17, ISO 21, ISO 60, ISO 69, Win 3.0

𝚱 Note

□ Default: Roman-8

Courier Font

You can select a courier font type.

- Regular
- Dark

□ Default: Regular

Extend A4 Width

You can extend the printing area width (when printing on A4 sheet with PCL).

- Off
- On

Note

- □ Default: Off
- \square When the setting is On, the width will be 8½ inches.

❖ Append CR to LF

When set to On, a carriage return will follow each line feed: CR=CR, LF=CR-LF, FF=CR-FF.

- Off
- On

Note

☐ Default: Off

Resolution

You can set the print resolution in dots per inch.

- 300 dpi
- 600 dpi (Fast)
- 600 dpi (Standard)

𝒯 Note

☐ Default: 600 dpi (Fast)

PS Menu

This menu appears only when the optional PostScript3 Unit Type 2238 is installed.

Data Format

You can select a data format.

- Binary data
- TBCP

Limitation

- ☐ This setting is not effective when operating the machine with a parallel, USB, or EtherTalk connection.
- ☐ When operating the machine with a parallel or USB connection, if binary data is sent from the printer driver, the print job is canceled.
- ☐ When operating the machine with an Ethernet connection, the print job is canceled under the following conditions;
 - The printer driver data format is TBCP, and the data format selected on the display panel is Binary data.
 - The printer driver data format is binary, and the data format selected on the display panel is TBCP.

Note

☐ Default: Binary data

Resolution

You can set the print resolution in dots per inch.

- 600 dpi (Fast)
- 600 dpi (Standard)
- 1200 dpi

Note

☐ Default: 600 dpi (Fast)

Color Setting

You can make an RGB setting.

- None
- Fine
- Super Fine

Ø Note

□ Default: Super Fine

Color Profile

You can set the color profile.

- Auto
- Presentation
- Solid Color
- Photographic
- User Setting

Ø Note

☐ Default: Auto

6. Appendix

Finisher

You can collate, staple or punch holes in printed paper by installing the optional finisher. Make sure you read the following precautions when using the optional finisher:

For information about optional finishers, see *General Settings Guide*.

To use the staple function, see p.54 "Staple".

To use the punch function, see p.58 "Punch".

Be sure to make settings for options installed on the machine in the printer drivers.

Reference

To make settings for options in the printer drivers, see *Printer Reference* 1.

♦ Be sure to set the paper size and paper orientation in the printer driver when using duplex printing, booklet, combine (layout), staple and punch functions.

₽ Reference

For information about duplex printing, booklet, and layout, see the printer driver Help.

To use the staple function, see p.54 "Staple" and the printer driver Help.

To use the punch function, see p.58 "Punch" and the printer driver Help.

∅ Note

- ☐ Depending on the application, print settings may not be enabled and printed output may not be as expected.
- ♦ When setting staple or collate in the printer driver, make sure that the Collate check box is cleared in the application's [Print] dialog box.

If Collate is enabled in the application, printing will not be as intended.

Staple

With the optional finisher installed, sets can be stapled individually when printing multiple sets.

Staple Position

The specified staple position varies depending on paper size, type, quantity and feed orientation. The following table shows staple positions:

| Paper Orientation on the Machine | Print Data Direction | Staple Position | 2 Tray Finisher | Booklet Finisher |
|----------------------------------|-------------------------|--------------------|--------------------|---------------------|
| Ţ | R | Top Left Slant | R | × |
| | Vertical | Top Right Slant | × | × |
| | | Top Left | R | R |
| | | Top Right | R | R |
| | | 2 at Top | × | × |
| | | 2 at Left | R | R |
| | | 2 at Right | R | R. |
| | | 2 at Center | × | × |
| | R Horizontal | Top Left Slant | × | × |
| | Horizontai | Top Right Slant | R | × |
| | | Top Left | ™ R | ™ R |
| | | Top Right | R | R |
| | | 2 at Top | R | R |
| | | 2 at Left | × | × |
| | | 2 at Right | × | × |
| | | 2 at Center | × | × |

x: means that the staple position is not supported.

GPSTPL2E

| Paper Orientation on the Machine | Print Data Direction | Staple Position | 2 Tray Finisher | Booklet Finisher |
|----------------------------------|-------------------------|--------------------|--------------------|---------------------|
| Ţ | R Vertical | Top Left Slant | × | × |
| | | Top Right Slant | R | × |
| | | Top Left | R | R |
| | | Top Right | R | R |
| | | 2 at Top | R | R |
| | | 2 at Left | × | × |
| | | 2 at Right | × | × |
| | | 2 at Center | × | R.'R |
| | R | Top Left Slant | *R | × |
| | Horizontal | Top Right Slant | × | × |
| | | Top Left | * R | ® R |
| | | Top Right | R | R * |
| | | 2 at Top | × | × |
| | | 2 at Left | R | R |
| | | 2 at Right | R: | R: |
| | | 2 at Center | × | n:n |

 ${\sf x}$: means that the staple position is not supported.

GPSTPL3E

- For paper sizes and maximum numbers of sheets available for stapling, see "Specifications", *General Settings Guide*.
- For printing methods, see the printer driver Help.
- The staple position will vary when using the PostScript 3 printer driver. For more information, see the PostScript 3 printer driver Help.

Stapling Precautions

Limitation ☐ Stapling can be done only with the optional finisher installed. ☐ Stapling cannot be done when paper is fed from the bypass tray. ☐ You cannot interrupt the current job with a job for another function requiring stapling or collating. ☐ When printing on letterhead, stapling may not be at the specified position. Note \square When the finisher is installed, and when an output tray that cannot output using the staple function has been selected, the paper will be output according to System Settings. If you cannot make staple settings even with the finisher installed, options may not be set correctly in the printer driver. Correct option settings in the printer driver. For details, see the printer driver Help. \square When duplex printing is selected, adjust staple positions to the binding orientation. \square When the finisher is being used for another function's job (for example, a copy job), printing will start after that job ends. \square When [Top left slant] or [Top right slant] is selected, the machine tries to staple at an angle. However, if slanted staple is mechanically impossible, the machine staples horizontally or vertically. When setting Staple in the printer driver settings, make sure that a collate option is not selected in the print settings of the application. If a collate option is selected in the application, printing will not be as intended. \square Be sure to set paper size and orientation in the printer driver when stapling. Depending on the software you are using, print settings may not be saved and the printed result may not be as expected. \square When printing restarts after removing jammed paper, the printing position may be different, depending on the location of the jam. If the paper jam occurred in the optional finisher, printing will restart from the top page of the data currently being printed, or from the page where the paper jam occurred.

If the paper jam occurred in the machine, printing will restart from the

Even if the paper jam occurred in the machine, the error will not be cleared

page where the paper jam occurred.

unless the cover of the finisher is opened and closed.

- ☐ Staple printing will be canceled under the following conditions:
 - If the number of staple jobs exceeds maximum. For information about the maximum number, see "Specifications", *General Settings Guide*.
 - If a paper size that cannot be stapled is selected. For information about paper sizes that can be stapled, see "Specifications", *General Settings Guide*.
 - If positions other than those fixed for stapling are specified.
 - If there are inconsistencies between the orientation in duplex mode and the staple position.
 - If paper sizes are mixed when a different paper size is specified during a print job.
 - When staples have run out.
 - When feeding paper from the bypass tray.
 - When staples have run out and Auto Continue is set, printing will continue without stapling after the message has been displayed.
- ☐ When using the optional booklet finisher to select [2 at Center], the print job will be canceled if the staples run out.
- ☐ Paper sizes that can be stapled when using the Mixed Size mode are as follows (enable with the optional 2250 finisher):
 - A3 □ and A4 □
 - B4 □ and B5 □
 - $11" \times 17" \square$ and $81/2" \times 11" \square$
- ☐ When stapling along the fold of a booklet using Booklet Finisher, output is delivered to the lower tray.

Punch

With the optional finisher installed, holes can be punched into printed output.

Punch Position

The specified punch position varies depending on paper feed and print data orientation. The following table shows punch positions:

| Paper Orientation | Print Data | Punch Position | | | |
|-------------------|-----------------|----------------|---------|---------|--|
| on the Machine | Direction | 2 Holes | 3 Holes | 4 Holes | |
| | R Vertical | R R | R | R | |
| | R Horizontal | *R* | Ř | Ŕ | |
| • | R Vertical | Ŕ | R | R | |
| | R Horizontal | R R. | R R | RR | |

𝒯 Note

☐ Punch positions will vary slightly from page to page as holes are punched into each sheet individually.

For information about paper sizes that can be punched, see "Specifications", *General Settings Guide*.

For printing methods, see the printer driver Help.

The punch position will vary when using the PostScript 3 printer driver. For details, see the PostScript 3 printer driver Help.

Punching Precautions

Limitation

 \square Punching cannot be done when paper is fed from the bypass tray.

𝚱 Note


- ☐ If you cannot make punch settings even with the finisher installed, options may not be set correctly in the printer driver. Correct option settings in the printer driver. For details, see the printer driver Help.
- ☐ When duplex printing is selected, adjust punch positions according to binding orientation.
- ☐ Be sure to set the punch position the same as the staple position when using it with the staple function.
- \square Be sure to set paper size and orientation in the printer driver when punching.
 - Depending on the software you are using, print settings may not be enabled and the printed result may not be as expected.
- Punch will be canceled under the following conditions:
 - When a paper size that cannot be punched is selected. For information about paper sizes that can be punched, see "Specifications", *General Settings Guide*.
 - If positions other than those fixed for punching are specified.
 - If there are inconsistencies between the orientation in duplex mode and the punch position.
 - When feeding paper from the bypass tray.
 - When the punch receptacle has become full and Auto Continue is set, printing will continue without punching after the message appears.

Collate

When printing multiple documents such as handouts for meetings, you can separate sets into order. This function is known as "Collate". Collate stores data transmitted from a computer in memory. The following are the three types of collate:


Collate

Printed output is assembled as sets in sequential order.




Rotating Collate

Every other print set is rotated by 90 degrees \square .



Shift Collate

(The optional finisher is required for this function.)
The finisher shift tray moves backward or forward when a job or set is output, causing the next to shift, so you can separate them.



Limitation

- ☐ The optional finisher is required for Shift Collate.
- ☐ Rotating Collate is not possible when feeding paper from the bypass tray.
- \square Shift Collate is not possible when printing on $8^1/2'' \times 5^1/2'' \square$.
- ☐ If jobs containing pages of various sizes are set, Rotating Collate will not work.
- ☐ Rotating Collate, staple and punch functions cannot be combined.

Ø Note

- ☐ You can set Collate in the RPCS[™] printer driver.
 - If you cannot make Shift Collate even with the optional finisher installed, options may not be set up correctly in the printer driver. Correct the printer driver's option settings. For details, see the printer driver Help.
- ☐ If Auto Continue occurs on the first set, Collate will be canceled.
- ☐ If forced printing occurs on the first set, Collate will be canceled.
- \square If a document with mixed paper sizes or sizes larger than A4, $8^1/_2$ "× 11" is set, it can only be collated, even if Rotating Collate has been selected.
- ☐ When Cover/Slip Sheet has been selected, Collate or Shift Collate will occur even if Rotating Collate has been selected.
- ☐ When Rotating Collate has been selected, printing speed will be slower than with other collate functions.
- ☐ When setting Collate in the printer driver settings, make sure that a collate option is not selected in the application's print settings. If a collate option is selected, printing will not be as intended.
- ☐ The Rotating Collate function requires two paper trays containing same size paper but in different orientations.

For information about paper sizes and the number of sets you can use Collate, Rotating Collate, and Shift Collate with in every option, see *Copy Reference*.

For printing methods, see the printer driver Help.

Spool Printing

Spool Printing allows print jobs transferred from a computer to be temporarily stored, and then prints them after they are transferred. This shortens printing time as it maximizes printer efficiency.

∰Important

During Spool Printing, the hard disk is accessed and the Data-In indicator blinks. Turning off the computer or machine during Spool Printing can damage the hard disk. Also, if the computer or machine is turned off during Spool Printing, spooled jobs will be deleted. Therefore, do not turn the power to the computer or machine off during Spool Printing.

Limitation

- ☐ If data is sent to the machine using other protocols besides LPR, IPP or SMB, Spool Printing cannot be performed.
- ☐ Up to a maximum of 150 jobs at once can be spool printed.

Ø Note

- ☐ Printing the first page with Spool Printing will be slow.
- ☐ The computer requires less print processing time when large amounts of data are spooled.

.

☐ Stored spool jobs can be viewed or deleted using a Web browser.

Viewing/Deleting spool jobs in a Web browser

Start the Web browser and enter the machine's IP address in the address bar. This displays the top page.

Example: http://192.168.155.160

(In this example, the IP address of the machine is 192.168.155.160)

Click **[Administrator Mode]**, and then click **[Spool Printing Job List]** to display the spool jobs. To delete, check the box next to the name of the file you want to delete. Enter the password *1, and then click **[Delete]**. For more information, see *Network Guide*.

*1 The default password is "password".

6

Setting Spool Printing

Spool Printing can be set using telnet or a Web browser.

- Using a Web browser Click [Configuration], and then click [Device Settings]. Set [Spool Printing] to [Enable].
 - See Network Guide or Help for more information.
- Using telnet Type in "spoolsw spool on" to set Spool Printing. See *Network Guide* for more information about telnet.

O

Covers

Using this function, you can insert cover and back sheets fed from a different tray to that of the main paper, and print on them.

For printing methods, see the printer driver Help.

Limitation

☐ To use this function, Collate must be set. Rotating Collate cannot be set.


Note

- ☐ The cover sheets should be the same size and orientation as the body of the paper.
- ☐ If Auto Tray Select is set as the paper feed tray for the body paper, the paper will be delivered from a tray containing paper in the ☐ orientation. Therefore, if the cover paper is set to ☐ orientation, the orientation of cover and body will be different.


Cover Sheet

Prints the first page of the document on the sheet for the cover page.


Print on one side
 Prints on one side of the cover sheet only, even when duplex printing is selected.




- Print on both sides
 Prints on both sides of the cover sheet when duplex printing is selected.
 - Front cover printed on both sides




• Front cover printed on one side



- Blank
 - When printing one side




• When printing both sides




Front/Back covers

Prints the first and last page of the document as the cover and back cover pages.


- Print on one side
 Prints on one side of the cover sheets only, even when duplex printing is selected.
 - Back cover page face inside




• Back cover page face outside




- Print on both sides
 Prints on both sides of the cover sheets when duplex printing is selected.
 - Front cover printed on both sides, back cover page face inside, and the number of pages is even




• Front cover printed on both sides, back cover page face inside, and the number of pages is odd




• Front cover printed on one side, back cover page face inside, and the number of pages is even




• Front cover printed on one side, back cover page face inside, and the number of pages is odd



- Blank
 - When printing one side




• When printing both sides




Slip Sheets

Inserting a slip sheet between each page



Inserting a slip sheet between OHP transparencies



Note

- ☐ Collate cannot be set when using slip sheets.
- \square Slip sheets cannot be inserted while duplex printing.
- \Box The slip sheet should be the same size and orientation as the main paper.
- ☐ The same paper feed tray cannot be set for the main paper and slip sheets.

6

User Defined Pages


Using this function, you can specify the page numbers for each input tray.

₽ Reference

For printing methods, see the printer driver Help.

Limitation

- ☐ This function is available with the PCL 5c printer driver only.
- ☐ If [Document Server] is selected under [Job Type:], User Defined Page cannot be used.
- ☐ If [User Defined Pages] is selected under [Paper Selection] on [Paper] tab, [Layout:] and [Duplex:] cannot be selected.



System Settings (Parallel Connection)

Interface Settings/Parallel Interface

Parallel Timing

Specifies the timing for the parallel interface. Normally, you do not need to change this setting.

- ACK inside
- ACK outside
- STB down
- Note
- ☐ Default: *ACK inside*

❖ Parallel Communication Speed

Specifies the communication speed of the parallel interface. If the speed is too high, data may not be transferred smoothly. If this happens, change the setting to "Standard".

- High speed
- Standard
- **𝒜** Note
- ☐ Default: *High speed*

Selection Signal Status

Specifies the signal level of the parallel interface.

- High
- Low
- **𝒯** Note
- ☐ Default: *High*

Input Prime

Specifies whether the prime signal is active or inactive when an input prime signal is sent. Normally, you do not need to change this setting.

- Effective
- Invalid
- Note
- ☐ Default: *Invalid*

Bidirectional Communication

Specifies, for instance, how a printer connected to the parallel interface responds to a status request. If you experience problems using another manufacturer's printer, set this to OFF.

Limitation

- ☐ If set to OFF, asynchronous communication will not work.
- ON
- OFF
- Note
- ☐ Default: ON

Signal Control

Specifies how to handle any errors that occur when printing from a computer or sending faxes. Normally, you do not need to change this setting.

- Job acceptance priority
- Printer priority
- Facsimile priority
- **𝚱** Note
- ☐ Default: *Job acceptance priority*

Precautions when using Windows Server 2003

Precautions when using the Terminal Server mode

Certain printer driver functions are disabled. Disabled functions are displayed in gray. When using all printer driver functions, use Windows Server 2003 in normal mode.

Specifications

This section contains the machine's electrical and hardware specifications, including information about its options.

| Component | Specifications |
|------------------|--|
| Resolution | PCL 5c: 300 dpi, 600 dpi |
| | RPCS™: 300 dpi, 600 dpi, 1200 dpi |
| | PostScript 3: 600 dpi, 1200dpi |
| Printing speed | Color |
| | 24 ppm/28 ppm |
| | B&W |
| | 32 ppm/38 ppm |
| | $(A4 \square, 8\%" \times 11" \square$ plain paper) |
| | Ø Note |
| | ☐ Printing speeds depend on the machine. Check which type of machine you have. See <i>General Settings Guide</i> . |
| Interface | Standard: |
| | IEEE 1284 parallel interface |
| | Ø Note |
| | ☐ Use a standard 36-pin printer cable not longer than 3 meters (10 feet). |
| | Ethernet interface (100BASE-TX/10BASE-T) |
| | Option: |
| | IEEE 1394 interface |
| | IEEE 802.11b wireless LAN interface |
| | USB 2.0 interface |
| | Bluetooth TM interface |
| Network protocol | TCP/IP, IPX/SPX, NetBEUI *1 , AppleTalk |
| Printer language | Standard: PCL 5c, RPCS TM |
| | Option: PostScript 3 |
| Fonts | PCL 5c: |
| | Agfa Monotype Font Manager 35 Intellifonts, 10 TrueType fonts, and 1 Bitmap font Font Manager available. |
| | PostScript 3: |
| | 136 fonts (Type 2:24, Type 14:112) |
| Memory | 512 MB |
| Hard disk | Storage capacity: 40 GB x2 |

| Component | Specifications |
|---|--|
| Operating systems supported by this machine | Windows 95/98/Me Windows 2000 |
| | Windows XP |
| | Windows Server 2003 |
| | Windows NT 4.0 |
| | Mac OS 8.6 to 9.2 |
| | Mac OS X |
| Network cable | 100BASE-TX/10BASE-T shielded twisted-pair (STP, Category/Type5) cable. |

^{*1} To use NetBEUI, use the SmartNetMonitor port.

Options

Limitation

□ Only one optional interface board can be installed in the machine at a time. Therefore, the optional IEEE 1394 interface board, the IEEE 802.11b interface unit, the USB 2.0 interface board, and Bluetooth interface unit cannot be installed concurrently.

IEEE 1394 Interface Board Type B

Transmission spec.:

IEEE 1394

Interface:

IEEE std 1394-1995 compliant IEEE std 1394a-2000 compliant

Device class:

SCSI print (Windows 2000/XP, Windows Server 2003) IP over 1394 (Windows Me/XP, Windows Server 2003)

❖ Protocol:

SBP-2 (SCSI print) TCP/IP (IP over 1394)

Interface connector:

IEEE 1394 (6 pin × 2)

❖ Required cable:

1394 interface cable (6 pin x 4 pin, 6 pin x 6 pin)

∰Important

- ☐ You cannot plug devices together to create loops.
- \square Do not use cable that is more than 4.5 meters in length.

Data transfer speed:

Maximum 400 Mbps

Connectable number of devices on a bus:

Maximum 63

Allowed cable hops on a bus:

Maximum 16

❖ Power supply:

Non external power supply Cable Power repeated (IEEE 1394a-2000 compliant)

IEEE 802.11b Interface Unit Type C

❖ Transmission spec.:

Based on IEEE 802.11b (wireless LAN)

Protocol:

TCP/IP, NetBEUI, IPX/SPX, AppleTalk

𝚱 Note

☐ SmartNetMonitor and Web browser are supported.

Data transfer speed:

Auto select from below speed 1Mbps, 2Mbps, 5.5Mbps, 11Mbps

Frequency range:

- Inch version: 2400-2497 MHz (1-11 channels)
- Metric version: 2400-2497 MHz (1-13 channels)

Transmittable distance:

1Mbps 400 m *1 2Mbps 270 m *1 5.5Mbps 200 m *1 11Mbps 140 m *1

Transmission mode:

802.11 ad hoc, ad hoc, and infrastructure mode

^{*1} These figures are a guideline for outdoor use. In general, the transmittable distance indoors is 10-100 m, depending on environment.

USB2.0 Interface Board Type B

❖ Transmission spec:

Based on USB 2.0

Data transfer speed:

High Speed: 480 Mbps Full Speed: 12 Mbps

Supported operating system:

Windows 98 SE/Me/2000/XP, Windows Server 2003, Mac OS 9.x, Mac OS X Classic

- ☐ This USB 2.0 interface board is compatible with devices that support USB 1.1.
- ☐ For Windows 98 SE/Me, be sure to install USB Printing Support included on the CD-ROM that comes with this machine. When USB 2.0 is used under Windows 98 SE/Me, only a speed equal to that of USB 1.1 is possible.
- ☐ Mac OS supports only the standard USB 1.1 port.

PostScript 3 Unit Type 2238

PostScript 3 Unit Type 2238 Operating Instructions Supplement

Bluetooth Interface Unit Type 2238

See the manual that comes with optional Bluetooth interface unit.

INDEX

| В | М |
|---|--|
| Bluetooth Interface Unit Type 2238, 75 C Canceling a job | Mac OS canceling a job, 11 setting up, printer driver, 9 Maintenance, 46 |
| Mac OS, 11 Windows, 10 Collate, 60 Configuration page, 44 Control panel | Memory, 72 N Network Cable, 73 Network protocol, 72 |
| locked print, 15 printer features, adjusting, 41 sample print, 15 | O Operating system, 73 |
| Covers, 64 | Options, 73 |
| Data In indicator, 32, 36, 37 Display panel error messages, 25 Document Server, 13 | Paper Input, 44 PCL menu, 50 PostScript 3 Unit Type 2238, 75 Precautions when using the Terminal |
| Error messages, 25 | Server mode Windows Server 2003, 71 Precautions when using Windows Server 2003 |
| Finisher, 53 Fonts, 72 | Windows Server 2003, 71 Printer driver Printer properties, Windows 2000/XP, Windows Server 2003, 6 Printer properties, Windows 95/98/Me, 5 |
| Hard disk, 72 | Printer properties, Windows NT 4.0, 7 setting up, Mac OS, 9 Printer features |
| Host Interface, 50 | adjusting, 43 menu, 41 parameters, 44 Printer Language, 72 |
| IEEE 1394 Interface Board Type B, 73 IEEE 802.11b Interface Unit Type C, 74 Interface, 72 | Printer Language, 72 Printing speed, 72 Punch, 58 |
| L | |
| List/Test Print, 44 Locked print, 19 deleting, 20 | Resolution, 72 |

S

Sample print, 15 deleting, 17 Slip Sheets, 68 Specifications, 72 Spool printing, 62 Staple, 54 System, 47

T

Troubleshooting, 25
error messages, 25
machine does not print, 30
other printing problems, 34
status messages, 25

U

USB2.0 Interface Board Type B, 75

W

Windows
canceling a job, 10
Windows 2000/XP, Windows Server 2003
printer properties, printer driver, 6
Windows 95/98/Me
printer properties, printer driver, 5
Windows NT 4.0
printer properties, printer driver, 7

FAX Option Type 2238

Operating Instructions Facsimile Reference <Basic Features>



- 1 Getting Started
- 2 Faxing
- (3) Using Internet Fax Functions
- 4 Programming
- 5 Troubleshooting

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Trademarks

Microsoft® and Outlook® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe® and Acrobat® are registered trademarks of Adobe Systems Incorporated.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1"Operating Instructions for Printer/Scanner"
 - CD-ROM 2"Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

♦ Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

❖ Facsimile Reference <Basic Features>(this manual)

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference<Advanced Features>

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an
 overview of ScanRouter V2 Lite functions. This guide is added to the [Start]
 menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- Unix Supplement (Available from an authorized dealer, or as a PDF file on our Web site.)

Note

- $\ensuremath{\square}$ The following software products are referred to using a general names:
 - Desk Top
Binder V2 Lite and Desk top Binder V2 Professional \rightarrow Desk top
Binder V2 Lite/Professional
 - ScanRouter V2 Lite and ScanRouter V2 Professional (optional) → Scan-Router V2 Lite/Professional
 - SmartNetMonitor for Admin and SmartNetMonitor for Client → Smart-NetMonitor for Admin/Client

TABLE OF CONTENTS

| Manuals for This Machine | i |
|--|----|
| How to Read This Manual | 1 |
| Symbols | 1 |
| 1. Getting Started | |
| Control Panel | |
| Reading the Display | |
| Reading the display panel and using keys | |
| Reading the display pariel and using keys | |
| Standby display | |
| Communication display | |
| User code entry display | |
| 2. Faxing | |
| Transmission Modes | 11 |
| Switching between Memory Transmission and Immediate Transmission | |
| Placing Originals | |
| Placing a Single Original on the Exposure Glass | |
| Bound original page order | |
| Placing Originals in the Optional Auto Document Feeder (ADF) | 15 |
| Originals unsuitable for the optional Auto Document Feeder | 16 |
| Setting a Scan Area | |
| Original sizes difficult to detect | |
| Memory Transmission | 20 |
| Canceling a Memory Transmission | 24 |
| Before the Original Is Scanned | |
| While the Original Is Being Scanned | 24 |
| While the Original Is Being Transmitted | 24 |
| Before the Transmission Is Started | |
| Immediate Transmission | |
| Canceling an Immediate Transmission | 29 |
| Before You Have Pressed the [Start] Key | |
| After You Have Pressed the [Start] Key | |
| Scan Settings | |
| Resolution | |
| Original Type | |
| Image Density (Contrast) | |
| Mixing Scan Settings for a Multiple Page Original | |
| When placing originals on the exposure glass | 34 |
| | |
| Specifying a Destination | |
| Entering a Fax Number | |
| Pause Tone | |
| Entering an E-mail Address | |
| Using Destination Lists | |

| Searching for a Destination | |
|--|----|
| Search by Destination Name | |
| Search by Fax Number | |
| Search by E-mail Address | |
| Specifying a Registration Number | 44 |
| Reception | 46 |
| Switching the Reception Mode | 46 |
| Receiving a Fax in Manual Reception Mode | 47 |
| 3. Using Internet Fax Functions | |
| Internet Fax Functions | 49 |
| Internet Fax Precautions | 50 |
| Functions Not Supported by E-mail Transmission | 50 |
| Functions Not Supported by E-mail Reception | |
| Sending Internet Fax Documents | 52 |
| Confirming Reception | |
| Canceling a Transmission of an Internet Fax | |
| Before the Original Is Scanned | |
| While the Original Is Being Scanned In | |
| After the Original Has Been Scanned In | |
| Receiving Internet Fax | |
| Auto E-mail Reception | |
| Manual E-mail Reception | |
| Received Images | |
| 4. Programming | |
| | |
| Initial Settings and Adjustments | |
| Programming | |
| Editing | |
| Deleting | |
| Programming Fax Numbers and E-mail addresses | 71 |
| 5. Troubleshooting | |
| Adjusting the Volume | |
| When the [Facsimile] Key Is Lit in Red | |
| When Toner Runs Out | |
| Error Messages and Their Meanings | |
| | |
| Solving Problems | |
| When Things Don't Go as Expected | 82 |
| INDEX | 83 |

How to Read This Manual

Symbols

In this manual, the following symbols are used:

↑ WARNING:

This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

A CAUTION:

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

* The statements above are notes for your safety.

#Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates information or preparations required prior to operating.

Note

This symbol indicates precautions for operation, or actions to take after abnormal operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions under which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys that appear on the machine's display panel.

[]


Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

1. Getting Started

Control Panel

The actual machine control panel may differ from this illustration depending on installed optional units. This illustration has all options installed.



1. [User Tools/Counter] key

User Tools:

Press to enter User Tools mode. These tools allow you to customize default settings. See p.139 "Facsimile Features", Facsimile Reference < Advanced Features>.

Counter:

Displays and prints the total number of copied or printed pages.

2. Communicating indicator

Lights during transmission or reception.

3. Receive File indicator

Lights when a message other than a Confidential Reception or Memory Lock file is received. See p.86 "Substitute Reception", Facsimile Reference < Advanced Features>.

When Reception File Setting is set to Store, also lights when a message is received. See p.186 "Storing or Printing Received Documents", Facsimile Reference <Advanced Features>.

4. Confidential file indicator

Lights when a message is received into memory with Confidential Reception or Personal Box. See p.41 "Printing Personal Box Messages", Facsimile Reference < Advanced Features>.

Blinks when a Memory Lock file is received into memory. See p.38 "Printing a File Received with Memory Lock", Facsimile Reference < Advanced Features>.

5. Indicators

Shows errors and machine status.

: Service Call indicator

%: Misfeed indicator

: Open Cover indicator

: Add Staple indicator

▲: Add Toner indicator

i: Paper run-out indicator

See "Control Panel", General Settings Guide.

6. Display Panel

This guides you through tasks and displays the machine status. Messages appear here.

7. [Check Modes] key

Press before pressing the **[Start]** key to check the settings selected for the fax about to be sent. See p.23 "Checking the transmission settings"

8. [Program] key

Enables you to program frequently used settings and recall previously programmed settings. See p.127 "Programs", Facsimile Reference < Advanced Features>.

9. [Clear Modes] key

Press to cancel the current settings.

10. On indicator

This indicator lights when the operation switch is turned on.

∰Important

Do not turn off the main power switch while the On indicator stays lighted or is blinking. Neglecting this may damage the hard disk.

Note

☐ If the main power switch is on even when the On indicator is off, the machine will receive a fax message.

11. Main Power indicator

This indicator lights when the main power switch is turned on.

12. Operation switch

Press to turn the power on (the On indicator lights). To turn the power off, press this switch again (the On indicator goes off). See p.190 "Turning Off the Main Power / When a Power Failure Occurs", Facsimile Reference < Advanced Features>.

The Operation switch does not function when the [User Tools/Counter/Inquiry] display is shown.

13. Function status indicators

- When lit green, the corresponding function is active.
- When lit red, the corresponding function is interrupted. Press the respective key and then follow the instructions that appear on the screen.

14. ♦ Data In indicator

Lights when there is data remaining to be printed.

Blinks when data is being received.

15. Function keys

Press the [Copy], [Document Server], [Facsimile], [Printer], or [Scanner] key to activate the respective function. The display content changes accordingly.

The indicator for the selected function lights up.

16. [Start Manual RX] key

Press when Manual Reception is set. See p.47 "Receiving a Fax in Manual Reception Mode".

17. [On Hook Dial] key

Press when you want to dial while hearing tone from the internal speaker. See p.56 "On Hook Dial", Facsimile Reference <Advanced Features>.

18. [Pause/Redial] key

Pause:

Inserts a pause when you are dialing or storing a fax number. A pause cannot be inserted as the first digit. See p.35 "Pause".

Redial:

Press to redial one of the last ten numbers. See p.47 "Redial", Facsimile Reference <Advanced Features>.

19. [Tone] key

Press to send tonal signals down a pulse dialing line. See p.36 "Tone".

20. Number keys

Use to dial fax numbers, or enter the number of copies.

21. [#] key (Enter key)

Registers entered contents or settings.

22. [Clear/Stop] key

Clear:

Cancels entered numbers or characters.

Stop:

Interrupts the current operation (transmission, scanning, copying, or printing).

23. [Start] key

Press to start faxing, or printing reports, or lists

Reading the Display

The display shows you the machine status, messages, and guides you through operations.


Note

☐ This machine automatically returns to standby mode if you do not use the machine for a certain period of time. You can select the period using the Fax Reset Timer. See "Timer Settings", General Settings Guide.

Reading the display panel and using keys


Display contents will differ depending on installed optional units.

Initial Display



- 1. Allows you to select scanning conditions and sizes.
- 2. Displays the date and time, the name and facsimile number of a destination when transmitting, and the size of the original.
- 3. Press to add a destination by entering a fax number or e-mail address.
- 4. Displays messages and the machine status.
- 5. Displays the entered number of a destination. When adding destinations using the number keys, press [Add].
- 6. Press to display various information about transmission.

- 7. Switches transmission mode between Memory Transmission and Immediate Transmission.
- 8. Displays Quick Operation keys set for often used functions. [TX File Status] and [RX File Status] are preset.
- 9. Displays various functions for transmitting.
- 10. Displays the destination lists of programmed destinations.
- Initial Display (When Internet Fax Setting is ON)



71.JS030F


1. Switches the destination between fax number and e-mail address.

☐ You also need to set Internet Fax Setting to ON in Fax Features. See p.147 "E-mail Settings", Facsimile Reference <Advanced Features>.

Reading the destination list

When using the facsimile function, only fax and Internet Fax destinations programmed in the Address Book appears.

Destination List




71 10000

- 1. Title word keys appear. Allows you to switch from one page (display) to another on the destination list.
- 2. Allows you to search for a destination by destinatin name, fax number, e-mail address or registration number.
- 3. Appears on Quick Dial keys programmed as a transfer station.
- 4. Appears on Quick Dial keys programmed with a group of destinations.

Standby display

While the machine is in standby mode (immediately after the **[Facsimile]** key is pressed or after the **[Clear Modes]** key is pressed), the following display appears.

Memory Transmission (initial display)



Immediate Transmission



Note

- ☐ To return to standby mode, do one of the following:
 - If you have placed the original in the optional Auto Document Feeder (ADF) and have not pressed the [Start] key, remove the original.
 - If you have not placed an original, press the [Clear Modes] key.
 - If you are in User Tools mode, press the [User Tools/Counter] key.

Communication display

While communicating, the machine status is displayed.

Memory Transmission (fax transmission)



𝚱 Note

☐ While e-mail is being sent, the "Sending E-mail...:" message appears.

Reception



☐ Even when the machine is being used as a copier, printer, or scanner, the sender name or number will appear for received faxes.

Immediate Transmission



User code entry display

When the following message appears on the display, User Code Management is active. Enter a user code to deactivate User Code Management.



The machine can be set up so that no one can use it without entering a user code. This prevents unauthorized people from sending fax messages and helps track the activity of each user or department.

Note

- ☐ You can specify a user code with "System Settings". See "Registering a New User Code", *General Settings Guide*.
- ☐ Even when User Code Management is on, you can still receive and print fax messages as normal.
- 1 Enter a user code of up to eight digits using the number keys.
- 2 Press [#].

Note

☐ If an unprogrammed user code is entered, the display returns to that of step ①.

2. Faxing

Transmission Modes


There are two types of transmission:

- Memory Transmission
- Immediate Transmission

Memory Transmission


Transmission starts automatically after the original has been stored in memory. It is a convenient method for when you are in a hurry and want to take the document away with you. You can also send the same original to several destinations (broadcasting).

☐ You can use Parallel Memory Transmission that dials while the original is being scanned. See p.78 "Parallel Memory Transmission", Facsimile Reference < Advanced Features > .



Immediate Transmission

Immediately dials the destination number, and while reading the original, sends it. It is very convenient when you want to send an original quickly or when you want to check the destination you are sending to. When using this type of transmission, the original is not stored in memory. You can only specify one address.




∰Important

☐ If power outage lasts about an hour, or the machine is disconnected from the power outlet for about an hour, documents stored in the fax machine's memory are deleted. If any document is deleted, the Power Failure Report is automatically printed out when the main power switch is turned on. Use this report to check which documents were deleted. Simply turning off the power by pressing the Operation switch does not delete stored documents. See p.190 "Turning Off the Main Power / When a Power Failure Occurs", Facsimile Reference <Advanced Features>.

Switching between Memory Transmission and Immediate Transmission

Check the display to see which mode is currently active. You can change transmission mode by pressing [Immed. TX] or [Memory TX].




- ☐ You can select the transmission mode that is operative when the machine is turned on with [Memory/Immed. Transmission Switch] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- ☐ You can have the machine return to default mode after each transmission using [Scan End Reset] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

Placing Originals


You can place the originals either in the optional ADF or on the exposure glass. Some types of originals are unsuitable for the ADF, so they must be placed on the exposure glass.

Which way you place the original depends on its size and whether you are using the ADF or the exposure glass. See p.19 "Original sizes difficult to detect".

How to place A4, B4 JIS (Japanese Industrial Standard), A3, 8¹/₂"×11", $8^{1}/_{2}$ "×14", and 11"×17" size originals



How to place A5 and B5 JIS size originals



- ☐ When you place originals as shown in the above illustrations. the fax header will be printed on received faxes at the destination as follows:
 - *1 On the top of the fax
 - *2 On the left side of the fax

Limitation

☐ If you place A5 size documents on the exposure glass, they will not be detected. A5 size documents placed in the ADF are sent. See p.19 "Original sizes difficult to detect".

- ☐ When sending a fax, the image output at the other end depends on the size and orientation of paper used in the receiver's terminal. If the receiver does not use paper of the same size and orientation as that of the original, the fax image may be reduced in size, trimmed at both edges, or divided into two or more sheets. When sending an important original, we recommend you ask the receiver about the size and orientation of the paper used in their terminal.
- When sending an original of irregular (i.e. custom) size or part of a large original, you can specify the scan area precisely. See p.16 "Setting a Scan Area".

- ☐ Custom size documents are scanned as regular size documents, so the receiver may find extra blank margins or edges of images missing. If you specify a scan area, only that area will be scanned regardless of actual document size.
- ☐ Make sure that all ink, correcting fluid etc., has completely dried before placing your original. If it is still wet, the exposure glass will be marked and those marks will appear on the received image.
- ☐ If you place an A4 size original in the portrait orientation, the machine rotates the image by 90 degrees before sending. See p.80 "Transmission with Image Rotation", Facsimile Reference < Advanced Features>.
- ☐ You can send the first pages from the exposure glass then the remaining pages from the ADF. After you have removed the last page from the exposure glass, insert the remaining pages in the ADF, and then press the **[Start]** key.
- ☐ When using the Internet Fax function, documents transmitted are sent at A4 width. Documents larger than A4 are reduced to A4 width.


For how to place two-sided documents, see p.62 "Two-Sided Transmission (Double-Sided Transmission)", Facsimile Reference <Advanced Features>.

For acceptable types of originals, see p.199 "Acceptable Types of Originals", Facsimile Reference < Advanced Features>.

Placing a Single Original on the Exposure Glass

Place originals that cannot be placed in the optional ADF, such as a book, on the exposure glass one page at a time.

- **1** Lift the exposure glass cover or the ADF by at least 30 degrees.
 - Ø Note
 - ☐ If you do not lift the ADF by at least 30 degrees, the original size will not be detected.
- Place the original face down and align its upper left corner with the reference mark at the upper left corner of the exposure glass.



- 1. Positioning mark
- 2. Scale
- 3 Lower the ADF.

 - When setting a bound original, the received image may contain some black areas. To reduce this effect, hold down the original to prevent the bound part from rising.

Bound original page order

When setting bound originals (books, magazines, etc.), you can select to have either the left page or right page sent first. See p.61 "Book Fax", Facsimile Reference < Advanced Features>.

Note

☐ You can select whether the left page or right page is sent first. See p.161 "User Parameters", Facsimile Reference <Advanced Features> (switch 06, bit 6).

Placing Originals in the Optional Auto Document Feeder (ADF)

Use the ADF to scan in a stack of originals in one operation. The ADF can handle both one-sided and two-sided originals.


Limitation

- ☐ Place all the originals to be sent in a single stack.
- You cannot place originals in the ADF one page at a time or in sheaves.

Note

- ☐ The maximum document length is 1200 mm (47").
- □ If you send documents longer than 420 mm (17"), specify the area to be scanned. If you send such documents frequently, select Long Document mode with the User Parameters. If a jam occurs, the document might be damaged because scanning will not stop. See p.16 "Setting a Scan Area". See p.161 "User Parameters", Facsimile Reference < Advanced Features > (switch 14, bit 1).

- ☐ Documents longer than 800 mm (32") must be sent by memory transmission (immediate transmission is not possible).
- ☐ If your original is bent or folded, flatten it before you place it.
- ☐ When sending thin originals, place them on the exposure glass.
- ☐ If an original jammed, press the **[Clear/Stop]** key, and then slowly remove the original.
- ☐ You can check information about the sizes and number of originals that can be placed in the ADF. See p.199 "Acceptable Types of Originals", Facsimile Reference <Advanced Features>.
- 1 Adjust the document guide to match the size of the originals.
- 2 Align the edges of the originals and stack them in the ADF face up.



1. Limit mark

2. Document guide

Originals unsuitable for the optional Auto Document Feeder

Do not place the following types of originals in the ADF because they may be damaged. Place them on the exposure glass instead.

- Originals in unacceptable sizes (See p.199 "Acceptable Types of Originals", Facsimile Reference < Advanced Features>.)
- Originals containing staples or clips
- Perforated or torn originals
- Curled, folded, or creased originals
- · Pasted originals
- Originals with any kind of coating, such as thermosensitive paper, art paper, aluminum foil, carbon paper, or conductive paper
- Originals with index tabs, tags, or other projecting parts
- Sticky originals, such as translucent paper
- Thin and soft originals
- Originals of inappropriate weight (See p.199 "Acceptable Types of Originals", Facsimile Reference < Advanced Features> .)
- Originals in bound form, such as books
- Transparent originals, such as OHP transparencies or translucent paper

Setting a Scan Area

Normally, a placed document is scanned according to the automatically detected size. If a scan area is specified, the document is scanned accordingly. Thus, documents can be sent without extra space or blank margins.

Auto Detect

Detects the size of the first page and scans all pages using that size. If you want to scan originals of different sizes, use the Mixed Original Sizes function.

Note

 If the machine cannot detect the original size, a confirmation message appears. Replace the original.

Regular

The placed document is scanned according to specified size regardless of actual size.

The sizes that can be specified are A4 $\square \square$, B4 JIS \square , A3 \square , $8^1/2"\times11" \square \square$, $8^1/2"\times14" \square$, and $11"\times17" \square$.

Area

Enter the area to be scanned. Only the area in the specified size is scanned regardless of the actual size of a placed document. See p.154 "Programming, Changing and Deleting a Scan Size", Facsimile Reference < Advanced Features>.


Mixed Original Sizes

Select this to individually scan the size of originals loaded in the ADF. For example, when A4 and B4 JIS size originals are sent together, usually all are sent using the size of the first original. By selecting Mixed Original Sizes, the machine scans and sends each document according to its size.

- ☐ To cancel the selected scan area, select [Auto Detect]. See p.18 "Specifying Auto Detect".
- When using the Mixed Original Sizes, the machine sends the originals by memory transmission.
- □ When using the Mixed Original Sizes, rotation transmission is disabled. See p.80 "Transmission with Image Rotation", Facsimile Reference < Advanced Features>.
- Place the originals, and then select any scan settings you require.

Ø Note


- ☐ When placing different size originals into the ADF, adjust the document guide to the largest original.
- ☐ Small-size originals may be sent at a slight slant since they do not match the document guide.
- 2 Press [Scan Area].



3 Select the scan area.

Specifying standard sizes

1 Press [Regular].




2 Press the size of the originals to be sent, and then press [OK].



Note

8¹/₂"×11" indicates LT. 8¹/₂"×
 14" indicates LG. 11"×17" indicates DLT.


3 Press [OK].




The selected size is shown above the highlighted [Scan Area].

Specifying programmed sizes

1 Press [Area 1] or [Area 2].




2 Press [OK].




"Area 1" or "Area 2" is shown above the highlighted [Scan Area].

Specifying Mixed Original Sizes

• Press [Mixed Original Sizes].




2 Press [OK].



"Mixed Original Sizes" is shown above the highlighted [Scan Area].


Specifying Auto Detect

Make sure that [Auto Detect] is selected.



If it is not, press [Auto Detect].

2 Press [OK].



"Auto Detect" is shown above [Scan Area].

A Specify a destination and press the [Start] key.

Original sizes difficult to detect

The machine finds it difficult to detect the size of the following kinds of originals. If this happens, the receiving machine may not select print paper of the correct size.

- Documents placed on the exposure glass of sizes other than those listed in the table below
- Originals with index tabs, tags, or protruding parts
- Transparent originals, such as OHP transparencies or translucent paper
- Dark originals with dense text or drawings
- · Originals which partially contain solid printing
- Originals which have solid printing around their edges
- Originals with glossy surfaces
- Bound originals of more than 10 mm (0.3") in thickness, such as books.

The following paper sizes are automatically detected in facsimile mode.

Metric Version

| Paper size where original is placed | A3 D | 8 ¹ / ₂ "×13" (F4) | B4 JIS □ | A4 D □ | B5 JIS □ | A5 🕽 🗗 |
|-------------------------------------|-------------|---|-----------------|--------|-------------|--------|
| Exposure glass | О | О | О | О | О | × |
| ADF | О | О | О | О | О | О |

Inch Version

| Paper size where original is placed | 11"×17"□ | 8 ¹ / ₂ "×14"□ | 8 ¹ / ₂ "×11" | 5 ¹ / ₂ "×8 ¹ / ₂ " |
|-------------------------------------|----------|--------------------------------------|-------------------------------------|---|
| Exposure glass | О | О | О | × |
| ADF | О | О | О | О |

O - Auto detect

× - Unable to auto detect

Memory Transmission

In Memory Transmission mode, after you press the [Start] key, the machine does not dial the destination until all pages of your fax message have been scanned into memory (in contrast to Immediate Transmission, where the number is dialed first and pages are scanned and sent one by one).

Memory Transmission is useful because:

- You can take your original away from the machine without having to wait too long.
- While your message is being sent, other people can use the machine.
- You can send the same message to more than one place in a single operation (broadcasting).

Memory transmission mode has normal fax and Internet Fax functions.

#Important

- ☐ If there is a power failure (the main power switch is off) or the machine is unplugged out for more than one hour, all the documents stored in memory are deleted. As soon as the main power switch is turned on, the Power Failure Report is printed to help you identify deleted files. If you turn only the operation switch off, documents are not deleted. See p.190 "Turning Off the Main Power / When a Power Failure Occurs", Facsimile Reference <Advanced Features>.
- We recommend you call the receiver and confirm with them when sending important messages.

Limitation


☐ If memory is full (0% appears on the display), Memory Transmission is disabled. Use Immediate Transmission instead.

- ☐ Maximum number of destinations per Memory Transmission: 500.
- ☐ Combined total number of destinations of standby messages stored in memory: 500 (2,000 with the optional fax function upgrade unit).
- ☐ After the total number of programmed destination numbers exceeds 500 (2,000 with the optional fax function upgrade unit), you can perform only Immediate Transmission.
- ☐ The number of documents you can store is 400. You can store 800 documents with the optional fax function upgrade unit.
- ☐ The number of pages you can store in memory depends on the original images and the scan settings. You can store up to 320 standard pages (ITU-T #4 chart, Resolution: Standard, Original Type: Text). You can store up to 2,240 standard pages, with the optional expansion memory installed.
- ☐ You can have the machine set to Memory Transmission mode or Immediate Transmission mode right after the power is turned on or the **[Clear Modes]** key is pressed. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

- ☐ You can have the machine return to the default transmission mode (Memory Transmission or Immediate Transmission) after every transmission. You can change this so that the desired setting is maintained. See p.144 "General Settings/Adjustment", Facsimile Reference < Advanced Features>.
- □ When E-mail TX Results is programmed in a Quick Operation key, you can select whether transmission result report e-mail is sent to specified e-mail addresses. The destination for notification is selected from Internet Fax destinations in the destination list. See p.83 "Transmission Result Report (Memory Transmission)", Facsimile Reference <Advanced Features> and p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- ☐ Allows you to specify fax number and e-mail address simultaneously.

p.52 "Sending Internet Fax Documents"

1 Make sure that Memory TX is selected.



𝚱 Note

☐ If it is not, press [Memory TX].

2 Place the original.

Note

- ☐ You can send the first few pages from the exposure glass then the remaining pages from the ADF. After you remove the last page from the exposure glass, you have 60 seconds to insert the remaining pages in the ADF.
- Note that you cannot place pages on the exposure glass after you have started using the ADF.
- ☐ The original can be placed either in the ADF or on the exposure glass, until the **[Start]** key is pressed.

p.13 "Placing Originals"

3 Make the settings you require.



p.30 "Scan Settings" p.31 "Original Type" p.32 "Image Density (Contrast)"

4 Specify a destination.



𝒯 Note


☐ If you make a mistake, press the **[Clear/Stop]** key, and then enter the correct number.

p.35 "Entering a Fax Number" p.37 "Entering an E-mail Address"

p.38 "Using Destination Lists" p.47 "Chain Dial", Facsimile Reference < Advanced Features>


p.47 "Redial", Facsimile Reference < Advanced Features>

When sending the same original to several destinations (broadcasting), press [Add] to specify the destinations.



Note

- ☐ You do not have to press [Add] when adding a destination using the destination list.
- ☐ If you do not want to do a broadcast transmission, proceed to step **7**.
- 6 Specify a destination.



Note

- Press to switch the destination between fax number and email address.
- ☐ If you want to specify another destination, repeat steps **⑤** and **⑥**.

7 Press the [Start] key.


Note

Do not lift the ADF during scanning.

After scanning, the standby display appears.

Sending originals using the exposure glass

- Make sure that Memory TX is selected. If it is not, press [Memory TX].
- ② Place the first page of your original face down on the exposure glass.
- 3 Dial a destination.
- Make the scan settings you require.
- ⑤ Press the [Start] key. The machine starts scanning.
- Place the next original on the exposure glass within 60 seconds after
 the machine has finished scanning
 the first original.



- Repeat steps 4 to 6 for all originals.
- Place the last original, and then press [].


Checking the transmission settings

You can check the transmission settings (e.g. destination and transmission mode) on the display.

① Press the [Check Modes] key.



The following display appears.



Note

- Press to switch the destination between fax number and email address.
- ② After checking the settings on the display, press the [Check Modes] key.

The display before the [Check Modes] key was pressed appears.

Broadcasting Sequence

If you dial several destinations for the same message (broadcasting), the messages are sent in the order in which they were dialed. If the fax message could not be transmitted, the machine redials that destination after the last destination specified for broadcasting. For example, if you specify four destinations, A through D, for broadcasting, and if the lines to destinations A and C are busy, the machine dials the destinations in the following order: A, B, C, D, A, and C. See p.80 "Simultaneous Broadcast", Facsimile Reference < Advanced Features>

Checking the transmission progress

To check the transmission progress, print the TX file list. See p.25 "Printing a List of Files in Memory (Print TX File List)", Facsimile Reference <Advanced Features>.

Canceling a Memory Transmission

Even when fax number and e-mail address are simultaneously specified, or only e-mail address is specified, you can cancel the mode using the same procedure. However, you cannot cancel transmission of an Internet Fax document during sending.

Before the Original Is Scanned

Use this procedure to cancel a transmission before pressing the **[Start]** key.

1 Press the [Clear Modes] key.




- Note
- ☐ When documents are placed in the ADF, you can cancel transmission simply by removing them.

While the Original Is Being Scanned

Use this procedure to cancel a transmission after pressing the [Start] key.

1 Press the [Clear/Stop] key.



Note

- ☐ You can also cancel scanning by pressing [Stop Scanning].
- ☐ Scanning may be completed while you are performing the cancel operation.

While the Original Is Being Transmitted

- Note
- If the transmission finishes while you are carrying out this procedure, it will not be canceled.
- ☐ If you cancel a message while it is being sent, the transmission is halted as soon as you finish the cancellation procedure. However, some pages of your message may have already been sent and received at the other end.
- 1 Press the [Clear/Stop] key.



ZFLS070

- Note
- ☐ You can also cancel a Memory Transmission by pressing [Change/Stop TX File].

2 Select the file you want to cancel.




- ☐ If the desired file is not shown, press [▲ Prev.] or [▼ Next] to find it.
- Press [Stop Transmission].



𝒯 Note

- ☐ To cancel another file, repeat steps ② and ③.
- ☐ To cancel stopping transmission, press [Save].
- 4 Press [Exit].



The standby display appears.

Before the Transmission Is Started

Use this procedure to cancel a transmission after the original has been scanned.

1 Press [Change/Stop TX File].



The list of stored files being transmitted or waiting for transmission appears.

2 Select the file you want to cancel.




- Note
- ☐ If the desired file is not shown, press [▲ Prev.] or [▼ Next] to find it.
- Press [Stop Transmission].



- **∅** Note
- ☐ To cancel another file, repeat steps ② and ③.
- ☐ To cancel stopping transmission, press [Save].

4 Press [Exit].



The standby display appears.

Immediate Transmission

With Immediate Transmission, when you press the [Start] key, the fax number is dialed immediately. The message is scanned and transmitted page by page without being stored in memory. This contrasts with Memory Transmission which scans all pages into memory before dialing the destination.

Immediate Transmission is useful if you want immediate confirmation that the message is being sent to the correct destination (just check the other terminal's Own Name or Own Fax Number on the control panel during transmission).


Limitation

☐ Internet Fax is executed in only Memory Transmission that starts transmission automatically after storing documents in memory. If you specify Immediate Transmission in Internet Fax, the mode is switched to Memory Transmission while an e-mail address is being entered.

Note

- ☐ You cannot send the same document to multiple destinations (broadcasting). Memory Transmission allows this function.
- ☐ You can have the machine set to Memory Transmission mode or Immediate Transmission mode right after the power is turned on. See p.144 "General Settings/Adjustment", Facsimile Reference < Advanced Features>.

- ☐ You can have the machine return to the default transmission mode (Memory Transmission or Immediate Transmission) after every transmission. You can change this so that the desired setting is maintained. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- ☐ When E-mail TX Results is programmed in a Quick Operation key, you can send notification of memory transmission results to specified e-mail addresses. The destination for notification is selected from Internet Fax destinations in the destination list. See p.84 "Transmission Result Report (Immediate Transmission)", Facsimile Reference <Advanced Features> and p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- 1 Make sure that Immed. TX is selected.



- \square If it is not, press [Immed. TX].
- 2 Place the original.

𝒯 Note

- ☐ You can scan a few pages of your original from the exposure glass and the remaining pages from the ADF. When you have finished scanning from the exposure glass, remove the original from the exposure glass and place the remaining pages in the ADF within ten seconds.
- ☐ To send two or more pages using the exposure glass, set them one page at a time.
- ☐ The original can be placed whenever, before the [Start] key is pressed.


p.13 "Placing Originals"

Select the scan settings you require.



p.30 "Scan Settings"

4 Dial a destination.



☐ If you make a mistake, press the **[Clear/Stop]** key, and then enter the correct number.

₽ Reference

p.35 "Specifying a Destination" p.47 "Chain Dial", Facsimile Reference < Advanced Features> p.47 "Redial", Facsimile Reference < Advanced Features>

Press the [Start] key.

Note

Do not lift the ADF during scanning.

After transmission, the standby display appears.

Sending originals using the exposure glass

- Make sure that Immed. TX is selected. If it is not, press [Immed. TX].
- ② Place the first page face down on the exposure glass.
- ③ Dial a destination.
- Make the scan settings you require.
- ⑤ Press the [Start] key.
- Place the next original on the exposure glass within 10 seconds after the machine has finished scanning the first original.



- Repeat steps 4 to 6 for all originals.
- Place the last original, and then press [].

Canceling an Immediate Transmission

Before You Have Pressed the [Start] Key

1 Press the [Clear Modes] key.




Note

When the original is placed in the ADF, you can also cancel an Immediate Transmission by removing the original.

After You Have Pressed the [Start] Key

Press the [Clear/Stop] key, and then remove the original.



- ☐ You can also cancel an Immediate Transmission by pressing [Stop Transmission].
- ☐ If the transmission finishes while you are carrying out this procedure, it will not be canceled.

Scan Settings

You may want to send many different types of fax messages. Some of these may be difficult to reproduce at the receiver's end. However, your machine has three settings that you can adjust to help you transmit your document with the best possible image quality.

Resolution:

Standard, Detail, Super Fine (optional)

Original Type:

Text, Text/Photo, Photo

Image Density (Contrast):

Auto Image Density, Manual Image Density (seven levels), Combined Auto and Manual Image Density

Resolution

Images and text are scanned into the machine by converting them to sequences of dots. The density of the dots determines the quality of the image and how long it takes to transmit. Therefore, images scanned at high resolution (Super Fine) have high quality but transmission takes longer. Conversely, low resolution (Standards) scanning results in lower quality but your original is sent more quickly. Select the setting that matches your needs based upon this trade off between speed and image clarity.

Standard (8 x 3.85 lines/mm, 200 x 100 dpi)

Select for originals containing normal size characters.

- Detail (8 x 7.7 lines/mm, 200 x 200 dpi) Select for originals containing small characters or when you require greater clarity. This resolution is twice as fine as Standard.
- Super Fine (optional expansion memory required: 16 x 15.4 lines/mm, 400 x 400 dpi)

Select for originals with very fine details or when you require the best possible image clarity. This resolution is eight times finer than Standard.


Limitation

- ☐ If the other party's machine does not support the resolution at which you are sending, this machine automatically switches to a resolution that is supported. You can check the resolution at which you sent actually. See p.156 "Printing the Journal", Facsimile Reference < Advanced Features>.
- ☐ Sending with Super Fine resolution requires that your machine has the optional expansion memory, and the other party's machine has the capability to receive fax messages at Super Fine resolution.

- ☐ The machine supports Standard, Detail, and (with the optional expansion memory) Super Fine resolutions.
- ☐ You can select the resolution type that is selected right after the machine is turned on or modes are cleared with [Scan End Reset] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

- ☐ You can have the machine return to the resolution default setting after every transmission, with [Text Size Priority] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- ☐ In Internet Fax transmission, the original is scanned using "Detail" for transmission, even if you select "Super Fine".

1 Press [Resolution].



2 Select the resolution you require, and then press [OK].



If you install the optional expansion memory, "Super Fine" will be displayed in the Resolution box.

Original Type

If your original contains photographs, illustrations, or diagrams with complex shading patterns or grays, select the appropriate original type to optimize image clarity.

Text

Select [Text] to send high-contrast black-and-white image originals. Use this setting even if your original contains text and photographs, or if you only want to send clearer text.

Text/Photo

Select **[Text/Photo]** to send an original containing both a high-contrast black-and-white image, such as text, and a halftone image, such as a photograph.

Photo

Select [Photo] to send an original containing a halftone image, such as a photograph or a colour original.

- If you select [Text/Photo] or [Photo], the transmission will take longer than when [Text] is selected.
- ☐ If you send a fax message with [Text/Photo] or [Photo] and the background of the received image is dirty, reduce the density setting and resend the fax. See p.32 "Image Density (Contrast)".
- ☐ You can set the original type that is selected right after the machine is turned on or modes are cleared, with [Original Type Priority] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

☐ You can have the machine return to the original type default setting after every transmission, with [Scan End Reset] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

1 Press [Original Type].



2 Select the original type you require, and then press [OK].



Image Density (Contrast)

The text and diagrams on originals should stand out clearly from the paper they are on. If your original has a darker background than normal (for example, a newspaper clipping), or if the writing is faint, adjust the image density.

Auto Image Density

The appropriate density setting for the original is automatically selected.

Manual Image Density

Use manual image density to set image density yourself. You can select one of seven image density levels.

Combined Auto and Manual Image Density

You can only adjust image density for photographs, illustrations, or diagrams if the original has a dark background.

You can select one of seven image density levels.

- ☐ Selecting [Text] or [Text/Photo] for the original type causes [Auto Image Density] to be selected.
- ☐ You can set the image density that is selected right after the machine is turned on or modes are cleared, with [Auto Image Density] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- ☐ You can have the machine return to the image density default setting after every transmission, with [Scan End Reset] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.

1 Select the type of image density.

Auto Image Density

Make sure that [Auto Image Density] is selected.



Note

 If [Auto Image Density] has not been selected, press [Auto Image Density].

Manual Image Density

- Make sure that [Auto Image Density] is not selected. If it has been selected, press [Auto Image Density] to turn it off.
 - Note
 - ☐ If [Auto Image Density] has not been selected, proceed to step ②.
- 2 Press [Lighter] or [Darker] to adjust the density.



Combined Auto and Manual Image Density

- Make sure that [Auto Image Density] is selected.
 - Note
 - ☐ If [Auto Image Density] has not been selected, press [Auto Image Density].
- 2 Press [☐ Lighter] or [Darker] to adjust the density.

The square moves.



Mixing Scan Settings for a Multiple Page Original

When sending an original of several pages, you can select a different image density, resolution, and original type setting for each page.

Place the original, select the scan settings for the first page, dial, and then press the **[Start]** key as you would normally. Then follow one of the following two procedures.

Note

☐ It is recommended that originals be placed on the exposure glass when mixing scan settings for a multiple page original.

When placing originals on the exposure glass

Note

- ☐ While the machine is beeping, you have about 60 seconds (10 seconds for Immediate Transmission) to select density, resolution, and original type. The remaining time is shown on the display.
- 1 Check which pages you want to scan with different settings.
- Remove the previous page and place the next page.
- Select the image density, resolution, and original type.



Note

☐ Adjust the settings for each page before you press the **[Start]** key.

When placing originals in the optional Auto Document Feeder

Note

- Depending on what time the scan settings are adjusted, the settings may not be reflected in the resulting operation.
- 1 Check which pages you want to scan with different settings.

2 Select the image density, resolution, and original type before the next page is scanned.



Specifying a Destination

You can specify the destination using one of three methods.

◆ Fax number p.35 "Entering a Fax Number"

◆ E-mail address p.37 "Entering an E-mail Address"

Destination list

p.38 "Using Destination Lists"

This section covers these functions and others in more detail.

Note

☐ The display shows the percentage of free memory space for storing originals. Since fax numbers and email addresses are programmed in separate memory, dialing fax numbers using the number keys does not change the percentage on the display.


Entering a Fax Number

Enter numbers directly using the key pad on the right side of the control panel.

Note

- ☐ Maximum length of a fax number: 128 digits.
- ☐ You can insert pauses and tones in a fax number. See p.35 "Pause", p.36 "Tone".

1 Enter the fax number using the number keys.



- Note
- ☐ If you make a mistake, press the **[Clear/Stop]** key, and then enter again.
- ☐ If the optional extra G3 interface unit is installed, select G3 before you proceed to the next step. See p.59 "Changing the Line Port", Facsimile Reference <Advanced Features>.
- ☐ Press [ProgDest] after entering the fax number to store the fax number in the destination list.

Pause

Press the **[Pause/Redial]** key when dialing or storing a number to insert a pause of about two seconds.



ZFLS090E

Note

- ☐ You cannot insert a pause before the first digit of a fax number. If you press the **[Pause/Redial]** key at the first digit, a redial occurs. See p.47 "Redial", Facsimile Reference <Advanced Features>.
- ☐ A pause is shown as a "-" on the display.



Ø Note

☐ You can also program numbers including pauses in destination lists.

Tone

This function allows a machine connected to a pulse dialing line to send tonal signals (for example if you want to use a special service on a tone dialing line). When you press the **[Tone]** key, the machine dials the number using tonal signals.

Limitation

☐ Certain services may be unavailable when using the **[Tone]** key.

Note

☐ A tone is shown as a "•" on the display.

Using the **[Tone]** key with On Hook Dial

1 Press the [On Hook Dial] key.



- 2 Enter the fax number using the number keys.
- Press the [Tone] key.




4 Enter the number you want to tone dial using the number keys.

Entering an E-mail Address


When using Internet Fax transmission, specify the e-mail address in place of the fax number.

Note

- ☐ You can enter up to 128 characters.
- 1 Press to switch the destination to e-mail address.



2 Press [Manual Input].



Enter the e-mail address destination and then press [OK].



- If you enter an incorrect character, press [Backspace] or [Delete All]. Then, re-enter the characters correctly.
- ☐ To change the e-mail address after pressing [OK], press [Edit Dest.], re-enter an e-mail address, and then press [OK].

"Entering Text", General Settings Guide

The destination is specified.



- ☐ Press [ProgDest] in this order to store the entered e-mail address in the address book.

Using Destination Lists

When you program a destination number into a destination list, you can specify the destination by just selecting the Quick Dial key from the destination list.

The programmed name appears on Ouick Dial key.

Pressing switches the destination list between fax number destination and e-mail address destination.

If you frequently send the same message to more than one place, program these numbers and/or e-mail addresses into a Group. Then you can send messages to all the destinations in that Group with just a few keystrokes. You can also program a name for the Group (for example, "Branch Offices"), this will be displayed before you press the [Start] key.

Preparation

In the destination list, program individual fax number, e-mail address and/or groups of destinations. See "Registering a Fax Destination", "Registering an E-mail Destination", and "Registering a New Group", General Settings Guide.

Limitation


☐ Group Dial can be used only for Memory Transmission; it cannot be used for Immediate Transmission. The machine automatically changes to Memory Transmission when you use Group Dial.

Note

When you press the title key above the destination keys, the destination keys programmed in that title key appear.

- ☐ To check the contents of Quick Dial, print the destination list. See "Key Operator Tools", *General Settings Guide*.
- □ A stored name can be printed out on the first page of a received fax at the other end. See p.74 "Label Insertion", Facsimile Reference <Advanced Features>.
- ☐ To check the contents of the Groups, print the list. See "Key Operator Tools", *General Settings Guide*.
- A total of 500 destinations (per message) can be programmed for Group Dial.
- Press to switch the destination to fax number or e-mail address.
- 2 Press the title key where the desired destination is programmed.

For example, if you want to specify "NEW YORK OFFICE" programmed in "LMN", press [LMN].




Note

☐ There are three types of title for destination lists; "Title 1", "Title 2", and "Title 3". The above display shows "Title 1".

Switching the titles of destination lists

- 1 Press Q.
- 2 Press [Switch Title].
- 3 Select the type of the title, and then press [Exit].
- **3** Select a destination.




Note

 Press to switch the destination between fax number and email address.

Specifying a single destination

• Press the Quick Dial key programmed with the desired destination.




Ø Note

☐ If the desired Quick Dial key is not shown, press [▲] and
 [▼] to scroll through the list.

- ☐ To cancel the selection, press the selected Quick Dial key again. You can also press the 【Clear/Stop】 key to cancel the selection.
- ☐ To select more destinations, repeat steps ② and ③.

Specifying a group of destinations

Press the Quick Dial key programmed with the desired group.



- ☐ If the desired Quick Dial key is not shown, press [▲] and [▼] to look through the list.
- ☐ To cancel the selection, press the selected Quick Dial key again. You can also press the 【Clear/Stop】 key to cancel the selection.
- □ To cancel any destination(s) among the group, press [▲P-rev.] and [▼Next] to display the desired destination. Then, press the [Clear/Stop] key.
- Quick Dial keys with fax numbers and e-mail addresses programmed in them appear in both fax destination and Internet Fax destination.

- ☐ When a destination where neither fax number nor email address are programmed is included in the specified group, the "The specified group contains some invalid destination(s). Do you want to select only valid destination(s)?" message appears. Press [Select] to specify destinations where the fax number or the e-mail address is programmed. Press [Cancel] to change the destination.
- ☐ To select more groups, repeat steps ② and ③.
- 4 Press the [Start] key.


Searching for a Destination

Use this procedure to search through the destination lists for a particular destination.

- ♦ Search by Destination Name p.41 "Search by Destination Name"
- Search by Fax Number p.42 "Search by Fax Number"
- Search by E-mail Address p.43 "Search by E-mail Address"
- Specifying a Registration Number p.44 "Specifying a Registration Number"
- **∅** Note
- ☐ The search returns only destinations whose beginnings match the entered name.

Search by Destination Name

- Ø Note
- ☐ This function distinguishes between small and capital letters.
- Press to switch the destination to fax number or e-mail address.
- 2 Press , the magnifier icon.



Press [Search by Dest. Name].



Enter a destination name to search for, and then press [OK].



A search-in-progress message appears.

When the search is finished, a result appears.

- Note
- ☐ If you press [Fax] or [E-mail] on the search result display, you can switch between fax destination and e-mail destination.
- □ A warning appears if the search returns more than 100 items. Press [OK] to proceed to step **5**.

5 Select a destination.




Note

- ☐ If the desired destination does not appear, use [▲] or [▼] to scroll through the list.
- ☐ If the search returns more than 100 destinations, only 100 will appear. Change the destination name to view fewer destinations.

Search by Fax Number

Limitation

- ☐ You can search by fax number only. To search by e-mail address, see p.43 "Search by E-mail Address".
- Press to switch the destination to fax number.
- 2 Press , the magnifier icon.



Press [Search by Fax No.].



Note

☐ If [Search by Fax No.] appears dimmed, press [Fax] on the right of the display, and then press [Search by Fax No.].



4 Enter a number to search for, and then press [OK].



Note


□ If you enter a wrong number, press [←] / [→] and [Clear], and then enter the number again.

A search-in-progress message appears.

When the search is finished, a result appears.

𝒯 Note


- ☐ A warning appears if the search returns more than 100 items. Press [OK] to proceed to step ⑤.
- **5** Select a destination.



- ☐ If the desired destination does not appear, use [▲] or [▼] to scroll through the list.
- Limitation
- ☐ If the search returns more than 100 destinations, only 100 will appear. Change the number to view fewer destinations.

Search by E-mail Address

- Limitation
- ☐ You can search by e-mail address only. To search by fax number, see p.42 "Search by Fax Number".
- 1 Press to switch the destination to e-mail address.
- 2 Press , the magnifier icon.




Press [Search by E-mail].



☐ If [Search by E-mail] appears dimmed, press [E-mail] on the right of the display, and then press [Search by E-mail].



Enter an e-mail address to search for, and then press [OK].



Note

□ If you enter a wrong e-mail address, press [←] / [→] and [Backspace] / [Delete All], and then enter the e-mail address again.

A search-in-progress message appears.

When the search is finished, a result appears.

- ☐ A warning appears if the search returns more than 100 items. Press [OK] to proceed to step **5**.
- **5** Select a destination.



Note

☐ If the desired destination does not appear, use [▲] or [▼] to scroll through the list.


Limitation

☐ If the search returns more than 100 destinations, only 100 will appear. Change the e-mail address to view fewer destinations.

Specifying a Registration Number


Use this procedure to select a destination by specifying a registration number.

- Press to switch the destination to fax number or e-mail address.
- 2 Press [Registration No.].



The registration number entry display appears.

Enter a registration number using the number keys.



𝒯 Note

☐ You do not need to enter the first zeros of a registration number when the display prompts you to enter five digits. If you do not enter 5 digits, press the [#] key to complete the entry.

The corresponding destination appears.



Note

- ☐ Title word key is switched to the one that the specified destination is programmed in.
- ☐ If the "Cannot find the specified Registration No."

 message appears, the specified registration number is wrong. Press [Exit], check the registration number again, and then follow the procedure from step ①. If the "No valid destination under the specified No."

 message appears, the ★ key is wrong. Press [Exit], and then follow the procedure from step ②.

Reception

There are two ways you can set up your machine to handle incoming calls:

- Manual Reception (external telephone required)
- Auto Reception

You can change the reception mode only if a standard G3 line is used.

You cannot change the reception mode when a line other than the standard G3 line (G3-2) is used.

Manual Reception

When a telephone call comes in, the machine rings. If the call is a fax message, you must switch manually to facsimile mode.

Auto Reception

When a telephone call comes in, the machine automatically receives it as a fax message. Use this setting on a dedicated fax line.

☐ The external telephone is required to use this machine as a telephone.


Switching the Reception Mode

You can switch reception modes using the Reception Settings menu (under Facsimile Features). See p.146 "Reception Settings", Facsimile Reference < Advanced Features>.

If you program a Quick Operation key with Switch Reception Mode, you can switch reception mode quickly.

Note

- ☐ You can only use this function after programming a Quick Operation key as the reception mode switch with [Quick Operation key 1], [Quick Operation key 3] under Gen. Settings/Adjust. See p.144 "General Settings/Adjustment", Facsimile Reference <Advanced Features>.
- Press the [Switch RX Mode] Quick Operation key.



2 Select the reception mode, and then press [OK].



The standby display appears.

Note

☐ To cancel the selection, press [Cancel].

Receiving a Fax in Manual Reception Mode

- When the machine rings, pick up the handset of the external telephone.
- If you hear beeps, press the [Start] key or the [Start Manual RX] key. (The [Start] key is only available in facsimile mode when an original is not placed.)
- Replace the handset of the external telephone. The machine will start receiving.

Limitation

☐ When printing documents stored in the Document Server, the [Start Manual RX] key or the [Start] key cannot be used to switch to facsimile mode. Press the [2] key of the external telephone.


3. Using Internet Fax Functions

Internet Fax Functions

This machine converts scanned document images to e-mail format and transmits the data over the Internet.

The e-mail sent by this machine can be received by another Internet Fax machine. Instead of dialing the telephone number of the destination you want to send to, you enter the relevant e-mail address.

You can also print or forward received e-mail messages.



Note

- ☐ This machine must be connected to a LAN and set up correctly in order to use its Internet Fax functions. See "User Tools Menu (System Settings)", Network Guide.
- ☐ The Internet Fax function supported by this machine is compliant with ITU-T Rec. T.37. See p.198 "Compatible Machines", Facsimile Reference <Advanced Features>.
- ☐ You can receive e-mail messages with an attached TIFF-F image from computers.

Internet Fax Precautions

- Internet Fax communicates with a server over a LAN. It cannot communicate directly with other parties.
- If a transmission is not successful, this machine usually receives an e-mail error notification. See p.191 "Server-Generated Error E-mail", Facsimile Reference <Advanced Features>. However, e-mail error notifications may not be transmitted for various reasons. We recommend you confirm receipt of important document by calling the other party.
- The level of security for Internet communications is low. We recommend you use the telephone network for confidential communications.
- Voice communication is not supported over a LAN.
- Internet Fax delivery might be delayed due to network congestion. Use a standard fax whenever communication is time sensitive.
- If you use this machine with dial-up connection, the Auto E-mail Reception function accesses the provider's server via telephone line and may incur call charges even if you do not receive e-mail. To reduce the frequency of server access, specify a large E-mail Reception Interval. For the E-mail Reception Interval setting, see "Settings You Can Change with User Tools - File Transfer", Network Guide.
- You cannot place pages on the exposure glass after you have started using the ADF.

Functions Not Supported by E-mail Transmission

The following functions are supported with standard fax transmission, but not with Internet Faxing.

- Immediate Transmission
- Confidential Transmission
- ID Transmission
- Polling Transmission
- Chain Dial
- Transmission by SUB Code
- On Hook Dial
- Manual Dial
- JBIG Transmission
- Batch Transmission
- ECM (Error Correction Mode)
- Memory File Transfer

Functions Not Supported by E-mail Reception

The following functions are supported with standard fax reception, but not with Internet Faxing.

- Confidential Reception
- Memory Lock Reception
- Polling Reception
- SUB Code reception
- Authorized Reception
- Reception File Print Quantity

Sending Internet Fax Documents

Preparation

You need to make System Settings beforehand. See "Setting Up the Machine on a Network", Network Guide.

This section describes how to scan a document into the memory and send it as e-mail. Specify the destination's e-mail address instead of fax number.

You can send Internet Fax documents only by Memory Transmission. If you specify Immediate Transmission in Internet Fax, the mode is switched to Memory Transmission when one email address or more is specified.

When sending documents, you can set e-mail options using [Sub TX Mode]. You can set the following options:

Enter Subject

Allows you to enter a subject for the document you want to send.

Note

- ☐ For convenience, program frequently-used subject. "Urgent", and "High" are programmed as default. See "Settings You Can Change with User Tools File Transfer", Network Guide.
- ☐ You can enter up to 64 characters in total.
- ☐ If you send e-mail without setting a subject/text in "E-mail Options" under "Sub TX Mode", the subject is automatically inserted. For more details about how a subject is automatically inserted, see p.62 "Received Images".
- ☐ You cannot send a subject only as e-mail without an original.

Enter Text

Allows you to enter the text to be transmitted.

Note

- ☐ To enter text, program it beforehand. See "Settings You Can Change with User Tools - File Transfer", Network Guide.
- ☐ You cannot send a text only without an original.

Reception Notice

You can confirm sent documents were properly received using email or Journal.

BCC Transmission

E-mails are sent to all specified destinations as bcc.

#Important

- ☐ If power outage lasts about an hour, or the machine is disconnected from the power outlet for about an hour, documents stored in the fax machine's memory are deleted. If any document is deleted, the Power Failure Report is automatically printed out when the main power switch is turned on. Use this report to check which documents were deleted. Simply turning off the power by pressing the Operation switch does not delete stored documents. See p.190 "Turning Off the Main Power / When a Power Failure Occurs", Facsimile Reference < Advanced Features > .
- You may not be able to send large files as e-mail, depending on email environment conditions.
- ☐ The level of security for Internet communications is low. Use of the telephone network is recommended for confidential communications.


Limitation

☐ When available memory is low, you may not be able to send Internet Fax documents.


Note

- ☐ Because the machine sends documents as e-mail messages with an attached TIFF-F image, viewer applications are required in order to view documents when they are received on a computer.
- ☐ You can limit the size of transmitted e-mail messages in "E-mail Settings" of "Fax Features". See p.147 "E-mail Settings", Facsimile Reference <Advanced Features>.
- ☐ See p.62 "Received Images" for how e-mail is actually received by the computer when it is sent with mail options selected.
- ☐ When you send Internet Fax documents specifying a user code, and the e-mail address is set as the routing destination of the specified user code, a Communication Result Report is sent after the transmission is completed. This makes it possible to verify the result of a transmission.
- ☐ You can specify fax destination and Internet Fax destination simultaneously.
- ☐ You cannot send e-mails to a destination as cc.

Press to switch the destination to e-mail address.




When you set an e-mail option, press [Sub TX Mode].



If you are not setting e-mail options, proceed to step **[7]**.

Press [E-mail Options].




To enter the subject

• Press [Change] for Enter Subject.




There are two methods of entering a subject: Selecting from programmed subjects, or entering characters directly. If you are entering characters, proceed to step 3.

2 Select the subject from the displayed list.




The selected subject appears in the manual input column.



Note

☐ You can enter extra characters after the selected subject. If you do not need to enter extra characters, proceed to step **⑤**.

3 Press [Manual Input].




4 After entering the subject, press [OK].



"Entering Text", General Settings Guide

Entered characters appear in the manual input column.



☐ You can add a programmed subject after the entered subject. Select the subject from the displayed subjects.

6 Press [OK].



To enter the text

1 Press [Change] for Enter Text.




2 Select a text, and then press [OK].



To set reception notice

• Select [ON] or [OFF] for Recept. Notice.




₽ Reference


p.58 "Confirming Reception"

To set BCC transmission


• Select [Yes] or [No] for BCC TX.



4 Press [OK].



Press [OK].



6 Place the original.

Note

- ☐ You can send the first few pages from the exposure glass then the remaining pages from the ADF. After you remove the last page from the exposure glass, you have 60 seconds to insert the remaining pages in the ADF.
- ☐ The original can be placed either in the ADF or on the exposure glass, until the **[Start]** key is pressed.

Reference

p.13 "Placing Originals"

Select the scan settings you require.




Note

In Internet Fax transmission, the original is scanned using "Detail" resolution for transmission, even if you select "Super Fine". ☐ When using the Internet Fax function, documents transmitted are sent at A4 width. Documents larger than A4 are reduced to A4 width.

p.30 "Resolution" p.31 "Original Type" p.32 "Image Density (Contrast)"

8 Enter the e-mail address.




☐ If ♠ is not displayed in the destination display column, press

p.37 "Entering an E-mail Address"

p.38 "Using Destination Lists" p.47 "Redial", Facsimile Reference < Advanced Features>

To send the same document to multiple destinations, press [Add].



To send e-mail to one destination only, proceed to step **(1)**.

Note

☐ It is not necessary to press [Add] when adding destinations using the destination list.

10 Specify the next destination.



- Press to switch the destination between fax number and email address.
- ☐ To specify more destinations, repeat steps ☐ and ⑥.

Press the [Start] key.

This starts reading the document into memory. The e-mail send operation starts after the read operation is complete. When scanning is complete, the Communicating indicator lights and transmission starts.

Ø Note

- ☐ With a large volume of document, it may take some time before transmission starts. This is due to the time the machine requires to convert the data in memory.
- ☐ To cancel transmission of an Internet Fax, see p.59 "Canceling a Transmission of an Internet Fax".

About the E-mail Subject

If there is no subject specified in "Enter Subject / Text" under "E-mail Options", a subject is automatically inserted. Subjects differ according to Stamp Sender Name settings.

When a name is set to Stamp Sender Name:

From "Stamp Sender Name" Fax Message NO.xxxx.

When Stamp Sender Name is set to [Do not Stamp]:

- If Own Fax Number and Own Name are programmed: From "Own Fax Number" ("Own Name") (Fax Message NO.xxxx)
- If only Own Fax Number is programmed:
 From "Own Fax Number" (Fax Message NO.xxxx)
- If only Own Name is programmed: From "Own Name" (Fax Message NO.xxxx)
- If neither Own Fax Number nor Own Name are programmed: Fax Message NO.xxxx

Note

□ "xxxx" is the document number that appears in the Journal.

p.75 "Selecting transmission options for a single transmission", Facsimile Reference < Advanced Features>

E-mail Text

When Internet Fax e-mail is sent to computer, the following information is always inserted in the e-mail text. To check the host name and e-mail address, see "Settings You can Change with User Tools", Network Guide.

This e-mail was sent from "Host Name" (product name)

Queries to: "Administrator's e-mail address"

Confirming Reception

When Reception Notice is set under "E-mail Options", the receiver sends back a reception notice message. Once the reception notice message has been received, "OK" appears in the Result column of Journal, allowing the originator to verify that the transmission has been received.

Limitation

☐ The Reception Notice feature is only available if the receiver supports MDN (Message Disposition Notification).

Note

- ☐ If your fax is not received normally, "Error" appears in the Result column.
- ☐ Information regarding the last 250 messages is recorded, but only the last 50 communications appear in Journal. If you do not receive a reception notice message for one of the last 50 communications from the receiver's machine, you may not be able to confirm that the email has been received by the Journal's Result column.

- ☐ If you specify mailing list addresses, do not set for Reception Notice. Otherwise, you will receive multiple reception notice messages from e-mail recipients, and the Result column will be overwritten each time a new notice message is received. However, if you receive a reception notice message indicating an error, "Error" appears in the Result column and will not be overwritten, even if you subsequently receive a reception notice message as "OK" following the error message.
- ☐ Reception notice results are only shown in Journal. The Result column in all other files, lists, and transmission reports show "--".
- ☐ Reception notice messages themselves are not recorded in Journal.
- ☐ You can select whether or not to print the Reception Notice. This can be set with User Parameters. See p.161 "User Parameters", Facsimile Reference <Advanced Features> (switch 21, bit 0).
- You cannot send e-mails using Reception Notice.

Canceling a Transmission of an Internet Fax

When fax and Internet Fax destinations are specified simultaneously, you can cancel sending using the same method. However, you cannot cancel transmission of an Internet Fax document during sending.

Before the Original Is Scanned

Use this procedure to cancel a transmission before pressing the **[Start]** key.

1 Press the [Clear Modes] key.




- ☐ When documents are placed in the ADF, you can cancel transmission simply by removing them.

While the Original Is Being Scanned In

Use this procedure to cancel a transmission after pressing the [Start] key.

1 Press the [Clear/Stop] key.



ZFLS070

The machine stops scanning.

Note

- ☐ You can also cancel scanning by pressing [Stop Scanning].
- ☐ Scanning may be completed while you are performing the cancel operation.
- ☐ If the transmission finishes while you are carrying out this procedure, it will not be canceled.

After the Original Has Been Scanned In

- Note
- ☐ You can not cancel the transmission of an Internet Fax being sent.
- 1 Press [Change/Stop TX File].



The list of stored files being transmitted or waiting for transmission appears.


2 Select the file you want to cancel.



- Note
- □ If the desired file is not shown, press [▲ Prev.] or [▼ Next] to find it
- 3 Press [Stop Transmission].



- Note
- ☐ To cancel another file, repeat steps ② and ③.
- ☐ To save the scanned file, press [Save].
- 4 Press [Exit].



The standby display appears.

Receiving Internet Fax

You can receive e-mail documents by Internet Fax.

There are two methods of receiving email: Auto E-mail Reception and Manual E-mail Reception.

Limitation

☐ E-mail with attachments other than TIFF-F format files cannot be received. Senders receive an Error Mail Notification if their e-mail contains attachments. You can select whether or not the machine sends this message with User Parameters. See p.161 "User Parameters", Facsimile Reference < Advanced Features> (switch 21, bit 7). However, TIFF-F documents created by the Saving function of Desktop-Binder V2 Professional Lite can be received.

Note

- □ When Reception Protocol is set to POP3 or IMAP4, you can set the machine to retain incoming e-mail or delete it from the server in "System Settings". See "Settings You Can Change with User Tools - File Transfer", Network Guide.
- □ With User Parameters, you can have the machine return the acknowledgment of e-mail to the sender. See p.161 "User Parameters", Facsimile Reference < Advanced Features> (switch 21, bit 1).

Auto E-mail Reception

When this function is turned on, the machine periodically checks the email server for incoming e-mail and downloads it as necessary.

E-mail auto-reception should be set in "System Settings". When you select auto-reception, set the reception interval in minutes.

See "Settings You Can Change with User Tools - File Transfer", Network Guide.

Note

☐ If memory runs out, e-mail will not be received at the specified intervals. Reception will resume when sufficient memory becomes available.


Manual E-mail Reception

The following operation allows you to receive e-mail at all times.

Preparation

Program the Manual E-mail RX function to a Quick Operation key beforehand. See p.144 "General Settings/Adjustment", Facsimile Reference < Advanced Features>.

1 Press [Manual E-mail RX].



Access the server to check for e-mail. Receive any saved e-mails.

Check the message, and then press [Exit].



The standby display appears.

Received Images

Here is an example of an Internet Fax message sent from this machine and received on a computer using Outlook e-mail software.

The received image varies according to e-mail software.



- 1. E-mail transmitted without specifying a subject in "E-mail Options".
- 2. E-mail transmitted with a subject specified in "E-mail Options".

3. From

The name (e-mail address) of the sender

Note

The display format of the sender name differs according to that of the Stamp Sender Name setting and other functions.

4. Date

The date and time of e-mail transmission

5. To

The e-mail address of the recipient

6. Subject

Shows the subject specified in "E-mail Options" at the time of transmission. If no subject is specified, one is automatically assigned in the format shown in 1 above. From "Own Fax Number" ("Own Name") (Fax Message NO. document number)

Note

- ☐ The format varies according to Stamp Sender Name and other settings. See p.57 "About the E-mail Subject".
- 7. The message is inserted in all emails. "xxxx" is the product name.

8. Attachment File

Any message included by the sender is displayed as an attached document.

4. Programming

Initial Settings and Adjustments

You can send information to the other party when transmitting or receiving a fax message. This information is shown on the display of the other machine and printed as a report. The following information can be sent.

∰Important

☐ You can confirm programmed settings from the User Parameter List. We recommend that you print and keep the User Parameter List when you program or change settings. See p.165 "Printing the User Parameter List", Facsimile Reference < Advanced Features>.

Fax Header

The Fax Header is printed as the header of every fax you send. You should include your name in the Fax Header.

You can program Fax Header1 or Fax Header2. When you send originals using Quick Dial, you can select which Fax Header will be printed on the message received by the other party.

Note

- ☐ You can register up to 32 characters in the Fax Header.
- ☐ You can use characters, symbols, numbers, and spaces.
- ☐ You can set whether or not to print a Fax Header using [Fax Header Print] under Options . See p.74 "Fax Header Print", Facsimile Reference <Advanced Features> .

☐ In program No. 1 you can register a preference about whether or not the Fax Header is always printed. You will then switch the setting using the Fax Header Print function only when necessary. See p.128 "Registering a priority function using a program", Facsimile Reference <Advanced Features>.

p.74 "Fax Header Print", Facsimile Reference < Advanced Features>

p.128 "Registering a priority function using a program", Facsimile Reference < Advanced Features>

Own Name

The Own Name is sent to the other party when you send or receive a fax using a G3 line. This name should include your name. The Own Name is shown on the display of the other machine and printed in a report.

Limitation

Own Name works only when the other machine is of the same manufacturer, and has the Own Name function.

- ☐ You can use characters, symbols, numbers, and spaces.
- ☐ You can register up to 20 characters as an Own Name.

Own Fax Number (facsimile number of sender)

The sender's Own Fax Number is sent to the other party when sending a fax using a G3 line. The received facsimile number is shown on the display of the other machine and printed in a report. This function is available regardless of the manufacturer of the other party's machine.

Note


☐ You can register up to 20 characters in Own Fax Number.

Programming

1 Press the [User Tools/Counter] key.




2 Press [Facsimile Features].



𝒯 Note

- ☐ When the Key Operator Code is programmed and turned on, user have to enter programmed the Key Operator Code (maximum 8 digit) to operate Key Operator Tools.
- ☐ This prevents unauthorized people from changing registration.


3 Press [Program Fax Information].



4 Program the name and facsimile number.

Programming a Fax Header

• Press [First Name] or [Second Name].



2 Enter a fax header, and then press [OK].



"Entering Text", General Settings Guide

Programming an Own Name

1 Press [Own Name].



2 Press [Own Name].



3 Enter an own name, and then press [OK].



₽ Reference

"Entering Text", General Settings Guide

Programming an Own Fax Number

1 Press [Own Fax Number].



2 Select line type to program.



- Note
- ☐ The display differs depending on the optional units installed on your machine.
- 3 Enter your own facsimile's number using the number keys, and then press [OK].



- Note
- ☐ To enter a + sign or a space, press [+] or [Space].
- ☐ If you make a mistake, press [Clear] or the [Clear / Stop] key, and then enter the facsimile number again.


- Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Editing

- ☐ The following procedure explains how to edit Own Name, as an example of editing.
- 1 Press the [User Tools/Counter] key.




2 Press [Facsimile Features].



- Note
- When the Key Operator Code is programmed and turned on, user have to enter programmed the Key Operator Code (maximum 8 digit) to operate Key Operator Tools.
- ☐ This prevents unauthorized people from changing registration.

3 Press [Program Fax Information].



Press [Fax Header], [Own Name], or [Own Fax Number] for editing.



5 Press the item you want to edit.



Press [Backspace] or [Delete All], and then re-enter the name or number.



- **𝚱** Note
- Press [Clear] or the [Clear/Stop] key if you want to edit Own Fax Number.

7 Press [OK].



8 Press [Exit].




Press the [User Tools/Counter] key.
The standby display appears.

Deleting


- ☐ The following procedure explains how to delete Own Name, as an example of deleting.
- 1 Press the [User Tools/Counter] key.



2 Press [Facsimile Features].



- **𝒯** Note
- When the Key Operator Code is programmed and turned on, user have to enter programmed the Key Operator Code (maximum 8 digit) to operate Key Operator Tools.
- ☐ This prevents unauthorized people from changing registration.
- Press [Program Fax Information].




Press [Fax Header], [Own Name], or [Own Fax Number] to delete.



5 Press the item you want to delete.



Press [Backspace] or [Delete All], and then press [OK].



- Note
- ☐ Press [Clear] or the [Clear/Stop] key if you want to edit Own Fax Number.
- **7** Press [Exit].



Press the [User Tools/Counter] key. The standby display appears.

Programming Fax Numbers and E-mail addresses

You can program fax destinations using Address Book Management in the Key Operator Tools menu under System Settings.

You can also register the programmed fax numbers and e-mail addresses in a Group.

𝒜 Note

□ When you press the **[Facsimile]** key after changing the contents of the Address Book, such a message appears that indicates that the destination list has been updated. Press **[Exit]**. The standby display appears.

"Key Operator Tools", General Settings Guide

"E-mail Destination", General Settings Guide

"Registering Destinations to a Group", General Settings Guide

5. Troubleshooting

Adjusting the Volume

You can change the volume of the following sounds that the machine makes.

On Hook Mode

Heard when the **[On Hook Dial]** key is pressed.

At Transmission

Heard when the machine sends a message.

At Reception

Heard when the machine receives a message.

At Dialing

Heard after pressing the **[Start]** key, until the line connects to the destination.

At Printing


Heard when a received message is printed. See p.96 "Print Completion Beep", Facsimile Reference < Advanced Features>.

Note


- ☐ You can adjust the On Hook volume when you press the **[On Hook Dial]** key. See p.56 "On Hook Dial", Facsimile Reference <Advanced Features>.
- Press the [User Tools/Counter] key.




2 Press [Facsimile Features].



Press [Adjust Sound Volume].



Press [Lower] or [Louder] for each item, and then press [OK].




- Note
- ☐ You can hear the actual volume by pressing [Check].
- ☐ If you press **[Cancel]**, the volume setting is canceled. The display returns to that of step **§**.
- **5** Press the [User Tools/Counter] key.

The standby display appears.

When the [Facsimile] Key Is Lit in Red

If this key is lit, press the key to enter the facsimile mode. Then, refer to the table below and take the appropriate action.



| Problem | Solutions | |
|---------------------------------|---|--|
| The paper output tray is full. | Remove the paper from the tray. | |
| A facsimile error has occurred. | The facsimile has a problem. Contact your service representative. See p.76 "Error Messages and Their Meanings" The copier will still function normally. | |
| Out of paper | Add more paper. | |
| | "Loading Paper", General Settings Guide | |
| A network error has occurred. | Check the displayed message. See p.76 "Error Messages and Their Meanings". | |
| | Check the machine is correctly connected to the network, and the machine is correct- ly set. See <i>Network Guide</i> . | |
| | Consult your network administrator. | |
| | When the key is still lit in red even if you take the measures above, please contact your service representative. | |

When Toner Runs Out


When the machine has run out of toner, the symbol appears on the display. Note that even if there is no toner left, you can still send fax messages.

#Important

☐ The number of communications, that have been executed after the toner has run out and that automatically-output Journal has not list, exceeds 200 (1000 with the optional expansion memory installed), communication will not be possible.

Limitation

- ☐ The Memory Storage Report, Polling Reserve Report, and Confidential File Report are not printed.
- 1 Make sure that the machine is in facsimile mode.



- ☐ If the standby screen is not displayed, press the **[Facsimile]** key.
- Press [Exit], and then perform transmission operation.

The error message disappears.

p.20 "Memory Transmission" p.27 "Immediate Transmission"

Error Messages and Their Meanings

If there is an error, one of the following messages may appear on the display. If other message appears, follow the message.

| Message | Causes and solutions | |
|---|---|--|
| Put original back, check it and press [Start]. | Original jammed during Memory Transmission. Place originals that have not been scanned again. | |
| Error occurred, and transmission was canceled. | A document jam occurred during Immediate Transmission. Press [OK], and then resend the pages that have not been sent. | |
| | An error occurred during Immediate Transmission. Press [OK], and then resend the original. | |
| | Ø Note | |
| | ☐ There may be a problem with the machine or the telephone line (for example noise or cross talk). If the error reoccurs frequently, contact your service representative. | |
| Cannot detect original size. Place original again, then press [Start]. | The machine failed to detect the size of the original. Place originals again, and then press the [Start] key. | |
| Call Service Functional problems with fac- simile. Please call service. | There is a problem with the fax. Record the code number shown in the display and contact your service representative. The copy function will still work normally. | |
| Memory is full. Cannot scan more. Transmitting only scanned pages. | If you press [Exit], the machine returns to standby mode and starts transmitting the pages that have been stored. | |
| Following output tray is full. Remove paper. | The paper output tray is full. Remove paper from the tray indicated in the display. | |
| Cannot scan to send fax message as scanner is in use for other function. | The Copy or Document Server function is in use. To cancel the job in process, do the following, and then try faxing again. | |
| | Press [Exit], and then press the [Copy] or [Document Server] key. Next press the [Clear/Stop] key. When the message "[Stop] key was pressed. Stop copying?" or "[Stop] key was pressed. Stop storing?" appears, press [Stop]. | |
| Updating the destination list. Please wait. Selected destinations or function settings have been cleared. Please re-select after the update finishes. | Wait with the main power switch on. The machine will enter standby mode after it exits from RDS mode. | |

| Message | Causes and solutions | |
|---|--|--|
| Check whether there are any network problems. | Cannot find the DNS server or SMTP server. | |
| [14-01] | Check the DNS server's IP address is correctly programmed using the Web browser. See the Web browser's Help. | |
| | Check the DNS server is correctly pro- grammed using the Web browser. See the Web browser's Help. | |
| | Check the host name or IP address of the SMTP server is correctly programmed us- ing the Web browser. See the Web brows- er's Help. | |
| | Check the SMTP server is correctly pro- grammed using the Web browser. See the Web browser's Help. | |
| | Check the LAN cable is correctly connected to the machine. See "Connecting the Net- work Cable to the Network", Network Guide. | |
| | Consult your network administrator. | |
| Check whether there are any network problems. [14-09] | E-mail transmission was refused by SMTP authentication or POP before SMTP authentication. | |
| | Check the user name and password for SMTP authentication or POP before SMTP authentication are correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. | |
| | Check the user name and password of the e-mail account are correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. | |
| | Consult your network administrator. | |
| Check whether there are any network problems. [14-33] | No machine's e-mail address is programmed. Check the machine's e-mail address is correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. | |
| | Consult your network administrator. | |

| Message | Causes and solutions | |
|---|---|--|
| Check whether there are any network problems. | No POP3/IMAP4 server's address is programmed. | |
| [15-01] | Check the host name or IP address of the POP3/IMAP4 server is correctly pro- grammed using the Web browser. See the Web browser's Help. | |
| | Consult your network administrator. | |
| Check whether there are any | Cannot log on to the POP3/IMAP4 server. | |
| network problems. [15-02] | Check the user name and password of the e-mail account are correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. | |
| | Consult your network administrator. | |
| Check whether there are any | No machine's e-mail address is programmed. | |
| network problems. [15-03] | Check the machine's e-mail address is correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. | |
| | Consult your network administrator. | |
| Check whether there are any network problems. | Cannot find the DNS server or POP3/IMAP4 server. | |
| [15-11] | Check the DNS server's IP address is cor- rectly programmed using the Web brows- er. See the Web browser's Help. | |
| | Check the DNS server is correctly pro- grammed using the Web browser. See the Web browser's Help. | |
| | Check the host name or IP address of the POP3/IMAP4 server is correctly pro- grammed using the Web browser. See the Web browser's Help. | |
| | Check the POP3/IMAP4 server is correctly programmed using the Web browser. See the Web browser's Help. | |
| | Consult your network administrator. | |

| Message | Causes and solutions | |
|---|---|--|
| Check whether there are any network problems. [15-12] | Cannot log on to the POP3/IMAP4 server. Check the user name and password of the e-mail account are correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. Check the user name and password for POP before SMTP authentication are correctly programmed from File Transfer under System Settings. See "Settings You Can Change with User Tools – File Transfer", Network Guide. Consult your network administrator. | |

Out of paper display message

If the paper tray runs out of paper, "No paper. Load it, then press [Exit]." appears on the display, asking you to add more paper.

- ☐ If there is paper left in the other paper trays, you can receive messages as usual, even if the message appears on the display.
- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters", *Facsimile Reference <Advanced Features* > (switch 05, bit 7).

Network error display message

If the "Check whether there are any network problems." message appears, the machine is not correctly connected to the network or the settings of the machine is not correct. If you do not need to connect the machine to the network, you can select so that the message disappear and the key goes out with User Parameters. See p.161 "User Parameters", Facsimile Reference < Advanced Features> (switch 21, bit 6).

Note

☐ When you restart connecting the machine to the network, make sure to set "Display" with User Parameters. Otherwise, you cannot check the status of the network connection.

Solving Problems

This table lists some common problems and their solutions.

| Problem | Causes and solutions | Reference |
|---|--|--|
| Image background appears dirty when received at the other end. Images from the back page appear. | Adjust scan density. | p.32 "Image Density (Contrast)" |
| Printed or sent image contains spots. | The ADF or exposure glass is dirty. Clean them. Make sure that ink or correction fluid is dry before placing originals. | "Maintaining Your Machine", General Settings Guide |
| Received image is too light. | Request the sender to increase image density. | |
| | When using moist, rough, or processed paper, the printed image may be partly invisible. Only use recommended paper. | "Copy Paper", General Set- tings Guide |
| | When a appears on the display, toner is beginning to run out. Replace the toner cartridge soon. | "L'Adding Toner", General Settings Guide |
| The machine failed to print received fax messages. | If this happened when the receive file indicator was lit, a problem such as run out of paper or toner might disable printing. | p.86 "Substitute Reception", Facsimile Reference <advanced Features></advanced |
| | Store has been selected for Reception File Setting. Print the fax messages using a Web browser or the Print Stored RX File function. | p.122 "Printing fax information using a Web browser", Facsimile Reference <advanced features=""> p.34 "Printing Received and Stored Documents", Facsimile Reference <advanced features=""></advanced></advanced> |
| | When ≜ is lit, load paper into the tray. | "Loading Paper", General Set- tings Guide |
| Message appears blank at the other end. | The original was placed upside down. Place it properly. | p.13 "Placing Originals" |
| Both transmission and receiving are impossible. | Make sure that the modular cord is correctly connected. | p.195 "Connecting the Machine to a Telephone Line and Telephone", Facsimile Reference < Advanced Features> |
| | The terminal adaptor setting is incorrect. Check the setting. | |

| Problem | Causes and solutions | Reference |
|---|--|--|
| Transmission is possible, though receiving is impossible. | The optional terminal adaptor setting is incorrect. Check the setting. | |
| Receiving is possible, though transmission is impossible. | The optional terminal adaptor setting is incorrect. Check the setting. | |
| When using On Hook Dial or Manual Dial, "Receiving" appears and transmission is not allowed. | If the machine fails to detect the size of the original when the [Start] key is pressed, it performs a receiving opera- tion. Press [Scan Area] , select the scan area, and then resend the document. | p.16 "Setting a Scan Area" |
| All fax messages stored in memory have been lost. Those messages include ones stored through Memory Transmission/Reception, Confidential Reception, Substitute Reception, or Auto Document. | When about one hour passes after power of the machine is turned off, all fax messages stored in memory are lost. If any messages have been lost for this reason, a Power Failure Report is automatically printed when the machine is turned on. If fax messages stored for Memory Transmission have been lost, check the destinations and resend the messages. If fax messages received through Memory, Confidential or Substitute Reception have been lost, ask the senders to resend the messages. If Auto Documents have been lost, reprogram them. | p.190 "Turning Off the Main Power / When a Power Fail- ure Occurs", Facsimile Refer- ence <advanced features=""></advanced> |
| Transmission failed due to "Exceeded max. E-mail size" error. | If the e-mail size specified on the machine is too large, the Internet Fax document cannot be sent. Set Max. E-mail Size to [OFF], or set the maximum e-mail size to a larger value. Then, re-send the document. | p.147 "E-mail Settings", Fac- simile Reference <advanced fea-<br="">tures></advanced> |
| When a correct password is entered, you cannot print documents that appear in the confidential box or bulletin board box, or transmit / print out stored documents. | Documents are locked by a security function when incorrect passwords are entered a certain number of times. Contact the administrator. | "Extended Security Function", General Settings Guide |

When Things Don't Go as Expected

| I Want | Operation | Reference |
|--------------------------------------|--|---|
| to cancel a Memory Transmission. | If the original is being scanned, press [Stop Scanning] or the [Clear/Stop] key. | p.24 "Canceling a Memory Transmission" |
| | If the original is being sent or if it is in standby, press [Change/Stop TX File] or the [Clear/Stop] key. | p.24 "Canceling a Memory Transmission" p.19 "Canceling a Transmis- sion", Facsimile Reference <ad- vanced Features></ad- |
| to cancel an Immediate Transmission. | Press [Stop Transmission] or the [Clear/Stop] key. | p.29 "Canceling an Immediate Transmission" |

INDEX

| Α | F |
|--|--|
| Adjusting The Volume, 73 At Dialing, 73 At Printing, 73 At Reception, 73 At Transmission, 73 On Hook Mode, 73 Authorized Reception, 51 Auto E-mail Reception, 61 Auto Reception, 46 | Facsimile key, 74 Fax Header, 65 Deleting, 69 Editing, 68 Programming, 66 Faxing, 11 Function keys, 4 Functions Not Supported by e-mail Reception, 51 Functions Not Supported by e-mail Transmission, 50 |
| Batch Transmission, 50 BCC Transmission, 52 Broadcasting, 20 | Getting Started, 3 |
| Broadcasting Sequence, 23 | Groups Specifying a Destination, 35 |
| Chain Dial, 50 Check Modes key, 4 Clear Modes key, 4 Clear/Stop key, 5 Communicating indicator, 3 Confidential file indicator, 3 Confidential Reception, 51 Confidential Transmission, 50 Control Panel, 3 CSI->Own Fax Number, 66 | ID Transmission, 50 Image Density (Contrast), 30, 32 Immediate Transmission, 11, 12, 27, 50 Canceling, 29 Internet Fax, 49 Canceling, 59 Precautions, 50 Receiving, 61 Sending, 52 |
| <u>D</u> | _ <u>J</u> |
| Destination list, 35, 38 Detail, 30 Display, 5 | JBIG Transmission, 50 |
| Display Panel, 3 E ECM (Error Correction Mode), 50 | Main Power indicator, 4 Manual Dial, 50 Manual Reception, 46 Memory File Transfer, 50 |
| Entering a fax number, 35 Entering an e-mail address, 37 Enter key (# key), 4 Enter Text, in e-mail, 52 | Memory Lock Reception, 51 Memory Transmission, 11, 12, 20 Canceling, 24 |
| Error Messages, 76 | Number keys 4 |

0

On Hook Dial, 50
On Hook Dial key, 4
On indicator, 4
Operation switch, 4
Original Type, 30, 31
Own Fax Number, 66
Deleting, 69
Editing, 68
Programming, 66
Own Name, 65
Deleting, 69
Editing, 69
Editing, 69

Programming, 66

Р

Pause, 35
Pause/Redial key, 4
Photo, 31
Placing Originals, 13
Polling Reception, 51
Polling Transmission, 50
Program key, 4
Programming, 65

ი

Quick Dial *Specifying a Destination*, 35

R

Received Images, 62
Receive File indicator, 3
Reception, 46
Auto Reception, 46
Manual Reception, 46
Reception File Print Quantity, 51
Reception Notice, 52, 58
Resolution, 30
RTI->Own Name, 65

S

Scan Settings, 30 Stamp Sender Name, 57 Standard, 30 Start key, 5 Start Manual RX key, 4 SUB Code reception, 51 Subject, in e-mail, 52, 57 Super Fine, 30

Т

Text, 31
Text / Photo, 31
Tone, 36
Tone key, 4
Toner, 75
Transmission by SUB Code, 50
TTI->Fax Header, 65

U

User Tools/Counter key, 3



Declaration of Conformity

Notice to Users in EEA Countries

This product complies with the essential requirements and provisions of Directive 1999/5/EC of the European Parliament and of the Council of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

Notice to Users Accessing Analog PSTN in EEA Countries

This product is designed to be able to access analog PSTN in all EEA countries. Local PSTN compatibility is dependent on software switch settings. Please contact your service representative if relocating this product to another country. In the event of problems, please contact your service representative in the first instance.

The CE Declaration of Conformity is available on the Internet at URL: http://www.ricoh.co.jp/fax/ce_doc/

FAX Option Type 2238

Operating Instructions Facsimile Reference <Advanced Features>



- 1 Transmission Mode
- 2 Checking and Canceling Transmission Files
- (3) Communication Information
- (4) Other Transmission Features
- 5 Reception Features
- 6 Fax via Computer
- 7 Simplifying the Operation
- 8 Facsimile Features
- (9) Key Operator Setting
- 10 Solving Operation Problems
- 11 Appendix

For safe and correct use of this machine, please be sure to read the Safety Information in the General Settings Guide before you use it.

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Trademarks

Microsoft[®], Windows[®] and Windows NT[®] are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe® and Acrobat® are registered trademarks of Adobe Systems Incorporated.

Ethernet is a registered trademark of Xerox Corporation.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

Note

The proper names of the Windows operating systems are as follows:

- The product name of Windows® 95 is Microsoft® Windows 95.
- The product name of Windows® 98 is Microsoft® Windows 98.
- The product name of Windows® Me is Microsoft® Windows Millennium Edition (Windows Me).
- The product names of Windows® 2000 are as follows:

Microsoft® Windows® 2000 Advanced Server

Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Professional

The product names of Windows® XP are as follows:

Microsoft® Windows® XP Professional Microsoft® Windows® XP Home Edition

The product names of Windows NT® 4.0 are as follows:

Microsoft® Windows NT® Server 4.0

Microsoft® Windows NT® Workstation 4.0

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1"Operating Instructions for Printer/Scanner"
 - CD-ROM 2"Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

❖ Facsimile Reference <Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference<Advanced Features>(this manual)

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

◆ Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an overview of ScanRouter V2 Lite functions. This guide is added to the [Start] menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- Unix Supplement (Available from an authorized dealer, or as a PDF file on our Web site.)

- $\ensuremath{\square}$ The following software products are referred to using a general names:
 - DeskTopBinder V2 Lite and DesktopBinder V2 Professional → DesktopBinder V2 Lite/Professional
 - ScanRouter V2 Lite and ScanRouter V2 Professional (optional) → Scan-Router V2 Lite/Professional
 - SmartNetMonitor for Admin and SmartNetMonitor for Client → Smart-NetMonitor for Admin/Client

TABLE OF CONTENTS

| Manuals for This Machine | |
|--|----|
| How to Read This Manual | |
| Symbols | 1 |
| 1. Transmission Mode | |
| Sending at a Specific Time (Send Later) | 3 |
| User Transmission | 5 |
| Priority Transmission | 7 |
| Confidential Transmission | |
| Polling Transmission | |
| Polling Transmission Clear Report | |
| Polling Reception | |
| Polling Result Report | |
| | |
| 2. Checking and Canceling Transmission Files | |
| Displaying Confirmation of Transmission | |
| Canceling a Transmission | |
| Deleting a Destination | |
| Adding a Destination | |
| Changing the Transmission Time | |
| Printing a File | |
| Resending a File Printing a List of Files in Memory (Print TX File List) | |
| Printing a List of Files in Memory (Print 1X File List) | 25 |
| 3. Communication Information | |
| Printing the Journal | 27 |
| Journal | |
| Checking the Transmission Result (TX File Status) | |
| Checking the Reception Result (RX File Status) | |
| Displaying the Memory Status | |
| Printing/Deleting Received and Stored Documents (Print Stored RX | |
| Printing Received and Stored Documents Deleting Received and Stored Documents | |
| Printing a Confidential Message | |
| Confidential File Report | |
| Printing a File Received with Memory Lock | |
| Personal Boxes | |
| Personal Boxes | |
| Printing Personal Box Messages | 41 |

| Information Boxes | 43 |
|--|----|
| Information Boxes | 43 |
| Storing Messages in Information Boxes | 43 |
| Printing Information Box Messages | |
| Deleting Information Box Messages | |
| | |
| 4. Other Transmission Features | |
| Handy Dialing Functions | |
| Chain Dial | |
| (Example) 01133-1-555333 | 47 |
| Redial | 47 |
| Advanced Features | 49 |
| SUB Code | |
| SID Code | |
| SEP Code | |
| PWD Code | |
| Transfer Request | |
| With transfer requests set in the system settings | |
| On Hook Dial | |
| Manual Dial | |
| Changing the Line Port | |
| Sub Transmission Mode | |
| Book Fax | |
| Two-Sided Transmission (Double-Sided Transmission) | 62 |
| Standard Message Stamp | |
| Sending an Auto Document | |
| Printing documents stored as Auto Documents | |
| Sending a Stored File | |
| Sending stored documents | |
| Printing stored documents | |
| Stamp | |
| Transmission Options | |
| Fax Header Print | |
| Label Insertion | 74 |
| Sender Stamp | |
| Reduced Image Transmission | |
| Auto Reduce | |
| Default ID Transmission | |
| Selecting transmission options for a single transmission | |
| More Transmission Functions | |
| If Memory Runs Out While Storing an Original | |
| Parallel Memory Transmission | |
| Checking the Transmission Result | 79 |
| Automatic Redial | |
| Batch Transmission | 79 |
| Dual Access | 79 |
| Transmission with Image Rotation | |
| Simultaneous Broadcast | |
| JBIG Transmission | 81 |
| Transmitting Journal by E-mail | |
| Journal by E-mail | |

| Printed Report | |
|--|-----|
| Memory Storage Report | 83 |
| Transmission Result Report (Memory Transmission) | 83 |
| Communication Failure Report | 84 |
| Transmission Result Report (Immediate Transmission) | 84 |
| 5 December Contures | |
| 5. Reception Features | |
| Reception | |
| Immediate Reception | |
| Memory Reception | |
| Substitute Reception | |
| Receiving messages unconditionally | |
| Receiving messages according to parameter-specified settings | |
| Reception Functions | 89 |
| Transfer Station | 89 |
| Transfer Result Report | |
| Transfer Result Report (transfer request by e-mail) | |
| Forwarding Received Documents | 91 |
| Routing Received Documents with SUB Code | 92 |
| Transferring Received Documents | |
| SMTP Reception Using Internet Fax | 93 |
| Routing E-mail Received via SMTP | |
| JBIG Reception | |
| Auto Fax Reception Power-up | |
| Printing Options | 96 |
| Print Completion Beep | |
| Checkered Mark | 96 |
| Centre Mark | 96 |
| Reception Time | 97 |
| Two-Sided Printing | 97 |
| 180-Degree Rotation Printing | |
| Multi-copy Reception | |
| Image Rotation | |
| Combine Two Originals | |
| Page Separation and Length Reduction | 100 |
| Reverse Order Printing | |
| Page Reduction | |
| TSI Print (Transmitting Subscriber Identification Print) | 101 |
| When There Is No Paper of the Correct Size | 102 |
| Setting priority trays | |
| Just size printing | |
| Having Incoming Messages Printed on Paper from the Bypass Tray | |
| Where Incoming Message are Delivered - Output Tray | 105 |
| Specifying Tray for Lines | 105 |
| Tray Shift | 105 |
| | |

6. Fax via Computer

| Sending Fax Documents from Computers | 107 |
|--|--------|
| Before Use | |
| Installing the Software | |
| Auto run program | 108 |
| Installing individual applications | |
| Applications Stored on the CD-ROM | |
| LAN-Fax Driver | 110 |
| Address Book | 110 |
| LAN-Fax Cover Sheet Editor | 110 |
| Setting LAN-Fax Properties | 111 |
| Basic Transmission | 112 |
| Attaching a cover sheet | 113 |
| Previewing fax images | 114 |
| Specifying options | 114 |
| Printing and Saving | |
| Editing Address Book | |
| Editing Fax Cover Sheets | |
| Creating a cover sheet | |
| Attaching a created cover sheet | |
| LAN-Fax Operation Messages | |
| LAN-Fax Error Report | |
| Error Messages | |
| LAN-Fax Result by E-mail | 120 |
| Viewing Fax Information Using a Web Browser | |
| Viewing, Printing, and Deleting Received Fax Messages Using a Web Browse | er 121 |
| Viewing received fax messages using a Web browser | 121 |
| Printing fax information using a Web browser | 122 |
| Deleting fax information using a Web browser | 123 |
| Viewing Received Messages on a Computer | 124 |
| Delivering Received Messages | |
| | |
| 7. Simplifying the Operation | |
| Programs | |
| Registering and Changing Keystroke Programs | |
| Registering a priority function using a program | 128 |
| Changing a program name | |
| Deleting a Program | |
| Using a Program | |
| Using the Document Server | |
| Storing a Document | |
| Changing Information of Stored Documents | |
| Deleting a Stored Document | |
| Managing Documents Saved in the Document Server from a Computer | |
| Using DesktopBinder | |
| Using a Web browser | 137 |

8. Facsimile Features

| Function List | 139 |
|--|-----|
| Accessing User Tools (Facsimile Features) | 143 |
| Quitting Default Settings | |
| General Settings/Adjustment | 144 |
| Reception Settings | |
| E-mail Settings | 147 |
| 9. Key Operator Setting | |
| · · · · · · · · · · · · · · · · · · · | 440 |
| Key Operator Tools List | |
| Using Key Operator Settings | 151 |
| Storing, Changing, and Deleting an Auto Document | |
| Deleting an Auto Document | |
| Programming, Changing and Deleting a Scan Size | |
| Deleting a scan size | |
| Printing the Journal | |
| Counters | |
| Forwarding | |
| Programming an End Receiver | |
| Quitting the forwarding function | 158 |
| Forwarding Mark | |
| Memory Lock | |
| ECM (Error Correction Mode) | |
| User Parameters | |
| Changing the User Parameters | |
| Printing the User Parameter List | |
| Special Senders to Treat Differently | |
| Authorized Reception | |
| Forwarding | 167 |
| Reception File Print QuantityPrint 2 Sided | 107 |
| Memory Lock | |
| Reception Reverse Printing | 167 |
| Paper Tray | |
| Programming/ Changing Special Senders | |
| Programming Initial Set Up of a Special Sender | 171 |
| Deleting a Special Sender | |
| Printing the Special Sender List | |
| Box Settings | |
| Programming/changing Personal Boxes | 174 |
| Deleting Personal Boxes | 176 |
| Programming/changing Information Boxes | 177 |
| Deleting Information Boxes | |
| Programming/changing Transfer Boxes | |
| Deleting Transfer Boxes | |
| Printing the Box List | 183 |
| | |

| Transfer Report | 184 185 185 |
|---|-------------------|
| Reception Report e-mail | 187 |
| Setting a User Code for Viewing Received and Stored Documents | 188 |
| 10.Solving Operation Problems | |
| When an Error Report is Printed | 189 |
| Turning Off the Main Power / When a Power Failure Occurs | 190 |
| When an Error Occurs Using Internet Fax | |
| Error Mail Notification | |
| Error Report (Mail) | |
| Server-Generated Error E-mail | 191 |
| 11.Appendix | |
| Replacing the Stamp Cartridge | 193 |
| Connecting the Machine to a Telephone Line and Telephone | 195 |
| Connecting the Telephone Line | |
| Selecting the Line Type | 195 |
| Optional Equipment | 196 |
| Fax Function Upgrade Unit | 196 |
| Expansion Memory (32MB: DIMM) | |
| Extra G3 Interface Unit | |
| Specifications | 197 |
| Compatible Machines | |
| Acceptable Types of Originals | |
| Acceptable original sizes | |
| Paper size and scanned area | |
| Maximum Values | 202 |
| INDEX | 204 |

How to Read This Manual

Symbols

In this manual, the following symbols are used:

↑ WARNING:

This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

A CAUTION:

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

* The statements above are notes for your safety.

#Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates information or preparations required prior to operating.

Note

This symbol indicates precautions for operation, or actions to take after abnormal operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions under which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys that appear on the machine's display panel.

[]


Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

1. Transmission Mode

Sending at a Specific Time (Send Later)

Using this function, you can instruct the machine to delay transmission of your fax message until a specified later time. This allows you to take advantage of off-peak telephone charges without having to be by the machine at the time.



If you have a non-urgent fax, select Send Later with Economy Transmission when you scan it. Faxes will be queued in memory and sent during Economy Transmission Time.

∰Important

☐ After the machine has been switched off for about one hour, all fax messages stored in memory are lost. If messages are lost for this reason, a Power Failure Report is automatically printed when the operation switch is turned on. Use this report to identify lost messages.

Limitation


 This function is unavailable with Immediate Transmission. Use Memory Transmission.

Note


- ☐ You can specify a time within 24 hours.
- ☐ If the current time shown is not correct, change it. See "Timer Settings", General Settings Guide.
- If the document is sent before the specified time, the Transmission Result Report is printed and the job is completed.
- ☐ For convenience, you can program the time when your phone charges become cheaper as the Economy Transmission Time. See p.145 "Program Economy Time".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".
- 1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

Press [Transmission Mode].



- Press [Send Later].
- 4 Enter the time (24 hour format) using the number keys, and then press [OK].



The specified time is shown above the highlighted [Send Later].

Note

- ☐ Press **[Economy Time]** to specify the economy time.
- ☐ When entering numbers smaller than 10, add a zero at the beginning.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Send Later, press [Cancel]. The display returns to that of step [3].
- Press [OK].

- Note
- ☐ To check the settings, press [Transmission Mode].
- Specify a destination, and then press the [Start] key.
 - Note
 - ☐ You can cancel the transmission setup for Send Later. See p.19 "Canceling a Transmission".

User Transmission

This function allows you to check each user or department's transmission history. To use the function, you need to program a user code (eight digits max.) for each user or department, to be entered before transmission. See "Displaying the Counter for Each User Code", General Settings Guide.


If a user code set with an e-mail address is specified, a transmission result e-mail can be sent.

- ☐ You can program codes of up to 8 digits for a maximum of 500 users and/or departments. See "Registering a New User Code", General Settings Guide. See p.145 "Quick Operation Key"
- ☐ You can enter user codes or names into various lists or reports.
- ☐ You can program transmission operations in Quick Operation key. Quick Operation key let you skip steps ② and ③. See p.145 "Quick Operation Key", Facsimile Reference <Advanced Features>.
- □ When you send documents by Internet Fax using the user code with e-mail address programmed and "Register as Sender" set to "[ON]", the following sender name appears on the e-mail received at the other end.
 - When User Name is programmed in the user code:
 User Name <E-mail address programmed in the user code>
 - When User Name is not programmed in the user code:
 <E-mail address programmed in the user code>


1 Place the original, and then select desired scan settings.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Press [Transmission Mode].



- 3 Press [User TX].
- Using the number keys enter a user code (up to eight digits), and then press [*].




The programmed user name will appear.

- Note
- ☐ If you enter a wrong code, press [Clear] or the [Clear/Stop] key before pressing [♠], and then try again.
- ☐ To cancel the operation, press [Cancel]. The display returns to that of step §.

When your e-mail address is programmed with the user code

If your e-mail address is programmed with the user code, you can select whether the machine sends transmission result by e-mail.

1 Press [Yes] or [No].




𝚱 Note

- ☐ If you select **[Yes]**, a Transmission Result Report is sent to the programmed e-mail address after the transmission so that you can check the result of transmission.
- **5** Press [OK] twice.

- Note
- ☐ To check the settings, press [Transmission Mode].
- 6 Specify a destination, and then press the [Start] key.
 - Note
 - ☐ You can cancel the transmission setup for User Transmission. See p.19 "Canceling a Transmission".

Priority Transmission

Documents you send with Memory Transmission are sent in the order they are scanned. Therefore, if several messages are queued in memory, the next document will not be sent immediately. However, by using this function you can have your message sent before other queued messages.




Limitation


☐ This function is not available with Immediate Transmission. If this function is selected, the machine automatically switches to Memory Transmission.

- ☐ If there is already a message stored with this function or a transmission in progress, your message will be sent after that message has been transmitted.
- Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features> 2 Press [Transmission Mode].




Press [Priority TX], and then press [OK].



- Note
- ☐ To check the settings, press [Transmission Mode].
- Specify the destination, and then press the [Start] key.
 - Note
 - ☐ Press [Change/Stop TX File] to cancel the transmission. See p.19 "Canceling a Transmission".

Confidential Transmission

If you want to limit who views your message, use this function. The message will be stored in memory at the other end and not printed until an ID is entered.



There are two types of Confidential Transmission:

Default ID

It is not necessary to enter an ID when transmitting.

The other party can print the message by entering the Confidential ID programmed in their machine.

ID Override

Should you want to send a confidential message to a particular person at the other end, you can specify the Confidential ID that the receiver has to enter to see that message. Before you send the message, do not forget to tell the receiver the ID that must be entered to print the message.

Limitation


- ☐ The destination machine must be of the same manufacturer and have the Confidential Reception function.
- ☐ The destination machine must have enough memory available.

Note

- ☐ We recommend you program the Confidential ID in this machine beforehand. See p.184 "Programming a Confidential ID".
- ☐ An ID can be any 4-digit number (except 0000).
- ☐ If the destination machine is not of the same manufacturer, you can use Confidential Transmission with "SUB Code". See p.49 "SUB Code".
- ☐ This function is not available with Internet Fax.
- 1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Press [Transmission Mode].



Press [Confidential TX].

Depending on the Confidential Transmission type, use one of the following procedures:



Default ID


• Check that [Default ID] has been selected, and then press [OK].

"Default ID" is shown above the highlighted [Confidential TX].

- ☐ To cancel Confidential Transmission, press [Cancel]. The display returns to that of step ☐.

Override ID

- 1 Select [ID Override].
- Enter the Confidential ID (4digit number) using the number keys, and then press [OK].



"ID Override" and the entered Confidential ID are shown above the highlighted [Confidential TX].

Note


- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Confidential Transmission, press [Cancel]. The display returns to that of step ■.
- Press [OK].

- Note
- ☐ To check the settings, press [Transmission Mode].
- Dial, and then press the [Start] key.

 - ☐ You can cancel the transmission setup for Confidential Transmission. See p.19 "Canceling a Transmission".

Polling Transmission

Use Polling Transmission when you want to leave an original in the machine memory for others to pick up. The message will be sent when the other party calls you up.



There are three types of Polling Transmission.

Free Polling Transmission

It is not necessary to enter the Polling ID during the procedure. Anybody can poll the message from your machine. The machine sends it regardless of whether Polling ID's match.

Default ID Transmission

It is not necessary to enter the Polling ID during the procedure.

The message will only be sent if the Polling ID of the machine trying to poll your message is the same as the Polling ID stored in your machine. Make sure in advance that both machines' Polling IDs are identical.

Before using Default ID Transmission, you need to program the Polling ID. See p.185 "Programming a Polling ID".

ID Override Transmission

You must enter an Override Polling ID unique to the transmission. This ID overrides the ID stored in the machine. The user must supply this ID when they poll your machine. If the IDs match, the message is sent. Make sure in advance the other end knows the ID you are using.

Limitation


- Polling Transmission is allowed only if the receiver's machine has the Polling Reception function.
- □ Usually, only machines of the same manufacturer that support Polling Reception can perform ID Polling Transmission. However, when the Information Box File function is used, and the other party's fax machine supports Polling Transmission and the SEP function, you can still carry out Polling Transmission with an ID. See p.43 "Information Boxes".

- ☐ Free Polling and Default ID Transmission allow only one file to be stored in memory.
- ☐ ID Override Polling Transmission allows a file to be stored in memory for each ID; you can store up to 400 files (800 with the optional fax function upgrade unit) by changing IDs.
- ☐ You can set whether a Polling Transmission file is deleted after transmitting in User Parameters. To save the file to transmit repeatedly, set to "Standby (Save)". See p.161 "User Parameters" (switch 11, bit 7).

- ☐ Polling Transmission Clear Report allows you to verify Polling Transmission has taken place. See p.12 "Polling Transmission Clear Report". If E-mail TX Results is programmed in a Quick Operation key, you can select whether a report e-mail is sent after transmission. The destination of this report can be selected from the e-mail addresses in the destination list.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".
- ☐ The communication fee is charged to the receiver.
- ☐ This function is not available with Internet Fax.
- 1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Press [Transmission Mode].



Press [Polling TX].

Depending on the Polling Transmission mode, use one of the following procedures:




Free Polling Transmission

• Check that [Free Polling TX] is selected.

Default ID Transmission

1 Select [Default ID TX].

- **ID Override Transmission**
- **●** Select [ID Override Transmission].
- Specify a 4-digit ID using the number keys and [A], [B], [C], [D], [E], and [F].



- ☐ A Polling ID may be any four numbers (0 to 9) and characters (A to F), except 0000 and FFFF.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then try again.

Press [Only Once] or [Save] to delete or save the file after transmission.

Note

- To delete the original immediately after transmission, select [Only Once].
- ☐ To repeatedly send the original, select **[Save]**.
- ☐ To cancel Polling Transmission, press [Cancel]. The display returns to that of step 3.

6 Press [OK].

"**XXXXXXX**" appears.

The type of Polling Transmission is shown above the highlighted [Polling TX].

7 Press [OK].

Note

☐ To check the settings, press [Transmission Mode].

8 Press the [Start] key.

𝚱 Note

☐ You can cancel the transmission setup for Polling Transmission. See p.19 "Canceling a Transmission".

Polling Transmission Clear Report

This report allows you to verify Polling Transmission has taken place.

If E-mail TX Results is programmed in a Quick Operation key, you can have the report e-mail sent after transmission.


Limitation

☐ This report is not printed if the User Parameters are set to allow the stored originals to be repeatedly sent (Save). See p.161 "User Parameters" (switch 11, bit 7).

- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 03, bit 6).
- ☐ You can have a portion of the sent image printed on the report with the User Parameters. See p.161 "User Parameters" (switch 04, bit 7).
- ☐ You can check the result of Polling Transmission with the Journal. See p.27 "Printing the Journal"
- ☐ To view the report without text disruption, select a font of even character width in your e-mail application's settings.

Polling Reception

Use this function to poll a message from another terminal. You can also poll documents from many terminals with only one operation (use Groups and Keystroke Programs to fully exploit this function).



There are two types of Polling Reception.

Default ID/Free Polling Reception

Use this method for Free Polling or Default ID Polling. If the Polling ID is programmed in your machine, any messages waiting in the transmitting machine with the same ID are received. If the other machine does not have any messages waiting with the same Polling ID, any messages that do not require ID are received (Free Polling).

For ID Polling Reception, program a Polling ID in advance. See p.185 "Programming a Polling ID".

♦ ID Override Polling Reception

You must enter an Override Polling ID unique to this transmission. This ID overrides the one stored in this machine.


Your machine will receive any messages waiting in the transmitting machine that have matching ID's. If no ID's match, any messages that do not require IDs are received (Free Polling).

Limitation

- Polling Reception requires that the other machine is capable of Polling Transmission.
- ☐ Usually, you can only receive documents with a Polling ID from machines of the same manufacturer that support the polling function. However, if the other party's fax machine supports Polling Transmissions and the SEP function, and also has stored IDs, you can still perform Polling Reception. See p.50 "SEP Code".

- ☐ To receive a message sent by Default ID Polling Transmission or ID Override Polling Transmission, it is necessary to specify the same Polling ID as the sender's. Free Polling Transmission does not require the same Polling ID.
- ☐ Polling Result Report allows you to verify Polling Reception has taken place. See p.15 "Polling Result Report". If E-mail TX Results is programmed in a Quick Operation key, you can select whether a report e-mail is sent after reception. The destination of this report can be selected from the e-mail addresses in the destination list.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ☐ and ☐. See p.145 "Quick Operation Key".
- ☐ This function is not available with Internet Fax.

1 Press [Transmission Mode].



- 2 Press [Polling RX].
- Depending on which method you are using, select one of the following procedures:



Default ID/Free Polling Reception

Check that [Default ID/Free Polling RX] is selected, and then press [OK].


"Deflt ID/Free Poll." is shown above the highlighted [Polling RX].

Note

☐ To cancel Polling Reception, press **[Cancel]**. The display returns to that of step **②**.

ID Override Polling Reception

- Select [ID Override Polling Reception].
- Specify a 4-digit ID using the number keys and [A], [B], [C], [D], [E], and [F], and then press [OK].



"ID Override" and the entered Polling ID are shown above the highlighted [Polling RX].

Note

- ☐ A Polling ID may be any four numbers (0 to 9) and characters (A to F), except 0000 and FFFF.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Polling Reception, press **[Cancel]**. The display returns to that of step **A**.

4 Press [OK].

The standby display appears.

Dial, and then press the [Start] key.

Polling Reserve Report

This report is printed after Polling Reception has been set up.

☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 03, bit 3).

Polling Result Report

This report is printed after a Polling Reception has been completed and shows its result.

If E-mail TX Results is programmed in a Quick Operation key, you can select whether a report e-mail is sent after reception.

𝚱 Note

- ☐ You can also check the result of a Polling Reception with the Journal. See p.27 "Printing the Journal".
- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 03, bit 4).
- ☐ To view the report without text disruption, select a font of even character width in your e-mail application's settings.

2. Checking and Canceling Transmission Files

After you have pressed the **[Start]** key (after scanning originals), you can check and edit the destination or settings of Memory Transmission. You can also cancel a transmission, change the settings of a transmission, print a stored file, print a list of stored files, and resend a file which the machine failed to transmit.

- Memory Transmission
- Internet Fax Transmission
- · Send Later
- User Transmission
- Priority Transmission
- Confidential Transmission
- Polling Reception
- · Polling Transmission
- · Transfer Request

Ø Note

- ☐ If there are no files being sent, received, or stored by Memory Transmission, [Change/Stop TX File] does not appear on the display.
- ☐ You cannot check or edit a file being sent or received. Also a Confidential Transmission file or stored file to be printed as a report cannot be checked or edited.

Displaying Confirmation of Transmission

1 Press [Change/Stop TX File].




5 Press [Exit].

The standby display appears.

2 Press [Check/Change Settings].



3 Select a file to check.



⊘ Note


- ☐ If multiple destinations were specified, only the destination selected first appears.
- ☐ If multiple destinations were specified, only the number of unsent messages appears.
- Confirm a transmission, and then press [Exit].

Canceling a Transmission

You can cancel transmission of a file when the file is being sent, stored in memory, or fails to transmit. All the scanned data is deleted from memory.

You can cancel a file for Memory Transmission. This function is useful to cancel a transmission when you notice a mistake in destination or with the originals after storing. To cancel Memory Transmission, search for the file to be canceled among the files stored in memory, and then delete it.

- ☐ If you cancel a transmission while the file is being sent, some pages of your file may have already been sent and will be received at the other end.
- ☐ If the transmission finishes while you are carrying out this procedure, transmission cannot be canceled.
- 1 Press [Change/Stop TX File].



2 Select a file whose transmission you want to cancel.



- **∅** Note
- ☐ To display only the files being sent, press [Files under TX].
- ☐ If multiple destinations were specified, only the number of unsent messages appears.
- ☐ If multiple destinations were specified, only one destination number appears. To display all destinations, press [Check/ Change Settings].
- Press [Stop Transmission].

The selected file is deleted.

- Note
- ☐ To quit transmission cancel, press [Save].
- ☐ To cancel another transmission, repeat from step ②.
- 4 Press [Exit].

Deleting a Destination

You can delete destinations.

Note


- ☐ If you delete a destination that is the only destination for a transmission, the transmission is canceled.
- 1 Press [Change/Stop TX File].




2 Press [Check/Change Settings].



Select the file from which you want to delete a destination.



Press [Change] for the destination you want to delete.



- Note
- □ Press ★ to switch the destination between fax number and email address.
- Press [Clear] to delete the destination.




- Note
- ☐ Pressing **[Clear]** deletes the destination by single digit.
- 6 Press [Exit].

 - ☐ To delete another destination, repeat from step 3.
- **7** Press [Exit].


Adding a Destination

Note


- ☐ A destination cannot be added using a destination list.
- 1 Press [Change/Stop TX File].




Press [Check/Change Settings].



Select the file to which you want to add a destination.



4 Press [Add].



- Note
- ☐ Press to switch the destination between fax number and email address.
- **5** Specify the destination using the number keys or soft (on-screen) keys.



- Ø Note
- ☐ To add e-mail address, press [Manual Input], and then specify the destination.
- ☐ You can also program a SUB Code by pressing [Adv. Features].
- ☐ Repeat steps ② and ⑤, if you want to add another destination.
- 6 Press [Exit].
- **7** Press [Exit].

Changing the Transmission Time

You can change the transmission time specified with Send Later. See p.3 "Sending at a Specific Time (Send Later)".

You can also delete the transmission time. If the transmission time is deleted, the file is transmitted immediately.


1 Press [Change/Stop TX File].



2 Press [Check/Change Settings].



3 Select the file for which you want to change or cancel the transmission time.



4 The recipient appears.

Press [Change TX time].



Press [Clear], and then re-enter the transmission time using the number keys or select [Economy Time], and then press [OK].




- **𝒜** Note
- ☐ If you select **[Economy Time]**, the economy time already specified is entered. See p.144 "General Settings/Adjustment".
- ☐ If you press [Transmit Now], the file is transmitted immediately. However, if there is a file on standby, that file is sent first.
- 7 Press [Exit].
 - Ø Note
 - ☐ Repeat from step **⑤**, if you want to change another transmission time.
- 8 Press [Exit].

Printing a File

If you want to check the contents of a file that is stored in memory and not yet sent, use this procedure to print it out.

Note


- ☐ Confidential Transmission files are displayed, but cannot be printed.
- ☐ You can also print files that have not been successfully transmitted.
- 1 Press [Change/Stop TX File].



2 Press [Print File].



3 Select the file you want to print.



Note

- If multiple destinations were specified, only the number of unsent messages appears.
- ☐ If you want two-sided printing, press [Print 2 Sides].
- ☐ To cancel printing, press [Cancel]. The display returns to that of step [3].
- 4 Press the [Start] key.

𝚱 Note

☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **§**.

5 Press [Exit].

The standby display appears.

Note

☐ Repeat from step **⑤**, if you want to print another file.

Resending a File

Machine memory stores messages that could not be successfully transmitted using Memory Transmission. Use this procedure to resend these messages.

Preparation


You should select "Store for 24 hours" for "Store a message that could not be transmitted" in User Parameters. See p.161 "User Parameters" (switch 24, bit 0).

Note

- ☐ Files that could not be transmitted will be kept for either 24 or 72 hours depending on how you program this function. See p.161 "User Parameters" (switch 24, bit 1).
- 1 Press [Change/Stop TX File].




2 Press [Transmit Failed File].



3 Select the file you want to resend.

"TX failed" is displayed for files that could not be sent.



- ☐ If multiple destinations were specified, only the destination number appears.
- ☐ If multiple destinations were specified, only the number of unsent messages appears.

4 Press [OK].

𝚱 Note

- ☐ To add destinations, press [Add], and then specify the destinations.
- ☐ To cancel transmissions, press [Cancel]. The display returns to that of step [3].
- ☐ Repeat from step 3 to resend another file.

Press [Exit].

The standby display appears.


Transmission starts.

Printing a List of Files in Memory (Print TX File List)


Print this list if you want to find out which files are stored in memory and what their file numbers are. Knowing the file number can be useful (for example when erasing files).

𝒜 Note

- ☐ The contents of a file stored in memory can also be printed. See p.23 "Printing a File".
- 1 Press [Change/Stop TX File].



2 Press [Print List].



Note

☐ To cancel printing before pressing the **[Start]** key, press **[Cancel]**. The display returns to that of step **2**.

3 Press the [Start] key.

- ☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **2**.
- 4 Press [Exit].

3. Communication Information

Printing the Journal

The Journal contains information about the last 50 communications (maximum) made by your machine. It is printed automatically after every 50 communications (receptions & transmissions).

You can also print a copy of the Journal at any time by following the procedure below.

If the machine is installed with the optional extra G3 interface unit, you can print the Journal of each line type.

∰Important

☐ The contents of a Journal printed automatically are deleted after printing. Keep the journal if you require a record of transmissions and receptions. You can check a total of 200 communications (receptions & transmissions) on the display.

◆ All

Prints the results of communications in the order made.

Print per File No.

Prints only the results of communications specified by file number.


Print per User Code

Prints only the results of communications through User Code Management or User Transmission. See p.9 "User code entry display", Facsimile Reference < Basic Features > and p.5 "User Transmission".

Note


- ☐ The setting on the machine can be changed so that user codes will be printed instead of user names. For more information, contact your service representative.
- ☐ The sender name column of the Journal is useful when you need to program a special sender. See p.165 "Special Senders to Treat Differently".
- ☐ You can set whether the Journal is automatically printed after every 50 communications in User Parameters. See p.161 "User Parameters" (switch 03, bit 7).
- ☐ You can set whether you print the Journal by line type. See p.161 "User Parameters" (switch 19, bit 1).
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**. See p.145 "Quick Operation Key".

1 Press [Information].



2 Press [Print Journal].

3 Select a printing mode.




ΑII

• Select [All].

Print per File No.

- Select [Print per File No.].
- 2 Enter a 4-digit file number.



Note

☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then try again.

Print per User Code


- Select [Print per User Code].
- ② Specify a user code of up to 8 digits using the number keys, and then press [⊕].



- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [♠], and then try again.
- 3 Check the user name shown on the display.
- 4 Press the [Start] key.

 - ☐ To cancel a file printing, press [Stop Printing]. The display returns to that of step ②.
- **5** Press [Exit] twice.

Journal



1. Printing date

Shows the date and time when the report is printed.

2. Programmed sender name

Shows the sender name programmed for printing.

3. Date

Shows the transmission or reception date.

4. Time

Shows the transmission or reception start time.

5. Other end

For fax destinations

- Shows the name (for display) programmed by the other end.
- Shows the programmed fax number if the name (for display) has not been programmed.
- If neither name nor fax number has been programmed by the other end, an entered fax number or a name programmed in a destination list is shown for transmissions.
- The space will be blank for receptions.

To prioritize a fax number or name programmed in the destination list, contact your service representative.

For Internet Fax destinations

- Shows the e-mail address or name programmed in the destination list for transmissions.
- Shows the number of the destinations after an e-mail address or a name for broadcasting transmissions.
- When receiving a fax, the e-mail address of the sender for receptions.

6. Communication mode

- For fax transmissions and receptions After "T" for outgoing fax or "R" for ingoing fax, shows a communication mode. If the optional Extra G3 interface unit has been installed, "G3-1" or "G3-2" will be shown.
- For Internet Fax transmissions and receptions

After ⋄, and "T" for outgoing e-mail or "R" for ingoing e-mail, the communication mode appears in alphabetical letters or symbols. Outgoing e-mail set for Reception Notice of E-mail Options bears a "Q", whereas "A" appears with reception confirmation e-mails.

7. Communication time

Shows time taken for transmissions or receptions.

8. Number of pages

Shows the number of pages transmitted or received.

9. Communication result

Shows the result of transmissions or receptions.

OK: All pages were properly transmitted or received. When Reception Notice is activated using the Internet Fax E-mail Options, receipt of Reception Notice is shown.

--: The Internet Fax was document sent to the mail server programmed in this machine. (However, this does not mean the e-mail was delivered.)

Error: A communication error occurred.

D: Power was disconnected during communication. Not all fax messages were transmitted.

10. User name

Shows the user name programmed for user code use restriction or User Transmission.

11. File number

Shows file management numbers.

Checking the Transmission Result (TX File Status)

You can browse a part of the Transmission Result Report on the display.


Note

- ☐ Only the transmission result of the last 200 communications (receptions & transmissions) are shown.
- ☐ You can view sent fax messages and their lists, using a network computer Web browser. For details, see the Web browser's Help.
- ☐ If a transmission is completed while you are using this function, the result will not appear. To view the latest result, exit TX File Status, and then try again.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**. See p.145 "Quick Operation Key".
- 1 Press [Information].



2 Select [TX File Status].

3 Check the transmission results.



Transmission results are displayed, from the latest result down, in groups of six.

☐ When a fax is sent, "Destination" shows the Own Fax Number or Fax Header information of a receiver. The e-mail address and name programmed in the destination list appears in the "To" field of the sent Internet Fax document. For a transmission from a computer, "-- LAN-Fax -->" is shown.


4 Press [Exit] twice.

Checking the Reception Result (RX File Status)

You can browse a part of the Reception Result Report on the display.

Note

- ☐ Only the reception result of the last 200 communications (receptions & transmissions) are shown.
- ☐ You can view received fax messages and their lists, using a network computer Web browser. For details, see the Web browser's Help.
- ☐ If a message is received while you are using this function, the result will not appear. To view the latest result, exit RX File Status, and then try again.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**. See p.145 "Quick Operation Key".
- 1 Press [Information].



2 Select [RX File Status].

3 Check the reception results.



Reception results are displayed from the latest result in groups of six.


☐ When a fax is received, Transmission Station shows the fax number of a sender or Fax Header information. The sender's e-mail address appears in the "From" field of the received Internet Fax.

4 Press [Exit] twice.

Displaying the Memory Status

Use this function to display a summary of current memory usage. Items shown are the percentage of free memory space, the number of received confidential messages, the number of files to be sent, the number of Memory Lock files and the number of received messages to be printed.

1 Press [Information].



- 2 Press [Memory Status].
- 3 Check the memory status.




- **𝚱** Note
- $\hfill\Box$ "Others" will be displayed:
 - When storing attachment files. See p.65 "Sending an Auto Document".
 - When storing Transfer Request files. See p.52 "Transfer Request".
 - When storing originals in the Information Boxes. See p.43 "Storing Messages in Information Boxes".

- When sending to the Personal Box. See p.41 "Printing Personal Box Messages".
- ☐ If you have made the machine save received messages on the hard disk, see "RX Print Standby File" on the display to check the number.
- 4 Press [Exit] twice.

Printing/Deleting Received and Stored Documents (Print Stored RX File)

You can print documents that are received and stored on the hard disk. You can also delete unwanted documents.



Preparation

Make a setting for received and stored documents before using this function. See p.186 "Storing or Printing Received Documents".


- ☐ If you have selected to store received documents and specified an e-mail address for notification of receipt, fax reception notification can be sent to that e-mail address. See p.187 "Reception Report e-mail".
- ☐ You can store up to 400 received documents on the hard disk (800 with the optional fax function upgrade unit).
- ☐ You can view and/or print received and stored documents using a Web browser or Desktop-Binder V2 Lite. See p.121 "Viewing Fax Information Using a Web Browser" or the DesktopBinder V2 Lite's manuals and Help.

Printing Received and Stored Documents


Use the following procedure to print documents saved on the hard disk.

Note

- This function allows you to print only received and stored documents.
- You cannot print and delete received documents using the Document Server function.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at one time.
- 1 Press [Information].



- 2 Press [Print Stored RX File].
- 3 Select a file to be printed, and then press [Print].



3

4 Select the printing mode, and then press the [Start] key.

- Note
- ☐ To cancel printing, press [Cancel]. The display returns to that of step [3].
- □ To delete the document after printing, press [Delete File after Printing].
- ☐ To perform 2-sided printing, press [Print on 2 Sides] before pressing the [Start] key.
- **5** Press [Exit] twice.

The standby display appears.

Deleting Received and Stored Documents

Use the following procedure to delete documents stored on the hard disk.


Note

- ☐ You cannot delete a document while another person is previewing or printing it using a Web browser or DesktopBinder V2 Lite.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at one time.
- 1 Press [Information].



2 Press [Print Stored RX File].

Select a file to be deleted, and then press [Delete].



- 4 Press [Yes].

 - ☐ To cancel a deletion, press [No].

 The display returns to that of step 3.
- **5** Press [Exit] twice.

Printing a Confidential Message

This function is designed to prevent unauthorized users from reading your messages. If someone sends you a message using Confidential Transmission, it is stored in memory but not automatically printed. To print the message you have to enter the Confidential ID Code. When your machine has received a confidential message, the Confidential File (Y) indicator lights.

Preparation

Before using this function, program your Confidential ID. See p.184 "Programming a Confidential ID".

∰Important

☐ If the main power switch is off more than one hour, all confidential messages are deleted. When this happens, use the Power Failure Report to identify which messages have been deleted. See p.190 "Turning Off the Main Power / When a Power Failure Occurs".

Limitation

 You must program the Confidential ID for Confidential Reception to work.


Note

☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".

1 Confirm that the Confidential File indicator is lit.



2 Press [Information].



Press [Print Confidential RX File].

Note

- ☐ If no confidential messages have been received, the message "No reception file." is shown. Press [Exit].
- 4 Enter a 4-digit Confidential ID using the number keys, and then press the [Start] key.



The Confidential ID differs depending on the Sender's specifications.

Note

- You must enter the Confidential ID programmed in this machine, if the received file has no Confidential ID.
- You must enter the Confidential ID programmed by the sender. Confirm the sender's Confidential ID in advance.
- ☐ If the Confidential IDs or Personal Confidential IDs do not match, the message "No reception file under specified Confidential ID." appears. Press [Exit] to cancel the operation, and then check the Confidential ID or Personal Confidential ID with the other party, and then try again.

Press [Exit].

The standby display appears.

If you cannot print confidential files even if the Confidential File (1947) indicator is lit.

The Confidential File indicator also lights if the machine received a message with a SUB Code. Check the Personal Boxes.

∅ Note

☐ Print from the Personal Box, when a file has been sent from another party with a SUB Code attached. See p.41 "Printing Personal Box Messages".

Confidential File Report

When this function is turned on, this report is printed whenever your machine receives a confidential message.

Note

☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 04, bit 0).

Printing a File Received with Memory Lock

This is a security function designed to prevent unauthorized users from reading your messages. If Memory Lock is switched on, all received messages are stored in memory and are not automatically printed. To print the messages, you have to enter the Memory Lock ID Code. When your machine has received a message with Memory Lock, the **Confidential File** (王) indicator blinks.

Preparation

Before using this function, program your Memory Lock ID. See p.185 "Programming a Memory Lock ID".

Before using this function, set Memory Lock to On. See p.167 "Memory Lock".

∰Important

☐ If the main power switch is turned off for more than an hour, all messages protected by Memory Lock will be deleted. In that case, the Power Failure Report will be printed so you can confirm which messages have been deleted. See p.190 "Turning Off the Main Power / When a Power Failure Occurs".

Note

☐ If Memory Lock and received document storage are both set to on, Memory Lock is unavailable and received documents become stored documents. For details, see p.186 "Storing or Printing Received Documents" and p.34 "Printing/Deleting Received and Stored Documents (Print Stored RX File)".

- Even when Memory Lock is available, if free memory is insufficient, reception is not possible.
- ☐ You can also apply a Memory Lock to messages that come only from certain senders. See p.168 "Programming/ Changing Special Senders".
- Messages received by Polling Reception are automatically printed even if this function is switched on.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".
- Confirm that the Confidential File indicator is blinking.




2 Press [Information].



Press [Print Memory Lock].

Note

- ☐ If no messages were received while Memory Lock was switched on, the message "No reception file." is shown. Press [Exit].
- 4 Enter a 4-digit Memory Lock ID with the number keys, and then press the [Start] key.



Note

☐ If the Memory Lock ID does not match, the message "Specified code does not correspond to programed Memory Lock ID." appears. Press [Exit] and retry after checking the Memory Lock ID.

5 Press [Exit].

Personal Boxes



Preparation


Before using this function, set the Personal Box in advance. See p.174 "Programming/changing Personal Boxes".

Personal Boxes

This function lets you set up the machine so that incoming messages addressed to certain users are stored in memory instead of being printed out immediately.

Each user must be assigned a SUB Code (Personal Code) that has been designated as a Personal Box beforehand. When the other party sends their message, they specify the SUB Code of the receiver. When the message is received, it is stored in the Personal Box with the matching SUB Code. In order to print a received message.

This enables several individuals or departments to share a single fax machine yet be able to differentiate between messages. Furthermore, if you specify a receiver for the Personal Box, instead of being stored in memory, incoming messages with this SUB Code appended are forwarded directly to the destination you specify. You can specify a fax number or an e-mail address. See p.174 "Programming/changing Personal Boxes".



- To be able to receive messages into a Personal Box you must inform the sender of the SUB Code programmed for that Personal Box and ask them to send the message using SUB Code Transmission with that SUB Code. See p.49 "SUB Code".
- When messages have been received into Personal Boxes, the Confidential Reception/Memory Lock indicator lights and the Confidential File Report is printed. See p.37 "Confidential File Report".
- If a Personal Box is assigned a receiver, incoming messages are transferred to that receiver with a Forwarding Mark stamped on them. See p.159 "Forwarding Mark".
- If a receiver is not assigned, print these messages. See p.41 "Printing Personal Box Messages".

SUB Code and SEP Code

SUB Code and SEP Code are IDs consisting of up to 20 digits, and can include numbers, #, *, and spaces. To use this function, you must program a box and SUB/SEP Code beforehand. The other party can send messages to, and retrieve stored messages from, this box using the code.

Note

This function is not available when you have set received documents to be delivered to the network delivery server.

Printing Personal Box Messages


Follow these steps to print a message that has been received into a Personal Box.

∅ Note


- ☐ If you print a Personal Box message, it is deleted.
- 1 Make sure that the Confidential File indicator is lit.



2 Press [Information].



- 3 Press [Print Personal Box File].
- 4 Select the box with the message you want to print.



When a password is required

The display appears, when the selected Personal Box password is set in advance.

Ø Note

- ☐ The password is programmed in "Key Operator Tools". See p.174 "Programming/changing Personal Boxes".
- Enter the password, and then press [OK].



Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step ④.

5 Press the [Start] key.

- Note
- ☐ To stop printing, press [Stop Printing]. The display returns to that of step [].
- 6 Press [Exit].
 - Note
 - ☐ To print a message in another Personal Box, refer to step 4, and then try again.
- **7** Press [Exit].


Information Boxes



Before using this function, set the Information Box in advance. See p.177 "Programming/changing Information Boxes".

Information Boxes

Use the Information Box function to set up the machine as Document Server. By scanning documents into Information Boxes, other parties can receive these messages whenever they request them.



- You can program documents for this function with "Store/Delete/Print Information Box File".
 See p.43 "Storing Messages in Information Boxes".
- For other parties to be able to retrieve a message programmed in an Information Box, you need to inform them of the SEP Code assigned to that Information Box.
- When an SEP Code Polling Reception request is made by another party, the SEP Code they specify is matched against the SEP Codes programmed in that Information Boxes. If a code matches, the message stored in the Information Box is sent to the other party automatically. See p.49 "SUB Code".

- You can check the contents of Information Boxes with "Store/Delete/Print Information Box File".
 See p.45 "Printing Information Box Messages".
- You can set a password for Information Boxes in advance. A password can be set in "Key Operator Setting". See p.177 "Programming/changing Information Boxes".


Storing Messages in Information Boxes

Follow these steps to store a message in an Information Box.

Note

- ☐ One Information Box stores one file.
- ☐ The stored file is not deleted automatically. If you want to delete a stored file, see p.46 "Deleting Information Box Messages".

1 Press [Information].



Press [Store/Delete/Print Information Box File.].

Select the box in which you want to store the file.




Note

- When there are pre-programmed files, a file mark is displayed at the end of the Box Name.
- ☐ A message is displayed, when selecting a box with a file stored in it. Press **[Yes]**, when changing the file name. The file stored originally will be overwritten.

When a password is required

• Enter the password, and then press [OK].



Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step [3].

Place the original, and then select the scan settings you require.



- ☐ You can also select the following settings:
 - Book Fax
 - Two-Sided Original (The optional ADF is required.)
 - Stamp (The optional ADF is required.)

₽ Reference

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

5 Press the [Start] key.

The machine starts to scan the original.

To stop scanning, press [Stop Scanning]. The display returns to that of step **g**.

6 Press [Exit].

Note


☐ To store a message in another Information Box, return to step ☐.

7 Press [Exit].

Printing Information Box Messages

Follow these steps to print a message stored in an Information Box.

1 Press [Information].



- Press [Store/Delete/Print Information Box File.].
- Press [Print File].
- 4 Select the box that contains the stored file you want to print.



- Note
- ☐ You cannot select a box that has no stored file.

When a password is required

• Enter the password, and then press [OK].




- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step 4.
- **5** Press the **(Start)** key.

 - ☐ If you want two-sided printing, press [Print 2 Sides] before pressing the [Start] key.
 - ☐ To stop printing before pressing the **[Start]** key, press **[Cancel]**. The display returns to that of step **4**.
 - ☐ To stop printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **[**].
- 6 Press [Exit].
 - Note
 - ☐ Repeat from step **4** to print another stored file in the box.
- Press [Exit].

Follow these steps to delete a file stored in an Information Box.

1 Press [Information].



- Press [Store/Delete/Print Information Box File.].
- Press [Delete File].
- 4 Select the box that contains the stored file you want to delete.



When a password is required

• Enter the password, and then press [OK].



- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step ♣.
- Press [Delete].

 - ☐ To stop deleting, press [Do not Delete]. The display returns to that of step 4.
- 6 Press [Exit].
 - **𝒜** Note
 - ☐ Repeat from step 4 to delete another stored file in another box.
- **7** Press [Exit].

The standby display appears.

2

4. Other Transmission Features

Handy Dialing Functions

Chain Dial

This allows you to compose a telephone number from various parts, some of which may be stored in Quick Dials and some of which may be entered using the number keys.

Note

- ☐ Maximum length of a telephone or fax number: 128 digits
- For Memory Transmission and Immediate Transmission, insert a pause between parts of a number. For On Hook Dial and Manual Dial, no pause is needed.
- ☐ You cannot use this function with Internet Fax transmission.
- ☐ The Advanced Features function programmed in the destination list is unavailable.

(Example) 01133-1-555333

Assume that 01133 is stored in a Quick Dial key.

- 1 Place the original, and then select the scan settings you require.
- Press the Quick Dial key that is programmed "01133".
- 3 Press the [Pause/Redial] key.
- 4 Enter (1), (5), (5), (5), (3), (3), (3), (3) using the number keys.
- Press the [Start] key.

Redial

The machine stores the last 10 destinations specified. If you want to send a message to a destination which you sent faxes to recently, the Redial function saves you time by finding and entering the destination again.

Limitation

- ☐ The following kinds of destinations are not stored:
 - · Quick Dials
 - Group Dials
 - Destinations dialed as Receiving Stations for Transfer Request
 - Forwarding terminal of the Substitute Reception
 - Destinations dialed using the external telephone
 - Destinations dialed by Redial (regarded as already stored in memory)
 - Second and later destinations broadcasted to
- ☐ To redial a fax number, do not dial any numbers before you press the **[Pause/Redial]** key. If you press the **[Pause/Redial]** key after entering numbers using the number keys, a pause will be entered instead.


Note

Redial can be used to specify Internet Fax recipients. To redial e-mail address, do not enter any characters before you press [Manual Input].





Select the destination you want to redial to.



Ø Note

- ☐ Now that the date and time the original was read appears as a key, select by pressing it.
- ☐ When you press [ProgDest], you can register a selected recipient in the destination list.

4

Advanced Features

SUB Code

Normally you can only use Confidential Transmission to send messages to fax machines of the same manufacturer that have the Confidential Reception function. See p.8 "Confidential Transmission". However, if the other machine supports a similar function called "SUB Code", you can send fax messages to the other party using this method instead.

Note

- \square The ID can be up to 20 digits long.
- ☐ You can enter numbers, *, #, and spaces to program an ID.
- ☐ Make sure the number of digits in the ID matches the specification of the machine to which you are sending.
- ☐ You can store IDs in destination lists and Programs. See "Registering a Fax Destination", General Settings Guide. See p.127 "Registering and Changing Keystroke Programs".
- Messages you send using this function are marked "SUB" on all reports.
- ☐ This function is not available with Internet Fax.
- Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

- 2 Dial the fax number using the number keys.
- Press [Adv. Features].



- 4 Press [SUB Code].
- Press [TX SUB Code].
- **6** Enter a SUB Code, and then press [OK].



"SUB Code" appears one line above **[Adv. Features]** on the display.

Note

- ☐ If you make a mistake, press [Cancel] or the [Clear/Stop] key before pressing [OK], and then try again.
- To enter a password, press [Password (SID)].
- 8 Enter the password with the number keys, and then press [OK].
- 9 Press [Exit].

11 Press the [Start] key.

Note

☐ If you use Immediate Transmission and the fax machine at the destination does not support the SUB Code function, a message will appear on the display to inform you of this. When this happens, press [OK] to cancel the transmission.

SID Code

There are times when you may want to use an "SID" (Sender ID) when sending confidential faxes with the SUB Code function.

Note

- \Box The ID can be up to 20 digits long.
- ☐ You can enter numbers, *, #, and spaces to program an ID.
- ☐ You can store IDs in destination lists and Programs. See p.127 "Registering and Changing Keystroke Programs". See "Registering a Fax Destination", General Settings Guide.
- Messages you send using this function are marked "SID" on all reports.

SEP Code

Normally you can only use Polling Reception to receive faxes from machines that have the Polling Reception function and the same manufacturer. However, if a machine of another manufacturer supports Polling Reception, you can receive fax messages from the other party using this method instead.


You can receive messages that have the same SEP Code as the SEP Code you entered.

Note

- \Box The ID can be up to 20 digits long.
- Make sure the number of digits in the ID matches the one set on the machine to which you are sending.
- ☐ You can enter numbers, *, #, and spaces to program an ID.
- ☐ You can store IDs in destination lists and Programs. See "Registering a Fax Destination", *General Settings Guide*. See p.127 "Registering and Changing Keystroke Programs".
- Messages you receive using this function are marked "SEP" on all reports.
- ☐ This function is not available with Internet Fax.
- 1 Dial the fax number using the number keys.
- Press [Adv. Features].




- Press [SEP Code].
- 4 Press [RX SEP Code].
- Enter a SEP Code, and then press [OK].



"SEP Code" appears one line above [Adv. Features] on the display.

Note

- ☐ If you make a mistake, press [Cancel] or the [Clear/Stop] key before pressing [OK], and then try again.
- To enter a password, press [Password (PWD)].
- 2 Enter the password using the number keys, and then press [OK].
- 8 Press [Exit].
- 9 Press [Transmission Mode].



10 Press [Polling RX].

Press [Default ID/Free Polling RX], and then press [OK].



[Polling RX] is highlighted, and "Deflt ID/Free Poll." is shown.

- ☐ To cancel Polling RX, press [Cancel]. The display returns to that of step ①.
- Press [OK].

The standby display appears.

Press the [Start] key.

PWD Code

There are times you may want to use a password when receiving faxes by polling using the SEP Code function.


- Ø Note
- ☐ The password can be up to 20 digits long.
- ☐ You can enter numbers, *, #, and spaces as a password.
- ☐ You can store IDs in destination lists and Programs. See "Registering a Fax Destination", General Settings Guide. See p.127 "Registering and Changing Keystroke Programs".
- Messages you send using this function are marked "PWD" on all reports.

Transfer Request

Transfer Request allows fax machines that have this function to automatically transfer incoming messages to multiple fax destinations. This function helps you save costs when you send the same message to more than one place in a distant area, and saves time since many messages can be sent in a single operation.

Transfer Requests can be sent by fax or e-mail.

The diagram below may make the concept clearer.



The following terminologies are used in this section:

Requesting Party

The machine where the message originates.

Transfer Station

The machine that forwards the incoming message to another destination.

Receiving Station

The facsimile or computer that received the message from the Transfer Station.

Preparation

Before you can use this function, you must make the following preparations:

- Program each Transfer Station number in this machine (Requesting Party) and in the Transfer Station itself. See p.183 "Transfer Report".
- Program the same Polling ID in both this machine (Requesting Party) and the Transfer Station. See p.185 "Programming a Polling ID".
- To send a Transfer Request by fax, the Transfer Station must be a fax machine of the same manufacturer and have the Transfer Station function.
- To send a Transfer Request by email, Transfer Station must be a fax machine of the same manufacturer that supports Internet Fax.
- You cannot use Transfer Request without programming the fax number of the Requesting Party in a Quick Dial or Speed Dial.
- The Receiving Station's fax number must be programmed in the Transfer Station's Quick Dial, Speed Dial or Group Dial.

Note

- ☐ You can specify up to 500 Transfer Stations in a Transfer Request.
- ☐ You can have up to 30 End Receivers per Transfer Station. If you specify a Transfer Station's Group, the Group counts as a single receiver.
- ☐ You can specify up to 100 Receiving Stations and Transfer Stations in total.

- ☐ When a Transfer Request is sent by e-mail, as soon as the Transfer Station completes transfer to all Receiving Stations, it sends back a Transfer Result Report by e-mail. See p.91 "Transfer Result Report (transfer request by e-mail)".
- □ When a Transfer Request is sent by e-mail to a computer or facsimile without the Transfer Request function, that machine receives it as ordinary e-mail. It does not transfer the message nor send an error report back to the Requesting Party. To send Transfer Request by email, use a Transfer Station that supports Internet Fax and has the Transfer Station function.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **B** and **G**. See p.145 "Quick Operation Key".
- Place the original, and then select any scan settings you require.

Ø Note

- When sending a Transfer Request by e-mail, sent text size is [Detail], even if [Super Fine] is selected.
- ☐ Transfer Requests by e-mail are sent at A4 width. Wider originals are reduced to A4 width.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Specify a Transfer Station.

Note

- ☐ Specify whether to enter the Transfer Station's fax number or e-mail address directly, or to use the destination list.
- ☐ If you make a mistake, press the **[Clear/Stop]** key, and then try again.
- □ When a Transfer Request is sent by e-mail, e-mail options can be set. See steps ② and ③ on p.52 "Sending Internet Fax Documents", Facsimile Reference <Basic Features>.

p.35 "Entering a Fax Number", Facsimile Reference < Basic Features>

p.37 "Entering an E-mail Address", Facsimile Reference < Basic Features>

p.38 "Using Destination Lists", Facsimile Reference <Basic Features>

Press [Adv. Features].



- 4 Select [Transfer Req.].
- Press [Receiving Station].

6 Specify a Receiving Station.



- Note
- ☐ You cannot enter Receiving Station numbers directly. The numbers must be stored in destination lists, Speed Dial, or Groups in the Transfer Station(s). To specify a Receiving Station, use the procedure described below.
- ☐ To cancel the Transfer Request, press [Cancel]. The display returns to that of step **5**.

Destination List

- Select [# Quick Dial].
- 2 Enter the registration number of the destination list where the Receiving Station is stored.

For example, to select the registration number stored in Quick Dial 01 of the Transfer Station, enter: [0][1].

- Note
- \square You can enter up to five digits.

Speed Dial

- Select [#X Speed Dial].
- **2** Enter the number of the Speed Dial code.

For example, to select the number stored in Speed Dial 12 of the Transfer Station, enter: [1][2].

Group Dial

- Select [#XX Group Dial].
- 2 Enter the number of the Group number.

For example, to select the number stored in Group Dial 04 of the Transfer Station, enter: [0][4].

- **7** To specify another Receiving Station, press [Add].
 - Note
 - □ Press [▲ Prev.] or [▼ Next] to see the Receiving Stations already entered. You can select a Receiving Station from this list and remove it by pressing [Clear] or the [Clear/Stop] key.
- 8 When you have specified all the Receiving Stations, press [OK].
- 9 Press [Exit].



The Transfer Stations and Receiving Stations are displayed.

Press the [Start] key.


With transfer requests set in the system settings

You can program a Quick Dial key with Transfer Station and/or Receiving Station using the Transfer Request function in the System Settings. See "Registering the Transfer Request", General Settings Guide.

Place the original down, and then select the desired settings.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Press the key programmed with Transfer Request.



3 Press the [Start] key.

Setting Multistep Transfer

Program a Transfer Station in a destination list. When receiving a Transfer Request that specifies the same Receiving Station as programmed in the destination list, this machine sends a Transfer Request to the programmed Transfer Station. This function allows fax messages to be transferred via multiple stations and makes fax message transfer more efficient.

You can program up to 30 Receiving Stations per Transfer Station. For more information, contact your service representative.

On Hook Dial

The On Hook Dial function allows you to dial while hearing tone from the internal speaker. You can send a fax checking the connection.

Limitation

☐ This function is unavailable for the optional extra G3 interface unit.

Note

- ☐ This function is unavailable in some countries.
- ☐ If a Transmission Result Report (Immediate Transmission) is printed, On Hook Dial transmission results are not mentioned on the report.
- 1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Press the [On Hook Dial] key.




You will hear a low tone from the internal speaker.

Note

☐ If you want to cancel this operation, press the **[On Hook Dial]** key again.

3 Dial.



The machine immediately dials the destination.

- □ You can adjust the volume of the On-hook sound by pressing [Higher] or [Lower] in the upper right-hand corner of the display. The volume can also be preprogrammed in "General Settings and Adjustments". See p.73 "Adjusting the Volume", Facsimile Reference < Basic Features> and p.144 "General Settings/Adjustment".
- ☐ If you make a mistake, press the **[On Hook Dial]** or **[Clear Modes]** key, and then return to step **2**.
- When the line is connected and you hear a high-pitched tone, press the [Start] key.

The transmission starts.

Note

- ☐ After transmission, the machine returns to standby mode.
- ☐ If you want to cancel a transmission, press the 【Clear/Stop】 key, and then remove the originals.



If you have an external telephone on the fax machine, you can speak with the other party when you hear a voice. If you hear a voice before pressing the **[Start]** key, pick up the external telephone and tell the receiver you want to send a fax message (ask them to switch to facsimile mode).

Manual Dial

The external telephone is required.

Pick up the handset of the external telephone and dial. When the line is connected and you hear a high-pitched tone, press the **[Start]** key to send your fax message. If, on the other hand, you hear a voice at the other end, continue conversation as normal.

Limitation

- ☐ This function is unavailable for the optional extra G3 interface unit.
- ☐ If Transmission Result Report (Immediate Transmission) is printed, the result of a transmission with Manual Dial is not mentioned in the report.
- Place the original, and then select the scan settings you require.


₽ Reference

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

2 Pick up the external telephone.

You will hear a tone.

3 Dial.



The machine immediately dials the destination.

- Note
- ☐ If you make a mistake, replace the external telephone, and then try again from step ②.
- When the line is connected and you hear a high-pitched tone, press the [Start] key to send your fax message.

The transmission starts.

- ☐ If you hear a voice, tell the receiver that you want to send them a fax message (ask them to switch to facsimile mode).
- **5** Replace the handset of the external telephone.

After transmission, the standby display appears.

- **∅** Note
- ☐ If you want to cancel a transmission, press the 【Clear/Stop】 key, and then remove the originals.

Changing the Line Port

The optional extra G3 interface unit is required.


When the extra G3 interface unit is installed, you can connect to a maximum of two ports.

Note

- ☐ When you install the extra G3 interface unit, you can specify the line port home position from "General Settings and Adjustment". See p.144 "General Settings/Adjustment".
- ☐ When sending a fax, you can select the line port if dialing with the number keys or Chain Dial.

◆ G3

G3 is selected after power up or when the machine is reset. If you install the extra G3 interface unit, you can select "G3-1", "G3-2", or "G3 Auto" depending on the number of the installed unit.



Multi-port

When the extra G3 interface unit is installed, communications can take place simultaneously through two lines at once.


The following list shows protocol combinations available for each line type.

| Option | Available line types | Available protocol combinations |
|-------------------------------|----------------------|---------------------------------|
| Without option | PSTN | G3 |
| Extra G3 interface unit | PSTN+ PSTN | G3+G3 |


∅ Note

- A maximum of two communications can take place simultaneously.
- You cannot perform two Immediate Transmissions simultaneously.
- If two communications are in progress, the display shows the first communication that was initiated.

1 Press [Select Line].



When one optional extra G3 unit is installed.



Note

- ☐ If you select "G3 Auto", the machine will use any available line. This increases efficiency.
- 3 Press [Exit].


The standby display appears.

4

Sub Transmission Mode

Book Fax

Use to send book originals from the exposure glass. Pages are scanned in the order shown below.



Limitation

- Place the original on the exposure glass. You cannot use the optional ADF.
- Depending on paper sizes available in the destination machine, the message may be reduced when printed at the other end.


Note

- ☐ You can have bound originals scanned as left or right page first. You can set which page (left or right) the machine scans first as default with the User Parameters. See p.161 "User Parameters" (switch 06, bit 6).
- □ When using the Internet Fax function, documents transmitted are sent at A4 width. Documents larger than A4 are reduced to A4 width. See p.13 "Placing Originals", Facsimile Reference < Basic Features>.


Place the original on the exposure glass, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

Press [Sub TX Mode].




- Press [Book Fax].
- 4 Select the size of the original.



- Note
- ☐ To cancel this mode, press [Cancel]. The display returns to that of step [3].
- ☐ If you select A3, the original will be sent using Image Rotation Transmission. See p.80 "Transmission with Image Rotation".

Select [From first Page] or [From second Page], and then press [OK].



The selected original size is shown above the highlighted [Book Fax].

Note

- ☐ Select **[From first Page]** to send a book original from the first page.
- ☐ Select [From second Page] if you want to send a cover letter as the first page.
- ☐ To cancel this mode, press [Cancel]. The display returns to that of step [].
- 6 Press [OK].
- Specify a destination, and then press the [Start] key.

- ☐ When sending more than one page, place the originals individually, one after the other, pressing the [Start] key after each page.
- ☐ After the last original has been scanned, press [④].
- ☐ If [④] is not pressed, the machine will automatically start sending the documents, 60 seconds after the last original has been scanned.


Two-Sided Transmission (Double-Sided Transmission)

The optional ADF is required.


Use this function to send two-sided originals.

Note

- ☐ Originals placed on the exposure glass cannot be sent.
- ☐ The front and back of the scanned original will be printed in order on separate sheets at the other end. The orientation of alternate sheets may be reversed at the other end. If you want to print the original with the same orientation at the other end, specify the "Original Position" and "Page Opening Orientation".




GHPY02



See p.80 "Transmission with Image Rotation"


- ☐ This function is only available with Memory Transmission.
- ☐ This function is only available with the ADF.
- ☐ You can confirm whether both sides were properly scanned using the Stamp function. See p.73 "Stamp".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".
- 1 Place the original in the ADF, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features> Press [Sub TX Mode].




- Press [2 Sided Original].
- 4 Specify the original position.


Check the orientation of the placed document, and then press to or the orientation of the placed document, and then press to or the orientation of the placed document, and the placed document document document.



- Make sure that the specified original position matches the orientation of originals loaded in the ADF.
- **5** Specify the page opening orientation from [Top to Top] or [Top to Bottom].



Specify the transmission mode from [2 Sided from 1st Page] or [1 Sided for 1st Page], and then press [OK].



The selected original position and page opening orientation are shown above the highlighted [2 Sided Original].

Note

- ☐ To cancel this mode, press [Cancel]. The display returns to that of step [3].
- ☐ Select [2 Sided from 1st Page] to send a two-sided original from the first page.
- ☐ Select [1 Sided for 1st Page] if you want to send a cover letter as the first page.
- **7** Press [OK].
- Specify the destination, and then press the [Start] key.

Standard Message Stamp

Use this function to stamp a standard message at the top of the first original sent.

There are four types of standard messages: "Confidential", "Urgent", "Please phone", and "Copy to corres. section"


You can also program other messages.

Note


- ☐ While this function is in use, the third line of the Label Insertion is not printed. See p.76 "Programming the Label Insertion".
- When there is an image around the area where the standard message is to be stamped, that image is deleted.
- ☐ To program a standard message, use the Program/Change/Delete Standard Message function. See p.151 "Programming, Changing, and Deleting Standard Messages".
- 1 Place the originals, and the select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

Press [Sub TX Mode].



- Press [Std. Message].
- 4 Select the standard message to be stamped, and then press [OK].



The selected standard message is shown above the highlighted [Std. Message].

𝒯 Note

- ☐ To cancel the selection, press [Cancel]. The display returns to that of step [3].
- ☐ Programmed standard messages are shown in the keys.
- ☐ The machine cannot stamp multiple standard messages.
- Press [OK].
- Specify the destination, and then press the [Start] key.

Sending an Auto Document

If you often send a particular page to people (for example a map, a standard attachment, or a set of instructions), store that page in memory as an Auto Document. This saves rescanning every time you want to send it.

You can fax an Auto Document by itself, or attach it to a normal fax message.

Preparation

You need to register an Auto Document. See p.152 "Storing, Changing, and Deleting an Auto Document".


- Note
- ☐ You can attach one Auto Document to each transmission.
- ☐ You can store up to 6 Auto Documents (up to 18 with the optional expansion memory installed). See p.152 "Storing, Changing, and Deleting an Auto Document".
- ☐ Files with Auto Documents are sent by Memory Transmission.
- When sending an Auto Document with other files, the Auto Document is sent first.
- ☐ Storing Auto Documents reduces the amount of free memory slightly. Unless you delete the document, free memory will not return to 100%.
- ☐ You can print an Auto Document currently stored in memory. See p.66 "Printing documents stored as Auto Documents".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ③. See p.145 "Quick Operation Key".

1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>


Note

- ☐ When you fax an Auto Document, start from step ②.
- 2 Press [Sub TX Mode].



- Press [Auto Document].
- 4 Select an Auto Document file, and then press [OK].

When you fax an Auto Document by itself, press [TX Stored File(AD) Only], and then press [OK].



The selected file name is shown above the highlighted [Auto Document].


Note

- ☐ Programmed Auto Documents are shown in the keys.
- ☐ To cancel the Auto Document, press [Cancel]. The display returns to that of step ■.
- **5** Press [OK].
- **6** Specify the destination, and then press the [Start] key.


Printing documents stored as Auto Documents

This function is used for printing documents stored as Auto Documents. This function is very convenient as it can be used for checking the contents of stored files.

1 Press [Sub TX Mode].



- 2 Press [Auto Document].
- Select an Auto Document file to be printed, and then press [Print File].



Note

☐ To cancel the Auto Document, press [Cancel]. The display returns to that of step ②.

4 Press the [Start] key.

Once printing is completed, the display returns to that of step **§**.

Note

- ☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **§**.
- 5 Press [Cancel].

𝒯 Note

☐ You can also send Auto Documents. See p.65 "Sending an Auto Document".


6 Press [OK].

The standby display appears.

Sending a Stored File

Use this function to send documents stored in the Document Server. You can specify and send multiple documents, and also send them with scanned originals all at once.

You can also print stored originals with **[Print File]**. See p.70 "Printing stored documents".



Preparation

Store the documents to be sent in advance. You can program a password for this function. You can change the user names, file names, and passwords of stored documents. See p.131 "Using the Document Server", and p.134 "Changing Information of Stored Documents".

- ☐ Received fax documents are stored and categorized as stored reception files. See p.34 "Printing/Deleting Received and Stored Documents (Print Stored RX File)".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**. See p.145 "Quick Operation Key".

Sending stored documents

The machine sends documents stored in the Document Server.


The documents stored in the Document Server can be sent again and again until they are deleted. Once sent, documents are stored in the Document Server. Therefore, you can send them in just one operation without having to set your originals again.

Limitation


- ☐ You cannot use the following transmission methods:
 - Free Polling Transmission
 - Default ID Transmission
 - ID Override Transmission
 - Immediate Transmission
 - Parallel Memory Transmission
 - On Hook Dial
 - Manual Dial

Ø Note

- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at once.
- ☐ The machine can send a total of 1,000 pages in one operation.
- ☐ The specified documents are sent with the scan settings made when they were stored.
- 1 Press [Sub TX Mode].



- 2 Press [Select Stored File].
- **3** Select the documents to be sent.



Note

- When multiple documents are selected, they are sent in the order of selection.
- Press [TX Order] to arrange the order of the documents to be sent.
- Press [File Name] to place the documents in alphabetical order.
- Press [User Name] to place the documents in order by programmed user name.
- Press [Date] to place the documents in order of programmed date.

Specifying documents from the file list


- Press [▲ Prev.] or [▼ Next] to display the documents to be sent.
- 2 Select the file name.

Specifying documents from the User Name

Select [Search by User Name].



2 Select the user name of the programmed document, and then press [OK].



- Note
- □ To search by user name, press [Non-programmed Name], and then enter the user name. Partial matching is used when searching for a user name. See p.165 "Special Senders to Treat Differently".
- 3 Select the file name to be sent.

Specifying documents from the file name

1 Select [Search by File Name].



2 Enter the name of the document to be sent, and then press [OK].



- Note
- ☐ Partial matching is used when searching for a file name. See p.165 "Special Senders to Treat Differently"
- 3 Select the file name to be sent.
- 4 If you select a document with a password, enter the password, and then press [OK].



If the document does not have a password, proceed to step **5**.

When you want to add your originals to stored documents and send them all at once, press [Origi. + Stored File] or [Stored file + Origi.].




When sending only stored documents, proceed to step **6**.

- □ When [Origi. + Stored File] is pressed, the machine sends the originals and then stored files. When [Stored file + Origi.] is pressed, the machine sends the stored files and then originals.
- ☐ The added originals are not stored.
- 6 Press [OK] twice.
 - Note
 - ☐ To add an original to stored documents, place the original, and then select any scan settings you require.
- Specify the destination, and then press the [Start] key.


Printing stored documents

Use this function to print documents stored in the Document Server.

- Note
- ☐ Only documents stored using the facsimile function can be printed.
- ☐ You can print documents saved from the copy or the printer function with the Document Server. You cannot print documents saved from the scanner function with this mode.
- You can also print the first page only to check the content of the original.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at one time.
- Press [Sub TX Mode].



- 2 Press [Select Stored File].
- **3** Select the document to be printed.



Note

- The documents stored using the facsimile function appear on the display.
- Press [File Name] to place the documents in alphabetical order.
- Press [User Name] to place documents in order of programmed user name.
- Press [Date] to place the documents in order by the programmed date.
- ☐ To see details of the selected document, press [Detail]. To return to the standby menu, press [Select File].



Selecting a document from file list

Select the file name.




□ Press [▲ Prev.] or [▼ Next] to display the document to be sent. Specifying a document from the User Name

Select [Search by User Name].



Press the user name of the document to be sent, and then press [OK].



- Note
- ☐ To search by user name, press [Non-programmed Name], and then enter the user name. User name searches using partial matching.
- Reference

"Entering Text", General Settings Guide

3 Select the file name.

Specifying a document from the file name

1 Press [Search by File Name].



2 Enter the file name to be printed, and then press [OK].




Note

☐ Partial matching is used to search for the file name.

₽ Reference

"Entering Text", General Settings Guide

- 3 Select the file name.
- If you select a document with a password, enter the password, and then press [OK].



If the document does not have a password, proceed to step **5**.

Press [Print File] or [Print 1st Page].

When [Print File] is pressed, the machine prints all the pages. When [Print 1st Page] is pressed, the machine prints only the first page.

Limitation

- When [Print 1st Page] is selected, originals larger than A4 size are printed after they are reduced to A4 size.
- ☐ The machine can print up to 30 files using the Print 1st Page function.

- ☐ To print both sides, press [Print 2 Sides].
- ☐ To cancel printing, press [Cancel].

6 Press the [Start] key.

Note

- ☐ When only the first page is printed, the file name is printed at the top of the paper.
- □ To cancel printing after pressing the [Start] key, press [Stop Printing].


Press [OK] twice.

The standby display appears.

Stamp

The optional ADF is required.

When sending a fax message using the ADF, the machine can stamp a circle mark at the bottom of the original. When sending a two-sided document, the document is marked at the bottom of the front page and top of the rear page. This stamp indicates that the original has been successfully stored in memory for Memory Transmission, or successfully sent by Immediate Transmission.




- ☐ Stamp only works when scanning from the ADF.
- ☐ When the stamp starts getting lighter, replace the cartridge. See p.193 "Replacing the Stamp Cartridge".
- ☐ If a page was not stamped even though the Stamp function is turned on, you need to resend that page.
- ☐ If you use this function often, you can set the default in General Settings and Adjustment so that this function is always on. In this case, Stamp can easily be turned off for any single transmission by pressing [Stamp]. See p.144 "General Settings/Adjustment".

- A paper jam during Parallel Memory Transmission may cause the transmission to be failed even if stamping is performed.
- ☐ You cannot turn the Stamp function on or off while a document is being scanned.
- 1 Place the original, and then select the scan settings you require.

p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

Press [Sub TX Mode].



- Press [Stamp], and then press [OK].
 - Note
 - ☐ To cancel the stamp, press [Stamp] again before pressing [OK].
- 4 Specify the destination, and then press the [Start] key.

Transmission Options

This section describes various functions that you can switch on and off for any particular transmission, following the procedures given here.

In addition, if you frequently use a certain option configuration, you can change the default home position (on or off) of each option.

Fax Header Print

In some cases, you may want the other party to receive an unmarked copy of your original. To do this, switch Fax Header off.

When the Fax Header is set to "ON", the stored name is printed on the receiver's paper.

You can store two Fax Headers; "First Name" and "Second Name".

For example, if you store your department name in one and your organization name in the other, you could use the first when sending internal faxes and the second for external faxes.

Note

- ☐ If you used the number keys to specify the receiver, the first header name will be printed on the receiver's paper.
- ☐ You can program fax header names using the Program Fax Information function.
- ☐ You can select whether or not dates, fax header names, file numbers, or page numbers are printed by changing their respective User Parameters. (switch 18, bit 3, 2, 1, 0) See p.161 "User Parameters".
- You can program one of the Quick Operation keys with operations for this function.

Label Insertion

With this function you can have the receiver name printed on the message when it is received at the other end. The name will be printed at the top of the page and will be preceded by "To". You can also cause the text programmed as a standard message to be printed. See p.151 "Programming, Changing, and Deleting Standard Messages".

Note

- When there is an image around the area where the Label is to be printed, that image is deleted.
- You can program one of the Quick Operation keys with operations for this function.

Sender Stamp


When there is data, such as the user name and department name, programmed into the user code, you can have the machine print a sender stamp on the right edge of your paper.

Note

☐ Enter the user name in System Settings. See "Registering a New User Code", General Settings Guide.

Reduced Image Transmission


Using this function, your message is sent at a reduced size (93%) with a blank margin on the left.



- This function is unavailable with Immediate Transmission, or specified transmission of a stored document.
- ☐ Image Rotation is unavailable with this function.


Auto Reduce

When this function is turned on, if the receiver's paper is smaller than the paper you are sending on, the message is automatically reduced to fit onto the paper available at the other end.



Important

☐ If you turn this function off, the scale of the original is maintained and some parts of the image may be deleted when printed at the other end.



Default ID Transmission

If you turn this function on, transmission will only take place if the destination's Polling ID is the same as yours. This function can stop you accidentally sending information to the wrong place (you need to coordinate Polling ID's with the other party).

Note

You can program one of the Quick Operation keys with operations for this function.


Selecting transmission options for a single transmission

1 Place the original, and then select the scan settings you require.


₽ Reference


p.13 "Placing Originals", Facsimile Reference <Basic Features> p.30 "Scan Settings", Facsimile Reference <Basic Features>

Press [Sub TX Mode].



- 3 Select [Options].
- 4 Select options to be set up.





Note

☐ To close the option settings, proceed to step **⑤**.

Programming the Fax Header Print

1 Press [ON] for Fax Header Print.

Ø Note

☐ Press [OFF] if you do not want to print the sender name.

Programming the Label Insertion


1 Press [Programed Name] for Label Insertion.

Note

☐ Press **[OFF]** if you do not want to insert a destination.

Programming the Stamp Sender Name

- Press [Change] for Stamp Sender Name.
- 2 Press the name of the user to be stamped, and then press [OK].



𝒜 Note

- ☐ The set user name is displayed when the user code has been stored. See "Registering a New User Code", General Settings Guide.
- ☐ You can switch titles by pressing the title keys.
- ☐ To stamp a non-programmed user name, press [Non-programmed Name], and then enter the user name.
- ☐ If you do not want to stamp the sender's stamp, press [*Do not Stamp].

Programming the Reduced Image Transmission

- Press [ON] in for Reduced Image TX.

 - ☐ Press **[0FF]** if you do not want to do a reduced transmission.

Programming the Auto Reduce

- Press [ON] for Auto Reduce.
 - **𝚱** Note
 - ☐ Press [OFF] if you do not want to use the Auto Reduce function.

Programming the Default ID Transmission

- Press [ON] for Default ID TX.
 - **𝒯** Note
 - ☐ Press **[OFF]** if you do not want to use ID transmission.
- **5** Press [OK] twice.
- 6 Specify the destination, and then press the [Start] key.

More Transmission Functions

If Memory Runs Out While Storing an Original

If you run out of memory while storing an original (free space reaches 0%), the message "Memory is full. Cannot scan more. Transmitting only scanned pages." is displayed. Press [Exit] to transmit stored pages only.

Note

In default, scanned pages are sent. To change the settings to delete scanned pages, contact your service representative.

Parallel Memory Transmission

This function dials while the original is being scanned. Standard Memory Transmission stores the original in memory, then dials the destination. Parallel Memory Transmission allows you to quickly determine whether a connection was made. In addition, this function scans the original faster than Immediate Transmission. This is useful when you are in a hurry and need to use the original for another purpose.

Limitation

- ☐ Standard Memory Transmission is used instead of Parallel Memory Transmission in the following cases:
 - When the line is busy and could not be connected to
 - With Send Later

- When you store an original for Memory Transmission while another communication is in progress
- When two or more destinations are specified
- When you send only an Auto Document
- When the first page of an original is placed on the exposure glass
- When you send messages stored in the Document Server

Note

- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 07, bit 2).
- ☐ Standard Memory Transmission may be used instead of Parallel Memory Transmission depending on the optional equipment installed if there is not enough free memory left.
- If you use this function, the Memory Storage Report will not be printed.
- ☐ If the **[Clear/Stop]** key is pressed, an original will jam or memory will run out during Parallel Memory Transmission stops. The Transmission Result Report is printed and files are deleted.
- ☐ When Parallel Memory Transmission is used, the total number of originals in "Fax Header Print" is not automatically printed.

Checking the Transmission Result

- Turn the Transmission Result Report on if you want a report to be printed after every successful transmission. See p.83 "Transmission Result Report (Memory Transmission)".
- If you leave the Transmission Result Report off, the report will not be printed after every transmission. However, if a transmission fails, a Communication Failure Report will be printed instead. See p.83 "Transmission Result Report (Memory Transmission)" and p.84 "Communication Failure Report".
- You can also check the transmission result by examining the Journal. See p.27 "Printing the Journal".
- You can either print or scroll through the Journal on the display.
 See p.31 "Checking the Transmission Result (TX File Status)".

Automatic Redial

If a fax message could not be transmitted because the line was busy or an error occurred during transmission, redialing is done five times in five minutes intervals (these figures vary according to which country you are in).

If redialing fails after four redials, the machine cancels the transmission and prints a Transmission Result Report or Communication Failure Report. See p.84 "Communication Failure Report". and p.83 "Transmission Result Report (Memory Transmission)".

Batch Transmission

If you send a fax message by Memory Transmission and there is another fax message waiting in memory to be sent to the same destination, that message is sent along with your original. Several fax messages can be sent with a single call, thus eliminating the need for several separate calls. This helps save communication costs and reduce transmission time.

Fax messages for which the transmission time has been set in advance are sent by batch transmission when that time is reached.

- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 14, bit 2).
- ☐ The originals to be transmitted at a specific time will be sent at that time.
- If fax memory is overloaded, messages may not be sent in the order they were scanned.

Dual Access

The machine can scan other messages into memory even while sending a fax message from memory, receiving a message into memory, or automatically printing a report. Since the machine starts sending the second message immediately after the current transmission ends, the line is used efficiently.

∅ Note

☐ Note that during Immediate Transmission or when in User Tools mode, the machine cannot scan an original.

Transmission with Image Rotation

Generally, place A4, $8^1/2"\times11"$ originals in the landscape orientation (\square). If you place an A4, $8^1/2"\times11"$ original in the portrait orientation (\square), the image will be sent rotated by 90°. Providing the receiver has A4, $8^1/2"\times11"$ landscape paper (\square), the message will be printed the same size as the original.

Note

- ☐ This function is unavailable with Immediate Transmission.
- When Image Rotation is used, all messages are sent by normal Memory Transmission.
- ☐ This function is unavailable when using Mixed Original Sizes.


Simultaneous Broadcast

The optional extra G3 interface unit is required.

The Standard Broadcast function sends faxes one at a time to multiple destinations in the order of specified destinations.

The Simultaneous Broadcast function, however, can simultaneously send faxes to multiple destinations using different lines.

This results in a shorter overall transmission time.



- ☐ This function can use a maximum of two lines simultaneously.
- □ When using the optional extra G3 interface unit, if you set the line selection as "G3 Auto" beforehand, the machine will use whichever G3 line is not busy. This increases efficiency.

JBIG Transmission

The optional fax function upgrade unit is required.

If you use JBIG (Joint Bi-level Image Experts Group) compression, you can send photographic originals faster than with other methods of compression. You can only use this function with G3 line type.

p.31 "Original Type", Facsimile Reference < Basic Features>

Limitation

- ☐ This function requires that the other party's fax machine has both the JBIG function and ECM function (G3 communication only).
- ☐ Unavailable when using Internet Fax.

Note

- ☐ When the optional extra G3 interface unit is installed, JBIG receptions of G3-2 line is standard.
- ☐ If ECM is turned off, JBIG Transmission is unavailable. See p.160 "ECM (Error Correction Mode)".

Transmitting Journal by E-mail

Preparation

To transmit the Journal by e-mail, it is necessary to make settings with User Parameters. See p.161 "User Parameters" (switch 21, bit 4).

The Journal is automatically transmitted to an e-mail address of the administrator by every 50 communications. A CSV format Journal is attached to the e-mail. See "Settings You Can Change with User Tools - File Transfer", Network Guide.

#Important

☐ This machine does not store sent CSV files. It is recommended that you double-check the e-mail address of an administrator before the Journal is transmitted. If the e-mail address of the administrator is not correct, your important Journal may be lost and sent CSV file is not left on the fax machine.

- ☐ If the administrator address is wrong, you may not be able to acquire Journal.
- If the Journal in e-mail format fails to be transmitted, the Journal is printed out.
- ☐ The name of an attached CSV file is "JOURNAL+year, month, hours, minutes". For example, the file name transmitted in 10:40:12 on 1st, December, 2003 is "JOURNAL20031201104012.csv".
- ☐ The subject of Journal by e-mail begins with "Journal".

Journal by E-mail

If the setting is made so that the Journal is transmitted as e-mail, it is transmitted to the e-mail address of an administrator.

This section describes the CSV format of the Journal attached with e-mail.

𝒯 Note

- ☐ To transmit the Journal, it is necessary to make settings with User Parameters. See p.161 "User Parameters" (switch 21, bit 4).
- ☐ To set the administrator e-mail address, see "Settings You Can Change with User Tools File Transfer", Network Guide.

Printed Report

Memory Storage Report

This report is printed after an original is stored in memory. It helps you review the contents and the destinations of stored originals.

Limitation

☐ If you use Parallel Memory Transmission, the Memory Storage Report is not printed.

Ø Note

- ☐ You can turn this report on and off. See p.161 "User Parameters" (switch 03, bit 2).
- Even if the machine is set up not to print this report, it is still printed if an original could not be stored.
- ☐ You can select whether to include part of the original image on the report. See p.161 "User Parameters" (switch 04, bit 7).

Transmission Result Report (Memory Transmission)

This report is printed when a Memory Transmission is completed, so you can check the result of the transmission. If E-mail TX Results is programmed in a Quick Operation key, you can select whether a report e-mail is sent after transmission.

- ☐ If two or more destinations are specified, this report is printed after the fax message has been sent to all the destinations.
- ☐ If the machine is set up not to print this report and the fax message could not be successfully transmitted, a Communication Failure Report is printed. See p.84 "Communication Failure Report".
- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 03, bit 0).
- ☐ You can select whether to include part of the original image on the report. See p.161 "User Parameters" (switch 04, bit 7).
- ☐ To view the report without text disruption, select a font of even character width in your e-mail application's settings.
- ☐ The Page column gives the total number of pages. The Not Sent column gives the number of pages that could not be sent successfully.
- -- column indicates the Internet Fax document was sent to the mail server programmed in this machine. (However, this does not mean the e-mail was delivered.)

Communication Failure Report

This report is printed when a message could not be successfully transmitted with Memory Transmission.

If the machine is set up to print a Transmission Result Report, this report is not printed. Use it to keep a record of failed transmissions so you can send them again.

𝚱 Note

- ☐ This report is only printed if the Transmission Result Report is turned off and a message could not be successfully transmitted with Memory Transmission.
- ☐ You can select whether to include part of the original image on the report. See p.161 "User Parameters" (switch 04, bit 7).
- ☐ The Page column gives the total number of pages. The Not Sent column gives the number of pages that could not be sent successfully.
- Unprogrammed destination column indicates the message could not be sent because the transfer's fax number is incorrect, or not programmed.
- -- column indicates the Internet Fax document was sent to the mail server programmed in this machine. (However, this does not mean the e-mail was delivered.)

Transmission Result Report (Immediate Transmission)

If you turn this report on, a report will be printed after every Immediate Transmission so you have a record of whether the transmission was successful or not. If the machine is set up not to print this report and the fax message could not be successfully transmitted, the Error Report is printed instead. If E-mail TX Results is programmed in a Quick Operation key, you can select whether a report e-mail is sent after transmission.

Note


- ☐ You can switch this report on or off in the User Parameters. See p.161 "User Parameters" (switch 03, bit 5).
- ☐ To view the report without text Disruption, select a font of even character width in your e-mail application's settings.
- If the page was sent successfully, the Page column gives the total number of pages sent successfully.

5. Reception Features

Reception

Immediate Reception

Each page of a fax message is printed as soon as it is received. This method is used for standard fax messages.



Normally this machine receives messages by Immediate Reception. But Memory Reception is used when "Combine 2 Originals", "Multi-copy Reception", "RX Reverse Printing" or "2 Sided Print" is set to "ON". See p.96 "Printing Options". If the conditions are that Substitute Reception should be used, a fax message is not printed. It will be stored in memory. See p.85 "Memory Reception". See p.86 "Substitute Reception".

Note


- ☐ The machine may not be able to receive fax messages when free memory space is low.
- ☐ If free memory reaches 0% during Immediate Reception, any further reception becomes impossible and the current communication is terminated.

Reception resolution

This machine supports Standard, Detail, and Super Fine resolutions for reception. If you do not have the optional fax function upgrade unit, faxes sent at Super Fine resolution will be printed on your machine at Detail resolution. This may differ from the sender's intended resolution. See p.30 "Resolution", Facsimile Reference < Basic Features>.

Memory Reception

The machine waits until all pages of the message have been received into memory before printing it.



This method is used with the following functions:

- Combine 2 originals See p.99 "Combine Two Originals".
- Multi-copy when set to multiple copies
 See p.98 "Multi-copy Reception".
- Reverse Order Printing See p.100 "Reverse Order Printing".
- 2-sided Printing See p.97 "Two-Sided Printing".

#Important

- ☐ When about one hour passes after power of the machine is turned off, all fax messages stored in memory will be lost. If any messages have been lost for this reason, a Power Failure Report is automatically printed when the operation switch is turned on. Use this report to identify lost messages.
- ☐ The machine may not be able to receive large numbers of messages or messages with high data content. In such cases, we recommend you switch off the above functions or install the optional expansion memory.

Limitation

☐ The machine may not be able to receive fax messages when free memory space is low.

Note

- ☐ If the free memory space reaches 0% during Memory Reception, the machine can no longer receive the current fax message and stops communicating.
- ☐ If you have selected Store for Reception File Setting, received messages will be saved on the hard disk and will not be printed. You can print those messages by operating the machine or a connected computer, as necessary. See p.186 "Storing or Printing Received Documents".

Substitute Reception

In Substitute Reception, a received fax message is stored in memory instead of being printed. Substitute Reception gets used when the machine cannot print any fax messages. Fax messages received using Substitute Reception are automatically printed when the condition which caused the machine to use Substitute Reception is rectified.

Depending on why the machine cannot print, Substitute Reception might be used for all fax messages received, or for only those messages that match a specified condition.

The Receive File indicator lights to let you know when fax messages have been received using Substitute Reception.



Note

- ☐ Reception may not take place if there is not enough free memory.
- ☐ If free memory reaches 0% during Substitute Reception, any further reception becomes impossible and the current communication is terminated.
- □ When a fax message is received after Store has been selected for Reception File Setting in the Facsimile Features menu, the Receive File indicator lights.

Receiving messages unconditionally

If one of the conditions listed below occurs, the machine receives all fax messages using Substitute Reception.

| Problems | Causes | Solutions |
|---|---|---|
| % is lit. | Paper is jammed. | Remove the jammed paper. See "% Clearing Misfeeds", General Settings Guide. |
| The machine is printing with other function. | The machine is busy printing with other function. | The message will be automatically printed after the current job finishes. |
| The message "Following output tray is full. Remove paper." appears. | The output tray is full. | Remove paper from the output tray. |
| ☐• is lit. | The cover is open. | Close the cover shown in the display. |

Receiving messages according to parameter-specified settings

If one of the conditions listed below occurs, the machine receives only those messages that match the conditions specified in the User Parameters. See p.161 "User Parameters" (switch 05, bit 2,1).

| Problems | Causes | Solutions |
|---|--------------------------|---|
| is lit. | All trays out of paper. | Add paper. See "Loading Paper", General Settings Guide. |
| is lit. | Toner is empty. | Replace the toner cartridge. See "Ladding Toner", General Settings Guide. |
| The message "This tray is out of order." appears. | All trays out of action. | Call your service representative. |

You can specify the following conditions with the User Parameters. See p.161 "User Parameters" (switch 05, bit 2,1).

When Own Name or Own Fax Number is received

The machine switches to Substitute Reception only when the sender has programmed their Own Name or Own Fax Number. If the power is switched off for more than an hour, all the messages stored in memory are deleted. In that case, the Power Failure Report or the Journal can be used to identify which messages are lost so you can ask the senders to transmit them again.

#Important

☐ If a sender has not programmed their Own Name or Own Fax Number, the machine may fail to receive an important fax message. We recommend that you ask important senders to program an Own Name or Own Fax Number in advance.

Free

The machine switches to Substitute Reception regardless of whether or not the sender has programmed their Own Name or Own Fax Number.

Polling ID match

The machine switches to Substitute Reception only when the programmed Polling ID of the other end matches the ID of this machine.


Disable

The machine does not receive any messages.

Reception Functions

Transfer Station

Transfer Stations allow you to expand the standard functions of your fax machine to set up complex networks. The diagram below may make the concept clearer.



The following terminologies are used in this section:

Requesting Party

The machine where the message originates.

Transfer Station (this machine)

The machine that forwards the incoming message to another destination.

Receiving Station

The facsimile or computer that received the message from the Transfer Station.

The final destination of the message, that is the machine the Transfer Station sends to. Receiving Stations must be programmed into a Quick Dial or Groups in the Transfer Station.

Preparation

This machine can receive forwarding requests by e-mail. Before you can use this function, you must make the following preparations.

- Program each Transfer Station number in this machine (Transfer Station) and in the Requesting Party itself. See p.183 "Transfer Report".
- Program the same Polling ID in both this machine (Transfer Station) and the Requesting Party. See p.185 "Programming a Polling ID".
- The Requesting Party's number must be programmed in the destination list of this machine (Transfer Station). The registration number must be between 00001 and 00100.
- The End Receiver's fax number or e-mail address must be programmed in the destination list or Group Dial of this machine (Transfer Station).

Note

- ☐ You cannot receive e-mails unless your machine has the capacity to store two or more destinations specified using the number keys.
- If the Requesting Party specifies a Group for the Receiving Stations and the total number of Receiving Stations exceeds 500, the Transfer Station cannot transfer the message and sends a Transfer Result Report to the Requesting Party.

☐ If the Requesting Party specified a destination with both the fax number and e-mail address programmed in Transfer Station as End Receiver, this machine sends the message to the fax number or email address according to the User Parameter setting. See p.161 "User Parameters" (switch 32, bit 0).

Nultistep transfer

The principles of Transfer Stations can be used to build up a multi-step facsimile network where messages are passed through several Transfer Stations. By programming the Receiving Stations in a Transfer Station Group, you can enable this machine to transfer messages onto other Transfer Stations.

For more information, contact your service representative.

This function can only be used if the machines are made by the same manufacturer.

Sending the Transfer Result Report

This machine compares the fax number of the Requesting Party with the Requesting Party's number programmed as a Quick Dial or Speed Dial. If the lower five digits of the two numbers match, it sends the Transfer Result Report to the Requesting Party. For example:

 Requesting Party's own dial number: 001813-11112222

Transfer Station's Quick Dial: 03-11112222

Transfer Result Report

Preparation

Program the Requesting Party fax number into a Quick Dial key in the Transfer Station (this machine) in advance.

Program your own fax number. See p.183 "Transfer Report".

Program the Polling ID. See p.185 "Programming a Polling ID".

This reports whether transmission to the Receiving Stations was successful or not.

When the Transfer Station has transferred the message to all Receiving Stations, it sends the Transfer Result Report back to the Requesting Party. The machine prints the report if it cannot be sent back to the Requesting Party.

Note

- You can set whether a portion of the original image is printed on the report with the User Parameters. See p.161 "User Parameters" (switch 04, bit 7).
- ☐ Unprogrammed destination column indicates the message could not be sent because either the end receiver's fax number or e-mail address is incorrect, or not programmed.
- -- column indicates the Internet Fax document was sent to the mail server programmed in this machine.

Transfer Result Report (transfer request by e-mail)


When this machine receives a transfer request by e-mail, the Transfer Result Report is sent by e-mail to the Requesting Party after completing all transmissions to the specified Transfer Stations. If the Key Operator's e-mail address has been programmed, the Transfer Result Report e-mail is forwarded to that address.



- ☐ Unprogrammed destination column indicates the message could not be sent because either the End Receiver's fax number or e-mail address is incorrect, or not programmed.
- -- column indicates the Internet Fax document was sent to the mail server programmed in this machine.
- When using multistep transfer, the Transfer Result Report e-mail is sent to the last Transfer Station that sent Transfer Request.

Forwarding Received Documents

This machine can forward received documents to other destinations programmed in memory based on Own Name, Own Fax Number or sender's e-mail address. If a sender's e-mail address is programmed as the destination, documents received are forwarded as e-mail.




Note

- ☐ You need to specify the Forwarding destination in advance. See p.157 "Forwarding".
- ☐ If you want to forward documents to a different destination depending on the sender, see p.165 "Special Senders to Treat Differently".
- ☐ You can select whether the machine prints out the messages it forwards with User Parameters (switch 11, bit 6). For details, see p.161 "User Parameters".

Routing Received Documents with SUB Code

When a document is received, its SUB Code is compared to user codes programmed in Personal Boxes and, if a match is found, the document is routed to the destination whose user code is specified. If the destination specified is an email address, the received document is routed to that destination as e-mail.

In addition to SUB Codes, you can use the forward feature to send all received transmissions to a specific e-mail address. See p.157 "Forwarding".



Note

- ☐ You can route documents received from any fax machine, regardless of manufacturer.
- ☐ Before routing received documents, you must set up a Personal Box and routing address. See p.174 "Programming/changing Personal Boxes".
- ☐ This function is not available when you have set received documents to be delivered to the network delivery server.

Transferring Received Documents

Originals sent with a SUB Code that matches the SUB Code programmed as a Transfer Box are received then relayed to the programmed receiver.

When e-mail addresses are programmed in the Transfer Station as receivers, received messages are sent in an e-mail format to the receivers.

Preparation

Transfer Boxes and Receiving Stations must be set up in order to transfer received documents. See p.180 "Programming/changing Transfer Boxes".


Note

- ☐ Transfer Results are not sent back to Requesting Party.
- You can transfer data received from any fax machine, regardless of manufacturer.

SMTP Reception Using Internet Fax

You can set this machine to SMTP reception.

With SMTP reception, e-mail is received as soon as it is sent to the e-mail address set by the machine. You can route received e-mail to other Internet Fax machines as well.



- ☐ For SMTP reception, set the MX record of the DNS server to receive SMTP.
- ☐ To use SMTP reception, set the reception protocol to SMTP. See "Settings You Can Change with User Tools File Transfer", *Network Guide*.
- ☐ Even if SMTP reception is enabled on the DNS server, e-mail sent from the SMTP server will not be received and the machine reports an error if SMTP reception is not set. Also, the SMTP server sends an error notification to the originator.
- ☐ If an error occurs while receiving e-mail, reception is aborted, the e-mail is deleted, and Error Report is printed. Also, the SMTP server will send an error notification to the originator.

□ When the SMTP server attempts to route received documents to this machine while the machine is transmitting an e-mail, the machine will respond to the SMTP server with a "busy" signal. Then, the SMTP server usually tries resending the documents until the set timeout.

∠ Reference


p.61 "Auto E-mail Reception", Facsimile Reference < Basic Features>

p.61 "Manual E-mail Reception", Facsimile Reference < Basic Features>

p.94 "Routing E-mail Received via SMTP"

Routing E-mail Received via SMTP

E-mail received via SMTP can be routed to other fax machines. It can also be routed to destinations programmed as Quick Dial entries or Groups.



Preparation

Before routing e-mail received via SMTP, you first must set "SMTP RX File Delivery Settings" to "On". See p.147 "E-mail Settings".

- ☐ If an e-mail transfer request is received when the "SMTP RX File Delivery Settings" to "Off", this machine responds with an error message to the SMTP server.
- ☐ You can make settings that limit transfer to specified originators. See p.147 "E-mail Settings".
- ☐ Using this function, you can also send documents from your e-mail software to e-mail addresses and G3 fax machines' destinations through this machine simultaneously. For details about specifying the destinations of fax machines, see the following.

Specifying E-mail Transfer

The originator can request transfer of e-mail sent to another fax machine by specifying the e-mail address as follows:

Fax Number

fax=destination fax number@host name of this machine. domain name Example: to transfer to fax number 212-123-4567, specify: fax=2121234567@abc.company.com

Quick Dial Destination

fax=#registration number of 5 digits or less@host name of this machine.do-main name

Example: to transfer to the destination number 00001: fax=#00001@abc.company.com

Group Destination

fax=#**registration number of 5 digits or less@host name of this machine.domain name

Example: to transfer to the destination programmed under Group number 04: fax=#**04@abc.company.com

JBIG Reception

The optional fax function upgrade unit is required.

If you use JBIG (Joint Bi-level Image Experts Group) compression, you can send photographic originals faster than with other methods of compression. You can only use this function with G3 line type. It allows you to receive messages sent in the JBIG format through JBIG Transmission.

Limitation

☐ If ECM is turned off, JBIG Reception is unavailable. See p.160 "ECM (Error Correction Mode)".

Note

□ When the optional extra G3 interface unit is installed, JBIG receptions of G3-2 line is as standard.

Auto Fax Reception Power-up

This machine can be set to shut down automatically if no one has used it for a while. In these situations, even though the operation switch is off, the machine can still receive incoming messages as long as the main power switch is on.

∰Important

 Reception is not possible if both the operation switch and main power switch are turned off.

- ☐ You can set whether messages are printed as soon as they are received (Immediate Reception) with the User Parameters. See p.161 "User Parameters" (switch 14, bit 0).
- You can also have fax messages received by Memory Reception (Substitute Reception) printed after the machine is turned on.

Printing Options

Print Completion Beep


When this function is turned on, the machine beeps to let you know when a received message has been printed.

Note

☐ You can alter the volume of the beep or turn it off completely (set the volume to the minimum level). See p.73 "Adjusting the Volume", Facsimile Reference < Basic Features>.

Checkered Mark

When this function is turned on, a Checkered Mark is printed on the first page of fax messages to help you separate them.




∅ Note

☐ You can turn this function on or off using Reception Setting. See p.146 "Reception Settings".

Centre Mark

When this function is turned on, marks are printed halfway down the left side and at the top centre of each page received. This makes it easy for you to position a hole puncher correctly when you file received messages.



Note

- ☐ The Centre Mark may deviate a little from the exact centre of the edge.
- ☐ You can turn this function on or off using Reception Settings. See p.146 "Reception Settings".

5

Reception Time


You can have the date and time printed at the bottom of the message when it is received. You can turn this function on or off using Reception Settings. See p.146 "Reception Settings".

Note

- When a received message is printed on two or more sheets, the date and time is printed on the last page.
- ☐ The date and time when the message was printed can also be recorded on the message. If you need this function, contact your service representative.


Two-Sided Printing

You can have a received message printed on both sides of a sheet. You can turn this function on or off using Reception Settings. See p.146 "Reception Settings".



Limitation

□ To use this function, all pages of the received document must be of the same size—inform the sending party of this beforehand if necessary. You must also have paper set in your machine of the same size as that sent by the sending party. In Two–Sided Printing, this machine will correctly receive in A3□, B4 JIS (Japanese Industrial Standard)□, A4□□, B5 JIS□□, A5□□(11"×17"□, 8¹/2"×14"□, 8¹/2"×11"□□, 8¹/2"×5¹/2"□). The following table shows the results that can be achieved when receiving with this machine.




- ☐ This function works only when all pages are of the same width and received into memory.
- ☐ This function cannot be used with Combine Two Originals.

Ø Note

- ☐ The machine will use Memory Reception for Two-Sided Printing.
- ☐ Printouts may vary depending on how the sender sets the originals.
- ☐ You can select to have messages only from selected senders printed in this way. See p.165 "Special Senders to Treat Differently".
- ☐ Stored documents of the same size are printed on the same paper. Some stored documents may be unavailable for this printing option.


180-Degree Rotation Printing

When printing on both sides of the paper, this machine rotates images as shown in the diagram.



Multi-copy Reception


If you switch this function on, multiple copies of each incoming fax message will be printed. You can also select to have multiple copies made of messages from particular senders. See p.165 "Special Senders to Treat Differently". See p.146 "Reception Settings".



- ☐ The maximum number of copies that can be made for each message is 10.
- ☐ When you are using the Multi-Copy function with specified senders, the maximum number of copies is 10.
- ☐ You can turn this function on or off using Reception Settings. See p.146 "Reception Settings".
- ☐ The machine will use Memory Reception for Multi-copy Reception.

Image Rotation


If you have set paper in the standard tray \square , incoming fax messages will be rotated automatically to fit onto the paper.



- Note
- ☐ You can choose to have received messages printed from a specified tray. See p.146 "Reception Settings".

Combine Two Originals

When two messages of the same size and orientation are received consecutively, they are printed on a single sheet when you turn this function on. This can help you economize on paper.



 Two A5 □ messages are printed side by side on a sheet of A4 □.

- Two B5 JIS ☐ messages are printed side by side on a sheet of B4 JIS ☐.
- Two A4 ☐ messages are printed side by side on a sheet of A3 ☐.
- Two 8¹/₂"×5¹/₂" messages are printed side by side on a sheet of 8¹/₂"×11" □.
- Two 8¹/₂"×11" messages are printed side by side on a sheet of 11"×17" □.


Limitation

- □ This function does not work with messages larger than A5 □, B5 JIS □, A4 □, 8¹/₂" × 11" □ or 8¹/₂" × 5¹/₂" □. When A5 □, B5 JIS □, A4 □, 8¹/₂" × 11" □ or 8¹/₂" × 5¹/₂" □ size paper is loaded in the machine, each page of the received message is printed on a single sheet.
- ☐ If paper matching the size and orientation of a received document is unavailable, Combine Two Originals is not possible.
- When Combine Two Originals and 2-Sided Printing are selected at the same time, 2-Sided Printing takes priority and Combine Two Originals is canceled.

- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 10, bit 1).
- ☐ This function uses Memory Reception.

Page Separation and Length Reduction

When the size of a received message is longer than the paper loaded in the machine, each page of the message can be split and printed on several sheets, or reduced and printed on a single sheet. For example, this function splits the message if the message length is 20 mm (0.79") or longer than the paper used. The message is reduced if it is less than 20 mm (0.79"). When a message is split, an asterix (*) is inserted at the split position and about 10 mm (0.39") of the split area is duplicated on the top of the second sheet.




Note

- ☐ Your service representative can customize this function with the following settings:
 - Reduction
 - · Print split mark
 - Overprinting
 - Overprinting length
 - Guideline for split
- ☐ You can adjust the overprinting and reduction lengths within the following ranges:
 - Overprinting length: 4 mm (0.16"), 10 mm (0.39"), 15 mm (0.59")
 - Guideline for split: 5-155 mm (5 mm steps)/0.2"-6.1" (0.2" steps)

Reverse Order Printing


Normally, received pages are printed and stacked on the tray in the order they are received. If you turn this function on, the machine will start printing the message from the last page received.



- ☐ You can turn this function on or off using Reception Settings. See p.146 "Reception Settings".
- ☐ When this function is on, the first page will be printed last.
- ☐ This function uses Memory Reception.

Page Reduction

If you receive a message that is longer than the paper in the tray, the machine usually prints it on two pages. If you turn this function on, the machine reduces the width and length of the received image so that it will fit on one page. If A4D paper is loaded and a message of B4 JISD size is received, the machine will reduce the message to a single A4D sheet.



- ☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 10, bit 3).
- ☐ When this function is used, the printing quality may not be as good as usual.

p.100 "Page Separation and Length Reduction"

TSI Print (Transmitting Subscriber Identification Print)

Usually the sender's Fax Header is printed on received messages. If the sender has not programmed their Fax Header, you will not be able to identify them. However, if you turn this function on, the sender's Own Name or Own Fax Number is printed instead so you can find out where the message came from. When you receive an Internet Fax document, the email address of the sender is printed.

p.65 "Initial Settings and Adjustments", Facsimile Reference < Basic Features>

Note

☐ You can turn this function on or off in the User Parameters. See p.161 "User Parameters" (switch 02, bit 3).

When There Is No Paper of the Correct Size

If there is no paper in your machine that matches the size of a received message, the machine will choose a paper size based on the paper available. For example, if your machine has $8^1/_2$ "×11" and A3D loaded and you receive a A4D size message, check the A4D column of the following table. The paper size at the top has highest priority. In this case, since $8^1/_2$ "×11" bis given a higher priority than A3D, the message is printed on $8^1/_2$ "×11" D.

If only B5 JIS□ is loaded and you receive an A3□ message, the received message is stored in memory and not printed.

Priority Table

Image Rotation

| | 1 | A3,DLT A3 | B4 JIS B4 JIS | A4,LT | A4,LT | mage Size | LG | F/F4 |
|-------------------------|----|--------------|------------------|---------|--------|-----------|-----------------|--------|
| | Ì | | B4 JIS | ┏ | A4,LT | B5 JIS | LG | F/F4 |
| | Ì | A3 | | | | | | |
| | 2 | | ┏ | LT. | A4 | B5 JIS | LG - | F/F4 |
| | | DLT | A3 | LT D | A4 | B5 JIS | A4 | LG |
| | 3 | A4 | DLT D | A4 | LT | B4 JIS | A4 | A4 |
| | 4 | A4 | B5 JIS | A4 | LT | A4 | | A4 |
| | 5 | LT D | B5 JIS | F/F4 | A3 | A4 | LT D | LT |
| | 6 | LT De De | A4 | LG - | F/F4 | LT | | LT |
| iorities | 7 | F/F4 | A4 | A3 | DLT | LT | B4 J I S | B4 JIS |
| Paper Select Priorities | 8 | B4 JIS | LT D | B4 JIS | B4 JIS | F/F4 | A3 | A3 |
| Paper S | 9 | LG | LT De De | DLT | LG | A3 | DLT | DLT |
| | 10 | | F/F4 | HLT | | DLT D | HLT | HLT |
| | 11 | | LG | A5 | | LG | A5 | A5 |

| Page reduction | Disabled |
|------------------------------------|---------------|
| Reduction in Sub-scan Direction | Enabled |
| Page Separation Threshold | 20 mm (0.79") |
| Width or Length Priority | Width |

 D and DD indicate that the message is split over two pages of paper with the orientation and size shown.

Note

- ☐ Paper placed in the bypass tray is not usually selected for printing a received message. However, you can use this tray if you select the bypass tray as the main paper tray using Reception with Specified Senders. See p.165 "Special Senders to Treat Differently".
- ☐ Widths that this machine can receive are A4, B4 JIS, and A3. Any messages narrower than A4 are sent as A4 width with the length unchanged.
- ☐ The paper size used to print a received message may be different from the size of the sent original.
- ☐ If you specify a receiving tray with the setting priority under System Settings, the messages may be received in a different order by setting the priority table. The priority tray may be used only when the document received is the same size as the priority tray.

GERRIOGE

p.99 "Image Rotation"

p.100 "Page Separation and Length Reduction"

p.101 "Page Reduction"

"Tray Paper Settings", General Settings Guide

Setting priority trays

With the same size of paper loaded into multiple trays, you can make the machine use one tray for one function and another tray for another function. For example, you may load white A4 paper into tray 1 to use when making copies, and yellow A4 paper into tray 2 to use when printing received faxes. You can then easily identify for which purpose paper has been output. You can perform this setting using System Settings. See "Tray Paper Settings", General Settings Guide.

Note

When a different size of document from the priority tray is received, the tray containing the same size of paper as the received document is used.

Just size printing

If you turn this function on and no paper tray is stocked with paper of a suitable size to print a received document, a message will appear on the display prompting you to load paper of the required size. When you have loaded new paper, you can then print the message.

Two messages can appear:

• Paper tray



• Bypass Tray



Limitation

- ☐ If the paper tray is pulled out or the machine runs out of the specified size of paper, the message will not be printed. Be sure the paper tray is inserted.
- ☐ The action that follows pressing **[Exit]** varies depending on the status of the machine when the message occurred.
 - If any received documents or reports were being printed automatically, the printer automatically continues printing from where it left off.
 - If any documents or reports were being printed manually, the printer does not resume printing. Perform the operation from the beginning again.

Note

☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 05, bit 5).

Having Incoming Messages Printed on Paper from the Bypass Tray

You can have messages sent from Specified Senders printed on paper from the bypass tray. This is useful if you need messages printed on a size of paper not stocked in the paper tray(s).

You can load a maximum of 100 sheets of standard paper in the bypass tray.

𝒯 Note

- ☐ Before you can use this function, you need to turn on Authorized Reception (Initial Setup Reception Mode settings), program the Specified Senders (Key Operator Settings) along with the paper. See p.146 "Reception Settings". See p.165 "Special Senders to Treat Differently".
- ☐ The print area is determined by the optional expansion memory, resolution, and the vertical length of the originals.
- ☐ If paper longer than 600 mm is used, the paper may get wrinkled, it may not be sent, or a paper jam may occur.
- □ The machine can detect A5□, A4□, A3□(5¹/₂"×8¹/₂"□, 8¹/₂"×11"□, 11"×13"□, 8"×13"□) paper sizes. When you load any other size, specify the paper size. See p.172 "Programming Bypass Tray Paper Size".
- If the specified paper size and the size of paper set in the bypass tray do not match, paper jams may occur, or the image may be truncated.

- ☐ If messages are printed on paper smaller than A4, the image may be truncated, or split across sheets.
- ☐ If you use this function, Image Rotation and 180-Degree Rotating Printing are not possible.

Where Incoming Message are Delivered - Output Tray

Specifying Tray for Lines

The optional extra G3 interface unit is required.

You can specify the document feeding tray for each port (telephone or LAN). For example, you can specify documents received through the G3-1 port to be fed to the "Internal Tray 1" and documents received through the G3-2 port to be fed to the "Internal Tray 2", facilitating separation of files. You can also set the machine to output Internet Faxes and ordinary faxes onto different trays.

Note

☐ To use this function, specify the port and destination using [Specify Tray for Lines]. See p.146 "Reception Settings".

Tray Shift

The optional finisher is required.

When the optional finisher unit is selected for fax output, you can use the Tray Shift function whenever a fax or report is printed.

This is useful for separating faxes stacked in the finisher output tray. For example, if the previous incoming fax was output to the left, the next incoming fax will be output to the right and vice-versa.

Note


☐ You can turn this function on or off with the User Parameters. See p.161 "User Parameters" (switch 19, bit 0).

6. Fax via Computer

Sending Fax Documents from Computers

Using computers connected to the machine through parallel ports, IEEE 1394 (IP Over 1394) ports, LANs, wireless LANs, or USB2.0 you can fax documents, created using Windows applications, to other fax machines over a telephone line.

- To send a fax, simply select [Print] from the Windows application, then select LAN-Fax as the printer, and then specify a destination.
- In addition to sending faxes, LAN-Fax Driver allows this machine to be used for printing out documents prepared on a computer for proof checking.
- To use LAN-Fax Driver, connect this machine to a LAN and make the necessary network settings, and then install LAN-Fax Driver and related utilities on your computer.



∰Important

☐ Errors occurring when the machine is used as a LAN-Fax will not be displayed on the computer. Check the help menus using a Web browser.

Before Use

To use these features, a LAN-Fax Driver must be installed on your computer. Use the LAN-Fax driver included on the printer CD-ROM. You must also make the required computer to fax network settings on the machine, according to the type of connection.

When a personal computer and the machine are connected in parallel:

See "System Settings (Parallel Connection)", *Printer Reference* 2.

When using Ethernet, IEEE 1394 (IP over 1394), or IEEE 802.11b (wireless LAN):

See "User Tools Menu (System Settings)", Network Guide.

Installing the Software

You need to install LAN-Fax Driver on your computer before using the LAN-Fax functions. LAN-Fax Driver is on the CD-ROM included with the printer.

Address Book and LAN-Fax Cover Sheet Editor are installed with LAN-Fax Driver. Address Book helps you edit LAN-Fax transmission destinations. LAN-Fax Cover Sheet Editor helps you edit LAN-Fax cover sheets.

Note

☐ The following explanation assumes that you are familiar with general Windows procedures and practices. If you are not, see the documentation that comes with Windows for details.

Auto run program

With Windows 95/98/Me, Windows 2000/XP, and Windows NT 4.0, the installers for various drivers and utilities launch automatically as Auto Run programs when you insert the CD-ROM.

If your operating system is Windows 2000/XP or Windows NT 4.0, installing a printer driver using Auto Run requires Administrator permissions. When you install LAN-Fax Driver using Auto Run, log on using an account that has Administrator permissions.

Note

- ☐ If the plug and play function starts, click [Cancel] in the [New Hardware Found], [Device Driver Wizard], or [Found New Hardware Wizard] dialog box, and then insert the CD-ROM. The [New Hardware Found] or [Found New Hardware Wizard] dialog box appears depending on the system version of Windows 95/98/Me, Windows 2000, or Windows XP.
- □ Auto Run might not work automatically with certain OS settings. If this is the case, double-click "Setup.exe", located on the CD-ROM root directory.
- ☐ If you want to cancel Auto Run, hold down the [SHIFT] key (when your system is Windows 2000/Windows XP, hold down the left [SHIFT] key) while inserting the CD-ROM. Keep the [SHIFT] key hold down until the computer stops reading the CD-ROM.
- ☐ Clicking **[Cancel]** during installation aborts the installation. If you cancel the installation, restart your computer and install the rest of the software or printer driver.

LAN-Fax Driver, Address Book, and LAN-Fax Cover Sheet Editor can be installed by Auto Run.

Installing individual applications

Preparation

Before installing the above applications, install SmartNetMonitor for Client. See "Installing SmartNetMonitor for Client/Admin", *Printer Reference 1*.

Use the following procedure to install LAN-Fax Driver, Address Book, and LAN-Fax Cover Sheet Editor at one time.

- 1 Quit all applications currently running.
- 2 Insert the CD-ROM included with this machine into the CD-ROM drive of your computer.

The installer launches automatically, and the language selection window appears.

𝒯 Note

- ☐ Depending on your operating system settings, the installer may not launch automatically. If it does not, double-click "SET-UP.EXE" in the CD-ROM root directory to launch the installer.
- Select the interface language of the software, and then click [OK].
- 4 Click [LAN-Fax Driver].

The software license agreement window appears.

Read all of the terms and, if you agree, select [laccept the agreement], and then click [Next].

- ☐ If you select [I don't accept the agreement], you cannot complete the installation.
- Click the [LAN-Fax Driver] check box, and then click [Next].
- Confirm that the [Printer Name:<LAN-Fax M3>] check box has been selected, and then click [Continue].
 - **𝒜** Note
 - ☐ Select the desired port.
- 8 Click [Finish].

The installation completion dialog box appears.

- 9 Click [Finish].
- Click [Exit].

Applications Stored on the CD-ROM

This section provides information about LAN-Fax Driver, Address Book, and LAN-Fax Cover Sheet Editor.

LAN-Fax Driver

This driver allows you to use LAN-Fax functions.

Location of the File

The following folders are on the CD-ROM:

- LAN-Fax Driver for Windows 95/98/Me DRIVERSLAN-FAXWIN9X Me
- LAN-Fax Driver for Windows 2000/XP DRIVERSLAN-FAXWIN2K_XP
- LAN-Fax Driver for Windows NT 4.0 DRIVERSLAN-FAX T4

Operating Environment

- Computer PC/AT Compatible
- Operating Systems Microsoft Windows 95/98/Me Microsoft Windows 2000/XP Microsoft Windows NT 4.0
- Display VGA 640×480 dots or more

Limitation

- All operations cannot be guaranteed depending on the system environment.
- □ When you use Windows NT, LAN-Fax Driver will not work in an RISC base processor (MIPS R series, Alpha AXP, PowerPC) environment.

Note

☐ Before beginning installation, exit all other applications.

Address Book

Address Book helps you edit LAN-Fax transmission destinations.

Operating Systems

Microsoft Windows 95/98/Me Microsoft Windows 2000/XP Microsoft Windows NT 4.0

LAN-Fax Cover Sheet Editor

LAN-Fax Cover Sheet Editor helps you edit LAN-Fax cover sheets.

Operating Systems

Microsoft Windows 95/98/Me Microsoft Windows 2000/XP Microsoft Windows NT 4.0

Setting LAN-Fax Properties

This section describes how to make settings such as paper size, resolution, and options.

- Paper size
- Orientation
- Tray
- Resolution
- · Gray scale
- Printing images of True Type fonts

When this machine is connected to a network, selections for the option configuration are automatically performed.

For details, see Help.

- If the options on this machine are not configured as instructed, LAN-Fax functions may fail to work as intended.
- ☐ If your operating system is Windows 2000/XP or Windows NT 4.0, log on using an account that has Administrator permissions.
- On the [Start] menu, point to [Settings], and then click [Printers].

∅ Note

- ☐ With Windows XP Professional, select [Printers and Faxes] on the [Start] menu.
- With Windows XP Home Edition, select [Control Panel] on the [Start] menu. Next select [Printers and Other Hardware], and then [Printers and Faxes].

Double-click [LAN-Fax M3], and then click [Properties] on the [File] menu.

Note

- ☐ With Windows NT, click [Document Default] on the [File] menu.
- Make settings for the option configuration.

When using Windows 95/98/Me

- ① Click the [Paper] tab.
- 2 Click [Accessories...].

When using Windows 2000, Windows XP, or Windows NT

- Click the [Advanced] tab.
- 2 Click [Printing Defaults...].
- 3 Click [Accessories...].
- 4 Confirm the settings for the option configuration.

When using a network

If the settings do not match the installed optional units, click [Reload from Device].

When not using a network

- Select the check box besides the installed optional units.
- Click [OK].

The settings for the option configuration are completed.

6 Click [OK].

Basic Transmission

This section describes how to send fax documents created using Windows applications.

To send a fax, simply select [Print] from the Windows application, then select [LAN-Fax] as the printer, and then specify a destination in the [LAN-Fax] dialog box.

Open the application document you want to send or create a new document, and then perform the following procedure.

For details, see Help.

Limitation

When using SmartNetMonitor for Client, you cannot send documents to this machine using more than one LAN-Fax at the same time.

Note

- ☐ To send to an Internet Fax destination, the destination must be set in the destination list of this machine beforehand. Use this machine's destination list to specify Internet Fax destinations. E-mail addresses cannot be entered in the LAN-Fax dialog box.
- 1 On the [File] menu, click [Print].
- 2 Select [LAN-Fax M3] in [Printer Name].
- Click [OK].

The LAN-Fax dialog box appears.

∅ Note

☐ The setting method may differ depending on the application you are using. In all cases, select **[LAN-Fax M3]** for the printer.

4 Specify the destination.

Use one of the following procedures to specify a destination. For details, see Help.

Note

- ☐ You can select the appropriate line in the [Line:] list.
- ☐ You can specify up to 500 destinations.
- ☐ The machine can hold up to 64 documents sent using LAN-Fax, as those to be transmitted.

Specifying a destination using a destination list

• Enter a destination in the [Fax Number:] box.

When using a destination list: Enter [#] and the registration number.

2 Click [Next Number].

The entered destination is added and displayed in the [List of Destinations:] box.

- ☐ If you do not want the entered destination to be added to the list, skip this step. Also when this step is skipped, the document will be sent to the number entered in the [Fax Number:] box.
- 3 To specify more destinations, repeat steps 1 and 2.

Specifying a destination by directly entering a fax number

• Enter a fax number in the [Fax Number:] box.



☐ To enter a pause, click [Pause].

2 Click [Next Number].

The entered destination is added and displayed in the [List of Destinations:] box.

- ☐ If you do not want the entered destination to be added to the list, skip this step. Also when this step is skipped, the document will be sent to the number entered in the [Fax Number:] box.
- 3 To specify more destinations, repeat steps 1 and 2.

Specifying a destination using Address Book

In order to use this method, you need to register destinations in the address list using Address Book. See p.110 "Address Book".

• Select a CSV file containing the desired address list, from the drop-down menu.

Note

- ☐ Up to three files used most lately appear in the dropdown menu. To use an address list that did not appear, click [Browse...], and then select the file.
- ② In the [Name:] list select [Contact], [Company], or [Group], and then select [ALL] or an initial letter.

The destinations matching the selected parameters appear.

Click the destination to highlight it, and then click [Set as Destination].

The entered destination is added and displayed in the **[List of Destinations:]** box.

4 To specify more destinations, repeat steps 2 and 3.

5 Specify options.

p.113 "Attaching a cover sheet". p.114 "Previewing fax images". p.114 "Specifying options".

p.115 "Printing and Saving".

p.116 "Specifying Two-Sided Printing".

If you do not want to specify options, proceed to step **6**.

6 Click [Send].

Note

☐ When you click [Print & Send], a fax will be transmitted to the destination and a copy of the document you send will be printed from your machine.

Attaching a cover sheet

Selecting the [Attach a Cover Sheet] check box causes a cover sheet to be attached to the top of the fax document.

The cover sheet includes the following items:

- Company name as destination info.
- Department name as destination info.
- Person name as destination info.
- Title of address as destination info.
- Company name as sender info.
- Department name as sender info.
- Person name as sender info.
- Telephone number as sender info.
- Fax number as sender info.

- Date
- Message



☐ To edit the cover sheet, click [Cover Sheet...]. See p.118 "Editing Fax Cover Sheets".

Previewing fax images

Selecting the [Preview] check box allows you to check how the fax document will be output at the destination.

Select the [Preview] check box, and then click [Print] or [Send].

The [Preview] window appears.

2 Check the image, and then click [OK].

𝚱 Note

☐ To cancel printing or sending, click [Cancel].

Images on the Preview window are not exactly the same as images to be output.

Specifying options

You can specify the following options:

For details, see Help.

- Sending at a Specific Time
- User Code
- User ID
- Print Fax Header
- Document Server

- 1 Click [Option...].
- 2 Specify options you want to use.
 - To send the fax document at a specific time:

Select the [Sending at Specific Time] check box, and then specify a transmission time.

To send with a user code:

Enter a user code into the **[User Code]** field.

To distinguish fax documents for each user:

Enter a user ID into the [User ID:] field. Use this option when checking the job history using SmartNetMonitor for Client.

To have the header printed on the fax document:

Select the [Print Fax Header] check box.

To store the fax document on the Document Server:

Select the [Send to Document Server] check box, and then enter a user name, file name, and password.

- ☐ The user code you specified for this machine must be the same as the one entered in this machine. See "Registering a New User Code", General Settings Guide.
- ☐ If [Hard Disk Unit] has not been selected in the [Accessories] window, you cannot perform selection for "Document Server". See p.111 "Setting LAN-Fax Properties".
- Click [OK].

Transmission result notification

After you have sent faxes, this function informs you whether the fax was successfully transmitted to its destination or not.

When you store documents in the Document Server or use this machine just as a printer, this function also informs you whether data was successfully transmitted to this machine or not.

Ø Note

- ☐ You cannot receive notification when using SmartNetMonitor for Client version 5.0 or earlier.
- Transmission results are informed only when connected with a network using SmartNetMonitor for Client.

Managing transmission using LAN-Fax Driver

From "SmartNetMonitor for Admin", "SmartNetMonitor for Client", or a Web browser, you can manage transmissions using LAN-Fax Driver. You can view the following information on transmitted files using LAN-Fax Driver.

- User ID
- Status
- Number of pages
- Start time
- File No.

For details, see Help.

Printing and Saving

You can print documents created using Windows applications.

You can also save documents in TIF format.

Open the application document you want to print or create a new document, and then perform the following procedure.

For details, see Help.

Note

- ☐ You can select whether to cause the machine to automatically restart printing when problems such as paper running-out or paper jams are resolved. The machine may not allow LAN-Fax Driver to send documents until it finishes reprinting. See p.161 "User Parameters" (switch 20, bit 1).
- ☐ You can select the time delay after problems are resolved until the machine restarts printing. See p.161 "User Parameters" (switch 20, bit 2/3/4/5).
- 1 On the [File] menu, click [Print...].
- Select [LAN-Fax M3] in [Printer Name], and then click [OK].

The [LAN-Fax] dialog box appears.



☐ The setting method may differ depending on the application you are using. In all cases, select **[LAN-Fax M3]** for the printer.

Printing

1 Click [Print].

Specifying Two-Sided Printing

- Selecting the [Duplex printing] check box.
- 2 Click [Print].

Saving as Files

You can save the fax document in TIF format.

- 1 Select the [Save as file] check box.
- 2 Click [Save to...].
- 3 Select a folder on the folder tree.
- 4 Select a file naming method.

Note

- ☐ To manually enter a file name, select the [Specify file name when saving] check box.

 To have the program itself name the file, select the [Automatically create a new file] check box.
- 6 Click [OK].
- 6 Click [Save].

If you have selected [Automatically create a new file], the image file is assigned a name and saved under the specified folder. The file name will be RicHH-MMSS.tif (HH: hours, MM: minutes, SS: seconds).

Tenter a file name.

Note

- ☐ You can also change the folder in this step.
- 8 Click [Save].

The image file is saved in the specified folder.

Editing Address Book

You can program and edit destinations in the address list using the Address Book.

For details, see Help.

On the [Start] menu, point to [Programs], [LAN-Fax Utilities], and then click [Address Book].

The Address Book display appears.

Note

- ☐ If LAN-Fax Driver has already started up, click [Address Book...].
- 2 Click [New/Browse], and then select the CSV file containing the address list to be edited.
- Edit an existing destination or program a new one.

Note

- ☐ You can use files created in CSV format, as Address Book data. For this purpose, create CSV files that conform to a certain format. For more information, see Help.
- ☐ You can register the Address Book data of this machine in the LAN-Fax's Address Book.

Programming new destinations

• Enter the destination and name.

- ☐ For **[Line:**], select the appropriate line type; G3, G3-2, or G3-3, G3 Dir. Auto, G3 PABX Auto. Do not select G3-3, G4, and I-G3, which is unavailable on this machine.
- 2 Click [Add].

Editing programmed destinations

• Select the destination you want to edit in the list.

The company name should appear in gray.

- 2 Edit the data.
- 3 Click [Update].

Deleting programmed destinations

1 Select the destination you want to edit in the list.

The company name should appear in gray.

- 2 Click [Delete].
- 3 Click [Yes].
- 4 Click [Close].
- If you made changes to a destination, a confirmation message appears. To save the changes, click [Yes].

If you do not want to save the changes and want to quit editing, click [No].

To return to the editing display, click [Cancel].

𝚱 Note

☐ The confirmation dialog box does not appear when you have not made any changes after starting Address Book.

Using the machine's Address Book data as the LAN-Fax's Address Book data

You can retrieve the Address Book data of this machine using SmartNet-Monitor for Admin and edit it to register in the LAN-Fax's Address Book.

For more information, see Help on SmartNetMonitor for Admin.

Managing the facsimile functions using SmartNetMonitor for Admin

Using SmartNetMonitor for Admin, you can check information about the machine's facsimile functions and save the information on the computer.

SmartNetMonitor for Admin provides the following management functions:

Using [Address Management Tool], you can check the information about destinations programmed on the machine and change the fax numbers and names of these destinations. You can also register a new destination.

Using [Address Management Tool], you can retrieve destinations programmed on the machine and save them on the computer as CSV files. You can then export the saved CSV files to the Address Book of LAN-Fax Driver using the Address Book application.

- ☐ For the method of installing Smart-NetMonitor for Admin, see the *Printer Reference 1*.
- For detailed operations, see Network Guide and Help on SmartNet-Monitor for Admin.

Editing Fax Cover Sheets

LAN-Fax Cover Sheet Editor allows you to edit the format for fax cover sheets. It is necessary to create a cover sheet file before attaching a cover sheet to fax messages using LAN-Fax Driver.

Creating a cover sheet

Use the following procedure to create a fax cover sheet.

You can edit the items below using LAN-Fax Cover Sheet Editor.

- Company name as destination info.
- Department name as destination info.
- Person name as destination info.
- Title of address as destination info.
- Company name as sender info.
- Department name as sender info.
- · Person name as sender info.
- Telephone number as sender info.
- Fax number as sender info.
- Date
- Message

- Cover sheet data is stored in its own format (using "fcp" as its extension)
- On the [Start] menu, point to [Programs], [LAN-Fax Utilities], and then click [LAN-Fax Cover Sheet Editor].

The dialog box of LAN-Fax Cover Sheet Editor appears.

2 Edit the cover sheet.

Note

- ☐ For details about operations, see Help.
- Click [Save as...] on the [File] menu.
- Select a folder, and then enter a file name.
- 5 Click [Save].

Attaching a created cover sheet

Use the following procedure to attach a created cover sheet file to a fax message.

- 1 On the [File] menu, click [Print...].
- 2 Select "LAN-Fax M3" in "Printer Name", and then click [OK].

The [LAN-Fax] dialog box appears.

- Click [Cover Sheet...].

 The [Cover Sheet...] dialog box appears.
- 4 Select a cover sheet file from the drop-down list or after clicking [Browse...] in [Select Cover Sheet].

Note

☐ The selection made in [Select Cover Sheet] is not canceled unless you select another file. If you want to change only destination information, skip this step and proceed to step ⑤.

- **5** Enter the destination information.
 - Note
 - ☐ You can select [Use Address Book], [To Whom It May Concern], [Edit Names], or [None]. Selecting [Edit Names] allows you to enter company, department, and person names.
- To print the date, select the [With a Date] check box.

- **7** Enter the sender information.

 - You can enter company, department, and person names, and telephone and fax numbers.
 - ☐ To add a message, select the [With a Message] check box, and then enter a message.
- 8 Click [OK].
- 9 Specify a destination.
- Select the [Attach a Cover Sheet] check box.
- 11 Click [Send].

LAN-Fax Operation Messages

☐ You can have the LAN-Fax Error Report printed when options are not properly selected, or there is a communication error with a computer. See p.161 "User Parameters" (switch 20, bit 0).

| Message | Causes and Solutions |
|--|---|
| Cannot access the printer. Click [retry] to send the data again. | Check the network connection. Check that the power is turned on. |
| The number of entries in Destinations exceed the limits. Up to 500 entries can be entered. | The number of destinations specified exceeds the maximum possible. The maximum number of destinations that can be specified at one time is 500. |
| "LAN-Fax" has already been launched. Cannot launch it again. | The [LAN-Fax] dialog box is already open. Quit LAN-Fax once, and then start it up again. |
| Failed to allocate memory. | Available memory on the computer is insufficient. Quit applications currently not in use. |

This report is printed when options are not properly selected, or a communication error with a computer occurs. Check the error message of the report.

If you entered a user code in the **[Options]** dialog box, this report can be sent to you by e-mail, provided your e-mail address is programmed in the machine. However, if User Code Management is on for fax, the report is not sent.

Note

☐ You can select whether or not a LAN-Fax Error Report is printed. See p.161 "User Parameters" (switch 20, bit 0).

Error Messages

Check the error report, and then try again.

LAN-Fax Result by E-mail

If you entered a user code in the **[Options]** dialog box, the result can be sent to you by e-mail, provided your e-mail address is programmed in the machine.

Note

☐ You can select whether or not a LAN-Fax Result is sent to the specified e-mail address. See p.161 "User Parameters" (switch 20, bit 7). If the message failed to be sent to one or more of the specified destinations, the result is sent regardless of this setting.

6

Viewing Fax Information Using a Web Browser

You can view received fax messages and their lists or print these messages using a Web browser on a network computer.

- ☐ You need to select "Store" as the "Reception File Setting" in the Facsimile Features menu. See p.186 "Storing or Printing Received Documents".
- ☐ You can also check and manage the documents using DeskTop-Binder V2 Lite. See p.137 "Managing Documents Saved in the Document Server from a Computer".

"Configuring the Network Interface Board Using a Web Browser",
Network Guide

Viewing, Printing, and Deleting Received Fax Messages Using a Web Browser

Use the following procedure to view and/or print received fax messages using a Web browser.

Viewing received fax messages using a Web browser

- 1 Start a Web browser.
- 2 Enter the machine's IP address in the [Address] field.
- Click [Fax Received File].

With a user code (stored reception file) programmed

If you have programmed a user code, enter the code, and then press [OK].

A list of the received fax messages appears.

Note

☐ If the programmed user code has been deleted using the Address Book Management function under System Settings, a message indicating incorrect user code entry appears. If this is the case, reprogram a user code. See p.188 "Setting a User Code for Viewing Received and Stored Documents".

4 Click the Property icon of the desired fax message.

Information such as reception dates, senders, line types, number of pages, and file numbers appear in addition to preview images.

Note

- ☐ To view a list of the fax messages, select the thumbnail display, detail display, or icon display. Click [Thumbnails], [Details], or [Icons].
- 5 View the content of the fax message.

Note

- ☐ To enlarge the preview image, click [Enlarge Image]. Enlargement cannot be performed without Acrobat Reader installed. For more information, see Help on the Web browser.
- To download the received fax message, click [PDF] or [Multi-page TIFF].

Clicking **[PDF]** causes Acrobat Reader to be started and the message to be displayed.

Clicking [Multi-page TIFF] causes a downloading confirmation window to appear.

∅ Note

☐ The method for downloading differs depending on the selected format. For more information, see Help on the Web browser.

Printing fax information using a Web browser

- 1 Start a Web browser.
- 2 Enter the machine's IP address in the [Address] field.
- 3 Click [Fax Received File].

The list of received fax messages appears.

4 Click and select the check box beside the fax message to be printed.

- ☐ To view a list of the fax messages, select the thumbnail display, detail display, or icon display. Click [Thumbnails], [Details], or [lcons].
- 5 Click [Print].
- 6 Click [Start Print].

Note

- ☐ To cancel printing, press [Cancel] before clicking [Start Print].
- ☐ You can change the printing order of selected multiple messages. You can also have messages printed on both sides of paper. For more information, see Help on the Web browser.

7 Click [0K].

The display returns to that of step **4**.

Deleting fax information using a Web browser

- 1 Start a Web browser.
- 2 Enter the machine's IP address in the [Address] field.
- Click [Fax Received File].

The list of received fax messages appears.

4 Click and check the check box beside the fax message to be deleted.

𝚱 Note

- ☐ To view a list of the fax messages, select the thumbnail display, detail display, or icon display. Click [Thumbnails], [Details], or [Icons].
- 5 Click [Delete].
- 6 Click [Delete File].

𝒜 Note

- ☐ To cancel deletion, press [Cancel] before clicking [Delete File].
- ☐ After selecting multiple messages, you can also cancel deletion of some of the selected messages. For more information, see Help on the Webbrowser.

7 Click [OK].

The display returns to that of step **3**.

6

Viewing Received Messages on a Computer

ScanRouter V2 Professional (sold separately) is also required as a delivery server. DesktopBinder V2 Professional Lite or DesktopBinder V2 Professional software (both sold separately) must be installed on your computer.

Delivering Received Messages

Messages received by the machine can be viewed on or downloaded to a computer with the network delivery server, ScanRouter V2 Professional. This is a useful function, enabling you to view and store messages on your computer without printing them.

Using the delivery server, you can eliminate the task of retrieving and delivering messages.

Functions

Delivery server provides the following functions:

- Use the delivery server to associate incoming messages (Confidential ID, SUB Code, Own Name, and Own Fax Number) with receivers, so messages are delivered to the intended receivers.
- You can select the delivery method for incoming messages: "Save in the delivery server inbox," "Send as an e-mail attachment," or "Save in the designated PC folder." Incoming messages with no Confidential ID, ID Override Confidential Transmission, SUB Code, Own Name, or Own Fax Number are saved in the delivery server inbox. You can also set so that the received messages are stored in the specified delivery server inbox according to the used line for reception.

 You can check or download received messages stored in the delivery server inbox using DesktopBinder V2 Professional Lite or DesktopBinder V2 Professional.

Limitation

 Confidential messages are also forwarded to the delivery server.

- ☐ To view or download messages stored in the delivery server inbox, you need to install the separately sold DesktopBinder V2 Professional Lite or DesktopBinder V2 Professional on your computer.
- ☐ To send received messages to your computer as e-mail attachments, you need to have a ScanRouter V2 Professional-compatible e-mail program on your computer.
- ☐ To create a network using the delivery server, settings must be specified in the User Tools of the machine. Settings must also be specified on the delivery server. See "Settings You Can Change with User Tools File Transfer", General Settings Guide.

- ☐ See ScanRouter V2 Professional Help or instructions for more information on the delivery server (ScanRouter V2 Professional).
- ☐ For information about DesktopBinder V2 Lite/Professional, see DesktopBinder V2 Lite/Professional Help or instructions.

7. Simplifying the Operation

Programs

If you regularly send messages to a particular destination or transmit using the same functions, you can save repetitive keypad operations by registering this information in a Keystroke Program.

Registering and Changing Keystroke Programs

Keystroke Programs can be recalled by just pressing a Quick Dial key. The following procedure can be used to program a new Keystroke Program or overwrite an old one.

You can register the following items in Keystroke Programs:

- Memory Transmission, Internet Fax transmission, Difference size originals, Immediate Transmission, destinations (up to 500 numbers), resolution, original type, G3 communication mode, Stamp, Send Later, Default ID, Auto Image Density, Manual Image Density, Scan Area, Auto Document, Book Fax, Polling Transmission, Polling Reception, Transfer Request, two-sided transmission, entering text, reception confirmation settings, and BCC transmission settings, optional functions
- Program name (up to 20 characters)

Note

- ☐ The maximum number of programs you can register is 100 (200 with the optional fax function upgrade unit).
- Use the same procedure to register and change programs. Follow the procedure for the items you want to change.
- ☐ The method of registering or changing programs for the copy function is different from that of the fax function.
- ☐ You cannot register the following using program No. 1.:
 - · Any destination
 - Polling Transmission
 - User Transmission
 - Store File
 - Specifying a stored file
 - Enter Subject of Mail Options
- 1 Make sure that the machine is in facsimile mode and the standby display is shown.

∅ Note

- ☐ If the standby display is not shown, press the [Facsimile] key.
- 2 Prepare for registering the program.

- ☐ The procedure for programming differs depending on the items you want to register.
- ☐ Press the **[Clear Modes]** key to cancel programming.

Example of registering a program using Send Later with the fax number "0123456789"

- Press [0], [1], [2], [3], [4], [5], [6], [7], [8], [9] using the number keys.
- Perform the Send Later setting till the procedure of pressing [OK] to return to the standby mode.

p.3 "Sending at a Specific Time (Send Later)"

3 Press the [Program] key.



Make sure that [Register] is selected.



Select a program number in which "*Not Programed" is shown.



- If you make a mistake, press [Cancel] and select a program number again.
- □ When you change a Keystroke Program, press [Register] after pressing the program number you want to change. If you make a mistake, press [Do not Register] and return to step [].

Enter the program name, and then press [OK].

The standby display appears.

𝒯 Note

- ☐ If you make a mistake, press [Backspace] or [Delete All], and then try again.
- ☐ You should register the program name.
- ☐ To cancel a programmed program, press [Cancel]. The display returns to that of step **5**.

₽ Reference

"Entering Text", General Settings Guide

Registering a priority function using a program

You can select whether or not the function registered in program No. 1 will be set after the power is turned on or the **[Clear Modes]** key is pressed.

After registering a function in program No. 1, select [Program No.1] for [Change Initial Mode] on the Facsimile Features menu. See p.144 "General Settings/Adjustment".

7

Changing a program name

- 1 Make sure that the machine is in facsimile mode and the standby display is shown.
 - Note
 - ☐ If the standby display is not shown, press the **[Facsimile]** key.
- 2 Press the [Program] key.



Press [Change Name].



4 Select the program number of the name you want to change.



- Enter a new program name, and then press [OK].
 - Note
 - ☐ Press **[Cancel]** to cancel the change, and proceed to step **6**.
- 6 Press [Exit].


The standby display appears.

Deleting a Program

- Make sure that the machine is in facsimile mode and the standby display is shown.
 - Note
 - ☐ If the standby display is not shown, press the **[Facsimile]** key.
- 2 Press the [Program] key.



3 Press [Delete].



4 Select the program number you want to delete.



- Press [Yes].
 - Ø Note
 - ☐ Press [No] not to delete the program. The display returns to that of step [3].
- 6 Press [Exit].

The standby display appears.

Using a Program

- Note
- ☐ Using the program causes the previous settings to be cleared.
- Make sure that the machine is in facsimile mode and the standby display is shown.
 - Note
 - ☐ If the standby display is not shown, press the **[Facsimile]** key.
- **2** Place the original.
 - **𝒯** Note
 - ☐ If you have no programmed destinations or scan settings as programs, enter the fax number of the destination and select the scan settings you require.
- 3 Press the [Program] key.



4 Select the program number you registered.



The standby display appears.

Then, the programmed fax number is shown. Transmission Mode is selected.

Press the [Start] key.

The fax number and specified time are shown on the display, and the machine starts to scan the original.

The registered program will start.

7

Using the Document Server

The Document Server can store documents from various applications.

The documents that are stored using the facsimile function are available to transmit by facsimile.

Storing in the Document Server enables the following:

- Once stored, a document can be sent out as many times as you want, just by selecting it.
- Storing a document does not use facsimile memory.

You can send and print multiple stored documents as a single document, and also send them with scanned originals at the same time. Follow the instructions under [Select Stored File] in [Sub TX Mode] when sending or printing stored documents. See p.67 "Sending a Stored File".

"What You Can Do with This Machine", General Settings Guide

#Important

☐ Data stored in the machine might be lost if some kind of failure occurs. The manufacturer shall not be responsible for any damage that might result from the loss of data.

Note

☐ Stored documents are not deleted even when there is a power failure, or the main power switch is turned off.

- ☐ You can specify whether or not the machine automatically deletes documents from the Document Server after a certain number of days. The delete function is preconfigured with the software and automatically deletes any stored document that is more than three days (72 hours) old. You can change the setting with "Auto Delete File" under "Key Operator Tools". See "Key Operator Tools Auto Delete File", General Settings Guide.
- ☐ You can store approximately 9,000 pages (ITU-T No.4 chart) in the Document Server, using the copy, facsimile, printer, and scanner functions.
- ☐ The Document Server (Copier, Facsimile (except for storing received document), Printer, and Scanner functions in total) has a memory capacity of approximately 2,000 documents.
- ☐ You can store up to 1,000 pages per document.
- ☐ You cannot check received and stored documents through the Document Server. See p.34 "Printing Received and Stored Documents".

Storing a Document

You can store and send a document at the same time. You can also just store a document.

File names

Scanned documents are automatically assigned names like "FAX0001" or "FAX0002". See p.133 "Setting a file name".

User Names

You can set this function if necessary to know who and what departments stored documents in the machine. See p.133 "Programming a user name".

Password

You can set this function so as not to send to unspecified people. See p.133 "Setting a password".

Note


- ☐ You can change file names and user names. See p.134 "Changing Information of Stored Documents".
- 1 Make sure that the machine is in facsimile mode and the standby display is shown.

If the standby display is not shown, press the **[Facsimile]** key.

Place the original, and then select the scan settings you require.


p.13 "Placing Originals", Facsimile Reference <Basic Features>

Press [Store File].



4 Select [Store & Transmit] or [Store only].


Select [Store & Transmit] to send documents after they are stored.



Select [Store only] to store documents.

When [Store only] is selected, "XXXXXXXXX" is shown.

Press [File Info. Setting], and then set the user name, file name, and password as necessary.




Note

- ☐ If you are not setting a user name, file name, or password, proceed to step **⑤**.
- ☐ You cannot change multiple documents at once.


Programming a user name

Note

- ☐ Set a user name from those programmed in the user code. User code is programmed in System Settings. See "Registering a New User Code", General Settings Guide.
- 1 Press [User Name].



2 Press the user name to be programmed, and then press [OK].



Note


- ☐ Press the title key to switch between titles.
- ☐ To set an non-programmed user name, press [Non-programmed Name], and then enter the name. User names entered by pressing [Non-programmed Name] are not programmed into the user code.

"Entering Text", General Settings Guide

3 Press [OK].

Setting a file name

• Press [File Name].




- 2 Enter the file name, and then press [OK].
 - Reference
 "Entering Text", General Set-
- 3 Press [OK].


Setting a password

tings Guide

1 Press [Password].



Enter a password using the number keys, and then press [*].



Note


- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then reenter your password.
- ☐ You can enter up to four digits.
- 3 Enter the password again, and then press [*].
- 4 Press [OK].
 - Note
 - ☐ Press [Change] to enter a different password.
- 6 Press [OK].
- 6 Press [OK].
- If you have selected [Store & Transmit], specify the receiver.
 - Note
 - ☐ If you have selected [Store only], proceed to step ③.
- 8 Press the [Start] key.

Changing Information of Stored Documents


You can change the file name, user name, and password of stored documents.

To change a stored document, delete the document you no longer need, and then reprogram the new document. See p.136 "Deleting a Stored Document".

- Note
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ☐ and ☐. See p.145 "Quick Operation Key".
- 1 Press [Sub TX Mode].




- 2 Select [Select Stored File].
- Select [Manage/Delete File], and then press the document to be changed.




If you select a document for which a password is set, enter the password, and then press [OK].

When a selected file does not have a password, proceed to step **5**.




5 Change the desired information of the stored document.



Changing a user name

- Press [Change User Name].
- 2 Press [Clear].

The user name is deleted.



- **3** Enter the new user name, and then press [OK].
 - Note
 - ☐ Press the title keys to switch between titles.
 - ☐ To set a non-programmed user name, press [Non-programmed Name], and then enter the name.
 - ☐ User names entered by pressing [Non-programmed Name] are not programmed into the user code.
 - **₽** Reference

"Entering Text", General Settings Guide

Changing the file name

- 1 Press [Change File Name].
- 2 Press [Backspace] or [Delete All], and then re-enter the file name.



₽ Reference

"Entering Text" General Settings Guide

3 Press [OK].

Changing the password

- Press [Change Password].
- 2 Press upper [Change].

3 Enter a new password using the number keys, and then press [#].



- 4 Press lower [Change].
- 6 Enter the password again, and then press [#].
- 6 Press [OK].
- 6 Press [Exit].
- 7 Press [OK].


The standby display appears.

Deleting a Stored Document

Use this function to delete stored documents.

Note

- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps 1 and 2. See p.145 "Quick Operation Key".
- 1 Press [Sub TX Mode].




2 Press [Select Stored File].

3 Press [Manage/Delete File].



4 Select the document you want to delete.



- ☐ You can also delete multiple documents at once.

With a programmed password

1 Enter a password using the number keys, and then press [OK].



- Press [Delete File].
- 6 Press [Delete].
 - Note
 - ☐ If you do not want to delete the document, press [Do not Delete].

7 Press [Exit].

8 Press [OK].

The standby display appears.

Managing Documents Saved in the Document Server from a Computer

Using DesktopBinder

Fax documents saved in the Document Server can be viewed and controlled from a network computer with DesktopBinder V2 Lite or DesktopBinder V2 Professional installed.

The following operations are available using the computer:

- Displaying documents (Easy Viewer)
- Displaying document properties (Properties)
- Deleting documents (Delete)
- Copying documents to a computer (Copy)
- Printing documents (Print from Document Server)
- Exporting documents as files (Export Document)

For more information, see Desktop-Binder V2 operating instructions and Help.

Note

Settings made in System Settings enable you to send documents to the delivery server. See "Setting up the Machine on a Network", Network Guide.

Using a Web browser

Fax documents saved in the Document Server can be viewed using a Web browser on a network computer. These fax documents can also be downloaded to the computer's hard disk. See p.121 "Viewing Fax Information Using a Web Browser".

8. Facsimile Features

Function List

The User Tools allow you to program your identification, store frequently used numbers and settings, and customize default settings to meet your needs.

The User Tools are grouped by functions so that you can quickly and easily find the desired User Tool.

General Settings /Adjustment

| Description | Reference |
|---|---|
| Default Transmission Mode and scan settings. When the power is turned on, settings specified here are selected: | p.144 "General Settings/Adjustment" |
| Memory/Immediate Transmission Switch | |
| Text Size Priority | |
| Original Type Priority | |
| Auto Image Density | |
| Adjust Scan Density | |
| Select Title | |
| Change Initial Mode | |
| Adjust Sound Volume | p.73 "Adjusting the Volume", Facsimile Reference <basic features=""></basic> |
| Program Fax Information | p.65 "Initial Settings and Adjustments", Fac- simile Reference < Basic Features> |
| Scan End Reset | |
| Transmission Stamp Priority | |
| Line Priority Setting | |
| Program Economy Time | |
| On Hook Mode Release Time | |
| Quick Operation key | |

❖ Reception Settings

| Description | Reference | | |
|---|--|--|--|
| Allows you to switch the following reception functions on or off: | p.146 "Reception Settings" | | |
| Switch Reception Mode | | | |
| Authorized Reception | p.169 "Authorized RX (Authorized Reception)" | | |
| Forwarding | p.169 "Forwarding" | | |
| Reception File Print Quantity | p.169 "Reception File Print Qty" | | |
| Two-Sided Print | p.97 "Two-Sided Printing" | | |
| Reception Reverse Printing | p.100 "Reverse Order Printing" | | |
| Paper Tray | p.170 "Paper Tray" | | |
| Specify Tray for Lines | p.105 "Specifying Tray for Lines" | | |
| Checkered Mark | p.96 "Checkered Mark" | | |
| Center Mark | p.96 "Centre Mark" | | |
| Print Reception Time | p.97 "Reception Time" | | |

◆ E-mail Settings

| Description | Reference |
|---------------------------------------|-------------------------|
| Internet Fax Settings | p.147 "E-mail Settings" |
| Maximum E-mail Size | |
| SMTP Reception File Delivery Settings | |

8

Key Operator Tools

| Description | Reference |
|-------------------------------------|------------------------------|
| Program/Change/Delete Standard Mes- | p.149 "Key Operator Setting" |
| sage | |
| Store/Change/Delete Auto Document | |
| Program/Change/Delete Scan Size | |
| Print Journal | |
| Transmission Page Count | |
| Forwarding | |
| Memory Lock Reception | |
| • ECM | |
| Parameter Setting | |
| Program Special Sender | |
| Box Setting | |
| Transfer Report | |
| Program Confidential ID | |
| Program Polling ID | |
| Program Memory Lock ID | |
| Select Dial/Push Phone | |
| Reception File Setting | |


Displays

- Each menu appears in each tab.
- You can switch the display by pressing [▲ Prev.] or [▼ Next].
- The selected item is highlighted.
- When you have made all required settings, press [OK]. If [OK] is not pressed, the new settings might be canceled.
- Press [Cancel] to cancel the new settings. The previous display appears.

When Key Operator Code is programmed and turned on, users have to enter a programmed Key Operator Code (eight digits maximum) to operate the User Tools. This prevents unauthorized people from changing settings.

Note

- ☐ You can turn the Key Operator Code on or off in "User Tools Menu (System Settings)". See "Key Operator Tools", *General Settings Guide*.
- ☐ When you set the Key Operator Code to active, enter a code (eight digits maximum) using the number keys and select [Partial] or [All Initial Settings] to limit access.
 - When [Partial] is selected:
 Only Key Operator Tools are protected with a Key Operator Code.
 - When [All Initial Settings] is selected:
 Key Operator Tools and User Tools are protected with a Key Operator Code.
- ① Press the **[User Tools/Counter]** key.
- ② Press [Facsimile Features].
 If you have selected [All Initial Settings], proceed to step ④.
- ③ Press [Key Operator Tools].
- Enter a Key Operator Code (eight digits maximum) using the number keys.



⑤ Press [OK].



☐ If you enter a Key Operator Code not programmed, the display will return to that of step ④.

R

Accessing User Tools (Facsimile Features)

Customize the facsimile settings according to the operations to be frequently performed.

- ☐ The machine allows you to change the facsimile defaults in a mode that is not the facsimile mode. After changing the defaults, select facsimile mode again. This section describes the facsimile defaults that the machine allows you to customize.
- ☐ Customized facsimile defaults are kept until the defaults are changed again. The new settings are not cancelled by turning off the main power switch or the Operation switch or pressing the 【Clear Modes】 key.

For the items that can be changed using System Settings, see "User Tools (System Settings)". See "User Tools Menu (System Settings)", General Settings Guide.

1 Press the [User Tools/Counter] key.

The main menu display for default settings appears.



Note

☐ With a Key Operator Code programmed, changing the default causes the Key Operator Code entry display to appear. If this happens, enter the programmed code first. For the Key Operator Code, see "Key Operator Tools", General Settings Guide.

2 Press [Facsimile Features].

The menu display for facsimile default settings appears.

Select the item that you want to change.

The corresponding setting display appears.


p.139 "Function List"

- 4 Follow the displayed instructions to change the default, and then press [OK].
 - Ø Note
 - ☐ If you make a mistake, press [Cancel].

Quitting Default Settings

After changing the defaults, press [Exit] on the main menu display for default settings.

The standby display appears.





☐ You can also press the **[User Tools/Counter]** key to quit the main menu display for default settings.

8

General Settings/Adjustment

Memory/Immed. Transmission Switch

Use this function to specify the Transmission Mode for document transmission.

- Memory Transmission
- Immediate Transmission

♦ Text Size Priority

Use this function to specify the character size of your originals for scanning.

- Standard
- Detail
- Super Fine (expansion memory required)

Original Type Priority

Use this function to specify the type of originals for scanning.

- Text
- Text/Photo
- Photo

Auto Image Density

Use this function to prioritize automatic Image Density for scanning your originals.

- ON
- OFF

Adjust Scan Density

Use this function to specify the scan density of your originals.

Select Title

Use this function for selecting the title to be shown on the destination list.

- Title 1
- Title 2
- Title 3

Change Initial Mode

Use this function to select whether contents registered in program No.1 are to be used as the initial settings after the power is turned on or the [Clear Modes] key is pressed:

- Standard
- Program No.1



You cannot select Program No.1 if program No.1 has not been programmed with priority functions.

Adjust Sound Volume

See p.73 "Adjusting the Volume", Facsimile Reference < Basic Features>.

- On Hook Mode
- At Transmission
- At Reception
- At Dialing
- At Printing

Program Fax Information

See p.65 "Initial Settings and Adjustments", Facsimile Reference < Basic Features>.

- Fax Header
- Own Name
- Own Fax Number

Scan End Reset

Use this function to return to the initial settings each time an original is scanned.

- ON
- OFF

◆ TX Stamp Priority

Use this function to press a TX stamp.

- ON
- OFF

Line Priority Setting

Use this function to specify the line of usage.

Note

☐ The display may differ depending on the line type you have.

Program Economy Time

Use this function for specifying a time for transmission when call charges are low. See p.3 "Sending at a Specific Time (Send Later)".

Limitation

☐ You can program only one Economy Time.

Note

☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.

On Hook Mode Release Time

Use this function to specify a time to cancel On Hook mode after you transmit using On Hook dialing.

- 1 minute
- 3 minutes
- 5 minutes
- 10 minutes

Quick Operation Key


Frequently used functions programmed as Quick Operation keys are shown on the menu immediately after the power is turned on. The Quick Operation keys can be programmed with the following functions:

- Journal
- TX File Status (Transmission File Status)
- Print Conf. RX (Print Confidential Reception)
- Print Memory Lock

- Stored File
- Send Later
- Auto Document
- · 2 Sided Original
- Closed Network
- Polling TX (Polling Transmission)
- Polling RX (Polling Reception)
- Fax Header Print
- Label Insertion
- RX File Status (Reception File Status)
- Forwarding
- Transfer Request
- Switch RX Mode (Reception Mode Switch)
- Manual E-mail RX (Manual E-mail Reception)
- TX Status Report (Transmission Status Report)
- User TX (User Transmission)
- E-mail TX Results (E-mail Transmission Results)

Up to three functions can be programmed into a Quick Operation keys.

- Select Quick Operation key you want to program.
- 2 Select the function you want to program in the Quick Operation key.





☐ Functions that appear dimmed have already been set.

R

Reception Settings

Switch Reception Mode

Specify the method for receiving fax messages.

- · Manual Reception
- · Auto Reception

Authorized RX (Authorized Reception)

Specify whether or not unwanted fax messages are to be screened out.

- ON
- OFF

Forwarding

Specify whether or not received fax messages are to be forwarded to a programmed receiver.

- ON
- OFF

RX File Print Qty (Reception File Print Quantity)

Specify the number of copies to be printed for each fax message received.

• 1 to 10 set(s)

2 Sided Print

Specify whether or not received fax messages are to be printed on both sides of paper.

- ON
- OFF

RX Reverse Printing (Reception Reverse Printing)

Specify whether or not received fax messages are to be printed from the last page received.

- ON
- OFF

Paper Tray

Use this function to print fax messages received from programmed senders and fax messages from other senders, using different paper trays.


Display of tray names may differ depending on the options installed

- Tray 1
- Tray 2
- Tray 3 (option)
- Tray 4 (option)
- Auto Select
- LCT (option)

Specify Tray for Lines


Specify a paper tray for each line (telephone/LAN).

- OFF
- ON
- ① Select [ON] to select a paper tray.






- ☐ If you select **[0FF]**, the received fax is delivered to a default tray.
- ② Select the line type.



③ Select a tray to deliver the received paper onto, and then press [OK].



☐ If you want to specify another line type, repeat from step ②.

Checkered Mark

Specify whether or not a checkered mark is to be printed on the first page of received fax messages.

- ON
- OFF

Center Mark

Specify whether or not a centre mark is to be printed halfway down the left side and at the top centre of each page received.

- ON
- OFF

Print Reception Time

Specify whether or not received date and time are to be printed at the bottom of received fax messages.

- ON
- OFF

E-mail Settings

Internet Fax Settings

You can select to display or not. When you want to send an Internet Fax, set ON to display the icon.

- ON
- OFF

Max. E-mail Size


Make this setting when you want to limit the size of e-mail messages that are transmitted, if receivers limit e-mail size, or you cannot send large size e-mail for some reason. When this function is set to on, transmission of e-mail that exceeds the set size is aborted.

- ON
- OFF

- When e-mail exceeds the maximum file size, an Error Report is output, and the e-mail is deleted.
- Even when e-mail does not exceed the size limit, it may be rejected if it does not meet the requirements of the server settings.
- ① Press [ON].



② Enter the maximum e-mail size using the number keys.



Note

- ☐ Maximum e-mail size can be between 64 and 102400 KB.
- ☐ If you make a mistake, press [Cancel] or the [Clear/Stop] key, and then enter again.
- ③ Press [OK].
- SMTP RX File Delivery Settings (SMTP Reception File Delivery Settings)

This function is available on systems that allow routing of e-mail received via SMTP. See p.94 "Routing E-mail Received via SMTP".

- On
- Off

When an authorized e-mail address is set, e-mail received from addresses that do not match the authorized address is discarded, and an error message is returned to the SMTP server.

The authorized e-mail address is compared with the addresses of email originators, as illustrated by the following examples.

When the authorized e-mail address is set to "@aaa.abcd.com": abc@aaa.abcd.com - accepted def@aaa.xyz.com - not accepted abc@abcd.com - not accepted

☐ No Error Report is output even when e-mail is discarded.

① Press [On].



② Press [Change], and then enter the sending e-mail address with transmission permission.



- ☐ If you make a mistake, press [Backspace] or [Delete All], and then enter again.
- ③ Press [OK] twice.

9. Key Operator Setting

Key Operator Tools List

You can program, change, or delete standard messages and auto documents. You can also set the line type for the machine connection, program various IDs (including a Polling ID), fax destinations, and many other items. In addition, you can check the number of documents transmitted and received.

| Function name | Description | Reference | | |
|---|--|---|--|--|
| Program/Change/Delete Standard Message | You can program, change, or delete standard messages printed at the top of the first page of each incoming message. | p.151 "Programming, Chang- ing, and Deleting Standard Messages" | | |
| Store/Change/Delete Auto Document | You can program, change, or delete pages stored as auto documents. | p.151 "Programming, Changing, and Deleting Standard Messages" | | |
| Program/Change/Delete Scan Size | You can program, change, or cancel frequently used scan sizes. | p.154 "Programming, Changing and Deleting a Scan Size" | | |
| Print Journal | Prints a Journal. | p.156 "Printing the Journal" | | |
| Transmission Page Count | Checks the transmission and reception, and totals on the display. | p.156 "Counters" | | |
| Forwarding | Transfers received messages to a programmed receiver (forwarding destination). | p.157 "Forwarding" | | |
| Memory Lock RX | Switches the Memory Lock to on or off. To use it, program an ID for printing a message received in Memory Lock mode. | p.159 "Memory Lock" | | |
| ECM | If part of the transmission fails due to a telephone line fault, this function resends the failed part automatically. | p.160 "ECM (Error Correction Mode)" | | |
| Parameter Setting | Allows you to change and print the function settings to meet your needs. | p.161 "User Parameters" | | |
| Program Special Sender | By programming particular receivers as Special Sender in advance, you can have Special Senders treated differently. | p.168 "Programming/ Changing Special Senders" | | |

| Function name | Description | Reference | | |
|----------------------------------|---|---|--|--|
| Box Setting | By using SUB and SEP Codes with these functions, you can send messages to another party's box, and retrieve messages stored in boxes. | p.174 "Box Settings" | | |
| Transfer Report | Before using Transfer Request, you need this Transfer Report setting. | p.183 "Transfer Report" | | |
| Program Confidential ID | Registers an ID required for Confidential communication. | p.184 "Programming a Confidential ID" | | |
| Program Polling ID | Registers an ID required for Polling communication. | p.185 "Programming a Polling ID" | | |
| Program Memory Lock ID | Registers an ID required for Memory Lock reception. | p.185 "Programming a Memory Lock ID" | | |
| Select Dial/Push Phone | Selects a line type when you connect the machine to a G3 analog line. | p.186 "Selecting Dial/Push Phone" | | |
| | ✓ Note☐ This function is not available in some areas. | | | |
| Reception File Setting | Selects whether received doc- uments are saved on the hard disk to be printed later or printed immediately without being saved. | p.186 "Storing or Printing Received Documents" | | |
| Stored RX File User Code Setting | Set the password to view received and stored documents using a Web browser or Desk-TopBinder V2 Lite. | p.188 "Setting a User Code for Viewing Received and Stored Documents" | | |

Using Key Operator Settings

Programming, Changing, and Deleting Standard Messages

Use this function to program standard messages to be printed at the top of the first page of the original. It is useful for personalizing messages such as sending greetings.

- ☐ You can program three standard messages. You cannot change the "Confidential", "Urgent", "Please phone", or "Copy to corres. section" messages.
- ☐ Use the same procedure to program and change your messages.
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Program/Change/Delete Standard Message].

Programming or changing standard messages

• Select the message number key you want to program or change.



- 2 Enter a new message.
 - Reference
 "Entering Text", General Settings Guide
- Press [OK].
 - Ø Note
 - ☐ To program another message, repeat the procedure from step ①.
 - ☐ To cancel a registration, press [Cancel].

Deleting Standard Messages

Press [Delete], and then select the message you want to delete.



2 Press [Delete].

- Note
- ☐ To delete another message, repeat from step **①**.
- ☐ To cancel a deletion, press [Do not Delete]. The display returns to that of step ①.
- 5 Press [Exit].
- Press the [User Tools/Counter] key. The standby display appears.

Storing, Changing, and Deleting an Auto Document

If you often have to send a particular page to people (for example, a map, a standard attachment, or a set of instructions), you can store that page in memory as an Auto Document. This saves rescanning the original every time you want to send it.

Use the following procedure to program a new Auto Document or overwrite an existing one.

You can store the following items in an Auto Document:

- Originals (6 documents maximum; when the optional fax function upgrade unit is installed, 18 documents maximum, only one page per file).
- Scan settings (resolution, original type, and image density)
- Irregular scan area
- Document name (16 characters maximum)

Important

- ☐ When about one hour passes after power of the machine is turned off, all fax messages stored in memory are lost. If any messages have been lost for this reason, a Power Failure Report is automatically printed when the operation switch is turned on. Use this report to identify lost messages.
- Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Store/Change/Delete Auto Document].
- Select and follow the appropriate procedure depending on what you want to perform.



- **∅** Note
- ☐ If there are stored files, the file names are shown.

Storing a file

- Select [*Not Programed].
- 2 Enter a file name, and then press [OK].

₽Reference

"Entering Text", General Settings Guide

Changing a file

• Select the file you want to change.

The "A file is already stored. If another file is stored, previous one will be deleted. Is it OK?" message is shown.

2 Press [Store].

If you want to cancel storing, press [Do not Store].

Changing only a file name

- 1 Press [Change Name].
- Select the file whose name you want to change.
- Enter a file name, and then press [OK].

"Entering Text", General Settings Guide

Proceed to step 3.

6 Place the original, and then select any scan settings you require.



- Note
- ☐ You can also specify a scan size. See p.16 "Setting a Scan Area", Facsimile Reference <Basic Features>.
- **7** Press the [Start] key.

The machine starts to scan and completes scanning.

- **𝒯** Note
- ☐ To cancel scanning, press [Stop Scanning].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Deleting an Auto Document

- ☐ You cannot delete an Auto Document waiting to be transmitted. Delete it after the transmission or cancel the transmission, and then delete the Auto Document.
- 1 Press the [User Tools/Counter] key.



- 3 Press [Key Operator Tools].
- Press [Store/Change/Delete Auto Document].
- Press [Delete], and then select the file you want to delete.



- 6 Press [Delete].
 - Note
 - ☐ To cancel deleting, press [Do not Delete]. The display returns to that of step ⑤.
- 7 Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Programming, Changing and Deleting a Scan Size

When you select a scan size to scan a non-standard size original, two custom sizes are available (Program Size 1 and Program Size 2). Use these functions to program a custom size in advance.

To change an existing scan size, just use the same procedure.

- ∰Important
- When programming or changing a scan size, we recommend you make a record of the new size.
- Note
- ☐ You can program up to two sizes.
- ☐ You can specify a horizontal length from 128 to 1,200 mm, or from 5.5 to 47 inches.
- 1 Press the [User Tools/Counter] key.




- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Program/Change/Delete Scan Size].

9

Select [Program Size 1] or [Program Size 2].




6 Enter a horizontal size using the number keys.



- □ Each time you press [mm] or [inch], the units switch between "mm" and "inch". If you enter a length and change the units by pressing [mm] or [inch], the length is converted automatically according to the unit (fractions are rounded off). For example, when you enter [2], [2], and [0] in millimeters and change to "inch", the length "8.7 inch" is shown on the display. If you press [mm] or [inch] again, "221 mm" is displayed.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then try again.
- ☐ To cancel a scan size, press [Cancel].

Select a vertical size, and then press [OK].



- **∅** Note
- ☐ A displayed vertical size differs depending on the selected unit. When [mm] is selected, [Auto Detect], [210mm (A4)], [257mm (B4 JIS)], [297mm (A3)], [216mm (8 1/2)], and [279mm (11)] are shown. When [inch] is selected, [Auto Detect], [8.3inch (A4)], [10.1inch (B4 JIS)], [11.7inch (A3)], [8.5inch], and [11.0inch] are shown.
- ☐ To cancel a scan size, press [Cancel].
- 8 Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Deleting a scan size

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Program/Change/Delete Scan Size].



- 6 Press [Yes].
 - Note
 - ☐ To cancel deleting, press [No].

 The display returns to that of step ⑤.
- **7** Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Printing the Journal

The Journal allows you to check a maximum of the last 50 communications (receptions & transmissions) performed by the machine. You can print the Journal using the Information menu. See p.27 "Printing the Journal".


Counters

This function allows you to check the total number of pages transmitted and received on the display.

- Transmissions: Total number of transmitted pages
- Receptions: Total number of received pages
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Transmission Page Count].



- 5 After checking the display, press [Exit].
- Press the [User Tools/Counter] key. The standby display appears.

9

Forwarding

This function allows you to have messages printed on the machine, and sent to a specified End Receiver.

This is useful if, for example, you are visiting another office and would like a copy of your messages to be sent to that office.

Preparation

To use this function, set Forwarding under Reception Settings to ON (enable). See p.146 "Reception Settings".

Limitation

- The Forwarding function does not forward messages received with Confidential Reception, Memory Lock, Polling Reception mode, or messages received by Transfer Request.
- ☐ You can select end receivers only from among destinations programmed in the Address Book. You cannot specify programmed transfer stations as end receivers.

Note

- ☐ An e-mail address can be set as the forwarding destination.
- ☐ If you do not program an End Receiver, the machine performs printing but not forwarding even with the Forwarding function On.
- ☐ You can program one of the Quick Operation keys with operations for this function. You can then switch the function on or off merely by pressing the Quick Operation key. The function is on when the Quick Operation key has been highlighted.

- ☐ If you want to change End Receivers separately according to senders, specify End Receivers for each special sender in "Special Senders to Treat Differently". You can program one receiver per Special Sender. Received messages from unspecified senders will be forwarded to the End Receiver specified here. See p.165 "Special Senders to Treat Differently".
- One receiver only can be specified using this function. For multiple receivers, use Group Dial.
- ☐ You can specify whether or not to print forwarded messages. See p.161 "User Parameters" (switch 11, bit 6).
- ☐ Deleting a destination specified as an end receiver from the Address Book causes the settings for the end receiver to be deleted. If this is the case, reprogram the end receiver. If the destination has been changed, a message is transmitted to the new destination.
- You can program one of the Quick Operation keys with operations for this function.


Programming an End Receiver

1 Press the [User Tools/Counter] key.




- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Forwarding].

Press [ON].



Note

- ☐ If there is an End Receiver already programmed, a receiver name is shown. If you want to change the receiver, press [Receiver] and proceed to step [3].
- ☐ To cancel Forwarding, press **[Cancel]** and proceed to step **⑤**.
- 6 Specify an End Receiver using the destination list, and then press [OK].



The receiver name is shown to the right of [Receiver].


- Pressing to switch the destination between fax number and e-mail address.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- **7** Press [OK].
- 8 Press the [User Tools/Counter] key.
 The standby display appears.

Quitting the forwarding function

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Forwarding].
- Press [OFF], and then press [OK].



6 Press the [User Tools/Counter] key. The standby display appears.


C

Forwarding Mark

You can print a Forwarding Mark on the receiver's messages that have been forwarded.

The receiver can distinguish between forwarded messages and usual receptions.

☐ You can specify whether or not to print a Forwarding Mark in the User Parameters. See p.161 "User Parameters" (switch 02, bit 0).



Memory Lock

When you switch Memory Lock on, received messages are stored in memory and not printed automatically. When a message is received in the Memory Lock mode, the Confidential File (Y) indicator blinks. To print this message, enter the Memory Lock ID. A user without the ID cannot print the message. This prevents unauthorized users from seeing the message.

Preparation

To use Memory Lock, program the Memory Lock ID, and then switch Memory Lock on. See p.185 "Programming a Memory Lock ID".

𝒯 Note

- ☐ To store incoming documents from Special Senders only in Memory Lock, program each sender with "Special Senders to Treat Differently". See p.165 "Special Senders to Treat Differently".
- Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Memory Lock RX].
- Select [ON] or [OFF], and then press [OK].



- ☐ To cancel this setting, press [Cancel]. The display returns to that of step 4.
- Press the [User Tools/Counter] key. The standby display appears.

ECM (Error Correction Mode)


If part of a transmission fails because of a line problem, the lost data is automatically resent. For this function to work, the other machine must have ECM. You can turn this function on or off through the following procedure.

Note

- ☐ If you turn ECM off, you cannot use the following functions:
 - IBIG Transmission
 - Super G3 Communication
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [ECM].
- Select [ON] or [OFF], and then press [OK].



- Note
- ☐ To cancel this setting, press [Cancel]. The display returns to that of step 4.
- Press the [User Tools/Counter] key.
 The standby display appears.

Q

User Parameters

User Parameters allow you to customize various settings to suit your needs. To change function settings, set the User Parameter Switches.

Switches and Bits

Each User Parameter has a set of switches, and each of the switches consist of eight bits, whose values are "0" or "1". The right most bit is bit 0 and the left most is bit 7. You can adjust the settings to match your needs by switching the value of bits between "0" and "1".

| : | Switch 02 | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 1 |
|---|-----------|----------|----------|----------|----------|----------|----------|----------|----------|
| | | \ |
| | | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |

User Parameter List

User Parameter Switches are outlined below.

| Switch | Bit | Item | 0 | 1 |
|--------|---|---|-----|----|
| 02 | 02 0 Forwarding Mark | | Off | On |
| • | 3 | TSI Print | Off | On |
| 03 | 03 0 Automatic printing of the Memory Transmission Result Report | | Off | On |
| | 2 | Automatic printing of the Memory Storage Report | Off | On |
| | 3 Automatic printing of the Polling Reception Reserve Report | | Off | On |
| | 4 | Automatic printing of the Polling Reception Result Report | Off | On |
| | 5 Automatic printing of the Im mediate Transmission Result Report | | Off | On |
| | 6 | Automatic printing of the Polling Transmission Clear Report | Off | On |
| | 7 | Automatic printing of the Journal | Off | On |
| 04 | 0 | Automatic printing of the Confidential File Report | Off | On |
| | 7 | Include a portion of the image on reports | Off | On |

| Switch | Bit | Item | 0 | 1 | | |
|--------|------|--|--|--|--|--|
| 05 | 0 | Receive Service Call (SC) Condition (Substitute Reception during service call) | Possible (Substitute RX) | Not possible (Reception off) | | |
| | 2, 1 | per trays have run out of paper of order) 00: Enabled unconditionally (F | Enabled unconditionally (Free) Enabled when Own Name/Own Fax Number is received Enabled for Polling ID match | | | |
| | 5 | Just Size Printing | Off | On | | |
| | 7 | Empty tray alert (Paper Empty Warning) even when one paper tray is empty | Off | On | | |
| 06 | 6 | First page scanned for book originals | From the left page | From the right page | | |
| 07 | 2 | Parallel Memory Transmission | Off | On | | |
| 08 | 2 | Authorized Reception Type | thorized Reception Type Receiving from only specified senders | | | |
| 10 | 1 | Combine two originals | Off | On | | |
| | 3 | Page reduction when printing | Off | On | | |
| 11 | 6 | Local print when forwarding | Off | On | | |
| | 7 | Polling file after sending (Polling transmission standby time) | Delete (Use Once) | Standby (Save) | | |
| 14 | 0 | Print documents received with Auto Power-On Recep- tion (Night Printing mode) | Immediate printing (On) | When turning on the operation switch (Off) | | |
| | 1 | Long Document Transmission (Well Log) | Off | On | | |
| | 2 | Batch Transmission | Off | On | | |
| | 3 | Reset when function changed | Off | On | | |
| | 7 | System Parameter List Transmission | Off | On | | |
| 17 | 2 | Whether you need to press [Add] after entering a Quick Dial/Group Dial when broadcasting | Not necessary | Necessary | | |
| | 7 | Receive messages by pressing the [Start] key when originals are not set. | Off (The machine does not receive messages by pressing the [Start] key.) | On (The machine receives messages by pressing the [Start] key .) | | |

| Switch | Bit | Item | 0 | 1 | |
|--------|------------|--|---|------------------|--|
| 18 | 0 | Print date with Fax Header | Off | On | |
| | 1 | Print transmitter origin with Fax Header | Off | On | |
| | 2 | Print file number with Fax Header | Off | On | |
| | 3 | Print page number with Fax Header | Off | On | |
| 19 | 0 | Use paper delivery shift function (Offset Print) | Off | On | |
| | 1 | Sort Journal by line type | Off | On | |
| 20 | 0 | Automatic printing of the LAN-Fax Error Report | Off | On | |
| | 1 | Reprint documents that could not be printed using LAN-Fax Driver | Off | On | |
| | 5, 4, 3, 2 | Reprinting time of stored documents in memory that could not be printed using LAN-Fax Driver 0000: 0 minute / 0001: 1 minute / 0010: 2 minutes / 0011: 3 minutes / 0100: 4 minutes / 0101: 5 minutes / 0110: 6 minutes / 0111: 7 minutes / 1000: 8 minutes / 1001: 9 minutes / 1010: 10 minutes / 1011: 11 minutes / 1100: 12 minutes / 1101: 13 minutes / 1110: 14 minutes / 1111: 15 minutes | | | |
| | 7 | Notify LAN-Fax Result by E-mail | Off | On | |
| 21 | 0 | Print results of sending Reception Notice Request message | Off (print only when an error occurs) | On | |
| | 1 | Respond to e-mail reception acknowledgment request | Off | On | |
| | 4 | Transmit Journal by E-mail | Off | On | |
| | 6 | Not display Network error | Display (Off) | Not display (On) | |
| | 7 | Transmit Error Mail Notification | On | Off | |
| 24 | 1, 0 | Store a message in memory that could not be transmitted 00: Off, 01: Store for 24 hours, 11: Store for 72 hours | | | |
| 25 | 4 | RDS | Off | On | |
| 32 | 0 | Priority destination for Forwarding Fax Destination E-mail Address | | | |

Preparation


Access to some User Parameter Settings requires installation of optional equipment, or that other settings be made beforehand.

#Important


- ☐ We recommend you print and keep a User Parameter list when you program or change a User Parameter. See p.165 "Printing the User Parameter List".
- ☐ Do not change any bit switches other than those shown on the previous pages.
- Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Parameter Setting].
- 5 Select the switch number you want to change.



6 Select the bit number you want to change.



When the bit number is pressed, the current value switches between 1 and 0.

- ☐ Repeat from step **(1)** to change another bit number for the same switch.
- Press [OK].
 - **∅** Note
 - ☐ To cancel these settings, press [Cancel]. The display returns to that of step **A**.
- 8 Repeat steps 5 and 7 to change the switch settings.
- 9 After all the settings are finished, press [Exit].
- Press the [User Tools/Counter] key. The standby display appears.

Printing the User Parameter List

Print this list to see the current User Parameter settings. However, only items of importance or often-used items are included in the list.

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Print List] next to "Parameter Setting".

 - ☐ To cancel printing a list, press **[Cancel]**. The display returns to that of step **[**].
- 5 Press the [Start] key.
 - **𝚱** Note
 - ☐ To cancel printing a list after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **2**.
- Press the [User Tools/Counter] key. The standby display appears.

Special Senders to Treat Differently

By programming particular receivers in advance, you can set the following function for each receiver:

- Authorized Reception
- Forwarding
- Reception File Print Quantity
- Print 2 Sided
- · Memory Lock
- Reception Reverse Printing
- Paper Tray

Use the Own Name or Own Fax Number to program your receivers. If the receiver has a machine of the same manufacturer, program an Own Name that has already been programmed as a receiver. If the machine is not of the same manufacturer, use Own Fax Number. You can apply the same settings to all programmed numbers. You can then customize the settings for individual numbers as necessary using the Special Sender Registration function.

The following items can be programmed.

- Special Senders (Up to 30. A maximum of 50 when the optional fax function upgrade unit is installed. A maximum of 20 characters for each name when using G3.)
- Full/ Partial agreement
 When you program own names
 and facsimile names for multiple
 destinations, you can program a
 common sequence of characters to
 identify destinations using Partial
 agreement.

y

Using a Full agreement

| Destination to be programmed (Own Name) | Number of programmed identifications | | |
|---|--------------------------------------|--|--|
| NEW YORK BRANCH | 3 | | |
| HONG KONG BRANCH | | | |
| SYDNEY BRANCH | | | |

Using a Partial agreement

| Destination to be programmed (Own Name) | Number of programmed identifications |
|---|--------------------------------------|
| BRANCH | 1 |

Note

- ☐ You can program up to 30 wild cards (50 with the optional fax function upgrade unit).
- ☐ Spaces are ignored when identifications are compared.
- ☐ You can use wild cards for the following functions:
 - See p.168 "Programming/ Changing Special Senders".
 - See p.169 "Authorized RX (Authorized Reception)".
 - See p.169 "Forwarding".
- You cannot use the following functions with Internet Fax receptions.
 - Authorized Reception
 - Reception File Print Quantity
 - Memory Lock
 - Reception Reverse Printing
- ☐ To use the Forwarding, Print 2 Sided, or Paper Tray with Internet Fax receptions, program the e-mail address of the sender.

Limitation

- ☐ You cannot program senders as Special Senders if they do not have Own Name or Own Fax Number programmed.
- ☐ The machine cannot differentiate between Polling Reception and Free Polling documents from Special Senders.

Note

- ☐ You can program up to 24 characters for the sender.
- ☐ You can check Own Name and Own Fax Number using the Journal. You can check programmed Special Senders using the specified sender list. See p.27 "Printing the Journal". See p.173 "Printing the Special Sender List".
- ☐ If you select "OFF" for the Special Sender function in "Initial Set Up", the settings will be the same as the Reception Settings. See p.146 "Reception Settings".

Authorized Reception

Use this function to limit incoming senders. The machine only receives faxes from programmed Special Senders, and therefore, it helps you screen out unwanted messages, such as junk mail, and saves wasting fax paper.

Note

- ☐ To use this function, program the Special Senders function, and then select "ON" in "Authorized RX" with "Reception Settings". See p.146 "Reception Settings". See p.161 "User Parameters" (switch 08, bit 2).
- ☐ Without programming Special Senders, the Authorized RX function will not work, even if you select "ON".

- ☐ You can select to receive only from programmed senders or receive only from senders other than those programmed in User Parameters. See p.161 "User Parameters" (switch 08, bit 2).
- ☐ If you select "OFF" for "Authorized RX" in "Initial Set Up", the settings will be the same as the Reception Mode settings. See p.146 "Reception Settings".
- You can change Special Senders in the same way as you program them.

Forwarding

Use this function to print received messages, and then transfer them to those receivers programmed beforehand.

It is also possible to forward faxes sent only by senders programmed as Special Senders.

∅ Note

- ☐ To use this function, program your Special Senders, and then select "ON" for "Forwarding" in "Reception Settings". See p.146 "Reception Settings".
- ☐ If you specify "ON" in "Forwarding" and select [Same as basic settings], the fax message will be forwarded to the other ends programmed in "Specify End Receiver". See p.157 "Forwarding".
- ☐ If you do not program any Special Senders, the machine transfers all incoming documents to the other end specified in "Specify End Receiver".
- ☐ You can program e-mail address as the receiver.

Reception File Print Quantity

Use this function to print the specified number of copies of documents received from programmed senders (Special Senders). If you do not program any Special Senders, the machine prints the specified number of copies for all received documents.

Limitation

You cannot use multi-copy printing with Polling Reception, Free Polling, Confidential Reception, or Memory Lock.

Note

☐ You can specify up to 10 copies.

Print 2 Sided

Use this function to print on both sides of paper.

Limitation

☐ If you select the bypass tray for "Paper Tray", duplex printing is disabled.

Memory Lock

Use this function to store incoming documents from programmed senders (Special Senders) in memory without printing them. People without the Memory Lock ID cannot print the documents, and therefore this function is useful for receiving confidential documents. If you do not program any senders, the machine receives fax message from all senders using Memory Lock reception.

₽ Reference

p.185 "Programming a Memory Lock ID"

Limitation

☐ If you program the same sender in Memory Lock and Forwarding, Forwarding is disabled. Use this function to print the pages in reverse order. See p.100 "Reverse Order Printing".

Paper Tray

Use this function to print documents received from programmed senders (Special Senders) and the documents from other senders on different types of paper.

For example, if blue paper is in Tray 1 and white paper is in Tray 2, the machine prints the documents from Special Senders on the blue paper and prints the documents from other senders on the white paper, making it easy for you to separate the two.

If you do not program any Special Senders, the machine outputs documents received from all senders using the default paper tray.

Limitation

For Polling Reception and Free Polling, you cannot select the paper tray.

Note


- ☐ If the machine receives a message that has a different size from the paper in the specified tray, the machine prints it after splitting it or minimizing its size. See p.100 "Page Separation and Length Reduction".
- ☐ Selection of the bypass tray enables you to specify the paper size in "Scan Area".

Programming/ Changing Special Senders

Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Program Special Sender].
- **5** Select the destination to program or change.



When programming a new Special Sender, press [*Not Programed].

6 Enter a destination name, and then press [OK].

Enter a destination name using Own Name or Own Fax Number.

"Entering Text", General Settings Guide

7 Press [Full agreement] or [Partial agreement].



Select the item you want to program.




- Note
- ☐ You must select only the item you want to program.
- ☐ To cancel these settings, press **[Cancel]**. The display returns to that of step **5**.

Authorized RX (Authorized Reception)

- Select [Authorized RX].
- 2 Press [ON] or [OFF], and then press [OK].
 - Note
 - ☐ After you perform step ②, set "Authorized RX" of "Reception Settings" to "ON". See p.146 "Reception Settings".

Forwarding


- 1 Select [Forwarding].
- 2 Select [ON] or [OFF].



If you select **[OFF]**, proceed to step **4**.

Note

- ☐ Selecting [Same as basic settings] will result in the same setting made for "Forwarding" under "Key Operator Tools". See p.157 "Forwarding".
- 3 Specify an End Receiver.



4 Press [OK].

If you select **[ON]**, the name of the End Receiver appears to the right of "Receiver".

6 Press [OK].



☐ After you perform step ②, set "Forwarding" of "Reception Settings" to "ON". See p.146 "Reception Settings".

Reception File Print Qty

- Select [Reception File Print Qty].
- 2 Press [Number of Sets].



Note

- ☐ Selecting [Same as basic settings] will result in the same setting made for "RX File Print Qty" of "Reception Settings". See p.146 "Reception Settings".
- Senter the print quantity using the number keys, and then press [OK].



Note

☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.

Print 2 Sided

- 1 Select [Print 2 Sided].
- 2 Select [ON] or [OFF], and then press [OK].

Note

☐ Selecting [Same as basic settings] will result in the same setting made for "2 Sided Print" of "Reception Settings". See p.146 "Reception Settings".

Memory Lock

- **●** Select [Memory Lock].
- 2 Select [ON] or [OFF], and then press [OK].
 - **𝚱** Note
 - ☐ Selecting [Same as basic settings] will result in the same setting made for "Program Memory Lock ID" under "Key Operator Tools". See p.159 "Memory Lock".

RX Reverse Printing (Reception Reverse Printing)

- **●** Select [RX Reverse Printing].
- 2 Select [ON] or [OFF], and then press [OK].
 - Note
 - ☐ Selecting [Same as basic settings] will result in the same setting made for "RX Reverse Printing" of "Reception Settings". See p.146 "Reception Settings".

Paper Tray

- Select [Paper Tray].
- 2 Select the tray you want to use, and then press [OK].
 - Ø Note
 - ☐ Selecting [Same as basic settings] will result in the same setting made for "Paper Tray" of "Reception Settings". See p.146 "Reception Settings".

9 Press [OK].

A Special Sender has been programmed.

- ☐ To program another sender, repeat the procedure from step **⑤**.
- Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.


Programming Initial Set Up of a Special Sender

Use this function to program "Initial Set Up" of a Special Sender. You can also specify the Bypass Tray Paper Size.


1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Program Special Sender].
- Press [Initial Set Up].




6 Select the function you want to program.



- Note
- ☐ In this feature, "Authorized RX" has the same settings as "Reception Settings". See p.146 "Reception Settings".

Programming Authorized RX and Special RX Function

- Select [Authorized RX] or [Special RX Function].
- 2 Select [ON] or [OFF], and then press [OK].



The illustration shows the "Authorized RX" display as an example.

• Press [Bypass Tray Paper Size].


You can select a size from [Auto Detect], [Standard Size], or [Custom Size].

If you select [Auto Detect], proceed to steps 2 and 7.

If you select [Standard Size], proceed to steps **2**, **3**, and **7**.

If you select [Custom Size], proceed to steps 2, and 4 to 7.


Select the size you want to program.




Note

- ☐ If you select [Auto Detect], the machine recognizes the paper size automatically.
 - The machine will detect the paper size for the bypass tray as the short edge of the paper is inserted into the machine. Even if you placed an A4 size sheet in the D orientation, the machine will detect it as A3D.
- ☐ If you select [Standard Size], select a paper size displayed, and then proceed to step ⑦.
- ☐ If you select [Custom Size], proceed to step 4.
- **3** Select the size you want to program from the sizes shown.

- 4 Make sure that [Vertical] is selected.
 - Note
 - ☐ If **[Vertical]** has not been selected, press **[Vertical]**.
- ⑤ Enter the vertical size of the paper using the number keys, and then press [⊕].



- ☐ You can specify a vertical size from 210 mm (8.3 inch) to 305 mm (12.0 inch). You cannot enter a size smaller than 210 mm or larger than 305mm.
- ☐ Each time you press [mm] or [inch], the units switch between "mm" and "inch". If you enter a length and change the units by pressing [mm] or [inch], it is converted automatically (fractions are rounded off).
- 6 Enter the horizontal size of the paper using the number keys, and then press [∰].



Note

- ☐ You can specify a horizontal size from 148 mm (5.9 inch) to 600 mm (23.7 inch). You cannot enter a size smaller than 148 mm or larger than 600 mm.
- ☐ Each time you press [mm] or [inch], the units switch between "mm" and "inch". If you enter a length and change the units by pressing [mm] or [inch], it is converted automatically (fractions are rounded off).
- Press [OK].
- 7 Press [Exit].
- Press the [User Tools/Counter] key. The standby display appears.

Deleting a Special Sender

Use this function to program "Initial Set Up" of a Special Sender. The Bypass Tray Paper Size can also be specified.

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- 3 Press [Key Operator Tools].
- 4 Press [Program Special Sender].
- Press [Delete], and then select the Special Sender you want to delete.

6 Press [Delete].

Note

- ☐ To cancel deleting a special sender, press [Do not Delete]. The display returns to that of step ⑤.
- **7** Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Printing the Special Sender List

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Print List] next to "Program Special Sender".
 - Note
 - □ To cancel printing, press [Cancel]. The display returns to that of step [7].
- Press the [Start] key.
 - Note
 - ☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **[3**.
- 6 Press the [User Tools/Counter] key.

The standby display appears.

Box Settings

The following functions are for delivery and transfer of messages:

- Personal Box
- Information Box
- · Transfer Box

₽ Reference

For details about how to set up these functions:

- p.174 "Programming/changing Personal Boxes"
- p.177 "Programming/changing Information Boxes"
- p.180 "Programming/changing Transfer Boxes"

For details about how to print out and delete messages stored in boxes:

- p.40 "Personal Boxes"
- p.43 "Information Boxes"

Limitation

- ☐ You cannot set the same Box code on two different boxes.
- ☐ Transmission or programming may not be allowed if there is not enough free memory left. The amount of free memory left differs depending on the optional equipment installed.

Note

☐ The combined total of items that can be stored using the Personal Box, Information Box, and Transfer Box functions is 150. Installing the optional fax function upgrade unit increases this capacity to 400.

Programming/changing Personal Boxes

This section describes how to program Personal Boxes.

You can store the following items:

- Box name (required)
 Up to 20 characters long
- SUB Code (required)
 Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).
- Password (optional)
 Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).

𝒜 Note

- When programming a password, a mark is displayed before the Box name.
- Receiver (optional)
 You can program one delivery destination for each Personal Box.
 Specify a delivery destination programmed in Quick Dial.

Note

- ☐ An e-mail address can be set as the transmission destination.
- ☐ The contents of the Personal Box will be saved until printing is completed.
- ☐ The Fax Header is not printed on delivered messages.
- If a message cannot be delivered, a Communication Failure Report is printed and the message is saved as a Confidential Reception document.
- ☐ You can edit boxes in the same way you program them. However, to change the SUB Code itself, you must delete the box, and then program a new SUB Code.

q

☐ If the fax number or e-mail address of a programmed receiver is deleted using System Settings, the setting for the receiver is cancelled and a message is not delivered. If the fax number or email address of a programmed receiver is changed, a message is delivered to the new fax number.


p.40 "Personal Boxes"

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- **5** Select a box to program.

When programming a new box, press [*Not Programed].



- Note
- ☐ To change a box already programmed, press it and proceed to step ②.
- 6 Press [Personal Box].
- Enter a box name, and then press [OK].

"Entering Text", General Settings Guide

8 Enter a SUB Code.



- Note
- ☐ To change the SUB Code, press [Clear] or the [Clear/Stop] key, and then try again. To change a Box name, press [Box Name], and then repeat the procedure from step].
- 9 Specify the settings you require.


If you do not want to program a password or receiver, proceed to step .

Programming a password

- 1 Press [Password].
- 2 Enter a password, and then press [OK].



- **∅** Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.




∅ Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ If you want to change the password after pressing [OK], press [Cancel], and then perform from step ①.
- 4 Press [OK].

Programming an End Receiver

- 1 Press [Receiver].
- 2 Select a destination using the Quick Dial Table, and then press [OK].



- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.

The standby display appears.


Deleting Personal Boxes

This section describes how to delete Personal Boxes.

- Limitation
- ☐ If messages have been programmed in the box, you cannot delete the box.
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- Press [Delete], and then select the box you want to delete.



q

With a programmed password

Enter a password using the number keys, and then press [OK].



- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key.
- 6 Press [Delete].
 - Note
 - ☐ To cancel deleting a box, press [Do not Delete]. The display returns to that of step ⑤.
- 7 Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Programming/changing Information Boxes

This section describes how to set up an Information Box.

You can store the following items:

- Box name (required) Up to 20 characters long
- SEP Code (required)
 Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).

• Password (optional)

Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).

When programming a password, a mark is displayed before the Box name.

- Note
- ☐ You can edit boxes in the same way you program them. However, to change the SEP Code itself, you must delete the box, and then program a new SEP Code.


p.43 "Information Boxes"

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- **5** Select the box to program.


When programming a new box, press [*Not Programed].



- ☐ To change a box already programmed, press it, and then proceed to step ②. If a password has been programmed, enter the password, press [OK], and then proceed to step ③.
- **6** Press [Information Box].
- Enter a box name, and then press [OK].

"Entering Text", General Settings Guide

8 Enter the SEP Code.



- Ø Note
- ☐ To change the SEP Code, press [Clear] or the [Clear/Stop] key, and then try again. To change the box name, press [Box Name], and then repeat the procedure from step 7.
- 9 Press [Password].
 - Note
 - ☐ If you do not want to program a password, proceed to step **②**.

Enter a password, and then press [OK].



- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- Re-enter the password, and then press [OK].



- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ If you want to change the password after pressing [OK], press [Cancel], and then perform from step [].
- Press [OK].
- Press [OK].
- Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Deleting Information Boxes


This section describes how to delete Information Boxes.

Limitation

- ☐ If messages have been programmed in the box, you cannot delete the box.
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- Press [Delete], and then select the box you want to delete.



With a programmed password

Enter a password using the number keys, and then press [OK].




- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key.
- 6 Press [Delete].
 - Note
 - ☐ To cancel deleting a box, press [Do not Delete]. The display returns to that of step ⑤.
- **7** Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.

Programming/changing Transfer Boxes

This function turns your machine into a fax relay station. Documents sent with a SUB Code that matches the SUB Code programmed as a Transfer Box are received, and then relayed to a programmed receiver.

Since documents can be sent to multiple destinations in a single transfer request, you can economize on call charges when sending to remote destinations.



Note

☐ Inform the Requesting Party of the SUB Code assigned to the Transfer Box. When they want to have a message transferred by your machine, ask them to send the message using SUB Code Transmission and specifying this SUB Code. If a password has also been programmed, inform them of this too, and ask them to enter it as the SID code.

You can store the following items:

- Box name (required) Up to 20 characters
- SUB (required)
 Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).

• Password (optional)
Up to 20 characters long and can be composed of digits 0-9, "#", "*", and spaces (the first character cannot be a space).

∅ Note

- When programming a password, a mark is displayed in front of the Box name.
- End Receiver (required)
 You can store five End Receivers
 (destinations to which messages
 will be forwarded) for each box.
 Specify End Receivers with Quick
 Dials or Groups assigned to Quick
 Dials that have been programmed
 beforehand.

Limitation

After messages are transferred,
 Transfer Result Reports are not sent back to the sender.

Note


- ☐ An e-mail address can be set as the End Receiver.
- ☐ After messages are transferred, they are deleted.
- □ When this function is turned on, the machine prints out the received messages it transfers and a Transfer Result Report after the transfer has finished. If you want to turn this function off, please contact your service representative.
- ☐ When the programmed receiver is a Multi-step Transfer Group Dial, Multi-step Transfer takes place. For more information, contact your service representative.
- ☐ You can edit boxes in the same way you program them.

- ☐ Deleting a destination specified as an end receiver from the Address Book causes the settings for the end receiver to be deleted. If this is the case, reprogram the end receiver. If the destination has been changed, a message is transmitted to the new destination.
- Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- **5** Select a box to program.


When programming a new box, press [*Not Programed].



- Note
- ☐ To change a box already programmed, press it, and then proceed to step ②.
- 6 Press [Transfer Box].
- Enter a Box name, and then press [OK].

"Entering Text", General Settings Guide


8 Enter a SUB Code.



- Note
- ☐ To change the SUB Code, press [Clear] or the [Clear/Stop] key, and then try again. To change Box name, press [Box Name], and then repeat from step 7.
- **9** Specify the condition of registration.

Programming End Receivers

- Select an End Receiver.
 - Note
 - ☐ You can store five End Receivers.
- Specify End Receivers with Quick Dials, and then press [OK].



- Note
- ☐ You can also specify End Receivers with Group Dials.
- ☐ Repeat from step ① to specify another End Receiver.

Programming a password

If you do not want to program a password, proceed to step **(I)**.

- 1 Press [Password].
- 2 Enter a password, and then press [OK].



- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- **3** Re-enter the password, and then press [OK].



𝒯 Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ If you want to change the password after pressing [OK], press [Cancel], and then perform from step ①.
- 4 Press [OK].
- Press [OK].
- 11 Press [Exit].


Press the [User Tools/Counter] key.
The standby display appears.

Deleting Transfer Boxes

Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Box Setting].
- Press [Delete], and then select the box you want to delete.



With a programmed password

• Enter a password using the number keys, and then press [OK].



Note

☐ If you make a mistake, press [Clear] or the [Clear/Stop] key.

Ç

6 Press [Delete].

Note

- ☐ To cancel deleting a special sender, press [Do not Delete]. The display returns to that of step ⑤.
- 7 Press [Exit].
- Press the [User Tools/Counter] key. The standby display appears.

Printing the Box List

Follow the procedure below to print a list showing the currently programmed Personal Boxes, Information Boxes, and Transfer Boxes.

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- Press [Print List] next to "Box Setting".
- 5 Press the [Start] key.

After printing the list, you can then start from step **4**.

Note

- ☐ To cancel printing a list before pressing the **[Start]** key, press **[Cancel]** or the **[Clear/Stop]** key. The display returns to that of step **[3**.
- ☐ To cancel printing a list after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **4**.

6 Press the [User Tools/Counter] key.

The standby display appears.

Transfer Report

For the Requesting Party to be able to receive Transfer Result Reports from the Transfer Station, the Requesting Party must program the number of the telephone line in connection on their own machine. See p.52 "Transfer Request".

Be sure to insert a pause after the area code.

For example, if you are in the United States and your fax number is 212-1234567, program the following:

1212-1234567


You can program the fax number for the G3 line.

Limitation

☐ You cannot program or edit a Transfer Report when using a line (during communication). Program or edit after communication.

Note

- ☐ You cannot use Transfer Request if the telephone number of their machine is not programmed into that machine.
- \square Up to 16 digits are available for G3.
- 1 Press the [User Tools/Counter] key.




- 2 Press [Facsimile Features].
- Press [Key Operator Tools].

5 Specify the fax number.



Programming a G3 Fax Number

- Press [G3 Fax No.(Dir.)].
- 2 Enter your facsimile number using the number keys, and then press [OK].



- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key.
- 6 Press [Exit].
- Press the [User Tools/Counter] key.
 The standby display appears.


Programming a Confidential ID

Program a Confidential ID to print a Confidential Reception. See p.36 "Printing a Confidential Message".

- Note
- ☐ If you do not program a Confidential ID, you cannot receive a Confidential Transmission.
- Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- 3 Press [Key Operator Tools].
- 4 Press [Program Confidential ID].
- Enter an ID using the number keys, and then press [OK].



- Note
- ☐ A Confidential ID can be any four-digit number, except 0000.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.

To cancel programming an ID, press [Cancel]. The display returns to that of step [3].

Press the [User Tools/Counter] key.
The standby display appears.

g

Programming a Polling ID

Program a Polling ID to use the Transfer Request, Transfer Station, Default ID Polling Transmission, and Default ID Polling Reception functions. When you use ID Transmission, program the same ID as the one programmed on the sender's machine.


p.10 "Polling Transmission"

p.13 "Polling Reception"


p.52 "Transfer Request"

p.75 "Selecting transmission options for a single transmission"

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Program Polling ID].
- Enter an ID using the number keys and [A] to [F], and then press [OK].



Ø Note

☐ A Polling ID can be any combination of digits (0-9) and letters (A-F), except 0000 and FFFF.

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel programming an ID, press [Cancel]. The display returns to that of step ②.
- 6 Press the [User Tools/Counter] key.
 The standby display appears.

Programming a Memory Lock ID


Program a Memory Lock ID to be entered before printing documents when the Memory Lock function is activated.

Note

- ☐ A Memory Lock ID can be any four-digit number, except 0000.
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Program Memory Lock ID].
- Enter an ID using the number keys, and then press [OK].



- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel programming an ID, press [Cancel]. The display returns to that of step ②.
- **6** Press the **(User Tools/Counter)** key. The standby display appears.

Selecting Dial/Push Phone

Use this function to select a line type when the machine is connected to a G3 analog line.

Dial and Push lines are available for selection.

- ☐ When the optional G3 expansion unit is installed, "G3-2" appears.
- ☐ This function is not available in some areas.
- 1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Select Dial/Push Phone].

Press [Push Button Phone] or [Dial Phone (10PPS)] to select the line, and then press [OK].



p.195 "Selecting the Line Type"

Press the [User Tools/Counter] key.
The standby display appears.

Storing or Printing Received Documents

Specify whether received documents are to be saved on the hard disk or printed immediately without being saved. You can print stored documents repeatedly or download them as images to a computer using a Web browser or DeskTopBinder V2 Lite. If you select printing without saving, documents are printed each time they are received.

Limitation

☐ If using System Settings you have set the machine to distribute received faxes to the delivery server, the documents cannot be saved on the hard disk.

Q

- ☐ If the facsimile is set to store received documents, document reception can be notified to a specified e-mail address.
- ☐ Documents saved on the hard disk are categorized as received and stored documents. For details about printing saved documents, see p.34 "Printing/Deleting Received and Stored Documents (Print Stored RX File)".
- ☐ You cannot switch the setting if received documents have been stored on the hard disk. To switch the setting, print documents stored on the hard disk if necessary, and then delete them.
- ☐ Received confidential messages are stored in memory. Use the Print Confidential RX File function to print them.
- ☐ With [Store] selected, more memory space will be used as the number of saved documents increase. After memory space becomes insufficient, no more documents are saved on the hard disk. If this happens, the machine will start printing and deleting saved documents with the oldest one.
- ☐ You can store received documents up to a total of approximately 320 pages or 2,240 (when the optional expansion memory is installed) of A4 size Standard <ITU-T#4Chart>.
- ☐ You cannot send received documents.
- You cannot manage documents stored on the Document Server display.

1 Press the [User Tools/Counter] key.



- 2 Press [Facsimile Features].
- Press [Key Operator Tools].
- 4 Press [Reception File Setting].
- Select [Print] or [Store], and then press [OK].



Note

- ☐ To cancel your selection, press **[Cancel]**. The display returns to that of step **4**.
- □ When [Store] is selected, you can select whether or not to send notice of reception to a specific e-mail address. To notify of reception, press [Notify Dest.] and select an e-mail address from the Internet Fax destinations programmed in the address book.

6 Press the [User Tools/Counter] key.

The standby display appears.

Reception Report e-mail

When a received document is stored, this report is sent to the e-mail address set as the destination for notification.

Setting a User Code for Viewing Received and Stored Documents

You can view and print documents received and saved on the hard disk using a Web browser or DeskTop-Binder V2 Lite. Specify whether or not a user code is entered to view saved documents. If you want to use a user code, set one using a maximum of eight digits.


Note

- ☐ This function is only available when received documents are saved on the hard disk. See p.186 "Storing or Printing Received Documents".
- ☐ You can set a user code with the System Settings. See "Registering a New User Code", General Settings Guide.
- ☐ If the programmed user code has been deleted using the Address Book Management function under System Settings, you cannot view received and saved documents using a Web browser. Select [OFF] in step **B** or reprogram a user code.
- 1 Press the [User Tools/Counter] key.




- 2 Press [Facsimile Features].
- 3 Press [Key Operator Tools].
- Press [Stored RX File User Code Setting].

If you want to use a user code, press [ON].



- Note
- ☐ If you do not want to use a user code, press [OFF] and proceed to step 7.
- ☐ To cancel the selection, press **[Cancel]**. The display returns to that of step **[**].
- 6 Enter a user code (eight digits maximum) using the number keys, and then press [♣].



- Note
- ☐ If you enter a wrong user code, press [Clear] or the [Clear/Stop] key, and then try again.
- **7** Press [OK].
- Press the [User Tools/Counter] key.
 The standby display appears.

10. Solving Operation Problems

When an Error Report is Printed

An Error Report is printed if a message cannot be successfully sent or received.

Possible causes include a problem with your machine or noise on the telephone line. If an error occurs during transmission, resend the original. If an error occurs during reception, ask the sender to resend the message.

- ☐ If an error happens frequently, contact your service representative.
- ☐ The "Page" column gives the total number of pages. The "Page Not Sent" column gives the number of pages not sent or received successfully.

Turning Off the Main Power / When a Power Failure Occurs

⚠ CAUTION:

 When you disconnect the power plug from the wall outlet, always pull the plug (not the cable).

A CAUTION:

 When you disconnect the power plug from the wall outlet, always pull the plug (not the cable).

Even if the main power switch is turned off, the contents of the machine memory (for example, programmed numbers) will not be lost. However, if power is lost for about one hour because the main power switch is turned off, there is a power cut, or the power cable is removed, contents of the Fax memory will be lost. Lost items will include any fax messages stored in memory using Memory Transmission/Reception, Auto Document, Confidential Reception, Memory Lock, or Substitute Reception.

If a file has been deleted from memory, a Power Failure Report is automatically printed as soon as the power is restored. This report can be used to identify lost files. If a memory stored for Memory Transmission was lost, resend it. If a message received by Memory Reception or Substitute Reception was lost, ask the sender to resend it.

∰Important

- Do not turn off the main power switch while the power indicator is lit or blinking. If you do, the hard disk and memory may be damaged and failure could result.
- □ Turn off the main power switch before pulling out the plug. If you pull out the plug with the switch on, the hard disk and memory may be damaged and failure could result.
- ☐ Make sure that 100% is shown on the display before you unplug the machine. If a lower value is shown, some data is currently present in memory.
- □ Right after a power failure, the internal battery needs to be sufficiently recharged to guard against future data loss. Keep the machine plugged in and the main power switch on for about one week after the power loss.

RDS (Remote Diagnostic System)

If your machine has a problem, a service representative can perform various settings over the telephone line from the service station.

If you want to use this function, change the User Parameter. See p.161 "User Parameters" (switch 25, bit 4).

When an Error Occurs Using Internet Fax

Error Mail Notification

The machine sends the Error Mail Notification to the sender when it is unable to successfully receive a particular e-mail message. A "cc" of this notification is also sent to the administrator's e-mail address when one is specified.

- ☐ You can select to send Error Mail Notification with User Parameters. See p.161 "User Parameters" (switch 21, bit 7).
- ☐ If Error Mail Notification cannot be sent, the Error Report (Mail) is printed by the machine.
- ☐ If an error occurs when an e-mail is received via SMTP, the SMTP server sends an error e-mail to the originator of the message.

p.161 "User Parameters"

p.191 "Error Report (Mail)"

Error Report (Mail)

The Error Report (Mail) is printed by the machine when it is unable to send an Error Mail Notification.

Server-Generated Error E-mail

The transmitting server sends this error e-mail to the originator of e-mail that cannot be transmitted successfully (due to reasons such as specifying an incorrect e-mail address).

☐ After a server-generated error e-mail is printed, the first page of the sent document is printed.

11. Appendix

Replacing the Stamp Cartridge


The optional ADF is required.

When the stamp becomes lighter, replace the cartridge.


Note

- ☐ Use the cartridge specified for this machine.
- Do not add ink to the cartridge by yourself. Neglecting this can cause ink leakage.
- ☐ Be sure not to dirty your fingers with ink from the cartridge.

1 Lift the ADF.




2 Open the stamp cover.




3 Pull out the cartridge.

Tap the cartridge lock lever several times. The cartridge will eject. Then remove the cartridge, while pushing the lock lever.




- 1. Cartridge
- 2. Cartridge Lock Lever
- 4 Set a new cartridge.

Insert the cartridge until the metal parts are no longer visible.



1. New cartridge

5 Replace the stamp cover until it clicks.



6 Lower the ADF.

11

Connecting the Machine to a Telephone Line and Telephone


Connecting the Telephone Line

To connect the machine to a telephone line, use a snap-in modular type connector.

∰Important

☐ Make sure the connector is the correct type before you start.

Where to connect the machine



- 1. G3 interface unit connector
- 3. Extra G3 interface unit connector
- 2. External telephone connector

Selecting the Line Type

Select the line type to which the machine is connected. There are two types: tone and pulse dial.

Note

☐ This function is not available in some areas.

Select the line type using "Key Operator Settings". See p.186 "Selecting Dial/Push Phone".

Optional Equipment

Fax Function Upgrade Unit

JBIG compression for transmission/reception becomes possible.

You can increase the maximum programmable numbers of the following functions. See p.202 "Maximum Values".

- Quick Dial
- Memory Transmission file
- · Auto Document
- Specific Sender
- Program
- Transmission Result
- Box

Expansion Memory (32MB: DIMM)

This allows you to send fax messages at high resolution (Super Fine). This also allows you to receive fax messages at high resolution (Fine or Super Fine). If you require this option, consult your service representative. See p.202 "Maximum Values".

Extra G3 Interface Unit

This option provides one extra G3 line connection.

A maximum of one G3 interface unit can be installed.

Specifications

❖ Fax Transmission and Reception

| Standard | G3 |
|-------------------------|--|
| Resolution | G3: 8×3.85/mm•200×100 dpi (Standard), 8×7.7/mm•200×200 dpi (Detail), 8×15.4/mm•200×400 dpi (Fine), 16×15.4/mm•400×400 dpi (Super Fine: optional expansion memory required) |
| Transmission time | G3: 3 seconds at 28,800 bps, Standard resolution |
| Data compression method | MH, MR, MMR, JBIG (optional fax function upgrade unit required) |
| Maximum original size | Standard size: A3, 11"×17" |
| Maximum scanning size | Standard size: 297×432 mm/11"×17" Irregular size: 297×1,200 mm/11"×47" |
| Print process | Printing on standard paper using a laser |
| Transmission speed | G3: 33,600/31,200/28,800/26,400/24,000/21,600/ 19,200/16,800/14,400/12,000/9,600/7,200/4,800/ 2,400bps (auto shift down system) |

❖ Power Consumption *1

| Standby mode | approx. 220 W | |
|---------------------------|--------------------------------|--|
| Transmission | approx. 260 W | |
| Reception | approx. 600 W | |
| Maximum power consumption | 1,500 W or less | |
| Low power mode/sleep mode | 196.3 W or less / 80 W or less | |

 $^{^{*1}}$ Measured with the ADF and fax options installed.

Internet Fax Transmission and Reception

| Network | LAN: Local Area Network Ethernet/10Base-T, 100Base-TX, IEEE1394 (IP over 1394), IEEE802.11b (wireless LAN) | |
|--------------------------------|--|--|
| Transmit function | E-mail | |
| Scan line density | Standard (200 × 100 dpi), Detail (200 × 200 dpi) | |
| Original size : Scanning width | A4:210 mm (8.3 in.) (Originals larger than A4 size is reduced in size when transmitted.) | |

| Communication Protocols | Transmission SMTP, TCP/IP Reception POP3, SMTP, IMAP4, TCP/IP | | |
|--------------------------|--|--|--|
| E-mail format | Single/Multi-part, MIME Conversion Attached file forms: TIFF-F (MH compression) | | |
| Authentication method | SMTP-AUTH, POP before SMTP, A-POP | | |
| Internet communication | Send and receive e-mail with a computer that has an e-mail address | | |
| E-mail send functions | Automatic conversion of sent documents to e-mail format and e-mail transmission. Memory transmission only. | | |
| E-mail receive functions | Automatic detection and printing of appended TIFF-F (MH) files and ASCII text. Memory reception only. | | |

Compatible Machines

This machine is compatible to machines having the following specifications.

| Communication protocols | Transmission SMTP Reception POP3, SMTP |
|-------------------------|---|
| E-mail format | Format MINE, Base64 Content-Type Image/tiff Multipart/mixed [text/plain, Image/tiff] (attached file forms) |
| Data format | Profile TIFF Profile S Coding MH Original size A4 Resolution (dpi) 200×100/200×200 or 204×98/204×196 |

Acceptable Types of Originals


Make sure your originals are completely dry before setting them in the machine. Wet ink or correcting fluid from originals will mark the exposure glass and affect the resulting image.

Acceptable original sizes


| Where original is set | Acceptable original size | Maximum number of sheets | Paper thickness |
|-------------------------|--|--------------------------------|------------------------------------|
| Exposure glass | Up to A3 (297×420 mm), 11"×17" (279×432 mm) | 1 | |
| ADF, one-sided document | Fax transmission: A5 to A3 (up to 1,200 mm long) 8"×51/2" to 11"×17" | 80 sheets (80 g/m², 20 lb) | 40-128 g/m ² (11-34 lb) |
| ADF, two-sided document | Fax transmission: A5 🗗 to A3 🗗 (up to 432 mm long) 8"×5 ¹ / ₂ " 🗗 to 11"×17" 🗗 | 80 sheets (80 g/m², 20 lb) | 52-105 g/m ² (14-28 lb) |

Paper size and scanned area

Exposure Glass



◆ ADF



Limitation

- ☐ There may be a difference in the size of the image when it is printed at the destination.
- ☐ If you place an original larger than A3, 11"×17" on the exposure glass, only an A3, 11"×17" area is scanned.

Note

- ☐ Even if an original is correctly placed on the exposure glass or in the ADF, a margin of 3 mm (0.1") around each edge of the original may not be sent.
- ☐ If the receiver uses paper of a smaller width than the original, the image will be reduced to fit that paper. See p.75 "Auto Reduce".
- ☐ The machine detects paper sizes in the following ways:
 - When you place an original in the ADF, an original wider than about 264 mm (10.4") is scanned as A3, 11"×17" size.
 - An original narrower than about 230 mm (9.1") will be sent as $8^1/2$ "×11" or $8^1/2$ "×14" size, and an original narrower than about 264 mm (10.4") is scanned as B4 IIS.
 - Originals up to 1,200 mm (47.2") in length can be scanned.
 - Refer to the table below for sizes the machine can detect when you place an original on the exposure glass. Because the machine scans non-standard size documents in a standard size, part of the image may be truncated depending on the length of the document. For details about how to set nonstandard size documents, see p.16 "Setting a Scan Area", Facsimile Reference < Basic Features>.

Metric Version

| | | Length *1 | | | |
|-------|---|-----------------|-----------------------------------|-----------------------------------|-----------------|
| | | -approx. 249 mm | approx. 249 mm– approx. 274 mm | approx. 274 mm- approx. 316 mm | approx. 316 mm- |
| | –approx. 243 mm | × | B5 JIS□ | A4D | F□ |
| Width | approx. 243 mm– approx. 268 mm | B5 JIS 🗗 | B4 JIS⊡ | B4 JIS⊡ | B4 JIS⊡ |
| | approx. 268 mm– | A4 🔽 | A3□ | A3□ | A3□ |

Inch Version

| | | Length *1 | | | | | |
|-------|---------------------------------------|---------------------------------------|--------------------------------|--------------------------------------|----------------|--|--|
| | | -approx. 9.8" | approx. 9.8"– approx. 10.8" | approx. 10.8"– approx. 12.4" | approx. 12.4"– | | |
| | -approx. 9.6" | × | × | 8 ¹ / ₂ "×11"□ | F□ | | |
| Width | approx. 9.6" – approx. 10.6" | 11"×8 ¹ / ₂ " □ | 11"×17"□ | 11"×17" □ | 11"×17"□ | | |
| | approx. 10.6"– | 11"×8¹/₂" □ | 11"×17" □ | 11"×17"□ | 11"×17"□ | | |

× - Unable to auto detect

.

Maximum scan area

The maximum scan area is shown below:

- Memory Transmission: 297×1,200 mm/11"×47" (W×L) from the ADF
- Immediate Transmission: 297×1,200mm/11"×47" (W×L) from the ADF

𝒯 Note

- ☐ During Immediate Transmission, the length of the scanning range can become narrower than 1,200 mm (47"), depending on the character size as well as the settings on the destination machine.
- 297×432 mm/11"×17" (W×L) (from the exposure glass)

^{*1} Normally a length of about 420 mm (16.5") can be scanned; however, it is only possible to specify a scanning size up to 432 mm (17").

Maximum Values

The following list contains the maximum value for each item.

𝒯 Note

☐ The maximum number of pages that can be stored or transmitted may decrease depending on the contents of documents.

| Item | Standard | | With optional un | it |
|---|-------------|---------------------------|------------------|--|
| | | Fax function upgrade unit | Expansion memory | Expansion mem- ory + fax function upgrade unit |
| Memory | 4 MB | 4 MB | 28 MB | 28 MB |
| The number of pages that you can store in memory (Using A4 size Standard <itu-t #4chart="">)</itu-t> | Approx. 320 | Approx. 320 | Approx. 2,240 | Approx. 2,240 |
| Total number of all documents | 400 | 800 | 400 | 800 |
| The number of pages per file | 1,000 | 1,000 | 1,000 | 1,000 |
| The number of pages for all files | 1,000 | 1,000 | 3,000 | 3,000 |
| The number of destinations you can specify for one file | 500 | 500 | 500 | 500 |
| The number of destinations you can specify for all files | 500 | 2,000 | 500 | 2,000 |
| The number of Quick Dials you can program | 2,000 | 2,000 | 2,000 | 2,000 |
| The number of Group Dials you can program | 100 | 100 | 100 | 100 |
| The number of destinations you can program in a group | 500 | 500 | 500 | 500 |
| The number of digits for Dials | 128 | 128 | 128 | 128 |
| The number of Programs you can register | 100 | 200 | 100 | 200 |
| The number of Auto Documents you can program | 6 | 18 | 6 | 18 |

11

| Item | Standard | | With optional un | it |
|---|---------------|---------------------------|---------------------|--|
| | | Fax function upgrade unit | Expansion memory | Expansion mem- ory + fax function upgrade unit |
| The number of Standard Message Stamps you can program | 3 | 3 | 3 | 3 |
| The number of transmission records the machine can store | 200 | 1,000 *1 | 200 | 1,000 *1 |
| The number of stored documents you can specify at one time | 1,000 | 1,000 | 1,000 | 1,000 |
| The number of stored documents you can send at one time | 30 | 30 | 30 | 30 |
| The number of pages that you can store in the Document Server (Using ITU-T #4Chart) | Approx. 9,000 | Approx. 9,000 | Approx. 9,000 | Approx. 9,000 |
| The number of pages you can store in the Document Server for one document | 1,000 | 1,000 | 1,000 | 1,000 |

^{*1} This indicates the number of transmission records that you can check using Smart-NetMonitor for Admin. From the machine you can check up to 400 communication records (transmission plus reception).

INDEX

| | D | | | | |
|---|--|--|--|--|--|
| 180-Degree Rotation Printing, 98 2-Sided Printing, 85 | Default ID/Free Polling Reception, 13 Default ID Transmission, 10, 11, 75 Deleting | | | | |
| A | Information Box Messages, 46 | | | | |
| Address Book, 116 Authorized Reception, 166 Auto Document, 65, 152 Changing, 152 Deleting, 153 Sending, 65 Storing, 152 Auto Fax Reception Power-up, 95 Automatic Redial, 79 Auto Reduce, 75 | programmed destinations, 117 Destination Adding, 21 Checking, 18 Deleting, 20 Displaying the Memory Status, 33 Document Server, 131 Delete File, 136 Manage File, 134 Storing a Document, 132 Dual Access, 79 | | | | |
| <u>B</u> | E | | | | |
| Basic Transmission, 112 Batch Transmission, 79 Book Fax, 61 Box Setting, 150, 174 C Canceling Transmission, 19 Centre Mark, 96 Chain Dial, 47 Checkered Mark, 96 Checking Transmission Result (TX File Status), 31 Combine 2 originals, 85 Combine Two originals, 99 Communication Failure Report, 84 Communication Information, 27 Confidential File Report, 37 Confidential ID, 184 Confidential Message, 36 Confidential Transmission, 8 Counters, 149, 156 Cover sheet, 113 | ECM (Error Correction Mode), 149, 160 Economy Transmission Time, 3 E-mail transfer, 95 End Receiver, 157 Error Mail Notification, 191 Error Report, 189 Error Report (Mail), 191 Expansion Memory, 196 Extra G3 Interface Unit, 196 | | | | |
| | Fax Function Upgrade Unit, 196 Fax Header Print, 74 Fax via Computer, 107 File Printing, 23 Printing a List of Files in Memory (Print TX File List), 25 Re-sending, 24 Forwarding, 91, 149, 157, 167 Free Polling Transmission, 10, 11 Full/Partial agreement, 165 G General Settings/Adjustment, 144 H | | | | |
| | Handy Dialing Functions, 47 | | | | |

| <u>I</u> | 0 |
|---|--|
| ID Override Polling Reception, 13 ID Override Transmission, 10 Image Rotation, 80, 99 Immediate Reception, 85 Information Boxes, 43, 179 Changing, 177 | On Hook Dial, 56 Optional Equipment, 196 Originals, 199 Output Tray, 105 |
| Deleting, 179 Printing, 183 Programming, 177 Storing Messages, 43 | Page Reduction, 101 Page Separation and Length Reduction, 100 Paper Tray, 146 Parallel Memory Transmission, 78 Parameter Setting, 149 Personal Boxes, 40, 174, 176 |
| JBIG, 81, 95 Reception, 95 Transmission, 81 Journal, 27 Journal by E-mail, 82 Journal by E-mail, Transmitting, 81 Just size printing, 103 | Changing, 174 Deleting, 176 Printing, 183 Programming, 174 Polling ID, 185 Polling Reception, 13 Polling Reserve Report, 15 Polling Result Report, 15 Polling Transmission, 10 |
| Key Operator Code, 142 Key Operator Settings, 149 Key Operator Tools List, 149 Keystroke Program, 127 | Polling Transmission Clear Report, 12 Power Failure Report, 190 Print 2 Sided, 167 Print Completion Beep, 96 Printed Report, 83 Printing |
| Label Insertion, 74 LAN-Fax Operation Messages, 119 LAN-Fax Properties, Setting, 111 Line Type Changing, 59 Selecting, 195 | Box List, 183 Confidential Message, 36 File Received with Memory Lock, 38 Information Box Messages, 45 Journal, 27 Options, 96 Personal Box Messages, 41 Special Sender List, 173 |
| Manual Dial, 58 Maximum Value, 202 Memory Lock, 38, 159, 167 Memory Lock ID, 185 Memory Reception, 85 Memory Status, 33 Memory Storage Report, 83 More Transmission Functions, 78 | Printing and Saving, 115 Priority trays, 103 Programs, 127 Changing, 127 Deleting, 129 Registering, 127 PWD Code, 51 |
| Multi-copy, 85 Multi-copy Reception, 98 Multi-port, 59 Multistep Transfer, 90 | Quick Operation key, 145 |

| R | Standard Message Stamp, 64 |
|--|--|
| PDS (Romoto Diagnostic System) 100 | SUB Code, 49, 92 |
| RDS (Remote Diagnostic System), 190 Receiving Station, 52, 89 | Substitute Reception, 86 |
| Reception, 85 | Switches and Bits, 161 |
| Reception Features, 85 | Т |
| Reception File Print Quantity, 167 | <u>'</u> |
| Reception Functions, 89 | Telephone Line, 195 |
| Reception Reverse Printing, 168 | Transfer Boxes, 182 |
| Reception Settings, 146 | Changing, 180 |
| Reception Time, 97 | Deleting, 182 |
| Reception Result (RX File Status), 32 | Printing, 183 |
| Redial, 47 | Programming, 180 |
| Reduced Image Transmission, 75 | Transfer Report, 183 |
| Report, 83 | Transfer Request, 52 |
| Communication Failure Report, 84 | Transfer Result Report, 90 |
| Error Report, 189 | Transfer Result Report |
| Memory Storage Report, 83 | (transfer request by e-mail), 91 |
| Power Failure Report, 190 | Transferring, 93 |
| Transmission Result Report | Transfer Station, 52, 89 |
| (Immediate Transmission), 84 | Transmission Features, 47 |
| Transmission Result Report | Transmission Mode, 3 |
| (Memory Transmission), 83 | Transmission Options, 74 |
| Requesting Party, 52, 89 | Transmission Result Report |
| Reverse Order Printing, 85, 100 | (Immediate Transmission), 84 |
| RX File Status, 32 | Transmission Result Report |
| 0 | (Memory Transmission), 83 |
| <u>S</u> | Transmission Time |
| Scan Size, 154 | Changing, 22 Transmission with Image Potation 80 |
| Changing, 154 | Transmission with Image Rotation, 80 |
| Deleting, 154 | Tray for Lines, 105 Tray Shift, 105 |
| Programming, 154 | TSI Print, 101 |
| Scan size | Two-Sided Printing, 97 |
| Deleting, 155 | Two-Sided Transmission, 62 |
| Selecting | TX File, 18 |
| Dial/Push Phone, 186 | TX File Status, 31 |
| Sender Stamp, 74 | The Status, of |
| Send Later, 3 | U |
| SEP Code, 50 | |
| Server-Generated Error E-mail, 191 | User Parameter List, 161 |
| SID Code, 50 | User Parameters, 161 |
| Simultaneous Broadcast, 80 | |
| SMTP, 94 | |
| SMTP reception, 93 | |
| Special Senders, 165 | |
| Special Senders to Treat Differently, 165 | |
| Specifications, 197 | |
| Stamp, 73 | |
| Stamp Cartridge, 193 | |
| Chandard Massacras 151 | |

Standard Messages, 151 Deleting, 151 Programming, 151



Operating Instructions Scanner Reference



- 1 Network Scanner
- Preparations for Use as a Network Scanner
- 3 Setting Originals
- 4 Sending Scan File by E-mail
- 5 Sending Scan File by Scan to Folder
- 6 Using the Document Server Function
- (7) Using the Network Delivery Scanner Function
- 8 Using the Network TWAIN Scanner Function
- 9 Appendix

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Warning:

Use of controls or adjustment or performance of procedures other than those specified in this manual might result in hazardous radiation exposure.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

Note

- ☐ The manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1 "Operating Instructions for Printer / Scanner"
 - CD-ROM 2 "Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

♦ Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference < Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference <Advanced Features>

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

Scanner Reference (this manual) (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

❖ Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes the installation of DeskTopBinder V2 Lite, and the operating environment for DeskTopBinder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations with DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with
 DeskTopBinder V2 Lite. This guide is added to the [Start] menu when
 DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes the installation of ScanRouter V2 Lite, settings, and the operating environment for ScanRouter V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an overview of ScanRouter V2 Lite functions. This guide is added to the [Start] menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- UNIX Supplement (available from an authorized dealer, or as a PDF file on our Web site)

TABLE OF CONTENTS

| Manuals for This Machine | i |
|--|----|
| How to Read This Manual | 1 |
| Symbols | |
| Names of Major Options | |
| 1. Network Scanner | |
| Outline | 3 |
| E-mail | 3 |
| Scan to Folder | 4 |
| Document Server | 5 |
| Network Delivery Scanner | |
| Network TWAIN Scanner | 7 |
| Control Panel | |
| Display Contents | 9 |
| 2. Preparations for Use as a Network Scanner | |
| Initial Scanner Setup | |
| Scanner Features | |
| Scan Settings | |
| Destination List Settings | |
| Send Settings | |
| Programs | |
| Registering a Program | |
| Recalling a Program | |
| Changing a Registered Program | |
| Deleting a Program | |
| Changing the program name | |
| Installing Software | |
| Auto Run ProgramSoftware for Using a Network TWAIN Scanner | |
| Software for Using the Network Delivery Scanner Function | |
| DeskTopBinder V2 Lite | |
| Software Supplied on CD-ROM | |
| 3. Setting Originals | |
| Placing Originals | 35 |
| Placing on the Exposure Glass | |
| Placing in the Auto Document Feeder | |
| Original Orientation and Scan Area | |
| For E-mail, Scan to Folder, and a Network Delivery Scanner | |
| For a Network TWAIN Scanner | |
| Scanning Originals in Several Times | |
| 5 5 | |

4. Sending Scan File by E-mail

| Preparation for Sending by E-mail E-mail Screen | |
|--|-----|
| Sending Scan File by E-mail | |
| Procedure for Sending E-mail | |
| Simultaneous Storage and Sending by E-mail | |
| Checking the Status of E-mail | |
| 5. Sending Scan File by Scan to Folder | |
| Preparation for Sending by Scan to Folder | |
| Scan to Folder Screen | |
| Sending Scan File by Scan to Folder | |
| Procedure for Sending by Scan to Folder | |
| Simultaneous Storage and Sending by Scan to Folder | |
| Checking the Status of Scan to Folder | / 1 |
| 6. Using the Document Server Function | |
| Storing Files | |
| Storage Procedure | |
| Viewing a List of Stored Files | |
| Viewing the List | |
| Searching for FilesSending Stored Files by E-mail or Scan to Folder, or Delivering | |
| Managing Stored Files | |
| Deleting Files | |
| Changing File Information | |
| 7. Using the Network Delivery Scanner Function | |
| Preparation for Delivering | |
| Network Delivery Scanner Screen | 86 |
| Delivering Scan File | |
| Delivery Procedure | |
| Simultaneous Storage and Delivery | |
| Checking the Status of Delivery | 94 |
| 8. Using the Network TWAIN Scanner Function | |
| Preparation for Using the Network TWAIN Scanner | 95 |
| Scanning Originals | |
| Functions of the TWAIN Driver | 98 |

9. Appendix

| Relationship between Resolution and File Size | 99 |
|---|-------|
| When Using as E-mail, Scan to Folder, Document Server or Network Delivery | |
| Scanner | 99 |
| When Using as a Network TWAIN Scanner | |
| Relationship between File Type Specified and File Type Used | |
| When Sending E-mail | 102 |
| Max. Number of Addresses Which Can Be Specified and Files | 400 |
| Which Can Be Stored | 103 |
| Troubleshooting | 104 |
| When Scanning Is Not Performed as Expected | |
| When the Delivery Function Does Not Work | |
| When Stored Files Cannot Be Accessed | 105 |
| When an Error Message Appears on the Control Panel | |
| When an Error Message Appears on the Client Computer | 111 |
| Specifications | 114 |
| INDEX | . 115 |

How to Read This Manual

Symbols

In this manual, the following symbols are used:

∰Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or files might be lost. Be sure to read this.

Preparation

This symbol indicates the prior knowledge or preparations required before operating.

Ø Note

This symbol indicates precautions for operation or actions to take after misoperation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys that appear on the machine's display panel.

[]

Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

Keys on the computer's keyboard.

Names of Major Options

Major options of this machine are referred to as follows in this manual:

• File Format Converter Type $B \rightarrow$ File Format Converter

The following software products are referred to using a general name:

- DeskTopBinder V2 Lite and DeskTopBinder V2 Professional → DeskTopBinder V2 Lite/Professional
- ScanRouter V2 Lite and ScanRouter V2 Professional (optional) → ScanRouter V2 Lite/Professional

1. Network Scanner

Outline


By installing the printer/scanner controller, the machine can be used as a network scanner.

As a network scanner, the machine can send e-mail, send files to the FTP server or the shared folders of client computers, store scan files in the Document Server, operate as a network delivery scanner, and operate as a network TWAIN scanner.

E-mail

Scan file that is attached to an e-mail can be sent using the e-mail system through a LAN or the Internet.

p.45 "Sending Scan File by E-mail"



1. This machine

Scan file that is attached to an e-mail can be sent to an e-mail server. In combination with the file storage function, scan files from multiple originals that have been temporarily stored can be sent all at once.

2. E-mail server

An e-mail server is the SMTP server used for an e-mail system. It transfers a received e-mail to a specified destination through a LAN or the Internet.

3. Client computer

An e-mail with scan file attached is received from the e-mail server using e-mail software.

Check the content of the file using an application appropriate for the file type.

4. LDAP server


LDAP server provides a directory service corresponding to the inquiry or reference operation from the client computer on the same network.

E-mail address information can be searched for from the machine when you use LDAP server as a data base of the user authentication and the e-mail account management.

Scan to Folder

Scan file can be sent to the folders of the FTP server or the shared folders of Windows on the same network.

p.59 "Sending Scan File by Scan to Folder"



1. This machine

Scan file can be sent to the folders of the FTP server using FTP protocol or the shared folders of Windows using SMB protocol. In combination with the file storage function, scan files from multiple originals that have been temporarily stored can be sent all at once.

2. FTP server

The FTP server is a server that provides file transfer services among client computers on the same network. Scan file that is sent to the FTP server can be stored, and the stored file can be downloaded by a client computer that logs onto the FTP server.

3. Client computer


Scan file that is sent from the machine is received in the shared folders of Windows.

Check the content of the file using an application appropriate for the file type.

Document Server

Scan file from the originals is stored as a file on the hard disk of the machine and can be viewed, copied, deleted, or retrieving using DeskTopBinder V2 Lite/Professional from a client computer via a network. A file can be searched for using the user name or the file name. Also, others can be kept from viewing a file by setting a password for the file.

p.73 "Using the Document Server Function"



1. This machine

Scan file from the originals scanned by the scanner is stored.

2. Client computer

A stored file can be viewed, copied, or deleted by connecting to the machine using DeskTopBinder V2 Lite/Professional.

Also, a file stored in the machine can be viewed, downloaded or deleted using a Web Browser.

For more information about DeskTopBinder V2 Lite, see the DeskTopBinder V2 Lite manuals. See p.i "Manuals for This Machine".

Network Delivery Scanner


The machine is used as a delivery scanner with ScanRouter V2 Lite/Professional. Scan file from the originals scanned by the machine is stored in the delivery server and delivered to the folders of client computers on the same network.

₽ Reference

p.85 "Using the Network Delivery Scanner Function"

Note

☐ When the optional ScanRouter V2 Professional is used, the machine can also deliver scan file using e-mail, store scan file in the Document Server, and the file can be viewed from a client computer using a Web browser.



1. This machine

Scan file from the originals scanned by the scanner is sent to the delivery server. In combination with the file storage function, scan files from multiple originals that have been temporarily stored can be delivered all at once. See p.93 "Simultaneous Storage and Delivery".

2. Delivery server

ScanRouter V2 Lite/Professional is installed in this computer which is used as a delivery server.

Received file is delivered to the in-tray of the specified destination (1) in the figure). According to the settings of the intray, the file is stored in the in-tray or in a Windows folder (2) in the figure).

3. Client computer

The contents of stored file can be checked in the following ways:

- View the file in the in-tray using Desk-TopBinder V2 Lite to check the contents. (③ in the figure)
- Use Auto Document Link to receive the file stored in the in-tray, and check the contents with an application corresponding to the file format. (4) in the figure)
- Access the Windows folder where the file is stored via the network, and check the contents with an application corresponding to the file format. (⑤ in the figure)


₽ Reference

For more information about ScanRouter V2 Lite, DeskTopBinder V2 Lite, or Auto Document Link, see the respective documentation. See p.i "Manuals for This Machine".

Network TWAIN Scanner

The scanning function of this machine can be used from a client computer via a network (Ethernet, IEEE 1394 (IP over 1394) [optional], or IEEE 802.11b (Wireless LAN) [optional]). Originals can be scanned with the same operation used for SCSI- and USB-connected scanners.

p.95 "Using the Network TWAIN Scanner Function"



1. This machine


The scanning function of the machine can be used from a client computer via a network.

2. Client computer

Originals are scanned using the TWAIN driver for the machine from an application.

Control Panel

This illustration shows the control panel when options are installed.



1. [Use Tools/Counter] key

Use to change default or operation parameters according to the operating conditions.

2. Indicators

Display errors and the machine status.

₫: Add Staple indicator

≟: Add Paper indicator

?: Service Call indicator

☐ : Open Cover indicator

%: Misfeed indicator

For more information, see *General Settings Guide*.

3. Display panel

Displays the operation status and messages.

4. [Check Modes] key

Press to check the destinations which are currently selected.

5. [Program] key

Use to register settings used frequently as a program or to recall the registered program.

6. [Clear Modes] key

Press to clear the current settings.

7. [Energy Saver] key

Press this key to begin warm-up. Pressing this key again while in warm-up mode cancels warm-up.

Note

☐ This key is inactive while scanning or setting scanner defaults.

8. [Interrupt] key

Press this key to interrupt the scanner mode and to activate the copy mode.

9. Main power indicator and power indicator

The main power indicator lights up when the main power switch is set to on. The power indicator lights up when the machine is on.

∰Important

☐ Do not turn off the main power while the power indicator is lit or blinking. Doing so may cause a failure of the hard disk.

10. Operation switch

Press this switch to turn the machine on. The power indicator lights up. To turn the machine off, press this switch again.

☐ This key is inactive while scanning or setting scanner defaults.

11. Function status indicators

- When lit green, the corresponding function is active.
- When lit red, the corresponding function is interrupted. Press the respective key, and then follow the instructions that appear on the screen.

12. Function keys

Press the **[Copy]**, **[Document Server]**, **[Facsimile]**, **[Printer]**, or **[Scanner]** key to activate the respective function. The display content changes accordingly.

The indicator for the selected function lights up.

13. Number keys

Use to enter numeric values.

14. [#] key (Enter key)

Use to confirm the entered numeric value.

15. [Clear/Stop] key

- Clear: Clears an entered numeric value
- Stop: Stops scanning

16. [Start] key

Use to begin scanning, file storing, or delivery.

Display Contents

This section explains the normal screen configuration.

The display's contents differ depending on the function.

Note

☐ The Copy screen is set as the default screen when the machine is turned on. You can change this setting in the System Settings. See *General Settings Guide*.

Using e-mail

Press the **[Scanner]** key to display the e-mail screen (when **[E-mail/ Folder]** has been selected in **[Destination List Display Priority 1]** and **[E-mail Address]** has been selected in **[Destination List Display Priority 2]**). If the Network TWAIN Scanner screen appears, press **[Exit]**.



For information about Destination List Display Priority, see p.19 "Destination List Settings".

Using Scan to Folder

Press the **[Scanner]** key to display the Scan to Folder screen (When **[E-mail/Folder]** has been selected in **[Destination List Display Priority 1]** and **[Folder]** has been selected in **[Destination List Display Priority 2]**). If the Network TWAIN Scanner screen appears, press **[Exit]**.



For information about Destination List Display Priority, see p.19 "Destination List Settings".

Using as a network delivery scanner

Press the **[Scanner]** key to display the Network Delivery Scanner screen (when **[Delivery Server]** has been selected in **[Destination List Display Priority 1]**). If the Network TWAIN Scanner screen appears, press **[Exit]**.



For information about Destination List Display Priority, see p.19 "Destination List Settings".

Using as a network TWAIN scanner

When using the machine as a network TWAIN scanner, it is not necessary to press the **[Scanner]** key on the control panel. When the TWAIN driver becomes active on a client computer, the display automatically switches to the following screen.



Press [Exit] to use functions other than the network TWAIN scanner function.

2. Preparations for Use as a Network Scanner

To use the machine as a network scanner, you must make settings required for use as a scanner as well as basic settings for use in a network.

₽ Reference

First, see *General Settings Guide* for details about how to make basic settings, and then make scanner settings.

For more information about settings for sending by e-mail, see Network Guide.

Initial Scanner Setup

This section explains all required settings and procedures for using the machine as a network scanner.

Scanner Features

The settings for using the network scanner functions of the machine are listed below. Make the necessary settings.

Ø Note

☐ Make settings for the items marked with ○ if necessary.

Scan Settings

For explanations of settings, see p.14 "Scan Settings".

| Settings | | Default | E-mail | Scan to Folder | Store | Delivery | TWAIN |
|---|------------------|-----------------------------------|--------|-------------------|-------|----------|-------|
| Default Scan Settings | Scan Type | Black & White: Text (Print) | О | 0 | О | 0 | |
| | Resolution | 200 dpi | 0 | 0 | 0 | 0 | |
| | Image Density | Auto Image Density (Medium) | 0 | 0 | 0 | 0 | |
| | Scan Size | Auto Detect | 0 | 0 | 0 | 0 | |
| Wait Time for Next Orig.: Exposure Glass | | Set Wait Time (60 sec.) | 0 | О | 0 | О | |
| Wait Time for Next Original(s): SADF | | Set Wait Time (60 sec.) | О | О | О | О | |
| Original Setting | | 1 sided original | 0 | 0 | 0 | 0 | |
| Original Feed Type Priority | | Off | 0 | 0 | 0 | 0 | |
| Mixed Original Sizes Priority | | Off | O | 0 | О | 0 | |
| Original Orier | ntation Priority | h® | О | О | О | О | |

| Settings | Default | E-mail | Scan to Folder | Store | Delivery | TWAIN |
|--------------------------------------|------------------|--------|-------------------|-------|----------|-------|
| Change Initial Mode | Standard | 0 | 0 | 0 | О | |
| Auto Colour Select: Mode Priority | Black & White | О | О | 0 | О | |
| A.C.S. Sensitivity Level | Medium | 0 | 0 | 0 | О | |

Destination List Settings

For explanations of settings, see p.19 "Destination List Settings".

| Settings | Default | E-mail | Scan to Folder | Store | Delivery | TWAIN |
|--|--------------------|--------|-------------------|-------|----------|-------|
| Destination List Display Priority 1 | Delivery Server | 0 | 0 | | 0 | |
| Destination List Display Priority 2 | E-mail Address | 0 | 0 | | | |
| Select Title | Title 1 | О | 0 | | 0 | |
| Update Delivery Server Destination List | - | | | | О | |

Note

☐ [Destination List Display Priority 1] and [Update Delivery Server Destination List] will not be displayed when [OFF] is selected for [Delivery Option] in [File Transfer] of System Settings. See *Network Guide*.

Send Settings

For explanations of settings, see p.19 "Send Settings".

| Settings | Default | E-mail | Scan to Folder | Store | Delivery | TWAIN |
|---|------------------------|--------|-------------------|-------|----------|-------|
| TWAIN Standby Time | 10 sec. | 0 | 0 | 0 | 0 | 0 |
| File Type Priority | Multi-page: TIFF | О | О | | | |
| Compression (Black & White) | On | О | О | О | О | |
| Compression (Gray Scale/Full Colour) | High | О | О | О | О | |
| Print & Delete Scanner Journal | Delete oldest only | О | 0 | | 0 | |
| Max. E-mail Size | 2048KB | 0 | | | | |
| Divide & Send E-mail | Yes (per max. size) | О | | | | |
| E-mail Information Language | British English | 0 | | | | |
| Sender's Name Default | No | О | | | | |

Setting procedure

- 1 Press the [Use Tools/Counter] key.
- 2 Press [Scanner Features].
- 3 Press the item to be set.
- 4 Press the item to be set.



Example: TWAIN Standby Time setting

5 Change the setting.



- To select an item, touch its key on the screen. The item is highlighted.
- To enter numbers, use the number keys.
- Note
- ☐ To cancel changing a setting, press **[Cancel]**. The setting returns to the previous condition.
- 6 Press [OK].
- **7** Repeat steps **4** to **6** to make other settings.
- 8 Press [Exit].

The initial display reappears.

Scan Settings

This section explains how to set the defaults for scan settings.

The scan settings consist of the following. For the list about settings and defaults, see p.11 "Scanner Features".

♦ Default Scan Settings

Various basic settings (scan type, resolution, image density, scan size) can be set.

- Scan Type
 The scan method suitable for the original is set.
 - Auto Colour Select
 The colour of original is automatically detected, and then the original is scanned.

For black and white or gray scale scans, select from the following types.

- Text (Print)
 For standard originals containing mainly text (for print)
- Text (OCR)
 For standard originals containing mainly text (for OCR)
- Text/ Photo
 For originals containing a mix-ture of text and photographs
- Photo
 For originals containing photographs and other pictures (two-value)
- Gray Scale
 For originals containing photographs and other pictures (multi-value)

When the original is scanned in full colour, the following items should be set.

Text/ Photo
 For standard originals containing mainly text

- Glossy Photo
 For originals containing photographs or other pictures
- sRGB *1
 When scanning the original as a sRGB (international standard of colour space) image, select [On].
 This function is available when "Full Colour: Text/Photo" or "Full Colour: Glossy Photo" is selected.
 - *1 File Format Converter (optional) is required to use this function.

𝒯 Note

- ☐ Printer printing is best scanned with Text (Print). Text (OCR) is suitable for higher OCR accuracy.
- ☐ An image is scanned with black and white in "Photo", and with gray scale/full colour in "Gray Scale". As a general rule, scanning for the purpose of printing is best done with "Photo", and scanning for viewing on the computer screen with "Gray Scale".
- ☐ When **[Auto Colour Select]** is set and multi-page TIFF is specified for the file format, the format is automatically changed to PDF.
- Resolution
 Select the resolution from 100 dpi,
 200 dpi, 300 dpi, 400 dpi, or 600 dpi.
- Image Density
 Set the image density for Black & White/ Gray Scale scanning. The setting can be made in Auto Image Density or seven steps, from "Lighter" (1) to "Darker" (7).
 For full colour scans, set the image density. It can be set in seven steps from "Lighter" (1) to "Darker" (7).

• Scan Size

Select the size of the original to be scanned.

When [Auto Detect] is selected, the auto detect function of the machine is used to set the original size.

When the size is specified, scanning is performed for that size, regardless of the actual size of the original. The following sizes can be selected:

A3 \square , A4 \square , A4 \square , A5 \square , A5 \square , 11 \times 17 \square , 8¹/₂ \times 14 \square , 8¹/₂ \times 13 \square , 8¹/₂ \times 11 \square , 8¹/₂ \times 11 \square , 5¹/₂ \times 8¹/₂ \square , B4 JIS \square (Japanese Industrial Standard), B5 JIS \square , B5 JIS \square , Custom size

𝚱 Note

- ☐ When **[Custom size]** is selected, the dimensions of the scan area (width and height) can be specified.
- ☐ When selecting [Custom size] for [Scan Size], see p.17 "Selecting a custom size".

Wait Time for Next Orig.: Exposure Glass

When dividing originals and scanning them individually with the exposure glass to form a single file, select [Off], [Set Wait Time], or [Continuous Wait] for the waiting status.

Note

- ☐ If either **[SADF]** or **[Batch]** is specified when scanning, this setting is invalid.
- ☐ If **[Off]** is selected, sending will start automatically after one page of original is scanned.

- ☐ If [Set Wait Time] is selected, enter the waiting time in seconds (3-999) for placing additional originals with the number keys. Scanning will start when additional originals are placed and the [Start] key is pressed within this time. You can end scanning and begin sending by pressing the [#] key within this time. If the specified time has passed, sending starts automatically and you do not need to press the [#] key.
- ☐ If [Continuous Wait] is selected, the machine will wait for additional originals until the [#] key is pressed. Scanning will start when additional originals are placed and the [Start] key is pressed. You can end scanning and begin sending by pressing the [#] key.
- ☐ If originals are placed in the ADF, sending will start without waiting for additional originals after all originals in the ADF have been scanned even if you select [Continuous Wait].
- ☐ If a paper jam occurs or any of the following operation is performed while the machine is waiting for additional originals, the countdown stops and the machine will wait for additional originals until the [#] key is pressed.
 - Changing the settings such as the scan settings
 - Pressing the [Interrupt] key to activate the copy mode

Wait Time for Next Original(s): SADF When dividing originals and scanning them separately with the ADF to form a single file, select [Set Wait Time] or [Continuous Wait] for the waiting status.

Note

- ☐ If **[SADF]** is specified when scanning, this setting is valid.
- ☐ If [Set Wait Time] is selected, enter the waiting time in seconds (3-999) for placing additional originals with the number keys. Scanning will start automatically when additional originals are placed within this time. You can end scanning and begin sending by pressing the [#] key within this time. If the specified time has passed, sending starts automatically and you do not need to press the [#] key.
- ☐ If [Continuous Wait] is selected, the machine will wait for the additional originals until the [#] key is pressed. Scanning will start when additional originals are placed and the [Start] key is pressed. You can end scanning and begin sending by pressing the [#] key.
- ☐ Even if originals are placed on the exposure glass, the machine will function as the settings. However, every time originals are placed, you must press the 【Start】 key to start scanning.
- ☐ If a paper jam occurs or any of the following operation is performed while the machine is waiting for additional originals, the countdown stops and the machine will wait for additional originals until the [#] key is pressed.
 - Changing the settings such as the scan settings

 Pressing the [Interrupt] key to activate the copy mode

Original Setting

Set the default for whether originals are one-sided or two-sided and if two-sided, the relationship between those sides. When the originals are always the same, set this for the default to make operation easier. You can select [1 Sided Original], [2 Sided Orig.:T to T] (Top to Top), or [2 Sided Orig.:T to B] (Top to Bottom).

p.39 "Original Orientation and Scan Area"

Original Feed Type Priority

Multiple originals can be divided and scanned separately using the exposure glass or ADF to form a single file. In this case, the waiting time for placing additional originals to scan can be specified.

If [SADF] is selected, the [Wait Time for Next Original(s): SADF] setting will be valid when scanning.

If [Batch] is selected, scanning will start when the additional originals are placed and the [Start] key is pressed regardless of the setting for [Wait Time for Next Orig.: Exposure Glass] or [Wait Time for Next Original(s): SADF].

If [Off] is selected, the [Wait Time for Next Orig.: Exposure Glass] setting is valid when scanning.

Note

☐ The countdown for scanning additional originals stops when scanning conditions are changed. The machine keeps waiting for restarting the countdown until the [#] key is pressed.

Mixed Original Sizes Priority

This setting determines whether the original size is to be automatically detected when originals of different sizes are inserted in the ADF. You can select [On] or [Off].

Note

- ☐ If the original size is specified when scanning, this setting is ignored.
- ☐ When [Off] is selected and [Auto Detect] is selected for scan size, if originals of different sizes are placed in the ADF, the maximum size will be detected as the scan size.

Original Orientation Priority

Select the default for original placement orientation. When originals are always positioned the same way, select that orientation as the default to make operation easier.

p.39 "Original Orientation and Scan Area"

♦ Change Initial Mode

If you use the settings which are displayed when modes are cleared, reset, or immediately after the operation switch is turned on as the initial mode, select [Standard].

Select **[Program No.10]** when you use the settings stored in Program No. 10 as the initial mode.

❖ Auto Colour Select: Mode Priority Select either [Full Colour] or [Black & White] for the image quality when [Scan Type] is set to [Auto Colour Select].


A.C.S. Sensitivity Level

Set the sensitivity level for detecting colours/black and white to scan the original when [Scan Type] is set to [Auto Colour Select].

Selecting a custom size


When selecting **[Custom size]** as the scan size, follow the procedure below.

1 Press [Custom size] on the Scan Size Setting screen.




2 Enter the original size with the number keys.

Select and enter values for [X1] and [Y1], and then press the [#] key.



Enter the scan starting point in relation to the standard scan starting point.

Select and enter values for **[X2]** and **[Y2]**, and then press the **[#]** key.




4 Enter the scan size (area) with the number keys.

Select and enter values for [X3] and [Y3], and then press the [#] key.



Depending on how the original is positioned, the scan starting point will be as follows:



ZHSY055E

R⊈ shows the face of the original.

R

Shows the back of the original.

← shows the feeding direction.


The range of possible original sizes and scan sizes is as follows:

Original Size
 X1: 140 - 432 mm (5.5" - 17.0")
 Y1: 140 - 297 mm (5.5" - 11.7")


• Scan Size X3: 10 - 432 mm (0.4" - 17.0") Y3: 10 - 297 mm (0.4" - 11.7")

Keep the scan area settings within these range.

When all dimensions are entered, press [OK].



Make sure that the area specified in step 4 (X3 and Y3) is shown in the [Custom size] field, and then press [OK].



7 Press [Exit].

The initial display reappears.

Destination List Settings

This section explains how to set the defaults for the destination list and titles displayed.

The destination list settings consist of the following. For the list about settings and defaults, see p.11 "Scanner Features".

Destination List Display Priority 1

Select a destination list to be displayed when the machine is in the initial state. You can select either **[E-mail/Folder]** or **[Delivery Server]**.

Destination List Display Priority 1

This function is available when [E-mail/ Folder] is selected for [Destination List Display Priority 1].

Select a destination list of the machine to be displayed when the machine is in the initial state.

You can select either [E-mail Address] or [Folder].

Select Title

Select what titles are displayed on the screen. Selecting a title on the screen will display the destinations programed for that title. This allows for easy selection of destinations including e-mail destinations and Scan to Folder destinations. Select either [Title 1] (ten titles), [Title 2] (ten titles), or [Title 3] (five titles).

Update Delivery Server Destination List

To update the Delivery Server Destination List, press [Update Delivery Server Destination List].

Ordinarily, the Delivery Server Destination List is automatically updated. This function allows updating at any time.

Send Settings

This section explains how to set the defaults for sending settings such as the compression level for scan file and how the machine switches to the network TWAIN scanner function.

The send settings consist of the following. For the list about settings and defaults, see p.11 "Scanner Features".

TWAIN Standby Time

When the machine is being used to send e-mail or a file, or functioning as Document Server or a network delivery scanner, a scanning request to the machine as a TWAIN scanner will switch the machine to the network TWAIN scanner function. This setting determines the delay until the machine switches to the network TWAIN scanner function.

- When [Off] is selected, the machine will switch to the network TWAIN scanner function at once.
- When [On] is selected, you can enter the delay time with the number keys (3 - 30 seconds). The machine will switch to the network TWAIN scanner function when the time set here passes after the last key operation.

❖ File Type Priority

Select whether to send the file of scanned originals using a single page or multiple pages.

When sending using multiple pages, select either TIFF or PDF.

Note

- ☐ If you specify multi-page TIFF for file in a JPEG format, the format is automatically changed to PDF.
- ☐ When [Scan Type] is set to [Auto Colour Select] and multi-page TIFF is specified for the file format, the format is automatically changed to PDF.

Compression (Black & White)

This setting determines whether scan file for the black and white setting is to be compressed.

𝚱 Note

- ☐ The actual time required for file transfer will vary depending on the file size and network load.
- ☐ Compression reduces the time required for transferring the scan file.

Compression (Gray Scale/Full Colour)

This setting determines to what extent scan file for the grayscale or full colour setting is to be compressed. You can select [High], [Standard], [Low], or [Off].

Note

- ☐ The compression ratio decreases in the order [High], [Standard], [Low], and [Off], and the time required for file transfer increases accordingly.
- ☐ The actual time required for file transfer will vary depending on the file size and network load.

Print & Delete Scanner Journal

Select whether to print the Scanner Journal automatically when the number of delivelies or sendings reaches 100.

Note

- ☐ When printed, all records are deleted after printing. When not printed, records over the limit are automatically deleted in succession from the oldest record.
- ☐ While the journal is being printed, files waiting for sending cannot be sent.

❖ Max. E-mail Size

Select whether the size of an e-mail is limited or not.

When **[On]** is selected, enter the size limit (64 - 102400 KB) with the number keys.

Note

☐ When the SMTP limits the size, match that setting.

Divide & Send E-mail

This function is effective only when [On] is selected for [Max. Email Size].

Select whether or not an image exceeding the size specified in [Max. E-mail Size] should be divided and sent using more than one e-mail. Select either [No], [Yes (per Page)], or [Yes (per Max. Size)]. When [Yes (per Max. Size)] is selected, enter the Max. Number of Divisions (2-500) with the number keys.

- □ When [Multi-page: TIFF] or [Multi-page: PDF] is selected for [File Type Priority], the image will not be divided even if [Yes (per Page)] is selected.
- ☐ When [Yes (per Max. Size)] is selected, some received files may not be able to be restored, depending on the type of e-mail software.
- ☐ When [No] is selected, the e-mail is not sent if its size exceeds the limit, and an error message appears. The scan file is discarded.
- ☐ Set the maximum e-mail size within the capacity of the SMTP server.

❖ E-mail Information Language

Select a language for E-mail Information Language with which Title, Document name, Sender's name and others are sent.

Select one of the following 20 languages: British English, American English, German, French, Italian, Spanish, Dutch, Portuguese, Polish, Czech, Swedish, Finnish, Hungarian, Norwegian, Danish, Japanese, Simplified Chinese, Traditional Chinese, Russian, and Hangul.

Note

☐ The e-mail text which is a template cannot be changed.

Sender's Name Default

Select whether an administrator is registered as a sender or a sender is specified each time an e-mail is sent. If the access code has been set, enter the code with the number keys, and then press the [#] key.

- Select [No] when a sender is to be specified each time.
- Select **[Yes]** when an administrator is to be the sender.

∰Important

☐ It is recommended that protection code be set to prevent the sender's name from being misused.

Note

□ When [On] is selected for [Key Operator Code] in [Key Operator Tools] of System Settings and [Partial] is set for the range, enter the access code when [Sender's Name Default] is selected. For more information about the System Settings, see "User Tools (System Settings)", General Settings Guide.

Programs

You can register frequently used settings in the machine memory and recall them for future use.

Note

- ☐ You can register up to 10 programs for the scanner mode.
- ☐ You can use the settings registered in program No.10 as the initial mode by selecting [Program No.10] in [Change Initial Mode] in [Scanner Features].
- ☐ Programs are not deleted by turning the power off or by pressing the [Clear Modes] key. They are deleted only when you delete or overwrite them with another program.
- ☐ The items which can be registered as a program are as follows: the scan settings, 1 sided/2 sided original, Top to Top/Top to Bottom, Last Page, Original Feed Type, File Type, and Batch/SADF.

Registering a Program

- 1 Make the settings you want to register in the initial display of the scanner mode.
- **2** Press the [Program] key.



Press [Register].



Press the program number you want to register.

Note

- ☐ Program numbers with � already have settings in them.
- Enter the program name with the letter keys on the display panel.

You can enter up to 40 characters.



For details about entering characters, see "Entering Text", General Settings Guide.

Ø Note

☐ If it is not necessary to enter the program name, proceed to step **6**.

6 Press [OK].

When the settings are successfully registered, $\ \ \ \ \ \$ appears on the left side of the registered program number and the program name appears on the right side. The display returns to the initial display after a moment.

Recalling a Program

- Press the [Program] key in the initial display of the scanner mode.
- 2 Press [Recall].



Press the number of the program you want to recall.

The registered settings are displayed.

- Ø Note
- ☐ Program numbers with � already have settings in them.
- Place the originals, and then press the [Start] key.

Changing a Registered Program

- 1 Make sure the [Scanner] key is selected, press the [Program] key.
- 2 Press [Recall].
- Press the number of the program you want to change.
- 4 Change settings of the program.
- Press the [Program] key.
- 6 Press [Register].
- Press the number of the program you changed the setting.
- Press [Register] to accept the confirmation message.

- 9 Enter a program name.
- Press [OK].
 - Note
 - ☐ The registered program is deleted when you restore the program.

Deleting a Program

- 1 Make sure the [Scanner] key is selected, press the [Program] key.
- 2 Press [Delete].



- Press the number of the program you want to delete.
- 4 Press [Yes].

The program is deleted, and the display returns to the initial display after a moment.

Changing the program name

- Make sure the [Scanner] key is selected, press the [Program] key.
- 2 Press [Change Name].



- Press the number of the program you want to change name.
- 4 Enter a new program name.

A program name can be entered up to 40 characters.

For details about entering characters, see "Entering Text", *General Settings Guide*.

Press [OK].

The display returns to the initial display after a moment.

Installing Software

The machine comes with two CD-ROMs containing various software.

The CD-ROM labeled "Scanner Driver & Document Management Utilities" contains the necessary software to use the machine as a network scanner. The CD-ROM labeled "Printer Driver & Utilities" contains the necessary software to use the machine as a printer.

This section explains the software to use the machine as a network scanner.

Auto Run Program

When the CD-ROM is inserted into a client computer in Windows 95/98/Me, Windows XP, Windows 2000, or Windows NT 4.0, the installer starts automatically (Auto Run) to install the TWAIN driver and various software.

Ø Note


- ☐ Auto Run might not automatically work with certain operating system settings. In this case, launch "Set up.exe" located in the CD-ROM root directory.
- ☐ If you want to install the software without using Auto Run, hold down the **[Shift]** key while inserting the CD-ROM. Keep the **[Shift]** key held down until the client computer has finished accessing the CD-ROM.
- ☐ If **[Cancel]** is pressed during installation, the installation will be stopped and all the remaining software will not be installed. If **[Cancel]** has been pressed, reinstall the remaining software after restarting the client computer.

Limitation

☐ For installation in Windows 2000, Windows XP, or Windows NT 4.0, log in as a member of the administrators group.

The installing sequence using Auto Run is as follows:

Installation Sequence



For information about the software that can be installed by Auto Run, see p.29 "Software Supplied on CD-ROM".

Software for Using a Network TWAIN Scanner

To use the machine as a network TWAIN scanner, it is essential to install the TWAIN driver.

If you do not have applications that work with TWAIN, it is necessary to also install DeskTopBinder V2 Lite. For information about the installation of DeskTopBinder V2 Lite, see p.28 "DeskTopBinder V2 Lite".

Preparation

Before installation, check the system requirements for the TWAIN driver. See p.29 "Type 2238 TWAIN Driver".

Using Windows 95/98/Me, Windows XP, Windows 2000, or Windows NT 4.0

Install the TWAIN driver using Auto Run.

1 Start Windows, and then insert the supplied CD-ROM labeled "Scanner Driver & Document Management Utilities" into the CD-ROM drive of the client computer.

The CD-ROM Launcher screen appears.

If the installer does not start automatically, see p.25 "Auto Run Program".

2 Click [TWAIN Driver].

The Software Setup screen appears.

The installer of the TWAIN driver starts. Follow the instructions on the screen.

𝒯 Note

☐ When the installation is complete, a message to prompt you to restart the client computer may appear. In this case, restart the client computer.

- ☐ After the installation is complete, the "Type 2232C_2238C TWAIN V3" folder is in the "Program" folder on the Start menu. Help can be displayed from here.
- ☐ Notes on using the network TWAIN scanner are provided in "Readme.txt". Be sure to read them before use.

Software for Using the Network Delivery Scanner Function

To use the machine as a network delivery scanner, it is essential to install Scan-Router V2 Lite on the delivery server. To check an in-tray or retrieve file, it is necessary to install DeskTopBinder V2 Lite on the client computer.

Use Auto Run for installation.

Preparation

Before installation, check the system requirements for the software. See p.29 "Software Supplied on CD-ROM".

1 Start Windows, and then insert the supplied CD-ROM labeled "Scanner Driver & Document Management Utilities" into the CD-ROM drive of the client computer.

The CD-ROM Launcher screen appears.

- **2** Click the key of the software to be installed.
 - Click [ScanRouter V2 Lite], and then the ScanRouter V2 Lite Setup screen appears.
 - Click [DeskTopBinder V2 Lite], and then the DeskTopBinder V2 Lite Setup screen appears.
- Click [ScanRouter V2 Lite] or [DeskTopBinder V2 Lite]. The installer of the software starts. Follow the instructions on the screen.

For information about the subsequent installation procedure, see *Setup Guide* that can be displayed from the Setup screen of the respective software.

DeskTopBinder V2 Lite

Use Auto Run for installation.

Preparation

Before installation, check the system requirements for DeskTopBinder V2 Lite. See p.30 "DeskTopBinder V2 Lite".

1 Start Windows, and then insert the supplied CD-ROM labeled "Scanner Driver & Document Management Utilities" into the CD-ROM drive of the client computer.

The CD-ROM Launcher screen appears.

2 Click [DeskTopBinder V2 Lite].

The DeskTopBinder V2 Lite Setup screen appears.

Click [DeskTopBinder V2 Lite]. The Installer of the DeskTopBinder V2 Lite starts. Follow the instructions on the screem.

For information about the subsequent installation procedure, see *Setup Guide* that can be displayed from the Setup screen of DeskTopBinder V2 Lite

Software Supplied on CD-ROM

List of files

| SCD-ROM Drive | | | | |
|----------------------|----------|-----------|---|--|
| | □Drivers | □Twain | TWAIN driver for Windows 95/98/Me, Windows XP, Windows 2000, Windows NT 4.0 | |
| | □Utility | □RouterV2 | ScanRouter V2 Lite, ScanRouter V2 Administration Utility | |
| | | DeskV2 | ☐DeskTopBinder V2 Lite | |
| | | □Acroread | Acrobat Reader | |

Type 2238 TWAIN Driver

This driver is required to scan an original on the machine.

To use the machine as a network TWAIN scanner, this driver must be installed.

❖ File storage folder

The files are stored in the following folder on the CD-ROM provided with this machine:

\DRIVERS\TWAIN

System requirements

Limitation

- ☐ Under Windows NT with RISC-based processors (MIPS R series, Alpha AXP, or PowerPC), this driver is not available.
- Hardware PC/AT compatible
- CPU

Pentium or faster (Pentium 150 MHz or faster recommended)

• Operating system

Microsoft Windows 95 (OSR 2 or later)

Microsoft Windows 98

Microsoft Windows Millennium Edition (Windows Me)

Microsoft Windows 2000 Professional

Microsoft Windows 2000 Server

Microsoft Windows XP Home Edition

Microsoft Windows XP Professional

Microsoft Windows NT Workstation 4.0 (Service Pack 5 or later)

Microsoft Windows NT Server 4.0 (Service Pack 5 or later)

Memory

Operating system min. operation memory + 8 MB (64 MB or more recommended)

- Hard disk space 100 MB or more
- Display resolution 800 × 600 pixels, 256 colours or higher
- Network protocol TCP/IP

DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is to be installed on the client computers for integration and management of various kinds of file such as scan file, files created with applications, and existing scan files. This software allows you to use various functions for scan files stored in the Document Server, e.g., viewing stored files. Also, with ScanRouter V2 Lite, you can view the files stored in in-trays of the delivery server or use other functions for stored files.

See DeskTopBinder V2 Lite Help or the manuals for DeskTopBinder V2 Lite.

❖ File storage folder

The files are stored in the following folder on the CD-ROM provided with this machine:

\UTILITY\DESKV2

System requirements

- Hardware PC/AT compatible
- CPU

Pentium 133 MHz or faster (Pentium II 266 MHz or faster recommended)

Operating system

Microsoft Windows 95 (OSR 2 or later)

Microsoft Windows 98

Microsoft Windows Millennium Edition (Windows Me)

Microsoft Windows 2000 Professional (Service Pack 1 or later)

Microsoft Windows 2000 Server (Service Pack 1 or later)

Microsoft Windows XP Home Edition

Microsoft Windows XP Professional

Microsoft Windows Server 2003 Standard Edition

Microsoft Windows Server 2003 Enterprise Edition

Microsoft Windows Server 2003 Web Edition

Microsoft Windows NT Workstation 4.0 (Service Pack 5 or later)

Microsoft Windows NT Server 4.0 (Service Pack 5 or later)

Memory

48 MB or more (128 MB or more recommended)

• Hard disk space

50 MB or more (200 MB or more recommended)

• Display resolution

 800×600 pixels, 64K colours or higher

 Network protocol TCP/IP

Software installed with DeskTopBinder V2 Lite

Auto Document Link

Auto Document Link on the client computer monitors in-trays of the delivery server. In addition, the file delivered to in-trays can be retrieved or the arrival of file can be received at the client computer with this software.

Function Palette

Function Palette allows you to use functions such as the network TWAIN scanner, printing, printing preview, sending files by e-mail or sending faxes without starting DeskTopBinder V2 Lite. You must make settings in advance in the **[Extended Features...]** to use Function Palette. Refer to manuals related to DeskTopBinder V2/Lt for the details.

Extended Features Wizard

You can make settings equal to **[Extended Features...]** of the **[Tools]** menu with Extended Features Wizard. Refer to manuals related to DeskTop-Binder V2/Lt for the details.

ScanRouter V2 Lite

ScanRouter V2 Lite is to be installed on the delivery server. The scan file can be sorted in the delivery server, stored in specified in-trays, or saved in folders of client computers on the same network.

See the manuals for ScanRouter V2 Lite or ScanRouter V2 Lite Help.

❖ File storage folder

The files are stored in the following folder on the CD-ROM provided with this machine:

\UTILITY\ROUTERV2

System requirements

Limitation

- ☐ When installing the software in Windows NT Server or Windows 2000 Server, a stand-alone server must be used. Do not use the primary domain controller or backup domain controller.
- ☐ If you install this software in an operating system, such as Windows NT Workstation and Windows 2000 Professional, in which a client server is not permitted to be used in a network, you may violate the license agreement of Microsoft Corporation.
- ☐ Under Windows Server 2003, this software is not available.
- Hardware PC/AT compatible
- CPU

Pentium 200 MHz or faster (Pentium II 350 MHz or faster recommended)

• Operating system

Microsoft Windows 95 (OSR 2 or later)

Microsoft Windows 98

Microsoft Windows Millennium Edition

Microsoft Windows 2000 Professional (Service Pack 1 or later)

Microsoft Windows 2000 Server (Service Pack 1 or later)

Microsoft Windows XP Home Edition

Microsoft Windows XP Professional

Microsoft Windows NT Workstation 4.0 (Service Pack 5 or later)

Microsoft Windows NT Server 4.0 (Service Pack 5 or later)

Memory

64 MB or more (128 MB or more recommended)

Hard disk space

Minimum free space required for installing: 200 MB

Note

- ☐ In addition to the space required for installation, the hard disk should have at least 500 MB of free space for files.
- Network protocol TCP/IP

Software installed with ScanRouter V2 Lite

 ScanRouter V2 Administration Utility ScanRouter V2 Administration Utility manages the delivery system run by ScanRouter V2 Lite.

You can register destination and sender information for the scanned documents in the delivery server. In addition, you can perform maintenance for free disk space monitoring, error log recording, and other features of the delivery server.



☐ ScanRouter V2 Administration Utility can be installed not only on the delivery server but also on client computers. To install it, click [Scan-Router V2 Lite] on the ScanRouter V2 Lite Setup screen.

3. Setting Originals

This chapter explains the procedure for placing originals on the exposure glass and in the ADF, and setting the original scan area and orientation according to the placement method.

To correctly display the top/bottom orientation of the scanned original on a client computer, the placement of the original and the settings made on the control panel and scanner driver must match.

Placing Originals

There are two orientations for placing the original. See the table below.

Ø Note

□ Normally, an original is 🗈 or 🗈, but in the table below, a square original is used to make original orientation easy to understand. If the actual shape of the original is different, the combination of original orientation and the orientation specified on the control panel or scanner driver does not change.

Specifying original orientation and setting originals

| An original to be scanned | | [F | 3 | |
|--|---|---|---|--|
| Decide the placement method. | Exposure glas | ss | ADF | |
| Place the original. (There are two original orientations.) | Place the original so that the top edge touches the top left of the exposure glass. | Place the original so that the top edge touches the rear of the exposure glass. | Place the top edge of the original first. | Place the original so that the top edge touches the back of the ADF. |
| | | | | R |

| Specify the orientation. | When scanning using the e-mail function, the Scan to Folder function, the Docu- ment Server function, or the delivery scan- ner function. (Specified on the con- trol panel screen) | Original Orientation 限配 色色 | Original Orientation | Original Orientation | Original Orientation |
|--------------------------------------|---|-------------------------------|----------------------|----------------------|----------------------|
| | When scanning using the TWAIN scanner function (Specified in the Scan- ner Control dialog box) | ₩ ₩ | ← প্লীক্ষ | ◆ ⊠₩ | ← Ræ |
| The original displayed on a computer | | R | | | |

Placing on the Exposure Glass

Originals which do not fit into the ADF, such as sheets with glued-on parts, books, etc., can be placed directly on the exposure glass for scanning.

Note

- ☐ For information about the originals which can be placed on the exposure glass, see *Copy Reference*.
- 1 Lift the exposure glass cover or the ADF.


Note

☐ Lift the exposure glass cover or ADF more than 30 degrees. The opening/closing action triggers the automatic original size detection process.

Place the original on the exposure glass with the side to be scanned facing down. Align the original with the back left corner mark.

There are two original orientations.


When placing the original so that the top edge touches the rear of the exposure glass



1. Positioning mark

When placing the original so that the top edge touches the top left of the exposure glass

When using the machine as a network TWAIN scanner, this orientation is the standard setting for the TWAIN driver. Normally, use this orientation for placing originals.



1. Positioning mark

- **3** Lower the exposure glass cover or the ADF.
- 4 Select the original orientation according to the orientation of the placed original.

p.35 "Specifying original orientation and setting originals"

Proceed to p.39 "Original Orientation and Scan Area".

Placing in the Auto Document Feeder

The ADF allows you to place multiple originals at one time. Originals placed in the ADF can be scanned on one side or both sides.

Originals that can and cannot be placed in the ADF

For information about the originals that can and cannot be placed in the ADF, see *Copy Reference*.


Attempting to use unsuitable originals in the ADF can lead to a misfeed and damage to the originals. Place such originals directly on the exposure glass.

∰Important

- ☐ For information about which original sizes can be detected automatically and notes on placing originals in the ADF, see *Copy Reference*.
- **1** Adjust the original guide to match the size of the originals.
- Place the originals with the side to be scanned facing up. (For originals which are to be scanned on both sides, the first side should face up.)


There are two orientations.

When placing the originals so that the top edges touch the back of the ADF




When placing the top edges of the originals first

When using the machine as a network TWAIN scanner, this orientation is the standard setting for the TWAIN driver. Normally, use this orientation for placement.



𝚱 Note

☐ Originals with different sizes can be placed at the same time. Place the originals as shown:



1. ADF placement orientation

2. Height

- ☐ For information about the originals with different sizes, see p.41 "Mixed size selection".
- ☐ Originals are scanned in the inserted order, starting with the topmost page.
- 3 Select the original orientation according to the orientation of the placed originals.

p.35 "Specifying original orientation and setting originals"

Proceed to p.39 "Original Orientation and Scan Area".

Original Orientation and Scan Area

To correctly display the top/bottom orientation of a scanned original on a client computer, original orientation and page flow must be set when placing the original.

When using the e-mail function, the Scan to Folder function, the Document Server function, and the network delivery scanner function, settings are made on the control panel of the machine. When using the machine as a network TWAIN scanner, settings are made with the TWAIN driver.

Note


☐ The difference between scanning with the TWAIN scanner function and the e-mail function, the Scan to Folder function, the Document Server function, or the network delivery scanner function is shown in the following table:

| | TWAIN Scanner | E-mail/Scan to Folder/Document Server/Network Delivery Scanner |
|--------------------------------------|---|---|
| Auto Detect Non-Mixed Original Sizes | A whole batch of originals is scanned using the size of the first original. | Auto detection is used to determine the size of each original placed on the exposure glass. A whole batch of originals set in the ADF will be scanned by the maximum size original. |

| | TWAIN Scanner | E-mail/Scan to Folder/Document Server/Network Delivery Scanner |
|---|--|---|
| size Specification Auto Detect Mixed Original Sizes | Auto detection is mine the size of e | |
| Size Specification | When an original is smaller than the specified size, a blank space appears in the resulting image. | |

For E-mail, Scan to Folder, and a Network Delivery Scanner

1 Make settings for one-sided/two-sided combination.



☐ The defaults can be changed using **[Original Setting]** of Scanner Features. See p.14 "Scan Settings".

One-sided original/Two-sided original selection

- When scanning one-sided originals, make sure that [1 Sided Orig.] is selected.
- When scanning two-sided originals, press [2 Sided Orig.] to select [2 Sided Orig.:T to T] or [2 Sided Orig.:T to B] according to the binding orientation of the original.

Top to top original:



Top to bottom original:



When the last page of two-sided originals is blank, select [1 Side] to skip that side and finish scanning, or select [2 Sides] to scan that side as a blank page.

Ø Note

- □ When [1 Side] is selected for [Last Page], file size will be bigger than the one for the originals, and the e-mail cannot be sent beyond the limit of Max. E-mail Size. In this case, change the setting of [Max. E-mail Size] of [Scanner Features].
- 4 Press [OK].

2 Make settings for Batch/SADF, mixed original sizes, and original orientation by pressing [Original Feed Type].



Note

☐ The defaults can be changed using [Original Feed Type Priority], [Mixed Original Sizes Priority], and [Original Orientation Priority] of Scanner Features. See p.14 "Scan Settings"

Batch/SADF selection

■ When scanning a large number of originals by dividing the originals and scanning them individually or in batches, check that either [Batch] or [SADF] is selected.

𝚱 Note

□ Select [SADF], and the setting of [Wait Time for Next Original(s): SADF] of [Scan Settings] of [Scanner Features] is available. Or select [Batch], and the machine waits until additional originals are set. See p.42 "Scanning Originals in Several Times".

Mixed size selection

- When originals of different sizes are placed, select [Mixed size].
 - Ø Note
 - ☐ If [Mixed size] is selected and [Auto Detect] is selected for scan size, the maximum size detected is set as the scan size. For originals smaller than this size, a blank space will appear in the resulting image.
 - ☐ Originals of different width may be sometimes scanned a little slantways because the guide of the original cannot be fitted to the size of the small original.

Orientation selection

- Press the key for the same orientation as the actual orientation of the original, so or so.
 - **₽** Reference

p.35 "Specifying original orientation and setting originals"

- Press [OK].

 - ☐ The current settings are displayed.



For a Network TWAIN Scanner

- 1 Open the Scanner Properties dialog box.

p.96 "Scanning Originals"

- 2 Select the position from the [Document:] list in the [Document] area.
- 3 Select [♣♥/♣] or [♣®®/♣] from the [Orientation:] list.
 - **₽** Reference

p.35 "Specifying original orientation and setting originals"

When the originals are placed in the ADF, select [Simplex], [Duplex (Top to Top)], or [Duplex (Top to Bottom)] in the [Side:] list.

Note

☐ If originals of different sizes are placed in the ADF, specify the document size or detection method in the [Size:] box. If [Auto detection (Uni-size)] is selected, all originals are scanned using the size of the first page. If [Auto detection (Multi-size)] is selected, all originals are scanned according to their own width. For both Uni-size and Multi-size, all originals are scanned using their own length.

Scanning Originals in Several Times

Multiple originals can be scanned as a single file by dividing them and scanning them using the exposure glass or the ADF. When scanning originals dividing in several times, there are two waiting status for setting additional originals: specifying a time limit for additional originals or not.

Specifying a time limit for additional originals

In advance, specify the waiting time in seconds for placing the additional originals.

- Scanning using the exposure glass Select [Set Wait Time] for [Wait Time for Next Orig.: Exposure Glass].
- Scanning using the ADF Select [Set Wait Time] for [Wait Time for Next Original(s): SADF].

₽ Reference

p.15 "Wait Time for Next Orig.: Exposure Glass" or "Wait Time for Next Original(s): SADF"

- **1** Place the originals.
 - PReference p.35 "Placing Originals"
 - **𝚱** Note
 - ☐ Originals are scanned in order. Place them from the first page.

Make settings for scanning area and original orientation.



p.39 "Original Orientation and Scan Area"

Make settings for sending by email, Scan to Folder, storing, or delivering.

p.47 "Procedure for Sending E-mail"

p.61 "Procedure for Sending by Scan to Folder"

p.74 "Storage Procedure"

p.87 "Delivery Procedure"

When using the exposure glass

1 Press the [Start] key.

When scanning is finished, the remainder time until the additional original is placed is displayed.



When there are additional originals, place them within the specified time, and them press the [Start] key.

Repeat this procedure until the last original is scanned.

Note

☐ When the scan settings are changed while performing the procedure, the countdown for additional originals is stopped. After scanning is finished by pressing the [Start] key, the countdown will be restarted.

When using the ADF

- Select [SADF] in [Original Feed Type].
- 2 Press the [Start] key.

When scanning is finished, the remainder time until the additional original is placed is displayed.



3 When there are additional originals, repeat placing them within the specified time.

The machine starts scanning automatically.

∅ Note

- ☐ When the scan settings are changed while performing the procedure, the countdown for additional originals is stopped. After scanning is finished by pressing the [Start] key, the countdown will be restarted.
- ☐ You can also use the exposure glass instead of the ADF. In this case, you must press the **[Start]** key to start scanning.

4 When all originals are scanned and the countdown is finished, the machine starts storing or sending automatically.

Note


☐ You can also press the [#] key to restart storing or sending.

Not specifying a time limit for additional originals

- **1** Place the originals.
 - Reference
 See p.35 "Placing Originals".
 - Ø Note
 - ☐ Originals are scanned in order. Place them from the first page.
- Make settings for scanning area and original orientation.

p.39 "Original Orientation and Scan Area"

Select [Batch] for [Original Feed Type].



Make settings for sending by email, or Scan to Folder, storing, or delivering.

p.47 "Procedure for Sending Email"

p.61 "Procedure for Sending by Scan to Folder"

p.74 "Storage Procedure"

p.87 "Delivery Procedure"

5 Press the [Start] key.



6 When there are additional originals to scan, place them and press the [Start] key.

Repeat this step until all originals are scanned.

After all originals are scanned, press the [#] key.

Storing or sending will start.

4. Sending Scan File by E-mail

Scan file can be sent from this machine to a specified destination using e-mail system. This chapter explains the preparation for sending file by e-mail system, various display screens, procedures for sending, and how to check the sending result when this function is used.

Preparation for Sending by E-mail

To send by e-mail system, the preparation described below is required.

Ø Note

☐ Set up an e-mail server on the network in advance. For information about setting up an e-mail server, see the instruction manuals of the e-mail server to be used and the software to be installed.




Connect the machine to the network with an Ethernet cable or IEEE 1394 (optional) cable, or use Wireless LAN (optional). See *Network Guide*.



Make the network settings, settings for sending e-mail such as for the SMTP server and TCP/IP, or the destination (sender) settings in System Settings.

See Network Guide and General Settings Guide.




Make settings for sending e-mail such as file type priority and sender's default.

See p.19 "Send Settings".

E-mail Screen

The screen when using the machine for e-mail is as shown.



1. Destination field

The selected destination is shown here. If multiple destinations are selected, the destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].

Ø Note

☐ Pressing the **[Check Modes]** key lets you check the selected destinations.

2. [E-mail/Scan to Folder

Press to switch the e-mail function to the Scan to Folder function. You can send file to the destinations for both e-mail and Scan to Folder at the same time.

3. E-mail icon (🏩)

Shows that the screen for sending e-mail is displayed.

4. [Registration No.]

Press to specify a destination using a fivedigit registration number.

5. [Manual Input]

When specifying a destination that is not listed, press [Manual Input], and then enter the destination with the soft keyboard.

[Attach Sender's Name] [Subject/Message] [File Type]

Set the sender, subject, and message of the e-mail to be sent.

If necessary, set the file type and file name of the scan file attached to the email.

7. [🖭 Switch Destination List/Search/Switch Title

Press to switch a destination from the delivery server list to the destination list of this machine, to search for an e-mail destination, or to switch the titles.

8. Destination List

Displays the destinations programed in the delivery server or this machine.

Note


- □ When the entire list does not fit on one screen, [♠] or [▼] can be used to scroll through the display.
- ☐ Group destinations are denoted by this symbol (♣♣♣).

Sending Scan File by E-mail

Procedure for Sending E-mail

Scan file is sent after specifying scan settings and destinations.

1 Press the [Scanner] key.



2 If user codes are set, enter a user code with the number keys, and then press the [#] key.

The Scanner Function screen appears.

For information about user codes, see *General Settings Guide*.

Make sure that no previous settings remain.


𝚱 Note

- ☐ If a previous setting remains, press the **[Clear Modes]** key.
- 4 Place the original and then adjust the scan settings, settings for original size and orientation if required.

To make the scan settings, recall stored settings or make the settings individually.

p.14 "Scan Settings" p.35 "Setting Originals" Recalling stored scan settings

- 1 Press the [Program] key.
- 2 Select a program of scan settings.



The settings of the selected program are applied.

Making the settings individually

- 1 Press [Scan Settings].
- 2 Select items such as resolution and original size, and then change their settings.



Scan settings can be made in the same way as Default Scan Settings. See p.14 "Default Scan Settings".

- 3 Press [OK].
- If the network delivery scanner screen appears, switch to the screen for sending e-mail.
 - 1 Press [19].
 - 2 Press [Switch Destination List].



3 Press [E-mail].



4 Press [Exit].

The E-mail screen appears.

6 Specify the destination.

To specify a destination, you can select it from the list, select it by specifying a registration number, enter the e-mail address directly, search for the destination from the Destination List and selecting it, or search for the destination from the LDAP server and selecting it.

Note

- ☐ Before selecting the destination, be sure to select [To]. If necessary, select [Cc] or [Bcc] and the respective destinations.
- ☐ More than 500 destinations cannot be specified for [To], [Cc], and [Bcc]. See p.103 "Max. Number of Addresses Which Can Be Specified and Files Which Can Be Stored".

When selecting a destination from the list

• Press the title for the destination. The destinations for that title are displayed.

If the destination is not displayed, press $[\blacktriangle]$ or $[\blacktriangledown]$ to display the destination.



2 Select the destination to which the scan file is to be sent.



The selected destination is highlighted and also displayed in the destination field at the top of the screen.

3 To select more destinations, repeat steps 1 to 2.

𝚱 Note

□ To deselect a destination, press the destination once more, or press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.

Using a registration number to select a destination

- Press [Registration No.].
- 2 Use the number keys to enter the five-digit registration number that has been assigned to a destination.

If the entered number is less than five digits long, press the **[#]** key after the last number.

Example: To enter 00005

Press the **[5]** key, and then press the **[#]** key.



3 To select more destinations, repeat steps 1 to 2.

Note

□ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.

Manual entry of an e-mail address

• Press [Manual Input].

The soft keyboard is displayed for entering the e-mail address.

2 Enter the e-mail address.

Note

☐ It is possible to enter letters, numbers, @, and periods up to 128 characters. The symbols ()\,;:" cannot be used.

For information about how to enter characters, see *General Settings Guide*.

3 Press [OK].

Ø Note

- ☐ An e-mail address entered manually can be registered in the list. Press [ProgDest], and a screen for entering the address appears. For information about registering destinations, see *General Settings Guide*.
- ☐ To change an e-mail address that has been entered, press [Change] located on the left side of the destination field. A soft keyboard for entering the e-mail address is displayed. Make any changes, and then press [OK].

- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.
- 4 To enter more destinations, repeat steps 1 to 3.

Note

□ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.

Searching to select a destination from the Destination List

Press 🙉.



2 Press [Search by Dest. Name].





☐ To search using e-mail addresses, press [E-mail Address].

The soft keyboard is displayed for entering a user name.

3 Enter part of the destination name.

𝚱 Note

- ☐ Enter the first character or characters of the destination name.
- ☐ It is also possible to perform a combined search using [Search by Dest. Name] and [Email Address].
- ☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

- 4 Press [OK].
- 6 Select a destination.



6 Press [Exit].

Searching to select a destination from the LDAP server

1 Press [♣♥].




2 Press [Search LDAP].



3 Press [Advanced Search].



4 Enter information for each item of the destination.




Note

- ☐ Press the item, and the soft keyboard is displayed for entering information appears. Enter the first character or characters of the item.
- ☐ One reference item of Advanced Search can be added when [Search Options] is specified in [Program/ Change LDAP Server] of [Key Operator Tools] of System Settings. For more information, see "User Tools (System Settings)", General Settings Guide.
- ☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

6 Press [Search Criteria] corresponding to each item and then select criteria from the list to be displayed.



Note

- ☐ You can select criteria from the following list:
 - [Search Beginning Word]:
 The name located in front of an entered character is looked up.
 - [Search End Word]: The name located at the back of an entered character is looked up.
 - [Exact Match]: The name which corresponds to an entered character is looked up.
 - [Include One of Words]: The name which contains an entered character is looked up.
 - [Exclude Words]: The name which does not contain an entered character is looked up.
 - [Fuzzy Search]: a vague reference (The function of the vague reference depends on the system supported by the LDAP server.)

6 Press [OK].

𝒯 Note

☐ If a user name and password for the LDAP authentication are not set, a screen for entering a user name and password will appear. Enter them to log on.

- ☐ A destination cannot be specified as a proper address when the number of characters of the e-mail address searched from the LDAP server exceeds 128 characters.
- ☐ Some e-mail addresses can be registered for one person, but only one e-mail address can be hit by searching. Depending on the system supported by the LDAP server, generally, the address which was registered for first is hit.
- Select a destination.
- 8 Press [Exit].

𝚱 Note

☐ A searched e-mail address can be registered in the list. Press [ProgDest], and a screen for entering the address appears. For information about registering destinations, see *General Settings Guide*.

Checking selected destinations

• Use the destination field at the top of the screen to check which destinations are selected.

𝒯 Note

- □ When multiple destinations are selected, the selected destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].
- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.

- **7** Select the file type if necessary.
 - Press [File Type].
 - 2 Select the file type of the file to be attached to the e-mail from the displayed types.



- 3 Press [OK].
- Specify the file name of the file to be sent if necessary.
 - 1 Press [File Type].
 - 2 Press [File Name].

The soft keyboard is displayed for entering a file name.

- 3 Enter a file name.
- 4 Press [OK] twice.
- 9 Specify the e-mail sender.

To specify a sender, you can select the sender from the list, enter the five-digit registration number of the sender with the number keys, and search for the sender and selecting it.


Note

- ☐ The operation of step ② is unnecessary when [Yes] is specified for [Sender's Name Default] in [Send Settings] of [Scanner Features]. Proceed to step ①.
- ☐ When a sender is selected, the sender name is automatically placed in the From field of the email so that the sender can be identified when the e-mail is received.


- ☐ To prevent misuse of a sender name, we recommend you set protection code for that sender name.
- ☐ Be sure to select or enter a sender name. Otherwise Key Operator's E-mail Address is used as the sender name. See *General Settings Guide*.

When selecting a sender from the list


• Press [Attach Sender's Name].



2 Select the sender.



- **𝒯** Note
- ☐ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name is displayed.
- **3** For a reception confirmation email, press [Return Receipt].



Note

□ When [Return Receipt] is selected, an e-mail notifying that the e-mail has been read by the destination party is sent to the sender selected here. However, if the mailing software used by the destination party does not support MDN (Message Disposition Notification), the e-mail may not be sent.

4 Press [OK].

Using a registration number to specify a sender name

• Press [Attach Sender's Name].



2 Use the number keys to enter the five-digit registration number that has been assigned to a sender.

If the entered number is less than five digits long, press the [#] key after the last number.


Example: To enter 00004

Press the [4] key, and then press the [#] key.



Note

- ☐ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name and [Return Receipt] are displayed.
- **3** For a reception confirmation email, press [Return Receipt].



Note

- □ When [Return Receipt] is selected, an e-mail notifying that the e-mail has been read by the destination party is sent to the sender selected here. However, if the mailing software used by the destination party does not support MDN (Message Disposition Notification), the e-mail may not be sent.
- 4 Press [OK].

Searching to select a sender

1 Press [Attach Sender's Name].



2 Press [<u>__</u>].



3 Press [User (Dest.) Name].

To search using e-mail addresses, press [E-mail Address].



The soft keyboard is displayed for entering a user name.

4 Enter part of the sender name.




- ☐ Enter the first character or characters of the sender name.
- ☐ It is also possible to perform a combined search using [User (Dest.) Name] and [E-mail Address].
- ☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

- 6 Press [OK].
- **6** Select the sender.



- ☐ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name is highlighted.
- Press [Exit].
- **3** For a reception confirmation email, press [Return Receipt].



𝚱 Note

- □ When [Return Receipt] is selected, an e-mail notifying that the e-mail has been read by the destination party is sent to the sender selected here. However, if the mailing software used by the destination party does not support MDN (Message Disposition Notification), the setting in [Return Receipt] becomes invalid.
- Press [OK].

1 Specify a subject if necessary.

Note


- ☐ When a subject has been set, this information is added to the scan file. The subject name is automatically placed in the Subject field of the e-mail.
- ☐ To specify a subject name, you can select it from the list, enter it directly, or combine selecting and entering it.
- ☐ Subject name to select from the list must be registered in System Settings in advance. See *Network Guide*.
- ☐ Subject name can be entered up to 64 characters including characters of the name selected from the list.

The operation to specify a subject name "[Urgent] New product appearance" is explained as an example here.

- Press [Subject/Message].
- 2 Press [Attach Subject].



3 Select a subject [Urgent].



4 Press [Manual Input].


The soft keyboard is displayed for entering a subject.

6 Enter the subject "New product appearance".

₽ Reference

For information about how to enter characters, see *General Settings Guide*.

6 Press [OK].



- Press [OK].
- 11 Enter a messsage if necessary.

Note

- ☐ When a message has been entered, this information is added to the scan file.
- ☐ Message to select from the list must be registered in System Settings in advance. See *Network Guide*.
- ☐ Message can be entered to up to 80 characters.
- ☐ To specify a message, you can select it from the list, or enter it directly.

When selecting a message from the list

- Press [Subject/Message].
- 2 Press [E-mail Message].



3 Select a message.



4 Press [OK] twice.

Manual entry of a message

The operation to specify a message "Thank you for what you did yesterday." is explained as an example here.

- Press [Subject/Message].
- 2 Press [E-mail Message].



3 Press [Manual Input].

The soft keyboard is displayed for entering a message.

4 Enter the message "Thank you for what you did yesterday".

For information about how to enter characters, see *General Settings Guide*.

- Note
- ☐ Message can be entered to up to 80 characters.
- 6 Press [OK] three times.



12 Press the [Start] key.

Note

- ☐ To interrupt scanning, press the **[Clear/Stop]** key or press **[Stop]** on the screen.
- ☐ When using the Batch function or the SADF function, place the next original after the others have been scanned. See p.42 "Scanning Originals in Several Times".
- ☐ Regardless of the divide e-mail size setting, it is not possible to send e-mail with over 725.3MB of data. It is also not possible to send over 1,000 pages of file.

Simultaneous Storage and Sending by E-mail

You can use sending file by e-mail with storing file in the Document Server.

Scan file is stored in the Document Server at the same time the file is sent by e-mail.

Note

- ☐ This section explains mainly the operation for simultaneous storage and sending of e-mail. For more information, see p.47 "Procedure for Sending E-mail".
- ☐ The file stored when simultaneously storing file and sending file by e-mail cannot be resent in the E-mail screen. To resend the file, select the file in the Select Stored File screen and send it. See p.81 "Sending Stored Files by E-mail or Scan to Folder, or Delivering".

1 Place the original, and then adjust the settings for original size and orientation if required.

p.35 "Setting Originals"

- **2** Make the scan settings.
- **3** Select the destination.
- **4** Specify the sender and a subject if necessary.
- Press [Store File].



Make sure [Send & Store] is selected.



- **7** Set file information if necessary.
 - Reference
 p.75 "Specifying file information"
- 8 Press [OK].
- 9 Press the [Start] key.

Checking the Status of E-mail

The status of the last 100 sendings can be checked. For every new sending record after 100, the oldest record is deleted.

Ø Note

☐ When [Print & Delete Scanner Journal] is set to [Delete All after Printing], the whole journal is printed when the number of records reaches 100.

Items that can be checked

• Date/Time

The date and time the e-mail was sent or the date which "Error" or "Cancelled" is confirmed is displayed.

Destination

A used sending function (e-mail, Scan to Folder, or delivery function) is displayed with an icon.

When multiple destinations were selected, the first selected destination is displayed.


- Sender
- File Name

The file name is displayed only when storing a file and sending e-mail are performed simultaneously by pressing [Send & Store] or resending the file stored.


Status

Either of the following status is displayed: "Done", "Sending", "Waiting", "Error", or "Cancelled".

1 Press [Scanned Files Status] on the screen for sending e-mail.



2 Check the displayed records.



- Ø Note
- □ One screen shows the records for five sending operations. Use
 [▲ Prev.] or [▼ Next] to scroll through the screen.
- ☐ When the status of a file is waiting, the sending can be stopped by selecting that file, and then pressing [Cancel].
- ☐ Press [**Print**], and the whole journal is printed.

Press [Exit].

The display returns to the screen for sending e-mail.

5. Sending Scan File by Scan to Folder

Scan file can be sent to the folders of the FTP server or the shared folders of Windows. This chapter explains the preparation for sending file by Scan to Folder, various display screens, procedures for sending, and how to check the sending result when this function is used.

Preparation for Sending by Scan to Folder

To send by Scan to Folder, the preparation described below is required.



Connect the machine to the network with an Ethernet cable or IEEE 1394 (optional) cable, or use Wireless LAN (optional). See *Network Guide*.



Make the network settings, settings for sending by Scan to Folder such as for protocols, or the destination (sender) settings in System Settings.

See Network Guide and General Settings Guide.




Make settings for sending such as compression and file type priority.

See p.19 "Send Settings".

Sending files using SMB protocol is available only under the environment of NetBIOS over TCP/IP. Sending files using SMB protocol is not available under the NetBEUI environment.

Scan to Folder Screen

The screen when using the machine for Scan to Folder is as shown.



1. Destination field

The selected destination is shown here. If multiple destinations are selected, the destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].

Ø Note

☐ Pressing the **[Check Modes]** key lets you check the selected destinations.

2. [E-mail/Scan to Folder

Press to switch the Scan to Folder function to the e-mail function. You can send file to the destinations for both Scan to Folder and e-mail at the same time.

3. Scan to Folder icon ()

Shows that the screen for sending by Scan to Folder is displayed.

4. [Registration No.]

Press to specify a destination using a fivedigit registration number.

5. [Enter Destination]

When specifying a destination that is not listed, press **[Enter Destination]**, and then enter the destination with the soft keyboard.

6. [Attach Sender's Name] [Subject/Message] [File Type]

Set the sender, subject, and message of the scan file to be sent.

Set the file type and file name of the scan file to be sent.

∰Important

☐ When the scan file is sent to the destinations for both e-mail and Scan to Folder at the same time, the sender, subject, and message are sent to the destination for e-mail only.

7. [Switch Destination List/Search/Switch Title

Press to switch a destination from the delivery server list to the destination list of this machine, to search for a destination, or to switch the titles.

8. Destination List

Displays the destinations programed in the delivery server or this machine.

Note

- □ When the entire list does not fit on one screen, [♠] or [▼] can be used to scroll through the display.
- ☐ Group destinations are denoted by this symbol (♣♣♣).


5

Sending Scan File by Scan to Folder

Procedure for Sending by Scan to Folder

Scan file is sent after specifying scan settings and destinations.

1 Press the [Scanner] key.



ZHFS013E

2 If user codes are set, enter a user code with the number keys, and then press the [#] key.

The Scanner Function screen appears.

For information about user codes, see *General Settings Guide*.

Make sure that no previous settings remain.

Note


- ☐ If a previous setting remains, press the [Clear Modes] key.
- Place the original, and then adjust the scan settings, settings for original size and orientation if required.

To make the scan settings, recall stored settings or make the settings individually.

P Reference

p.14 "Scan Settings" p.35 "Setting Originals" Recalling stored scan settings

- 1 Press the [Program] key.
- 2 Select a program of scan settings.



The settings of the selected program are applied.

Making the settings individually

- Press [Scan Settings].
- 2 Select items such as resolution and original size, and then change their settings.



Scan settings can be made in the same way as Default Scan Settings. See p.14 "Default Scan Settings".

- 3 Press [OK].
- If the network delivery scanner screen appears, switch to the screen for Scan to Folder.
 - $lue{1}$ Press $lue{1}$.
 - 2 Press [Switch Destination List].



3 Press [E-mail].



4 Press [Exit].

The E-mail screen appears.

6 Press [🙉].

The Scan to Folder screen appears.

6 Specify the destination folder.

To specify the destination folder, you can select it from the list, select it by specifying a registration number, enter the path for the folder of the client computers on the same network directly, specify the folder in the FTP server, or select the destination from the client computers on the same network.

When selecting a destination folder from the list

Press the title for the destination folder. The destination folders for that title are displayed.

If the folder is not displayed, press $[\blacktriangle]$ or $[\blacktriangledown]$ to display the other folders.



2 Select the destination folder to which the scan file is to be sent.



The selected folder is highlighted and also is displayed in the destination field at the top of the screen.

Ø Note

- ☐ If a protection code has been set for the shared folder, a screen for entering the protection code appears.
- 3 To select more destination folders, repeat step 2.

Note

□ To deselect a destination, press the destination once more, or press [A Prev.] or [V Next] to display the destination in the destination field, and then press the [Clear/Stop] key.


Using a registration number to select a destination folder

- Press [Registration No.].
- 2 Use the number keys to enter the five-digit registration number that has been assigned to a destination folder.

If the entered number is less than five digits long, press the [#] key after the last number.

Example: To enter 00001

Press the [1] key, and then press the [#] key.



Note


☐ If a protection code has been set for the shared folder, a screen for entering the protection code appears. 3 To select more destination folders, repeat step 2.

Note

□ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.

Manual entry of a path for the destination folder of the client computers on the same network

- Press [Enter Destination].
- 2 Press [SMB].



3 Press [Manual Input] on the right side of the path field.

The soft keyboard is displayed for entering the path for the folder.

4 Enter the path for the folder.

Note

- ☐ This is an example of entering a pass to send to the folder "user" of the computer "desk01". \\desk01\user
- ☐ An IP address can be also entered if you use the following operating systems are available: Windows 98/Me, Windows XP, Windows 2000, Windows NT 4.0.

₽ Reference

For information about how to enter characters, see *General Settings Guide*.

6 Press [OK].

6 If entering a user name to log on is required, press [Manual Input] on the right side of the user name field.

The soft keyboard is displayed for entering the user name field.

- **7** Enter the user name.
- Press [OK].
- If entering a password to log on is required, press [Manual Input] on the right side of the password field.

The soft keyboard is displayed for entering a password.

- **10** Enter a password.
- Press [OK].
- Press [Connection Test].



A connection test is performed to check whether the specified shared folder exists.


𝚱 Note

- ☐ To change the path for the folder that has been entered, press [Change] located on the left side of the destination field. Enter a path for the folder properly, and then press [OK].
- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.
- ☐ The connection test sometimes takes time.

- ☐ [Connection Test] can not be pressed right after [Cancel] was pressed during the connection test.
- ☐ Though the connection test is succeeded, the machine sometimes fails in the file transfer, when the shared folder lacks writing authority or when there is no space in the hard disk.
- (3) To enter more destinations, repeat steps (1) to (2).
 - **𝚱** Note
 - □ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.
- Press [OK].

Specifying a folder in the FTP server

- 1 Press [Enter Destination].
- 2 Press [FTP].



A confirmation message for changing the protocol appears.

- 3 Press [Yes].
- 4 Press [Manual Input] on the right side of the server name field.



The soft keyboard is displayed for entering the server name.

- **6** Enter a server name.
 - Note
 - ☐ An IP address can be also entered.
- 6 Press [OK].
- **?** Press [Manual Input] on the right side of the path field.

The soft keyboard is displayed for entering the path for the folder.

- **8** Enter the path for the folder.
 - **𝚱** Note
 - ☐ This is a pass to send to the sub-folder "lib" in the folder "user". user\lib
 - **₽** Reference

For information about how to enter characters, see *General Settings Guide*.

- Press [OK].
- If entering a user name to log on is required, press [Manual Input] on the right side of the user name.

The soft keyboard is displayed for entering the user name.

- **1** Enter the user name.
- Press [OK].
- (B) If entering a password to log on is required, press [Manual Input] for password.

The soft keyboard is displayed for entering a password.

- 1 Enter a password.
- Press [OK].
- To change the port number which is set in the initial scan setting, press [Change] on the right side of the Port No. field. Enter a port number using the number keys, and then press [#].

Press [Connection Test].




A connection test is performed to check whether the specified shared folder exists.

Note

- ☐ To change a path for the folder that has been entered, press [Change] located on the left side of the destination field. Enter a path for the folder properly, and then press [OK].
- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.
- ☐ The connection test sometimes takes time.
- ☐ [Connection Test] can not be pressed right after [Cancel] was pressed during the connection test.
- To enter more destinations, repeat steps 1 to 7.
 - **𝚱** Note
 - □ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.
- Press [OK].

Searching to select a destination folder from the network

• Press [Enter Destination].




2 Press [SMB].



3 Press [Browse Network] on the right side of the path field.

The client computers list on the same network appears.

- **𝚱** Note
- □ Workgroup names or domain names must be set properly to browse the network.
- ☐ If the client computer you want to select is not displayed, press [Up One Level] to select other workgroups, and then you can search for the client computer.
- ☐ The maximum number of client computers and shared folders displayed is 100.
- **4** Select the client computer that has the destination folder.



Note

☐ The log on screen is displayed when the machine is required to authenticate the selected computer. Enter the user name and password correctly.

The folders list of the selected computer appears.

3 Select the destination folder.

∅ Note

☐ When the selected folder has sub-folders, the sub-folders list appears.



- 6 Press [OK].
- If entering a user name to log on is required, press [Manual Input] on the right side of the user name field.

The soft keyboard is displayed for entering a user name.


- 8 Enter a user name.
- Press [OK].
- ① If entering a password to log on is required, press [Manual Input] on the right side of the password field.

The soft keyboard is displayed for entering a password.

- **1** Enter a password.
- Press [OK] twice.

Searching to select a destination folder from the Destination List

● Press 🙉.



2 Press [Search by Dest. Name].



The soft keyboard is displayed for entering a user name.

3 Enter part of the destination folder name.



- ☐ Enter the first character or characters of the destination name.
- ☐ It is necessary to differentiate between capital and small letters.

₽ Reference

For information about how to enter characters, see *General Settings Guide*.

- 4 Press [OK].
- **6** Select a destination folder.



6 Press [Exit].

Checking selected destinations

- Use the destination field at the top of the screen to check which destinations are selected.
 - Note
 - □ When multiple destinations are selected, the selected destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].
 - ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.
- **7** Select the file type if necessary.
 - Press [File Type].
 - 2 Select the file type of the file to be sent from the displayed types.



- 3 Press [OK].
- Specify the file name of the file to be sent if necessary.
 - 1 Press [File Type].
 - 2 Press [File Name].

The soft keyboard is displayed for entering a file name.

3 Enter a file name.

Note

☐ The scan file is given a 21-digit (except the extension) file name which combines the time and date of scanning originals with a 4-digit page number. (Example: When one page is scanned in TIFF at 15.10 seconds, 3.30 p.m., 31 December, 2003, the file name is 200312311530150100001.tif)

4 Press [OK].



- 6 Press [OK].
- **9** Select a sender if necessary.

To specify a sender, you can select the sender from the list, enter the five-digit registration number of the sender with the number keys, and search for the sender and selecting it.

Note

- ☐ When the sender name is specified in this step, it is displayed in the journal.
- ☐ To prevent misuse of a sender name, we recommend you set a protection code for that sender name.
- ☐ Be sure to select or enter a sender name. Otherwise Key Operator's E-mail Address is used as the sender name. See *General Settings Guide*.

When selecting a sender from the list

1 Press [Attach Sender's Name].



2 Select the sender.




Note

☐ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name is displayed.

3 Press [OK].

Using a registration number to specify a sender name

• Press [Attach Sender's Name].




2 Use the number keys to enter the five-digit registration number that has been assigned to a sender.

If the entered number is less than five digits long, press the [#] key after the last number.

Example: To enter 00002

Press the [2] key, and then press the [#] key.




☐ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name and [Return Receipt] are displayed.

3 Press [OK].

Searching to select a sender

1 Press [Attach Sender's Name].



2 Press [<u>__</u>].



3 Press [User (Dest.) Name].



The soft keyboard is displayed for entering a sender name.

4 Enter part of the sender name.

Ø Note

- ☐ Enter the first character or characters of the sender name.
- ☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

- 6 Press [OK].
- 6 Select the sender.



𝒯 Note

- □ When a protection code has been set, a screen for entering the protection code appears after selecting the sender. Enter the protection code, and then press [OK]. When the protection code you entered is correct, the sender name is highlighted.
- Press [Exit].
- Press [OK].

Press the [Start] key.

- ☐ To interrupt scanning, press the **[Clear/Stop]** key or press **[Stop]** on the screen.
- ☐ When using the Batch function or the SADF function, place the next original after the others have been scanned. See p.42 "Scanning Originals in Several Times".
- ☐ A file beyond 2000 MB cannot be sent.

Simultaneous Storage and Sending by Scan to Folder

You can use sending file by Scan to Folder with storing file in the Document Server.

Scan file is stored in the Document Server at the same time the file is sent by Scan to Folder.

Ø Note

- ☐ This section explains mainly the operation for simultaneous storage and sending by Scan to Folder. For more information, see p.61 "Procedure for Sending by Scan to Folder".
- ☐ The file stored when simultaneously storing file and sending file by Scan to Folder cannot be resent in the Scan to Folder screen. To resend the file, select the file in the Select Stored File screen and send it. See p.81 "Sending Stored Files by E-mail or Scan to Folder, or Delivering".

- 1 Place the original, and then adjust the settings for original size and orientation if required.
 - PReference p.35 "Setting Originals"
- **2** Make the scan settings.
- **3** Select the destination.
- A Specify the sender name, subject, and message when storing a file and sending e-mail are performed at the same time.
- Press [Store File].



Make sure [Send & Store] is selected.



- **7** Set file information if necessary.
 - PReference
 p.75 "Specifying file information"
- Press [OK].
- 9 Press the [Start] key.

Checking the Status of Scan to Folder

The status of the last 100 sendings can be checked. For every new sending record after 100, the oldest record is deleted.

Note

☐ When [Print & Delete Scanner Journal] is set to [Delete All after Printing], the whole journal is printed when the number of records reaches 100.

Items that can be checked

Date/Time
 The date and time the sending was requested or the date which "Error" or "Cancelled" is confirmed is displayed.

Destination


A used sending function (e-mail, Scan to Folder, or delivery function) is displayed with an icon.

When multiple destinations were selected, the destinations are displayed individually.

- Sender
- File Name
 The file name is displayed by pressing [Send & Store] or resending the file stored.
- Status
 Either of the following status is
 displayed: "Done", "Sending",
 "Waiting", "Error", or "Cancelled".
- 1 Press [Scanned Files Status] on the screen for Scan to Folder.



2 Check the displayed records.



Ø Note

- □ One screen shows the records for five sending operations. Use
 [▲ Prev.] or [▼ Next] to scroll through the screen.
- □ When the status of a document is waiting, the sending can be stopped by selecting that document, and then pressing [Cancel].
- ☐ Press [**Print**], and the whole journal is printed.

Press [Exit].

The display returns to the screen for sending by Scan to Folder.

6. Using the Document Server Function

Scan file obtained by scanning originals can be stored in the hard disk of the machine using the Document Server, and the stored file can be used later. Using DeskTopBinder V2 Lite/Professional, stored file can be viewed, retrieved, or deleted with a client computer.

The stored file can also be viewed, downloaded, printed, or deleted using Web browser from a client computer.

For more information about using the Document Server, see *General Settings Guide*.

∰Important

- ☐ A password can be set for every stored file in the Document Server. There is a fear that stored files with no password can be accessed by the user who uses DeskTopBinder V2 Lite/Professional. We recommend you should consider a security system such as setting a password that protects illegal accesses.
- ☐ Scan file stored in the machine might be lost if some kind of failure occurs. The supplier shall not be responsible for any damage that might result from the loss of file. For long-term storage of files, we recommend the use of Desk-TopBinder V2 Lite or DeskTopBinder V2 Professional (optional). For more information, please contact your local dealer.

Note

□ When a delivery server is added to the network, files stored in the Document Server can be delivered. You can store scan files in the Document Server and simultaneously deliver it with the network delivery scanner function, send it by e-mail, or send it by Scan to Folder. See p.81 "Sending Stored Files by E-mail or Scan to Folder, or Delivering".

Storing Files

This section describes how to store files in the Document Server and how to specify file information for stored files.


Ø Note

- ☐ The files stored in the Document Server are deleted automatically after a certain number of days have passed. For information about making settings and changes, see *General Settings Guide*.
- ☐ The theoretical maximum number of files that can be stored is 2,000 (1,000 pages per file). However, the actual maximum may be less depending on the space used by the copier function and other functions of the machine.
- ☐ Stored file scanned using the scanner function cannot be printed from the control panel. Print the file after retrieving them, using DeskTopBinder V2 Lite/Professional.

Storage Procedure

Scan and store the file in the Document Server.

1 Press the [Scanner] key.



2 If the user codes are set, enter a user code with the number keys, and then press the [#] key.

The Scanner Function screen appears.

For information about the user codes, see General Settings Guide.

Make sure that no previous settings remain.

Note

- \square If a previous setting remains, press the [Clear Modes] key.
- 4 Place the original in the machine, and then adjust the settings for original size and orientation if required.

p.35 "Setting Originals"


5 Make the scan settings.

To make the scan settings, recall the stored settings or make the settings individually.

p.14 "Scan Settings"

Recalling stored scan settings

- Press the [Program] key.
- 2 Select a user program of scan settings.



The selected user program settings are applied.

Making settings individually

- Press [Scan Settings].
- 2 Select items such as resolution and original size and change their settings.



Scan settings can be made in the same way as Default Scan Settings. See p.14 "Default Scan Settings".

- **3** Press [**0**K].
- **6** Make the settings for storing scan files.
 - Press [Store File].



2 Press [Store Only].



𝚱 Note

- ☐ To store and deliver scan files, press [Send & Store]. See p.56 "Simultaneous Storage and Sending by E-mail", p.69 "Simultaneous Storage and Sending by Scan to Folder", or p.93 "Simultaneous Storage and Delivery".
- ☐ [Store Only] cannot be pressed if even a single destination or sender is selected.
- 3 Press [OK].

7 Specify file information.

Specify a user name, file name, and password for the file to be stored.

For more information about how to specify file information, see p.75 "Specifying file information".

8 Press the [Start] key.

∅ Note

- ☐ To abort the scanning process, press the **[Clear/Stop]** key or press **[Stop]** on the screen.
- ☐ When using the SADF function, place the next original after the others have been scanned. See p.42 "Scanning Originals in Several Times".

Specifying file information

You can specify a user name, file name, and password for a stored scan file.

According to the settings made, you can search for files by user name or file name and you can prevent unauthorized persons from accessing the files.

Note

☐ The file name can be up to 64 characters long. The user name can be up to 20 characters long. The first 15 characters are shown on the control panel. From a client computer with DeskTopBinder V2 Lite/Professional installed, you can view all the characters entered.

1 Press [Store File].



The File Information screen appears.



2 Specify file information.

Specifying a user name

1 Press [User Name].

Note


- ☐ If no user code is programed on the Key Operator Tools tab in System Settings, the User Code screen does not appear. Instead, the Non-programmed Name screen appears. Enter any user name.
- 2 Select the user name.

| U: | ser Name | | Clear | | Non-programmed Name | |
|----|---------------|---------------|--------------|-----------------|---------------------|----------|
| (| Freq. AS | B CD EF | GH IJK | LHN 0P0 | RST UVV | XYZ |
| Ш | LONDON OFFICE | Donald | LEGAL DIV | NEV YORK BRANCH | PARIS BRANCH | |
| Ш | ABC_NET | NORTH AMERICA | ALL BRANCHES | CENTRAL AMERICA | NEW CUSTOWERS | 1/1 |
| Ш | Alex | Allen | ABC_NET | Dorothy | Frank | i≜ FTeV. |
| Ш | Jones | Annette | Mark | Jeffrey | Jennifer | 単門は |
| | | | | | Cancel | OK |

Ø Note

☐ The user names shown here are names that were programed on the Key Operator Tools tab in System Settings. To specify a name not shown here, press [Non-programmed Name], and then enter the user name.

3 Press [OK].



Specifying a file name

Scan files are automatically named SCAN0001, SCAN0002, etc. If necessary, you can change the file name.

Press [File Name].

The soft keyboard is displayed for entering a file name.

2 Enter the file name.


For information about how to enter characters, see *General Settings Guide*.

3 Press [OK].

Specifying a password

When a password is specified, only a person who knows the password can view the file.

- 1 Press [Password].
- 2 Enter a four-digit password with the number keys.



3 Press the [#] key.

𝚱 Note

- ☐ To change the password, press [Change], and then enter a new one.
- 4 Enter the same number as you entered in step 2 to verify.
- 6 Press the [#] key.
- 6 Press [OK].

#Important


- ☐ Do not forget the password. If you forget it, consult the system administrator of the machine.
- Press [OK] to return to the previous screen.



Viewing a List of Stored Files

From the list of stored files, you can delete the files stored in the Document Server or change the file information. To show the list of stored files, perform the following steps:

1 Press the [Scanner] key.



2 If user codes are set, enter a user code using the number keys, and then press the [#] key.

The Scanner Function screen appears.

For information about the user codes, see *General Settings Guide*.

- The list of stored files is displayed.
 - Press [Select Stored File].




2 Press [Manage/Delete File].


Viewing the List

The list of stored files has the following elements.

When using the network delivery scanner function, e-mail, or Scan to Folder



When displaying information of a selected stored file



1. Keys for searching files

Switch to the screens for searching for a file by user name or file name, or to the screen for displaying all files.

2. Keys to switch to the information display

Use to switch between the stored file list and the detailed information of the selected file.

3. Keys for sorting files

Sort the files using the selected item. Select the same item once more for a reverse sort. However, the files cannot be sorted in reverse delivery order.

4. Keys for changing file information

Use for deleting the selected file or changing the user name, file name, or password.

5. List of stored files

The list of stored files is displayed.

Note

- ☐ Stored files cannot be shown when a function other than the scanning function is being used.
- □ If the file is not displayed, use [▲ Prev.] or [▼ Next] to scroll through the list.
- ☐ For files which are password protected, a key symbol(1) is shown to the left of the file name.

6. [Manage/Delete File]

Press to manage or delete files stored in the Document Server or to change file information etc..

7. [Send]


Press to send or deliver files stored in the Document Server. For more information, see p.81 "Sending Stored Files by E-mail or Scan to Folder, or Delivering".

8. Information of a selected stored file

Press [Detail] to display the information of a file after selecting the file from the file list.

Viewing a list of stored files in DeskTopBinder V2 Lite

The files stored in the Document Server are shown below using DeskTopBinder V2 Lite.



1. Connected device name

The files stored in the connected device are displayed on the desk tree divided into User name and All Users folders.

2. User name

Only the files stored with the same user name specified in the connected device properties are displayed. The files stored from the scanner are shown in the Scanner folder.

3. All Users

All files stored in the connected device are displayed.

4. Folder contents display


The files in the selected folder are displayed.

Searching for Files

You can search for files from the stored files using the user name or file name.

Searching by user name

- 1 On the screen with the list of stored files, press [Search by User Name].
- 2 Select the user name to be used for the search.



Ø Note

☐ The user names shown here are names that were registered on the Key Operator Tools tab in System Settings. To specify a user name not shown here, press [Non-programmed Name], and then enter the name.

Press [OK].

The search starts, and files whose user name starts with the specified string are displayed.



Searching by file name

1 On the screen with the list of stored files, press [Search by File Name].

The soft keyboard is displayed for searching by file name.

2 Enter the file name to search for.


Note

☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

Press [OK].

The search starts, and files whose name starts with the entered string are displayed.



Sending Stored Files by E-mail or Scan to Folder, or Delivering


Files stored in the Document Server can be sent by e-mail or Scan to Folder, or delivered to the delivery server.

Ø Note

- ☐ This section explains how to select files to be sent or delivered. For more information about sending by e-mail, see p.47 "Procedure for Sending E-mail". For more information about sending by Scan to Folder, see p.61 "Procedure for Sending by Scan to Folder". For more information about delivering stored files, see p.87 "Delivering Scan File".
- ☐ When sending or delivering stored files, scan settings cannot be changed. The files are sent or delivered with the scan settings specified when they were stored in the Document Server.
- 1 Display the list of stored files by pressing [Select Stored File].

p.77 "Viewing a List of Stored Files".

2 Select a file to be sent or delivered.



Note

☐ When you select a password protected file, the Password screen appears. After you have entered the correct password and pressed [OK], the file will be selected.

To select multiple files, repeat step 2.



Note

- ☐ You can select up to 30 files for one operation.
- ☐ If you select multiple files, the files will be sent or delivered in the order they were selected.
- ☐ If you press [Display Selection], the selected files will be shown in the order of delivery.

4 Press [OK].

The screen for sending or delivering appears.

- Switch the Destination List if necessary.
- **6** Specify a destination to be sent or delivered.
- **7** Select the sender, subject, and message if necessary.
- Press the [Start] key.

Managing Stored Files

Displaying and Downloading Stored Files Using a Web Browser

Using a Web Browser in a client computer, you can display or download the files in the Document Server. When http:// (machine IP address) / is entered in the address bar of the Web browser in a client computer, the Stored Files List screen for the Document Server is displayed.

For displaying or downloading stored files using a Web Browser, see *General Settings Guide*.

For more information about making settings for using a Web Browser, see *Network Guide*.

For more information about functions for managing stored files using a Web Browser, click **[Help]** on the upper-right corner of the displayed screen.

Deleting Files

You can delete files that are no longer needed.

Limitation

☐ Files waiting for delivery cannot be deleted.

Using a Web Browser (See *General Settings Guide*) from a client computer, you can also delete the files stored in the Document Server.


1 Display the list of stored files by pressing [Select Stored File].

p.77 "Viewing a List of Stored Files"

2 Press [Manage/Delete File].

The Manage/Delete File screen appears.

3 Select the file to be deleted.



𝚱 Note

- \Box Up to 30 files can be selected.
- ☐ When you select a password protected file, the Password screen appears. Enter the correct password, and then press [OK]. When more than one file is selected, the Password screen appears each time a password protected file is selected.

4 Press [Delete File].



A confirmation message for file deleting appears.

- **5** Press [Delete].
- 6 Press [Exit].

Changing File Information

The information about files stored in the Document Server (user name, file name, and password) can be changed.

Limitation

☐ Information about files waiting for delivery cannot be changed.


Using a Web Browser (See *General Settings Guide*) from a client computer, you can change the information of files stored in the Document Server.

1 Display the list of stored files by pressing [Select Stored File].

₽ Reference

p.77 "Viewing a List of Stored Files"

- 2 Press [Manage/Delete File].
- **3** Select the file for which you want to change the file information.




Note

☐ When you select a password protected file, the Password screen appears. Enter the correct password, and then press [OK].


4 Change the file information.

Changing the user name

1 Press [Change User Name].



2 Select the new user name.






☐ The user names shown here are names that were registered on the Key Operator Tools tab in System Settings. To change a user name not shown here, press [Non-programmed Name], and then enter the user name.

3 Press [OK].



Changing the file name

1 Press [Change File Name].



The soft keyboard is displayed for changing the file name.

2 Enter the new file name.


₽ Reference

For information about how to enter characters, see *General Settings Guide*.

3 Press [OK].

Changing the password

• Press [Change Password].



2 Enter a new four-digit password using the number keys.



3 Press the [#] key.



- ☐ To change the password, press [Change], and then enter a new one.
- 4 Enter the same number as you entered in step 2 to verify.
- **6** Press the [#] key.

6 Press [OK].

∰Important

- ☐ Do not forget the password. If you forget it, consult the system administrator of the machine.
- Make sure that the file information was changed as necessary, and press [Exit].



7. Using the Network Delivery Scanner Function

Scan file can be sent to a specified destination using the network delivery scanner function. This chapter explains the preparation sequence, various display screens, delivery procedures, and how to check the delivery result when this function is used.

∰Important

☐ A delivery server in which ScanRouter V2 Lite/Professional is installed is necessary to use the network delivery scanner function. Information about delivery destinations and senders must be registered first into the delivery server. Also, configure connected devices in [Set I/O Device] of ScanRouter V2 Administration Utility. For more information, see ScanRouter V2 Administration Utility Help.

Preparation for Delivering

To use the machine as a network delivery scanner, the preparation described below is required.



Connect the machine to the network with an Ethernet cable, IEEE 1394 (optional) cable, or use Wireless LAN (optional). See *Network Guide*.



Check the network settings in System Settings, and change if required.

See Network Guide.



Make settings for the network delivery scanner function, such as Destination List Settings.

See p.11 "Initial Scanner Setup".



Install the software required for using the network delivery scanner functions, such as ScanRouter V2 Lite, on the delivery server. After installing the software, make the required settings for server maintenance and delivery service.

See p.32 "ScanRouter V2 Lite".



Use ScanRouter V2 Administration Utility to set the destination, sender information, and connected devices.




On the client computers, install the software required for viewing or retrieving file by connecting to the delivery server, such as DeskTopBinder V2 Lite.

See p.28 "DeskTopBinder V2 Lite".

Network Delivery Scanner Screen

The screen when using the machine as a network delivery scanner is as shown.



1. Network delivery scanner icon (₺)

Shows that the screen for network delivery scanner function is displayed.

2. Destination field

The selected destination is shown here. If multiple destinations are selected, the destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].

𝚱 Note

☐ Pressing the **[Check Modes]** key lets you check the selected destinations.

3. [Registration No.]

Press to specify a destination using a fivedigit registration number.

4. [Manual Input]

When sending e-mail via the delivery server, press [Manual Input], and then enter the destination with the soft keyboard that is displayed. For information about sending e-mail from the delivery server, see the manual for ScanRouter V2. See p.i "Manuals for This Machine".

5. [Attach Sender's Name] [Attach Subject]

Set the sender, subject, and message of the document to be delivered.

6. [III] Switch Destination List/Search

Press to switch a destination list from the delivery server to the destination list of this machine or to search by user name.

7. Destination list

Displays the destinations programed in the delivery server or this machine.

Ø Note


- □ When the entire list does not fit on one screen, [▲] or [▼] can be used to scroll through the display.
- ☐ Group destinations are denoted by this symbol (****).

Delivering Scan File

Delivery Procedure

Scan file is delivered after scan settings and destinations are specified. If necessary, you can select a sender and a subject.

1 Press the [Scanner] key.



2 If user codes are set, enter a user code with the number keys, and then press the [#] key.

The Scanner Function screen appears.

Reference

For information about the user codes, see *General Settings Guide*.

Make sure that no previous settings remain.

Note

- ☐ If a previous setting remains, press the **[Clear Modes]** key.
- Place the original, and then adjust the scan settings, settings for original size and orientation if required.

To make the scan settings, recall stored settings or make the settings individually.

p.14 "Scan Settings" p.35 "Setting Originals"

Recalling stored scan settings


- 1 Press the [Program] key.
- Select a program of scan settings.



The settings of the selected program are applied.

Making settings individually

- Press [Scan Settings].
- Select items such as resolution and original size, and then change their settings.



Scan settings can be made in the same way as Default Scan Settings. See p.14 "Default Scan Settings".

- 3 Press [OK].
- If the E-mail screen appears, switch to the screen for network delivery scanner.
 - **●** Press [🙉].

2 Press [Switch Destination List].



Press [Delivery Server].



4 Press [Exit].

The Network Delivery Scanner screen appears.

6 Specify the destination.

To specify a destination, you can select it from the list, specifying a registration number, select it after search for it, or directly enter the email address.

Ø Note

☐ When using ScanRouter V2 Lite/Professional, the destination list is updated automatically. When selecting a destination from the list

• Press the title for the destination. The destinations for that title are displayed.

If the destination is not displayed, press $[\blacktriangle]$ or $[\blacktriangledown]$ to display the destination.



- Note
- ☐ The destination titles are programed in the delivery server.
- 2 Select the destination to which the scan file is to be delivered.



The selected destination is highlighted and also is displayed in the destination field at the top of the screen.

3 To select more destinations, repeat step 2.

- Ø Note
- □ To deselect a destination, press the destination once more, or press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.


Using a registration number to select a destination

- 1 Press [Registration No.].
- 2 Use the number keys to enter the five-digit registration number that has been assigned to a destination.

If the entered number is less than five digits long, press the **[#]** key after the last number.

Example: To enter 00001

Press the [1] key, and then press the [#] key.




3 To select more destinations, repeat step **2**.



□ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.

Searching to select a destination

1 Press [I].



2 Press [Search Address Book].



3 Press [Search by Dest. Name].



☐ When using ScanRouter V2 Professional, it is possible to search by comments.

The soft keyboard is displayed for entering a name.

4 Enter part of the destination name.



- ☐ Enter the first character or characters of the destination name.
- ☐ It is necessary to differentiate between capital and small letters.

For information about how to enter characters, see *General Settings Guide*.

- 6 Press [OK].
- 6 Select a destination.



Press [Exit].

Manual entry of a destination

Note

□ When using ScanRouter V2 Professional, it is possible to enter the destination e-mail address directly. In advance, you must make settings for sending e-mail with ScanRouter V2 Professional.

• Press [Manual Input].

The soft keyboard is displayed for entering a destination (email address).

2 Enter the destination.

Note

- ☐ Enter the e-mail address of the destination when sending via the delivery server.
- ☐ It is possible to use letters, numbers, and periods. The symbols ()\,;:" cannot be used.

For information about how to enter characters, see *General Settings Guide*.

- 3 Press [OK].
- 4 To enter more destinations, repeat steps 1 to 3.

Note

- □ To deselect a destination, press [▲ Prev.] or [▼ Next] to display the destination in the destination field, and then press the [Clear/Stop] key.
- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.

Checking selected destinations

• Use the destination field at the top of the screen to check which destinations are selected.

Note

- □ When multiple destinations are selected, the selected destinations are displayed in the order they were selected by pressing [▲ Prev.] or [▼ Next].
- ☐ Pressing the **[Check Modes]** key on the control panel lets you check the list of selected destinations.

7 Specify the scan file sender if necessary.

To specify a sender, you can select the sender from the list, enter the five-digit registration number of the sender with the number keys, and search for the sender and selecting it.

Note


☐ When a sender has been specified, this information is added to the scan file. Select a sender from the senders programed in the delivery server.

When selecting a sender from the list

1 Press [Attach Sender's Name].



2 Select the sender.



The selected sender and its registration number are displayed.

𝚱 Note

- ☐ When using ScanRouter V2 Professional, [Return Receipt] is displayed when a sender is selected.
- □ When [Return Receipt] is selected, an e-mail notifying that the file has been read by the destination party is sent to the sender selected here. To use [Return Receipt], it is necessary to make settings such as the e-mail address in advance in ScanRouter V2 Professional.



3 Press [OK].

Using a registration number to specify a sender name


• Press [Attach Sender's Name].



2 Use the number keys to enter the five-digit registration number that has been assigned to a sender.

Example: To enter 00007

Press the [7] key, and then press the [#] key.



- Note
- ☐ When using ScanRouter V2 Professional, [Return Receipt] is displayed when a sender is selected.
- □ When [Return Receipt] is selected, an e-mail notifying that the file has been read by the destination party is sent to the sender selected here. To use [Return Receipt], it is necessary to make settings such as the e-mail address in advance in ScanRouter V2 Professional.



Press [OK].

Searching to select a sender

1 Press [Attach Sender's Name].



2 Press [<u>__</u>].



Press [User (Dest.) Name].



The soft keyboard is displayed for entering a sender name.

4 Enter part of the sender name.

- ☐ Enter the first character or characters of the sender name.
- ☐ It is necessary to differentiate between capital and small letters.

₽ Reference

For information about how to enter characters, see *General Settings Guide*.

6 Press [OK].

6 Select a sender.




- Press [Exit].
- Press [OK].
- 8 Specify a subject if necessary.

Ø Note


- ☐ When a subject has been specified, this information is added to the scan file.
- ☐ When ScanRouter V2 Professional is used to send documents using e-mail, the subject is automatically entered as the message subject.
- ☐ To specify a subject name, you can select it from the list, enter it directly, or combine selecting and entering it.
- ☐ Subject name to select from the list must be registered in System Settings in advance. See *Network Guide*.
- ☐ Subject name can be entered up to 64 characters.

The operation to specify a subject name "[Urgent] New product appearance" is explained as an example here.

• Press [Attach Subject].



2 Press a subject [Urgent].



3 Press [Manual Input].

The soft keyboard is displayed for entering a subject.

Enter the subject "New product appearance".

₽ Reference

For information about how to enter characters, see *General Settings Guide*.

- **6** Press [OK] twice.
- 9 Press the [Start] key.
 - Note
 - ☐ To interrupt scanning, press the **[Clear/Stop]** key or **[Stop]** on the screen.
 - □ When using the Batch or SADF function, place the next original after the others have been scanned. See p.42 "Scanning Originals in Several Times".

Simultaneous Storage and Delivery

You can use the network delivery scanner function with the Document Server.

Scan file is stored in the Document Server at the same time the file is delivered.


- ☐ This section explains mainly the operation for simultaneous delivery and storage. For more information, see p.87 "Delivering Scan File".
- 1 Place the original, and then adjust the settings for original size and orientation if required.

p.35 "Setting Originals"

- 2 Make the scan settings.
- **3** Select the destination.
- 4 Specify the sender name and a subject if necessary.
- Press [Store File].



Make sure [Send & Store] is selected.



- **7** Set file information if necessary.

p.75 "Specifying file information"

- 8 Press [OK].
- 9 Press the [Start] key.

Checking the Status of Delivery

The status of the last 100 deliveries can be checked. For every new delivery record after 100, the oldest record is deleted.

Ø Note

☐ When [Print & Delete Scanner Journal] is set to [Delete All after Printing], the whole journal is printed when the number of records reaches 100.

Items that can be checked

• Date/Time

The date and time the delivery was requested or the date which "Error" or "Cancelled" is confirmed is displayed.

• Destination

A used sending function (e-mail, Scan to Folder, or delivery function) is displayed with an icon.

When multiple destinations were selected, the first selected destination is displayed.

- Sender
- File Name

The file name is displayed only when storing a file and sending e-mail are performed simultaneously by pressing [Send & Store] or resending the file stored.


Status

Either of the following status is displayed: "Done", "Sending", "Waiting", "Error", or "Cancelled".

1 Press [Scanned Files Status] on the Network Delivery Scanner screen.



2 Check the displayed records.



- Note
- □ One screen shows the records for five delivery operations. Use
 [▲ Prev.] or [▼ Next] to scroll through the screen.
- ☐ When the status of a file is waiting, the delivery can be stopped by selecting that file, and then pressing [Cancel].
- ☐ Press [Print], and the whole journal is printed.

Press [Exit].


The display returns to the Network Delivery Scanner screen.

8. Using the Network TWAIN Scanner Function

This chapter describes the operations for scanning originals with the network TWAIN scanner using DeskTopBinder V2 Lite. In addition, the preparation for using the network TWAIN scanner and some functions of the TWAIN driver are introduced.

Preparation for Using the Network TWAIN Scanner

To use the machine as a network TWAIN scanner, the preparation described below is required.



Connect the machine to the network with an Ethernet cable, IEEE 1394 (optional) cable, or use Wireless LAN (optional). See *Network Guide*.

Check the network settings in System Settings, and change if required.

See Network Guide.



On the client computers, install the software required for using the network TWAIN scanner functions, such as a TWAIN driver and DeskTopBinder V2 Lite.

See p.27 "Software for Using a Network TWAIN Scanner".

Scanning Originals

This section explains how to scan originals using the network TWAIN scanner function.

- **1** Start DeskTopBinder V2 Lite, and then select the scanner driver.
 - On the [Start] menu, point to [Program], point to [DeskTop-Binder V2], and then click [Desk-TopBinder V2].
 - Click [Scanner Settings] on the [Tools] menu.

If the scanner is already selected, no scanner settings are necessary. Check the settings in the [File format for scanned image(s)] area, and then proceed to step **5**.

- 3 Click [Select Scanner Driver...].
- 4 Select the name of the machine you want to use in the [Source] list, and then click [Select...].
- 6 Click [OK].
- **2** Place the original in the scanner.
 - Reference p.35 "Setting Originals"
- 3 Make the scan settings.
 - ① On the [File] menu, point to [Add Document], and then click [Scan].

The TWAIN driver starts.

After a short while, the dialog box of the TWAIN driver that operates the scanner appears. This dialog box is called the Scanner Properties dialog box.

Note

- ☐ The name of the scanner currently being used is shown on the title bar of the dialog box. When multiple machines are connected, make sure that the indicated machine is the machine you want to use. If it is different, click [Select Scanner] to select the scanner again.
- ☐ If the machine you want to use is not displayed in the list, make sure that the IP address is configured and that the machine is correctly connected to the network. If the machine is still not displayed in the list after confirming the above, consult with your network administrator.
- 2 Depending on the type of original or the objective for scanning, click the appropriate button in [Mode].
 - [Standard] is suitable for scanning standard originals that are comprised of mainly text.
 - [Photo] is suitable for scanning originals that include photos, shaded illustrations, etc.
 - [OCR] is suitable for conversion processing with an OCR (Optical Character Reading) application after scanning the original.
 - **[Filing]** is suitable for use with filing applications, etc.

:

Ø Note

- ☐ For advanced settings, click [Detail] to display the Detail window. For information about the Detail window, see TWAIN driver Help.
- According to the settings of [Document:] and [Orientation:], change the other setting of the [Document] group.

p.41 "For a Network TWAIN Scanner"

For information about making settings for the [Document] group, see TWAIN driver Help.

When you want to configure the scanning area

When you do not configure the scanning area, the area scanned is the size specified in the [Size:] box.

• Click [Preview].

The original that was placed is scanned and the [Preview] dialog box appears. The scanning area in the preview is displayed within the broken lines.

2 Configure the scanning area by dragging a border or a corner.

When reconfiguring the area, click and drag one corner of the area towards or away from its opposite corner.

Note

- ☐ Depending on the scanning resolution, the area to be scanned may be subject to restrictions. For more information about the relationship between the resolution and the scanning area, see TWAIN driver Help.
- 3 Click [Close].
 - Note
 - ☐ When an original placed in the ADF is previewed, place that original again.

4 Click [Scan].

When there are additional originals to scan, place the original, and then click [Continue]. When there are no more originals, click [Complete].

- Save the scan file in DeskTop-Binder V2 Lite.
 - 1 On the [File] menu, click [Exit].
 - 2 Enter the file name, and then click [OK].

The image is stored in DeskTop-Binder V2 Lite, and DeskTop-Binder Viewer closes.

Fediting and printing scan files

With DeskTopBinder V2 Lite, it is possible to edit and print scan files. For more information about how to edit and print, see DeskTopBinder V2 Lite Help.

Functions of the TWAIN Driver

The following is an introduction to the various functions of the TWAIN driver:

For more information about these functions or other functions, see TWAIN driver Help.

Automatic Tilt Correction

This function automatically corrects character strings that were scanned slanted.

Printing to the Image

This function allows you to imprint dates, page numbers, or your favorite characters on a scan file. You can also change the fonts of the imprints as well as change the ascending order of images to a descending order.

Scanning Mode Registration

This function allows you to register other scanning configurations that are often used as scanning modes besides the already pre-installed ones. After registration, you can quickly scan with these scanning configurations.

8

9. Appendix

Relationship between Resolution and File Size

Resolution and scan area are inversely related. The higher the resolution is set, the smaller the area that can be scanned. Conversely, the larger the scan area, the lower the resolution that can be set.

The relationship between the scanning resolution and the file size is shown below. If the file size is too large, the message "Exceeded max. data capacity. Check the scanning resolution." appears on the control panel of the machine. Specify the scan size and resolution again.

Limitation

☐ Depending on the image compression level, the maximum image size will be limited.

When Using as E-mail, Scan to Folder, Document Server or Network Delivery Scanner

♦ When Text, Text/ Photo, or Photo is selected as the Scan Type
All combinations up to A3/297 × 432 mm (11 × 17 inches) and 600 dpi are possible.

♦ When Gray Scale is selected as the Scan Type

The originals can be scanned using combinations marked with O in the table.

| | 100 dpi | 200 dpi | 300 dpi | 400 dpi | 600 dpi |
|--|---------|---------|---------|---------|---------|
| A3 | 0 | О | О | О | О |
| B4 | 0 | 0 | 0 | 0 | О |
| A4 | 0 | 0 | 0 | 0 | О |
| B5 | 0 | 0 | О | О | О |
| A5 | 0 | 0 | О | О | О |
| B6 *1 | 0 | О | О | О | О |
| A6 *1 | 0 | О | О | О | О |
| A7 *1 | 0 | 0 | О | О | 0 |
| 11 x 17 | 0 | 0 | О | О | 0 |
| Legal (8 ¹ / ₂ x 14) | 0 | 0 | О | О | 0 |
| $8^{1}/_{2} \times 13$ | 0 | 0 | О | О | 0 |
| Letter $(8^1/_2 \times 11)$ | О | О | О | О | О |
| $5^{1}/_{2} \times 8^{1}/_{2}$ | О | О | О | О | О |

^{*1} The scanning size must be manually entered.

♦ When Full Color is selected as the Scan Type

The originals can be scanned using combinations marked with O in the table.

| | 100 dpi | 200 dpi | 300 dpi | 400 dpi | 600 dpi |
|--|---------|---------|---------|---------|---------|
| A3 | 0 | О | 0 | О | |
| B4 | 0 | 0 | 0 | 0 | |
| A4 | 0 | 0 | О | 0 | 0 |
| B5 | 0 | 0 | 0 | 0 | 0 |
| A5 | 0 | 0 | О | О | 0 |
| B6 *1 | 0 | 0 | О | 0 | 0 |
| A6 *1 | 0 | 0 | О | О | 0 |
| A7 *1 | 0 | 0 | О | 0 | 0 |
| 11 x 17 | 0 | 0 | О | 0 | |
| Legal (8 ¹ / ₂ x 14) | 0 | 0 | 0 | 0 | |
| $8^{1}/_{2} \times 13$ | 0 | 0 | О | О | |
| Letter $(8^1/_2 \times 11)$ | 0 | О | О | 0 | 0 |
| $5^{1}/_{2} \times 8^{1}/_{2}$ | 0 | О | О | 0 | 0 |

^{*1} The scanning size must be manually entered.

When Using as a Network TWAIN Scanner

To specify the scanning area or resolution when using the machine as a network TWAIN scanner, see TWAIN driver Help.

When Binary, Halftone, Gray Scale, 8 colors, or 8 colors (halftone) is selected as the Colors/ Gradations

The originals can be scanned using combinations marked with \bigcirc in the table (Original orientation: \square).

| | 100 dpi | 200 dpi | 300 dpi | 400 dpi | 500 dpi | 600 dpi | 700 dpi | 800 dpi | 900 dpi | 1000 dpi | 1100 dpi | 1200 dpi |
|----|------------|------------|------------|------------|------------|------------|------------|------------|------------|-------------|-------------|-------------|
| A3 | 0 | 0 | 0 | 0 | 0 | 0 | | | | | | |
| B4 | 0 | 0 | 0 | 0 | 0 | 0 | | | | | | |
| A4 | 0 | 0 | 0 | 0 | О | О | 0 | О | | | | |
| B5 | 0 | 0 | 0 | 0 | 0 | О | 0 | 0 | 0 | | | |
| A5 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| В6 | O | 0 | O | О | О | 0 | 0 | О | O | 0 | 0 | 0 |
| A6 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

a

| | 100 dpi | 200 dpi | 300 dpi | 400 dpi | 500 dpi | 600 dpi | 700 dpi | 800 dpi | 900 dpi | 1000 dpi | 1100 dpi | 1200 dpi |
|---|------------|------------|------------|------------|------------|------------|------------|------------|------------|-------------|-------------|-------------|
| A7 *1 | О | О | 0 | 0 | О | О | О | 0 | 0 | 0 | 0 | О |
| 11x17 | О | О | 0 | 0 | О | О | | | | | | |
| Legal (8 ¹ / ₂ x14) | О | О | О | О | О | О | О | | | | | |
| $8^{1}/_{2}x13$ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | | | |
| Letter $(8^1/_2x11)$ | О | О | О | О | О | О | О | 0 | | | | |
| $5^1/_2 x 8^1/_2$ | О | О | О | О | О | О | 0 | О | О | О | О | О |

^{*1} The scanning size must be manually entered.

♦ When 16770K colors is selected as the Colors/ Gradations

The originals can be scanned using combinations marked with \bigcirc in the table (Original orientation: \square).

| | 100 dpi | 200 dpi | 300 dpi | 400 dpi | 500 dpi | 600 dpi | 700 dpi | 800 dpi | 900 dpi | 1000 dpi | 1100 dpi | 1200 dpi |
|---|------------|------------|------------|------------|------------|------------|------------|------------|------------|-------------|-------------|-------------|
| A3 | О | O | O | O | | | | | | | | |
| B4 | О | О | О | О | | | | | | | | |
| A4 | О | О | О | О | О | О | | | | | | |
| B5 | О | О | О | О | О | О | | | | | | |
| A5 | О | О | О | О | О | О | О | О | | | | |
| B6 | 0 | О | О | О | О | 0 | 0 | О | O | | | |
| A6 | 0 | О | О | О | О | 0 | 0 | О | O | О | 0 | О |
| A7 *1 | О | О | О | О | О | O | О | О | О | О | 0 | О |
| 11x17 | О | О | О | О | | | | | | | | |
| Legal (8 ¹ / ₂ x14) | О | О | О | О | О | | | | | | | |
| $8^{1}/_{2}x13$ | О | O | O | O | O | | | | | | | |
| Letter $(8^1/_2x11)$ | О | О | О | О | О | О | | | | | | |
| $5^1/_2 \times 8^1/_2$ | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | | |

^{*1} The scanning size must be manually entered.

Relationship between File Type Specified and File Type Used When Sending E-mail

The relationship between the file type specified when scanning originals and the file type converted into when sending e-mail or storing files is shown below by scan type.

| File type specified | Single page | Mult | i page | |
|------------------------------|-------------------------------|--|--------|--|
| Scan type | TIFF/JPEG | TIFF | PDF | |
| Text (Print) | | | | |
| Text (OCR) | TIFF | Multi-page: TIFF | | |
| Text/ Photo | 111.1. | With page. The | | |
| Photo | | | DDE | |
| Gray Scale | | | PDF | |
| Full Colour: Text/ Photo | TIFF (Non-compression) / JPEG | Multi-page TIFF (Non-compression) / | | |
| Full Colour: Glossy Photo | (Compression) *1 | PDF | | |

^{*1} When Gray Scale or Full Colour is used, the file format is converted to JPEG when **[Standard]**, **[High]**, or **[Low]** is selected for **[Compression (Gray Scale/Full Colour)]** in **[Send Settings]**, and TIFF when **[Off]** is selected.

Note

- ☐ Files are stored in single-page style. When sending files by e-mail, you can select single-page style or multi-page style.
- ☐ When multi-page TIFF is specified for the files saved in JPEG format, they are automatically changed to PDF.
- ☐ When **[Scan Type]** of the default scan settings is set to **[Auto Colour Select]** and multi-page TIFF is specified for the file format, the format is automatically changed to PDF.

q

Max. Number of Addresses Which Can Be Specified and Files Which Can Be Stored

| | E-mail | Scan to Folder | Delivery Server |
|---|---|--|--------------------|
| The number of addresses which can | 500 *1 *2 | 50 *1 | F00 *5 |
| be specified at a time when sending | When sending e-mail a Folder at the same time | | 500 * ⁵ |
| The number of addresses which can be registered in the list | 20 | See the manuals for ScanRouter V2 Lite/Professional. | |
| The max. number of files which can be stored | | | |
| The max. number of pages which can be stored | | | |
| The max. number of pages which can be stored as a single file | 1000 | | |

^{*1} There is a limitation to the number of addresses to specify in the following 1-4 case.

- ① The number of addresses to enter directly for sending e-mail: 65
- ② The number of addresses to enter directly for sending by Scan to Folder: 50
- 3 The number of addresses to search and specify from the LDAP server: 65
- ④ The number of addresses to specify combining with above 1, 2, and 3: 65
- When specifying 65 addresses to enter directly, the remainder of address should be specified from the registered ones within 500 addresses.

 When sending e-mail and sending by Scan to Folder at the same time, the address of
- When sending e-mail and sending by Scan to Folder at the same time, the address of e-mail cannot be specified over 500, and the address for Scan to Folder cannot be specified over 50.
- *4 It is the number including the files which is stored using not only the Scanner function, but the copy function, the facsimile function, the Document Server function, and the printer function.
- *5 The maximum number of addresses which can be specified differs when you use either Scan Router V2 Lite/Professional. See the manual for Scan Router V2 Lite/Professional.

Note

☐ Sometimes the machine cannot store or send files to the maximum number depending on the files and originals.

Troubleshooting

This section contains advice on what to do if you have problems scanning an original, or if the network delivery scanner or e-mail function does not work. Various messages that may appear on the control panel or client computer are listed, along with causes and solutions.

When Scanning Is Not Performed as Expected

| Problems | Causes and solutions |
|--|---|
| No image results from scanning. | The original was placed with the front and back reversed. When the original is placed directly on the exposure glass, the side to be scanned must face down. When the original is fed via the ADF, the side to be scanned must face up. See p.35 "Setting Originals". |
| The image is distorted or out of position. | The original was moved during scanning. Do not move the original during scanning. |
| | • The original was not pressed flat against the exposure glass. Make sure that the original is pressed flat against the exposure glass. |
| The scanned image is dirty. | The exposure glass or the exposure glass cover is dirty. Clean these parts. See <i>General Settings Guide</i> . |
| The scanned image is upside down. | The original was placed upside down. Place the original in the correct orientation. See p.35 "Setting Originals". Allows the original incommend in account of all colored to the control of the colored to the co |
| | When the original is scanned in gray scale or full color and [Single Page: TIFF/JPEG] is selected for [File Type Priority] of Scanner Features, place the top edge of the original first in the ADF. |

When the Delivery Function Does Not Work

| Problems | Causes and solutions |
|--|--|
| The delivery scanner function screen is not displayed. | If the network TWAIN scanner screen appears when the machine is switched to scanner mode, press [Exit] to switch to the network delivery scanner screen. If the display does not switch from network TWAIN scanner to network delivery scanner, the delivery scanner settings are not correct. See p.11 "Scanner Features", and then make the appropriate settings. |

9

When Stored Files Cannot Be Accessed

| Problems | Causes and solutions |
|--------------------|--|
| is not accessible. | The stored file with the protecting function is locked because the wrong password was entered ten times. For information about how to unlock the file, see "8. Security" <i>General Settings Guide</i> . |

When an Error Message Appears on the Control Panel

𝒯 Note

☐ If an error message that is not included in this section appears, turn off the main power switch of the machine, and then turn it on again. If the message still appears, note the content of the message and the error number (if listed in the table), and contact your service representative. For information about how to turn off the main power switch, see *General Settings Guide*.

| Message | Causes and solutions | | |
|---|--|--|--|
| Cannot cancel sending certain file(s). To confirm the result, check [Scanned Files Status]. | Only files in waiting can be canceled. Files with a delivery status of successful or other result cannot be canceled. | | |
| Cannot detect original size. Select scan size. | Place the original correctly. Specify the scan size. When placing an original directly on the exposure glass, the lifting/lowering action of the ADF triggers the automatic original size detection process. Lift the ADF by more than 30 degrees. | | |
| Cannot enter manually more than nnn destinations at the same time. Note "nnn" in the message represents changeable number. | When there are 65 or more destinations for an e-mail, split the destinations into two or more groups. | | |
| Cannot find the specified path. Please check the settings. | Check whether the computer name and the folder name for the destination are correct. | | |
| Cannot log on with the entered user name or password. | Make settings correctly for the user name and the password for the authentication. | | |
| Cannot select over 30 files at the same time. | To deliver more than 31 stored files, divide the files and perform the operation several times. | | |

| Message | Causes and solutions |
|---|---|
| Cannot specify more than 500 destinations at the same time. | When there are 500 or more destinations for a delivery or an e-mail, split the destinations into two or more groups. |
| Cannot specify more than 50 folders at the same time. | When there are 50 or more destinations for Scan to Folder, split the destinations into two or more groups. |
| Captured file exceeded max. number of pages per file. Cannot send the scanned data. | The maximum number of pages which can be stored as a single file is 1000. Reduce the number of pages and send them again. |
| Connection with LDAP server has failed. Check the server status. | A network error has occurred and connection has failed. Try the operation once more. If the message is still shown, the network may be crowded. Check the information of System Settings. |
| E-mail address entered is not correct. Please re-enter. | Make sure the e-mail address is correct, and then enter it again. |
| Entered protection code for destination is incorrect. Please re-enter. | Make sure the protection code is correct, and then enter it again. |
| Exceeded max. data capacity. Check the scanning resolution, then press Start again. | Specify the scan size and resolution again. Note that it may not be possible to scan very large originals at a high resolution. See p.99 "Relationship between Resolution and File Size". |
| Exceeded max. data capacity. Check the scanning resolution, then reset nnn original(s). Note "nnn" in the message represents changeable number. | Specify the scan size and resolution again. Note that it may not be possible to scan very large originals at a high resolution. See p.99 "Relationship between Resolution and File Size". |
| Exceeded max. E-mail size. Sending E-mail has been cancelled. Check [Max. E-mail Size] in Scanner Features. | Increase the size of [Max. E-mail Size]. Set [Divide & Send E-mail] to [Yes (per Page)] or [Yes (per Max. Size)]. |
| Exceeded max. file capacity. Delete the unnecessary stored files. | The maximum number of files that can be stored is 2000. Reduce the number of files or delete unneeded files. |

| Message | Causes and solutions |
|--|--|
| Exceeded max. No. of search results which can be displayed. | Search again after changing the search conditions. |
| Max.: nnn | |
| 𝒯 Note | |
| "nnn" in the message represents changeable number. | |
| Exceeded max. number of alphanumeric characters. | Make sure the maximum number of characters which can be entered, and then enter it again. |
| Exceeded max. number of alphanumeric characters for the path. | The maximum number of characters which can be entered for path is 128. Check the number of character you entered, and then enter it again. |
| Exceeded max. number of files which can be sent at the same time. Reduce the number of the selected files. | The number of files exceeded the maximum number possible. Reduce the number of files and send them again. |
| Exceeded max. number of files which can be used in Document Server at the same time. | Make sure the files stored by the other functions, and then delete unneeded files. |
| Exceeded max. number of pages per file. Do you want to store the scanned pages as 1 file? | The maximum number of pages per file is 1000. Specify whether to use the data or not. Scan the pages that were not scanned and store them as a new file. |
| Exceeded max. number of standby files. Try again after the current file is sent. | There are 100 files waiting in the sending queue for e-mail, Scan to Folder, or delivery function. Wait until files have been sent. |
| Exceeded max. number of stored files. Cannot send the scanned data as capturing files is unavailable. | The maximum number of files that can be stored in Document Server is 2000. Reduce the number of files or delete unneeded files. |
| Exceeded max. page capacity per file. Press [Send] to send the scanned data, or press [Cancel] to delete. | Because the number of pages has reached the maximum number that can be sent, the data up to this point is sent. Scan the remaining pages after transmission. |
| Exceeded time limit for LDAP server search. Check the server status. | A network error has occurred and connection has failed. Try the operation once more. If the message is still shown, the network may be crowded. Check the information of System Settings. |

| Message | Causes and solutions |
|--|---|
| LDAP server authentication has failed. Check the settings. | Make settings correctly for the user name and the password for LDAP server authentication. |
| Load paper of the following sizes.Required:A3D B4 JISD A4D A4D | Load paper of the sizes listed in the message. |
| Memory is full. Cannot scan. The scanned data will be deleted. | Because of insufficient hard disk space, the first page could not be scanned. Try one of the following measures: • Wait for a while, and then retry the scan operation. • Reduce the scan area or scanning resolution. • Delete unneeded stored files. |
| Memory is full. Press [Send] to send the current scanned data, or press [Cancel] to delete. | Because there is not enough free hard disk space in the machine for delivering or sending by e-mail while storing into the Document Server, only some of the pages could be scanned. Specify whether to use the data or not. |
| Memory is full. Do you want to store scanned file? | Because there is not enough free hard disk space in the machine for storing into the Document Server, only some of the pages could be scanned. Specify whether to use the data or not. |
| No HDD is available for this function. Cannot store. Set original and select the TWAIN settings from the PC. | Files can be stored with TWAIN by switching to the network TWAIN scanner function. |
| Original is being scanned by another function. | The machine is using another function such as copying. Retry scanning after the operation with the other function is completed. |
| Out of paper in Load paper of the following size. | Load paper in the tray indicated. |
| Output buffer is full. Sending the data has been cancelled. Please try again later. | Too many files are waiting to be delivered. Please try again after they have been delivered. |
| Selected file is currently in use. Cannot change file name. | The name of a file that is being edited with DeskTopBinder V2 Lite/Professional or that is waiting for delivery cannot be changed. Try the operation again after editing is finished or delivery is canceled. |

| Message | Causes and solutions |
|---|--|
| Selected file is currently in use. Cannot change password. | The password of a file that is being edited with DeskTopBinder V2 Lite/Professional or that is waiting for delivery cannot be changed. Try the operation again after editing is finished or delivery is canceled. |
| Selected file is currently in use. Cannot change user name. | The user name of a file that is being edited with DeskTopBinder V2 Lite/Professional or that is waiting for delivery cannot be changed. Try the operation again after editing is finished or delivery is canceled. |
| Selected file is currently in use. Cannot delete it. | A file that is being edited with Desk- TopBinder V2 Lite/Professional or that is waiting for delivery cannot be deleted. Try the operation again after editing is finished or delivery is can- celed. |
| Sender's name is not selected. Please specify sender's name. | A sender's name should be specified before sending e-mail. Send e-mail after specifying the sender's name. |
| Sending the data has failed. The data will be resent later. | A network error has occurred and a file was not sent correctly. Wait until sending is retried automatically after the preset interval. If the sending fails again, consult the network administrator. |
| Sending the data has failed. To confirm the result, check [Scanned Files Status]. | While a file was being sent, a network error occurred and the file could not be sent correctly. Try the operation once more. If the message is still shown, the network may be crowded. Consult the network administrator. If multiple files were sent, use the Scanned Files Status screen to check for which file the problem occurred. See p.58 "Checking the Status of Email", p.71 "Checking the Status of Scan to Folder", or p.94 "Checking the Status of Delivery". If there is not enough free hard disk space in the client computer, gain the enough free hard disk space. |

| Message | Causes and solutions |
|---|--|
| The destination list has been updated. Specified destination(s) or sender's name has been cleared. | A specified destination or sender's name was cleared when the destination list in the delivery server was updated. Specify the destination or sender's name again. |
| The entered path is not correct. Please re-enter. | Make sure the computer for destination and the path, and then enter if again. |
| The specified group contains some invalid destination(s). Do you want to select only valid destination(s)? | The specified group contains some destinations for sending by e-mail and sending by Scan to Folder. To select destinations for sending by e-mail, press [Select] for the warning displayed on the e-mail screen. To select destination for sending by Scan to Folder, press [Select] for the warning displayed on the Scan to Folder screen. |
| Updating the destination list. Please wait. Specified destination(s) or sender's name has been cleared. | If a destination or sender's name was already selected, re-select it after this message disappeared. |
| Updating the destination list has failed. Try again? | Check whether the server is connected. |

When an Error Message Appears on the Client Computer

This section describes the main possible causes and actions for error messages displayed on the client computer when the TWAIN driver is used.

Note

☐ If an error message that is not contained in this section appears, turn off the main power switch of the machine, and then turn it on again. If the message is still shown after scanning is performed again, note the content of the message and the error number (if listed in the table), and contact your service representative. For information about how to turn off the main power switch, see *General Settings Guide*.

| Message | Causes and solutions |
|---|--|
| [Cannot add any more scanning mode.] | The maximum number of modes that can be stored is 99. Delete unneeded modes. |
| [Cannot connect to the scanner. Check the network Access Control Range in Configuration.] | The access mask is set. Consult the network or scanner administrator. |
| [Cannot detect the paper size of the original. Specify the scanning size.] | Place the original correctly. Specify the scan size. When placing an original directly on the exposure glass, the lifting/lowering action of the ADF triggers the automatic original size detection process. Lift the ADF by more than 30 degrees. |
| [Cannot find the scanner. Check if the scanner main power is on.] | Check whether the main power switch of the machine is turned off. Check whether the machine is connected to the network correctly. Deselect the personal firewall function of the client computers. |
| [Cannot specify any more scanning area.] | The maximum number of scanning areas that can be stored is 99. Delete unneeded scanning area. |
| [Clear Misfeed(s) in ADF.] | Remove the originals jamming. When the originals are misfed, place them again. Check whether the originals are proper to be scanned by the machine. |
| [Communication error has occurred on the network.] | Check whether the client computer can use the TCP/IP protocol. |
| [Error has occurred in the scanner.] | Check whether the scanning settings made with the application exceed the setting range of the machine. |

| Message | Causes and solutions |
|---|---|
| [Error has occurred in the scanner driver.] | Check whether the network cable is connected correctly to the client computer. Check whether the Ethernet board of the client computer is recognized correctly by Windows. Check whether the client computer can use the TCP/IP protocol. |
| [Fatal error has occurred in the scanner.] | An recoverable error has occurred in the machine. Call your service representative. |
| [Insufficient memory. Close all other applications, then restart scanning.] | Close all the unnecessary applications running on the client computer. Uninstall the TWAIN driver, and then reinstall the driver after restarting the computer. |
| [Insufficient memory. Reduce the scanning area.] | Reset the scan size. Lower the resolution. Set with no compression. See p.19 "Send Settings". |
| | ✓ Note "The Relationship between the Resolution and the Scanning Area" chart in Help for halftone scanning might not always apply. Scanning cannot be performed if large values are set for brightness when using halftone or high resolution. |
| | ☐ When a paper misfeed occurs in the machine during printing, scanning cannot be performed. In this case, after the misfed paper has been removed, proceed with scanning. |
| [Invalid Winsock version. Please use version 1.1 or higher.] | Install the operating system of the computer or copy Winsock from the operating system CD-ROM. |
| [No response from the scanner.] | Check whether the machine is connected to the network correctly. The network is crowded. Wait for a while, and then try to reconnect. |
| [No User Code is registered. Consult your system administrator.] | Access is restricted with user codes. Consult the system administrator of the machine. |
| [Please call your service representative.] | An unrecoverable error has occurred in the machine. Call your service representative. |

| Message | Causes and solutions |
|--|--|
| [Scanner is in use for other function. Please wait.] | A function of the machine other than the scanner function is being used such as the copier function. Wait for a while and reconnect. |
| [Scanner is not available. Check the scanner connection status.] | Check whether the main power switch of the machine is turned off. |
| | Check whether the machine is connected to the network correctly. |
| | Deselect the personal firewall function of the client computers. |
| [Scanner is not ready. Check the scanner and the options.] | Check whether the ADF cover is closed. |
| [The name is already in use. Check the registered names.] | You tried to register a name that is already in use. Use another name. |

Specifications

| Scan method | Flatbed scanning |
|--|--|
| Scan speed | E-mail/Scan to Folder/Network Delivery Scanner: Black & White: 31 pages/minute [Scan size: A4], Scan settings: Scan type: Black & White Text (Print)/Resolution: 200dpi/Compression: On (MH)] Colour: 28 pages/minute [Scan size: A4], Scan settings: Scan type: Full Colour Text/Photo/Resolution: 200dpi/Compression: Standard] TWAIN Scanner Black & White: 21 pages/minute [Size: A4], Quality: Colors/Gradations: Binary/Resolution: 200dpi/Compression: Data compression (MMR)] Colour: 15 pages/minute [Size: A4], Quality: Colors/Gradations: 16770K colors/Resolution: 200dpi/Compression: Standard quality] |
| Maximum power consumption | 1500 W |
| Image sensor type | CCD Image Sensor |
| Scan type | Sheet, book |
| Interface | Ethernet interface (10BASE-T or 100BASE-TX), IEEE 1394 (IP over 1394) [optional], and IEEE 802.11b (Wireless LAN) [optional] |
| Maximum scan size | A3/297 × 432 mm, 11 × 17 inches |
| Scan size that can be detected automatically | Exposure glass A3△, B4△, A4ຝ△, B5ຝ△, 8″ × 13″△ ADF A3△, B4△, A4ຝ△, B5ຝ△, A5ຝ△, B6ຝ△, 8.5″ × 13″△, 8K△, 16K ຝ△ |
| Resolution | 600 dpi (8-bit grayscale) |
| Variable range of scan resolution | E-mail/Scan to Folder/Network Delivery Scanner Setting range: 100 dpi, 200 dpi, 300 dpi, 400 dpi, and 600 dpi TWAIN Scanner Setting range: 100 dpi - 1200 dpi |
| File formats that can be sent by e-mail | TIFF, JPEG, PDF |
| Compression method | Black & White: TIFF (MH, MR, MMR) Gray Scale/Full Colour: JPEG |
| Protocol | Network: TCP/IP Sending e-mail: SMTP Scan to Folder: SMB, FTP |

INDEX

| A | 1 |
|---|---|
| A.C.S. Sensitivity Level, 17 Auto Colour Select: Mode Priority, 17 Automatic Tilt Correction, 98 Auto run program, 25 | Image density, 14 Indicators, 8 Initial scanner setup, 11 Installing software, 25 [Interrupt] key, 8 |
| Change Initial Mode, 17 Checking the status of delivery, 94 [Check Modes] key, 8 [Clear Modes] key, 8 | LDAP server, 4 |
| [Clear/Stop] key, 9 Compression (Black & White), 20 Compression (Gray Scale/Full Colour), 20 | Main power indicator and power indicator, 8 Max. E-mail Size, 20 Max. Number of Addresses Which Can Be |
| Default Scan Settings, 14 DeskTopBinder V2 Lite, 28, 30, 95 Destination List Display Priority 1, 19 Destination List Settings, 12, 19 | Specified and Files Which Can Be Stored, 103 Mixed Original Sizes Priority, 17 Mode, 96 |
| Display Contents E-mail, 9 Network delivery scanner, 10 Network TWAIN scanner, 10 Scan to Folder, 10 Display panel, 8 | Network delivery scanner, 6, 85 Network TWAIN scanner, 7, 95 Not specifying a time limit for additional originals, 43 Number keys, 9 |
| Divide & Send E-mail, 20 Document Server, 5, 73 | 0 |
| E-mail, 3, 45 E-mail Information Language, 21 [Energy Saver] key, 8 | Operation switch, 9 Original Feed Type Priority, 16 Original orientation and scan area, 39 Original Orientation Priority, 17 Original Setting, 16 |
| [#] Enter key,9 | P |
| File Type Priority, 20 FTP server, 4, 64 Function keys, 9 Function status indicators, 9 | Placing original in the Auto Document Feeder (ADF), 37 Placing original on the exposure glass, 36 Preview, 97 Print & Delete Scanner Journal, 20 Printing to the image, 98 [Program] key, 8 Programs, 22 |

R

Relationship between File Type Specified and File Type Used When Sending E-mail, 102 Relationship between resolution and file size, 99 Resolution, 14

S

Save, 97 Scanner Features, 11 Scanning mode registration, 98 Scanning originals, 96 Scanning Originals in Several Times, 42 ScanRouter V2 Lite, 32 Scan Settings, 11, 14 Scan size, 15 Scan to Folder, 4, 59 Scan type, 14 Selecting a custom size, 17 Select Title, 19 Sender's Name Default, 21 Send Settings, 12, 19 Simultaneous Storage and Delivery, 93 Simultaneous Storage and Sending by E-mail, 56 Simultaneous Storage and Sending by Scan to Folder, 69 SMB, 4,63 SMTP server, 3 Software supplied on CD-ROM, 29 [Start] key, 9 Storing Files, 73

T

Troubleshooting, 104 TWAIN Standby Time, 19 Type 2238 TWAIN Driver, 29

U

Update delivery server destination list, 19 [Use Tools/Counter] key, 8

٧

Viewing a list of stored files in DeskTopBinder V2 Lite, 79

W

Wait Time for Next Orig.: Exposure Glass, 15 Wait Time for Next Original(s): SADF, 16 In accordance with IEC 60417, this machine uses the following symbols for the main power switch:

- I means POWER ON.
- O means POWER OFF.
- () means STAND BY.



Declaration of Conformity

"The Product complies with the requirements of the EMC Directive 89/336/EEC and its amending directives and the Low Voltage Directive 73/23/EEC and its amending directives."

Trademarks

Adobe and Acrobat are trademarks of Adobe Systems Incorporated.

Ethernet is a registered trademark of Xerox Corporation.

Pentium is a registered trademark of Intel Corporation.

MS, Microsoft, and Windows are registered trademarks of Microsoft Corporation.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

- The product name of Windows® 95 is Microsoft® Windows® 95.
- The product name of Windows® 98 is Microsoft® Windows® 98.
- The product name of Windows® Me is Microsoft® Windows® Millennium Edition (Windows Me).
- The product names of Windows® 2000 are as follows:

Microsoft® Windows® 2000 Professional

Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Advanced Server

• The product names of Windows® XP are as follows:

Microsoft® Windows® XP Home Edition

Microsoft® Windows® XP Professional

The product names of Windows Server[™] 2003 are as follows:

Microsoft® Windows ServerTM 2003 Standard Edition

Microsoft® Windows Server™ 2003 Enterprise Edition

Microsoft® Windows Server™ 2003 Web Edition

The product names of Windows NT® 4.0 are as follows:

Microsoft® Windows NT® Workstation 4.0

Microsoft® Windows NT® Server 4.0

Network Guide



- 1 Functions Available over a Network
- 2 Connecting the Network Cable to the Network
- 3 Setting Up the Machine on a Network
- 4 Windows Configuration
- 5 Using the Printer Function
- 6 Using SmartNetMonitor for Client
- (7) Using SmartNetMonitor for Admin
- 8 Configuring the Network Interface Board Using a Web Browser
- 9 Appendix

Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Software Version Conventions Used in This Manual

- NetWare 3.x means NetWare 3.12 and 3.2.
- NetWare 4.x means NetWare 4.1, 4.11, 4.2 and IntranetWare.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

Trademarks

Microsoft®, Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Apple, AppleTalk, EtherTalk, Macintosh and Mac are registered trademarks of Apple Computer, Inc.

Netscape and Netscape Navigator are registered trademarks of Netscape Communications Corporation.

Novell, NetWare, NDS and NDPS are registered trademarks of Novell, Inc.

PostScript® and Acrobat® are registered trademarks of Adobe Systems, Incorporated.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Citrix® and MetaFrame® are registered trademarks of Citrix Systems, Inc.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

The proper names of the Windows operating systems are as follows:

- The product name of Windows® 95 is Microsoft® Windows 95.
- The product name of Windows® 98 is Microsoft® Windows 98.
- The product name of Windows® Me is Microsoft® Windows Millennium Edition (Windows Me).
- The product names of Windows® 2000 are as follows:

Microsoft® Windows® 2000 Professional Microsoft® Windows® 2000 Server

Microsoft® Windows® 2000 Advanced Server

The product names of Windows® XP are as follows:

Microsoft® Windows® XP Home Edition Microsoft® Windows® XP Professional

The product names of Windows Server™ 2003 are as follows:

Microsoft® Windows Server™ 2003 Standard Edition

Microsoft® Windows Server™ 2003 Enterprise Edition

Microsoft® Windows Server™ 2003 Web Edition

The product names of Windows NT® 4.0 are as follows:

Microsoft® Windows NT® Workstation 4.0

Microsoft® Windows NT® Server 4.0

RSA Data Security, Inc. MD5 Message-Digest Algorithm

Copyright[©] 1991-2, RSA Data Security, Inc. Created 1991. All rights reserved.

License to copy and use this software is granted provided that it is identified as the "RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing this software or this function. License is also granted to make and use derivative works provided that such works are identified as "derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm" in all material mentioning or referencing the derived work.

RSA Data Security, Inc. makes no representations concerning either the merchantability of this software or the suitability of this software for any particular purpose. It is provided "as is" without express or implied warranty of any kind.

These notices must be retained in any copies of any part of this documentation and/or software.

TABLE OF CONTENTS

| Manuals for This Machine | 1 |
|--|----|
| How to Read This Manual | 3 |
| 1. Functions Available over a Network | |
| Using the Printer | 5 |
| Using Fax | 6 |
| Internet Fax | 6 |
| LAN-Fax | |
| Network Scanner | |
| E-mail | |
| Scan to Folder | |
| Network Delivery Scanner Network TWAIN Scanner | |
| Document Server | |
| 2. Connecting the Network Cable to the Network | |
| Confirming the Connection | |
| Connecting to the Ethernet Interface | |
| Connecting to the IEEE 1394 Interface | |
| Using the IEEE 802.11b (Wireless LAN) | |
| 3. Setting Up the Machine on a Network | |
| User Tools Menu (System Settings) | |
| Printer (LAN-Fax) | 19 |
| Internet Fax | |
| E-mail | |
| Scan to Folder Network Delivery Scanner | |
| Network TWAIN Scanner | |
| Document Server | |
| Network Configuration | |
| Settings You Can Change with User Tools | |
| 4. Windows Configuration | |
| Configuring TCP/IP | 49 |
| Configuring a Windows 95/98/Me Computer | |
| Configuring a Windows 2000 Computer | |
| Configuring a Windows XP Computer | |
| Configuring a Windows NT 4.0 Computer | |
| Configuring NotREIII | |
| Configuring NetBEUI Configuring a Windows 95/98/Me Computer | |
| Configuring a Windows 95/98/Me Computer | |
| Configuring a Windows NT 4.0 Computer | |
| comganing a trindotto iti no compatoriminini | |

5. Using the Printer Function

| Printing with Windows | 59 |
|---|--------|
| Printing with a Windows 2000/XP, Windows Server 2003, or Windows NT 4.0 Print S | |
| Printing without a Print Server | |
| Printing with a Mac OS | |
| Changing to EtherTalk | |
| Configuring the Printer | |
| Changing the Printer Name | |
| Changing the Zone Printing with NetWare | |
| Setting Up as a Print Server | |
| Setting Up as a Remote Printer | |
| Setting Up a Client Computer | |
| 6. Using SmartNetMonitor for Client | |
| SmartNetMonitor for Client | 77 |
| 7. Using SmartNetMonitor for Admin | |
| | |
| SmartNetMonitor for Admin | |
| Changing the Network Interface Board Configuration | |
| Displaying Machine Status | |
| Locking the Control Panel Menu | |
| Selecting the Paper Type | |
| Load Fax Journal | |
| Viewing and Deleting Spool Print Jobs | |
| Managing Address Information | |
| Configuring Energy Saver Mode | |
| 8. Configuring the Network Interface Board Using a Web B | rowser |
| Going to the Top Page | 90 |
| Types of Menu Configuration and Mode | |
| Verifying the Network Interface Board Settings | |
| Configuring the Network Interface Board Settings | |
| Using Help on the Web Browser | |
| Downloading Halp | |

9. Appendix

| Remote Maintenance by telnet | 97 |
|--|-----|
| Using telnet | |
| Commands List | 98 |
| Using DHCP | 114 |
| Using AutoNet | 115 |
| SNMP | 116 |
| Single-line Messages on the Display Panel | 117 |
| Messages without Code Numbers | |
| Messages with Code Numbers | |
| Understanding Displayed Information | 120 |
| Print Job Information | |
| Print Log Information | 120 |
| Machine Status and Configuration | 121 |
| Configuring the Network Interface Board | 125 |
| Message List | 130 |
| System Log Information | 130 |
| When Using Windows Terminal Service/MetaFrame | 140 |
| Operating Environment | |
| Supported Printer Drivers | 140 |
| Limitation | 140 |
| Precautions | 142 |
| Connecting a Dial-Up Router to a Network | 142 |
| NetWare Printing | |
| When Using IPP with SmartNetMonitor for Client | |
| When the optional IEEE 802.11b interface unit Is Installed | 145 |
| Specifications | 146 |
| INDEX | 147 |

Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

Note

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
 - CD-ROM 1 "Operating Instructions for Printer/Scanner" CD-ROM 2 "Scanner Driver & Document Management Utilities"

General Settings Guide

Provides an overview of the machine and describes System Settings (paper trays, Key Operator Tools, etc.), Document Server functions, and trouble-shooting.

Refer to this manual for Address Book procedures such as registering fax numbers, e-mail addresses, and user codes.

♦ Network Guide (PDF file - CD-ROM1) (this manual)

Describes procedures for configuring the machine and computers in a network environment.

Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

Facsimile Reference <Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

Facsimile Reference <Advanced Features>

Describes advanced functions and settings for key operators.

Printer Reference 1

Describes system settings and operations for the machine's printer function.

Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

♦ Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
 Describes operations of DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
 Describes operations and functions of Auto Document Link installed with
 DeskTopBinder V2 Lite. This guide is added to the [Start] menu when
 DeskTopBinder V2 Lite is installed.

Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
 Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
 Describes delivery server management and operations, and provides an overview of ScanRouter V2 Lite functions. This guide is added to the [Start] menu when ScanRouter V2 Lite is installed.

Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- UNIX Supplement (available from an authorized dealer, or as a PDF file on our Web site)

How to Read This Manual

Symbols

In this manual, the following symbols are used:

⚠ WARNING:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

↑ CAUTION:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury, or damage to property.

* The statements above are notes for your safety.

∰Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates prior knowledge or preparation is required before operation.

𝚱 Note

This symbol indicates precautions for operation, or actions to take after mal-operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys that appear on the machine's display panel.

Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

Keys on the computer's keyboard.


Functions Available over a Network

This machine provides printer, LAN-Fax, Internet Fax, and scanner functions over a network. Using the Document Server function, you can combine copied documents and print jobs into a single document. Not only can you print this document straight away, but you can also store it so it can be printed again whenever needed.

Using the Printer

The network interface board is compatible with NetWare *1 (IPX/SPX, TCP/IP), Windows NT 4.0 (TCP/IP, NetBEUI *2 , IPP *3), Windows 2000 (TCP/IP, NetBEUI *2 , IPP *3), Windows XP, Windows Server 2003 (TCP/IP, IPP *3), Windows 95/98/Me (TCP/IP, NetBEUI *2 , IPP *3), UNIX (TCP/IP), and Mac OS (AppleTalk) protocols. This allows you to operate the machine in a network that uses different protocols and operating systems.

- *1 If the optional 802.11b interface unit is installed, you can use only infrastructure mode.
- *2 For NetBEUI, use the SmartNetMonitor for Client port.
- *3 IPP (Internet Printing Protocol) is a protocol for printing via the Internet.



For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see p.55 "Using the Printer Function".

Using Fax


Internet Fax

This machine converts scanned document images to e-mail format and transmits the data over the Internet.

Specify the e-mail address instead of the fax number, and then send the document.

E-mail can be received on a fax machine that supports Internet Fax, or on a computer that can receive normal e-mail.

You can also receive e-mails or Internet faxes, and then print or forward them.



For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Using Internet Fax Functions", *Facsimile Reference < Basic Features >*.


Ľ

LAN-Fax

You can fax documents over phone lines from any computer connected to the machine via Ethernet, IEEE 1394 (IP over 1394), or wireless LAN.

To send a fax, print from the Windows application you are working with, select LAN-Fax as the printer, and then specify the destination.

You can also check the sent image data.




For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Sending Fax Documents from Computers", *Facsimile Reference <Advanced Features>*.

Network Scanner

E-mail

Scan file attached to an e-mail can be sent using the e-mail system through a LAN or the Internet.




For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Sending Scan File by E-mail", *Scanner Reference*.

Scan to Folder

You can send scan file directly to shared folders on computers running Windows or to FTP servers.




For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Sending Scan File by Scan to Folder", *Scanner Reference*.

Network Delivery Scanner

You can use the machine as a delivery scanner for ScanRouter V2 Lite / Professional.

Scan file or document received by fax can be stored in the delivery server, or delivered via the network to specified folders on client computers.




For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Using the Network Delivery Scanner Function", *Scanner Reference*.

Network TWAIN Scanner

You can use the scanning function of this machine from a computer connected via a network (Ethernet, IEEE 1394(IP over 1394), or IEEE 802.11b (wireless LAN)).

You can scan documents the same way you would if you were using a scanner connected directly to your computer.




For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For details about using this function, see "Using the Network TWAIN Scanner Function", *Scanner Reference*.

1

You can store copy, fax, printer, and scanner documents on the hard disk. Using DeskTopBinder V2 Lite or a Web browser, you can browse, print, delete, or copy these documents over a network.



For details about what settings to make, see p.19 "Setting Up the Machine on a Network".

For more information about Document Server operation from the printer, see "Using the Document Server", *Printer Reference* 2.

For more information about Document Server operation from the facsimile, see "Using the Document Server", *Facsimile Reference < Advanced Features >*.


For more information about Document Server operation from the scanner, see "Using the Document Server Function", *Scanner Reference*.

For all information about Document Server operation, see "Using the Document Server", *General Settings Guide*.

For more information about DeskTopBinder V2 Lite, see the manuals for DeskTopBinder V2 Lite.

2. Connecting the Network Cable to the Network

Confirming the Connection



1. 10BASE-T/100BASE-TX port

Port for connecting the 10BASE-T or 100BASE-TX cable

2. IEEE 1394 ports (optional)

Ports for connecting the IEEE 1394 interface cable

3. Wireless LAN port (optional)

Port for using the wireless LAN

Note

☐ The optional IEEE 1394 interface board and the IEEE 802.11b interface unit cannot be installed at the same time.

Connecting to the Ethernet Interface


The network interface board supports 10BASE-T or 100BASE-TX connections.

∰Important


- ☐ Before making the connection, touch the metallic part to ground yourself.
- 1 Turn off the main power switch.

∰Important

- ☐ Make sure the main power is off. See "Turning On the Power", *General Settings Guide*.
- **2** Connect the Ethernet interface cable to the 10BASE-T/100BASE-TX port.



3 Turn on the main power switch.



1. Indicator (green)

Remains green when the machine is properly connected to the network.

2. Indicator (yellow)

Turns yellow when 100 BASE-TX is operating. Turns off when 10 BASE-T is operating.

Connecting to the IEEE 1394 Interface

#Important


☐ Before making the connection, touch the metallic part to ground yourself.

Ø Note

- ☐ Use the interface cable supplied with the optional IEEE 1394 interface board.
- ☐ Make sure the interface cable is not looped.
- 1 Turn off the main power switch.

∰Important

- ☐ Make sure the main power is off. See "Turning On the Power", *General Settings Guide*.
- **2** Connect the IEEE 1394 interface cable to the IEEE 1394 ports.




Note

- ☐ Two interface ports are available for connecting the IEEE 1394 interface cable. Either is suitable.
- Turn on the main power switch.

Using the IEEE 802.11b (Wireless LAN)

Setting IEEE 802.11b (Wireless LAN)

■ IEEE 802.11b (wireless LAN) setup procedure




Note

☐ Select [802.11 Ad hoc mode] when connecting Windows XP as a wireless LAN client using Windows XP standard driver or utilities, or when not using the infrastructure mode.

Confirming the Connection


- Make sure the LED of the IEEE 802.11b interface unit is lit.
 - When using in infrastructure mode



ZGDH600J

- 1. If [LAN Type] on the [Interface Settings]/[Network] screen is not set to [IEEE 802.11b], it does not light, even if the main power is on.
- 2. If it is connected properly to the network, the LED is green when in infrastructure mode. If the LED is blinking, the machine is searching for devices.

When using in ad hoc mode/802.11 ad hoc mode



ZGDH600J

- 1. If the IEEE 802.11b interface unit is working, it is lit in orange.
- 2. If it is connected properly to the network, the LED is green when in ad hoc mode or 802.11 ad hoc mode. If the LED is blinking, the machine is searching for devices. The LED will light after a few seconds.
- Print the configuration page to verify settings.

₽ Reference

For more information about printing a configuration page, see *Printer Reference* 2.

Checking the machine's radio wave status

When using in infrastructure mode, you can check the machine's radio wave status using the control panel.

Ø Note

- ☐ To check the radio wave status, press [IEEE 802.11b] under [LAN Type] on the [Network] screen.
- 1 Press the [User Tools/Counter] key.
- **2** Press [System Settings].
- Press [Interface Settings].
- 4 Press [IEEE 802.11b].
- Press [Wireless LAN Signal].

 The machine's radio wave status appears.
- 6 After checking radio wave status, press [Exit].
- Press the [User Tools/Counter] key to return to the User Tools/Counter menu.

3. Setting Up the Machine on a Network

User Tools Menu (System Settings)

This section describes the network settings you can change with User Tools (System Settings). Make settings according to functions you want to use and the interface to be connected.

∰Important

☐ These settings should be made by the systems administrator, or after consulting with the systems administrator.

For details about settings, see p.37 "Settings You Can Change with User Tools"

Viewing the Information Displayed in the List

• These items must be set to use the function. Be sure to set them before attempting to use the corresponding function.

O These items must be set if required.

Printer (LAN-Fax)

| Interface | Settings | | |
|-----------|--|-----------------------|---|
| Ethernet | Interface Settings/ | IP Address | • |
| | Network | Gateway Address | 0 |
| | See p.37 "Interface Settings/Network". | DNS Configuration | 0 |
| | WINS Configuration | О | |
| | NW Frame Type | О | |
| | LAN Type *2 | • | |
| | | Ethernet Speed | О |
| | | Effective Protocol *3 | • |
| | | Host Name | О |
| | | Domain Name | 0 |

| Interface | Settings | | |
|-----------------------------|--|--------------------------|---|
| IEEE 1394 (IP over 1394) | Interface Settings/ IEEE 1394 *1 See p.39 "Interface | IP Address | • |
| | | IP over 1394 | • |
| | Settings/IEEE 1394". | WINS Configuration | О |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Gateway Address | О |
| | Network See p.37 "Interface | DNS Configuration | О |
| | Settings/Network". | Effective Protocol *3 | • |
| IEEE 802.11b | Interface Settings/ | IP Address | • |
| (wireless LAN) | Network | Gateway Address | О |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | О |
| | | NW Frame Type | О |
| | | LAN Type *2 | • |
| | | Ethernet Speed | О |
| | | Effective Protocol *3 | • |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Communication Mode | • |
| | IEEE 802.11b *2 | SSID Setting | О |
| | See p.40 "Interface Settings/IEEE 802.11b". | Channel | О |
| | | WEP (Encryption) Setting | О |
| | | Transmission Speed | О |

Appears when the optional IEEE 1394 interface board is installed.
 Appears when the optional IEEE 802.11b interface unit is installed. If Ethernet and IEEE 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.

*3 Check [Effective] is selected for TCP/IP.

Internet Fax

| Interface | | Settings | |
|-----------|---|--|---|
| Ethernet | Interface Settings/ Network | IP Address | • |
| | | Gateway Address | • |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | O |
| | | LAN Type *2 | • |
| | | Ethernet Speed | О |
| | | Effective Protocol *5 | • |
| | | Host Name | О |
| | | Domain Name | О |
| | File Transfer See p.41 "File Transfer". | SMTP Server *3 | • |
| | | SMTP Authentication | O |
| | | POP before SMTP | О |
| | | Reception Protocol *4 | • |
| | | POP3/ IMAP4 Settings *6 | О |
| | | Key Operator's E-mail Address | О |
| | | E-mail Reception Port *4 *7 | • |
| | | E-mail Reception Interval | O |
| | | Max. Reception E-mail Size | О |
| | | E-mail Storage in Server | O |
| | | Program/ Change/ Delete E- mail Message | 0 |
| | | Program/ Change/ Delete Subject | О |
| | | E-mail Account *3 *4 | • |

| Interface | | Settings | |
|----------------|----------------------------------|--|---|
| IEEE 1394 | Interface Settings/ | IP Address | • |
| (IP over 1394) | IEEE 1394 *1 See p.39 "Interface | IP over 1394 | • |
| | Settings/IEEE 1394". | WINS Configuration | О |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Gateway Address | • |
| | Network See p.37 "Interface | DNS Configuration | О |
| | Settings/Network". | Effective Protocol *5 | • |
| | File Transfer | SMTP Server *3 | • |
| | See p.41 "File Trans- | SMTP Authentication | О |
| | fer". | POP before SMTP | О |
| | | Reception Protocol *4 | • |
| | | POP3/ IMAP4 Settings *6 | О |
| | | Key Operator's E-mail Address | О |
| | | E-mail Reception Port *4 *7 | • |
| | | E-mail Reception Interval | О |
| | | Max. Reception E-mail Size | О |
| | | E-mail Storage in Server | О |
| | | Program/ Change/ Delete E-mail Message | О |
| | | Program/ Change/ Delete Subject | О |
| | | E-mail Account *3 *4 | • |

| Interface | | Settings | |
|----------------|---|--|---|
| IEEE 802.11b | Interface Settings/ Network | IP Address | • |
| (wireless LAN) | | Gateway Address | • |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | О |
| | | LAN Type *2 | • |
| | | Ethernet Speed | О |
| | | Effective Protocol *5 | • |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Communication Mode | • |
| | IEEE 802.11bDocument | SSID Setting | О |
| | Server *2 | Channel | О |
| | See p.40 "Interface Settings/IEEE 802.11b". | WEP (Encryption) Setting | О |
| | | Transmission Speed | О |
| | File Transfer See p.41 "File Transfer". | SMTP Server *3 | • |
| | | SMTP Authentication | О |
| | | POP before SMTP | О |
| | | Reception Protocol *4 | • |
| | | POP3/ IMAP4 Settings *6 | О |
| | | Key Operator's E-mail Address | О |
| | | E-mail Reception Port *4 *7 | • |
| | | E-mail Reception Interval | О |
| | | Max. Reception E-mail Size | О |
| | | E-mail Storage in Server | О |
| | | Program/ Change/ Delete E-mail Message | 0 |
| | | Program/ Change/ Delete Subject | О |
| | | E-mail Account *3 *4 | • |

 $^{^{\}ast 1}$ $\,$ Appears when the optional IEEE 1394 interface board is installed.

^{*2} Appears when the optional IEEE 802.11b interface unit is installed. If Ethernet and 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.

^{*3} Minimum settings required to use transmission.

^{*4} Minimum settings required to use reception.

^{*5} Check**[Effective]** is selected for TCP/IP.

^{*6} If you select **[ON]** for **[POP before SMTP]**, select this function also.

If you select [ON] for [POP before SMTP], check the port number for [POP3].
 If you select [ON] for [SMTP Authentication], select this function also.

E-mail

| Interface | | Settings | |
|-----------|--|--|---|
| Ethernet | Interface Settings/ | IP Address | • |
| | Network | Gateway Address | • |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | 0 |
| | | LAN Type *2 | • |
| | | Ethernet Speed | 0 |
| | | Effective Protocol *3 | • |
| | | Host Name | 0 |
| | | Domain Name | 0 |
| | File Transfer | SMTP Server | • |
| | See p.41 "File Transfer". | SMTP Authentication | 0 |
| | ier . | POP before SMTP | 0 |
| | | POP3/ IMAP4 Settings *4 | 0 |
| | | Key Operator's E-mail Address | 0 |
| | | E-mail Reception Port *5 | 0 |
| | | Program/ Change/ Delete E- mail Message | О |
| | | Program/ Change/ Delete Subject | О |
| | | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | О |

| Interface | | Settings | |
|----------------|---|--|---|
| IEEE 1394 | Interface Settings/ IEEE 1394 *1 | IP Address | • |
| (IP over 1394) | | IP over 1394 | • |
| | See p.39 "Interface Settings/IEEE 1394". | WINS Configuration | О |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Gateway Address | • |
| | Network See p.37 "Interface | DNS Configuration | О |
| | Settings/Network". | Effective Protocol *3 | • |
| | File Transfer | SMTP Server | • |
| | See p.41 "File Transfer". | SMTP Authentication | О |
| | | POP before SMTP | О |
| | | POP3/ IMAP4 Settings *4 | О |
| | | Key Operator's E-mail Address | О |
| | | E-mail Reception Port *5 | О |
| | | Program/ Change/ Delete E-mail Message | О |
| | | Program/ Change/ Delete Subject | О |
| | | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | О |

| Interface | Settings | | |
|----------------|---|--|---|
| IEEE 802.11b | Interface Settings/ | IP Address | • |
| (wireless LAN) | Network See p.37 "Interface | Gateway Address | • |
| | Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | О |
| | | LAN Type *2 | • |
| | | Ethernet Speed | 0 |
| | | Effective Protocol *3 | • |
| | | Host Name | О |
| | | Domain Name | 0 |
| | Interface Settings/ | Communication Mode | • |
| | IEEE 802.11b *2 | SSID Setting | 0 |
| | See p.40 "Interface Settings/IEEE 802.11b". | Channel | О |
| | | WEP (Encryption) Setting | О |
| | | Transmission Speed | 0 |
| | File Transfer See p.41 "File Transfer". | SMTP Server | • |
| | | SMTP Authentication | 0 |
| | | POP before SMTP | О |
| | | POP3/ IMAP4 Settings *4 | О |
| | | Key Operator's E-mail Address | О |
| | | E-mail Reception Port *5 | 0 |
| | | Program/ Change/ Delete E- mail Message | О |
| | | Program/ Change/ Delete Subject | 0 |
| | | Scanner Recall Interval Time | O |
| | | Number of Scanner Recalls | О |

 $^{^{*1}}$ Appears when the optional IEEE 1394 interface board is installed.

^{*2} Appears when the optional IEEE 802.11b interface unit is installed. If Ethernet and 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.

^{*3} Check **[Effective]** is selected for TCP/IP.

If you select [ON] for [POP before SMTP], select this function as well.
 If you select [ON] for [POP before SMTP], check the port number for [POP3].

Scan to Folder

| Interface | | Settings | |
|----------------|--|------------------------------------|---|
| Ethernet | Interface Settings/ | IP Address | • |
| | Network | Gateway Address | • |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | 0 |
| | | LAN Type *2 | • |
| | | Ethernet Speed | 0 |
| | | Effective Protocol *3 | • |
| | | Host Name | 0 |
| | | Domain Name | 0 |
| | File Transfer See p.41 "File Trans- | Default User Name/ Password (Send) | О |
| | fer". | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | 0 |
| IEEE 1394 | Interface Settings/ IEEE 1394 *1 See p.39 "Interface Settings/IEEE 1394". | IP Address | • |
| (IP over 1394) | | IP over 1394 | • |
| | | WINS Configuration | 0 |
| | | Host Name | 0 |
| | | Domain Name | 0 |
| | Interface Settings/ | Gateway Address | • |
| | Network | DNS Configuration | 0 |
| | See p.37 "Interface Settings/Network". | Effective Protocol *3 | • |
| | File Transfer See p.41 "File Transfer". | Default User Name/ Password (Send) | О |
| | | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | 0 |

| Interface | Settings | | |
|--|--|-------------------------------------|---|
| IEEE 802.11b | Interface Settings/ Network | IP Address | • |
| (wireless LAN) | | Gateway Address | • |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | О |
| | | LAN Type *2 | • |
| | | Ethernet Speed | О |
| | | Effective Protocol *3 | • |
| | | Host Name | О |
| | | Domain Name | О |
| | Interface Settings/ | Communication Mode | • |
| | IEEE 802.11b *2 See p.40 "Interface | SSID Setting | О |
| | Settings/IEEE | Channel | О |
| | 802.11b". | WEP (Encryption) Setting | О |
| File Transfer See p.41 "File Tra fer". | | Transmission Speed | О |
| | File Transfer See p.41 "File Trans- | Default User Name / Password (Send) | О |
| | _ | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | 0 |

Appears when the optional IEEE 1394 interface board is installed.
 Appears when the optional IEEE 802.11b interface unit is installed.
 If Ethernet and IEEE 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.
*3 Check **[Effective]** is selected for TCP/IP.

Network Delivery Scanner

| Interface | | Settings | |
|----------------|--|------------------------------|---|
| Ethernet | Interface Settings/ | IP Address | • |
| | Network | Gateway Address | О |
| | See p.37 "Interface Settings/Network". | DNS Configuration | О |
| | | WINS Configuration | 0 |
| | | LAN Type *2 | • |
| | | Ethernet Speed | 0 |
| | | Effective Protocol *4 | • |
| | | Host Name | 0 |
| | | Domain Name | 0 |
| | File Transfer See p.41 "File Transfer". | Delivery Option *3 | 0 |
| | | Fax RX File Transmission | 0 |
| | | Scanner Recall Interval Time | 0 |
| | | Number of Scanner Recalls | 0 |
| IEEE 1394 | Interface Settings/ IEEE 1394 *1 See p.39 "Interface Settings/IEEE 1394". | IP Address | • |
| (IP over 1394) | | IP over 1394 | • |
| | | WINS Configuration | 0 |
| | | Host Name | 0 |
| | | Domain Name | 0 |
| | Interface Settings/ | Gateway Address | 0 |
| | Network See p.37 "Interface | DNS Configuration | 0 |
| | Settings/Network". | Effective Protocol *4 | • |
| | File Transfer | Delivery Option *3 | О |
| | See p.41 "File Transfer". | Fax RX File Transmission | 0 |
| | 161 . | Scanner Recall Interval Time | 0 |
| | | Number of Scanner Recalls | 0 |

| Interface | Settings | | |
|----------------|---|------------------------------|---|
| IEEE 802.11b | Interface Settings/ Network See p.37 "Interface Settings/Network". | IP Address | • |
| (wireless LAN) | | Gateway Address | О |
| | | DNS Configuration | О |
| | | WINS Configuration | О |
| | | LAN Type *2 | • |
| | | Ethernet Speed | О |
| | | Effective Protocol *4 | • |
| | | Host Name | О |
| | | Domain Name | О |
| Interf | Interface Settings/ | Communication Mode | • |
| | IEEE 802.11b *2 See p.40 "Interface | SSID Setting | О |
| | Settings/IEEE | Channel | О |
| | 802.11b". | WEP (Encryption) Setting | О |
| | | Transmission Speed | О |
| | File Transfer See p.41 "File Transfer". | Delivery Option *3 | О |
| | | Fax RX File Transmission | О |
| | | Scanner Recall Interval Time | О |
| | | Number of Scanner Recalls | О |

Appears when the optional IEEE 1394 interface board is installed.

*2 Appears when the optional IEEE 802.11b interface unit is installed.

If Ethernet and IEEE 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.

^{*3} When delivery option is set to **[0N]**, make sure the IP address is set.
*4 Check **[Effective]** is selected for TCP/IP.

Network TWAIN Scanner

| Interface | Settings | | | |
|--------------------------------|---|--------------------------|---|--|
| Ethernet | Interface Settings/ | IP Address | • | |
| | Network | Gateway Address | 0 | |
| | See p.37 "Interface Settings/Network". | DNS Configuration | 0 | |
| | | WINS Configuration | 0 | |
| | | LAN Type *2 | • | |
| | | Ethernet Speed | 0 | |
| | | Effective Protocol *3 | • | |
| | | Host Name | 0 | |
| | | Domain Name | 0 | |
| IEEE 1394 | Interface Settings/ | IP Address | • | |
| (IP over 1394) | IEEE 1394 *1 | IP over 1394 | • | |
| | See p.39 "Interface Settings/IEEE 1394". | WINS Configuration | 0 | |
| | | Host Name | 0 | |
| | | Domain Name | 0 | |
| | Interface Settings/ | Gateway Address | 0 | |
| | Network | DNS Configuration | 0 | |
| | See p.37 "Interface Settings/Network". | Effective Protocol *3 | • | |
| IEEE 802.11b (wireless LAN) | Interface Settings/ | IP Address | • | |
| | Network | Gateway Address | 0 | |
| | See p.37 "Interface Settings/Network". | DNS Configuration | 0 | |
| | | WINS Configuration | О | |
| | | LAN Type *2 | • | |
| | | Ethernet Speed | 0 | |
| | | Effective Protocol *3 | • | |
| | | Host Name | 0 | |
| | | Domain Name | О | |
| | Interface Settings/ | Communication Mode | • | |
| | IEEE 802.11b *2 | SSID Setting | О | |
| | See p.40 "Interface Settings/IEEE | Channel | О | |
| | 802.11b". | WEP (Encryption) Setting | О | |
| | | Transmission Speed | О | |

Appears when the optional IEEE 1394 interface board is installed.
 Appears when the optional IEEE 802.11b interface unit is installed. If Ethernet and 802.11b (wireless LAN) are both connected to the machine, the selected interface has priority.

Check **[Effective]** is selected for TCP/IP.

Document Server

| Interface | Settings | | | |
|----------------|---|--------------------------|---|--|
| Ethernet | Interface Settings/ | IP Address | • | |
| | Network See p.37 "Interface Settings/Network". | Gateway Address | О | |
| | | DNS Configuration | О | |
| | | WINS Configuration | 0 | |
| | | LAN Type *2 | • | |
| | | Ethernet Speed | О | |
| | | Effective Protocol *3 | • | |
| | | Host Name | 0 | |
| | | Domain Name | 0 | |
| IEEE 1394 | Interface Settings/ | IP Address | • | |
| (IP over 1394) | IEEE 1394 *1 | IP over 1394 | • | |
| | See p.39 "Interface Settings/IEEE 1394". | WINS Configuration | О | |
| | | Host Name | 0 | |
| | | Domain Name | 0 | |
| | Interface Settings/ Network See p.37 "Interface Settings/Network". | Gateway Address | О | |
| | | DNS Configuration | О | |
| | | Effective Protocol *3 | • | |
| IEEE 802.11b | Interface Settings/ Network See p.37 "Interface Settings/Network". | IP Address | • | |
| (wireless LAN) | | Gateway Address | О | |
| | | DNS Configuration | О | |
| | | WINS Configuration | 0 | |
| | | LAN Type *2 | • | |
| | | Ethernet Speed | 0 | |
| | | Effective Protocol *3 | • | |
| | | Host Name | О | |
| | | Domain Name | 0 | |
| | Interface Settings/ IEEE 802.11b *2 See p.40 "Interface Settings/IEEE 802.11b". | Communication Mode | • | |
| | | SSID Setting | 0 | |
| | | Channel | 0 | |
| | | WEP (Encryption) Setting | О | |
| | | Transmission Speed | 0 | |

selected interface has priority. Check **[Effective]** is selected for TCP/IP.

Appears when the optional IEEE 1394 interface board is installed.
 Appears when the optional IEEE 802.11b interface unit is installed. If Ethernet and IEEE 802.11b (wireless LAN) are both connected to the machine, the

Network Configuration

Any change you make with User Tools remains in effect even if the main power switch or operation switch is turned off, or the [Energy Saver] or [Clear Modes] key is pressed.

Configuring the network using the control panel

- Note
- Operations for System Settings are different from normal operations.
 After using User Tools, press the [User Tools/Counter] key to exit.
- ☐ If the **[Key Operator Code]** has been set, the key operator code entry screen appears. Enter the code, and then press **[OK]**. See *General Settings Guide*.
- 1 Press the [User Tools/Counter] key.



- Note
- ☐ The machine will be offline during setting.
- **2** Press [System Settings].
- Press [Interface Settings] or [File Transfer].
- A Select the required menu, and then press the desired key.

- Change settings by following the instructions on the display panel, and then press [OK].
 - Note
 - ☐ To cancel changes made to settings and return to the System Settings menu, press [Cancel].
- 6 Press [Exit].
- **7** Press the [User Tools/Counter] key.
 - Ø Note
 - ☐ You can also exit by pressing **[Exit]** on the User Tools main menu.

Configuring the network using other utilities

As well as using the control panel to make network settings, utilities such as a Web browser and SmartNetMonitor for Admin can also be used. The following table shows available settings:

Note

- ☐ Indicates machine settings can be changed.
- $\hfill\Box$ Indicates the setting cannot be changed from that device.

| Name on the control panel | | | Web browser | Smart- NetMon- itor for Admin | telnet | | |
|---------------------------|---------|----------------------------|--------------------|--|--------|---|---|
| Interface N Settings | Network | IP Address | Auto-Obtain (DHCP) | | О | О | 0 |
| | | | Specify | IP Address | О | О | О |
| | | | | Sub-net Mask | О | О | 0 |
| | | Gateway Address | | О | О | 0 | |
| | | DNS Configu- ration | Auto-Obtain (DHCP) | | О | - | 0 |
| | | | Specify | ►DNS Server 1 | О | - | 0 |
| | | | | ►DNS Server 2 | О | - | 0 |
| | | | | ►DNS Server 3 | О | - | О |
| | | WINS Configu- ration | ►WINS Server | | O | - | 0 |
| | | | Scope ID | | 0 | - | О |
| | | NW Frame Type | Auto Select | | 0 | - | 0 |
| | | | Ethernet II | | 0 | - | О |
| | | | Ethernet 802.2 | | 0 | - | О |
| | | | Ethernet 802.3 | | 0 | - | 0 |
| | | | Ethernet SNAP | | 0 | - | О |
| | | LAN Type | Ethernet | | 0 | - | 0 |
| | | | IEEE 802.11b | | 0 | - | О |
| | | Ethernet Speed | | - | - | - | |

| Name on the control panel | | | | Web browser | Smart- NetMon- itor for Admin | telnet | |
|---------------------------|-----------------|----------------------------|--------------------|-----------------|--|--------|---|
| Interface Settings | Network | Effective Protocol | TCP/IP | | - | O *1 | 0 |
| | | | NetWare | | 0 | O *2 | 0 |
| | | | SMB | | 0 | 0 | 0 |
| | | | AppleTalk | | 0 | 0 | 0 |
| | | | SNMP | | 0 | О | 0 |
| | | Host Name | | 0 | О | 0 | |
| | | Domain Name | | 0 | - | 0 | |
| | IEEE 1394 | IP Address | Auto-Obtain (DHCP) | | 0 | - | 0 |
| | | | Specify | IP Address | 0 | - | 0 |
| | | | | Sub-net Mask | 0 | - | 0 |
| | | IP over 1394 | | 0 | - | О | |
| | | WINS Configu- ration | ►WINS Server | | 0 | - | 0 |
| | | | Scope ID | | О | - | О |
| | | SCSI print (SBP-2) | | 0 | - | O | |
| | | Bidirectional SCSI print | | | О | - | 0 |
| | | Host Name | | | 0 | - | 0 |
| | | Domain Name | | | 0 | - | O |
| | IEEE 802.11b | Communication Mode | | | 0 | - | 0 |
| | | SSID Setting | | 0 | - | 0 | |
| | | Channel | | 0 | - | O | |
| | | WEP (Encryption) Setting | | 0 | - | O | |
| | | Transmission Speed | | | - | - | 0 |

| | Name on the control panel | Web browser | Smart- NetMon- itor for Admin | telnet |
|----------|--|----------------|--|--------|
| File | SMTP Server | 0 | - | - |
| Transfer | SMTP Authentication | 0 | - | - |
| | POP before SMTP | 0 | - | - |
| | Reception Protocol | 0 | - | - |
| | POP3/ IMAP4 Settings | 0 | - | - |
| | Key Operator's E-mail Address | 0 | - | - |
| | E-mail Reception Port | 0 | - | - |
| | E-mail Reception Interval | 0 | - | - |
| | Max. Reception E-mail Size | 0 | - | - |
| | E-mail Storage in Server | 0 | - | - |
| | Default User Name/ Password (Send) | 0 | - | - |
| | Program/ Change/ Delete E-mail Message | - | - | - |
| | Program/ Change/ Delete Subject | - | - | - |
| | Scanner Recall Interval Time | - | - | - |
| | Number of Scanner Recalls | - | - | - |
| | E-mail Account | - | - | - |

You can make the TCP/IP settings if SmartNetMonitor for Admin is communicating with the machine using IPX/SPX. You can make the IPX/SPX settings if SmartNetMonitor for Admin is communicating with the machine using TCP/IP.

Settings You Can Change with User Tools

Interface Settings/Network

IP Address

Before using this machine in the network environment, you must configure the IP address and subnet mask.

- Auto-Obtain (DHCP)
- Specify
 When you select [Specify], enter
 the [IP Address] and [Sub-net
 Mask] as "xxx.xxx.xxx.xxx"("x"
 indicates a number).
 - IP Address: 011.022.033.044
 - Sub-net Mask: 000.000.000.000

Note

- ☐ Default: *Auto-Obtain (DHCP)*
- ☐ If you use the interface for Ethernet and IEEE 1394 (IP over 1394) at the same time, settings must be made carefully. See p.114 "Using DHCP".
- ☐ If you install the optional IEEE 1394 interface board and use the IEEE 1394 interface, you must set the address of the domain, different from the [IP Address] of [IEEE 1394]. If you intend to set the address for the same domain, set a different value for the [Sub-net Mask].
- ☐ When you select [Specify], be sure not to set the same [IP Address] as that of another machines on the network.
- ☐ The physical address (MAC address) also appears.

Gateway Address

A gateway is a connection or interchange point between two networks. Configure the gateway address for the router or host computer used as a gateway.

• Gateway Address:000.000.000.000

☐ Default: 000.000.000.000

DNS Configuration

Make settings for the DNS server.

- Auto-Obtain (DHCP)
- Specify
 When you select [Specify], enter
 the [DNS Server] IP address as
 "xxx.xxx.xxx.xxx"("x" indicates a number).
 - DNS Server 1:000.000.000.000
 - DNS Server 2:000.000.000.000
 - DNS Server 3:000.000.000.000

Ø Note

☐ Default: *Auto-Obtain (DHCP)*

♦ NW Frame Type

Select the frame type when you use NetWare.

- Auto Select
- Ethernet II
- Ethernet 802.2
- Ethernet 802.3
- Ethernet SNAP

Note

☐ Default: Auto Select

◆ LAN Type

When you have installed the optional IEEE 802.11b interface unit, select interface, IEEE 802.11b (wireless LAN) or Ethernet.

- Ethernet
- IEEE 802.11b

Note

- ☐ Default: *Ethernet*
- ☐ Appears when the optional IEEE 802.11b interface unit is installed.
- ☐ If Ethernet and IEEE 802.11b (wireless LAN) are both connected to the machine, the selected interface takes precedence.

Ethernet Speed

Set the access speed for networks. Select a speed that matches your network environment. [Auto Select] should usually be selected.

- Auto Select
- 100Mbps Fixed
- 10Mbps Fixed

𝒯 Note

☐ Default: Auto Select

Effective Protocol

Select the protocol to use in the network.

- TCP/IP:Effective/Invalid
- NetWare:Effective/Invalid
- SMB:Effective/Invalid
- AppleTalk:Effective/Invalid

Note

☐ Default: TCP/IP: Effective, Net-Ware: Effective, SMB: Effective, AppleTalk: Effective

Host Name

Specify the host name.

Domain Name

Specify the domain name.

♦ WINS Configuration

You can specify the WINS server settings.

• ON

If **[ON]** is selected, enter the **[►WINS Server]** IP address as "xxx.xxx.xxx.xxx"("x" indicates a number).

If DHCP is in use, specify the **[Scope ID]**.

- **WINS Server:000.000.000.000**
- Scope ID
- OFF

Limitation

☐ Enter a **[Scope ID]** using up to 31 alphanumeric characters.

Ø Note

☐ Default: OFF

Interface Settings/IEEE 1394



You must install the optional IEEE 1394 interface board in the machine.

IP Address

When you connect the machine to a network using the IEEE 1394 interface, you must configure the IP address and subnet mask.

- Auto-Obtain (DHCP)
- Specify
 When you select [Specify], enter
 the [IP Address] and [Sub-net
 Mask] as "xxx.xxx.xxx.xxx"("x"
 indicates a number).
 - IP Address: 011.022.033.044
 - Sub-net Mask: 000.000.000.000

𝚱 Note

- ☐ Default: *Auto-Obtain (DHCP)*
- ☐ If you use the interface for Ethernet and IEEE 1394 (IP over 1394) at the same time, settings must be made carefully. See p.114 "Using DHCP"
- ☐ When you use the IEEE 1394 interface on a network, you cannot use the Ethernet interface in the same domain. To use both interfaces in the same domain, set different values for the [Subnet Mask].
- ☐ The physical address (MAC address) also appears.

❖ IP over 1394

When you use the IP over 1394 function of the IEEE 1394 interface to connect the machine to the network, or you print from computer with the IP over 1394 driver, you must specify [Active] for [IP over 1394].

- Active
- Inactive

Limitation

☐ Printing with IP over 1394 is possible under Windows Me/XP and Windows Server 2003

Ø Note

☐ Default: *Active*

WINS Configuration

You can specify the WINS server settings.

ON

If **[ON]** is selected, specify the **[►WINS Server]** IP address as "xxx.xxx.xxx.xxx" ("xxx" indicates a number).

If DHCP is in use, specify the [Scope ID].

- **WINS Server:000.000.000.000**
- Scope ID
- OFF

Limitation

☐ Enter **[Scope ID]** using up to 31 alphanumeric characters.



□ Default: OFF

♦ SCSI print (SBP-2)

When you print using the SCSI print client function supported by Windows 2000/XP, or Windows Server 2003, you must set [SCSI print (SBP-2)].

- Active
- Inactive

Limitation

☐ The IEEE 1394 interface can be used when Windows 2000 Service Pack 1 or later is installed. If the Service Pack is not installed, only one SCSI print device is connectable via 1394 bus.

Note

□ Default: *Active*

Bidirectional SCSI print

Specifies the printer's response mode etc. for status requests when using the IEEE 1394 interface.

- ON
- OFF

Note

- ☐ Default: *ON*
- ☐ If this is set to [OFF], bidirectional communication will not work.

Host Name

Specify the host name.

Domain Name

Specify the domain name.

Interface Settings/IEEE 802.11b



Preparation

You must install the optional IEEE 802.11b interface unit into the machine.



☐ Be sure to make all settings simultaneously.

Communication Mode

Specifies the communication mode of the wireless LAN.

- 802.11 Ad hoc
- Ad hoc
- Infrastructure

Note

□ Default: 802.11 Ad hoc

SSID Setting

Specifies SSID to distinguish the access point in infrastructure mode or 802.11 ad hoc mode.

Limitation

☐ The characters that can be used are ASCII 0x20-0x7e (32 bytes).

Mote

- ☐ Default: blank (ASSID)
- ☐ If blank is specified in 802.11b ad hoc mode or ad hoc mode, "ASSID" appears.

Channel

Specifies a channel when you select 802.11b ad hoc mode or ad hoc mode.

Note

☐ Default: 11

☐ The following channels are available:

Metric version: 1-13

Inch version: 1-11

♦ WEP (Encryption) Setting

Specifies the encryption of the IEEE 802.11b (wireless LAN). If this is set to **[Active]**, you must enter the WEP key.

- ►WEP
 - Active
 - Inactive
- Encryption

10 alphanumeric characters must be entered for 64 bit, 26 characters for 128 bit.

Note

□ Default: *Inactive*

Wireless LAN Signal

Shows the radio wave conditions of the access point connected in infrastructure mode.

Note

☐ Radio wave status is displayed when you press [Wireless LAN Signal].

Transmission Speed

Specifies the communication speed of the IEEE 802.11b (wireless LAN).

- Auto
- 11Mbps Fixed
- 5.5Mbps Fixed
- 2Mbps Fixed
- 1Mbps Fixed

Ø Note

☐ Default: Auto

Return to Defaults

You can return the IEEE 802.11b (wireless LAN) settings to their defaults.

- No
- Yes

Interface Settings/Print List

You can check items related to the network in use.

For details about printing, see p.47 "Printing the Interface Settings".

File Transfer

Delivery Option

Enables or disables sending stored or scanned documents via the ScanRouter V2 Professional/Lite delivery server.

- ON
 - Main Delivery Server IP Address
 - Sub Delivery Server IP Address
- OFF

Note

□ Default: OFF

☐ Set this option when specifying whether or not to use ScanRouter V2 Professional/Lite. If you do, you will have to re-register I/O devices in ScanRouter V2 Professional/Lite.

Fax RX File Transmission

- Setting per Line Specifies whether or not received fax documents are sent to ScanRouter V2 Professional for each fax line.
 - Line 1:Deliver to Server/Do not Deliver
 - Line 2:Deliver to Server/Do not Deliver
 - E-mail:Deliver to Server/Do not Deliver



☐ Default: Do not Deliver

Print at Delivery Specifies whether or not received fax documents sent to ScanRouter V2 Professional should also be printed at the

Print

same time.

Do not Print

Note

☐ Default: *Do not Print*

File to Deliver Specifies whether all received fax documents or only received fax documents that include de livery codes (documents with an ID and SUB/SEP code) are sent to ScanRouter V2 Profes

- File with Dlvry Code
- All Files

𝚱 Note

sional.

☐ Default: All Files

- Dlvry Failure File
 - Print File
 - Delete File

If a received fax document cannot be sent to ScanRouter V2 Professional, it is stored in memory. To print a stored file, select [Print File]; to delete, select [Delete File].

Note

- ☐ If the machine can send the data to ScanRouter V2 Professional, it does so automatically.
- ☐ If you delete the data, you will not be able to distribute or print it.

SMTP Server

Specify the SMTP server name. If DNS is in use, enter the host name.

If DNS is not in use, enter the SMTP server IP address.

- Server Name
- Port No.:25

Limitation

☐ Enter the **[Server Name]** using up to 127 alphanumeric characters. Spaces cannot be used.

Note

☐ Enter[Port No.] between 1 and 65535 using the number keys, and then press the [#]key.

SMTP Authentication

You can configure SMTP authentication (PLAIN, LOGIN, CRAMMD5).

Authentication prevents unauthorized access, by making users enter a user name and password when sending e-mail to the SMTP server.

SMTP Authentication

- ON
 If the SMTP server requires authentication, set [SMTP Authentication] to [ON], and then specify [User Name], [Password], and [►Encryption].
 - User Name
 - Password
 - Encryption Auto/ON/OFF
- OFF

Limitation

☐ Enter **[User Name]** using up to 191 alphanumeric characters. Spaces cannot be used.

- ☐ Depending on the SMTP server type, "realm" must be specified. Add "@" after the user name, as in "user name@realm".
- ☐ Enter **[Password]** using up to 63 alphanumeric characters. Spaces cannot be used.
- ☐ Enter the user name and password to be set for [Key Operator's E-mail Address] when using Internet Fax.

Note

- ☐ Default: OFF
- □ [►Encryption]-[Auto]: If the authentication method is PLAIN, LOGIN, or, CRAM-MD5.
- □ [►Encryption]-[ON]: If the authentication method is CRAM-MD5.
- □ [►Encryption]-[OFF]: If the authentication method is PLAIN, or LOGIN.

❖ POP before SMTP

You can configure POP authentication (POP before SMTP).

Authentication prevents unauthorized access, by authenticating with the POP server before sending e-mail to the SMTP server.

ON

To enable POP server authentication before sending e-mail via the SMTP server, set [POP before SMTP] to [ON].

E-mail is sent to the SMTP server after the time specified for [>Wait Time after Auth.] has elapsed.

- Wait Time after Auth.: 300msec
- User Name
- Password
- OFF

Limitation

- ☐ Enter [User Name] using up to 63 alphanumeric characters. Spaces cannot be used.
- ☐ Enter [Password] using up to 63 alphanumeric characters. Spaces cannot be used.

Note

- ☐ Default: OFF
- ☐ Using the number keys, you can set [►Wait Time after Auth.] from zero to 10,000 milliseconds, in increments of one millisecond.
- ☐ If you select [ON], enter [Server Name] in [POP3/ IMAP4 Settings].
 Also, check the port number for [POP3] in [E-mail Reception Port].

Reception Protocol

Specify Reception Protocol for receiving Internet faxes.

- OFF
- POP3
- IMAP4
- SMTP

Note

☐ Default: *OFF*

❖ POP3/ IMAP4 Settings

Specify the POP3/IMAP4 [Server Name] for receiving Internet faxes. The specified POP3 server name is used for [POP before SMTP].

If DNS is in use, enter the host name.

If DNS is not in use, enter the POP3 or IMAP4 server IP address.

- Server Name
- Encryption
 - Auto
 - ON
 - OFF

Limitation

☐ Enter POP3 or IMAP4 [Server Name] using to 127 alphanumeric characters. Spaces cannot be used.

Note

- □ ► Encryption-[Auto]: Password encryption is automatically set according to the POP server settings.
- □ ► Encryption-[ON]: Encrypt password.
- ☐ ► Encryption-[OFF]: Do not encrypt password.

Key Operator's E-mail Address

On e-mailed scanned documents, if the sender is not specified this appears as the sender's address.

This can be used as the sender with SMTP authentication for Internet Fax. If **[ON]** is selected for **[SMTP Authentication]** be sure to enter the key operator's e-mail address here.

This can be used as the destination for data transmission result cc emails, as well as the destination for data communication management e-mail.

Limitation

☐ Enter up to 128 alphanumeric characters.

Note

Specify the sender's name when sending scanned document email, if [No] is selected in [Sender's Name Default].

E-mail Reception Port

Specify the [POP3], [IMAP4], and [SMTP] port numbers for receiving Internet faxes.

The specified POP3 port number is used for **[POP before SMTP]**.

- POP3: 110
- IMAP4: 143
- SMTP: 25

𝚱 Note

- ☐ Default: *POP3/110, IMAP4/143, SMTP/25*
- ☐ Enter a port number between 1 and 65535 using the number keys, and then press the [#] key.

E-mail Reception Interval

Specify, in minutes, the time limit for receiving Internet faxes via POP3 or IMAP4 server.

- ON: 15 minute(s)
- OFF

𝚱 Note

- ☐ Default: *ON/15 minute(s)*
- ☐ If **[ON]** is selected, the number of times can be set from 1 to 1440 in increments of one minute, using the number keys.

Max. Reception E-mail Size

Specify the [Max. Reception E-mail Size] for receiving Internet faxes.

Note

□ Default: 2MB

☐ Using the number keys, enter a size from one to 50 MB in increments of one megabyte.

E-mail Storage in Server

You can specify whether or not to store received Internet fax e-mails on the POP3 or IMAP4 server.

- OFF
- All
- Errors Only

∅ Note

☐ Default: OFF

Default User Name/ Password (Send)

You can specify the user name and password required when sending scan file directly to a shared folder on a computer running Windows, or to an FTP server.

- SMB User Name
- SMB Password
- FTP User Name
- FTP Password

Limitation

☐ Enter up to 128 alphanumeric characters.

Program/ Change/ Delete E-mail Message

You can program, change, or delete the e-mail message used when sending an Internet fax or scan file as an attachment.

- Program / Change
- Delete

- ☐ Enter a name using up to 20 alphanumeric characters.
- ☐ Enter up to five lines of text. Each line can consist of up to 80 alphanumeric characters.

Program/ Change/ Delete Subject

You can program, change, or delete the subject used when sending an Internet fax or scan file as an attachment.

- Program/ Change
- Delete

Ø Note

☐ Enter a subject using up to 20 alphanumeric characters.

Scanner Recall Interval Time

Specifies the interval the machine waits before resending scan file, if they cannot be sent to the delivery server or mail server.

- ☐ Default: 300 seconds
- ☐ The interval time can be set from 60 to 999 seconds in one second increments, using the number keys.
- ☐ This setting is for the scanner function.

Number of Scanner Recalls

Sets a maximum number of times scan file is resent to the delivery server or mail server.

- ON: 3 time(s)
- OFF

Note

- \square Default: *ON/3 time(s)*
- ☐ If **[ON]** is selected, the number of times can be set from 1 to 99 using the number keys.
- ☐ This setting is for the scanner function.

❖ E-mail Account

Specify [E-mail Address], [User Name], and [Password] for receiving Internet faxes.

- ►Fax Mail Reception
 - E-mail Address
 - User Name
 - Password

Limitation

- ☐ Enter an e-mail address using up to 128 alphanumeric characters.
- ☐ Enter a user name using up to 64 alphanumeric characters.
- ☐ Enter a password using up to 64 alphanumeric characters.

Programming, changing, or deleting an e-mail message

Limitation

- ☐ Enter a name using up to 20 alphanumeric characters.
- ☐ Enter up to five lines of text. Each line can consist of up to 80 alphanumeric characters.
- 1 Press the [User Tools/Counter] key.
- **2** Press [System Settings].
- 3 Press [File Transfer].
- 4 Press [▼ Next].

The next screen appears.

Press [Program/ Change/ Delete E-mail Message].

Programming an e-mail message

• Press [*Not programed].

2 Press [Change], and then enter the name.

For more information about entering text, see "Entering Text", General Settings Guide.

- 3 Press [OK].
- 4 Press [Edit], and then enter the text.

To start a new line, press [OK] to return to the e-mail message screen, and then press [▼] in [Select Line to Edit:].

6 Press [OK].

The e-mail message screen appears.

6 Press [OK].

Changing an e-mail message

- Select the e-mail message to change.
- 2 If you want to change the subject, press [Change].
- 3 Change the subject, and then press [OK].
- 4 If you want to change the text, press [Edit].
- **⑤** Press [▲] or [▼] to select the line to change.
- **6** Change the text, and then press [OK].
- Press [OK].

Deleting an e-mail message

- 1 Press [Delete].
- 2 Select the e-mail message to delete.

The confirmation message about deleting appears.

3 To delete the data, press [Yes].

- 6 Press [Exit].
- 7 Press [Exit].
- Press the [User Tools/Counter] key.
 - Note
 - ☐ You can also exit by pressing **[Exit]** on the User Tools main menu.

Programming, changing, or deleting a subject

- Limitation
- ☐ Enter a subject using up to 20 alphanumeric characters.
- Ø Note
- ☐ [**Urgent**] and [**High**] are programmed as the e-mail subjects.
- 1 Press the [User Tools/Counter] key.
- **2** Press [System Settings].
- Press [File Transfer].
- Press [▼Next]. The next screen appears.
- Press [Program/ Change/ Delete Subject].

Programming a subject

- Press [*Not programed], and then enter the text.

For more information about entering text, see "Entering Text", General Settings Guide.

2 Press [OK].

Changing a subject

- Select the subject to change.
- 2 Enter the text.
- 3 Press [OK].

Deleting a subject

- 1 Press [Delete].
- **2** Select the subject to delete.

The confirmation message about deleting appears.

- 3 To delete the subject, press [Yes].
- 6 Press [Exit].
- **7** Press [Exit].
- 8 Press the [User Tools/Counter] key.

You can also exit by pressing **[Exit]** on the User Tools main menu.

Printing the Interface Settings

The configuration page shows the current network settings and network information.

- 1 Press the [User Tools/Counter] key.
- **2** Press [System Settings].
- Press [Interface Settings].
- 4 Press [Print List].
- Press the [Start] key.

The configuration page is printed.

- 6 Press [Exit].
- **7** Press the [User Tools/Counter] key.
 - Note
 - ☐ You can also exit by pressing **[Exit]** on the User Tools main menu.

4. Windows Configuration

Configuring TCP/IP

This describes how to configure Windows for TCP/IP and IPP.

Configuring a Windows 95/98/Me Computer

Follow the procedure below to configure a Windows 95/98/Me computer to use TCP/IP.

Open [Control Panel], and then double-click the Network icon. Make sure [TCP/IP] is listed in the [The following network components are installed] box on the [Configuration] tab.

∅ Note

☐ Under Windows Me, if you want to use IEEE 1394 (IP over 1394) interface, make sure TCP/IP is bound to the IEEE 1394 adaptor being used. The following message appears:

TCP/ IP -> (IEEE 1394 adaptor in use)

- ☐ If TCP/IP is not installed, click [Add] on the [Configuration] tab to install it. For more information about installing TCP/IP, see Windows 95/98/Me Help.
- 2 Configure TCP/IP using the appropriate IP address, subnet mask, and other settings.

Check with the network administrator that the settings are correct.

Configuring a Windows 2000 Computer

Follow the procedure below to configure a Windows 2000 computer to use TCP/IP.

- On the [Start] menu, point to [Settings], and then click [Network and Dial-up Connections].
- Double-click [Local Area Connection]. On the [General] tab, click [Properties].
- Make sure [Internet Protocol (TCP/IP)] is selected in the [Components checked are used by this connection] box on the [General] tab.

Note

- ☐ Select TCP/IP if it is not already selected.
- ☐ If TCP/IP is not installed, click [Install] on the [General] tab to install it. For more information about installing TCP/IP, see Windows 2000 Help.
- 4 Configure TCP/IP using the appropriate IP address, subnet mask, and other settings.

Check with the network administrator that the settings are correct.

Configuring a Windows XP Computer

Follow the procedure below to configure a Windows XP computer to use TCP/IP.

- On the [Start] menu, click [Control Panel], and then click [Network and Internet Connections].
- 2 Click [Network Connections], and then double-click [Local Area Connection].
 - **𝚱** Note
 - ☐ If you want to use IEEE 1394 (IP over 1394) interface, click [1394 Connection].
- On the [General] tab, click [Properties].
- Make sure [Internet Protocol (TCP/IP)] is selected in the [This connection uses the following items] box on the [General] tab.
 - Note
 - ☐ Select TCP/IP if it is not already selected.
 - ☐ If TCP/IP is not installed, click **[Install]** on the **[General]** tab to install it. For more information about installing TCP/IP, see Windows XP Help.
- Configure TCP/IP using the appropriate IP address, subnet mask, and other settings.

Check with the network administrator that the settings are correct.

Configuring a Windows Server 2003 Computer

Follow the procedure below to configure a Windows Server 2003 computer to use TCP/IP.

- 1 On the [Start] menu, point to [Control Panel], point to [Network Connections] and then click [Local Area Connection].
 - **∅** Note
 - ☐ If you want to use IEEE 1394 (IP over 1394) interface, click **[1394 Connection]**.
- 2 On the [General] tab, click [Properties].
- Make sure [Internet Protocol (TCP/IP)] is selected in the [This connection uses the following items] box on the [General] tab.
 - Note
 - ☐ Select TCP/IP if it is not already selected.
 - ☐ If TCP/IP is not installed, click [Install] on the [General] tab to install it. For more information about installing TCP/IP, see Windows Server 2003 Help.
- 4 Configure TCP/IP using the appropriate IP address, subnet mask, and other settings.

Check with the network administrator that the settings are correct.

Configuring a Windows NT 4.0 Computer

Follow the procedure below to configure a Windows NT 4.0 computer to use TCP/IP.

Open [Control Panel], and then double-click the Network icon. Make sure [TCP/IP Protocol] is listed in the [Network protocols] box on the [Protocols] tab.

𝒯 Note

- ☐ If TCP/IP is not installed, click **[Add]** on the **[Protocols]** tab to install it. For more information about installing TCP/IP, see Windows NT 4.0 Help.
- 2 Configure TCP/IP using the appropriate IP address, subnet mask, and other settings.

Check with the network administrator that the settings are correct.

Configuring NetBEUI

This describes how to configure Windows to use NetBEUI.

Limitation

□ NetBEUI cannot be used under Windows XP and Windows Server 2003.

𝚱 Note

☐ NetBEUI appears as SMB in the control panel, manual, and related utilities.

Configuring a Windows 95/98/Me Computer

Follow the procedure below to configure a Windows 95/98/Me computer to use NetBEUI.

Open [Control Panel], and then double-click the Network icon. Make sure [NetBEUI] is listed in the [The following network components are installed] box on the [Configuration] tab.

Note

- ☐ If NetBEUI is not installed, click [Add] on the [Configuration] tab to install it. For more information about installing NetBEUI, see Windows 95/98/Me Help.
- ☐ If [NetBEUI →Dial-Up Adaptor] is listed in the [The following network components are installed] box, select it, and then click [Remove] to remove the binding.
- 2 Click [OK] to close the [Network] dialog box.

Configuring a Windows 2000 Computer

Follow the procedure below to configure a Windows 2000 computer to use NetBEUI.

- On the [Start] menu, point to [Settings], and then click [Network and Dial-up Connections].
- 2 Double-click [Local Area Connection]. On the [General] tab, click [Properties].
- Make sure [NetBEUI Protocol] is selected in the [Components checked are used by this connection] box on the [General] tab.

Note

- ☐ Select NetBEUI if it is not already selected.
- ☐ If NetBEUI is not installed, click [Install] on the [General] tab to install it. For more information about installing NetBEUI, see Windows 2000 Help.

Configuring a Windows NT 4.0 Computer

Follow the procedure below to configure a Windows NT 4.0 computer to use NetBEUI.

- Open [Control Panel], and then double-click the Network icon. Make sure [NetBEUI Protocol] is listed in the [Network protocols] box on the [Protocols] tab.
 - Note
 - ☐ If NetBEUI is not installed, click **[Add]** on the **[Protocols]** tab to install it. For more information about installing NetBEUI, see Windows NT 4.0 Help.
- 2 Change the Lana Number. Click the [Services] tab, click [NetBIOS Interface] in the [Network services] box, and then click [Properties].
- Click the Lana Number corresponding to the Nbf protocol in the [Network Route] column, and then click [Edit].
- 4 Enter "0" as the Lana Number.
 - Note
 - ☐ If the other protocol's Lana Number is "0", you must change the Lana Number to a number other than "0".
- **5** Click [**0**K].
- 6 Click [Close] to close the [Network] dialog box.

The confirmation message about restarting appears.

7 Click [Yes].

Note

☐ After you change the Lana Number, you must restart the computer.


5. Using the Printer Function

This section contains instructions for configuring the machine as a network printer. Read the section that relates to your network environment for information about correct configuration.

❖ Printing with a Windows 2000/XP, Windows Server 2003 ,or Windows NT 4.0 Print Server


To set up the machine as a network printer in Windows 95/98/Me/2000/XP, Windows Server 2003, and Windows NT 4.0 environment, see p.59 "Printing with Windows".

 Printing with a Windows 2000/XP, Windows Server 2003, or Windows NT 4.0 print server



GKRH090F

• Printing without a print server




GKRH100E

𝚱 Note

☐ Under Windows XP and Windows Server 2003, you cannot print via NetBEUI using SMB.

Printing with a Mac OS

To set up the machine as a network printer in a Mac OS environment, see p.63 "Printing with a Mac OS".




GKRH110E


Printing with NetWare

To set up the machine as a print server or remote printer in a NetWare environment, see p.65 "Printing with NetWare". The network interface board allows you to use the machine as either a print server or a remote printer.

• Configuring the machine as a print server




• Configuring the machine as a remote printer



❖ Printing with UNIX

For UNIX printing information, visit our Web site or consult your authorized dealer.



GKRH140E

Printing with Windows


Printing with a Windows 2000/XP, Windows Server 2003, or Windows NT 4.0 Print Server

This describes how to configure a client computer on a network using Windows 2000/XP, Windows Server 2003, Windows NT 4.0 Server or Windows NT 4.0 Workstation as a print server.

When using a Windows 2000/XP, Windows Server 2003 or Windows NT 4.0 print server, select a shared printer on Windows 2000/XP, Windows Server 2003 or Windows NT 4.0.

This section describes running [Add Printer Wizard] on each client computer, and adding the Windows 2000, Windows XP, Windows Server 2003, and Windows NT 4.0 print servers as the network printer.

These instructions are for Windows 98.



GKRH150E

Limitation

- ☐ When using a print server connected to the machine with SmartNet-Monitor for Client, you cannot use Recovery Printing and Parallel Printing.
- ☐ When using Windows XP and Windows Server 2003 as a print server, the client computer cannot receive notification of print job completion.

𝚱 Note

- ☐ This section assumes the client is already configured to communicate with a Windows 2000/XP, Windows Server 2003 or Windows NT 4.0 print server. Do not begin the following procedure until the client computer is set up and configured correctly.
- ☐ When using Windows NT 4.0 as the print server, make sure you install the Windows NT 4.0 printer driver before connecting the print server. There is a Windows NT 4.0 printer driver on the CD-ROM labeled "Printer Drivers and Utilities".
- 1 On the [Start] menu, point to [Settings], and then click [Printers].
- 2 Click the icon of the printer you want to use. On the [File] menu, click [Properties].
- Click the [Details] tab, and then click [Add Port].
- 4 Click [Network], and then click [Browse].

On the network tree, double-click the name of the computer used as the print server.

The printers connected to the network are displayed.

- 6 Click the name of the printer you want to use, and then click [OK].
- **7** Click [**0**K].
- Make sure the port name is displayed in the [Print to the following port] box, and then click [OK].

Printing without a Print Server

You can use this machine as a network printer without connecting to a print server.

You can configure the following ports:

SmartNetMonitor

You can print via TCP/IP, IPP, or NetBEUI using SmartNetMonitor.

- ☐ Install SmartNetMonitor for Client from the supplied CD-ROM. For more information about installation, see *Printer Reference* 1.
- ☐ For more information about SmartNetMonitor for Client, see p.77 "Using SmartNetMonitor for Client".

Standard TCP/IP port

You can print via TCP/IP using a standard TCP/IP port.

Note

☐ A standard TCP/IP port can be used with Windows 2000/XP or Windows Server 2003.

◆ LPR port

You can print via TCP/IP using an LPR port.

Note

☐ An LPR port can be used with Windows 2000/XP, Windows Server 2003, or Windows NT 4.0.

Changing port settings

This describes how to change the port settings under Windows 2000 when a printer driver has been installed.

- In the [Printers] window, click the icon of the printer you want to use. On the [File] menu, click [Properties].
- 2 Click the [Ports] tab, and then click [Add Port].

Select the port you want to use.

SmartNetMonitor

- Click [SmartNetMonitor], and then click [New Port].
- 2 Select the printer you want to use.

❖ TCP/IP

- Click [TCP/IP], and then click [Search].
 Available printers are listed.
- ② Click the printer you want to use, and then click [OK].

Note

☐ Printers that respond to a broadcast from the computer will be displayed. To print to a printer not listed here, click [Specify Address], and then enter the printer's IP address or host name.

❖ NetBEUI

Note

- ☐ Do not use NetBEUI under Windows XP and Windows Server 2003.
- Click [NetBEUI], and then click [Search].
 Available printers are listed.
- ② Click the printer you want to use, and then click [OK].

Note

- ☐ Printers that respond to a broadcast from the computer will be displayed. To print to a printer not listed here, click [Specify Address], and then enter the NetBEUI address. Confirm the NetBEUI address on the network appears on the configuration page. For more information about printing the configuration page, see Printer Reference 2. Net-BEUI addresses appear as "\\RNPxxxx\xxx" on the configuration page. Enter the printer's network path name in the format: "%%Computer name\Share name". Do not enter "\\" as head characters but "%%".
- ☐ You cannot print to printers beyond routers.

♣ IPP

- ① Click [IPP].

 The IPP setting dialog box appears.
- ② To specify the IP address of the printer, enter "http://printer's IP address/printer" or "ipp://printer's IP address/printer" in the [Printer URL] box.

(Example: IP address is 192.168.15.16)

http://192.168.15.16/ printer ipp://192.168.15.16/ printer

- ③ If necessary, enter the name to identify the printer in the [IPP Port Name] box. Enter a different name from those of any existing port name.

 If you do not do this, the address entered in the [Printer URL] box is set as the IPP port name.
- ④ If a proxy server and IPP user name are used, click [Detailed Settings] and make the necessary settings.
- ⑤ Click [OK].

Standard TCP/IP Port


- Click [Standard TCP/IP], and then click [New Port].
- 2 In the [Add Standard TCP/IP Printer Port Wizard] dialog box, click [Next].
- 3 In the [Printer Name or IP Address] box, enter the printer name or IP address, and then click [Next].
- 4 In the [Add Standard TCP/IP Printer Port Wizard] dialog box, click [Finish].

LPR Port

- Click [LPR Port], and then click [New Port].
- 2 In the [Name or address of server providing lpd] box, enter the printer's IP address.
- 3 In the [Name of printer or print queue on that server] box, enter "lp", and then click [OK].
- Click [OK].
- 4 Check the location for the selected printer, and click [Close].

Printing with a Mac OS

This describes how to configure a Mac OS computer to use EtherTalk. Actual procedures may vary depending on the version of the Mac OS. The following procedures describe how to configure Mac OS 9.1 and Mac OS X v10.1. If you are using other version than Mac OS 9.1 and Mac OS X v10.1, see the manual that comes with Mac OS for more information.



𝚱 Note

- ☐ Mac OS 8.6 and later versions are supported (except for Mac OS X v10.0.x).
- ☐ To print from a Mac OS, PostScript 3 option is required.

Changing to EtherTalk

Follow the procedure below to configure a Mac OS computer to use EtherTalk.

For more information about installing the software required for EtherTalk, see the Mac OS manuals.

Mac OS

- 1 Open [Control Panel], and then double-click the AppleTalk icon.
- On the [Connect via] pop-up menu, click [Ethernet].
- If you change zones, select a name on the [Current zone] pop-up menu.
- Close the [AppleTalk] control panel.
- **5** Restart the Mac OS.

Mac OS X

Note

- ☐ You need an administrator name and a password (phrase). For more information, consult your administrator.
- 1 Open [System Preferences], and then click the Network icon.
- 2 From the [show] menu, select [Built-in Ethernet].
- Click the [AppleTalk] tab.
- 4 If you change zones, select a name on the [AppleTalk Zone:] pop-up menu.
- When the setting is complete, click [Apply Now].

Configuring the Printer

Use the control panel to activate the AppleTalk protocol. (The default is active.)

For more information about configuration, see p.37 "Interface Settings/Network".

Changing the Printer Name

If the network has several similar model printers, the names will be the same. Printers with the same name will have slightly different names in the **[Chooser]** dialog box. For example, three printers named "printer" will appear in the **[Chooser]** dialog box as "printer0", "printer1", and "printer2".

To change the printer name in the Mac OS EtherTalk environment, use Printer Utility for Mac included on the CD-ROM labeled "Printer Drivers and Utilities".


Changing the Zone

To change the zone configuration in a Mac OS EtherTalk environment, use Printer Utility for Mac included on the CD-ROM labeled "Printer Drivers and Utilities".

For more information about using Printer Utility for Mac, see *Post-Script 3 Supplement*, provided as a PDF file on the CD-ROM labeled "Operating Instructions for Printer/Scanner".

Printing with NetWare

This describes how to configure the machine for use as a print server or remote printer in a NetWare environment.



This section assumes NetWare is functional and the necessary environment for the NetWare print service is available.

Note

□ NetWare must be set to active using the machine's control panel. For more information about how to set it, see p.19 "Setting Up the Machine on a Network".

SmartNetMonitor for Admin

To use a printer in a NetWare environment, configure the NetWare printing environment using SmartNetMonitor for Admin.

Note

- ☐ If you configure NetWare printing using SmartNetMonitor for Admin under the following environments, NetWare Client from Novell is required:
 - NDS mode in Windows 95/98/Me
 - NDS or Bindery mode in Windows 2000/Windows NT 4.0

Printers listed by SmartNetMonitor for Admin

SmartNetMonitor for Admin displays a list of printers that are connected to the network.

If you cannot find the printer from the displayed list, refer to the configuration page printed from the machine. For more information about printing a configuration page, see *Printer Reference* 2.

Setting Up as a Print Server

NetWare 3.x

- 1 Log on to the file server as a Supervisor, or equivalent.
- 2 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPX/SPX].

A list of machines appears.

- In the list, select the printer for which you want to change configuration.
- On the [Tools] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

- 6 Click [Wizard], and then click [OK].
- If necessary, enter the print server name in the [Device Name:] box, and then click [Next >].
- Select the [NetWare] check box, and then click [Next >].
- Olick [Bindery Mode], enter the file server name in the [File Server Name:] box, and then click [Next>].
 - In the [File Server Name:] box, enter the file server name (up to 47 alphanumeric characters) of the server to make the print server. You can also click [Browse...] to select a file server in the [Browse...] dialog box.

- Enter the print server name in the [Print Server Name:] box, the printer name in the [Printer Name:] box, and the print queue name in the [Print Queue Name:] box, then click [Next >].
 - In the [Print Server Name:] box, enter the name of the NetWare print server using up to 47 characters.
 - In the **[Printer Name:]** box, enter the name of the NetWare printer using up to 47 characters.
 - In the [Print Queue Name:] box, enter the name of the print queue to be added to NetWare.
- After confirming the settings, click [Next >].

The settings take effect, and NIB Setup Tool closes.

- **Q**uit SmartNetMonitor for Admin.
- 13 Restart the printer.

Note

☐ To make sure the printer is correctly configured, enter the following from the command prompt:

F:> USERLIST

☐ If the printer works as configured, the name of the print server appears as an attached user.

NetWare 4.x, 5/5.1, 6

#Important

☐ You must set up the print server using NDS mode in NetWare 4.x, 5/5.1, 6.

❖ To use NetWare 5/5.1, 6

- Use the printer as a print server.
 Do not use it as a remote printer in a PureIP environment.
- If you use PureIP, configure the machine to use TCP/IP. For more information about how to make the settings, see p.19 "Setting Up the Machine on a Network".
- 1 Log on to the file server as an administrator, or equivalent.
- 2 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPX/SPX] or [TCP/IP].

A list of machines appears.

- 4 In the list, select the printer for which you want to change configuration.
- On the [Tools] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

If you use NetWare 5/5.1 or NetWare 6.0 in a PureIP environment, see p.68 "Using PureIP in the NetWare 5/5.1, 6 environment".

6 Click [Wizard], and then click [OK].

- If necessary, enter the print server name in the [Device Name:] box, and then click [Next >].
- Select the [NetWare] check box, and then click [Next >].
- Click [NDS Mode:], enter the file server name in the [File Server Name:] box, the NDS tree name in the [NDS Tree:] box and the context in the [NDS Context:] box, and then click [Next >].
 - In the [File Server Name:] box, enter the file server name (up to 47 alphanumeric characters) of the server to make the print server. You can also click [Browse...] to select a file server in the [Browse...] dialog box.
 - In the [NDS Tree:] box, enter the NDS tree name (using up to 32 alphanumeric characters ("-" and "_" can be used)) of the NDS tree in which you want to make the print server. [Browse...] to select an NDS tree from those listed in the [Browse...] dialog box.
 - In the [NDS Context:] box, enter the NDS context in which to make the print server. As context, object names are entered in lower object order and divided by a period. For example, if you want to create a print server in NET under DS, enter "NET.DS".



- Enter the print server name in the [Print Server Name:] box, the printer name in the [Printer Name:] box, the print queue name in the [Print Queue Name:] box, and the print queue volume in the [Queue Volume:], and then click [Next >].
 - In the [Print Server Name:] box, enter the name of the NetWare print server using up to 47 characters.
 - In the [Printer Name:] box, enter the name of the NetWare printer using up to 47 characters.
 - In the [Print Queue Name:] box, enter the name of the print queue to be added to NetWare.
 - In [Queue Volume:], enter the print queue volume. As a volume, object names are entered from a lower object and divided by a period. You can also click [Browse...] to select a volume in the [Browse...] dialog box.
- After confirming the settings, click [Next >].
- 12 Click [Finish].

The settings take effect, and NIB Setup Tool closes.

- Ouit SmartNetMonitor for Admin.
- 11 Restart the printer.
 - Ø Note
 - ☐ To make sure the printer is correctly configured, enter the following from the command prompt:

F:>NLIST USER /A/B

☐ If the printer works as configured, the name of the print server appears as an attached user.

Using PureIP in the NetWare 5/5.1, 6 environment

Note

- □ When not using IPX, it is recommended that you change the print server protocol in the Web browser from [TCP/IP+IPX] to [TCP/IP].
- 1 Log on to the file server as an administrator, or equivalent.
- 2 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPX/SPX].

A list of machines appears.

- In the list, select the printer for which you want to change configuration.
- On the [Tools] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

- Click [Property Sheet], and then click [OK].
- If necessary, enter the print server name in the [Device Name:] box.
- Click the [NetWare] tab, and then make the following settings:
 - **1** In the [Logon Mode] area, click [File Server Mode] or [NDS Mode].
 - Ø Note
 - ☐ If **[File Server Mode]** is selected, a connecting destination will be chosen based on the string entered in step **3**.
 - ☐ If **[NDS Mode]** is selected, a connecting destination will be chosen based on the string entered in step **4**.

2 In the [Print Server Name:] box, enter the print server name.

Limitation

- ☐ Enter up to 47 alphanumeric characters.
- 3 In the [File Server Name:] box, enter the name of the file server in which the print server is to be created.

By clicking [Browse...], you can select a file server among those listed in the [Browse...] dialog box.

Limitation

- ☐ Enter up to 47 alphanumeric characters.
- 4 In the [NDS Tree:] box, enter the NDS tree name in which to make the file server.

By clicking [Browse...], you can select the NDS tree name and NDS context name from their lists.

Limitation

- ☐ Enter up to 32 alphanumeric characters ("-" and "_" can be used).
- **6** In the [NDS Context:] box, enter the context of the print server.

Limitation

☐ Enter up to 127 alphanumeric characters.

☐ As context, object names are entered in lower object order and divided by a period. For example, if you want to create a print server into NET under d, enter "d".



- 6 In the [Print Server Operation Mode] area, click [As Print Server].
- Click [OK] to close the [NIB Setup Tool - Network board list] dialog box.

Quit SmartNetMonitor for Admin.

After this step, operate the machine by following the procedure from step ② on p.72 "NetWare 4.x, 5/5.1, 6". However, steps ①-③ and ①-④ are not required.

Setting Up as a Remote Printer

NetWare 3.x

- 1 Log on to the file server as an administrator, or equivalent.
- 2 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPX/SPX].

A list of machines appears.

- In the list, select the printer for which you want to change configuration.
- On the [[Tools]] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

6 Click [Property Sheet], and then click [OK].

The [NIB Setup Tool - Network board list] dialog box appears.

- Click the [NetWare] tab, and then make the following settings:
 - In the [Print Server Name:] box, enter the name of the print server.
 - **?** Limitation
 - ☐ Enter up to 47 alphanumeric characters.
 - 2 In the [File Server Name:] box, enter the name of the file server in which a print server is to be created.

By clicking [Browse...], you can select a file server among those listed in the [Browse...] dialog box.

Limitation

☐ Enter up to 47 alphanumeric characters.

- 3 In the [Print Server Operation Mode] area, click [As Remote Printer].
- 4 In the [Remote Printer No.] box, enter the printer number.

∰Important

- ☐ Use the same printer number as that to be created in the print server.
- **6** Click [OK] to close the [NIB Setup Tool - Network board list] dialog box.
- **2** Quit SmartNetMonitor for Admin.
- **9** Enter "PCONSOLE" from the command prompt.

F:> PCONSOLE

Treate a print queue as follows:

Note

- ☐ If you are using a currently defined print queue, proceed to step ①
- On the [Available Options] menu, click [Print Queue Information], and then press the [ENTER] key.
- 2 Press the [INSERT] key, and then enter a print queue name.
- 3 Press the [ESCAPE] key to return to the [Available Options] menu.
- 11 Create a printer as follows:
 - On the [Available Options] menu, click [Print Server Information], and then press the [ENTER] key.

2 To create a new print server, press the [INSERT] key, and then enter a print server name.

Note

☐ If you are using a currently defined print server, select one of the print servers shown in the [Print Server] list.

∰Important

- ☐ Use the same name as that specified in NIB Setup Tool. (Step **7-①**).
- 3 On the [Print Server Information] menu, click [Print Server Configuration].
- On the [Print Server Configuration] menu, click [Printer Configuration].
- **6** Select the printer indicated as "Not Installed".

∰Important

- ☐ Use the same number as that specified as the Remote Printer No. using NIB Setup Tool. (Step 7-4).
- 6 If you want to change the printer name, enter a new name.

Ø Note

- ☐ The name "Printer x" is assigned to the printer. "x" stands for the number of the selected printer.
- Click [Remote Parallel, LPT1] as the printer type.

IRQ, Buffer size, Starting form, and Queue service mode are automatically configured.

8 Press the [ESC] key, and then click [Yes] when the confirmation message appears.

- Press the [ESC] key to return to the [Print Server Configuration] menu.
- Assign print queues to the created printer as follows:
 - On the [Print Server Configuration] menu, click [Queues Serviced By Printer].
 - 2 Select the printer created in step [].
 - 3 Press the [INSERT] key to select a queue serviced by the printer.

Note

- ☐ You can select more than one queue at a time.
- **4** Follow the instructions on screen to make other necessary settings.

When you have finished the above procedure, make sure the queues are assigned.

- Press the [ESC] key until the "Exit?" appears, and then click [Yes] to quit PCONSOLE.
- Start the print server by entering the following from the NetWare server's keyboard.

If it is running, restart after quitting.

To quit

CAREE: unload pserver

To start

CAREE: load pserver print_server_name

Note

- ☐ If the printer works as configured, "Waiting for job" appears.
- ☐ NetWare 3.x ends here.

NetWare 4.x, 5/5.1, 6

- 1 Log on to the file server as an administrator, or equivalent.
- 2 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [IPX/SPX].

A list of machines appears.

- In the list, select the printer for which you want to change configuration.
- On the [Tools] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

Click [Property Sheet], and then click [OK].

The [NIB Setup Tool - Network board list] dialog box appears.

- Click the [NetWare] tab, and then make the following settings:
 - In the [Logon Mode] area, select [File Server Mode] or [NDS Mode].

 - ☐ If **[File Server Mode]** is selected, a connecting destination will be chosen based on the string entered in step **3**.
 - ☐ If **[NDS Mode]** is selected, a connecting destination will be chosen based on the string entered in step **4**.

2 In the [Print Server Name:] box, enter the name of the print server.

#Important

☐ Use the same name as that of the print server name to be set from NWadmin (③-③).

Limitation

- ☐ Enter up to 47 alphanumeric characters.
- 3 In the [File Server Name:] box, enter the name of the file server in which a print server is to be created.

By clicking [Browse...], you can select a file server among those listed in the [Browse...] dialog box.

Limitation

- ☐ Enter up to 47 alphanumeric characters.
- 4 In the [NDS Tree:] box, enter the NDS tree name in which to make the file server.

By clicking [Browse...], you can select the NDS tree name and NDS context name from their lists.

? Limitation

- ☐ Enter up to 32 alphanumeric characters ("-" and "_" can be used).
- **6** In the [NDS Context:] box, enter the context in which the print server is to be created.

Limitation

- ☐ Enter up to 127 alphanumeric characters.
- 6 In the [Print Server Operation Mode] area, click [As Remote Printer].

In the [Remote Printer No.] box, enter the number of the printer.

∰Important

- ☐ Use the same number as that of the printer to be created in the print server (44-4).
- 8 Click [OK] to close the [NIB Setup Tool - Network board list] dialog box.
- **8** Quit SmartNetMonitor for Admin.
- 9 On Windows, start NWadmin.

For more information about NWadmin, see the operating instructions that come with the NetWare.

Treate a print queue as follows:

Ø Note

- ☐ If you are using a currently defined print queue, proceed to step ①.
- Select the container object the print queue is located in from those in the directory tree, and then click [Create] on the [Object] menu.
- 2 In the [Class of new object] box, click [Print Queue], and then click [OK].
- 3 In the [Print Queue name] box, enter the name of the print queue.
- In the [Print Queue Volume] box, click [Browse].
- 6 In the [Available objects] box, click the volume in which the print queue is created, and then click [OK].
- **6** After checking the settings, click [Create].

- **1** Create a printer as follows:
 - Select the container object where the printer is located, and then click [Create] on the [Object] menu.
 - 2 In the [Class of new object] box, click [Printer], and then click [OK]. If you are using NetWare 5/5.1, 6, click [Printer (Non NDPS)].
 - 3 In the [Printer name] box, enter the name of the printer.
 - 4 Select the [Define additional properties] check box, and then click [Create].
- Assign print queues to the created printer as follows:
 - Click [Assignments], and then click [Add] in the [Assignments] area.
 - 2 In the [Available objects] box, click the queue created in step [1], and then click [OK].
 - Click [Configuration], and in the [Printer type] list, click [Parallel], and then click [Communication].
 - 4 In the [Communication type] area, click [Manual load], and then click [OK].
 - **6** After checking the settings, click [OK].
- Create a print server as follows:
 - Select the context specified using NIB Setup Tool (Step 7-2), and on the [Object] menu, click [Create].
 - 2 In the [Class of new object] list, click [Print Server], and then click [OK].

If you are using NetWare 5/5.1, 6, click [Print Server (Non NDPS)].

3 In the [Print Server name] box, enter the name of the print server.

#Important

- ☐ Use the same name as that specified using NIB Setup Tool (step **1-2**).
- Select the [Define additional properties] check box, and then click [Create].
- Assign the printer to the created print server as follows:
 - Click [Assignments], and then click [Add] in the [Assignments] area.
 - 2 In the [Available objects] box, click the queue created in step [], and then click [OK].
 - 3 In the [Printers] box, click the printer assigned in step 2, and then click [Printer Number].
 - 4 Enter the printer number, and then click [OK].

∰Important

- □ Use the same number as that specified as Remote Printer No. using NIB Setup Tool (step 1-7).
- **6** After checking the settings, click [OK].
- Start the print server by entering the following from the NetWare server's keyboard.

If it is running, restart after quitting.

❖ To quit

CAREE: unload pserver

❖ To start

CAREE: load pserver print server name

Setting Up a Client Computer

This describes how to set up a client computer when using a NetWare print server.

Note

- ☐ Use the version of Novell Client provided with your operating system, or the latest version.
- ☐ This section assumes the client computer has NetWare client applications installed and is correctly configured to communicate with a NetWare print server. If it is not, install the necessary applications before starting the setting up procedure.

Windows 95/98/Me

Follow the procedure below to set up a Windows 95/98/Me client computer:

Preparation

Log on to the NetWare file server before starting the following procedure:

Install the printer driver you want to use as "local printer".

For more information about installing the printer driver, see *Printer Reference* 1.

Note

- ☐ Any port can be selected during installation. However, LPT1 is recommended.
- 2 On the [Start] menu, point to [Settings], and then click [Printers].

- In the [Printers] window, click the icon of the printer you want to use.
- On the [File] menu, click [Properties].
- Click the [Details] tab, and then click [Add Port].
- Click [Network], and then click [Browse].
- In the tree pane, double-click the name of the file server.

The queues are displayed.

- Select the queue you want to print, and then click [OK].
- **9** Click [**0**K].

In the [Print to the following port] box, a network path to the printer appears.

- Click [OK] to close the printer properties dialog box, and open it again.
- Click the [Printer Settings] tab.
- Clear the [Form feed] and [Enable banner] check boxes.

𝚱 Note

☐ You do not have to select these boxes because they should be specified in the printer driver. If they are selected, the printer might not print correctly.

When using the PostScript printer driver

Follow the procedure below to set the PostScript printer driver:

- Click the [PostScript] tab.
- 2 Click [Advanced].

- 3 Clear the [Send CTRL+D before job] and [Send CTRL+D after job] check boxes.
- Click [OK] to close the printer properties dialog box.

Windows 2000/XP, Windows Server 2003, Windows NT 4.0

Follow the procedure below to set up a Windows 2000/XP, Windows Server 2003, Windows NT 4.0 client computer.

Preparation

Log on to the NetWare file server before starting the following procedure:

1 Double-click the My Network Places icon on the desktop, and then double-click.

The [Printers] dialog box appears.

- ☐ When using Windows NT 4.0, the Network Neighborhood icon appears on the desktop instead of the My Network Places icon.
- **2** Click [Yes], and then click [OK]. Add Printer Wizard starts.
- Insert the CD-ROM labeled "Printer Drivers and Utilities" into the CD-ROM drive, and then click [Have Disk].

If the setup menu starts automatically, you can proceed to the next step. If not, see *Printer Reference* 1.

4 Follow the instructions on screen to complete installation of the printer driver.

The machine operates using NDPS. Operating requirements are as follows:

• NetWare Version: 5/5.1, 6

Printer Drivers and Operating Systems

| Printer driver | Operating system |
|----------------|-------------------------|
| PCL | Windows 95/98/Me |
| | Windows 2000 |
| | Windows XP Professional |
| | Windows Server 2003 |
| | Windows NT 4.0 |
| PostScript 3 | Windows 95/98/Me |
| | Windows 2000 |
| | Windows XP Professional |
| | Windows Server 2003 |
| | Windows NT 4.0 |

To use the machine with NDPS, NDPS Gateway is required.

- Novell NDPS Gateway
 For more information about using Novell NDPS Gateway, see the manual provided with it.
- Custom NDPS Gateway
 For more information about using
 Custom NDPS Gateway, consult
 your authorized retailer.



This machine does not support iPrint.

6. Using SmartNetMonitor for Client

SmartNetMonitor for Client

SmartNetMonitor for Client is equipped with the following functions. We recommend all users of this printer to install this software.

Protocol Stack

| Operating system | Protocol stack |
|-------------------------------|---|
| Microsoft Windows 95/98/Me | TCP/IP provided with Windows 95/98/Me |
| | IPX/SPX provided with Windows 95/98/Me |
| | NetBEUI provided with Windows 95/98/Me |
| | NetWare network client provided with Windows 95/98/Me |
| | Novell Client for Windows 95/98/Me |
| Microsoft Windows 2000 | TCP/IP provided with Windows 2000 |
| | IPX/SPX provided with Windows 2000 |
| | NetBEUI provided with Windows 2000 |
| | NetWare Client provided with Windows 2000 |
| | Novell Client for Windows NT/2000/XP |
| Microsoft Windows XP | TCP/IP provided with Windows XP |
| | IPX/SPX provided with Windows XP |
| | NetWare Client provided with Windows XP |
| | Novell Client for Windows NT/2000/XP |
| Microsoft Windows Server 2003 | TCP/IP provided with Windows Server 2003 |
| | IPX/SPX provided with Windows Server 2003 |
| Microsoft Windows NT 4.0 | TCP/IP provided with Windows NT 4.0 |
| | IPX/SPX provided with Windows NT 4.0 |
| | NetBEUI provided with Windows NT 4.0 |
| | Client Service for NetWare provided with Windows NT |
| | Novell Client for Windows NT/2000/XP |

What can it do?

- Peer-to-Peer print function
 - Prints directly on the network printer without a print server.
 - Prints on a substitute printer if too many jobs accumulate in the specified printer, or an error disables printing (Recovery Printing).
 - Allocates multiple printings to multiple printers (Parallel Printing).
 - Prior group registration of printers specified for Recovery Printing /Parallel Printing.

Notification function

- An error message appears if there is an error on the specified printer during transfer or printing of data.
- A window opens to notify you of print completion. You can also select to be notified of the print condition, such as displaying the notice only when Recovery Printing is executed.
- You can have a completion notice appear after printing, document storage, and LAN-Fax transmission.
- An error message can be displayed if an error occurs during printing or transmission of a print job.
- Monitoring function
 - Checks the equipment to give you information about printing, paper levels, etc., via your computer.
 - Simultaneously monitors multiple printers in use.
 - Checks the printer's network settings and detailed information of devices.
 - Enables you to check the print job log using the user ID.
- Reports print completion and document storage using the printer function, and print completion, document storage and transmission by the LAN-Fax function.
- Up to 100 print jobs can be displayed.

Limitation

- ☐ Make the same settings for the option configuration of the printer for Recovery/Parallel Printing and the printer for giving print commands. If the options necessary for printing, such as the paper feed unit, are not installed on the substitute printer, that function is disabled.
- □ Load paper of the same size on both the printer for Recovery/Parallel Printing and the printer for giving print commands. When specifying a particular paper tray for printing, load paper of the same size into that tray.
- ☐ If the type and devices of the printer for Recovery/Parallel Printing and the printer for giving commands are different, print results might not be identical.
- ☐ If you select Sample Print or Locked Print, you cannot execute Recovery/Parallel Printing.

For more information about using Recovery Printing/Parallel Printing, see SmartNetMonitor for Client Help.

Setting the Network Monitoring Function

To view the status of machines using SmartNetMonitor for Client, you must configure SmartNetMonitor for Client in advance, so that it monitors the machine whose status you want to view.

1 Start SmartNetMonitor for Client.

The SmartNetMonitor for Client icon appears at the right end of the taskbar.

2 Right-click the SmartNetMonitor for Client icon, and check the desired machine is on the shortcut menu that appears.

For details about the machine status icon, see SmartNetMonitor for Client Help.

If the desired machine does not appear, click [Options...] on the shortcut menu.

The [SmartNetMonitor for Client - Options] dialog box appears.

- Select the machine to be monitored, and select the [To be Monitored] check box in the [Monitoring Information Settings] area.
 - Note
 - ☐ Selecting the **[Displayed on Task Bar]** check box will bring up the status of a machine on the SmartNetMonitor for Client icon on the taskbar.
- Click [OK].

The dialog box closes and the selected machine is monitored.

Displaying the Status of Machines

Follow the procedure below to monitor machine status using SmartNetMonitor for Client.

- **1** Start SmartNetMonitor for Client.
- The status of machines is displayed on the SmartNetMonitor for Client icon on the taskbar.
 - Note
 - ☐ For more information about status icons, see SmartNetMonitor for Client Help.

3 For further information on status, right-click the SmartNetMonitor for Client icon, and then select the desired machine.

The status of the machine is displayed in the dialog box.



☐ For more information about each item in the dialog box, see SmartNet-Monitor for Client Help.

7. Using SmartNetMonitor for Admin

SmartNetMonitor for Admin

Using SmartNetMonitor for Admin, not only can you monitor the status of network printers, but you can also change the configuration of the network interface board using TCP/IP or IPX/SPX protocol.

❖ Protocol Stack

| Operating system | Protocol stack |
|-------------------------------|---|
| Microsoft Windows 95/98/Me | TCP/IP provided with Windows 95/98/Me |
| | IPX *1 /SPX provided with Windows 95/98/Me |
| | NetWare network client provided with Windows 95/98/Me |
| | Novell Client for Windows 95/98/Me |
| Microsoft Windows 2000 | TCP/IP provided with Windows 2000 |
| | IPX *1 /SPX provided with Windows 2000 |
| | NetWare Client provided with Windows 2000 |
| | Novell Client for Windows NT/2000/XP |
| Microsoft Windows XP | TCP/IP provided with Windows XP |
| | IPX *1 /SPX provided with Windows XP |
| | Novell Client for Windows NT/2000/XP |
| Microsoft Windows Server 2003 | TCP/IP provided with Windows Server 2003 |
| | IPX *1 /SPX provided with Windows Server 2003 |
| | NetWare Client provided with Windows Server 2003 |
| Microsoft Windows NT 4.0 | TCP/IP provided with Windows NT 4.0 |
| | IPX *1 /SPX provided with Windows NT 4.0 |
| | Client Service for NetWare provided with Windows NT |
| | Novell Client for Windows NT/2000/XP |

 $^{^{*1}}$ IPX is used for monitoring the machines.

What can it do?

- Limits settings done from the control panel, and disables changes made to certain items.
- Enables selection of paper type loaded in the machine.
- Switches to, and comes out of Energy Saver mode.
- Checks information about printing, paper quantity, etc.
- Simultaneously monitors multiple printers. When there are many printers, you can create groups and classify printers to facilitate management.
- Checks the machine's network settings and detailed device information.
- Enables you to change the machine's network settings.
- You can check details of print jobs sent from a computer.
- Allows you to check job histories of printed, faxed (LAN-Fax), scanned, and photocopied documents identified by user codes.
- Allows selection of functions such as printing and scanning for each user code.
- Fax numbers and e-mail addresses stored in the machine can be changed and saved by computer.
- You can check each fax job history entry.
- You can make settings for and display the status changes of group devices.
- Using Address Management Tool, you can manage LAN-Fax numbers, user names for Scan to Folder, and addresses for sending and receiving Internet faxes.
- The e-mail sender's name and folder can be protected.

₽ Reference

For more information about these settings, see SmartNetMonitor for Admin Help.

Limitation

- $\hfill \square$ TCP/IP is required for the following functions:
 - Using Tools
 - Locking the Control Panel Menu
 - Selecting the Paper Type
 - Managing User Information
 - Address Management Tool
 - Load Fax Journal
 - Viewing and Deleting Spool Print Jobs
 - Starting the Web browser using SmartNetMonitor for Admin

Changing the Network Interface Board Configuration

Limitation

- ☐ Internet Explorer 4.01 or a later version is required to use NIB Setup Tool.
- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

𝚱 Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- 4 On the [Tools] menu, click [NIB Setup Tool].

NIB Setup Tool starts.

Click [Property Sheet], and then click [OK].

Network Board Selection Wizard starts.

6 Follow the instructions on the screen.

☐ For more information about changing machine names, comments, and other items, see NIB Setup Tool Help.

Displaying Machine Status

Follow the procedure below view the status of machines using SmartNet-Monitor for Admin.

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

The status of machines is indicated by an icon in the list.

Note

- ☐ For more information about status icons, see SmartNetMonitor for Admin Help.
- For further information, select the desired machine in the list, and then click [Open] on the [Device] menu.

The status of the machine is displayed in the dialog box.

Ø Note

☐ For more information about each item in the dialog box, see SmartNetMonitor for Admin Help.

Locking the Control Panel Menu

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- 4 On the [Tools] menu, point to [Device Settings], and then click [Lock Operation Panel Menu].

The dialog box for entering the password appears.

Enter your user name and password, and then click [OK].

Ø Note

☐ To use the factory default account, enter no user name and enter "password" for the password.

Check the device status on the Device Settings of the Web browser, and change the device settings.

For more information about viewing status information and changing settings using a Web browser, see Device Settings Help.

Selecting the Paper Type

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- On the [Tools] menu, point to [Device Settings], and then click [Select Paper Type].

The dialog box for entering the password appears.

Enter your user name and password, and then click [OK].

Note

☐ To use the factory default account, enter no user name and enter "password" for the password.

Check the device status on the Device Settings of the Web browser, and change the device settings.

For more information about viewing status information and changing settings using a Web browser, see Device Settings Help.

Managing User Information

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- On the [Tools] menu, click [User Management Tool].

The dialog box for entering the password appears.

Enter the password, and then click [OK].

Note

☐ The factory default password is "password".

User Management Tool starts.

For more information about using User Management Tool, see User Management Tool Help.

Load Fax Journal

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- On the [Tools] menu, click [Load Fax Journal].
- **5** Check the Load Fax Journal area that appears in the Web browser.

For details, see Help in Load Fax Journal area.

Viewing and Deleting Spool Print Jobs

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select a machine whose numerical values you want to manage.
- 4 On the [Tools] menu, click [Spool Printing Job List (Printer)].
- Enter your user name and password, and then click [OK].

Note

☐ To use the factory default account, enter no user name and enter "password" for the password.

Check Spool Printing Job List on the Web browser, and print out.

₽ Reference

For more information about Spool Printing Job List, see Spool Printing Job List Help.

Note

☐ To display Spool Printing Job List, spool must be set to **[Enable]** on Device Settings in advance.

Managing Address Information

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

Note

- ☐ Select the protocol of the machine for which you want to change configuration.
- In the list, select the machine for which you want to change configuration.
- 4 On the [Tools] menu, click [Address Management Tool].

The dialog box for entering the password appears.

Enter the password, and then click [OK].

Note

☐ The factory default password is "password".

Address Management Tool starts.

For more information about Address Management Tool, see Address Management Tool Help.

Configuring Energy Saver Mode

- 1 Start SmartNetMonitor for Admin.
- On the [Group] menu, point to [Search Device], and then click [TCP/IP] or [IPX/SPX].

A list of machines appears.

On the [Group] menu, point to [Energy Saver Mode].

For more information about settings, see SmartNetMonitor for Admin Help.

𝚱 Note

- ☐ Point to **[Set by Group]** if you want to change all devices in the area.
- ☐ Point to **[Set Individually]** if you want to change only selected devices.
- ☐ In both cases, select the Energy Saver mode on the displayed menu.
- ☐ When you point to [Set Individually], [Timer Settings] is not displayed.

8. Configuring the Network Interface Board Using a Web Browser

You can check the status of a machine and change its settings using the Web browser.

♦ What can it do?

You can remotely check the status of a machine or specify its settings over the network using a computer's Web browser.

The following functions are available with Web browser:

- Displaying machine status/settings
- Checking print job status/history
- Checking, modifying, printing, or deleting print jobs stored in the Document Server
- Managing the Address Book
- Making machine settings

Configuring the machine

This requires TCP/IP to be installed. After the machine has been configured to use TCP/IP, it will be possible to adjust settings using a Web browser.

For more information about configuring the machine to use TCP/IP, see p.19 "Setting Up the Machine on a Network".

Browser

- Windows
 - Microsoft Internet Explorer 5.5 or later
 - Netscape Navigator 6.2 or later
- Mac OS
 - Netscape Navigator 6.2 or later

Limitation

- ☐ If the Web browser in use is older than the recommended version or [Java-Script] and [Cookie] are not available, display and operation problems may occur.
- ☐ If you are using a proxy server, change the Web browser settings. Consult your network administrator about the settings.
- ☐ Sometimes after clicking [Back], the previous page may not appear. In this case, click [Refresh] or [Reload].
- ☐ This machine information cannot refresh automatically. Click [Reload] or [Refresh] on the Web browser, or click [Refresh] on the work area when you want to refresh.

In the **[Address]** box, enter the address (for example http://XXX.XXX,XXX, where the Xs are the numbers of the IP address). If the host name of the machine is registered on the DNS server, you can enter it.

Going to the Top Page



1. Header area

You can register favorite URLs using **[URL]**. To view the Help section, click **[Help]**.

2. Menu area

These buttons are for configuring the network interface board and checking machine status.

3. Status

Displays machine status, network interface board name, and comments.

4. Help

8

Types of Menu Configuration and Mode

Items that appear on the menu area differ between user mode and administrator mode.

The work area which appears under the selected menu displays machine status under user mode and machine setting under administrator mode.

𝒯 Note

- ☐ Indicates machine status can be displayed.
- ☐ Indicates machine settings can be changed.

| Menu | | User mode | Administra- tor mode | |
|-------------------|---------------|----------------|-------------------------|---|
| Status | Input Tray | | 0 | 0 |
| | Output Tray | | 0 | О |
| | Toner | | 0 | О |
| | Function | | 0 | О |
| | System | | 0 | О |
| | Printer Langu | age | 0 | О |
| Document Server | | • | • | |
| Fax Received File | | • | • | |
| Job | Printer | Spool Printing | 0 | О |
| | | History | 0 | О |
| | Fax History | Transmission | 0 | О |
| | | Reception | 0 | О |
| | | LAN-Fax | 0 | О |
| Document Server | | 0 | О | |
| Address Book | | - | • | |

| Menu | | User mode | Administra- tor mode | | |
|------------|---------------|------------|-------------------------|---|---|
| Configura- | Device Setti | ngs | | - | • |
| tion | E-mail | | | 0 | • |
| | File Transfer | • | | - | • |
| | Network | Interface | | 0 | • |
| | | Protocol | Protocol | 0 | • |
| | | | TCP/IP | 0 | • |
| | | | NetWare | 0 | • |
| | | | AppleTalk | 0 | • |
| | | | SMB | 0 | • |
| | | | SNMP | - | • |
| | | System Log | System Log | | О |
| | Webpage | I. | | | • |
| | Security | Password | Password | | • |
| | Acce | | trol | - | • |
| | | IPP Authen | tication | - | • |

Limitation

☐ Documents stored under the copier and printer functions cannot be downloaded.

𝒯 Note

☐ Check print results of Document Server jobs in [Status] in [Document Server Job History].

For more information about displaying status and changing settings, see p.95 "Using Help on the Web Browser".

Verifying the Network Interface Board Settings

- **1** Start the Web browser.
- In the [Address] box, enter the address (for example http://XXX.XXX,XXX,XXX, where the Xs are the numbers of the IP address).

The status of the machine you chose appears on the Web browser.

In the menu area, click the selected menu.

If a sub-menu appears, click it.

For more information about each item, see p.95 "Using Help on the Web Browser".

Configuring the Network Interface Board Settings

- 1 Start the Web browser.
- In the [Address] box, enter the address (for example http://XXX.XXX,XXX,XXX, where the Xs are the numbers of the IP address).

The status of the machine you chose appears on the Web browser.

Click [Administrator Mode].

The dialog box for entering the password and user name appears.

4 Enter your user name and password, and then click [OK].

To use the factory default account, enter no user name and enter "password" for the password.

- In the menu area, click the selected item, and then make the necessary settings.
- 6 Click [Apply].

The configuration is transmitted.

For more information about making settings, see p.95 "Using Help on the Web Browser".

Я

Using Help on the Web Browser

When using Help for the first time, clicking either [Help] in the header area or the icon marked "?" in the work area makes the following screen appear. From there you can check Help in two different ways, as shown below:

- Checking a Help Using the Internet You can check the latest Help updates.
- ♦ Downloading and Checking Help
 You can download Help to your
 computer's hard drive and view it.
 As the Help URL, you can specify
 the path to the local file to view the
 Help without connecting to the Internet.

𝚱 Note

- ☐ By clicking **[Help]** in the header area, Help contents normally appear.
- ☐ By clicking "?", the Help icon in the work area, Help for the items shown in the work area normally appears.

Downloading Help

- In the [OS] list, select the operating system.
- In the [Language] list, select the language.
- Click [Download].
- Download Help by following the messages on screen.

5 Save the downloaded compressed file, and then decompress it.

Note

☐ To check the downloaded Help, specify the path where the file is decompressed.

Linking the address (URL) to the [Help] button

You can link the address (URL) of the **[Help]** button to the Help files on the computer or Web server.

- ① Download the Help files on the computer to the desired location.
- ② Using a Web browser, navigate to Top Page and click [Administrator Mode].
- ③ Enter your password, (it is not necessary to enter a user name) and click [OK].
- 4 Click [Configuration], and then click [Webpage].
- ⑤ In the [Help URL] box, enter the path to the Help files.
 If you copied the Help files to "C:\HELP\EN", enter "file://C:/HELP/". For example, if you copied the files to a Web server and the index URL is "http://a.b.c.d/HELP/EN/index.html", enter "http://a.b.c.d/HELP/".
- 6 Click [Apply].

9. Appendix

Remote Maintenance by telnet

You can view printer status and configure the network interface board using telnet.

Note

- ☐ You should specify a password so only the network administrator, or a person with network administrator privileges, can use remote maintenance.
- ☐ The password is the same as that used for configuring the network interface board with a Web browser.
- ☐ If you change a password using remote maintenance, the other passwords are also changed.

Using telnet

Follow the procedure below to use telnet.

Limitation

- ☐ Only one person at a time can be logged on to do remote maintenance.
- **1** Using the machine's IP address or host name, start telnet.
 - % telnet IP_address
 - Ø Note
 - ☐ In order to use the host name instead of the IP address, you must write it to the hosts file.
- **2** Enter the password.
 - **∅** Note
 - \square The default is "password".

Enter a command.

For more information about telnet commands, see p.98 "Commands List".

4 Quit telnet.

msh> logout

When the configuration changes, a message asks whether the changes should be saved or not.

Enter "yes" to save the changes, and then press the [ENTER] key.

If you do not want to save the changes, enter "no", and then press the **[ENTER]** key. If you want to make additional changes, enter "return", and then press the **[ENTER]** key.

Note

- ☐ If "Cannot write NVRAM information" appears, the changes are not saved. Repeat the steps above, as necessary.
- ☐ The network interface board is automatically reset when the changes are saved.
- ☐ When the network interface board is reset, active print jobs already sent to the machine will be finished. However, jobs not already sent will be canceled.

9

Commands List

Use the "help" command to display remote maintenance use.

Note

☐ Enter "help" to display a list of commands that can be used.

msh> help

☐ Enter "help command_name" to display information about the syntax of that command.

msh> help command name

TCP/IP address

Use the "ifconfig" command to configure the Ethernet interface, the IEEE 1394 interface/IEEE 802.11b, and the TCP/IP (IP address, subnet mask, broadcast address, default gateway address) for the machine.

❖ Reference msh> ifconfig

Configuration

msh> ifconfig interface_name
parameter address

| Interface name | Interface to be configured |
|----------------|----------------------------|
| ether | Ethernet interface *1 |
| ip1394 *2 | IEEE 1394 interface |
| wlan *3 | IEEE 802.11b interface |

^{*1} If you did not enter an interface name, it will automatically be set to the Ethernet interface.

*2 Available when the optional IEEE 1394 interface board is installed.

*3 You can specify an interface when installing the optional IEEE 802.11b interface unit.

| Parameter | Meaning |
|----------------|-------------------|
| (no parameter) | IP address |
| netmask | subnet mask |
| broadcast | broadcast address |

Changing the Interface

You can specify either Ethernet interface or IEEE 802.11b interface when using the optional IEEE 802.11b interface unit.

msh> ifconfig interface up

Ø Note

☐ You cannot specify the optional IEEE 1394 interface board (ip1394).

The following is a sample configuration, using an IP address of 192.168.15.16 on an Ethernet interface:

msh> ifconfig ether 192.168.15.16

The following is a sample configuration, using a subnet mask of 255.255.255.0 on an Ethernet interface:

msh> ifconfig ether netmask 255.255.255.0

Note

- ☐ This affects the configuration of the network interface board on the IP address used.
- ☐ The TCP/IP setting is the same as that of the Ethernet interface and IEEE 802.11b interface.
- \square To enter an address using hexadecimal, prefix it with "0x".

Address

Sub-net Mask

A number used to numerically "mask" or hide the IP address on the network by eliminating those parts of the address that are alike for all machines on the network.

Broadcast address

A specified address for sending data to specific devices on the network.

Note

- ☐ To get the above addresses, contact your network administrator.
- ☐ If you do not know the address to configure, use the machine's default.
- ☐ The Ethernet interface and IEEE 802.11b interface share the same TCP/IP address. When changing interfaces, the former interface setting is applied to the new interface.
- ☐ When installing the optional IEEE 1394 interface board, set the subnet so it does not overlap with the Ethernet interface or the IEEE 1394 interface.

Access control

Use the "access" command to view and configure access control. You can also specify two or more access ranges.

Reference

msh> access

Configuration

msh> access ☆ range startaddress end-address

 * represents a target number between 1 and 5. (Up to five access ranges can be registered and selected.)

Example: To specify accessible IP addresses between 192.168.0.10 and 192.168.0.20:

msh> access 1 range 192.168.0.10 192.168.0.20

Ø Note

- ☐ The access range restricts the workstations from which printing is possible by means of an address. If you do not need to restrict printing, make the setting "0.0.0.0".
- ☐ The entry is invalid if the start address is greater than the end address.
- ☐ Up to five access ranges can be specified. The entry is invalid if the target number is omitted.
- ☐ Sessions other than those from a Web browser *1 or telnet are limited by access control.
 - *1 This does not include viewing and file management with the Document Server.

♦ Access control initialization msh> access flush

Note

☐ This restores the factory default so all access ranges become "0.0.0.0".

9

DHCP

Use the "dhcp" command to configure the DHCP settings.

Reference

The following command displays the current DHCP settings.

msh> dhcp

Configuration

You can configure the DHCP settings.

msh> dhcp interface_name
[on|off]



☐ Select **[on]** to enable DHCP. Select **[off]** to disable DHCP.

Interface Priority Configuration

You can assign priorities governing which interface obtains DHCP parameters.

msh> dchp priority
interface_name



- Priority assignment is useful when connecting more than one interface to the machine.
- ☐ If an interface is not selected, it appears according to the currently set priority regardless of multiple interface connections.

| Interface name | Interface to be configured | |
|----------------|----------------------------|--|
| ether | Ethernet interface | |
| wlan *1 | IEEE 802.11b interface | |
| ip1394 *2 | IEEE 1394 interface | |

*1 Available when the optional IEEE 802.11b interface unit is installed.

*2 Available when the optional IEEE 1394 interface board is installed.

For more information about DH-CP, see p.114 "Using DHCP".

Protocol

Use the "set" command to

allow or prevent remote access for each protocol.

msh> set protocol {up | down}

| Protocol | |
|--------------|------------------------|
| tcpip | "up" means active and |
| appletalk | "down" means inactive. |
| netware | |
| smb | |
| scsiprint *1 | |
| ip1394 *1 | |
| lpr | |
| ftp | |
| rsh | |
| diprint | |
| web | |
| snmp | |
| ipp | |
| http | |

^{*1} Available when the optional IEEE 1394 interface board is installed.

Note

- ☐ If you prohibit remote access via TCP/IP and then log out, you cannot use remote access. If you did this by mistake, you can use the control panel to allow access by TCP/IP.
- ☐ When you prevent access via TCP/IP, you are also prevented from using ip1394, lpr, ftp, rsh, diprint, web, snmp, ipp, and http.

Display

The following command displays current tcpip, appletalk, netware, and smb settings.

msh> set protocol

Printer status

The following command can be used to get information about the current printer status:

msh> command

| Command | Information that is displayed |
|-------------|---|
| status | Status of printer. |
| | Information about print jobs. |
| info | Information about the paper tray, output tray, printer language of printer. |
| prnlog [ID] | Lists the last 50 print jobs. |

Note

☐ For more information about print jobs is displayed when the ID number is added after the prnlog command.

For more information about the meaning of the data returned using these commands, see p.120 "Understanding Displayed Information".

Network interface board configuration settings information

Use the "show" command to display the network interface board configuration settings.

msh> show [-p]

☐ Add "-p" (as above) to have the information displayed one screen at a time.

For more information about the meaning of the data returned using this command, see p.125 "Configuring the Network Interface Board".

System log information

Use the "syslog" command to display information stored in the system log.

msh> syslog

For more information about the displayed information, see p.130 "System Log Information".

SNMP

Use the "snmp" command to display and edit SNMP configuration settings such as the community name.

Limitation

☐ The optional IEEE 1394 interface board supports TCP/IP only.

Note

- ☐ You can configure one of ten SNMP access settings numbered 1-10.
- ☐ If you change the community name, you must change your computer settings. See p.116 "SNMP".
- ☐ Default access settings 1 and 2 are as follows:

| Number | 1 | 2 |
|----------------|-----------------------|------------------------|
| Community name | public | admin |
| IP address | 0.0.0.0 | 0.0.0.0 |
| Access type | read-only trap off | read-write trap off |

Display

Shows SNMP information and available protocols.

msh> snmp ?

The following command displays the settings of registered number specified.

msh> snmp [registered_number] Omitting the number displays all access settings.

msh> snmp [-p]



☐ Add "-p" (as above) to have the information displayed one screen at a time.

Community name configuration

You can set the community name of the registered number.

msh> snmp number name
community name



☐ The community name can consist of up to 15 characters.

Access type configuration

You can select the access type from those listed below:

msh> snmp number type
access_type

| Access type | Type of access permitted |
|----------------|---------------------------------|
| read | Read only |
| write | Read and write |
| trap | User notified of trap messages. |
| no | All access denied. |

Protocol configuration

You should use the following command to set protocols to active or inactive. If you set a protocol to inactive, all access settings for that protocol will be disabled:

$$msh> snmp \{ip \mid ipx\} \ \{on \mid off\}$$

 "on" means active, "off" means inactive.

To change an access setting protocol, use the following command. However, if you have disabled a protocol using the above command, making it active here will have no effect.

msh> snmp number active
{ip | ipx} {on | off}

Access configuration

You can configure a host address according to protocols used.

The network interface board accepts requests only from hosts with "read-only" or "read-write" access type addresses. Enter "0" to have the network interface board accept requests from any host without requiring a specific type of access.

msh> snmp number {ip | ipx}
address



- ☐ To specify TCP/IP protocol, enter "ip" followed by a space, and then the IP address.
- ☐ To specify the IPX/SPX protocol, enter "ipx" followed by a space, and then the IPX address followed by a decimal, and then the MAC address of the network interface board.

The following is a sample configuration using the registration number 3 with the IP address 192.168.15.16:

msh> snmp 3 ip 192.168.15.16

The following is a sample configuration using the registration number 3 with the IPX address 7390A448, and the MAC address 00:00:74:62:5C:65:

msh> snmp 3 ipx 7390A448:0000

IPP

Use the "ipp" command to configure IPP settings.

Viewing setting

The following command displays the current IPP setting:

msh> ipp
Example output:

timeout=900(sec) auth off

- The "timeout" setting specifies how many seconds the computer keeps trying to access the network printer to send print jobs if no connection can be made.
- The "auth" setting indicates the user authorization mode.

IPP timeout configuration

Specify how many seconds to wait before canceling a print job if it has been interrupted for some reason. The time can be from 30 to 65535 seconds.

msh> ipp timeout {30 - 65535}

IPP user authorization configuration

Use IPP user authorization to restrict printing with IPP to certain users. The default is "off".

msh> ipp auth
{basic|digest|off}

- "basic" and "digest" are user authorization settings.
- "off" removes the user authorization.

Ø Note

☐ If you select "basic" or "digest", see next section "Configuring IPP user authorization" for how to configure the user name. Up to ten user names are available.

Configuring IPP user authorization

Use the following command:

msh> ipp user
The following message appears:

Input user number (1 to 10): Enter the number, user name, and password.

IPP user name:user1 IPP
password:******

After configuring, the following message appears:

IPP configuration changed.

_

Direct printing port

The direct printing port allows printing directly from a computer, connected to the network, to the printer.

Use the "diprint" command to change direct printing port settings.

View settings

The following command displays the current direct printing port settings:

msh> diprint Example output:

port 9100 timeout=300(sec)
bidirect off

- "Port" specifies the port number of the direct printing port.
- The "bidirect" setting indicates whether the direct printing port is bidirectional or not.

Setting timeout

You can specify the timeout interval in use when receiving data from the network.

msh> diprint timeout
[30~65535]



☐ The default is 300 seconds.

Bidirectional configuration for the direct printing port

Use this setting to configure whether the direct printing port is bidirectional or not. The default is "off".

msh> diprint bidirect
{on | off}



☐ If you select **[on]**, SmartNet-Monitor for Client or Standard TCP/IP on Windows 2000 might not work correctly.

Netware

Use the "netware "command to configure the NetWare settings such as the print server name or file server name.

msh> netware parameter

| Parameter | Settings |
|--|---|
| | _ |
| pname | Enter the NetWare print server name using up to 47 characters. |
| fname | Enter the NetWare file server name using up to 47 characters. |
| encap [802.3/802.2 /snap/ ethernet2/ auto] | Select the encap type. |
| rnum | Specify the remote printer number. |
| timeout | Set the timeout. |
| mode pserver mode ps | Select the print server mode. |
| mode rprinter mode rp | Select the remote printer mode. |
| context | Specify the NDS context name. |
| sap_interva l | Specify the SAP intervals. Each interval can be set to between 0 and 3600 seconds in one-second increments. |
| login server | Specify "login with a selected file server" as the login mode. |
| login tree | Specify "login with a selected NDS tree" as the login mode. |
| tree NDS tree name | Select the NDS tree to log on to. |

SMB

Use the "smb" command to configure or delete the NetBEUI settings such as the computer name or workgroup name.

msh> smb parameter

| Parameter | Settings |
|--------------------|--|
| comp | Your computer name consisting of up to 15 characters |
| group | Workgroup name consisting of up to 15 characters |
| comment | Comment consisting of up to 31 characters |
| notif {on off} | To notify print job completion, specify "on". Otherwise, specify "off" |
| clear comp | Clears the computer name |
| clear group | Clears the Workgroup name |
| clear com- ment | Clears comment |

𝚱 Note

☐ You cannot use a computer name starting with "RNP" or "rnp".

web

Use the "web" command to display and configure the parameters on the Web browser.

View Settings

msh> web

URL Configuration

The link address reached by pressing **[URL]** on the Web browser can be set.

web url The URL or IP address you want to register. Example:

(Xs represent the IP address.)

msh> web url http://
XXX.XXX.XXX.XXX/

Link Name Configuration

You can enter the name for **[URL]** that appears on the Web browser.

msh> web name Name you want to display

Example:

(Xs represent the name you want to display.)

msh> web name XXX

Help URL Configuration

The link address reached by pressing [Help] or "?" on the Web browser can be set.

msh> web help Help URL or IP address

Example:

(Xs represent the IP address.)

msh> web url http://
XXX.XXX.XXX.XXX/help/

ROUTE

Use the "route" command to control the routing table.

This command allows you to configure and display routing information. You can change the network configuration from remote computers using this command.

☐ The maximum number of routing tables is 16.

| Commands | Topics of setting |
|--|--|
| route add {host net} destination *1 gateway *1 | Adds a host/network route to "destination", and a gateway address to "gateway" in the table. Host becomes the default. |
| route de- lete {host net} desti- nation *1 | Deletes a host/network route from the table. Host becomes the default. |

| | ı | ۹ |
|----|---|----|
| r | 4 | 'n |
| ĸ. | ų | v |
| | 6 | d |

| Commands | Topics of setting |
|--|--|
| route get {destination *1} | Displays only route information corresponding to a specified destination. When the destination is unspecified, all routing information is displayed. |
| route active {host net} destination on/off | You can turn the specified destination on or off. Host becomes the default. |
| route add default gateway *1 | You can set the default gateway address. |
| route flush | Deletes all routing information. |

^{*1} IP address

SLP

Use the "slp" command to configure SLP settings.

You can search the NetWare server using SLP in the PureIP environment of NetWare5/5.1, 6. Use the "slp" command to configure the value of TTL used by the SLP multi-cast-packet.

𝚱 Note

- ☐ The default value of TTL is "1". A search is executed only within a local segment. If the router does not support multi-cast, the settings are not available even if the TTL value is increased.
- ☐ The acceptable TTL value is 1 255.

 msh> slp ttl {1 255}

SPRINT

Use the "sprint" command to view and configure SCSI print (SBP-2) on IEEE 1394.

Limitation

☐ You can use this function when the optional IEEE 1394 interface board is installed.

Viewing settings

The following command displays the current IEEE 1394 (SCSI print) settings:

msh> sprint

Bidirectional configuration for IEEE 1394 (SCSI print)

msh> sprint bidi {on | off}

Use this setting to select whether IEEE 1394 (SCSI print) is bidirectional or not. The default is "on".

Setting IEEE 802.11b

Use the "wiconfig" command to configure IEEE 802.11b settings.

Limitation

☐ You can make settings when installing the optional IEEE 802.11b interface unit.

View settings

The following command displays the current IEEE 802.11b settings.

msh> wiconfig

The following command displays the IEEE 802.11b card information.

msh> wiconfig cardinfo

☐ If the IEEE 802.11b interface is not working correctly, the optional IEEE 802.11b interface unit information is not displayed.

♦ Configuration

| Parameter | Value to be con- |
|---------------------------------------|--|
| | figured |
| mode [ap 802.11adhoc adhoc] | You can set infrastructure mode (ap), 802.11 ad hoc mode (802.11adhoc), or ad hoc mode (adhoc). The default is 802.11 ad hoc mode. |
| ssid ID value | You can set SSID in infrastructure mode. The characters that can be used are ASCII 0x20-0x7e (32 bytes). SSID value is set automatically to the nearest access point if the setting has not been made. If the setting has not been made for ad hoc mode, the same value as for infrastructure mode or an "ASSID" value is automatically set. |
| channel frequency channel no. | You can set the channel. You can specify from the following channels: • Metric Version: 1-13 • Inch Version: 1-11 Set the same channel for all the machines you are using. |

| Parameter | Value to be con- figured |
|--------------------|---|
| enc [on off] | You can enable or disable the WEP function. To enable the WEP function, select [on]; to disable it, select [off]. To start the WEP |
| | function, enter the correct WEP key. |
| key [key value] | 64-bit or 128-bit can be set. |
| | Only 10 hexadecimal characters can be set when using 64-bit; or 26 hexadecimal characters when using 128-bit. |
| | Also, set 0x as the prefix. To use this function, set the same WEP key for all ports that transmit to each other. |
| auth [open shared] | You can set the authorized mode when using WEP. The specified value and the authorized mode are as follows: |
| | open: Open system authorized (de- fault) |
| | shared: Shared key authorized |

| Parameter | Value to be con- figured |
|---------------------------------------|--|
| rate [auto 11m 5.5m 2m 1m] | You can set the IEEE 802.11b transmission speed. |
| | The transmission speed you specify here is the speed at which data is sent. You can receive data at any speed. |
| | auto: automatically set (default) 11m: 11 Mbps |
| | fixed 5.5m: 5.5 Mbps fixed |
| | 2m: 2 Mbps fixed 1m: 1 Mbps fixed |

Ø Note

- ☐ When changing the interface to IEEE 802.11b, see p.98 "TCP/IP address".
- ☐ When configuring the IEEE 802.11b TCP/IP, see p.98 "TCP/IP address".

Job Spool

Use the "spoolsw" command to configure Job Spool settings.

Limitation

☐ You can only specify LPR, IPP, and SMB protocol.

𝚱 Note

☐ This information cannot reload automatically when you confirm Job Spool settings with the Web browser. Click [Reload] or [Refresh] on the Web browser when you want to reload this information.

Reference

The Job Spool setting appears. msh> spoolsw

Job Spool setting

msh> spoolsw spool {on | off}

Note

☐ Select [on] to enable Job Spool or [off] to disable it.

Protocol configuration

To change protocol settings, use the following command. You can specify the setting for "lpr", "ipp" or "smb".

- lprmsh> spoolsw lpr {on | off}
- ipp msh> spoolsw ipp {on | off}
- smbmsh> spoolsw smb {on | off}

Changing the host name

Use the "hostname" command to change the printer name.

msh> hostname interface_name printer name

| Interface name | Interface to be configured |
|----------------|----------------------------|
| ether | Ethernet interface *1 |
| wlan *2 | IEEE 802.11b interface |
| ip1394 *3 | IEEE 1394 interface |

- *1 If you did not enter the interface name, it will be automatically set to the Ethernet interface.
- *2 Available when the optional IEEE 802.11b interface unit is installed.
- *3 Available when the optional IEEE 1394 interface board is installed.

Note

- ☐ Enter the printer name using up to 15 characters.
- ☐ You cannot use a printer name starting with "RNP" or "rnp".
- ☐ The Ethernet interface and IEEE 802.11b interface will have the same printer name.

WINS

Use the "wins" command to configure WINS server settings.

Viewing setting

The following command displays the WINS server IP address:

msh> wins

Example output:

msh> wins WINS Configuration:

interface name:

WINS: On

primary server 0.0.0.0 secondary server 0.0.0.0 ScopeID

Current configuration:
primary server 0.0.0.0
secondary server 0.0.0.0
hostname host_name
ScopeID

Ø Note

☐ If the IP address obtained from DHCP differs from the WINS IP address, the DHCP address is the valid address.

Configuration

Use the "set" command to make WINS active or inactive.

msh> wins interface_name
{on | off}

• "on" means active; "off" means inactive.

Setting WINS Server Address

You can make settings for the WINS server address.

msh> wins interface_name
{primary|secondary}
IP address

- "primary" is for setting the primary WINS server address.
- "secondary" is for setting the secondary WINS server address.

NBT scope ID setting

You can configure the NBT scope ID.

Limitation

☐ Enter a scope ID using up to 31 alphanumeric characters.

msh> wins interface name
scope scope ID

☐ If you receive different scope IDs from DHCP and WINS, the scope ID from DHCP takes priority.

| Interface name | Interface to be configured |
|-------------------|----------------------------|
| ether | Ethernet interface |
| wlan *1 | IEEE 802.11b interface |
| ip1394 *2 | IEEE 1394 interface |

- Available when the optional IEEE 802.11b interface unit is installed.
- *2 Available when the optional IEEE 1394 interface board is installed.

AutoNet

Use the "autonet" command to configure AutoNet settings.

Display

The following command displays the current AutoNet settings.

msh> autonet

Configuration

You can configure the AutoNet settings.

msh> autonet [on off]

Note

- ☐ Select **[on]** to enable AutoNet.
- ☐ Select [off] to disable AutoNet.

Interface Priority Configuration

You can assign priorities governing which interface obtains AutoNet parameters.

msh> autonet priority
interface_name



- ☐ Priority assignment is useful when connecting more than one interface to the machine.
- ☐ If an interface is not selected, the interface appears according to the currently set priority, regardless of multiple interface connections.

| Interface name | Interface to be configured |
|-------------------|----------------------------|
| ether | Ethernet interface |
| wlan *1 | IEEE 802.11b interface |
| ip1394 *2 | IEEE 1394 interface |

^{*1} Available when the optional IEEE 802.11b interface unit is installed.

For more information about AutoNet, see p.115 "Using AutoNet".

Changing the password

Use the "passwd" command to change the remote maintenance password.

∰Important

☐ Be sure not to forget or lose the password.

Note

- ☐ The default password is "password".
- 1 Enter "passwd".

 msh> passwd
- 2 Enter the current password.
 Old password:
- **3** Enter the new password.

New password:

Note

- ☐ The password must consist of three to eight alphanumeric characters and symbols. Passwords are case-sensitive. For example, "R" is different from "r".
- ☐ The password is the same as that used in configuring the network interface board with a Web browser and that used in NIB Setup Tool. If you change a password from telnet, the other passwords are also changed.
- 4 Enter the new password again.
 Retype new password:

^{*2} Available when the optional IEEE 1394 interface board is installed.

DNS

Use the "dns" command to configure or display DNS (Domain Name System) settings.

View setting

The following command displays current DNS settings:

msh> dns

Using the DNS server obtained from the DHCP server

The following command enables/disables use the DNS server obtained from the DHCP server:

msh> dns dhcp {valid invalid}

• If you use the DNS server obtained from the DHCP server, select "valid". If not, select "invalid".

If you set "valid", the DNS server from the DHCP server is prioritized.

DNS server configuration

The following command enables/disables use of the DNS server address:

msh> dns number server server address

The following is a sample configuration using an IP address of 192.168.15.16 on DNS 1 server:

msh> dns 1 server 192.168.15.16

- You can register up to three DNS server numbers.
- You cannot use "255.255.255.255" as the DNS server address.

Domain name

Use the "domainname" command to display or configure domain name settings.

You can configure the Ethernet interface, IEEE 1394 interface, or IEEE 802.11b interface.

View setting

The following command displays the current domain name:

msh> domainname

Interface domain configuration

The following command displays or sets the Ethernet interface domain name, IEEE 1394 interface, or IEEE 802.11b interface.

msh > domainname interface_name domainname The following is a sample configuration using a domain name on the Ethernet interface:

msh> domainname ether

| Interface | Interface that can be set |
|-----------|---------------------------|
| ether | Ethernet interface |
| ip1394 *1 | IEEE 1394 interface |
| wlan *2 | IEEE 802.11b interface |

- *1 Available when the optional IEEE 1394 interface board is installed.
- *2 Available when the optional IEEE 802.11b interface unit is installed.

Note

☐ A domain name can consist of up to 63 alphanumeric characters.

Setting Protocols

The protocols described in this section provide various functions that can be used on the machine.

#Important

☐ If a protocol is disabled or inactive, functions provided by that protocol cannot be used.

For more information about setting protocols, consult your network administrator.

❖ TCP/IP

- Functions using ftp, lpr, rsh/rcp, diprint, http, ipp, web, wins, ip1394, snmp *1, or smb *2
 - *1 SNMP session using TCP/IP
 - *2 SMB session using TCP/IP

Note

You cannot switch between protocols, but turning off or disabling TCP/IP will also disable smtp and dns.

◆ AppleTalk

 Printer function using Apple-Talk under Mac OS

Note

☐ This can be configured when a module supporting PostScript 3 is installed in the machine.

NetWare

Printer function using NetWare server

Note

- ☐ In a PureIP environment, you can use only the print server even if this protocol has been turned off or disabled.
- ☐ Turning off or disabling Net-Ware will also disable the SNMP session using IPX/SPX.

❖ SMB

- Printer function using Smart-NetMonitor for Client
- Printer function using Microsoft Windows Network

SCSI print

 Printer function using the IEEE 1394 interface (SCSI print)

❖ IP1394

• Printer function using the IEEE 1394 interface (IP over 1394)

❖ LPR

- Printer function using standard TCP/IP
- Printer function using the command line

◆ FTP

- Printer function using the command line
- Scanner function using the delivery server
- Function to obtain device information using the command line

◆ RSH/RCP

- Printer function using the command line
- Scanner function using the Network TWAIN Driver
- Function to obtain device information using the command line

❖ DIPRINT

 Printer function using Smart-NetMonitor for Client

♦ WEB

• Web browser function

SNMP

- Bidirectional communication function using a printer driver
- Function to obtain device information using SmartNetMonitor for Client/Admin

♦ IPP

 Printer function using Smart-NetMonitor for Client

♦ HTTP

- Web browser function
- Printer function using Smart-NetMonitor for Client
- Function to obtain device information using SmartNetMonitor for Client/Admin

Note

☐ Disabling http will also disable ipp and web.

Using DHCP

You can use the printer in a DHCP environment. You can also register the printer NetBIOS name on a WINS server when it is running.

If you connect an Ethernet interface and IEEE 1394 (IP over 1394) interface simultaneously, pay attention to the following:

When a static IP address is set for both interfaces

- IP Address: If interface IP addresses overlap, the Ethernet interface is selected.
- Subnet Mask: If interface subnet masks overlap, the Ethernet interface is selected.
- Gateway Address: The selected value is applied.

Ø Note

- ☐ Make the gateway address setting inside the subnet set in the interface.
- ☐ If a value is beyond the range of the subnet selected by the interface, the machine operates using "0.0.0.0".

When obtaining addresses from the DHCP server

 IP Address, Subnet Mask: you can configure addresses assigned by a DHCP server.

Note

- ☐ If IP addresses overlap or the same subnet IP addresses are selected, the effective value is assigned only to the prioritized interface.
- Ethernet has default interface priority.

AutoNet: A temporary IP address starting with 169.254 and not used on the network, is assigned to the prioritized interface.

∅ Note

- ☐ Default interface priority is IEEE 1394 (IP over 1394).
- Gateway Address, DNS Server Address, and Domain Name: You can configure the addresses assigned by DHCP to the prioritized interface.

If the gateway address is beyond the range of the subnet selected for the interface, the machine operates using "0.0.0.0".

Note

☐ Ethernet has default interface priority.

When there are static IP addresses and addresses assigned by DHCP

 IP Address and subnet mask: if a static IP address is the same as an address assigned by DHCP, or the static subnet mask address and the subnet mask address assigned by DHCP overlap, the machine uses the static IP address interface.

Note

- ☐ The interface with the DHCP setting is set by default.
 - Gateway Address: operates using the address entered manually.

Note

☐ If a static address is not selected, or is set to 0.0.0.0, the interface using the address assigned by DHCP is used.

Note

- ☐ Printers that register the printer NetBIOS name on a WINS server must be configured for the WINS server. See p.109 "WINS".
- ☐ Supported DHCP servers are Microsoft DHCP Server included with Windows 2000 Server, Windows Server 2003, and Windows NT 4.0, and the DHCP server included with NetWare and UNIX.
- ☐ If you do not use the WINS server, reserve the printer's IP address in the DHCP server so the same IP address is assigned every time.
- ☐ To use the WINS server, change the WINS server setting to "active" using the control panel.
- ☐ Using the WINS server, you can configure the host name via the remote network printer port.
- ☐ DHCP relay-agent is not supported. If you use DHCP relay-agent on a network via ISDN, it will result in increased line charges. This is because your computer connects to the ISDN line whenever a packet is transferred from the printer.
- ☐ If there is more than one DHCP server, use the same setting for all servers. The machine operates using data from the DHCP server that responds first.

Using AutoNet

If the printer IP address is not automatically assigned by the DHCP server, a temporary IP address starting with 169.254 and not used on the network can be automatically selected by the printer.

Note

- ☐ The IP address assigned by the DHCP server is given priority over that selected by AutoNet.
- ☐ You can confirm the current IP address on the configuration page. For more information about the configuration page, see *Printer Reference* 2.
- ☐ When AutoNet is running, the NetBIOS name is not registered on the WINS server.
- ☐ The machine cannot communicate with devices that do not have the AutoNet function.

SNMP

The machine is equipped with an SNMP (Simple Network Management Protocol) agent that operates under UDP and IPX on the Ethernet/wireless LAN interface, and UDP on the IEEE 1394 (IP over 1394) interface. Using the SNMP manager you can get information about the machine.

The default community names are "public" and "admin". You can get MIB information using these community names.

∰Important

If you change the machine's community name to one different from the default, use SNMP Setup Tool to change the setting for the computer. For more information, see SNMP Setup Tool Help.

Note

- ☐ Follow the procedure below to start SNMP Setup Tool:
 - Before using SNMP Setup Tool, install SmartNetMonitor for Admin.
 - Windows 95/98/Me/2000, Windows NT 4.0: On the [Start] menu, point to [Programs], point to [SmartNetMonitor for Admin], and then click [SNMP Setup Tool].
 - Windows XP, Windows Server 2003: On the [Start] menu, point to [All Programs], point to [SmartNetMonitor for Admin], and then click [SNMP Setup Tool].

Supported MIBs

- MIB-II
- **PrinterMIB**
- HostResourceMIB
- RicohPrivateMIB

Single-line Messages on the Display Panel

This section describes the most common network-related messages that appear on the display panel. If a message not described here appears, act according to that message.

Messages without Code Numbers

Before turning the main power off, see "Turning On the Power", *General Settings Guide*.

| Message | Causes | Solutions | |
|--|--|--|--|
| Ethernet board has a problem. | An error has occurred in the Ethernet board. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. | |
| Problems with IEEE1394 Board. | An error may have occurred in the IEEE 1394 interface board. | | |
| HDD has a problem. | An error has occurred in the hard disk drive. | | |
| Wireless LAN has a problem. | An error has occurred in the IEEE 802.11b interface unit. | Turn off the main power switch, and check the card is installed correctly. If the message appears again, contact your sales or service representative. | |
| Cannot connect with the wireless card. | IEEE 802.11b interface unit was not inserted when the machine was turned on, or it was pulled out after the machine turned on. An error has occurred in the IEEE 802.11b interface unit. | | |
| Problems with the wireless card. | An error has occurred in the IEEE 802.11b interface unit. | Turn off the main power switch, and back on again. If the message appears again, contact your sales or service representative. | |
| Problems with the wireless board. | An error has occurred in the IEEE 802.11b interface unit. | | |

Messages with Code Numbers

𝚱 Note

☐ A message reporting an error appears on the display panel as shown.

| Message | Causes | Solutions | Code numbers |
|---|---|---|--------------|
| Cannot | The DHCP server cannot be | Check the DHCP server is running | 101 |
| connect with | found. | on the network. | 201 |
| DHCP Server. (| | | 301 |
| IP Ad- | The specified IP address overlaps | The IP address specified for the | 102 |
| dress is already in | another IP address. | machine overlaps another IP address in use. Check the address of | 202 |
| use.: | | the device indicated in <mac address="">.</mac> | 302 |
| Check the | An unauthorized value is speci- | Change the IP address, subnet | 103 |
| follow- ing: IP | fied as the IP address or gateway address. | mask, or gateway address to the correct value. | 203 |
| Address, Sub-net Mask and Gateway Address. | | | 303 |
| The same IP Address exists on more than one interfaces. | IP addresses overlap across multiple interfaces. IP addresses of simultaneously operating interfaces overlap. | The IP address of the specified interface overlaps the IP address of another interface. Configure the IP address so it does not overlap. | 004 |
| Cannot set within the same subnet range. | Subnet masks overlap across multiple interfaces. The subnet masks of simultaneously operating interfaces overlap. | The subnet range of the specified interface overlaps the subnet range of another interface. Configure the subnet mask so it does not overlap. | 005 |
| Cannot connect | Cannot contact to the specified file | The file server is refusing the connection for some reason. Check | 106 |
| to the specified Netware server. (| server. | the file server setting. See p.65 "Printing with NetWare". | 206 |

| Message | Causes | Solutions | Code numbers |
|---|---|---|-------------------|
| Cannot connect to the specified Netware print server. (| Cannot contact to the specified file server in remote printer mode. | The print server is refusing the connection for some reason. Check the print server setting. See p.65 "Printing with NetWare". | 107 |
| This Net- BIOS name is already in use. (| The NetBIOS name overlaps. | The interface's NetBIOS name specified overlaps another interface's NetBIOS name. Configure the NetBIOS name so that it does not overlap. | 108 208 308 |

Code Numbers

The problem interface is displayed.

• 1XX: Ethernet

• 2XX: IEEE 802.11b

• 3XX: IEEE 1394

• 0XX: Independent of interface

Order of priority of messages (when multiple errors occur)

Order of interface priority

- 1.Ethernet
- 2.IEEE 802.11b
- 3.IEEE 1394

Order of protocol priority

- 1.TCP/IP
- 2.NetWare
- 3.NetBEUI
- 4.AppleTalk

𝚱 Note

 $\ \square$ When messages for the same protocol appear, they are displayed ascending in code order.

Understanding Displayed Information

This section describes how to read the status information returned by the network interface board.

Print Job Information

Print job status can be viewed using the following commands:

• telnet: Use the "status" command. See p.101 "Printer status".

| Item name | Meaning |
|------------|---|
| Rank | Print job status: |
| | Active Printing or preparing for printingWaiting |
| | Waiting to be transferred to the printer |
| Owner | Print request user name |
| Job | Print request number |
| Files | The name of the document |
| Total Size | The size of the data (spooled) The default is "0 bytes". |

Print Log Information

This is a record of the most recent 50 jobs printed.

This log can be displayed with the following commands:

• telnet: Use the "prnlog" command. See p.101 "Printer status".

| Name | Meaning |
|------------|--|
| ID | Print request ID |
| User | Print request user name |
| Page | The number of pages printed |
| Result | The result of the print request |
| Time | The time the print request was received |
| UserID *1 | User ID is to be configured using the printer driver |
| JobName *1 | The name of the document for printing |

^{*1} Displays UserID and JobName information when entering the "prnlog" command using the ID.

9

Machine Status and Configuration

You can check the machine status and configuration using telnet or UNIX.

◆ telnet

Use the "info" or "status" command.

♦ UNIX

Use the "lpr" or "lpstat" command, or "stat", "info" parameter of rsh, rcp, or ftp.

Machine status

| Status | Description |
|----------------------------------|--|
| Call Service Center | Call service center and ask for assistance. |
| Card/Counter not inserted | The machine is waiting for prepaid card or key counter to be inserted. |
| Coin/Key Counter not inserted | The machine is waiting for coin or key counter to be inserted. |
| Coin or amount not inserted | The machine is waiting for coin to be inserted. |
| Cover Open: Finisher | Finisher cover is open. |
| Cover Open: Finisher Front lower | Finisher lower-front cover is open |
| Cover Open: Finisher Upper | Finisher top cover is open. |
| Energy Saver Mode | The machine is standing by in Energy Saver mode. |
| Error: Ethernet Board | An Ethernet board error has occurred. |
| Error: HDD Board | A hard disk drive board error has occurred. |
| Error: IEEE1394 Board | An IEEE 1394 interface board error has occurred. |
| Error: Memory Switch | Memory switch data is corrupt. |
| Error: Parallel I/F Board | A parallel interface board error has occurred. |
| Error: USB I/F | A USB 2.0 interface board error has occurred. |
| Error: Wireless Card | Wireless card is not inserted. |
| Error: Wireless Card or Board | A wireless card or IEEE 802.11b interface unit error has occurred. |
| Full: Finisher | Finisher tray is full. |
| Full: Finisher Booklet Tray | Booklet finisher tray is full. |
| Full: Hole Punch Receptacle | Chad receptacle for hole punch is full. |
| Full: Waste Oil Bottle | Waste oil bottle is full. |
| In Use: Finisher | Finishing is in progress. |
| In Use: Input Tray | Paper tray is in use. |
| In Use: Staple Unit | Stapling is in progress. |

| Status | Description |
|--------------------------------|---|
| Key Card not inserted | The machine is waiting for key card to be inserted. |
| Key Card/Counter not inserted | The machine is waiting for key card or key counter to be inserted. |
| Key Counter not inserted | The machine is waiting for key counter to be inserted. |
| Malfunction: Ext. Charge Unit | There is a problem with the external charge un |
| Malfunction: Tray 1 | There is a problem with tray 1. |
| Malfunction: Tray 2 | There is a problem with tray 2. |
| Malfunction: Tray 3 | There is a problem with tray 3. |
| Malfunction: Tray 4 | There is a problem with tray 4. |
| Mismatch: Paper Size | Indicated paper tray does not contain paper selected size. |
| Mismatch: Paper Size and Type | Indicated paper tray does not contain paper selected size and type. |
| Mismatch: Paper Type | Indicated paper tray does not contain paper selected type. |
| | Auto Paper Select cannot detect selected pap size and type. |
| Near Replacing: Fuser Oil Unit | Prepare the new fuser oil unit. |
| Nearly Full: Waste Oil Bottle | Waste oil bottle is nearly full. |
| Need more Staples | Stapler has almost run out of staples. |
| No Paper: Selected Tray | Selected tray has run out of paper. |
| Not Detected: Fuser Oil Unit | Fuser oil unit is not attached correctly. |
| Not Detected: Selected Tray | Selected tray is not attached or is not attached correctly. |
| Not Detected: Waste Oil Bottle | Waste oil bottle is not attached correctly. |
| Panel Off Mode | The machine is in Panel-Off mode. |
| Paper in Finisher | Finisher cannot be used because there is pap left in it. |
| Paper Misfeed: Duplex Unit | Paper has jammed in duplex unit. |
| Paper Misfeed: Finisher | Paper has jammed in finisher. |
| Paper Misfeed: Input Tray | Paper has jammed in paper feed path. |
| Prepaid Card not inserted | The machine is waiting for prepaid card to inserted. |
| Printing | Printing is in progress. |
| Ready | The machine is ready to print. |
| Replace Fuser Oil Unit | Fuser oil unit is empty. |
| Tray Error: Duplex Printing | Selected paper tray cannot be used for dupl printing. |

Machine configuration

𝒯 Note

- $\hfill\Box$ "*" (asterisk) is displayed with the current setting.
- \square Regarding *1-*5, see table below.

| Item | Description |
|-------------|---------------------------------------|
| Input Tray | |
| No. | ID number of the paper tray |
| Name | Name of the paper tray*1 |
| Paper Size | Paper size loaded in the paper tray*2 |
| Status | Current status of the paper tray*3 |
| Output Tray | |
| No. | ID number of the output tray |
| Name | Name of the output tray*4 |
| Status | Current status of the output tray*5 |

◆ *1 Input Tray: Name

| Name | Description |
|-------------|---|
| Tray X | Name of installed paper tray (X is the number of tray.) |
| LCT | Large Capacity Tray (LCT) |
| Bypass Tray | Bypass tray |

◆ *2 Input Tray: Paper Size

| Paper size | Description |
|---|-------------|
| A3 (297 × 420) | A3D |
| B4JIS (Japanese Industrial Standard) (257 × 364) | B4C7 |
| A4 (297 × 210) | A4C |
| A4 (210 × 297) | A4 🗸 |
| B5JIS (257 × 182) | B5 □ |
| B5JIS (182 × 257) | B5 □ |
| A5 (210 × 148) | A5□ |
| A5 (148 × 210) | A5 🖸 |
| A6 (105 × 148) | A6□ |
| 12×18 | 12×18□ |
| 11 × 17 | DLT 🖸 |
| $8^{1}/_{2} \times 14$ | LGD |

| Paper size | Description |
|---------------------------------|-------------|
| $8^{1}/_{2} \times 11$ | LTD |
| $11 \times 8^{1}/_{2}$ | LTD |
| $5^1/_2 \times 8^1/_2$ | HLT [] |
| $8^{1}/_{2} \times 5^{1}/_{2}$ | HLTD |
| Custom Size | Custom Size |
| $10^{1}/_{2} \times 7^{1}/_{4}$ | Executive 🗸 |
| $7^{1}/_{4} \times 10^{1}/_{2}$ | Executive□ |
| $8^{1}/_{4} \times 13$ | Folio□ |
| $8^{1}/_{2} \times 13$ | Foolscap□ |
| 8×13 | 8"×13"□ |
| Com#10 | Com10 □ |
| Monarch | Monarch 🗸 |
| C6 Env | C6D |
| C5 Env | C5 🖸 |
| DL Env | DLD |
| 8K (267 × 390) | 8KD |
| 16K (195 × 267) | 16K [J |
| 16K (267 × 195) | 16K□ |

◆ *3 Input Tray: Status

| Status | Description |
|--------------|--------------------------------------|
| Normal | _ |
| Not Detected | There is no paper tray. |
| No Paper | There is no paper in the paper tray. |

◆ *4 Output Tray: Name

| Name | Description |
|-----------------------|--|
| Internal Tray | Internal tray |
| External Tray | External tray |
| Finisher Upper Tray | Finisher upper tray (optional: Finisher or booklet finisher) |
| Finisher Shift Tray | Finisher shift tray (optional: Finisher) |
| Finisher Booklet Tray | (optional: Booklet finisher) |

◆ *5 Output Tray: Status

| Status | Description |
|----------|------------------------------------|
| Normal | |
| Paper In | There is paper in the output tray. |
| Full | Output tray is full of paper. |
| Error | Other error |

Configuring the Network Interface Board

The network interface board settings can be displayed using the commands below.

• telnet: Use the "show" command. See p.101 "Network interface board configuration settings information".

| Item name | Meaning |
|--------------------|---|
| Common | |
| Mode | |
| Protocol Up/Down | "Up" means active; "Down" means inactive. |
| AppleTalk | |
| TCP/IP | |
| NetWare | |
| SMB | |
| IP over 1394 *1 | |
| SCSI print *1 | |
| Ethernet interface | Internal version number |
| Syslog priority | |
| NVRAM version | Internal version number |
| Device name | |
| Comment | |
| Location | |
| Contact | |
| Soft switch | |

| Item name | Meaning |
|--------------------------|---|
| AppleTalk | |
| Mode | AppleTalk protocol selected |
| Net | Network number |
| Object | Mac OS printer name |
| Туре | The type of printer |
| Zone | Name of zone the printer belongs to |
| TCP/IP | |
| Mode | "Up" means active, "Down" means inactive. |
| ftp | |
| lpr | |
| rsh | |
| telnet | |
| diprint | |
| web | |
| http | |
| ftpc | |
| snmp | |
| ipp | |
| autonet | |
| EncapType | Frame type |
| DHCP | Dynamic Host Configuration Protocol |
| Address | IP address |
| Netmask | Subnet mask |
| Broadcast | Broadcast address |
| Gateway | Default gateway address |
| AccessRange[☆] *2 | Access Control Range |
| Time server | NTP server address |
| Time Zone | NTP server time difference |
| Time server polling time | Synchronizes interval |
| SYSLOG server | |
| Home page URL | URL of homepage |
| Home page link name | URL name of homepage |
| Help page URL | URL of Help page |
| SNMP protocol | Protocol used with SNMP |

| Item name | Meaning |
|--------------------|---------------------------------------|
| NetWare | - |
| EncapType | Frame type |
| RPRINTER number | Remote printer number |
| Print server name | Print server name |
| File server name | Name of the connect file server |
| Context name | Context of print server |
| Switch | |
| Mode | Active mode |
| NDS/Bindery | (this value is fixed) |
| Packet negotiation | (this value is fixed) |
| Login Mode | |
| Print job timeout | Time of the job timeout |
| Protocol | Protocol names that can be used |
| SAP interval time | Intervals under the SAP function |
| NDS Tree Name | NDS Tree Name |
| SMB | |
| Switch | |
| Mode | (this value is fixed) |
| Direct print | (this value is fixed) |
| Notification | Notification of print job completion |
| Workgroup name | Name of the workgroup |
| Computer name | Name of the computer |
| Comment | Comment |
| Share name[1] | Share name (name of the printer type) |
| Protocol | |

| Item name | Meaning |
|---------------------|--|
| IEEE 802.11b *3 | Wieumig |
| Device name | |
| DHCP | Dynamic Host Configuration Protocol |
| Address | IP address |
| Netmask | Subnet mask |
| Broadcast | Broadcast address |
| SSID | SSID being used |
| Channel range | Channels available for use |
| Channel | Channel being used |
| Communication mode | IEEE 802.11b interface transmission mode |
| Authentication | Validity or invalidity of the authorized mode setting when using WEP |
| Tx Rate | IEEE 802.11b interface speed |
| WEP encryption | Enable or disable WEP |
| Encryption key | 64-bit WEP key/128-bit WEP key |
| IP over 1394 *1 | |
| Device name | Name of the machine |
| DHCP | Dynamic Host Configuration Protocol |
| Address | IP address |
| Netmask | Subnet mask |
| Broadcast | Broadcast address |
| SCSI print *1 | |
| Bidi. | Bidirectional setting (on/off) |
| DNS | |
| Server [☆] *4 | DNS server address |
| use DHCP parameters | |
| Domain name | |
| ether | Ethernet interface domain name |
| ip1394 *1 | IEEE 802.11b interface domain name |
| wlan *3 | IEEE 1394 interface domain name |

| Item name | Meaning |
|--------------------|-------------------------------------|
| WINS | |
| ether | Ethernet interface WINS name |
| Primary WINS | Primary WINS server address |
| Secondary WINS | Secondary WINS server address |
| ip 1394 *1 | IEEE 1394 interface WINS name |
| Primary WINS | Primary WINS server address |
| Secondary WINS | Secondary WINS server address |
| wlan ^{*3} | IEEE 802.11b interface WINS name |
| Primary WINS | Primary WINS server address |
| Secondary WINS | Secondary WINS server address |
| Shell mode | Mode of the remote maintenance tool |

^{*1} You can display these item names when installing the optional IEEE 1394 interface board.

^{*2} \Rightarrow represents a target number between 1 and 5.

You can display these item names when installing the optional IEEE 802.11b interface unit.

^{*4} $\stackrel{\text{thin.}}{\approx}$ represents a target number between 1 and 3.

Message List

This is a list of messages written to the machine's system log. The system log can be viewed using the "syslog" command.

System Log Information

You can use the following methods to view the system log:

• telnet: Use the "syslog" command. See p.101 "System log information".

| Message | Causes and solutions |
|--|--|
| Access to NetWare server <file name="" server=""> denied. Either there is no account for this print server or the NetWare server or the password was incorrect.</file> | (In print server mode) Cannot log on to the file server. Make sure the print server is registered on the file server. If a password is specified for the print server, delete it. |
| add_sess: bad trap addr: <ipaddress>, community:<community name=""></community></ipaddress> | The IP address (0.0.0.0.) is unavailable when the community access type is TRAP. Specify the host IP address for the TRAP destination. |
| add_sess: community <community name=""> already defined.</community> | The same community name already exists. Use another community name. |
| add_sess_ipx: bad trap addr: <ipx address="">, <community name=""></community></ipx> | The IPX address (00:00:00:00:00:00) is unavailable when the community access type is TRAP. Specify the host IPX address for the TRAP destination. |
| add_sess_ipx: community <community name=""> already defined.</community> | The community name already exists. Use another community name. |
| ANONYMOUS FTP LOGIN FROM <ip address="">, <password></password></ip> | An anonymous login has been made with a password <password> from the host <ip address="">.</ip></password> |
| anpd start.(AppleTalk) | An anpd (AppleTalk Network Package Daemon) has started. |
| Attach FileServer= <file name="" server=""></file> | Attached to the file server as a nearest server |
| Attach to print queue <print name="" queue=""></print> | (In print server mode) Attached to the print queue name |
| Cannot create service connection | If the remote printer is working: A connection with the file server cannot be established. The amount of data may have exceeded the file server's user limit. |
| | If the remote printer is working: The printer with the required <printer number=""> does not appear in <pri>print server name>. Check the printer number of the printer registered in the print server.</pri></printer> |

9

| Message | Causes and solutions |
|---|---|
| Cannot find rprinter (<print name="" server="">/ <printer number="">)</printer></print> | Check the printer number registered in the print server. |
| Change IP address from DHCP Server. | The IP address changes when DHCP LEASE is renewed. To always assign the same IP address, set a static IP address to the DHCP server. |
| child process exec error! (process name) | The network service failed to start. Turn the printer off and then on. If this does not work, contact your service or sales representatives. |
| Connected DHCP Server (<dhcp address="" server="">).</dhcp> | The IP address was successfully received from the DHCP server. |
| connection from <ip address=""></ip> | Logged on from the host <ip address=""></ip> |
| Could not attach to PServer <print name="" server=""></print> | When using a remote printer: Cannot connect to the print server. The print server is rejecting the connection for some reason. Check the print server settings. |
| Could not attach to FileServer <error code=""></error> | When using a remote printer: Cannot connect to the file server. The file server is rejecting the connection for some reason. Check the file server settings. |
| Current Interface Speed:xxxMbps | The speed of the network (10 Mbps or 100 Mbps) |
| Current IP address <current address="" ip=""></current> | The IP address <current address="" ip=""> was received from the DHCP server.</current> |
| Current IPX address <ipx address=""></ipx> | The current IPX address |
| DHCP lease time expired. | DHCP lease time has expired. The printer tries to locate the DHCP server again. The IP address used till now becomes invalid. |
| DHCP server not found. | The DHCP server cannot be found. Make sure the DHCP server is running on the network. |
| dhcpcd start. | A dhcpcd (DHCP client server) has started. |
| Duplicate IP= <ip address="">(from <mac address="">).</mac></ip> | The same IP address is used. Every IP address must be unique. Check the address of the device indicated in <mac address="">.</mac> |
| Established SPX Connection with PServer, (RPSocket= <socket number="">, connID =<connection id="">)</connection></socket> | (In remote printer mode) A connection with the print server has been established. |
| exiting | lpd service has ended and the system is closing down. |
| Exit pserver | (In print server mode) Exits the print server because necessary print server settings have not been made. |

| Message | Causes and solutions |
|---|--|
| Frametype = <frame name="" type=""/> | The <frame name="" type=""/> is configured to be used on NetWare. |
| httpd start. | httpd has started. |
| IEEE 802.11b < Transmission mode > mode | Transmission mode for IEEE 802.11b (Example: current mode is infrastructure mode.) |
| | IEEE 802.11b [infrastructure] mode |
| | (Example: current mode is 802.11 ad hoc mode.) |
| | IEEE 802.11b [802.11 ad hoc] mode |
| | (Example: current mode is ad hoc mode.) IEEE 802.11b [ad hoc] mode |
| IEEE 802.11b current channel <channel></channel> | The current channel is displayed. The value selected by the user is displayed in ad hoc mode. |
| | The channel used in the access point is displayed in infrastructure mode. |
| | (Example: current channel is 11.) |
| | IEEE 802.11b current channel 11 |
| IEEE 802.11b Card Firmware REV. <version></version> | IEEE 802.11b interface unit Firmware version |
| | (Example: current version is 0.8.3.) |
| | IEEE 802.11b interface unit Firmware REV. 0.8.3 |
| IEEE 802.11b MAC Address = <mac address=""></mac> | The IEEE 802.11b I/F MAC address is displayed. |
| | (Example: current MAC address is 00:00:74:XX:XX:XX.) |
| | IEEE 802.11b MAC Address = |
| | 00:00:74:XX:XX |
| IEEE 802.11b SSID <ssid> (AP MAC Address < MAC Address>)</ssid> | The access point SSID used in infrastructure mode and the MAC address of the access point are displayed. |
| | (Example: current MAC address is xx:xx:xx:xx:xx and SSID value is "test-ssid".) |
| | IEEE 802.11b SSID test-ssid (AP MAC Address xx:xx:xx:xx:xx) |

| Message | Causes and solutions |
|---|---|
| IEEE 802.11b TX Rate <transfer speed=""></transfer> | The IEEE 802.11b transmitting speed (set speed) is displayed. |
| | (Example: current Tx Rate is 11 Mbps.) |
| | IEEE 802.11b Tx Rate 11 Mbps |
| | Transmission speeds vary depending on signal quality. Displayed values may differ from actual transmission speed. |
| inetd start. | An inetd has started. |
| <interface> started with IP: <ip address=""></ip></interface> | <pre><ip address=""> has been set for <interface> and <interface> started.</interface></interface></ip></pre> |
| <interface>: Subnet overlap.</interface> | Subnet from Netmask and the IP address you tried to set for <interface> overlap the subnet of another interface. Set Subnet so it does not overlap with another interface.</interface> |
| IPP cancel-job: permission denied. | The printer could not authenticate the name of the user attempting to cancel a job. |
| ipp disable. | Printing with ipp is disabled. |
| ipp enable. | Printing with ipp is enabled. |
| IPP job canceled. jobid=%d. | The spooled job has been canceled due to error or user request. |
| job canceled. jobid=%d. | The spooled job has been canceled due to error or user request. |
| LeaseTime= <lease time="">(sec), RenewTime= <renew time="">(sec).</renew></lease> | The resource lease time received from the DHCP server is <lease time=""> in seconds. The renewal time is also <renew time=""> in seconds.</renew></lease> |
| Login to fileserver <file name="" server=""> (<ipx ip="" ="">,<nds bindery="" ="">)</nds></ipx></file> | (In print server mode) Logged on to the file server with NDS or BINDERY mode. |
| multid start. | Data transmission service for multiprotocols has started. |
| Name registration failed. name= <netbios name=""></netbios> | The printer could not register the name of NetBIOS. |
| Name registration success in Broadcast name= <netbios name=""></netbios> | The NetBIOS name was successfully registered from a broadcast. |
| Name registration success. WINS Server= <wins address="" server=""> NetBIOS Name= <netbios name=""></netbios></wins> | The NetBIOS name was successfully registered to the WINS server. |
| nbstart start.(NetBEUI) | The server for setting the NetBEUI protocol stack has started. |
| nbtd start. | nbtd (NetBIOS over TCP/IP Daemon) has started. (Available only in DHCP mode) |

| Message | Causes and solutions | |
|---|--|--|
| NetBEUI Computer Name = <computer name=""></computer> | The NetBEUI Computer Name is defined as <computer name="">.</computer> | |
| nmsd start. (NetBEUI) | nmsd (Name Server Daemon) has started. | |
| nprinter start. (NetWare) | (In remote printer mode) NetWare service has started. | |
| nwstart start. (NetWare) | The service for NetWare protocol stack setting has started. | |
| Open log file <file name=""></file> | (In print server mode) The specified log file has been opened. | |
| papd start. (Apple Talk) | Apple Talk print service has started. | |
| permission denied. | Job cancellation was determined to be unauthorized after checking the user name and host address (except for ROOT authorization). | |
| phy release file open failed. | A replacement network interface board is required. Contact your sales or service representatives. | |
| Print queue <print name="" queue=""> cannot be serviced by printer 0, <print name="" server=""></print></print> | (In print server mode) The print queue name cannot be serviced. Make sure that print queue volume is on the specified file server. | |
| Print server <print name="" server=""> has no printer.</print> | (In print server mode) The printer is not assigned to the print server <pri>print server name>. Using NWadmin, assign the printer, and then restart the printer device.</pri> | |
| Print sessions full | Cannot accept the print session. | |
| Printer <printer name=""> has no queue.</printer> | (In print server mode) The print queue is not assigned to the printer. Using NWadmin, assign the print queue to the printer, and then restart it. | |
| pserver start. (NetWare) | (In print server mode) NetWare service has started. | |
| Required computer name (<computer name="">) is duplicated name.</computer> | The same computer name is detected on the network. The start job determines the computer name by adding it to the suffix (0,1). Configure a new computer name that is unique. | |
| Required file server (<file name="" server="">) not found.</file> | Cannot find the required file server. | |
| restarted. | LPD has started. | |
| sap enable, saptype= <sap type="">, sapname= <sap name=""></sap></sap> | The SAP function has started. The SAP (SAP type and SAP name) packet is issued to advertise the service on the NetWare server SAP table. | |

| Message | Causes and solutions | |
|--|---|--|
| session <community name=""> not defined.</community> | The requested community name is not defined. | |
| session_ipx <community name=""> not defined.</community> | The requested community name is not defined. | |
| Set context to <nds context="" name=""></nds> | A <nds context="" name=""> has been set.</nds> | |
| shutdown signal received. network service rebooting | Rebooting the network service. | |
| smbd start. (NetBEUI) | An smbd (SMB (Server Message Block) service) has started. | |
| Snmp over ip is ready. | Communication over TCP/IP via SNMP is available. | |
| Snmp over IP over 1394 is ready. | Communication over IP over 1394 via SNMP is available. | |
| Snmp over ipx is ready. | Communication over IPX via SNMP is available. | |
| snmpd start. | SNMP service has started. | |
| started. | Direct print service has started. | |
| The print server received error <error number=""> during attempt to log in to the network. Access to the network was denied. Verify that the print server name and password are correct.</error> | Cannot log on to the file server. The print server is not registered or a password is specified. Register the print server without specifying a password. | |
| SMTPC: failed to get smtp server ip-address. | Failed to get the SMTP server IP address. This could be because: | |
| | The DNS server could not be found. | |
| | There is no connection to the network. | |
| | The specified DNS server could not be connected to. | |
| | Incorrect DNS server is specified. | |
| | No specified SMTP server IP address in the DNS server. | |
| SMTPC: failed to connect smtp server. timeout. | Failed to connect the SMTP server due to timeout. This could be because: | |
| | The SMTP server name is incorrect. | |
| | There is no connection to the network. | |
| | • The network configuration is incorrect, so there is no response from the SMTP server. | |
| SMTPC: refused connect by smtp server. | The connection to the SMTP server is denied. This could be because: | |
| | Another server other than the SMTP server has been specified. | |
| | • The SMTP server port number is incorrect. | |

| Message | Causes and solutions | |
|---|--|--|
| SMTPC: no smtp server. connection close. | No response from the SMTP protocol. Cannot connect to the SMTP server. This could be because: | |
| | Another server other than the SMTP server has been specified. | |
| | • The SMTP server port number is incorrect. | |
| SMTPC: failed to connect smtp server. | Failed to connect the SMTP server. This could be because: | |
| | There is no connection to the network. | |
| | • The network configuration is incorrect, so there is no response from the SMTP server. | |
| | The SMTP server name is incorrect. | |
| | The specified SMTP server is incorrect. | |
| | There is no specified SMTP server IP address in the DNS server. | |
| | Another server other than the SMTP server has been specified. | |
| | • The SMTP server port number is incorrect. | |
| SMTPC: username or password wasn't correct. | Failed to connect the SMTP server. This could be because: | |
| | • The specified SMTP user name is incorrect. | |
| | • The specified SMTP password is incorrect. | |
| | Check the SMTP user name and password. | |
| WINS name registration: No response to server (WINS server address) | There is no response from the server during data registration. | |
| | Check the WINS server address is correct and WINS server is working properly. | |
| WINS name registration/refresh error code (error code) | The NetBEUI name could not be registered or updated. Make sure the name is not already being used. If the name is not the problem, check that the WINS server address is correct and that the WINS server is working properly. | |
| WINS wrong scopeID | The scope ID is wrong. | |
| | Specify the correct scope ID. | |
| write error occurred. (diskfull) | The hard disk became full while the spool file was being written. | |
| | Wait until enough HDD space becomes available as printing proceeds. | |
| write error occurred. (fatal) | A fatal error occurred while the spool file was being written. | |
| | Turn the printer off and then on. If this does not work, contact your service or sales representative. | |

♦ LDAP error messages

𝚱 Note

☐ See the description corresponding to the error message. The number in the error message is the RFC error number.

LDAP errors appear thus:

<Status>:<LDAP error message>

- Status
 - init Error during LDAP initialization.
 - bind Error during LDAP binding.
 - search Error during LDAP search.
- LDAP error message

| LDAP error message | Causes and solutions |
|--|--|
| Operations error(1) | An operating error has occurred. The function is not possible in the current status. |
| Protocol error(2) | A protocol error has occurred. |
| Time limit exceeded(3) | The search could not be completed within the time allowed. |
| Size limit exceeded(4) | Too many hits have been returned. Check the search criteria or starting position. |
| Compare False(5) | Result of compare request is false. |
| Compare True(6) | Result of compare request is true. |
| Authentication method not supported(7) | The selected authentication method is not supported. Check the authentication setting. |
| Strong authentication required(8) | Strong authentication is required. Check the authentication setting. |
| Partial results and referral received(9) | Partial results and referrals have been received. |
| Referral(10) | Referral |
| Administrative limit exceeded(11) | The amount of data has exceeded the limit set by the network administrator. |
| Criticial extension is unavailable(12) | Extended function is unavailable. Consult the network administrator. |
| Confidentiality required(13) | Confidentiality is required. Check the server setting. Consult the network administrator if necessary. |
| SASL bind in progress(14) | SASL binding is in progress. |

| LDAP error message | Causes and solutions |
|--------------------------------------|--|
| No such attribute(16) | The requested attribute does not exist. Check the attribute settings. |
| Undefined attribute type(17) | The specified attribute is undefined. |
| Inappropriate matching(18) | The match is inappropriate. |
| Constraint violation(19) | A constraint violation has occurred. |
| Type or value exists(20) | The specified attribute already exists. |
| Invalid syntax(21) | The syntax of the specified attribute is invalid. |
| No such object(32) | A matching object cannot be found. |
| Alias problem(33) | The alias is incorrect. |
| Invalid DN syntax(34) | The DN syntax is invalid. Check the settings. |
| Entry is a leaf(35) | Entry is a leaf. |
| Alias dereferencing problem(36) | Alias cannot be resolved. |
| Inappropriate authentication(48) | Authentication has failed. Check the authentication setting. |
| Invalid credentials(49) | The specified authentication credentials are invalid. |
| Insufficient access(50) | The user's access rights are insufficient to carry out the requested operation. |
| DSA is busy(51) | The DSA is busy. |
| DSA is unavailable(52) | No DSA is available to carry out the request. Consult the network administrator. |
| DSA is unwilling to perform(53) | The DSA has rejected the request. |
| Loop detected(54) | A loop has been detected. |
| Naming violation(64) | A naming violation has occurred. |
| Object class violation(65) | An object class violation has occurred. |
| Operation not allowed on nonleaf(66) | The specified operation is not allowed on a non-leaf entry. |
| Operation not allowed on RDN(67) | The specified operation is not allowed on RDN. |
| Already exists(68) | The specified entry already exists. |
| Cannot modify object class(69) | The specified object class cannot be modified. |
| Results too large(70) | Too many hits have been returned. Check the search criteria. |
| Operation affects multiple DSAs(71) | The operation affects multiple DSAs. |
| Unknown error(80) | An unknown error has occurred. Consult the network administrator. |

| LDAP error message | Causes and solutions |
|--------------------------------------|---|
| Can't contact LDAP server(81) | Cannot contact the LDAP server. Check the server is working and communicating properly. |
| Local error(82) | A local program error or an SASL authentication error has occurred. Consult the network administrator. |
| Encoding error(83) | An error occurred while encoding the message to be transmitted. Consult the network administrator. |
| Decoding error(84) | An error occurred while decoding the received message. Consult the network administrator. |
| Timed out(85) | The search could not be completed within the time allowed. |
| Unknown authentication method(86) | An unknown authentication method has been specified. Check the authentication setting. |
| Bad search filter(87) | An error has been detected in the search filter specification. Check the search criteria. If the error persists, consult the network administrator. |
| User cancelled operation(88) | The operation has been cancelled. |
| Bad parameter to an Idap routine(89) | An illegal parameter was passed to the LDAP routine. Check the settings. If the error persists, consult the network administrator. |
| Out of memory(90) | The machine is out of memory. |
| Connect error(91) | A connection with the server could not be established. Check the settings. |
| Not Supported(92) | The specified function is not supported. |
| Control not found(93) | Control is not found. |
| No results returned(94) | There are no results to return. |
| More results to return(95) | There are more results to return. |
| Client Loop(96) | A client loop has been detected. |
| Referral Limit Exceeded(97) | The amount of data has exceeded the referral limit. |

When Using Windows Terminal Service/MetaFrame

Operating Environment

The following combinations of operating system and MetaFrame are supported:

- Windows NT Server 4.0 Terminal Server Edition
 - MetaFrame 1.8 SP3/FR1 SP3
 - MetaFrame XP 1.0 SP1/SP2/FR1
- Windows 2000 Server /Advanced Server
 - MetaFrame 1.8 SP3/FR1 SP3
 - MetaFrame XP 1.0 SP1/SP2/ FR1/FR2

Supported Printer Drivers

- When Windows Terminal Service is operating
 - PCL5c
 - PostScript 3

Note

- ☐ The RPCS printer driver is not supported.
- ☐ Some RPCS printer driver functions do not work if Windows Terminal Service is installed, even if it is not operating.

Limitation

The following restrictions apply in the Windows Terminal Service environment.

These restrictions are due to the way Windows Terminal Service or Meta-Frame works.

When printing (Windows Terminal Service)

When printing a file containing a large number of bitmap images or fonts, some images or font settings may be lost. We strongly recommend testing this function under your network environment before applying it to actual jobs.

When using [Auto-creating client printers] (MetaFrame)

[Auto-creating client printers] can select a logical printer created by copying the client's local printer data to the MetaFrame server. We strongly recommend testing this function under your network environment before applying it to actual jobs.

 The settings for optional equipment, such as the finisher or Large Capacity Tray, will not be stored in the server after the equipment is disconnected. The settings for optional items will return to default values each time the client computer logs on to the server.

9

- When printing a large number of bitmap images or using the server in a WAN environment over dial-up lines such as ISDN, depending on the data rate, printing may be disabled or errors may occur.
- When using MetaFrame XP 1.0 or later versions, we recommend configuring [Client Printer bandwidth] available from [Citrix Management Console], according to the environment.
- If a printing error occurs on the server and the print job or [Autocreating client printers] cannot be deleted, we recommend doing the following:
 - MetaFrame 1.8 SP3, Meta-Frame XP 1.0 SP1/FR1
 Configure the [Delete unfinished print jobs] settings in the registry. For more information, see the Readme file provided with MetaFrame.
 - MetaFrame XP 1.0 FR2
 Configure the [Delete pending print jobs at logout] settings in [Printer Properties Management] of the Citrix Management Console.

When using [Printer driver replication] (MetaFrame)

[Printer driver replication] is designed to distribute printer drivers across all servers in a server farm. We strongly recommend testing this function under your network environment before applying it to actual jobs.

 If the printer drivers are not properly copied, we recommend installing them directly onto each server.

g

riecaulions

Please pay attention to the following when using the network interface board. When configuration is necessary, follow the appropriate procedures below.

Connecting a Dial-Up Router to a Network

When using NetWare (file server)

If the NetWare file server and printer are on opposite sides of a router, packets are sent back and forth continuously, possibly incurring communications charges. Because packet transmission is a feature of NetWare, you need to change the configuration of the router. If the network you are using does not allow you to configure the router, configure the machine instead.

Configuring the router

Filter packets so they do not pass over the dial-up router.

- ☐ The MAC address of the filtering printer is printed on the printer configuration page. For more information about printing a configuration page, see *Printer Reference* 2.
- ☐ For more information about configuring the printer if the router cannot be configured, see the following instructions.

Configuring the printer with NetWare

- 1 Following the setup method described earlier in this manual, configure the file server.
- 2 Set the frame type for NetWare environment.

For more information about selecting a frame type, see p.19 "Setting Up the Machine on a Network" p.19 "Setting Up the Machine on a Network".

Configuring the printer without NetWare

1 When not printing, the network interface board sends packets over the network. Set NetWare to "inactive".

For more information about selecting a protocol, see \Rightarrow p.19 "Setting Up the Machine on a Network".

When Using Network Utility

If the machine is connected to a network, observe the following points when setting up the machine or changing settings:

For more details, see the operating instructions and Help for ScanRouter V2 Lite/Professional and DeskTop-Binder V2 Lite/Professional.

When a dial-up router is connected in a network environment

The settings for the delivery server to be connected must be made appropriately for the machine with ScanRouter V2 Lite/Professional, Auto Document Link, or DeskTop-Binder V2 Lite/Professional. In addition, set up connected devices using the I/O settings of Scan-Router V2 Administration Utility. If the network environment changes, make the necessary changes for the delivery server using the machine, the administration utility of client computers, Auto Document Link, and DeskTopBinder V2 Lite/Professional. Also, set the correct information for the connected devices using the I/O seto f ScanRouter Administration Utility.

#Important

☐ If the machine is set up to connect to the delivery server via a dial-up router, the router will dial and go online whenever a connection to the delivery server is made. Telephone charges may be incurred.

When connected to a computer that uses dial-up access

- Do not install ScanRouter V2 Lite/Professional on a computer which uses dial-up access.
- When using ScanRouter V2 Lite/Professional, DeskTop-Binder V2 Lite/Professional, Auto Document Link, or a TWAIN driver on a computer with dial-up access, a dial-up connection may be performed when connecting to the delivery server and other equipment, depending on the setup. If the computer is set up to connect to the Internet automatically, the confirmation dialog box will not appear, and telephone charges may be incurred without your being aware of it. To prevent unnecessary connections, the computer should be set up so the confirmation dialog box always appears before establishing a connection. Do not make unnecessary connections when using the above listed software.

9

NetWare Printing

Form feed

You should not configure form feed on NetWare. Form feed is controlled by the printer driver on Windows. If NetWare form feed is configured, the printer might not work properly. If you want to change form feed settings, always configure them using Windows.

- Under Windows 95/98/Me, clear the [Form feed] check box on the [Printer Settings] tab in the printer properties dialog box.
- Under Windows 2000/XP and Windows Server 2003, clear the [Form feed] check box on the [Net-Ware Settings] tab in the printer properties dialog box.
- Under Windows NT 4.0, clear the [Form feed] check box on the [Net-Ware Settings] tab in the printer properties dialog box.

Banner page

You should not configure a banner page on NetWare. If you want to change the banner page setting, always configure it using Windows.

- Under Windows 95/98/Me, clear the [Enable banner] check box on the [Printer Settings] tab in the printer properties dialog box.
- Under Windows 2000/XP and Windows Server 2003, clear the [Enable banner] check box on the [NetWare Settings] tab in the printer properties dialog box.
- Under Windows NT 4.0, clear the [Enable banner] check box on the [NetWare Settings] tab in the printer properties dialog box.

Printing after resetting the machine

After resetting the remote printer, the connection from the print server will be cut off for about 30-40 seconds before re-connecting. Depending on the NetWare specification, print jobs may be accepted, but they will not be printed during this interval.

When using the machine as a remote printer, wait about two minutes after resetting before attempting to print.

When Using IPP with SmartNetMonitor for Client

When using IPP with SmartNetMonitor for Client, note the following:

- The network printer can only receive one print job from SmartNet-Monitor for Client at a time. While the network printer is printing, another user cannot access it until the job is finished. In this case, Smart-NetMonitor for Client tries to access the network printer until the retry interval expires.
- If SmartNetMonitor for Client cannot access the network printer and times out, it will stop sending the print job. In this case, you should cancel the paused status from the print queue window. SmartNetMonitor for Client will resume access to the network printer. You can delete the print job from the print queue window, but canceling a print job printed by the network printer might cause the next job sent from another user to be incorrectly printed.
- If a print job sent from SmartNet-Monitor for Client is interrupted and the network printer cancels the job because something went wrong, send the print job again.

- Print jobs sent from another computer do not appear in the print queue window, regardless of protocol.
- If various users send print jobs using SmartNetMonitor for Client to network printers, the printing order might not be the same as that in which the jobs were sent.
- An IP address cannot be used for the IPP port name because the IP address is used for the SmartNet-Monitor for Client port name.

When the optional IEEE 802.11b interface unit Is Installed

When using the wireless LAN interface on the network, note the following:

When moving the machine

Detach the antennas when relocating the machine locally.

After moving the machine, reattach the antennas, ensuring that:

- The antennas are positioned clear of obstacles.
- There is 40 to 60 mm between the antennas, so that they do not touch.
- The exposure glass cover and the Auto Document Feeder (ADF) do not knock the antennas.

If the network area provides poor radio environment

Where radio wave conditions are bad, the network may not function due to interrupted or failed connections. When checking the wireless LAN signal and the access point, follow the procedure below to improve the situation:

- Position the access point nearer to the machine.
- Clear the space between access point and machine of obstructions.
- Move radio wave generating appliances, such as microwaves, away from the machine and access point.

For information about how to check radio wave status, see p.17 "Checking the machine's radio wave status".

For more information about access point radio wave conditions, refer to the access point manual.

146

Specifications

| Interface | 100BASE-TX, 10BASE-T, IEEE 1394 (IP over 1394) *1, IEEE 802.11b |
|------------|---|
| Frame type | EthernetII, IEEE 802.2, IEEE 802.3, SNAP |
| Protocol | Printer (LAN-Fax) TCP/IP LPR RSH RCP DIPRINT FTP IPP *2 *3 SMB *2 *5 IPX/SPX (NetWare) AppleTalk *4 NetBEUI |
| | Internet Fax TCP/IP SMTP POP IMAP Network Scanner TCP/IP RSH FTP SMTP POP SMB *6 |
| | Document Server TCP/IP FTP HTTP |
| | Management Function TCP/IP RSH RCP FTP SNMP HTTP TELNET (mshell) NBT DHCP DNS LDAP |
| SNMP | MIB-II, PrinterMIB, HostResourceMIB, RicohPrivateMIB |

 $^{^{\}ast 1}~$ The optional IEEE 1394 interface board supports only TCP/IP.

*2 Use the SmartNetMonitor for Client port.

- *4 This can be used when the PostScript 3 module is installed.
- *5 Under Windows, this function can be used with TCP/IP and NetBEUI.
- *6 SMB using NetBEUI is unavailable.

^{*3} To use IPP under Windows XP, Windows Server 2003, use the Standard IPP port. Note, in SmartNetMonitor for Client however, this port does not support digest access authentication.

INDEX

| Α | 1 |
|--|--|
| Access Control, 99 access type, 102 AutoNet, 110, 115 | IEEE 802.11b, 106 setting, 15 information Network Interface Board configuration, 101 |
| <u>B</u> | print job, 120 print log, 120 |
| Bidirectional SCSI print, 40 Broadcast address, 99 | system log, 101, 130 Interface Settings/IEEE 1394, 39 |
| C | Interface Settings/IEEE 802.11b, 40 Interface Settings/Network, 37 |
| Channel, 40 Communication Mode, 40 community name, 102 configuration access type, 102 community name, 102 Network Interface Board configuration, 125 Web Browser, 89 | IP Address, 37, 39 IP address, 98 IP over 1394, 39 IPP, 103, 144 |
| D | <u>L</u> |
| Delivery Option, 41 DHCP, 100, 114 dial-up router, 142 Direct Printing Port, 104 DNS, 111 DNS Configuration, 37 Domain Name, 38, 40 Domainname, 111 | M Machine configuration, 121, 123 Machine status, 121 Mac OS EtherTalk, 63 printer name, 64 zone, 64 |
| Effective Protocol, 38 Energy saver mode, 87 | message, 130 MIB, 116 N |
| Ethernet Speed, 38 EtherTalk Mac OS, 63 | NBT scope ID setting, 109 Number of Scanner Recalls, 45 NW Frame Type, 37 |
| <u> </u> | P |
| File Transfer, 41 | - |
| G | password, 110 precautions, 142 |
| Gateway Address, 37 | printer name <i>Mac OS</i> , 64 |
| н | printer status, 101 |
| Host Name, 38, 40, 108 | |

R

```
remote maintenance

telnet, 97

Return to Defaults, 41

ROUTE, 105
```

S

```
Scanner Recall Interval Time, 45
SCSI print (SBP-2), 40
SLP, 106
SmartNetMonitor for Client, 144
SMB, 105
SMTP Server, 42
SNMP, 101, 116
specifications, 146
SPRINT, 106
SSID Setting, 40
subnet mask, 99
system Log, 130
system log
information, 101
```

Т

```
Telnet, 121
telnet

remote maintenance, 97
using, 97
Transmission Speed, 41
```

U

UNIX, 121

W

Web Browser, 89 WEP (Encryption) Setting, 41 WINS, 109 Wireless LAN Signal, 41

Z

zone

Mac OS, 64



PostScript3 Unit Type 2238

Operating Instructions

Supplement



Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Trademarks

Microsoft®, Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe®, PostScript®, Acrobat® and PageMaker® are registered trademarks of Adobe Systems Incorporated.

AppleTalk, Apple, Macintosh and Mac are registered trademarks of Apple Computer, Incorporated.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

Notes

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

TABLE OF CONTENTS

1. PostScript 3

| Installable Options | |
|------------------------------------|----|
| Setting Up Options | |
| Printing a Document | 3 |
| Toner Saving | |
| Staple | |
| Punch | |
| Sample Print | 14 |
| Locked Print | |
| Document Server | 27 |
| Printer Utility for Mac | 29 |
| Installing Printer Utility for Mac | |
| Starting Printer Utility for Mac | |
| Printer Utility for Mac Functions | |
| Downloading PS Fonts | |
| Displaying Fonts | 33 |
| Deleting Fonts | 33 |
| Initializing the Hard Disk | 34 |
| Page Setup | 34 |
| Printing the Font Catalog | 34 |
| Printing Font Samples | 35 |
| Renaming the Machine | 35 |
| Restarting the Machine | 36 |
| Downloading PostScript Files | 36 |
| Selecting the Zone | 36 |
| Displaying the Machine Status | |
| Launching the Dialog Console | 37 |
| INDEX | 39 |

1. PostScript 3

Installable Options

The following options are available:

❖ Input Paper Device

- Tray 3
- Tray 3 and 4
- Tray 3 (LCT)

Output Paper Device

- Left Tray 1 and 2
- 2 Tray Finisher
- Booklet Finisher

Setting Up Options

To use installed options correctly, first set up the printer driver. If the options are not recognized, you cannot use them, even though they are physically installed. The procedure to set up a printer driver varies depending on the operating system.

Windows

You can set up any of the options using the following tabs:

| Windows 95/98/Me | [Accessories] tab |
|---|-----------------------|
| Windows 2000/XP, Windows Server 2003, Windows NT 4.0 | [Device Settings] tab |

Note

☐ To set up options, access the printer driver from Windows. You cannot set up options if you access the printer driver from an application.

Limitation

☐ If your system is Windows 2000, Windows XP Professional, or Windows Server 2003, changing printer driver settings requires Manage Printers permission. Members of Administrators and Power Users groups have Manage Printers permission by default. When you change printer driver settings, log on with an account that has Manage Printers permission.

- ☐ If your system is Windows NT 4.0, changing printer driver settings requires Full Control access permission. Members of Administrators, Server Operators, Print Operators, and Power Users groups have Full Control permission by default. When you change printer driver settings, log on with an account that has Full Control permission.
- ☐ If you are using Adobe Page Maker 6.0, 6.5, or 7.0 with Windows 95/98/Me/2000/XP, WIndows Server 2003, or Windows NT 4.0, you have to set up options in the Adobe PageMaker's print dialog box.

♦ Mac OS

You can set up all options using the **[Chooser]** dialog box.

Limitation

 \square If you use Mac OS X, this functions cannot be used.

Printing a Document

This section describes how to print documents from an application.

Note

 \square "Mac OS X" in the tables below refers to Mac OS X 10.2.x or later versions. For Mac OS X 10.1.x, read "Set x as " Feature x".

Paper Source

The following table shows where you can select this function.

| Windows 95/98/Me | [Input Tray:] in the [Paper] tab |
|---|---|
| Windows 2000/XP, Windows Server 2003 | [Paper Source] in the [Paper/Quality] tab |
| Windows NT 4.0 | [Paper Source] in the [Page Setup] tab |
| Mac OS | [Paper Source] in [General] in the print dialog box |
| Mac OS X | [Paper Feed] in the print dialog box |

Destination Tray

The following table shows where you can select this function.

| Windows 95/98/Me | [Output Tray:] in [Destination] on the [Paper] tab |
|---|--|
| Windows 2000/XP, Windows Server 2003 | [Destination] in [Printer Features] on [Advanced] on the [Paper/Quality] or [Layout] tab |
| Windows NT 4.0 | [Destination] in [Printer Features] on [Document Options] on the [Advanced] tab |
| Mac OS | [Destination] in [Printer Specific Options] in the print dialog box |
| Mac OS X | [Destination]on the [Set 3] tab in [Printer Features] in the print dialog box |

❖ Media Type

Use this to select the paper type.

The following table shows the tabs or menus where you can select this function.

| Windows 95/98/Me | [Type:] in [All Pages] on the [Paper] tab |
|---|--|
| Windows 2000/XP, Windows Server 2003 | [Media] on the [Paper/Quality] tab |
| Windows NT 4.0 | [Media] in [Paper/Output] on the [Advanced] tab |
| Mac OS | [Paper Type] in [Printer Specific Options] in the print dialog box. |
| Mac OS X | [Paper Type] on the [Set 4] tab in [Printer Features] in the print dialog box. |

Duplex Printing

Use this function to select duplex printing.

Limitation

 \Box To use this function, the duplex unit must be installed on the printer. The following table shows where you can select this function.

| Windows 95/98/Me | [Duplex] on the [Setup] tab |
|---|---|
| Windows 2000/XP, Windows Server 2003 | [Print on Both Sides] on the [Layout] tab |
| Windows NT 4.0 | [Print on Both Sides] on the [Page Setup] tab |
| Mac OS | [Print on Both Sides] on [Layout] in the print dialog box |
| Mac OS X | [Print on Both Sides] on [Duplex] in the print dialog box |

❖ Collate

Use this function to enable collation. With it, the printer can efficiently print collated sets of multiple-page documents.

Limitation

- ☐ If you are using Windows 2000/XP, Windows Server 2003, Mac OS, or Mac OS X, make sure the following check boxes have not been selected:
 - Windows 2000/XP, Windows Server 2003
 The [Collated] check box on [Paper/Output] on [Advanced...] on the [Paper/Quality] tab
 - Mac OS
 The [Collate] check box in the print dialog box
- Mac OS X
 The **[Collated]** check box on **[Copies & Pages]** in the print dialog box
 The following table shows where you can select this function.

| Windows 95/98/Me | [Collate] on the [Setup] tab |
|---|--|
| Windows 2000/XP, Windows Server 2003 | [Collate] in [Printer Features] on [Advanced] on the [Paper/Quality] or [Layout] tab |
| Windows NT 4.0 | [Collate] in [Printer Features] on [Document Options] on the [Advanced] tab |
| Mac OS | [Collate] in [Printer Specific Options] in the print dialog box |
| Mac OS X | [Collate] on the [Set 1] tab in [Printer Features] in the print dialog box |

Toner Saving

Use this function to reduce the amount of toner used when printing.

 \square This will increase the life of the toner, the output will appear slightly lighter.

The following table shows where you can select this function.

| <u> </u> | • |
|---|---|
| Windows 95/98/Me | [Toner Saving] on the [Print Quality] tab |
| Windows 2000/XP, Windows Server 2003 | [Printer Features] on [Advanced] on the [Paper/Quality] or [Layout] tab |
| Windows NT 4.0 | [Printer Features] on [Document Options] on the [Advanced] tab |
| Mac OS | [Toner Saving] in [Printer Specific Options] in the print dialog box |
| Mac OS X | [Toner Saving] on the [Set 3] tab in [Printer Features] in the print dialog box |

❖ Staple

Use this function to staple sheets of printed paper together.

Limitation

□ When stapling, use the finisher option. See *Copy Reference* or *Printer Reference* 2.

Ø Note

☐ The stapling location might differ depending on the orientation of the paper set in the printer and the orientation of the data to be printed. For details, see "Staple and Punch", *Printer Reference* 2.

The following table shows where you can select this function.

| Windows 95/98/Me | [Staple] on the [Setup] tab |
|---|---|
| Windows 2000/XP, Windows Server 2003 | [Staple] in [Printer Features] on [Advanced] on the [Paper/Quality] or [Layout] tab |
| Windows NT 4.0 | [Staple] in [Printer Features] on [Document Options] on the [Advanced] tab |
| Mac OS | [Staple] in [Printer Specific Options] in the print dialog box |
| Mac OS X | [Staple] on the [Set 3] tab in [Printer Features] in the print dialog box |

Punch

Use this function to punch holes in the printed documents.

Limitation

☐ When punching holes, use the finisher option. See *Copy Reference* or *Printer Reference* 2.

Note

□ Punch positions and the number of punch holes that are available will change depending on the type of finisher, the original's orientation, and the printing paper size and orientation. For details, see "Staple and Punch", *Printer Reference* 2.

The following table shows where you can select this function.

| Windows 95/98/Me | [Punch] on the [Setup] tab |
|---|--|
| Windows 2000/XP, Windows Server 2003 | [Punch] in [Printer Features] on [Advanced] on the [Paper/Quality] or [Layout] tab |
| Windows NT 4.0 | [Punch] in [Printer Features] on [Document Options] on the [Advanced] tab |
| Mac OS | [Punch] in [Printer Specific Options] in the print dialog box |
| Mac OS X | [Punch] on the [Set 2] tab in[Printer Features] in the print dialog box |

Sample Print

Use this function to make only one set of a multiple print job, then, if the result is satisfactory, the remaining sets can be printed out from the machine's control panel.

Limitation

☐ Applications, like PageMaker, which use original drivers do not work with this function.

Note

- ☐ The user ID can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters.
- ☐ Entering the user ID helps you distinguish a print job from others. The following table shows where you can select this function.

| Windows 95/98/Me | [Job Type:] on the [Setup] tab | |
|---|---|--|
| Windows 2000/XP, Windows Server 2003, Windows NT 4.0 | [Job Type:] on the [Job Log] tab | |
| Mac OS | [Job Type:] on the[Job Log] in the print dialog box | |
| Mac OS X | This function is not available. | |

Locked Print

Use this function to save documents in the machine's hard disk using a password, and then print them as required.

Limitation

☐ Applications, like PageMaker, which use original drivers do not work with this function.

Note

☐ The user ID can consist of up to eight alphanumeric (a-z, A-Z, 0-9) characters. The password must be four digits.

The following table shows where you can select this function.

| Windows 95/98/Me | [Job Type:] on the [Setup] tab | | |
|------------------|---|--|--|
| Windows 2000/XP | [Job Type:] on the [Job Log] tab | | |
| Windows NT 4.0 | [Job Type:] on the [Job Log] tab | | |
| Mac OS | [Job Type:] on the[Job Log] in the print dialog box | | |
| Mac OS X | This function is not available. | | |

❖ Document Server

Use this function to store hard disk documents that you want to print as well as documents you might want to later combine or process for printing. For more information about the Document Server function, see "Accessing the Document Server", *Printer Reference* 2.

Limitation

☐ Applications, like PageMaker, which use original drivers do not work with this function.

Ø Note

☐ An optional hard disk drive is required for the Document Server function. The following table shows where you can select this function.

| Windows 95/98/Me | [Job Type:] on the [Setup] tab | |
|---|--|--|
| Windows 2000/XP, Winodws Server 2003, Windows NT 4.0 | [Job Type:] on the [Job Log] tab | |
| Mac OS | [Job Type:] on the [Job Log] in the print dialog box | |
| Mac OS X | This function is not available. | |

Toner Saving

Follow the procedure below to print documents using Toner Saving.

Windows 95/98/Me

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- Click the [Print Quality] tab.
- 4 Click [On] for [Toner Saving].
- Click [OK] to close the printer properties dialog box.
- 6 Start the printing from the application's [Print] dialog box.

Windows 2000

1 From an application, click [Print] on the [File] menu. The [Print] dialog box appears.

- 2 Click the [Paper/Quality] tab.
- Click [Advanced...].
 The [Advanced Options] dialog box appears.
- 4 Click [On] for [Toner Saving] under [Printer Features].
- **5** Click [**0**K].
- 6 Start the printing from the application's [Print] dialog box.

Windows XP, Windows Server 2003

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Preferences].
- Click [Advanced...].

The [Advanced Options] dialog box appears.

4 Click [On] for [Toner Saving] under [Printer Features].

- Click [OK] to close the [Advanced Options] dialog box.
- 6 After making the necessary settings, click [OK] to close the [Printing Preferences] dialog box.
- **7** Start the printing from the application's [Print] dialog box.

Windows NT 4.0

- 1 From an application, click [Print] on the [File] menu. The [Print] dialog box appears.
- 2 Select the printer, and then click [Properties].
- 3 Click the [Advanced] tab.
- 4 From [Document Options], click [On] for [Toner Saving] under [Printer Features].
- Click [OK] to close the [Properties] dialog box.
- 6 Start the printing from the application's [Print] dialog box.

Mac OS/Mac OS X

- 1 From an application, click [Print] on the [File] menu.
 - The [Print] dialog box appears.
- 2 In the pop-up menu, click [Printer Specific Options].
 - Note
 - ☐ Under Mac OS X, click [Printer Features].
- Click [On] for [Toner Saving].
 - Note
 - \square Under Mac OS X, select [On] for [Toner Saving] pop-up menu under [Set 3].
- 4 After making the necessary settings, click [Print].

Staple

Follow the procedure below to print a document using the Staple functions.

Windows 95/ 98/ Me

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- Click the [Setup] tab.
- 4 Make the necessary settings in [Staple], and then click [OK] to close the printer properties dialog box.
- 5 Start the printing from the application's [Print] dialog box.

Windows 2000

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Click the [Paper/Quality] tab.
- 3 Click [Advanced...].

The [Advanced Options] dialog box appears.

- 4 Click [Staple] under [Printer Features].
- **5** After making the necessary settings, click [OK].
- 6 Start the printing from the application's [Print] dialog box.

Windows XP, Windows Server 2003

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Preferences].
- 3 Click [Advanced...].

The [Advanced Options] dialog box appears.

4 Click [Staple] under [Printer Features].

- Click [OK] to close the [Advanced Options] dialog box.
- 6 After making the necessary settings, click [OK] to close the [Printing Preferences] dialog box.
- **7** Start the printing from the application's [Print] dialog box.

Windows NT 4.0

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- 3 Click the [Advanced] tab.
- 4 From [Document Options], click [Staple] under [Printer Features].
- After making the necessary settings, click [OK] to close the [Properties] dialog box.
- 6 Start the printing from the application's [Print] dialog box.

Mac OS/Mac OS X

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 In the pop-up menu, click [Printer Specific Options].

 - ☐ Under Mac OS X, click [Printer Features].
- 3 On the [Staple] pop-up menu, select the location for stapling.
 - Note
 - ☐ Under Mac OS X, on the **[Staple]** pop-up menu under **[Set 3]**, select the location for stapling.
- 4 After making the necessary settings, click [Print].

Punch

Follow the procedure below to print a document using the Punchfunction.

Windows 95/ 98/ Me

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- Click the [Setup] tab.
- Make the necessary settings in [Punch], and then click [OK] to close the printer properties dialog box.
- 5 Start the printing from the application's [Print] dialog box.

Windows 2000

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Click the [Paper/Quality] tab.
- 3 Click [Advanced...].

The [Advanced Options] dialog box appears.

- 4 Click [Punch] under [Printer Features]
- **5** After making the necessary settings, click [OK].
- 6 Start the printing from the application's [Print] dialog box.

Windows XP, Windows Server 2003

1 From an application, click [Print] on the [File] menu.

The **[Print]** dialog box appears.

- 2 Select the printer, and then click [Preferences].
- 3 Click [Advanced...].

The [Advanced Options] dialog box appears.

4 Click [Punch] under [Printer Features].

- Click [OK] to close the [Advanced Options] dialog box.
- 6 After making the necessary settings, click [OK] to close the [Printing Preferences] dialog box.
- **7** Start the printing from the application's [Print] dialog box.

Windows NT 4.0

1 From an application, click [Print] on the [File] menu. The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- Click the [Advanced] tab.
- 4 From [Document Options], click [Punch] under [Printer Features].
- After making the necessary settings, click [OK] to close the [Properties] dialog box.
- 6 Start the printing from the application's [Print] dialog box.

Mac OS/Mac OS X

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 In the pop-up menu, click [Printer Specific].

 - ☐ Under Mac OS X, click [Printer Features].
- On the [Punch] pop-up menu, select the location for punching.
 - Note
 - ☐ Under Mac OS X, on the **[Punch]** pop-up menu under **[Set 3]**, select the location for punching.
- 4 After making the necessary settings, click [Print].

Sample Print

Follow the procedure below to print a document using the Sample Print function.

Windows 95/98/Me

Mote

- ☐ If the application has a collate option, make sure it is not selected before sending a print job. By default, sample print jobs are automatically collated by the printer driver. If the collate option is selected in the application's [Print] dialog box, more prints than intended may be printed.
- 1 From an application, click [Print] on the [File] menu. The [Print] dialog box appears.
- 2 Select the printer, and then click [Properties].
- Click the [Setup] tab.
- 4 In the [Job Type:] list, click [Sample Print].
- Click [Details...].
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters.
 - Note
 - ☐ This is used to identify the user associated with a job.
- 7 Click [OK].
- 8 Click [OK] to close the printer properties dialog box.
- Set the number of copies to two or more, and then start the printing from the application's [Print] dialog box.


The sample print job is sent to the machine and one set is printed.

- Check the printed output to make sure the settings are correct.

 If the settings are correct, proceed to step 1 to print the remaining sets.

 If you want to delete a saved job, see p.20 "Deleting a Sample Print File".
- 11 On the machine's control panel, press the [Printer] key to display the printer screen.


Press [Locked & Sample Print Job List].



A list of the print files stored appears.

Press [Sample Print Job List].

A list of the sample print files stored appears.



The following items will also appear:

- User ID: The user ID set by the printer driver
- Date/Time: The date and time the job was sent from the computer
- Qty.: The number of remaining sets
- Press [▲Prev.] or [▼Next.] to scroll through the files to the one you want to print.
- **E** Select the file you want to print by pressing it.
 - If you want to cancel a sample print file, press it again.
 - You can select only one file at a time.
- 16 Press [Change Set Qty.] to change the number of sets to be printed.

If you do not want to change the set quantity, proceed to step [8].

Enter the new number of sets using the number keys, and then press [OK].



The file list screen reappears.



- ☐ You can enter up to 999 sets.
- ☐ Press [Clear] to correct any entry mistakes.
- ☐ If you want to cancel [Change Set Qty.], press [Cancel].

18 Press [Print].

A print confirmation screen appears.

Press [Yes].

The remaining sets are printed.

∰Important

- ☐ When printing finishes, the stored file will be deleted.
- ☐ Press [No] to cancel the printing.

Windows 2000/XP, Windows Server 2003, Windows NT 4.0

Ø Note

- ☐ If the application has a collate option, make sure it is not selected before sending a print job. By default, sample print jobs are automatically collated by the printer driver. If the collate option is selected in the application's [Print] dialog box, more prints than intended may be printed.
- 1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
 - **𝚱** Note
 - ☐ Under Windows 2000, select the printer, and then proceed to step **3**.
 - ☐ Under Windows XP and Windows Server 2003, select the printer, and then click [Preferences].
- Click the [Job Log] tab.
- 4 In the [Job Type:] list, click [Sample Print].
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters.
 - Note
 - $\hfill\Box$ This is used to identify the user associated with a job.
- 6 Click [OK] to close the printer properties dialog box.
 - Note
 - ☐ Under Windows 2000, proceed to step **②**.

2 Set the number of copies to two or more, and then start the printing from the application's [Print] dialog box.

The sample print job is sent to the machine, and one set is printed.

- Check the printed output to make sure the settings are correct.

 If the settings are correct, proceed to step **()** to print the remaining sets.

 If you want to delete a saved job, see p.20 "Deleting a Sample Print File".
- On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored appears.

Press [Sample Print Job List].

A list of the sample print files stored appears.



The following items will also appear:

- User ID: The user ID set by the printer driver
- Date/Time: The date and time the job was sent from the computer
- Qty.: The number of remaining sets
- Press [▲Prev.] or [▼Next.] to scroll through the files to the one you want to print.
- **1** Select the file you want to print by pressing it.
 - If you want to cancel a sample print file, press it again.
 - You can select only one file at a time.
- 14 Press [Change Set Qty.] to change the number of sets to be printed.

If you do not want to change the set quantity, proceed to step **(L)**.

15 Enter the new number of sets using the number keys, and then press [OK].



The file list screen reappears.

- Note
- ☐ You can enter up to 999 sets.
- ☐ Press [Clear] to correct any entry mistakes.
- ☐ If you want to cancel [Change Set Qty.], press [Cancel].
- 16 Press [Print].

A print confirmation screen appears.

Press [Yes].

The remaining sets are printed.

- ∰Important
- □ When printing finishes, the stored file will be deleted.
- Note
- ☐ Press [No] to cancel the printing.

Mac OS/Mac OS X

- Limitation
- \square If you use Mac OS X, this function cannot be used.
- 1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 In the pop-up menu, click [Job Log].
- On the [Job Type:] pop-up menu, select the appropriate setting.
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters.
 - **𝒯** Note
 - \Box This is used to identify the user associated with a job.
- **5** Set the number of copies to two or more, and then click [Print].

The sample print job is sent to the machine, and one set is printed.

6 Check the printed output to make sure the settings are correct.

If the settings are correct, proceed to step **7** to print the remaining sets. If you want to delete a saved job, see p.20 "Deleting a Sample Print File".

- On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored appears.

9 Press [Sample Print Job List].

A list of the sample print files stored appears.



The following items will also appear:

- User ID: The user ID set by the printer driver
- Date/Time: The date and time the job was sent from the computer
- Qty.: The number of remaining sets
- Press [▲Prev.] or [▼Next.] to scroll through the files to the one you want to print.
- 11 Select the file you want to print by pressing it.
 - If you want to cancel a sample print file, press it again.
 - You can select only one file at a time.
- Press [Change Set Qty.] to change the number of sets to be printed.

If you do not want to change the set quantity, proceed to step **[**].

Enter the new number of sets using the number keys, and then press [OK].



The file list screen reappears.

Note

- ☐ You can enter up to 999 sets.
- ☐ Press [Clear] to correct any entry mistakes.
- ☐ If you want to cancel [Change Set Qty.], press [Cancel].
- Press [Print].

A print confirmation screen appears.

Press [Yes].

The remaining sets are printed.

∰Important

- \square When printing finishes, the stored file will be deleted.
- **𝒯** Note
- \square Press [No] to cancel the printing.

Deleting a Sample Print File

If the printed document is not as you expected, you can delete the sample print file.

- 1 On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].

A list of the print files stored appears.

Press [Sample Print Job List].

A list of sample print files stored appears.

- 4 Select the file you want to delete by pressing it.
 - Note
 - \square Press [\blacktriangle Prev.] or [\blacktriangledown Next.] to scroll through the list.
 - ☐ To cancel a selection, press the highlighted file again.
 - $\ \square$ Only one file can be selected at a time.
- **5** Press [Delete].

A delete confirmation screen appears.

6 Press [Yes] to delete the file.

After the file has been deleted the printer screen reappears.

- Note
- \square Press [No] to cancel the delete request.

Locked Print

Follow the procedure below to print a document using the Locked Print function.

Windows 95/98/Me


- f 1 From an application, click [Print] on the [File] menu.
 - The [Print] dialog box appears.
- 2 Select the printer, and then click [Properties].
- Click the [Setup] tab.
- 4 In the [Job Type:] list, click [Locked Print].
- 5 Click [Details...].
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters, and then enter a four-digit password in the [Password:] box.
 - Note
 - \Box This is used to identify the user associated with a job.
- Click [OK].
- Click [OK] to close the printer properties dialog box.
- After making the necessary settings, click [OK] to close the [Print] dialog box.

The document file is saved in the machine.

If you want to print the document, proceed to step **(1)**.

If you want to delete the document, see p.26 "Deleting a Locked Print File".

- On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored appears.

Press [Locked Print Job List].

A list of the locked print files stored appears.



The date and time the job was sent from the computer, as well as the user ID is displayed.

- **B** Select the file you want to print by pressing it.
 - Note
 - ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - ☐ To cancel a selection, press the highlighted file again.
 - \Box Only one file can be selected at a time.
- Press [Print].

The password screen appears.



1 Enter the password using the number keys, and then press [OK].

A print confirmation screen appears.

- ☐ The confirmation screen will reappear if the password was entered incorrectly. Press **[OK]** to enter the password again.
- 16 Press [Yes].

The locked print file is printed.

- **∰**Important
- \square When printing finishes, the stored file will be deleted.
- Note
- \square Press [No] to cancel the printing.
- ☐ If printing is stopped by pressing [Job Reset] after it has started, the file will be deleted.

Windows 2000/XP, Windows Server 2003, Windows NT 4.0

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
 - Note
 - ☐ Under Windows 2000, select the printer, and then proceed to step 3.
 - ☐ Under Windows XP and Windows Server 2003, select the printer, and then click [Preferences].
- Click the [Job Log] tab.
- 4 In the [Job Type:] list, click [Locked Print].
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters, and then enter a 4-digit password in the [Password:] box.
 - Note
 - ☐ This is used to identify the user associated with a job.
- 6 Click [OK] to close the printer properties dialog box.
 - Note
 - \square Under Windows 2000, proceed to step \square .
- **7** Start the printing from the application's [Print] dialog box.

The document file is saved in the machine.

If you want to print the document, proceed to step 3.

If you want to delete the document, see p.26 "Deleting a Locked Print File".

- On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored appears.

Press [Locked Print Job List].

A list of the locked print files stored appears.



The date and time the job was sent from the computer, as well as the user ID is displayed.

- **1** Select the file you want to print by pressing it.
 - **𝚱** Note
 - ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - ☐ To cancel a selection, press the highlighted file again.
 - \Box Only one file can be selected at a time.
- Press [Print].

The password screen appears.



B Enter the password using the number keys, and then press [OK].

A print confirmation screen appears.

- Ø Note
- ☐ The confirmation screen will reappear if the password was entered incorrectly. Press [OK] to enter the password again.
- 14 Press [Yes].

The locked print file is printed.

- **∰**Important
- □ When printing finishes, the stored file will be deleted.
- Note
- \square Press [No] to cancel the printing.
- ☐ If printing is stopped by pressing [Job Reset] after it has started, the file will be deleted.

Mac OS/Mac OS X

- Limitation
- \square If you use Mac OS X, this function cannot be used.
- **1** From an application, click [Print] on the [File] menu. The [Print] dialog box appears.
- 2 In the pop-up menu, click [Job Log].
- On the [Job Type:] pop-up menu, click [Locked Print].
- In the [User ID] box, enter the user ID using up to eight alphanumeric (a-z, A-Z, 0-9) characters, and then enter a 4-digit password in the [Password:] box.


 - ☐ This is used to identify the user associated with a job.
- **5** After making the necessary settings, click [Print].

The document file is saved in the machine.

If you want to print the document, proceed to step [6].

If you want to delete the document, see p.26 "Deleting a Locked Print File".

- On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].



A list of the print files stored appears.

Press [Locked Print Job List].

A list of the locked print files stored appears.



The date and time the job was sent from the computer, as well as the user ID is displayed.

9 Select the file you want to print by pressing it.

𝒯 Note

- ☐ Press [▲Prev.] or [▼Next.] to scroll through the list.
- ☐ To cancel a selection, press the highlighted file again.
- ☐ Only one file can be selected at a time.

Press [Print].

The password screen appears.



11 Enter the password using the number keys, and then press [OK].

A print confirmation screen appears.

- Ø Note
- ☐ The confirmation screen will reappear if the password was entered incorrectly. Press **[OK]** to enter the password again.
- Press [Yes].

The locked print file is printed.

- **∰**Important
- \square When printing finishes, the stored file will be deleted.
- **𝚱** Note
- ☐ Press **[No]** to cancel the printing.
- ☐ If printing is stopped by pressing [Job Reset] after it has started, the file will be deleted.

Deleting a Locked Print File

If the printed document is not as you expected, you can delete the locked print file.

- 1 On the machine's control panel, press the [Printer] key to display the printer screen.
- Press [Locked & Sample Print Job List].

A list of the print files stored appears.

Press [Locked Print Job List].

A list of locked print files stored appears.

- Select the file you want to delete by pressing it.
 Note
 □ Press [▲Prev.] or [▼Next.] to scroll through the list.
 - ☐ To cancel a selection, press the highlighted file again.
 - \square Only one file can be selected at a time.
- Press [Delete].

The password screen is appears.

6 Enter the password using the number keys, and then press [OK].

A delete confirmation screen appears.

- **𝚱** Note
- ☐ The confirmation screen will reappear if the password was entered incorrectly. Press [OK] to enter the password again.
- **7** Press [Yes].

After the file has been deleted, the printer screen reappears.

- Note
- ☐ Press [No] to cancel the delete request.

Document Server

Follow the procedure below to print a document using the Document Server function.

- Ø Note
- $\hfill \square$ An optional hard disk drive is required to use the Document Server function.

Windows 95/98/Me

1 From an application, click [Print] on the [File] menu.

The [Print] dialog box appears.

- 2 Select the printer, and then click [Properties].
- 3 Click the [Setup] tab.
- In the [Job Type:] list, click [Document Server].
- 5 Click [Details...].
- 6 Enter a user ID, file name, and password in the dialog box that appears. The file name and password are optional.

- 7 Click [OK].
- Start the printing from the application's [Print] dialog box.

Windows 2000/XP, Windows Server 2003, Windows NT 4.0

- 1 From an application, click [Print] on the [File] menu.
 - The [Print] dialog box appears.
- 2 Select the printer, and then click [Properties].
 - **𝚱** Note
 - ☐ Under Windows 2000, select the printer, and then proceed to step 3.
 - ☐ Under Windows XP and Windows Server 2003, select the printer, and then click [Preferences].
- Click the [Job Log] tab.
- In the [Job Type:] list, click [Document Server].
- Enter a user ID, file name, and password in the dialog box that appears. The file name and password are optional.
- 6 Click [OK].
 - **𝚱** Note
 - ☐ Under Windows 2000, proceed to step **7**.
- **7** Start the printing from the application's [Print] dialog box.

Mac OS/Mac OS X

- Limitation
- \square If you use Mac OS X, this function cannot be used.
- 1 From an application, click [Print] on the [File] menu. The [Print] dialog box appears.
- 2 In the pop-up menu, click [Job Log].
- On the [Job Type:] pop-up menu, click [Document Server].
- Enter a user ID, file name, and password in the dialog box that appears. The file name and password are optional.
- 5 Start the printing from the application's [Print] dialog box.

Printer Utility for Mac

By using Printer Utility for Mac, you can download fonts, change the printer name, and so on.

Limitation

☐ If the Mac OS and printer are connected by USB (optional), you cannot use Printer Utility for Mac.

𝚱 Note

- ☐ Printer Utility for Mac is included on the CD-ROM labeled "Printer Drivers and Utilities".
- ☐ Printer Utility for Mac requires Mac OS 7.6.1 ~ 9.x, or Mac OS X 10.1.x or 10.2.1. Mac OS X 10.0.x and 10.2 are not supported.

Installing Printer Utility for Mac

Follow the procedure below to install Printer Utility for Mac on the machine.

- 1 Start the Mac OS.
- 2 Insert the CD-ROM into the CD-ROM drive.

The CD-ROM icon appears.

- 3 Double-click the hard disk icon to open it.
- 4 Double-click the CD-ROM icon.

The contents of the CD-ROM appear.

Double-click the [Mac OS 8 and 9] folder.

𝚱 Note

- ☐ Under Mac OS X, double-click the [Mac OS X] folder.
- **6** Double-click the [PS Utility] folder of the CD-ROM.
- **7** Double-click the folder of the language you use.
- Drag the "Printer Utility for Mac" file, and then drop it into the Mac OS hard disk.
- Drag the CD-ROM icon and drop it into [Trash] to eject the CD-ROM. Printer Utility for Mac is installed.

Starting Printer Utility for Mac

This describes how to start Printer Utility for Mac.

Mac OS

∰Important

- ☐ Before starting Printer Utility for Mac, make sure the printer is selected in **[Chooser]** on the Apple menu.
- 1 Double-click the Printer Utility for Mac icon. The [Printer Utility for Mac] dialog box appears.
- 2 Click [OK].

Printer Utility for Mac will take a few seconds to start.

For more information, see p.31 "Printer Utility for Mac Functions".

Mac OS X

- **1** Double-click the Printer Utility for Mac icon.
 - The [Printer Utility for Mac] dialog box appears.
- 2 Click [0K].
- In the [Available Printers:] box, select the printer you want to use.
 - Note
 - ☐ If you change zones, select a name from [Available Network Zones:].
 - ☐ Click **[Choose Printer..]** on the Printer Utility for Mac menu if you want to change the printer.
- 4 Select the printer you want to use.

Printer Utility for Mac will take a few seconds to start.

For more information, see p.31 "Printer Utility for Mac Functions".

Printer Utility for Mac Functions

Printer Utility for Mac functions are described below.

♣ Apple menu (Mac OS), Printer Utility for Mac menu (Mac OS X)

- [About Printer Utility for Mac...]
- [Choose Printer...]

Displays the [Choose target printer] dialog box.

◆ [File] menu

• [Download PS Fonts]

Downloads fonts (PostScript Type 1) to the machine. See p.32 "Downloading PS Fonts".

• [Display Printer's Fonts]

Displays and deletes the fonts in machine memory and the hard disk. See p.33 "Displaying Fonts".

• [Initialize Printer's Disk]

Initializes the machine's hard disk. See p.34 "Initializing the Hard Disk".

• [Page Setup]

Sets up the paper size to print "Print Fonts Catalog" and "Print Fonts Sample". See p.34 "Page Setup".

• [Print Fonts Catalog]

Prints the names of available fonts. See p.34 "Printing the Font Catalog".

• [Print Fonts Sample]

Prints a sample of fonts. See p.35 "Printing Font Samples".

• [Rename Printer]

Changes the machine name when viewed via Appletalk. See p.35 "Renaming the Machine".

• [Restart Printer]

Restarts the machine. See p.36 "Restarting the Machine".

◆ [Utility] menu

• [Download PostScript File]

Downloads a PostScript file. See p.36 "Downloading PostScript Files".

• [Select Zone]

Changes the zone the printer belongs to via Appletalk. See p.36 "Selecting the Zone".

• [Display Printer Status]

Displays the status of the printer. See p.37 "Displaying the Machine Status".

• [Launch Dialogue Console]

Creates and edits a PostScript file, and downloads it to the printer. See p.37 "Launching the Dialog Console".

Downloading PS Fonts

You can download the PS fonts to the machine memory or hard disk.

#Important

- ☐ The following download procedure assumes you are a system administrator. If you are not, consult your system administrator.
- \square Resetting the machine deletes the fonts.
- ☐ Make sure the machine and Mac OS are connected in the Appletalk environment.

∅ Note

- ☐ Some fonts cannot be downloaded.
- ☐ Before downloading, read the documentation of the fonts you want to use.
- 1 On the [File] menu, click [Download PS Fonts...].
- 2 Click [Add to list].

The dialog box for selecting font files appears.

Select the desired font files, and then click [Open].

The list of selectable font names appears.

4 After adding all the fonts you want to download, click [OK].

The dialog box for selecting fonts to download appears.

- ☐ You can select [Printer's disk].
- 5 Click [Download].

The fonts are downloaded, and download status appears.

#Important

- ☐ During download, do not turn off the main power switch, operate the panel, or open/close the cover.
- 6 When the completion message appears, click [OK].
- **7** Click [Cancel].

Displaying Fonts

You can view available fonts that have been downloaded. Fonts in machine memory and the hard disk can be displayed.

- 1 On the [File] menu, click [Display Printer's Fonts...].
 The dialog box appears.
- 2 Click [Printer's disk] or [Printer's memory].
- Click [OK].

Deleting Fonts

You can delete fonts from machine memory or the hard disk.

- 1 On the [File] menu, click [Display Printer's Fonts...]. The dialog box appears.
- 2 Click [Printer's disk] or [Printer's memory].
- **3** Select the fonts you want to delete.
 - Limitation
 - ☐ You cannot delete fonts that appear in italics.
- 4 Click [Delete].

A confirmation message appears.

- Make sure the fonts you want to delete, and the name of the printer from which you want to delete the fonts, are correct.
- 6 Click [Continue], and then click [OK].
- **7** Click [**0**K].

Initializing the Hard Disk

When initializing the machine's hard disk using Printer Utility for Mac, only fonts related to PostScript will be deleted. Before initializing, make sure you know the fonts already stored in the machine.

#Important

- ☐ When initializing the machine's hard disk from the machine's control panel, all the data in the machine, such as the Document Server data, will be deleted. Before initializing, be sure to check the data on the hard disk.
- 1 On the [File] menu, click [Initialize Printer's Disk...].

A confirmation message appears.

- Note
- ☐ To cancel initialization, click [Cancel].
- 2 Click [Execute].

Initializing starts.

∰Important

- ☐ Do not turn off the main power switch until initialization finishes, otherwise it might damage the hard disk.
- 3 When the completion message appears, click [OK].

Page Setup

You can set the paper size in [Print Fonts Catalogue] and [Print Fonts Sample].

- f 1 On the [File] menu, click [Page Setup].
- **2** Select the paper size.

Printing the Font Catalog

You can print the names of fonts available on the machine.

- Limitation
- \square If you use Mac OS X, this function is not possible.
- Note
- \Box The paper selected under [Page Setup] is used.
- 1 On the [File] menu, click [Print Fonts Catalogue].
- 2 Click [Print].

Printing Font Samples

You can print samples of fonts that have been downloaded into the hard disk and memory.

- Limitation
- \square If you use Mac OS X, this function is not possible.
- **𝚱** Note
- ☐ The paper selected under [Page Setup] is used.
- 1 On the [File] menu, click [Print Fonts Sample...].
- 2 Click [Print].

Renaming the Machine

You can change the machine name that appears under Appletalk. If you connect several printers on the network, assign different names to help identify them. If several printers have the same name, a digit appears next to the machine name in the **[Chooser]** dialog box.

- 1 On the [File] menu, click [Rename Printer...].
- 2 In the [New Name:] box, enter a new name.
 - Limitation
 - ☐ You can enter up to 31 alphanumerical characters.
 - \square Do not use symbols, for example "*", ":", "=","@", " \approx ".
- 3 Click [Rename].

The machine name is changed.

- 4 Click [OK].
- **5** On the Apple menu, click [Chooser].
- 6 Click the [AdobePS] icon.
- Select the machine name renamed in step 2, and then close the [Chooser] dialog box.
 - **𝚱** Note
 - ☐ If there are several Appletalk zones, select the zone the machine belongs to.

Restarting the Machine

You can restart the machine from the **[File]** menu; however, the fonts in machine memory will be deleted.

- 1 On the [File] menu, click [Restart Printer].
- 2 Check the message that appears on the screen, and then click [Restart]. The machine restarts.



☐ If the machine is restarted, all settings return to default. For setting functions, see *Printer Reference* 2 provided as a PDF file on the CD-ROM labeled "Operating Instructions for Printer / Scanner".

Downloading PostScript Files

You can download PostScript files for printing.

- 1 On the [Utility] menu, click [Download PostScript File...].
- 2 Select the file name, and then click [Open].
- 3 Enter the log file name, and then click [Save].

The selected file is printed.



 \square Errors are recorded in the log file.

Selecting the Zone

You can change the zone the machine belongs to under Appletalk.

∰Important

- ☐ Make sure the machine and Mac OS are connected in the Appletalk environment.
- 1 On the [Utility] menu, click [Select Zone...].

The zone the printer belongs to and the available zone list appear.

- 2 Select the zone you want to switch the printer to, and then click [Change]. A confirmation message appears.
- 3 Click [Continue].

A confirmation message appears.

- 4 Click [OK].
- **5** On the Apple menu, click [Chooser].
- 6 Click the [AdobePS] icon.
- In the [Appletalk zone:] list, select the zone changed in step 2.
- In the [Select a PostScript Printer:] list, select the machine you want to use.
- **9** Close the [Chooser] dialog box.

Displaying the Machine Status

You can display current machine status.

1 On the [Utility] menu, click [Display Printer Status...].

The current machine status appears.

2 Check the current machine status.

You can check memory capacity, VM space, hard disk status, and available hard disk space. You can also see the zone the machine belongs to.

Click [OK].

Launching the Dialog Console

You can create and edit PostScript files for printing and downloading to the machine.

∰Important

- ☐ Because the "Launch Dialogue Console" is recommended for users who have a firm grasp of PostScript, you are advised to take extreme care when using it.
- ☐ Only download PostScript files to the machine.
- 1 On the [Utility] menu, click [Launch Dialogue Console...].

Open the editing screen. The Dialogue Console menu bar appears.

2 In the editor screen, enter the PostScript command.

Ø Note

- ☐ To edit a PostScript file, click [Open] on the [File] menu to open it.
- ☐ You can search or replace a character string using the [Search] menu.
- After editing the PostScript file, click [Download Top Window] on the [Console] menu to start printing.

The PostScript file is sent to the machine.

- 4 Printing is executed according to the sent PostScript file.
 - **𝒜** Note
 - ☐ The [Reply from Printer] window may open, depending on the PostScript file sent.
- On the [Console] menu, click [Return To Main Menu] to close the PostScript file.

| IN | D | EX | |
|----|---|----|--|
| | | | |

Collate, 4

D

C

Deleting a Locked Print File, 26 Deleting a Sample Print File, 20 Deleting Fonts, 33 Destination Tray, 3 Displaying Fonts, 33 Displaying the Machine Status, 37 Document Server, 7, 27 Downloading PostScript Files, 36 Downloading PS Fonts, 32 Duplex Printing, 4

Initializing the Hard Disk, 34 Installing Printer Utility for Mac, 29

Launching the Dialog Console, 37 Locked Print, 7, 21

Ρ

Page Setup, 34 Paper Source, 3 Printer Utility for Mac Functions, 31 Printing Font Samples, 35 Printing the Font Catalog, 34 Punch, 6, 12

R

Renaming the Machine, 35 Restarting the Machine, 36

S

Sample Print, 6, 14 Selecting the Zone, 36 Setting Up Options, 1 Staple, 5, 10 Starting Printer Utility for Mac, 30

Toner Saving, 5

UNIX Supplement



Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

Important

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

Notes

For use with the following machine:

• Printer/Scanner Unit Type 2238

Trademarks

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

PostScript® and Acrobat® are registered trademarks of Adobe Systems, Incorporated.

Sun, SunOS and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

HP-UX is a registered trademark of Hewlett-Packard Company.

LINUX is a trademark of Linus Torvalds.

RED HAT is a registered trademark of Red Hat, Inc.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

TABLE OF CONTENTS

| How to Read This Manual | | |
|--|----|--|
| 1. UNIX Configuration | | |
| Before Setup | 3 | |
| Using the "lp"/"lpr" commands | | |
| Using the "rsh"/"rcp"/"ftp" commands | 3 | |
| Using the Installation Shell Script | 4 | |
| Assigning the IP Address | 5 | |
| Executing the Installation Shell Script | | |
| After Executing the Installation Shell Script | 9 | |
| Printing Methods | 14 | |
| Printing with "lpr" and "lp" | | |
| Printing with "rsh", "rcp", and "ftp" | 15 | |
| Printer Status | | |
| Viewing Print Job Status with "lpq" and "lpstat" | | |
| Viewing Printer Status with "rsh" and "ftp" | | |
| Copying Information to a File | 18 | |
| Specifying the Device Option | | |
| Configuring the Device Option | | |
| Printer Language | | |
| Text Printing | | |
| Input Tray | | |
| Paper Size | | |
| Paper Type | | |
| Output Tray | | |
| Copies | | |
| Collating Duplex Printing | | |
| Binding | | |
| Orientation | | |
| Resolution | | |
| Staple | | |
| Punch, Punchhole | | |
| Symbol Set | | |
| • | | |
| INDEX | 34 | |

How to Read This Manual

Symbols

In this manual, the following symbols are used:

⚠ WARNING:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, could result in death or serious injury.

A CAUTION:

This symbol indicates a potentially hazardous situation which, if instructions are not followed, may result in minor or moderate injury, or damage to property.

* The statements above are notes for your safety.

∰Important

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

Preparation

This symbol indicates prior knowledge or preparation required before operation.

𝚱 Note

This symbol indicates precautions for operation, or actions to take after mal-operation.

Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions in which a particular function cannot be used.

This symbol indicates a reference.

[]

Keys that appear on the machine's panel display.

Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

Keys on the computer's keyboard.

1. UNIX Configuration

This section explains how to set up a network printer and check print status using UNIX.

Limitation

☐ To print from a UNIX workstation, use a file that the printer supports.

Before Setup

Setup varies depending on the printing commands. Be sure to make settings accordingly.

Using the "lp"/"lpr" commands

1 Use the installation shell script to register the device option, as well as the printer host name and IP address.

See p.4 "Using the Installation Shell Script".

2 Start printing.

See p.14 "Printing Methods".

Using the "rsh"/"rcp"/"ftp" commands

- 1 Edit the host file to register the printer host name and IP address.
- 2 Start printing.

See p.14 "Printing Methods".

For information about host file editing, see p.9 "After Executing the Installation Shell Script".

☐ If you cannot edit the host file, use the install shell script to register the host name.

Using the Installation Shell Script

The installation shell script helps the setup process. The installation shell script automates some of the tasks in configuring /etc/hosts, /etc/printcap; creating the spool directory for BSD UNIX; and running the "lpadmin" command for System V UNIX.

Preparation

The installation shell script can be used on the following workstations (it cannot be used with other types of workstations):

- SunOS 4.x.x, 5.x
- Solaris 2.x, 7, 8
- HP-UX 8.x, 9.x, 10.x, 11.x
- Redhat Linux 5.2, 6.x, 7.0, 7.1, 7.2
- UnixWare 7.1.1
- OpenServer 5.06

Depending on security settings made at installation, the "rsh"/"rcp"/"telnet" commands may not be usable with Red Hat 7.1 or later versions. Change the security level to allows use of "rsh"/"rcp"/"telnet". For more information about how to change the setting, see the operating instructions for Red Hat.

When you use NIS (Network Information Service) or DNS, you should configure the server before running the installation shell script.

For more information about the configuration utility of your operating system, see the manual that comes with that utility.

Assigning the IP Address

Preparation

Configure the machine to use TCP/IP.

- Make sure that TCP/IP on the machine is set to active. (The default is active.)
- Assign an IP address to the machine and configure the other settings required for TCP/IP.

For more information about how to make the above settings, see *Network Guide*.

Checking the IP address configuration

Follow the procedure below to make sure that the IP address is configured correctly.

• The following procedure uses the sample IP address: 192.168.15.16.

1 Enter the following:

ping 192.168.15.16

If the address is configured correctly, the following message appears:

192.168.15.16 is alive

If the address is configured incorrectly, the following message appears:

no answer from 192.168.15.16

Note

☐ When you use NIS, the IP address and host name are written to /etc/hosts on the master server. When you use DNS, the information is written to a data file on the name server. After writing the host name and IP address to the file, make sure that the configuration is correct by pinging the host.

ping host_name

☐ If the host name is registered with an IP address, the server can access the printer using its host name instead of its IP address.

Executing the Installation Shell Script

Having configured the printer IP address, follow the procedure below to execute the installation shell script and set up the workstation printing environment.

Preparation

Before executing the installation shell script, the IP address, host name and printer name, are required.

The following procedures use the sample IP address: 192.168.15.16; sample host name: "nphost"; and sample printer name: "np".

Note

- ☐ Use the "ftp" command to get the installation shell script from the printer.
- 1 Log on to the workstation as "root".
 - Note
 - ☐ If you do not log on as "root", the installation shell script will not run.
- **2** Get the installation shell script from the printer.
 - Specify the directory you want to copy the installation shell script to.
 - 2 Use the "ftp" command to connect to the printer with the IP address you just configured.

```
# ftp 192.168.15.16
Connected to 192.168.15.16
220 printer FTP server ready.
name (192.168.15.16: root:)
```

(3) When a user name is requested, leave the user name field blank and press the [RETURN] ([ENTER]) key.

```
331 Password required for root. Password:
```

4 When a password is requested, leave the password field blank and press the [RETURN] ([ENTER]) key.

```
230 User root logged in. ftp>
```

5 Enter the following to get the installation shell script:

```
ftp> get install
```

6 Close the ftp session.

```
ftp> bye
221 Goodbye.
#
```

3 Run the installation shell script.

```
# sh ./install
```

- **𝚱** Note
- ☐ Insert a period and slash before the current directory.
- 4 Enter a number to select the workstation operating system you are using.

```
Network printer install shell
Copyright RICOH CO.,LTD. 1994-2003
Select your workstation OS type
1.SunOS 4.x.x
2.Solaris 2.x, Solaris 7-8 (SunOS5.x)
3.HP-UX
4.UnixWare
5.Linux
6.OpenServer
7.Quit
Enter <1-7>:
```

- **𝚱** Note
- ☐ SunOS, UnixWare, and OpenServer appear on the screen, but they are not supported. Use Solaris, HP-UX, or Linux.
- \square If you select "7", the installation shell script ends.
- **5** Enter the printer's IP address.

```
Enter Printer host IP address <xxx.xxx.xxx.xxx> [re-
turn=skip]:
192.168.15.16
```

- Note
- ☐ The IP address will be added to the /etc/hosts file.
- ☐ If the host name of the printer has already been configured, press the **[RETURN]** (**[ENTER]**) key. Nothing will be added to the /etc/hosts file.
- **6** Enter the printer's host name.

Enter Printer host name : nphost

- Note
- ☐ The host name will be added to the /etc/hosts file.
- ☐ If no IP address was entered in step **⑤**, nothing is added to the /etc/hosts file.

7 Configure the printer name.

Enter logical printer name [default nphost prn]

If you want to use the default name, press the **[RETURN]** (**[ENTER]**) key. Enter a new name if you want to use a different one.

Note

- ☐ The host name entered in step **⑤** followed by "_prn" appears in "default".
- **8** Set the print option.

Enter remote printer name [default lp]:

- Press the **[RETURN]** (**[ENTER]**) key, and printing with PCL or PostScript 3 is enabled.
- If you want to set the device option, enter the option parameter.

Enter remote printer name [default lp]:tray=tray1

For more information about the device option, see p.19 "Specifying the Device Option".

• If you enter "text", text printing is enabled.

If you enter "text", printing with PCL and PostScript 3 is disabled.

Enter remote printer name [default lp]:text

Limitation

- ☐ You can enter up to 14 characters for HP-UX 11.0, 256 for Solaris 8 and Red Hat Linux 7.0, and 51 for Red Hat Linux 6.2.
- □ When printing with the "lp" command, use "_" instead of "=" and ";" instead of "," for operating systems that cannot use "=" and "," such as Solaris 2.5 or later.

After setup with the installation shell script is complete, and if you entered the IP address in step **5**, the following message appears:

hosts file is modified

- **2** Do a test print to make sure that the settings are correct.
 - # lpr -Pnp file_name
 - # lp -dnp file name

For more information about the "lpr" and "lp" commands, see p.14 "Printing Methods".

1

Deleting the printer

To print using the "lp" or "lpr" commands, the option specified when the installation shell script is executed is used. Change the option in accordance with the workstation you are using.

♦ BSD UNIX workstation, Linux

Delete the printer entry from /etc/printcap, and then execute the installation shell script again. Select options during the setup process.

Alternatively, search the printer entry from /etc/printcap, and change its "rp" capability to option setting.

Solaris, HP-UX

Delete the printer entry, and then execute the installation shell script again. Select options during the setup process. To delete the printer entry, follow the procedure below:

- ① Stop the scheduler.
 - # /usr/sbin/lpshut
- ② Delete the printer.
 - # /usr/sbin/lpadmin -x printer name
- ③ Restart the scheduler.
 - # /usr/lib/lpsched

After Executing the Installation Shell Script

The printing environment is automatically set up when the installation shell script is executed.

This section describes setup contents when the installation shell script is executed under Red Hat Linux, Solaris, and HP-UX.

Linux

Adding the IP address and host name to the /etc/hosts file

The following line is added to the /etc/hosts file. The IP address and printer host name previously entered in the installation script will be used:

192.168.15.16 nphost # Network Printer

• "192.168.15.16" is the IP address, "nphost" is the host name, from # to the end of the line is the comment.

- ☐ The /etc/hosts file contains a list of the IP addresses and names of all hosts communicating on the network. Each entry is delimited with a space or a tab, and each line is separated with a return.
- ☐ If you do not use NIS or DNS, you must enter the IP address and host name of each workstation using the network printer in the /etc/hosts file.

Adding an entry to the /etc/printcap file

The following entry is added to the /etc/printcap file, which is the configuration for printing with the "lpr" command. In order to use the "lpr" command to print, you need to edit the /etc/hosts file, add an entry for the network printer to the /etc/printcap file, and create a spool directory:

```
##PRINTTOOL3## REMOTE
np | Network Printer:
    :rm=nphost:
    :rp=option:
    :sd=/var/spool/lpd/npd:
    :lf=/var/log/npd-errs:
    :sh:
    :mx#0:
```

- ☐ The /etc/printcap file is used to register the name and attributes of a printer. You must make an entry for the network printer in the /etc/printcap file of all workstations using the network printer.
- ☐ You must make an entry for each printer option when using the same printer.
- ☐ Each entry is separated into several fields by colons. Each entry begins with a colon, followed by the entry, and then ends with a colon, a back slash, and finally a return.
- ☐ The first line of the field is the name of the printer. Use this name when logging on to a network printer from a workstation. You can define several different names by separating each name with the " | " character.
- ☐ The second and following lines contain the printer's attributes. Attributes are represented by two-character names referred to as capabilities. For more information about capabilities, see the following table:

| Capability | Explanation | Value required for the network printer. |
|------------|---|---|
| rm | Host name of the printer. | The host name registered with the/etc/hosts file. |
| rp | Optional specification. "lp" will be assigned, if the option is not used. | Select options for printing. For more information about available options, see p.19 "Specifying the Device Option". |
| sd | Path name of the spool directory. | Path name of the spool directory to be created. |
| lf | Path name of the log file. | Path name of the log file. For example /var/log/lpd-errs. |
| mx | Maximum file size which the directory can copy. When set to 0, the size is unlimited. If nothing is entered, the size is set to 1024 k. | None, or something suitable. |

1

Making the spool directory

Create a spool directory under /var/spool/lpd. The name of the spool directory should be the name of the printer followed by "d".

𝒯 Note

- ☐ The spool directory is used to control print job data. For example, when a print job is created, a temporary copy of the data used is created in the spool directory. All workstations accessing the network printer need to have a network printer spool directory.
- ☐ A spool directory should be made for every network printer listed in the /etc/printcap file.
- ☐ The spool directory should normally be made under /var/spool/lpd and the name should match that listed under the "sd" capability in /etc/print-cap. Change the owner and group of the directory to "root" and "lp". The following examples show how to make a /var/spool/lpd/npd spool directory:

```
# cd /var/spool/lpd
# mkdir npd
# chown root npd
# chgrp lp npd
```

Making the log file

Error messages are logged to a file created in the /var/log directory. The log file name is the printer name followed by "d-errs".

- ☐ The log file is used for logging errors or warning messages by the UNIX workstation.
- ☐ The log file should be made for every network printer listed in the /etc/printcap file.
- ☐ The log file should normally be made under /var/log directory and the name should match that listed under the lf capability in /etc/printcap. Change the owner and group of the log file to "root" and "lp". The following examples show how to make a /var/log/npd-errs file:

```
# cd /var/log
# touch npd-errs
# chown root npd-errs
# chgrp lp npd-errs
```

Solaris

Adding the IP address and host name to the /etc/hosts file

The following line is added to the /etc/hosts file. The IP address and printer host name previously entered in the installation script will be used.

192.168.15.16 nphost # Network Printer

• "192.168.15.16" is the IP address, "nphost" is the host name, from # to the end of the line is the comment.

𝚱 Note

- ☐ The /etc/hosts file contains a list of IP addresses and names of all hosts communicating on the network. Each entry is delimited with a space or a tab, and each line is separated with a return.
- ☐ If you do not use NIS or DNS, you must enter the IP address and host name of each workstation using the network printer in the /etc/hosts file.

Registering the printer

The installation shell script registers the printer as a remote printer using the procedure below:

- ① If your workstation is Solaris 2.5.1, register the print server and print client to the print service.
 - # lpsystem -t bsd -R 0 -y "Network Printer" nphost
- ② Register the printer as a remote printer.
 - # lpadmin -p np -s nphost!option -T dump -I any
 - "np" is the printer name, "nphost" is the host name. For more information about "option", see p.19 "Specifying the Device Option".
 "lp" will be assigned if the option is not used.
 When printing with the "lp" command, use "_" instead of "=" and ";" instead of "," for operating systems that cannot use "=" and "," such as Solaris 2.5 or later.
- ③ If your workstation is Solaris 2.5.1, set the print job to active so it can be put in the print queue.

/usr/lib/accept np

④ If your workstation is Solaris 2.5.1, set the print job to active to print.

/usr/lib/enable np

1

HP-UX

Adding the IP address and host name to the /etc/hosts file

The following line is added to the /etc/hosts file. The IP address and printer host name previously entered in the installation script will be used:

192.168.15.16 *np* # Network Printer

• "192.168.15.16" is the IP address, "np" is the host name, the comment comes after the #.

Note

- ☐ The /etc/hosts file contains a list of IP addresses and names of all hosts communicating on the network. Each entry is delimited with a space or a tab, and each line is separated with a return.
- ☐ If you do not use NIS or DNS, you must enter the IP address and host name of each workstation using the network printer in the /etc/hosts file.

Registering the printer

The installation shell script registers the printer as a remote printer using the procedure below:

① Stop the scheduler.

/usr/lib/lpshut

② Register the printer.

/usr/lib/lpadmin -Pnp -v/dev/null -mrmodel

-ormnphost -orpoption -ob3

• "np" is the printer name, "nphost" is the host name. For more information about "option", see p.19 "Specifying the Device Option".

"lp" will be assigned if the option is not used.

③ Set the printer so the print job is put in the print queue.

/usr/lib/accept np

④ Set the printer to perform the print job.

/usr/lib/enable np

(5) Restart the scheduler.

/usr/lib/lpsched

Printing Methods

Printing with "lpr" and "lp"

the machine's total memory size.

Execute one of the following commands according to type of workstation used:

```
BSD UNIX workstation, Linux
  % lpr -Pprinter name file name [file name...]
  For example:
  (printer name: "np"; file names: "file1" and "file2")
  % lpr -Pnp file1 file2
Solaris, HP-UX
  % lp -dprinter name file name [file name...]
  For example:
  (printer name: "np"; file names: "file1" and "file2")
  % lp -dnp file1 file2
Note
☐ "printer_name" is the name entered when executing the installation shell
  script.
\square You can use wild cards ("*" or "?") as the file name.
☐ The "print session full" appears when the maximum number of print re-
  quests is reached (max. 5 sessions - Job Spool setting available). Try printing
  again when the number of requests is less than five. You can check the
  number of print requests using telnet. For more information about using tel-
  net, see Network Guide.
☐ The number of print sessions does not change, even if you increase or reduce
```

Printing with "rsh", "rcp", and "ftp"

You can also print using the "rsh", "rcp" and "ftp" commands.

Ø Note

- ☐ Print using a format the printer supports.
- ☐ Try to print again when the number of requests is zero.
- ☐ The "print session full" appears when the maximum number of print requests is reached.
- ☐ The maximum number of print sessions varies depending on the command. When using the "rsh" or "rcp" command, the maximum number of print sessions is five; when using the "ftp" command, the number is three.

rsh

```
% rsh host name print < file name
```

For example:

(host name: "nphost"; file name: "file1")

% rsh nphost print < file1

Note

- \square "host_name" is the name entered when executing the installation shell script.
- ☐ If you are using HP-UX, use the "remsh" command instead of "rsh".

rcp

To specify and print the file

```
% rcp file_name [file_name...] host_name:
For example:
(host name: "nphost"; file names: "file1" and "file2")
% rcp file1 file2 nphost:
```

To print all of the files in a directory

```
% rcp -r directory_name host_name:
For example:
(host name: "nphost"; directory name: "directory")
% rcp -r directory1 nphost:
```

- \square "host_name" is the name entered when executing the installation shell script.
- $\hfill \square$ You can use wild cards ("*" or "?") as the file name.

ftp

Use the "put" or "mput" commands depending on the number of files to be printed.

- Limitation
- ☐ File names cannot contain "=", ",",",", or ";".
- ☐ It is not possible to set options with the "mput" command:
- ❖ To print one file

```
ftp> put file name
```

❖ To print several files

```
ftp> mput file name [file name...]
```

Ø Note

☐ You can use wild cards ("*" or "?") for the file name with the "mput" command.

The following procedure shows an example of how to print a file using the "ftp" command.

- 1 Start ftp using the IP address or host name of the printer.
 - % ftp IP address
- 2 Enter the user name. Leave the password field blank and press the [RETURN] ([ENTER]) key.

Name:

Password:

3 Set the file transfer mode to binary.

ftp> bin

- **𝚱** Note
- ☐ If the file transfer mode is not set to binary, the image may not be printed correctly.
- 4 Print the file.
 - Note
 - $\hfill\Box$ For example, to print the file named "file1":

ftp> put file1

 \square For example, to print the two files named "file1" and "file2":

ftp> mput file1 file2

5 Exit ftp.

ftp> bye

Printer Status

You can use the following commands to have information and printer status displayed or copied to a file.

Use the "lpq" or "lpstat" command to display printer status, or information about print jobs.

Use the "rsh", "rcp", or "ftp" commands to get more detailed information from the printer.

Viewing Print Job Status with "Ipq" and "Ipstat"

```
BSD UNIX workstation, Linux
```

```
% lpq -Pprinter_name
For example:
(printer name: "np")
% lpq -Pnp
```

System V UNIX, Solaris, HP-UX

```
% lpstat -o printer_name
For example:
(printer name: "np")
% lpstat -o np
```

Ø Note

☐ If you are using HP-UX, do not put a space between "-o" and "printer name".

Viewing Printer Status with "rsh" and "ftp"

Use the "rsh" or "ftp" command to display printer status or information about print jobs using specified parameters.

You can use these commands for BSD and System V UNIX.

```
Note
```

 \square If your workstation is HP-UX, use the "remsh" command instead of "rsh".

```
% rsh host_name parameter
```

```
% ftp host_name
User: user_name
password:
ftp> get parameter -
```

Note

- ☐ Leave the user name and password field blank and press the **[RETURN]** (**[ENTER]**) key.
- \square "-" indicates standard output. It will be displayed on screen if standard output has not been specified.

Parameters that can be used with "rsh", "rcp", and "ftp" are as follows:

| Parameter | Information returned | |
|-----------|--|--|
| stat | Status of the printer. Information about print jobs. | |
| info | Information about the paper tray, output tray, and printer language. | |
| prnlog | Record of the last 20 jobs printed. | |
| syslog | Record of messages about the network interface board. | |

Copying Information to a File

Use the "rcp" or "ftp" command to copy information about specified parameters to a file.

You can use these commands for BSD and System V UNIX.

Note

 $\hfill \square$ The same parameters are used as those above.

```
% rcp host_name:parameter file_name
```

```
% ftp host_name
User: user_name
password:
```

ftp> get parameter file name

𝒯 Note

☐ Leave the user name and password field blank and press the 【RETURN】 (【ENTER】) key.

1

Specifying the Device Option

With the following options, you can print with specific printer functions.

Configuring the Device Option

The configuration of the print option varies, depending on printing commands.

- rsh
 - % rsh host name print option1=value1,... < file name
- rcp
 - % rcp file name host name:option1=value1,...
- ftp

```
ftp> put file name option1=value1,...
```

"host_name" is the printer host name. "file_name" is the file name you want to print. The device option is specified in the form of "option=value". For more information about types of device options and values, see the following explanations.

For example, the following settings are for printing with "rsh", "rcp", and "ftp": switch to PostScript 3, use paper from paper tray 1, set the number of copies to 3 sets, and print with the resolution set to 600 dpi (host_name: "nphost"; file_name: "file1").

- rsh
 - % rsh nphost print filetype=postscript,tray=tray1,copies=3,resolution=600 < file1</pre>
- rcp
 - % rcp file1 nphost:filetype=postscript,tray=tray1,copies=3,resolution=600
- ftp

```
ftp> put file1 filetype=postscript,tray=tray1,cop-
ies=3,resolution=600
```

Note

- ☐ Multiple options must be separated by commas (,). Do not use spaces.
- ☐ When the printing file contains the PCL, PJL, PostScript 3 commands control of the option, the command takes priority.
- □ Enter the option using the "lp" or "lpr" command when the shell script is executed. The option settings made here are configured as default. You must create another printer if you want to change printer option settings. For more information about changing the configured option, see p.9 "Deleting the printer".
- □ When printing with the "lp" command, use "_" instead of "=" and ";" instead of "," for operating systems that cannot use "=" and "," such as Solaris 2.5 or later.

| _ |
|---|
| |

Limitation

- ☐ The optional character strings the printer can recognize contain a maximum of 512 bytes.
- ☐ The number of available characters used as options is limited, depending on operating systems.

Using the "cd" command with ftp

For printing with ftp, if the option is specified using the "cd" command, it becomes available whenever the "put" or "mput" command is used.

ftp> cd option

| A) | Note |
|----|------|
| | note |

☐ The "pwd" command shows the current option settings.

ftp> pwd

List of the device options

| Device option | Value | Function summary |
|---------------|---|---|
| filetype | pcl, postscript (rps) | Specifies the printer language for printing. |
| filter | text | Specifies the text printing. |
| tray | tray1~tray4, lct, bypass, all | Specifies the input tray. |
| paper | a3wide, a3~a6, jisb4, jisb5, ledger, letter, halfletter, legal, executive, fgl, foolscap, folio, com10, monarch, c6, c5, dl, k8, k6, custom | Specifies the paper size. |
| mediatype | plain, letterhead, transparency, recycled, color, special, thick, preprinted, plainduplexbacks, thickduplexbacks, plainorrecycled | Specifies the paper type. |
| outbin | upper, lower, lower2, lower3, finisherproof, finishershift, finisherbooklet | Specifies the output tray. |
| copies | Number of copies (1-999) | Specifies the number of copies. |
| qty | Number of collated sets (1-999) | Specifies the number of sets to collate. |
| duplex | on, off | Specifies whether to use duplex printing. |
| binding | longedge, shortedge | Specifies the binding side for duplex printing. |

| Device option | Value | Function summary |
|---------------|--|--------------------------------------|
| orientation | portrait, landscape | Specifies the paper feed direction. |
| resolution | 300, 600, 1200 | Specifies the print resolution. |
| staple | off, lefttop, righttop, left- topslantport, lefttopslant- land, righttopslantport, righttopslantland, lefttopvert- port, lefttopvertland, right- topvertport, righttopvertland, lefttophorizport, lefttophoriz- land, left2port, left2land, right2port, right2land, top2port, top2land, booklet | Specifies the staple position. |
| punch | off, leftport, leftland, right- port, rightland, topport, top- land | Specifies the punch position. |
| punchhole | jp2, us2, us3, eu4, neu4 | Specifies the punch hole. |
| symbol set | desktop, iso4, iso6, iso11, iso15, iso17, iso21, iso60, iso69, isol1, isol2, isol5, legal, math8, mspubl, pc8, pc850, pc852, pc8dn, pc8tk, pifont, psmath, pstext, roman8, vnintl, vnmath, vnus, win30, win11, win12, win15 | Specify the set of print characters. |

Printer Language

Specify a printer language to print in.

filetype=printer language

fil=printer language

| Printer language | Value |
|------------------|-------------------|
| PCL 5c | pcl |
| PostScript 3 | postscript or rps |

The following sample shows how to print with PostScript 3 (host name: "nphost"; file name: "file1"):

- rch
 - % rsh nphost print filetype=postscript < file1
- rcp
 - % rcp file1 nphost:filetype=postscript
- ftp

ftp> put file1 filetype=postscript

Text Printing

Set this function when printing text files directly.

filter=text

flt=text

The following sample shows how to print text files directly.

- rsh
 - % rsh nphost print filter=text < file1
- rcp
 - % rcp file1 nphost:filter=text
- ftp

ftp> put file1 filter=text

Input Tray

Specify a default input tray.

Limitation

☐ Only installed input trays are available.

☐ Before printing a PostScript 3 file, the input tray option must be set to "on".

tray=value of input tray

| Input tray | Value |
|---------------------------|--------|
| Tray 1 | tray1 |
| Tray 2 | tray2 |
| Tray 3 | tray3 |
| Tray 4 | tray4 |
| Large Capacity Tray (LCT) | lct |
| Bypass tray | bypass |
| Auto Tray Select | all |

The following sample shows how to print from tray 2 (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print tray=tray2 < file1
- rcp
 - % rcp file1 nphost:tray=tray2
- ftp

ftp> put file1 tray=tray2

Paper Size

Specify the paper size.

Limitation

 $\hfill \square$ Only the loaded paper sizes are available.

paper=value of paper size

| Paper size | Value |
|--------------------------------------|------------|
| A3 wide | a3wide |
| A3 | a3 |
| A4 | a4 |
| A5 | a5 |
| A6 | а6 |
| B4JIS (Japanese Industrial Standard) | jisb4 |
| B5JIS | jisb5 |
| 11 × 17 | ledger |
| $8^1/_2 \times 11$ | letter |
| $5^{1}/_{2} \times 8^{1}/_{2}$ | halfletter |
| $8^{1}/_{2} \times 14$ | legal |
| $7^{1}/_{4} \times 10^{1}/_{2}$ | executive |
| 8×13 | fgl |
| $8^{1}/_{2} \times 13$ | foolscap |
| $8^1/_4 \times 13$ | folio |
| Com10 | com10 |
| Monarch | monarch |
| C6 Env | с6 |
| C5 Env | c5 |
| DL Env | dl |
| K8 | k8 |
| K16 | k16 |
| Custom size | custom |

The following sample shows how to print using A4 paper (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print paper=a4 < file1
- rcp
 - % rcp file1 nphost:paper=a4
- ftp

ftp> put file1 paper=a4

Paper Type

Specify the paper type.

Limitation

- ☐ This function is only for PostScript 3.
- ☐ Only the loaded paper types are available.

mediatype=value of paper type

| Paper type | Value |
|-------------------------------|------------------|
| Plain paper | plain |
| Letterhead | letterhead |
| OHP transparency | transparency |
| Recycled paper | recycled |
| Color paper | color |
| Special paper | special |
| Thick paper | thick |
| Preprinted paper | preprinted |
| Plain duplex paper (back) | plainduplexbacks |
| Thick duplex paper (back) | thickduplexbacks |
| Plain paper or Recycled paper | plainorrecycled |

The following sample shows how to print using recycled paper (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print mediatype=recycled < file1
- rcp
 - % rcp file1 nphost:mediatype=recycled
- ftp
 - % ftp> put file1 mediatype=recycled

Output Tray

Specify the output tray.

outbin=value of output tray

Limitation

☐ Only installed output trays are available.

Ø Note

- ☐ The output tray value corresponds to the ID number of the output tray obtained from the printer information (for example: "info" command in ftp, "info" command in telnet. For more information about telnet, see *Network Guide*.).
- ☐ You can select an output tray using alphabetical letters instead of the output tray's ID number. For more printer information, see *Printer Reference* 2.

| Output tray | Value |
|-----------------------|-----------------|
| Internal tray 1 | upper |
| External tray | lower |
| Left tray 1 | lower2 |
| Left tray 2 | lower3 |
| Finisher upper tray | finisherproof |
| Finisher shift tray | finishershift |
| Finisher booklet tray | finisherbooklet |

The following sample shows how to print from internal tray 1 (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print outbin=upper < file1
- rcp
 - % rcp file1 nphost:outbin=upper
- ftp

ftp> put file1 outbin=upper

П

Copies

Specify the number of copies.

copies=number of copies (1 to 999)

Limitation

☐ Do not specify "copies" and "qty *1" commands at the same time.

*1 "qty" is a collate function.

The following sample shows how to print 10 copies (host name: "nphost"; file name: "file1"):

• rsh

% rsh nphost print copies=10 < file1

• rcp

% rcp file1 nphost:copies=10

ftp

ftp> put file1 copies=10

Collating

Specify the number of collated sets.

qty=number of collated sets (1 to 999)

Limitation

 \square This function is only for PostScript 3.

☐ Do not specify "qty" and "copies" commands at the same time.

The following sample shows how to print 10 copies using the collate function (host name: "nphost"; file name: "file1"):

rsh

% rsh nphost print qty=10 < file1

rcp

% rcp file1 nphost:qty=10

ftp

ftp> put file1 qty=10

Duplex Printing

Specify whether to use duplex printing.

𝒯 Note

- ☐ Before specifying the binding option, the duplex option must be set to on.
- ☐ Data and paper volume affect the completion of the print job.

duplex=value of duplex printing

| Duplex printing | Value |
|-----------------|-------|
| enable | on |
| disable | off |

For more information about available paper size for duplex printing, see *General Settings Guide*.

The following sample shows how to set duplex printing (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print duplex=on,binding=longedge < file1</pre>
- rcp
 - % rcp file1 nphost:duplex=on,binding=longedge
- ftp

ftp> put file1 duplex=on,binding=longedge

Binding

Specify the binding side for duplex printing.

Ø Note

- ☐ Before specifying the binding option, the duplex option must be set to "on".
- ☐ Data and paper volume affect completion of the print job.

binding=value of binding

| Binding direction | Value |
|-------------------|-----------|
| Longedge | longedge |
| Shortedge | shortedge |

The following sample shows how to set duplex printing and long-edge binding (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print duplex=on,binding=longedge < file1
- rcp
 - % rcp file1 nphost:duplex=on,binding=longedge
- ftp

ftp> put file1 duplex=on,binding=longedge

Orientation

Specify the paper orientation.

Limitation

☐ Only the selected PCL 5c from the printer language option is available.

orientation=feed direction (portrait or landscape)

| Orientation | value |
|-------------|-----------|
| Portrait | portrait |
| Landscape | landscape |

The following sample shows how to print the paper vertically using the orientation function (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print orientation=portrait < file1
- rcp
 - % rcp file1 nphost:orientation=portrait
- ftp

ftp> put file1 orientation=portrait

Resolution

Specify the printing resolution.

resolution=value of resolution

| Resolution | Value |
|------------|-------|
| 300 dpi | 300 |
| 600 dpi | 600 |
| 1200 dpi | 1200 |

The following sample shows how to print with 600 dpi and better quality. (host name: "nphost"; file name: "file1"):

- rsh
 - % rsh nphost print resolution=600 < file1
- rcp
 - % rcp file1 nphost:resolution=600
- ftp

ftp> put file1 resolution=600

Staple

Specify the staple position.

Limitation

- ☐ Before executing the "staple" command, make sure the number of collated sets and the output tray is specified.
- \square When using this option, the optional finisher unit is required.
- □ When printing with this option, be sure to specify the optional finisher using "finisherproof" or "finishershift" as the value, for example "outbin=finisherproof". For more information about the optional finisher unit, see p.25 "Output Tray".

Ø Note

□ Available staple positions vary depending on the type of output tray you have installed. For more information about stapling, see *Printer Reference* 2 (PDF file) on the CD-ROM labeled "Operating Instructions for Printer / Scanner".

staple=value of staple position

| Position | Value |
|-----------------------|-------------------------------------|
| Off | off |
| Upper left | lefttop |
| Upper right | righttop |
| Upper left slant | lefttopslantport lefttopslantland |
| Upper left vertical | lefttopvertport lefttopvertland |
| Left 2 | left2port left2land |
| Right 2 | right2port right2land |
| Upper right vertical | righttopvertport righttopvertland |
| Upper right slant | righttopslantport righttopslantland |
| Upper 2 | top2port top2land |
| Upper left horizontal | lefttophorizport lefttophorizland |
| Booklet | booklet |

The following sample shows how to print with the staple on the upper left using finisher shift tray (host name: "nphost"; file name: "file1"):

• rsh

% rsh nphost print staple=lefttop,outbin=finishershift <
file1</pre>

- rcp
 - % rcp file1 nphost:staple=lefttop,outbin=finishershift
- ftp

ftp> put file1 staple=lefttop,outbin=finishershift

Punch, Punchhole

Specify the punch position and the number of punch holes.

Limitation

- ☐ Before executing the "punch" command, make sure the number of collated sets, the output tray, and number of punch holes is specified.
- \Box When using this option, the optional finisher unit is required.
- □ When printing with this option, be sure to specify the optional finisher using "finisherproof" or "finishershift" as the value, for example "outbin=finisherproof". For more information about the optional finisher unit, see p.25 "Output Tray".

Ø Note

- ☐ Available punch positions may vary depending on the type of output tray you have installed. For more information about punching, see *Printer Reference* 2 (PDF file) on the CD-ROM labeled "Operating Instructions for Printer / Scanner".
- ☐ When "punchhole" is not specified, the machine executes the punch function using the default number of punch holes. The default number of punch holes is marked with "*" in the table below.
- ☐ If "punchhole" is not specified correctly, the machine does not execute the function.

punch=value of punch position

| Position | Value |
|----------|---------------------|
| Off | off |
| Left | leftport leftland |
| Right | rightport rightland |
| Тор | topport topland |

punchhole=value of punchhole

Available numbers of punch holes may vary depending on the type of Punch Kit you have installed. Specify an appropriate value referring to the table below.

| Number of punch holes | Name of punch kit | Value |
|-----------------------|------------------------|-------|
| 2 | Punch Kit Type 1045 EU | jp2 |
| | Punch Kit Type 1045 NA | us2 |
| 3 | | us3 |
| 4 | Punch Kit Type 1045 EU | eu4 |
| | Punch Kit Type 1045 SC | neu4 |

The following sample shows how to print with four punch holes on the left using tray finisher 1 (host name: "nphost"; file name: "file1").

- rsh
 - % rsh nphost print punch=leftport,punchhole=eu4,outbin=finisherproof < file1</pre>
- rcp
 - % rcp file1 nphost:punch=leftport,punchhole=eu4,outbin=finisherproof
- ftp

ftp > put file1 punch=leftport,punchhole=eu4,outbin=finisherproof

Symbol Set

Specify the set of print characters for the chosen font.

Limitation

☐ Only the selected PCL 5c from the printer language option is available.

symset=value of font

| Font | Value |
|---------|---------|
| Desktop | desktop |
| ISO 4 | iso4 |
| ISO 6 | iso6 |
| ISO 11 | iso11 |
| ISO 15 | iso15 |
| ISO 17 | iso17 |
| ISO 21 | iso21 |
| ISO 60 | iso60 |
| ISO 69 | iso69 |
| ISO L1 | isol1 |
| ISO L2 | isol2 |
| ISO L5 | isol5 |
| Legal | legal |
| Math-8 | math8 |
| MS Publ | mspubl |
| PC-8 | pc8 |
| PC-850 | pc850 |
| PC-852 | pc852 |

| Font | Value |
|----------|--------|
| PC-8 D/N | pc8dn |
| PC8-TK | pc8tk |
| Pifont | pifont |
| PS Math | psmath |
| PS Text | pstext |
| Roman-8 | roman8 |
| VN Intl | vnintl |
| VN Math | vnmath |
| VN US | vnus |
| Win 3.0 | win30 |
| Win L1 | winl1 |
| Win L2 | winl2 |
| Win L5 | winl5 |

The following sample shows how to print using the ISO 4 character set (host name: "nphost"; file name: "file1"):

• rsh

% rsh nphost print symset=iso4 < file1

• rcn

% rcp file1 nphost:symset=iso4

• ftp

ftp> put file1 symset=iso4

INDEX

| В | L | |
|--|--|--|
| Binding Option, 28 BSD UNIX workstation Deleting the printer, 9 Printer Status, 17 Printing Method, 14 | Linux Deleting the printer, 9 Printer Status, 17 Printing Method, 14 lp Printing, 14 lpr Printing, 14 | |
| Collating Option, 26 configuration UNIX, 3 Copies Option, 26 | Orientation Option, 28 Output Tray Option, 25 | |
| D | Р | |
| Deleting the printer, 9 Device Option, 19 Duplex Printing Option, 27 | Paper Size Option, 23 Paper Type Option, 24 Printer Language | |
| <u>F</u> | Option, 21 | |
| ftp Printing, 16 | Printer Status, 17 ftp, 17 rsh, 17 | |
| HP-UX Deleting the printer, 9 Printer Status, 17 Printing Method, 14 | Printing Method, 14 Printing with rsh, rcp, ftp, 15 Punch, Punchhole Option, 31 R | |
| | rcp | |
| Input Tray Option, 22 Installation Shell Script, 4, 6, 9 IP Address, 5 | Printing, 15 Resolution Option, 29 rsh Printing, 15 | |

S

```
Solaris

Deleting the printer, 9
Printer Status, 17
Printing Method, 14
Staple
Option, 30
Symbol Set
Option, 32
System V UNIX
Printer Status, 17

T

Text Printing
Option, 22

U
```

UNIX, 3