

SR790 (B408)

(RoHS Compliant Materials)

SR790 (B408)


PARTS CATALOG

This catalog gives the numbers and names of parts on this machine.

1.EXTERIOR (B408)	2
2.TRANSPORT SECTION (B408)	4
3.PAPER EXIT SECTION 1 (B408)	6
4.PAPER EXIT SECTION 2 (B408)	8
5.VERTICAL TRANSPORT (B408).....	10
6.STAPLE SECTION 1 (B408).....	12
7.STAPLE SECTION 2 (B408).....	14
8.STAPLE SECTION 3 (B408).....	16
9.SHIFT TRAY DRIVE (B408).....	18
10.DRIVE SECTION (B408).....	20
11.ELECTRICAL SECTION (B408)	22
12.DECALS AND DOCUMENTS (B408)	24
PARTS INDEX	27

July ,01' 2005

1.EXTERIOR (B408)




1.EXTERIOR (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 6141	Rear Cover	1
2	B408 6151	Left Upper Cover	1
3	B408 3412	Slide Tray	2
4	A628 3115	Knob Screw - M4	1
5	B408 3411	Tray	1
6	B408 6161	Left Lower Cover	1
7	B408 1314	Caster:250N	4
8	B408 1429	Ground Plate Bracket	1
9	G020 1391	Screw - M3X4.5	2
10	B408 6131	Left Inner Cover	1
11	B408 1241	Guard - Side Plate Front	1
12	B408 6124	Hinge - Door Lower	1
13	B408 7151	Decal - Misfeed Removal	1
14	B408 6121	Front Cover	1
15	AG07 0512	Magnetic Catch:Ass'y	1
16	B408 6172	Cover:Right Lower	1
17	B408 6122	Hinge - Door Upper	1
18	B408 7171	Decal - Staple	1
19	B408 6111	Upper Cover	1
20	B408 2192	Guide Plate - Connecting Upper	1
21	B408 1418	Mylar - Rear Joint Bracket	1
22	B408 1431	Flat Screw:Coupling	4
23	B408 1414	Bracket - Coupling Rear	1
24	B408 1425	Bracket - Coupling Front	1
25	B408 2191	Guide Plate - Connecting Lower	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3008N	Tapping Screw - M3x8	

2.TRANSPORT SECTION (B408)




2.TRANSPORT SECTION (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2271	Pulley - T24	1
2	AA08 2101	Bushing - 6x10x6	6
3	B408 2532	Lever - Paper Guide Upper	1
4	G020 5626	Push Switch	1
5	B408 2221	Transfer Roller - Upper	1
6	B408 2231	Exit Roller - Proof Tray	1
7	B408 2211	Transfer Roller	1
8	B408 5315	Harness - Connecting	1
9	AW02 0170	Photointerruptor:Overflow:CT	1
10	A859 3425	Spring Plate	2
11	A859 3420	Middle Driven Roller	2
12	B408 2157	Left Guide Plate - Entrance MB1	1
13	B408 2152	Guide Plate - Entrance	1
14	AW02 0169	Photointerruptor - OS - 580213-703	1
15	A548 1317	Lever Cushion	1
16	B408 2723	Upper Paer Guide	1
17	B408 2722	Spring - Upper Paper Guide	1
18	AG07 0514	Magnet Catch:Ass'y	2
19	B408 2715	Discharge Brush	1
20	B408 2731	Arm - Top Cover	1
21	5447 2681	Snap Ring	1
22	B408 2711	Top Cover	1
23	AF04 0558	Driven Roller	4
24	A688 3960	Roller Holder	2
25	B408 2281	Knob - Transfer Roller	1
26	B408 7112	Decal - Knob R2	1
27	B408 1231	Angle - Front Side Plate	1
28	B408 2751	Ground Plate:Exit:Proof Tray	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	1105 0511	Harness Clamp - LWS-0306ZC	
104	1105 0522	Edge Saddle - LES0510	

3.PAPER EXIT SECTION 1 (B408)




3.PAPER EXIT SECTION 1 (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2314	Arm - Roller Slide	1
2	B408 2313	Pulley - T24	1
3	AA08 2101	Bushing - 6x10x6	1
4	B408 5355	Sensor Relay Harness - 280mm	1
5	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
6	B408 2841	Bracket - Home Position Sensor	1
7	B408 2833	Shaft - Worm Wheel	1
8	B408 2832	Worm Wheel - Z20	1
9	B408 2861	Arm - Guide Plate	1
10	5447 2681	Snap Ring	1
11	B408 2831	Gear - Z53	1
12	B408 2821	Stay - Guide Plate	1
13	AX05 0244	Stepper Motor:MM42:0.85A	1
14	A681 2742	Driven Exit Roller	2
15	A666 4210	Shaft - Exit Roller	1
16	B408 2812	Discharge Brush:Exit:Open And C	1
17	B408 2852	Spring - Guide Plate Exit	1
18	B408 2811	Guide Plate - Exit	1
19	B408 2312	Bushing - Roller Slide	1
20	AW01 0109	Photo Reflection Sensor:PS117ED1	1
21	B408 2311	Slide Roller	1
22	B408 2162	Guide Mylar	2
23	B408 2161	Guide Plate:Shift	1
24	AG07 0514	Magnet Catch:Ass'y	1
25	B408 2175	Bushing - Roller Slide	2
26	A697 2144	Pressure Spring	2
27	B408 2172	Guide Plate - Shift	1
28	B408 2174	Spring	2
29	B408 2173	Slide Roller	1
30	B408 7102	Decal - Shift Tray R1 MB1	1
31	B408 5345	Harness:Connecting:325MM	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0720 0040E	Retaining Ring - M4	
104	0451 3006N	Tapping Screw - 3x6	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	0453 3006N	Tapping Screw - M3x6	

4.PAPER EXIT SECTION 2 (B408)




4.PAPER EXIT SECTION 2 (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2272	Pulley - T30	1
2	AA08 2101	Bushing - 6x10x6	2
3	B352 2407	Reverse Roller - 20z	2
4	B408 2246	Reverse Roller Arm	1
5	B352 2409	Idler Gear - 17z	2
6	B408 2241	Exit Roller	1
7	B408 5307	Harness:Connecting:Paper Senser	1
8	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
9	B408 3613	Lever - Micro Switch	1
10	B408 3611	Stay - Paper Sensor	1
11	B408 3612	Paper Sensor Feeler	1
12	B408 2182	Guide Plate - Exit Stapler	1
13	A681 2722	Guide Mylar - Lower Exit Guide	4
14	B408 1413	Coupling Stay	1
15	AA14 3790	Screw:Contact Point	2
16	B408 1411	Coupling Lever	1
17	B408 1412	Flat Screw	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0720 0040E	Retaining Ring - M4	
103	0452 3020N	Tapping Screw - 3x20	
104	0452 3008N	Tapping Screw - M3x8	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	1204 2540	Micro Switch - AM50650C3	

5.VERTICAL TRANSPORT (B408)




5.VERTICAL TRANSPORT (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2101	Bushing - 6x10x6	4
2	AG07 0514	Magnet Catch:Ass'y	1
3	B408 7122	Decal - Stapler Tray R3	1
4	A859 3425	Spring Plate	2
5	A859 3420	Middle Driven Roller	2
6	B408 2142	Guide Plate - Stapler Tray	1
7	A697 2144	Pressure Spring	2
8	AA08 0237	Bushing - 4x5x7	2
9	AF02 2097	Driven Roller	1
10	B408 2541	Gate Pawl:Lower	1
11	A548 1317	Lever Cushion	1
12	B408 2211	Transfer Roller	2
13	B408 2131	Upper Guide Plate	1
14	B408 2271	Pulley - T24	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0720 0040E	Retaining Ring - M4	
103	0805 0089	Retaining Ring - M4	
104	1204 2541	Interlock Switch	
105	1105 0511	Harness Clamp - LWS-0306ZC	

6.STAPLE SECTION 1 (B408)




6.STAPLE SECTION 1 (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	AA08 2101	Bushing - 6x10x6	5
2	B408 2435	Gathering Roller:Ass'y	1
3	B408 2434	Timing Belt - 124P2M4	1
4	B408 2422	Pulley - T16	1
5	B408 2411	Arm - Positioning Roller	1
6	B408 2421	Bracket - Positioning Roller	1
7	B408 2444	Spring - Positioning Roller	1
8	B408 2451	DC Solenoid - 12.5W	1
9	A498 4625	Arm Cushion	1
10	B408 2441	Shaft - Positioning Roller	1
11	B408 2251	Stapler Exit Roller	1
12	B352 2203	Discharge Brush - Stapler Tray	1
13	B352 2206	Tension Spring - Lower Guide	2
14	B408 7132	Decal - Stapler Tray Exit R4	1
15	B408 2113	Guide - Trailing Edge	4
16	B408 2011	Guide Plate:Lower:Open And Close:Small:Ass'y	1
17	A697 2144	Pressure Spring	2
18	B352 2205	Bushing - Driven Roller	2
19	B352 2204	Driven Roller	1
20	B352 2229	Roller - Paper Guide	2
21	B352 2222	Paper Guide - Trailing Edge	1
22	B352 2232	Torsion Spring	1
23	AW02 0169	Photointerruptor - Os - 580213-703	1
24	B408 5355	Sensor Relay Harness - 280mm	1
25	B408 2122	Guide Plate - Lower	1
26	B408 2271	Pulley - T24	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0720 0040E	Retaining Ring - M4	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0328	Harness Clamp - ES-0505	
106	0353 0040N	Screw - M3X4	

7.STAPLE SECTION 2 (B408)




7.STAPLE SECTION 2 (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 5335	Harness:Connecting:Stapler Tray	1
2	AW02 0166	Photointerruptor:Paper Feed Sensor	1
3	B408 4336	Timing Belt - 940P2M4	1
4	A697 4170	Pulley - 32T	1
5	B408 4392	Exit Tension Bracket	1
6	B408 4398	Tension Spring	1
7	B408 4395	Pulley - Exit Belt	1
8	B408 4321	Stay - Stapler Tray	1
9	AX05 0244	Stepper Motor:MM42:0.85A	1
10	B408 4337	Spring	1
11	B408 4332	Bracket - Jogger Motor	1
12	AA14 3790	Screw:Contact Point	1
13	B408 4343	Slider Fence Shaft	1
14	B352 4232	Slider - Training Edge Fence	2
15	B408 4342	Trailing Edge Fence	2
16	B700 4107	Spring:Rerurn:Standard Fence	1
17	A666 3180	Timing Pulley - Z32	2
18	B408 5512	Stepper Motor:Sub-ass'y	1
19	B408 4385	Shaft - Exit Belt	1
20	B408 4382	Pulley - T26	1
21	B408 4371	Timing Belt - 246P3M4	1
22	B408 4311	Stapler Tray	1
23	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
24	B408 5325	Harness:Connecting:575MM	1
25	B408 4383	Shaft - Idler Exit Belt	1
26	B408 4372	Exit Belt Ass'y	1
27	AW01 0109	Photo Reflection Sensor:PS117ED1	1
28	B408 4363	Slider - Jogger Fence	2
29	B408 4362	Jogger Fence - Front	1
30	B408 7142	Decal - Jogger Fence R5 MB1	1
31	B408 4367	Shaft - Jogger Fence	1
32	A681 4515	Bushing - 6mm	2
33	B408 4364	Film - Jogger Fence	2
34	B408 4366	Jogger Fence - Inner	1
35	B408 4335	Timing Pulley - Jogger	1

Index No.	Part No.	Description	Q'ty Per Assembly
36	B408 4344	Guide:Standard Fence:Front	1
37	B408 4347	Guide:Standard Fence:Inner Back	1
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0450 3008N	Tapping Screw - M3x8	
104	0720 0040E	Retaining Ring - M4	
105	1105 0310	Harness Clamp - LWS-1S	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	0453 3006N	Tapping Screw - M3x6	
108	0805 3385	Bushing - 6mm	
109	0451 3008N	Tapping Screw - M3x8	
110	0451 3010N	Tapping Screw:3x10	

8.STAPLE SECTION 3 (B408)




8.STAPLE SECTION 3 (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 4211	Stapler Stay	1
2	B408 5227	Harness:Sensor:Stapler Tray	1
3	B408 4212	Stapler Guide Rod	1
4	B408 4223	Belt Tensioner - Stapler	1
5	AA06 2334	Tension Spring:4.9N	1
6	AA14 3790	Screw:Contact Point	1
7	A697 4170	Pulley - 32T	1
8	B408 4231	Timing Belt - 846P2M4	1
9	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
10	B408 4125	Stapler Bushing	2
11	B408 4126	Timing Belt Stay	1
12	B408 4121	Stapler Slider	1
13	B408 4127	Stay Slider	1
14	B408 4128	Spring	1
15	B408 4129	Screw:Guide Plate	1
16	B408 4114	Stapler Stopper	1
17	B408 7161	Decal - Stapler	1
18	B408 4113	Stapler Knob	1
19	B408 4111	Stapler Base	1
20	B408 5255	Harness:Stapler MB3	1
21	B408 4112	Stapler Guide	1
22	B352 4380	Stapler - EH530	1
23	B408 5552	Stepper Motor:Ass'y	1
24	B408 4115	Stapler Upper Mylar	1
25	B408 4101	Stapler Ass'y	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0720 0040E	Retaining Ring - M4	
104	1105 0328	Harness Clamp - ES-0505	
105	0452 3006N	Binding Self-tapping Screw:3x6	
106	1105 0511	Harness Clamp - LWS-0306ZC	
107	1105 0310	Harness Clamp - LWS-1S	
108	1105 0334	Edge - 17	
109	1607 0622	Ferrite Core - TFC16816	

9.SHIFT TRAY DRIVE (B408)




9.SHIFT TRAY DRIVE (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 3233	Tray H.P Sensor Feeler	1
2	A666 2331	Rack	2
3	B408 3231	Rear Guide Plate	1
4	B408 3211	Tray Base	1
5	B408 1511	Middle Stay	1
6	B408 3221	Front Guide Plate	1
7	B408 3112	End Fence	1
8	A666 2345	Gear - Z20	2
9	AA08 2070	Bushing - 8x16x7	2
10	B408 3311	Tray Shaft	1
11	A666 2347	Gear - Z45	1
12	AW02 0166	Photointerruptor:Paper Feed Sensor	1
13	AX04 0214	DC Motor:Shift:Upper Lower:Drive	1
14	B408 5325	Harness:Connecting:575mm	1
15	B408 1315	Cap - Base	2

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0453 3006N	Tapping Screw - M3x6	
103	0450 4020N	Tapping Screw - M4x20	
104	0720 0060E	Retaining Ring - M6	
105	1105 0511	Harness Clamp - LWS-0306ZC	
106	1105 0291	Harness Clamp - LWS-3S	
107	0451 3010N	Tapping Screw:3x10	
108	0802 5276	Tapping Screw With Washer - M3x6	

10.DRIVE SECTION (B408)




10.DRIVE SECTION (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 2512	Bracket - DC Solenoid	2
2	B545 5809	DC Solenoid:Polarization Powl	1
3	B408 5502	Stepper Motor:Sub-ass'y	2
4	B408 2912	Bracket - Stepper Motor	1
5	B408 2901	Timing Belt - B40S3M720	1
6	B408 2903	Timing Belt - B40S3M525	1
7	B408 2922	Bracket - Stepper Motor	1
8	B408 2902	Timing Belt - B40S3M579	1
9	AA06 2333	Tension Spring:2.16N	1
10	B408 2955	Bracket:Tightener:Ass'y	3
11	A548 2139	Pulley	6
12	AA14 3790	Screw:Contact Point	3
13	AA06 2334	Tension Spring:4.9N	3
14	AB03 0354	Pulley - 20T	1
15	AX11 0118	DC Solenoid:24V:5.76W	1
16	A697 2101	Tension Spring	1

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0451 3006N	Tapping Screw - 3x6	
103	0353 0040N	Screw - M3X4	
104	0720 0040E	Retaining Ring - M4	

11.ELECTRICAL SECTION (B408)



11.ELECTRICAL SECTION (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 5261	Harness:Interface:EXP:Ass'y	1
2	B408 5217	Harness:Sensor:Main	1
3	B408 5237	Harness:Sensor:Tray:Lower	1
4	B408 5160	ROM:Main Control	1
5	B408 5227	Harness:Sensor:Stapler Tray	1
6	B408 5150	PCB:Main Control	1
7	B408 5247	Harness:Motor:Main	1
8	B408 5532	Stepper Motor:Sub-Ass'y	1
9	B408 2321	Bracket - Motor Slide	1
10	AW02 0156	Photointerruptor:EE-SX4235A-P2	1
11	B408 2331	Link Drive Gear	1
12	B408 1121	Angle - Side Plate Rear	1
13	B408 5540	Main Board Bracket	4
14	B408 5545	Harness Bracket	4

Index No.	Part No.	Description	Q'ty Per Assembly
101	0454 3006Q	Tapping Screw:3x6	
102	0805 0089	Retaining Ring - M4	
103	0453 3006N	Tapping Screw - M3x6	
104	1105 0511	Harness Clamp - LWS-0306ZC	
105	1105 0310	Harness Clamp - LWS-1S	

12.DECALS AND DOCUMENTS (B408)

1

>PS<

R₁

↑

R₁

2

R₂

3

>PS<

←

R₃

R₃

4

>PS<

↗

R₄

5

R₅

←

>PS<

6

1

2

3

4

5

6

7

1

2

3

4

5

6

1

2

3

4

5

6

7

8

7

✓

>PS<

8

U

R

R

R

R

R

U

A5, 5½x 8½

>PS<

24

12.DECALS AND DOCUMENTS (B408)

Index No.	Part No.	Description	Q'ty Per Assembly
1	B408 7102	Decal:Shift Tray:R1	1
2	B408 7112	Decal:Knob:R2	1
3	B408 7122	Decal:Stapler Tray:Lengthwise:R3	1
4	B408 7132	Decal:Stapler Tray:Exit:R4	1
5	B408 7142	Decal:Jogger Fence:R5	1
6	B408 7151	Decal - Misfeed Removal	1
7	B408 7161	Decal - Stapler	1
8	B408 7171	Decal - Staple	1

Index No.	Part No.	Description	Q'ty Per Assembly

Parts Index

Parts Index

Part No.	Description	Page and Index No.
B408 1121	Angle - Side Plate Rear	23 - 12
B408 1231	Angle - Front Side Plate	5 - 27
B408 1241	Guard - Side Plate Front	3 - 11
B408 1314	Caster:250N	3 - 7
B408 1315	Cap - Base	19 - 15
B408 1411	Coupling Lever	9 - 16
B408 1412	Flat Screw	9 - 17
B408 1413	Coupling Stay	9 - 14
B408 1414	Bracket - Coupling Rear	3 - 23
B408 1418	Mylar - Rear Joint Bracket	3 - 21
B408 1425	Bracket - Coupling Front	3 - 24
B408 1429	Ground Plate Bracket	3 - 8
B408 1431	Flat Screw:Coupling	3 - 22
B408 1511	Middle Stay	19 - 5
B408 2011	Guide Plate:Lower:Open And Close:Small:Ass'y	13 - 16
B408 2113	Guide - Trailing Edge	13 - 15
B408 2122	Guide Plate - Lower	13 - 25
B408 2131	Upper Guide Plate	11 - 13
B408 2142	Guide Plate - Stapler Tray	11 - 6
B408 2152	Guide Plate - Entrance	5 - 13
B408 2157	Left Guide Plate - Entrance MB1	5 - 12
B408 2161	Guide Plate:Shift	7 - 23
B408 2162	Guide Mylar	7 - 22
B408 2172	Guide Plate - Shift	7 - 27
B408 2173	Slide Roller	7 - 29
B408 2174	Spring	7 - 28
B408 2175	Bushing - Roller Slide	7 - 25
B408 2182	Guide Plate - Exit Stapler	9 - 12
B408 2191	Guide Plate - Connecting Lower	3 - 25
B408 2192	Guide Plate - Connecting Upper	3 - 20
B408 2211	Transfer Roller	11 - 12
B408 2211	Transfer Roller	5 - 7
B408 2221	Transfer Roller - Upper	5 - 5
B408 2231	Exit Roller - Proof Tray	5 - 6
B408 2241	Exit Roller	9 - 6

Part No.	Description	Page and Index No.
B408 2246	Reverse Roller Arm	9 - 4
B408 2251	Stapler Exit Roller	13 - 11
B408 2271	Pulley - T24	11 - 14
B408 2271	Pulley - T24	13 - 26
B408 2271	Pulley - T24	5 - 1
B408 2272	Pulley - T30	9 - 1
B408 2281	Knob - Transfer Roller	5 - 25
B408 2311	Slide Roller	7 - 21
B408 2312	Bushing - Roller Slide	7 - 19
B408 2313	Pulley - T24	7 - 2
B408 2314	Arm - Roller Slide	7 - 1
B408 2321	Bracket - Motor Slide	23 - 9
B408 2331	Link Drive Gear	23 - 11
B408 2411	Arm - Positioning Roller	13 - 5
B408 2421	Bracket - Positioning Roller	13 - 6
B408 2422	Pulley - T16	13 - 4
B408 2434	Timing Belt - 124P2M4	13 - 3
B408 2435	Gathering Roller:Ass'y	13 - 2
B408 2441	Shaft - Positioning Roller	13 - 10
B408 2444	Spring - Positioning Roller	13 - 7
B408 2451	DC Solenoid - 12.5W	13 - 8
B408 2512	Bracket - DC Solenoid	21 - 1
B408 2532	Lever - Paper Guide Upper	5 - 3
B408 2541	Gate Pawl:Lower	11 - 10
B408 2711	Top Cover	5 - 22
B408 2715	Discharge Brush	5 - 19
B408 2722	Spring - Upper Paper Guide	5 - 17
B408 2723	Upper Paer Guide	5 - 16
B408 2731	Arm - Top Cover	5 - 20
B408 2751	Ground Plate:Exit:Proof Tray	5 - 28
B408 2811	Guide Plate - Exit	7 - 18
B408 2812	Discharge Brush:Exit:Open And C	7 - 16
B408 2821	Stay - Guide Plate	7 - 12
B408 2831	Gear - Z53	7 - 11
B408 2832	Worm Wheel - Z20	7 - 8

Part No.	Description	Page and Index No.
B408 2833	Shaft - Worm Wheel	7 - 7
B408 2841	Bracket - Home Position Sensor	7 - 6
B408 2852	Spring - Guide Plate Exit	7 - 17
B408 2861	Arm - Guide Plate	7 - 9
B408 2901	Timing Belt - B40S3M720	21 - 5
B408 2902	Timing Belt - B40S3M579	21 - 8
B408 2903	Timing Belt - B40S3M525	21 - 6
B408 2912	Bracket - Stepper Motor	21 - 4
B408 2922	Bracket - Stepper Motor	21 - 7
B408 2955	Bracket:Tightener:Ass'y	21 - 10
B408 3112	End Fence	19 - 7
B408 3211	Tray Base	19 - 4
B408 3221	Front Guide Plate	19 - 6
B408 3231	Rear Guide Plate	19 - 3
B408 3233	Tray H.P Sensor Feeler	19 - 1
B408 3311	Tray Shaft	19 - 10
B408 3411	Tray	3 - 5
B408 3412	Slide Tray	3 - 3
B408 3611	Stay - Paper Sensor	9 - 10
B408 3612	Paper Sensor Feeler	9 - 11
B408 3613	Lever - Micro Switch	9 - 9
B408 4101	Stapler Ass'y	17 - 25
B408 4111	Stapler Base	17 - 19
B408 4112	Stapler Guide	17 - 21
B408 4113	Stapler Knob	17 - 18
B408 4114	Stapler Stopper	17 - 16
B408 4115	Stapler Upper Mylar	17 - 24
B408 4121	Stapler Slider	17 - 12
B408 4125	Stapler Bushing	17 - 10
B408 4126	Timing Belt Stay	17 - 11
B408 4127	Stay Slider	17 - 13
B408 4128	Spring	17 - 14
B408 4129	Screw:Guide Plate	17 - 15
B408 4211	Stapler Stay	17 - 1
B408 4212	Stapler Guide Rod	17 - 3

Part No.	Description	Page and Index No.
B408 4223	Belt Tensioner - Stapler	17 - 4
B408 4231	Timing Belt - 846P2M4	17 - 8
B408 4311	Stapler Tray	15 - 22
B408 4321	Stay - Stapler Tray	15 - 8
B408 4332	Bracket - Jogger Motor	15 - 11
B408 4335	Timing Pulley - Jogger	15 - 35
B408 4336	Timing Belt - 940P2M4	15 - 3
B408 4337	Spring	15 - 10
B408 4342	Trailing Edge Fence	15 - 15
B408 4343	Slider Fence Shaft	15 - 13
B408 4344	Guide:Standard Fence:Front	15 - 36
B408 4347	Guide:Standard Fence:Inner Back	15 - 37
B408 4362	Jogger Fence - Front	15 - 29
B408 4363	Slider - Jogger Fence	15 - 28
B408 4364	Film - Jogger Fence	15 - 33
B408 4366	Jogger Fence - Inner	15 - 34
B408 4367	Shaft - Jogger Fence	15 - 31
B408 4371	Timing Belt - 246P3M4	15 - 21
B408 4372	Exit Belt Ass'y	15 - 26
B408 4382	Pulley - T26	15 - 20
B408 4383	Shaft - Idler Exit Belt	15 - 25
B408 4385	Shaft - Exit Belt	15 - 19
B408 4392	Exit Tension Bracket	15 - 5
B408 4395	Pulley - Exit Belt	15 - 7
B408 4398	Tension Spring	15 - 6
B408 5150	PCB:Main Control	23 - 6
B408 5160	ROM:Main Control	23 - 4
B408 5217	Harness:Sensor:Main	23 - 2
B408 5227	Harness:Sensor:Stapler Tray	23 - 5
B408 5227	Harness:Sensor:Stapler Tray	17 - 2
B408 5237	Harness:Sensor:Tray:Lower	23 - 3
B408 5247	Harness:Motor:Main	23 - 7
B408 5255	Harness:Stapler MB3	17 - 20
B408 5261	Harness:Interface:EXP:Ass'y	23 - 1
B408 5307	Harness:Connecting:Paper Senser	9 - 7

Part No.	Description	Page and Index No.
B408 5315	Harness - Connecting	5 - 8
B408 5325	Harness:Connecting:575MM	15 - 24
B408 5325	Harness:Connecting:575mm	19 - 14
B408 5335	Harness:Connecting:Stapler Tray	15 - 1
B408 5345	Harness:Connecting:325MM	7 - 31
B408 5355	Sensor Relay Harness - 280mm	13 - 24
B408 5355	Sensor Relay Harness - 280mm	7 - 4
B408 5502	Stepper Motor:Sub-ass'y	21 - 3
B408 5512	Stepper Motor:Sub-ass'y	15 - 18
B408 5532	Stepper Motor:Sub-Ass'y	23 - 8
B408 5540	Main Board Bracket	23 - 13
B408 5545	Harness Bracket	23 - 14
B408 5552	Stepper Motor:Ass'y	17 - 23
B408 6111	Upper Cover	3 - 19
B408 6121	Front Cover	3 - 14
B408 6122	Hinge - Door Upper	3 - 17
B408 6124	Hinge - Door Lower	3 - 12
B408 6131	Left Inner Cover	3 - 10
B408 6141	Rear Cover	3 - 1
B408 6151	Left Upper Cover	3 - 2
B408 6161	Left Lower Cover	3 - 6
B408 6172	Cover:Right Lower	3 - 16
B408 7102	Decal - Shift Tray R1 MB1	7 - 30
B408 7102	Decal:Shift Tray:R1	25 - 1
B408 7112	Decal - Knob R2	5 - 26
B408 7112	Decal:Knob:R2	25 - 2
B408 7122	Decal - Stapler Tray R3	11 - 3
B408 7122	Decal:Stapler Tray:Lengthwise:R3	25 - 3
B408 7132	Decal - Stapler Tray Exit R4	13 - 14
B408 7132	Decal:Stapler Tray:Exit:R4	25 - 4
B408 7142	Decal - Jogger Fence R5 MB1	15 - 30
B408 7142	Decal:Jogger Fence:R5	25 - 5
B408 7151	Decal - Misfeed Removal	25 - 6
B408 7151	Decal - Misfeed Removal	3 - 13
B408 7161	Decal - Stapler	25 - 7

Part No.	Description	Page and Index No.
B408 7161	Decal - Stapler	17 - 17
B408 7171	Decal - Staple	3 - 18
B408 7171	Decal - Staple	25 - 8

Part No.	Description	Page and Index No.
A498 4625	Arm Cushion	13 - 9
A548 1317	Lever Cushion	11 - 11
A548 1317	Lever Cushion	5 - 15
A548 2139	Pulley	21 - 11
A628 3115	Knob Screw - M4	3 - 4
A666 2331	Rack	19 - 2
A666 2345	Gear - Z20	19 - 8
A666 2347	Gear - Z45	19 - 11
A666 3180	Timing Pulley - Z32	15 - 17
A666 4210	Shaft - Exit Roller	7 - 15
A681 2722	Guide Mylar - Lower Exit Guide	9 - 13
A681 2742	Driven Exit Roller	7 - 14
A681 4515	Bushing - 6mm	15 - 32
A688 3960	Roller Holder	5 - 24
A697 2101	Tension Spring	21 - 16
A697 2144	Pressure Spring	13 - 17
A697 2144	Pressure Spring	7 - 26
A697 2144	Pressure Spring	11 - 7
A697 4170	Pulley - 32T	17 - 7
A697 4170	Pulley - 32T	15 - 4
A859 3420	Middle Driven Roller	11 - 5
A859 3420	Middle Driven Roller	5 - 11
A859 3425	Spring Plate	5 - 10
A859 3425	Spring Plate	11 - 4
B352 2203	Discharge Brush - Stapler Tray	13 - 12
B352 2204	Driven Roller	13 - 19
B352 2205	Bushing - Driven Roller	13 - 18
B352 2206	Tension Spring - Lower Guide	13 - 13
B352 2222	Paper Guide - Trailing Edge	13 - 21
B352 2229	Roller - Paper Guide	13 - 20
B352 2232	Torsion Spring	13 - 22
B352 2407	Reverse Roller - 20z	9 - 3
B352 2409	Idler Gear - 17z	9 - 5
B352 4232	Slider - Training Edge Fence	15 - 14
B352 4380	Stapler - EH530	17 - 22

Part No.	Description	Page and Index No.
B545 5809	DC Solenoid:Polarization Powl	21 - 2
B700 4107	Spring:Rerurn:Standard Fence	15 - 16
G020 1391	Screw - M3X4.5	3 - 9
G020 5626	Push Switch	5 - 4

Part No.	Description	Page and Index No.
AA06 2333	Tension Spring:2.16N	21 - 9
AA06 2334	Tension Spring:4.9N	17 - 5
AA06 2334	Tension Spring:4.9N	21 - 13
AA08 0237	Bushing - 4x5x7	11 - 8
AA08 2070	Bushing - 8x16x7	19 - 9
AA08 2101	Bushing - 6x10x6	7 - 3
AA08 2101	Bushing - 6x10x6	5 - 2
AA08 2101	Bushing - 6x10x6	9 - 2
AA08 2101	Bushing - 6x10x6	11 - 1
AA08 2101	Bushing - 6x10x6	13 - 1
AA14 3790	Screw:Contact Point	21 - 12
AA14 3790	Screw:Contact Point	17 - 6
AA14 3790	Screw:Contact Point	15 - 12
AA14 3790	Screw:Contact Point	9 - 15
AB03 0354	Pulley - 20T	21 - 14
AF02 2097	Driven Roller	11 - 9
AF04 0558	Driven Roller	5 - 23
AG07 0512	Magnetic Catch:Ass'y	3 - 15
AG07 0514	Magnet Catch:Ass'y	7 - 24
AG07 0514	Magnet Catch:Ass'y	5 - 18
AG07 0514	Magnet Catch:Ass'y	11 - 2
AW01 0109	Photo Reflection Sensor:PS117ED1	7 - 20
AW01 0109	Photo Reflection Sensor:PS117ED1	15 - 27
AW02 0156	Photointerruptor:EE-SX4235A-P2	23 - 10
AW02 0156	Photointerruptor:EE-SX4235A-P2	7 - 5
AW02 0156	Photointerruptor:EE-SX4235A-P2	17 - 9
AW02 0156	Photointerruptor:EE-SX4235A-P2	15 - 23
AW02 0156	Photointerruptor:EE-SX4235A-P2	9 - 8
AW02 0166	Photointerruptor:Paper Feed Sensor	19 - 12
AW02 0166	Photointerruptor:Paper Feed Sensor	15 - 2
AW02 0169	Photointerruptor - OS - 580213-703	5 - 14
AW02 0169	Photointerruptor - Os - 580213-703	13 - 23
AW02 0170	Photointerruptor:Overflow:CT	5 - 9
AX04 0214	DC Motor:Shift:Upper Lower:Drive	19 - 13
AX05 0244	Stepper Motor:MM42:0.85A	7 - 13

Part No.	Description	Page and Index No.
AX05 0244	Stepper Motor:MM42:0.85A	15 - 9
AX11 0118	DC Solenoid:24V:5.76W	21 - 15

Part No.	Description	Page and Index No.
0353 0040N	Screw - M3X4	13 -106
0353 0040N	Screw - M3X4	21 -103
0450 3008N	Tapping Screw - M3x8	15 -103
0450 4020N	Tapping Screw - M4x20	19 -103
0451 3006N	Tapping Screw - 3x6	15 -102
0451 3006N	Tapping Screw - 3x6	17 -102
0451 3006N	Tapping Screw - 3x6	21 -102
0451 3006N	Tapping Screw - 3x6	7 - 104
0451 3008N	Tapping Screw - M3x8	3 - 102
0451 3008N	Tapping Screw - M3x8	15 -109
0451 3010N	Tapping Screw:3x10	19 -107
0451 3010N	Tapping Screw:3x10	15 -110
0452 3006N	Binding Self-tapping Screw:3x6	17 -105
0452 3008N	Tapping Screw - M3x8	9 - 104
0452 3020N	Tapping Screw - 3x20	9 - 103
0453 3006N	Tapping Screw - M3x6	7 - 106
0453 3006N	Tapping Screw - M3x6	19 -102
0453 3006N	Tapping Screw - M3x6	23 -103
0453 3006N	Tapping Screw - M3x6	15 -107
0454 3006Q	Tapping Screw:3x6	17 -101
0454 3006Q	Tapping Screw:3x6	3 - 101
0454 3006Q	Tapping Screw:3x6	5 - 101
0454 3006Q	Tapping Screw:3x6	15 -101
0454 3006Q	Tapping Screw:3x6	23 -101
0454 3006Q	Tapping Screw:3x6	7 - 101
0454 3006Q	Tapping Screw:3x6	13 -101
0454 3006Q	Tapping Screw:3x6	21 -101
0454 3006Q	Tapping Screw:3x6	19 -101
0454 3006Q	Tapping Screw:3x6	11 -101
0454 3006Q	Tapping Screw:3x6	9 - 101
0720 0040E	Retaining Ring - M4	21 -104
0720 0040E	Retaining Ring - M4	17 -103
0720 0040E	Retaining Ring - M4	15 -104
0720 0040E	Retaining Ring - M4	11 -102
0720 0040E	Retaining Ring - M4	13 -103

Part No.	Description	Page and Index No.
0720 0040E	Retaining Ring - M4	7 - 103
0720 0040E	Retaining Ring - M4	9 - 102
0720 0060E	Retaining Ring - M6	19 -104
0802 5276	Tapping Screw With Washer - M3x6	19 -108
0805 0089	Retaining Ring - M4	5 - 102
0805 0089	Retaining Ring - M4	23 -102
0805 0089	Retaining Ring - M4	13 -102
0805 0089	Retaining Ring - M4	7 - 102
0805 0089	Retaining Ring - M4	11 -103
0805 3385	Bushing - 6mm	15 -108
1105 0291	Harness Clamp - LWS-3S	19 -106
1105 0310	Harness Clamp - LWS-1S	23 -105
1105 0310	Harness Clamp - LWS-1S	15 -105
1105 0310	Harness Clamp - LWS-1S	17 -107
1105 0328	Harness Clamp - ES-0505	13 -105
1105 0328	Harness Clamp - ES-0505	17 -104
1105 0334	Edge - 17	17 -108
1105 0511	Harness Clamp - LWS-0306ZC	11 -105
1105 0511	Harness Clamp - LWS-0306ZC	23 -104
1105 0511	Harness Clamp - LWS-0306ZC	13 -104
1105 0511	Harness Clamp - LWS-0306ZC	5 - 103
1105 0511	Harness Clamp - LWS-0306ZC	15 -106
1105 0511	Harness Clamp - LWS-0306ZC	7 - 105
1105 0511	Harness Clamp - LWS-0306ZC	17 -106
1105 0511	Harness Clamp - LWS-0306ZC	19 -105
1105 0511	Harness Clamp - LWS-0306ZC	9 - 105
1105 0522	Edge Saddle - LES0510	5 - 104
1204 2540	Micro Switch - AM50650C3	9 - 106
1204 2541	Interlock Switch	11 -104
1607 0622	Ferrite Core - TFC16816	17 -109

Part No.	Description	Page and Index No.
5447 2681	Snap Ring	5 - 21
5447 2681	Snap Ring	7 - 10

Part No.	Description	Page and Index No.