

Agilent 34410A/11A 6 ½ Digit Multimeter

User's Guide



Agilent Technologies

Notices

© Agilent Technologies, Inc. 2005

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

34410-90001

Edition

First Edition, October 2005

Printed in USA

Agilent Technologies, Inc.
395 Page Mill Road
Palo Alto, CA 94303 USA

Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC

This product complies with the WEEE Directive (2002/96/EC) marking requirement. The affixed product label (see below) indicates that you must not discard this electrical/electronic product in domestic household waste.

Product Category: With reference to the equipment types in the WEEE directive Annex 1, this product is classified as a "Monitoring and Control instrumentation" product.

Do not dispose in domestic household waste

To return unwanted products, contact your local Agilent office, or see www.agilent.com/environment/product for more information



Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or subcontract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.


Safety Information

Do not defeat power cord safety ground feature. Plug in to a grounded (earthed) outlet.


Do not use product in any manner not specified by the manufacturer.

Do not install substitute parts or perform any unauthorized modification to the product. Return the product to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

Safety Symbols



Earth Ground



Chassis Ground



Risk of electric shock



Refer to manual for additional safety information

CAT II (300 v) IEC Measurement Category II. Inputs may be connected to mains (up to 300 VAC) under Category II overvoltage conditions.

WARNING

Main Power and Test Input Disconnect: Unplug instrument from wall outlet, remove power cord, and remove all probes from all terminals before servicing. Only qualified, service-trained personnel should remove the cover from the instrument.

WARNING

Line and Current Protection Fuses: For continued protection against fire, replace the line fuse and the current-protection fuse only with fuses of the specified type and rating.

WARNING

Front/Rear Switch: Do not change the position of the Front/Rear switch on the front panel while signals are present on either the front or rear set of terminals. The switch is not intended as an active multiplexer. Switching while high voltages or currents are present may cause instrument damage and lead to the risk of electric shock.

WARNING


IEC Measurement Category II. The HI and LO input terminals may be connected to mains in IEC Category II installations for line voltages up to 300 VAC. To avoid the danger of electric shock, do not connect the inputs to mains for line voltages above 300 VAC. See "IEC Measurement Category II Overvoltage Protection" on the following page for further information.

WARNING

Protection Limits: To avoid instrument damage and the risk of electric shock, do not exceed any of the Protection Limits defined in the following section.

Protection Limits

The Agilent 34410A Digital Multimeter provides protection circuitry to prevent damage to the instrument and to protect against the danger of electric shock, provided the Protection Limits are not exceeded. To ensure safe operation of the instrument, do not exceed the Protection Limits shown on the front and rear panel, and defined below:



Note: The front-panel terminals are shown above. The rear-panel terminals are identical. The Front/Rear switch selects the terminal set to be used. *Do not operate this switch while signals are present on the front or rear terminals.* The current-protection fuse is on the rear panel.

Input Terminal Protection Limits

Protection Limits are defined for the three input terminals:

Main Input (HI and LO) Terminals. The HI and LO input terminals are used for voltage, resistance, capacitance, and diode test measurements. Two Protection Limits are defined for these terminals:

HI to LO Protection Limit. The Protection Limit from HI to LO ("A" in the figure at left) is 1000 VDC or 750 VAC, which is also the maximum voltage measurement. This limit can also be expressed as 1000 Vpk maximum.

LO to Ground Protection Limit. The LO input terminal can safely "float" a maximum of 500 Vpk relative to ground. This is Protection Limit "B" in the figure.

As is implied by the above limits, the Protection Limit for the HI input terminal is a maximum of 1500 Vpk relative to ground.

Current Input Terminal. The current input ("I") terminal has a Protection Limit of 3A (rms) maximum current flowing from the LO input terminal. This is Protection Limit "C" in the figure. Note that the current input terminal will be at approximately the same voltage as the LO terminal.

Note: The current-protection circuitry includes a fuse on the rear panel. To maintain protection, replace this fuse only with a fuse of the specified type and rating (see "Operator Maintenance" in Chapter 1).

Sense Terminal Protection Limits

The HI and LO sense terminals are used only for four-wire resistance measurements ("Ω 4W"). The Protection Limit is 200 Vpk for all of the terminal pairings ("D" in the figure):

- LO sense to LO input.
- HI sense to LO input.
- HI sense to LO sense.

Note: The 200 Vpk limit on the sense terminals is the Protection Limit. Operational voltages in resistance measurements are much lower — less than 10 V in normal operation.

IEC Measurement Category II Overvoltage Protection

To protect against the danger of electric shock, the Agilent 34410A/11A Digital Multimeter provides overvoltage protection for line-voltage mains connections meeting **both** of the following conditions:

The HI and LO input terminals are connected to the mains under Measurement Category II conditions, defined below, **and**

The mains are limited to a maximum line voltage of 300 VAC.

IEC Measurement Category II includes electrical devices connected to mains at an outlet on a branch circuit. Such devices include most small appliances, test equipment, and other devices that plug into a branch outlet or socket. The 34410A/11A may be used to make measurements with the HI and LO inputs connected to mains in such devices, or to the branch outlet itself (up to 300 VAC). However, the 34410A/11A may not be used with its HI and LO inputs connected to mains in permanently installed electrical devices such as the main circuit-breaker panel, sub-panel disconnect boxes, or permanently wired motors. Such devices and circuits are subject to overvoltages that may exceed the protection limits of the 34410A.

Note: Voltages above 300 VAC may be measured only in circuits that are isolated from mains. However, transient overvoltages are also present on circuits that are isolated from mains. The Agilent 34410A/11A is designed to safely withstand occasional transient overvoltages up to 2500 Vpk. Do not use this equipment to measure circuits where transient overvoltages could exceed this level.



Agilent Technologies

DECLARATION OF CONFORMITY
According to ISO/IEC Guide 22 and CEN/CENELEC EN 45014



Manufacturer's Name: Agilent Technologies, Incorporated
Manufacturer's Address: 815 – 14th St. SW
Loveland, CO 80537
USA

Declares under sole responsibility that the product as originally delivered

Product Name: 6 ½ Digit Multimeter
Model Number: 34410A, 34411A
Product Options: This declaration covers all options of the above product(s)

complies with the essential requirements of the following applicable European Directives, and carries the CE marking accordingly:

Low Voltage Directive (73/23/EEC, amended by 93/68/EEC)
EMC Directive (89/336/EEC, amended by 93/68/EEC)

and conforms with the following product standards:

| EMC | Standard | Limit |
|-----|--|---------------------------------------|
| | IEC 61326-1:1997+A1:1998 / EN 61326-1:1997+A1:1998 | |
| | CISPR 11:1990 / EN 55011:1991 | Group 1 Class A |
| | IEC 61000-4-2:1995+A1:1998 / EN 61000-4-2:1995 | 4 kV CD, 4 kV AD |
| | IEC 61000-4-3:1995 / EN 61000-4-3:1995 | 3 V/m, 80-1000 MHz |
| | IEC 61000-4-4:1995 / EN 61000-4-4:1995 | 0.5 kV signal lines, 1 kV power lines |
| | IEC 61000-4-5:1995 / EN 61000-4-5:1995 | 0.5 kV line-line, 1 kV line-ground |
| | IEC 61000-4-6:1996 / EN 61000-4-6:1996 | 3 V, 0.15-80 MHz 1 cycle, 100% |
| | IEC 61000-4-11:1994 / EN 61000-4-11:1994 | Interrupts: 10 ms, 20 ms |
| | Canada: ICES-001:1998 | |
| | Australia/New Zealand: AS/NZS 2064.1 | |

The product was tested in a typical configuration with Agilent Technologies test systems.

Safety IEC 61010-1:2001 / EN 61010-1:2001
Canada: CSA C22.2 No. 61010-1:2004
USA: UL 61010-1: 2004

Supplementary Information:

This DoC applies to above-listed products placed on the EU market after:

20 October 2005
Date

Ray Corson
Product Regulations Program Manager

For further information, please contact your local Agilent Technologies sales office, agent or distributor,
or Agilent Technologies Deutschland GmbH, Herrenberger Straße 130, D 71034 Böblingen, Germany.

Agilent 34410A/11A at a Glance

The Agilent Technologies 34410A and 34411A multimeters give you the performance you need for fast, accurate bench and system testing. These multimeters provides 6½-digits of resolution and 0.0015% basic 24-hr dcV accuracy.

Convenient bench-top features

- Continuity and diode testing
- Capacitance measurements
- A dual display of multiple measurement data, such as Frequency and ac voltage, at the same time
- Bar graph display to help you see limits exceeded in measurements
- Data logging that allows you to select a function, space measurements in time, and choose your logging duration
- Instrument state storage with user-defined names
- Portable, ruggedized case with non-skid feet


Flexible system features

- GPIB (IEEE-488), USB, and LAN remote interfaces are standard
- SCPI (Standard Commands for Programmable Instruments) compatibility
- Voltmeter Complete and External Trigger signals to synchronize to other instruments in your test system

Note: This manual covers the operation of the Agilent 34410A and 34411A 6½ Digit Multimeters. The features described in this manual, except where otherwise stated, apply to both Models 34410A and 34411A.

| Model 34410A | Model 34411A |
|--|---|
| <ul style="list-style-type: none">• Up to 10,000 readings per second• Reading memory (buffer) up to 50,000 readings | <ul style="list-style-type: none">• Up to 50,000 readings per second• Reading memory (buffer) up to 1 million readings |
| | <ul style="list-style-type: none">• Pretriggering, internal level triggering, and digitizer specifications. |

The Front Panel at a Glance




| | | | |
|----|---|----|--|
| 1 | Multimeter On/Off Switch | 13 | DC Voltage measurement function key (<i>shifted function: DC Current</i>) |
| 2 | Front/Rear Terminal Selection Switch | 14 | AC Voltage measurement function key (<i>shifted function: AC Current</i>) |
| 3 | HI Sense Terminal (also 4-wire Ω) | 15 | 2-wire Ohms measurement function key (<i>shifted function: 4-wire Ohms</i>) |
| 4 | LO Sense Terminal (also 4-wire Ω) | 16 | Second Display key (<i>shifted function: Multimeter Reset</i>) |
| 5 | HI Input terminal | 17 | Data Logger Function Key (<i>shifted function: Utility Menu</i>) |
| 6 | LO Input terminal | 18 | Exit key (<i>when not in a menu, also toggles Auto Range function on/off</i>) |
| 7 | Current Input terminal | 19 | Frequency/Period measurement function key (<i>shifted function: Capacitance</i>) |
| 8 | Left navigation key (< integration) | 20 | Continuity measurement function key (<i>shifted function: Diode Check</i>) |
| 9 | Right navigation key (> integration) | 21 | Configuration Menu key (<i>shifted function: Temperature</i>) |
| 10 | Up navigation key (> range) | 22 | Null function key (<i>shifted function: Math Menu</i>) |
| 11 | Down navigation key (< range) | 23 | Trigger key (<i>shifted function: Auto Trigger Menu</i>) |
| 12 | Enter key | 24 | Shift key (<i>also returns multimeter from remote to Local operation</i>) |

WARNING

Front/Rear Switch: Do not change the position of the Front/Rear switch on the front panel while signals are present on either the front or rear set of terminals. This switch is not intended as an active multiplexer. Switching while high voltages or currents are present may cause instrument damage and lead to the risk of electric shock.

The Rear Panel at a Glance




| | |
|----|---|
| 1 | Power cord receptacle |
| 2 | Power-line fuse holder |
| 3 | Line voltage indicator |
| 4 | Current input fuse holder |
| 5 | LAN cable receptacle |
| 6 | USB cable receptacle |
| 7 | GPIB cable receptacle |
| 8 | HI Sense Terminal (also 4-wire Ω) |
| 9 | LO Sense Terminal (also 4-wire Ω) |
| 10 | HI Input terminal |
| 11 | LO Input terminal |
| 12 | Current Input terminal |
| 13 | External Trigger terminal |
| 14 | VM Comp (reading complete) terminal |

WARNING

For protection from electrical shock, the power cord ground must not be defeated.

The Display at a Glance



| | |
|----|---|
| 1 | Primary Display Line |
| 2 | Secondary Display Line |
| 3 | * Annunciator (on during a measurement) |
| 4 | Hi-Z (high input impedance) Annunciator |
| 5 | OComp (offset compensation) Annunciator |
| 6 | ManRng (manual ranging) Annunciator |
| 7 | Trig (wait-for-trigger state) Annunciator |
| 8 | Hold (reading hold) Annunciator |
| 9 | Remote (remote interface operation) Annunciator |
| 10 | Error (detected error) Annunciator |
| 11 | Null (null function enabled) Annunciator |
| 12 | Shift (shift key just pressed) Annunciator |
| 13 | Math (dB or dBm function enabled) Annunciator |
| 14 | Stats (statistics functions enabled) Annunciator |
| 15 | Limits (limit test function enabled) Annunciator |
| 16 | Rear Annunciator |
| 17 | 4W (four-wire ohms or temperature) Annunciator |
| 18 |))) (continuity test function enabled) Annunciator |
| 19 | ➤ (diode check function enabled) Annunciator |

For a complete description of the front panel displays and annunciator indications, see “[Front Panel Display](#)” on page 39, and “[Annunciators](#)” on page 41.

The following key refers to the primary front-panel display.

-H.DDD,DDD EFFF

Front-panel display format.

- Negative sign or blank (positive)
- H “ 1/2 ” digit (0 or 1)
- D Numeric digits
- E Exponent (m, k, M)
- F Measurement units (VDC, OHM, HZ, dB)

In This Guide...

1 Quick Start

In this chapter you prepare the multimeter for use and become familiar with the most common front-panel operations.

2 Features and Functions

In this chapter you will find a detailed description of the multimeter's capabilities and operation. This chapter is useful whether you are using the multimeter from the front panel or over the remote interface.

3 Remote Interface

This chapter describes how to connect the multimeter to a remote interface. An introduction to the SCPI programming language is also provided.

4 Measurement Tutorial

This chapter discusses measurement techniques and considerations to help you obtain the best accuracies and reduce sources of measurement error.

5 Specifications

This chapter lists the multimeter's specifications and describes how to interpret these specifications.

Contents

| | | |
|----------|--|-----------|
| 1 | Quick Start | 19 |
| | To Prepare the Multimeter for Use | 20 |
| | Basic Measurement Operation | 21 |
| | Test Lead Connections | 21 |
| | Front Panel Keys | 21 |
| | Front–Panel Display Shortcuts | 22 |
| | To Measure DC Voltage | 23 |
| | To Measure AC Voltage | 23 |
| | To Measure DC Current | 24 |
| | To Measure AC Current | 24 |
| | To Make a 2-Wire Resistance Measurement | 25 |
| | To Make a 4-wire Resistance Measurement | 25 |
| | To Measure Frequency | 26 |
| | To Measure Period | 26 |
| | To Measure Capacitance | 27 |
| | To Make a 2-Wire Temperature Measurement | 28 |
| | To Make a 4-Wire Temperature Measurement | 28 |
| | To Test Continuity | 29 |
| | To Check Diodes | 29 |
| | Other Basics of Operation | 30 |
| | If the Multimeter Does Not Turn On | 30 |
| | To Replace the Power Line Fuse | 31 |
| | To Adjust the Carrying Handle | 32 |
| | To Rack-Mount the Multimeter | 33 |

| | | |
|----------|--|-----------|
| 2 | Features and Functions | 35 |
| | SCPI Commands | 38 |
| | SCPI Language Conventions | 38 |
| | SCPI Language Version | 38 |
| | Front Panel Features | 39 |
| | Front Panel Display | 39 |
| | Displayed Messages | 39 |
| | Self-Guiding Menus | 39 |
| | Annunciators | 41 |
| | Second Display Options | 42 |
| | Turning the Display Off | 42 |
| | Front-Panel Display Shortcuts | 43 |
| | Front Panel Alphanumeric Character Entry | 44 |
| | Front Panel Measurement Configuration Menus | 45 |
| | Configuring DC Voltage and DC Current Measurements | 45 |
| | Configuring AC Voltage and Current Measurements | 46 |
| | Configuring Resistance Measurements | 46 |
| | Configuring Frequency and Period Measurements | 47 |
| | Configuring Temperature Measurements | 47 |
| | Configuring Capacitance Measurements | 48 |
| | Front/Rear Input Terminal Switching | 48 |
| | Advanced Configuration Options | 49 |
| | Power-On State | 49 |
| | Multimeter State Storage | 51 |
| | Multimeter Reset | 52 |
| | Measurement Time and Resolution | 53 |
| | DC, Resistance and Temperature Measurements | 53 |
| | AC Measurements | 55 |
| | AC Filter | 56 |
| | DC Input Impedance | 57 |
| | Autozero | 58 |
| | Ranging | 59 |
| | Null Measurements | 61 |

2 Features and Functions (continued)

Miscellaneous Configuration Settings 62

Radix Character 62

Thousands Separator 62

Beeper 63

Math Functions 64

dBm Measurements 65

dB Measurements 65

Using Statistics 67

Limit Testing 68

Triggering the Multimeter 69

Selecting a Trigger Source 69

Auto Triggering 70

Single Triggering 70

Reading Hold 70

Internal Triggering 71

Software (Bus) Triggering 71

Number of Samples per Trigger 72

Trigger Delay 72

Automatic Trigger Delay 74

External Triggering 76

Trigger Slope 77

Reading Memory 78

Data Logging 79

System-Related Operations 83

Self-Test 83

Error Conditions 84

Calibration 84

| | | |
|----------|---|-----------|
| 3 | Remote Interface Configuration | 85 |
| | Remote Interface Configuration Methods | 86 |
| | Configuring a GPIB Interface | 87 |
| | Configuring a USB Interface | 88 |
| | Configuring a LAN Interface | 89 |
| | LAN Configuration Parameters | 89 |
| | Assigning the LAN IP Address Using Auto-IP | 90 |
| | Setting the LAN IP Address Manually | 90 |
| | Setting the LAN Subnet Mask | 91 |
| | Setting the LAN Default Gateway | 91 |
| | Setting the LAN Host Name | 92 |
| | Setting the LAN DNS Server | 92 |
| | Setting a Web Password | 92 |
| | 34410A/34411A Web Browser Interface | 93 |
| | Setting up a LAN connection from the Front Panel | 94 |
| | Setting up a LAN connection from the Remote Interface | 95 |
| 4 | Measurement Tutorial | 97 |
| | DC Measurement Considerations | 99 |
| | Thermal EMF Errors | 99 |
| | Loading Errors (dc volts) | 99 |
| | Noise Rejection | 100 |
| | Rejecting Power-Line Noise Voltages | 100 |
| | Common Mode Rejection (CMR) | 100 |
| | Noise Caused by Magnetic Loops | 101 |
| | Noise Caused by Ground Loops | 101 |
| | Resistance Measurement Considerations | 102 |
| | 4-Wire Ohms Measurements | 102 |
| | Removing Test Lead Resistance Errors | 103 |
| | Minimizing Power Dissipation Effects | 103 |
| | Errors in High Resistance Measurements | 103 |

4 Measurement Tutorial (continued)

True RMS AC Measurements 104

True RMS Accuracy and High-Frequency Signal Content 105

Estimating High-Frequency (Out-of-Band) Error 107

Other Primary Measurement Functions 109

Frequency and Period Measurement Errors 109

DC Current Measurements 109

Capacitance Measurements 110

Temperature Measurements 112

Probe Type Choice 112

2-Wire vs. 4-Wire Measurements 112

Auto Zero On/Off 113

Integration 113

Offset Compensation 113

NULL Reading: 113

High-Speed Measurements 114

Making High-Speed AC Measurements 114

Making High-Speed dc and Resistance Measurements 115

Other Sources of Measurement Error 116

Settling Time Effects 116

Loading Errors (ac volts) 116

Measurements Below Full Scale 117

High-Voltage Self-Heating Errors 117


AC Current Measurement Errors (Burden Voltage) 117

Low-Level Measurement Errors 117

Common Mode Errors 119

Leakage Current Errors 119

| | | |
|----------|--|------------|
| 5 | Specifications | 121 |
| | DC Characteristics | 123 |
| | AC Characteristics | 126 |
| | Frequency and Period Characteristics | 128 |
| | Capacitance Characteristics | 130 |
| | Temperature Characteristics | 130 |
| | Measurement and System Speeds | 131 |
| | Data From Memory | 132 |
| | General Specifications | 133 |
| | Dimensions | 135 |
| | To Calculate Total Measurement Error | 136 |
| | Accuracy Specifications | 138 |
| | Transfer Accuracy | 138 |
| | 24–Hour Accuracy | 138 |
| | 90–Day and 1–Year Accuracy | 138 |
| | Temperature Coefficients | 138 |
| | Configuring for Highest Accuracy Measurements | 139 |
| | DC Voltage, DC Current, and Resistance Measurements: | 139 |
| | AC Voltage and AC Current Measurements: | 139 |
| | Frequency and Period Measurements: | 139 |



1

Quick Start

One of the first things you will want to do with your multimeter is to become acquainted with its front panel and basic metering functions. We have written the examples in this chapter to prepare the multimeter for use and help you get familiar with some of its measurement operations.

To Prepare the Multimeter for Use 20

- Test Lead Connections 21
- Front Panel Keys 21
- Front-Panel Display Shortcuts 22

Basic Measurement Operation 21

- To Measure DC Voltage 23
- To Measure DC Current 24
- To Measure AC Current 24
- To Make a 2-Wire Resistance Measurement 25
- To Make a 4-wire Resistance Measurement 25
- To Measure Frequency 26
- To Measure Period 26
- To Make a 2-Wire Temperature Measurement 28
- To Make a 4-Wire Temperature Measurement 28
- To Measure Capacitance 27
- To Test Continuity 29
- To Check Diodes 29

Other Basics of Operation 30

- If the Multimeter Does Not Turn On 30
- To Replace the Power Line Fuse 31
- To Adjust the Carrying Handle 32
- To Rack-Mount the Multimeter 33



To Prepare the Multimeter for Use

The following steps help you verify that the multimeter is ready for use.

1 Check the list of supplied items.

Verify that you have received the following items with your multimeter. If anything is missing, contact your nearest Agilent Sales Office.

- One test lead set.
- One power cord.
- One USB 2.0 cable
- *Product Reference* CD-ROM.
- *Agilent Automation Ready* (IO Libraries) CD-ROM.
- One folded *Quick Reference Card*.
- *Certificate of Calibration*.

The product documentation, including the *Programmer's Reference Help* and the product manuals, are included on the *Product Reference* CD-ROM. Printed (hardcopy) manuals are optional, and included only if you ordered them.

2 Connect the power cord and turn on the multimeter.

The front-panel display will light up while the multimeter performs its power-on self-test. The multimeter powers up in the dc voltage function with autoranging enabled (unless a previous user has configured power-up using a non-default stored state (see "[Multimeter State Storage](#)" on page 51).

Basic Measurement Operation

Each of the next several subsections will introduce a type of measurement and show front-panel connections. **Basic measurements can be taken with the factory default settings.** A more complete description of all multimeter functions, measurement parameter configuration and remote interface operation can be found in Chapter 2. Some basics of operation follow:

Test Lead Connections

For each measurement, connect the leads as shown. The arrangement of the test lead connections illustrated are the same for the front or rear terminals.

*Before making test lead connections, press the **Front/Rear** button in to use the rear terminals, or leave it extended to use the front terminals.*

WARNING

Do not change the position of the Front/Rear button on the front panel while signals are present on either the front or rear set of terminals. Switching while high voltages or currents are present may cause instrument damage, and increase the risk of electric shock.

Front Panel Keys

The front panel has two rows of keys to select various functions and operations. Pressing a measurement function key (e.g. **DCV**) selects that function. Press **Config** to enter the configuration menu for the selected measurement function.

Most keys have a shifted function printed in blue above the key. To perform a shifted function, press **Shift**. Then, press the key that has the desired label above it.



To view menu selections, use the navigation keypad (i.e. the **Left Arrow** or **Right Arrow** keys). The current (or default) selection is displayed in **FULL BRIGHTNESS**. All other choices are displayed in HALF BRIGHTNESS. The selections on each menu level scroll, but do not wrap. Arrow annunciators on the second display line indicate additional selections to the left or right. To *select* a choice, press **Enter**.

To set numeric parameters, use **Left Arrow** or **Right Arrow** to select a digit, and **Up Arrow** or **Down Arrow** to increase or decrease that digit.








Front-Panel Display Shortcuts

Direct front-panel shortcuts are provided for three commonly used display functions: ranging, digit masking and integration time.







Ranging The multimeter's manual range can be set directly from the navigation keypad.

- To manually change the current multimeter range, press  or . The **ManRng** annunciator will light, and the selected range (e.g. 100mV RANGE) will be briefly displayed on the second line.

Digit Masking The navigation keypad provides a shortcut to mask (change the number of digits displayed) the reading on the main display, easing readability.


- To enable digit masking during any measurement function, press   or  . DIGIT MASK will be displayed, along with a list of choices (3.5, 4.5, 5.5, 6.5 and AUTO) on the secondary display line. Press  or  to scroll through and select one of these settings, then press .

Integration Time (Bandwidth, Gate Time) Four measurement functions allow you to select the multimeter's integration time: dc voltage, dc current, resistance, and temperature. The ac voltage and current measurements allow you to select the ac signal filter (bandwidth). The frequency/period function allows you to select gate time. The navigation keypad provides a shortcut for quickly changing these settings.

- If the multimeter is configured to take the measurement using an integration time in *NPLCs*, pressing  or  during front panel measurement operations will increase or decrease the integration time setting.
- If either the ac voltage or ac current measurement function is selected, pressing  or  during front panel measurement operations will increase or decrease the bandwidth setting.
- If the frequency/period measurement function is selected, pressing  or  during front panel measurement operations will increase or decrease the gate time setting.


To Measure DC Voltage

- Ranges: 100 mV, 1 V, 10 V, 100 V, 1000 V
- Maximum resolution: 100 nV (*on 100 mV range*)
- Configurable parameters: INTEGRATION, RANGE, INPUT Z (input impedance), AUTO ZERO, NULL, and NULL VALUE




To Measure AC Voltage

- Ranges: 100 mV, 1 V, 10 V, 100 V, 750 V
- Maximum resolution: 100 nV (*on 100 mV range*)
- Resolution: Fixed at 6 1/2 digits
- AC Technique: true-RMS, ac-coupled
- Configurable parameters: AC FILTER, RANGE, NULL and NULL VALUE




To Measure DC Current

- Ranges: 100 μ A, 1 mA, 10 mA, 100 mA, 1A, 3A
- Maximum resolution: 10 nA (*on 100 μ A range*)
- Configurable parameters: INTEGRATION, RANGE, AUTO ZERO, NULL, and NULL VALUE




To Measure AC Current

- Ranges: 100 μ A, 1 mA, 10 mA, 100 mA, 1A, 3A
- Maximum resolution: 100 nV (*on 100 mV range*)
- Resolution: Fixed at 6 1/2 digits
- AC Technique: true-RMS, ac-coupled
- Configurable parameters: AC FILTER, RANGE, NULL and NULL VALUE



To Make a 2-Wire Resistance Measurement

- Ranges: 100Ω, 1 kΩ, 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, 100 MΩ
- Maximum resolution: 100 μΩ (on 100Ω range)
- Configurable parameters: INTEGRATION, RANGE, OFFSET COMP, AUTO ZERO, NULL, and NULL VALUE




To null-out the test lead resistance:

- 1 Connect one end of the test leads at the meter, and short the probe ends together.
- 2 Press null.
- 3 Connect the probe ends to the test circuit, and measure the corrected resistance value.


To Make a 4-wire Resistance Measurement

- Ranges: 100Ω, 1 kΩ, 10 kΩ, 100 kΩ, 1 MΩ, 10 MΩ, 100 MΩ
- Maximum resolution: 100 μΩ (on 100Ω range)
- Configurable parameters: INTEGRATION, RANGE, OFFSET COMP, AUTO ZERO, NULL, and NULL VALUE




To Measure Frequency

- Measurement band: 3Hz to 300 kHz (0.33 sec to 3.3 μ sec)
- Input signal range: 100 mVAC to 750 VAC
- Maximum resolution:
 - 0.1 ppm for 1 sec gate time
 - 1 ppm for 100 ms gate time
 - 10 ppm for 10 ms gate time
 - 100 ppm for 1 ms gate time
- Technique: reciprocal counting
- Configurable parameters: GATE TIME, RANGE, AC FILTER, NULL and NULL VALUE




To Measure Period

- Measurement band: (0.33 sec to 3.3 μ sec)
- Input signal range: 100 mVAC to 750 VAC
- Maximum resolution:
 - 0.1 ppm for 1 sec gate time
 - 1 ppm for 100 ms gate time
 - 10 ppm for 10 ms gate time
 - 100 ppm for 1 ms gate time
- Technique: reciprocal counting
- Configurable parameters: GATE TIME, RANGE, AC FILTER, NULL and NULL VALUE



To Measure Capacitance

- Ranges: 1 nF, 10 nF, 100 nF, 1 μ F, 10 μ F
- Maximum resolution: 100 pF (*on 1 nF range*)
- Configurable parameters: RANGE, NULL, and NULL VALUE




To null-out the test lead capacitance:

- 1 Disconnect the + lead's probe end from the test circuit, and leave open.
- 2 Press null.
- 3 Reconnect the + lead's probe end to the test circuit, and measure the corrected capacitance value.


To Make a 2-Wire Temperature Measurement

- Probe types: 2.2 k Ω , 5 k Ω , 10 k Ω thermistors; 0.00385%/°C RTD
- Maximum resolution: 0.001° for RTDs; 0.01° for thermistors
- Configurable parameters: PROBE TYPE, THERMISTOR or RTD value, AUTO ZERO (2-wire thermistor probes only), OFFSET COMP (*RTD probes only*), INTEGRATION, NULL, NULL VALUE, and UNITS




To Make a 4-Wire Temperature Measurement

- Probe types: 2.2 k Ω , 5 k Ω , 10 k Ω thermistors; 0.00385%/°C RTD
- Maximum resolution: 0.001° for RTDs; 0.01° for thermistors
- Configurable parameters: PROBE TYPE, THERMISTOR or RTD value, OFFSET COMP (*RTD probes only*), INTEGRATION, NULL, NULL VALUE, and UNITS




To Test Continuity

- Test current source: 1 mA
- Maximum resolution 0.1Ω (*range is fixed at 1 k Ω*)
- Beeper Threshold: beeps below 10Ω



To Check Diodes

- Test current source: 1 mA
- Maximum resolution $100\mu\text{V}$ (*range is fixed at 1 VDC*)
- Beeper Threshold: $0.3\text{V} \leq \text{voltage}_{\text{measured}} \leq 0.8\text{V}$ (*not adjustable*)



- The diode check function is used to indicate correct diode operation; closed-circuit on forward bias and open-circuit on reverse-bias.

Other Basics of Operation

If the Multimeter Does Not Turn On

Use the following steps to help solve problems you might encounter when turning on the multimeter. If you need more help, see the *Service Guide* for instructions on returning the multimeter to Agilent for service.

1 Verify that there is ac power to the multimeter.

First, verify that the multimeter's Power switch is in the "On" position. Also, make sure that the power cord is firmly plugged into the power module on the rear panel. You should also make sure that the power source you plugged the multimeter into is energized.

2 Verify the power-line voltage setting.

The line voltage is set to the proper value for your country when the multimeter is shipped from the factory. Change the voltage setting if it is not correct. The settings are: 100, 120, 220, or 240 Vac (for 230 Vac operation, use the 220 Vac setting).

See "To Replace the Power Line Fuse" on page 31 if you need to change the line-voltage setting.

3 Verify that the power-line fuse is good.


The multimeter is shipped from the factory with a power-line fuse installed. The supplied fuse is a **250 mAT, 250V, slow-blow, 5x20mm fuse, Agilent part number 2110-0817**. If you determine that the fuse is faulty, replace it with one of the same size and rating.

See "To Replace the Power Line Fuse" on page 31 if you need to replace the power-line fuse.


The *current input path* is also fused. The supplied fuse is a **3 AT, 250V, slow-blow, 5x20mm fuse, Agilent part number 2110-0780**, and is housed in a standard screw-in fuse holder on the left side of the rear panel. If you determine that the fuse is faulty, replace it with one of the same size and rating.

To Replace the Power Line Fuse


- 1** Remove the power cord. Then depress tab ① and pull fuse holder ② from the rear panel.




- 2** Remove the line voltage selector from the fuse holder assembly.



- 3** Rotate the line-voltage selector, and reinstall so the correct voltage appears in the fuse holder window.



- 4** Replace the fuse holder assembly in the rear panel.





Verify that the correct line voltage is selected and the power line fuse is good.

NOTE

For multimeter operations with a 230 VAC supply, set the line-voltage selector to 220V.

To Adjust the Carrying Handle

To adjust the position, grasp the handle by the sides and *pull outward*. Then, rotate the handle to the desired position.



To Rack-Mount the Multimeter

You can mount the multimeter in a standard 19-inch rack cabinet using one of three optional kits available. Instructions and mounting hardware are included with each rack-mounting kit. Any Agilent System II instrument of the same size can be rack-mounted side-by-side with the 34410A/34411A.


You must remove the carrying handle, and the front and rear rubber bumpers, *before* rack-mounting the multimeter.




To remove each rubber bumper, stretch a corner and slide it off



To remove the handle, rotate it to the vertical position and pull the ends outward.



To rack-mount a single instrument, order adapter kit 5063-9240



To rack-mount two instruments side-by-side, order link-lock kit 5061-9694 and flange kit 5063-9212



2 Features and Functions

SCPI Commands 38

SCPI Language Conventions 38

SCPI Language Version 38

Front Panel Features 39

Front Panel Display 39

Displayed Messages 39

Self-Guiding Menus 39

Annunciators 41

Second Display Options 42

Turning the Display Off 42

Front-Panel Display Shortcuts 43

Ranging 43

Digit Masking 43

Integration Time (Bandwidth, Gate Time) 43

Front Panel Alphanumeric Character Entry 44

Front Panel Measurement Configuration Menus 45

Configuring DC Voltage and DC Current Measurements 45

Configuring AC Voltage and Current Measurements 46

Configuring Resistance Measurements 46

Configuring Frequency and Period Measurements 47

Configuring Temperature Measurements 47

Configuring Capacitance Measurements 48

Front/Rear Input Terminal Switching 48



Advanced Configuration Options 49

Power-On State 49

Multimeter State Storage 51

Multimeter Reset 52

Measurement Time and Resolution 53

DC, Resistance and Temperature Measurements 53

AC Measurements 55

AC Filter 56

DC Input Impedance 57

Autozero 58

Ranging 59

Null Measurements 61

Miscellaneous Configuration Settings 62

Radix Character 62

Thousands Separator 62

Beeper 63

Math Functions 64

dBm Measurements 65

dB Measurements 65

Using Statistics 67

Limit Testing 68

Triggering the Multimeter 69

Selecting a Trigger Source 69

Auto Triggering 70

Single Triggering 70

Reading Hold 70

Internal Triggering 71

Software (Bus) Triggering 71

Number of Samples per Trigger 72

Trigger Delay 72

Automatic Trigger Delay 74

External Triggering 76

Trigger Slope 77

Data Logging 79

System-Related Operations 83

Self-Test 83

Error Conditions 84

Calibration 84

SCPI Commands

The instrument complies with the rules and conventions of the present version of SCPI (*Standard Commands for Programmable Instruments*).

SCPI Language Conventions

Throughout this guide, the following conventions are used for SCPI command syntax for remote interface programming:

- Braces ({ }) enclose the parameter choices for a given command string. The braces are not sent with the command string.
- A vertical bar (|) separates multiple parameter choices for a given command string.
- Triangle brackets (< >) indicate that you must specify a value for the enclosed parameter. The brackets are not sent with the command string.
- Some parameters are enclosed in square brackets ([]). This indicates that the parameter is optional and can be omitted. The brackets are not sent with the command string. If you do not specify a value for an optional parameter, the instrument chooses a default value.

SCPI Language Version

You can determine the SCPI version with which the multimeter is in compliance by sending a command from the remote interface.

- You can query the SCPI version from the remote interface only.
- **Remote Interface Operation:** The following command queries the multimeter's SCPI language version:
SYSTem:VERSion?
- The SCPI version is returned in the form "YYYY.V", where "YYYY" represents the year of the version, and "V" represents a version number for that year (for example, 1994.0).

Front Panel Features

Front Panel Display

The 34410A and 34411A multimeters feature a dual-line, alphanumeric display, *plus* a set of text annunciators to indicate non-default operational states.

















Displayed Messages

During menu-driven operations (e.g. measurement configuration), the primary display line indicates the configuration feature or menu, and the second display line indicates the submenu, configuration choices or parameters. The second display line also displays temporary messages, when exiting menus or to convey meter state changes.

During measurement operations, the primary display line shows the measurement reading and selected measurement function, and the second display line can be enabled to display secondary measurements.

Self-Guiding Menus

The 34410A and 34411A multimeters utilize context-sensitive, self-guiding menus for you to configure measurement functions. The following general directions apply to most menu operations.

- Instructions in this guide which use the words “navigation keypad” refer to the , ,  and  keys surrounding the  key.
- Several keys (or shifted key sequences) open a context-sensitive menu. These include:
 - : to configure the currently selected measurement function.
 - : to select a secondary measurement to display on the second display line.
 - : to set up and use the Data Logger function.
 -   (**Math**): to turn on and select the Math functions.
 -   (**Auto Trig**): to return the multimeter to Auto Trigger mode, enable reading hold or configure advanced triggering options.
 -   (**Utility**): to configure utility options or the remote interface.
 -   (**Reset**): to reset the multimeter to its reset state (equivalent to the *RST command in SCPI).

The shifted functions are shown in parentheses, after the key sequence.

- When you press **(Shift)**, the **Shift** annunciator is lit, indicating that the shifted functions are active.
- If the multimeter is in the remote interface operational mode (**Remote** annunciator is lit), pressing **(Shift)** (**Local**) returns the multimeter to Local (front panel) operation.
- Once you have entered a menu, to *view* menu choices (selections) after pressing the key or shifted key sequence, use the **(Left Arrow)** or **(Right Arrow)** keys.

The selections on each menu level scroll, but do not wrap. Pressing **(Left Arrow)** or **(Right Arrow)** produces an audible “click” as you scroll, until you reach the end of the list.

Arrow annunciators on the second display line indicate additional selections to the left or right. These do not light if you are at the end of the selection list, or if all selections are currently visible.

The current (or default) selection is displayed in **FULL BRIGHTNESS**. All other choices are displayed in **HALF BRIGHTNESS**.

- To *select* a choice, press **(Enter)**. This action takes you to the next menu level. If you are already at the last selection level in the menu, pressing **(Enter)** exits the menu structure.
- To *review* a current menu configuration, pressing **(Enter)** repeatedly without pressing the navigation keys will take you in order through all current selections in sequence and exit the menu.
- To step through the remaining menu choices after making desired selections, you may hold down **(Enter)** or the key that you used to enter the menu structure (e.g. **(Config)**).
- To *exit* a menu *before* completing its sequence, press **(Exit)**. If you have made changes, you will be prompted whether to save or discard them.

Annunciators





The annunciator line has seventeen possible indications, shown below. All display for a few seconds during the power-on sequence. Subsequently the annunciators light to indicate the following meter states:

- * (“sample annunciator”)– Turns on during a measurement.
- **Hi-Z** - For DC voltage measurements in the 100 mV, 1V or 10V ranges, an input impedance of >10 GΩ is configured.
- **OComp** - For resistance measurements in the 100Ω, 1 kΩ and 10 kΩ ranges, offset compensation is enabled.
- **ManRng** - For the selected measurement function, auto ranging is disabled (a fixed meter range is selected).
- **Trig** - The single triggering mode (from the front panel or rear trigger terminal) is enabled, and the multimeter is in the “wait-for-trigger” state.
- **Hold** - The reading hold function is enabled.
- **Remote** - The multimeter is in the remote interface operational mode.
- **Error** - A hardware error or remote interface error has been detected.
- **Null** - For the selected measurement function, the null feature is enabled.
- **Shift** - The Shift key has been pressed.
- **Math** - Either the dB or dBm math feature is enabled.
- **Stats** - The statistics math feature is enabled.
- **Limits** - For an applicable measurement function, the limits math feature is enabled.
- **Rear** - The multimeter will recognize input connections made at the rear panel terminals (the **Front/Rear** switch is set to **Rear**).
- **4W** - A 4-wire resistance or temperature measurement function mode is selected.
- **))** - The continuity test function is selected.
- **⤴** - The diode test function is selected.

Second Display Options

Four measurement functions have an auxiliary measurement that can be displayed in parallel on the second display line, as follows:

| Primary Function | Dual Measurement Option |
|---|-------------------------|
| DC V, DC I | Peak-to-Peak value* |
| FREQ | AC Voltage** |
| TEMP | Raw Resistance*** |
| * largest spike measured during reading integration | |
| ** ac voltage of the input waveform | |
| *** actual raw resistance measured across temperature probe and leads | |

- **Front Panel Operation:** To enter the second display menu for the selected measurement function, press . Then press  or  to select the desired second display option, and press . Once the second display is enabled, you can always scroll through the available display options, including STATS or LIMITS if these Math functions are enabled.
- **Remote Interface Operation:** The following command selects the measurement or math function to be displayed on the second display line. The <feed> parameter is a quoted ASCII string designating the function to be displayed, such as VOLTage:PTPeak.
 DISPlay:WINDow2: TEXT:FEED <feed>
 The following query returns the currently selected <feed> parameter, as a quoted ASCII string:
 DISPlay:WINDow2: TEXT:FEED?
 Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Turning the Display Off

This feature is available from the remote interface only.





For security reasons, you may wish to disable the front panel display. When disabled, the entire front panel display (except for the **Error** and **Remote** annunciators) goes dark.

- **Remote Interface Operation:** The following command disables the front panel display:
 DISP OFF
 The following command queries the front panel display setting:
 DISP?
 The query returns a “0” (OFF) or “1” (ON).
 Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.








Front-Panel Display Shortcuts

Direct front-panel shortcuts are provided for three commonly used display functions: ranging, digit masking and integration time.






Ranging The multimeter's manual range can be set directly from the navigation keypad.

- To manually change the current multimeter range, press  or . The **ManRng** annunciator will light, and the selected range (e.g. 100mV RANGE) will be briefly displayed on the second line.
- To quickly toggle between the selected manual range and auto ranging, press  (**Auto Rng**). The second line will briefly display the selected range or AUTO RANGE and the **ManRng** annunciator will light or turn off, as appropriate. *Note: This is a dual-function key, not a shifted key; pressing  when in a configuration menu will exit the menu.*















Digit Masking The navigation keypad provides a shortcut to mask (change the number of digits displayed) the reading on the main display, easing readability.

- To enable digit masking during any measurement function, press   or  . DIGIT MASK will be displayed, along with a list of choices (3.5, 4.5, 5.5, 6.5 and AUTO) on the secondary display line. Press  or  to scroll through and select one of these settings, and press .
- Masking digits only affects what is displayed; it does not affect measurement speed or accuracy.

Integration Time (Bandwidth, Gate Time) Four measurement functions allow you to select the integration time: dc voltage, dc current, resistance, and temperature. The ac voltage and current measurements allow you to select the ac signal filter (bandwidth). The frequency/period function allows you to select gate time. The navigation keypad provides a shortcut for quickly changing these settings.









- If the multimeter is configured to take the measurement using an integration time in *NPLCs*, pressing  or  during front panel measurement operations will increase or decrease the integration time setting, and briefly display the new setting on the second display line (e.g. if the setting was 0.2 NPLC, the display will show 0.06 NPLC when you press ). Repeated use of  or  will scroll through the entire range of integration time settings (0.001*, 0.002*, 0.006, 0.02, 0.06, 0.2, 1, 2, 10 and 100 NPLC).

**These additional two settings are provided on model 34411A only.*

- If the multimeter is configured to take the measurement using an *aperture* integration time, pressing  or  during front panel measurement operations will display APERTURE on the the main display line and the current setting on the second display line (e.g. 101.005mSEC). You can then use the navigation keypad to change the aperture setting. Press  to save the setting. If you wish to keep the previous setting, press  and do not save the changes.
- If either the ac voltage or ac current measurement function is selected, pressing  or  during front panel measurement operations will increase or decrease the bandwidth setting, and briefly display the new setting on the second display line (e.g. if the setting was 20 HZ : MEDIUM, the display will show 3 HZ : SLOW when you press ). Repeated use of  or  will scroll through the selection of three bandwidth settings (3 HZ : SLOW, 20 HZ : MEDIUM and 200 HZ : FAST).
- If the frequency/period measurement function is selected, pressing  or  during front panel measurement operations will increase or decrease the gate time setting, and briefly display the new setting on the second display line (e.g. if the setting was 0.1 GATE TIME, the display will show 0.01 GATE TIME when you press ). Repeated use of  or  will scroll through the selection of gate time settings (0.001 GATE TIME, 0.01 GATE TIME, 0.1 GATE TIME and 1 GATE TIME).

Front Panel Alphanumeric Character Entry

When you are in the menus for storing instrument states (see “*Multimeter State Storage*” on page 51), data logging and advanced triggering, you may need to manually enter an alphanumeric character on the second display line.

- **To enter a number or character**, press  or  to select the displayed character (digit or letter) you wish to edit. The selected character will flash to indicate it can be edited. Use the  and  keys to modify a digit (from 0 to 9) or a letter (from A to Z).
- **To quickly enter large numbers**, you may press  to scroll over to the most significant digit allowed and/or add leading zeros, instead of incrementing the less significant digits up from zero. For non-zero floating-point entries, you may also press  to scroll to the magnitude prefix (e.g. u, m, k, M), then use the  and  keys to change the numerical entry.

The left and right arrow annunciators on the second display line will indicate if there are editable characters left or right of the one selected.

Front Panel Measurement Configuration Menus

Each measurement function is configured separately, except for Ω **2W** and Ω **4W** (which are partially inter-dependent), and for Frequency and Period, (which share a configuration menu). The configuration settings (e.g. range, null value, etc.) for each measurement function are retained when switching between functions.

- **To enter the configuration menu** for any selected measurement function, press **Config**. The menus are context-sensitive; only the options applicable to the selected function will appear. Descriptions of the menu selections are listed below, for each of the six groups of primary measurement functions with configurable options (none for diode/continuity checks.)
- When digit masking is enabled (see *“Digit Masking”* on page 43) the DIGIT MASK submenu will appear before other configuration choices.
- *For a detailed description of the configuration choices, see “Advanced Configuration Options” on page 49.*

Configuring DC Voltage and DC Current Measurements

For dc voltage and current measurements, your configuration menu choices are: INTEGRATION, RANGE, AUTO ZERO, NULL and NULL VALUE. For dc voltage measurements, you can also configure INPUT Z.

- **INTEGRATION:** Allows you to set the integration time for the measurement in two ways; in power-line cycles (select NPLC) or in seconds (select APERTURE).
- **RANGE:** Allows you to select a fixed range using *manual ranging* (select MANUAL), or let the multimeter automatically select the range using the *autoranging* feature (select AUTO).
- **INPUT IMPEDANCE:** Allows you to select a dc input impedance of 10 M Ω (select 10M Ω) or >10 G Ω (select HI-Z) for the 100 mVDC, 1 VDC and 10 VDC ranges only.
- **AUTO ZERO:** Allows you to enable for all readings (select ON), enable for one reading (select ONCE), or disable (select OFF) the auto zero feature, which subtracts a subsequent zero reading from each measurement taken, to prevent offset voltages in the multimeter’s input circuitry from affecting measurement accuracy.
- **NULL:** Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- **NULL VALUE:** Allows you to view and edit the null value.

Configuring AC Voltage and Current Measurements

For ac voltage and current measurements, your configuration menu choices are: AC FILTER, RANGE, NULL and NULL VALUE.

- AC FILTER: Allows you to select one of three choices (SLOW, MEDIUM or FAST) of bandwidth (ac signal filter), enabling you to optimize low-frequency accuracy or achieve faster ac settling times.
- RANGE: Allows you to let the multimeter automatically select the range using the *autoranging* feature (select AUTO), or you may select a fixed range using *manual ranging* (select MANUAL).
- NULL: Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- NULL VALUE: Allows you to view and edit the null value.

Configuring Resistance Measurements

For 2-wire and 4-wire resistance measurements, your configuration menu choices are: INTEGRATION, RANGE, OFFSET COMP, AUTO ZERO, NULL and NULL VALUE.

- INTEGRATION: Allows you to set the integration time for the measurement in two ways; in power-line cycles (select NPLC) or in seconds (select APERTURE).
- RANGE: Allows you to let the multimeter automatically select the range using the *autoranging* feature (select AUTO), or you may select a fixed range using *manual ranging* (select MANUAL).
- OFFSET COMP: Allows you to enable (select ON) or disable (select OFF) the offset compensation feature. With offset compensation enabled, the multimeter makes a normal resistance measurement first, followed by a second measurement to determine any offset voltage in the input circuitry. The resultant displayed measurement corrects for this offset. Enabling offset compensation increases measurement time.
- AUTO ZERO: Allows you to enable for all readings (select ON), enable for one reading (select ONCE), or disable (select OFF) the auto zero feature, which subtracts a subsequent zero reading from each measurement taken, to prevent offset voltages in the multimeter's input circuitry from affecting measurement accuracy.
- NULL: Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- NULL VALUE: Allows you to view and edit the null value.

Configuring Frequency and Period Measurements

For frequency and period measurements, your configuration menu choices are: CONFIGURE, GATE TIME, RANGE, AC FILTER, NULL and NULL VALUE.

- **CONFIGURE:** Allows you to select either FREQUENCY or PERIOD as the primary measurement.
- **GATE TIME:** Allows you to select one of four choices (0.001, 0.01, 0.1 or 1) for measurement gate time, in seconds.
- **RANGE:** Allows you to let the multimeter automatically select the range using the *autoranging* feature (select AUTO), or you may select a fixed range using *manual ranging* (select MANUAL).
- **AC FILTER:** Allows you to select one of three choices (SLOW, MEDIUM or FAST) of bandwidth (ac signal filter), enabling you to optimize low-frequency accuracy or achieve faster ac settling times.
- **NULL:** Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- **NULL VALUE:** Allows you to view and edit the null value.

Configuring Temperature Measurements

For temperature measurements, your configuration menu choices are: PROBE TYPE, OFFSET COMP, AUTO ZERO, INTEGRATION, NULL, NULL VALUE, and UNITS.

- **PROBE TYPE:** Allows you to select from four choices (RTD–4W, RTD–2W, THERMISTOR–2W, or THERMISTOR–4W) of temperature probe type.
- **OFFSET COMP (*for RTD probes only*):** Allows you to enable (select ON) or disable (select OFF) the offset compensation feature. With offset compensation enabled, the multimeter makes a normal temperature measurement first, followed by a second measurement to determine any offset voltage in the input circuitry. The resultant displayed measurement corrects for this offset. Enabling offset compensation increases measurement time.
- **AUTO ZERO (*for 2-wire thermistor probes only*):** Allows you to enable (select ON) or disable (select OFF) the auto zero feature, which subtracts a subsequent zero reading from each measurement taken, to prevent offset voltages in the multimeter's input circuitry from affecting measurement accuracy.

- **INTEGRATION:** Allows you to set the integration time for the measurement in two ways; in power-line cycles (select NPLC) or in seconds (select APERTURE).
- **NULL:** Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- **NULL VALUE:** Allows you to view and edit the null value.
- **UNITS:** Allows you to select from three choices of temperature degree units, Celsius (select C), Fahrenheit (select F) or Kelvin (select K).

Configuring Capacitance Measurements

For capacitance measurements, your configuration menu choices are: RANGE, NULL and NULL VALUE.

- **RANGE:** Allows you to let the multimeter automatically select the range using the *autoranging* feature (select AUTO), or you may select a fixed range using *manual ranging* (select MANUAL).
- **NULL:** Allows you to enable (select ON) or disable (select OFF) the null measurement feature, which measures the difference between a stored null value and the input signal.
- **NULL VALUE:** Allows you to view and edit the null value.

Front/Rear Input Terminal Switching

Any measurement made using the front panel input terminals may also be made using the input terminals on the rear panel. See *“The Front Panel at a Glance”* on page 8, for the location of the front/rear switch.

WARNING

Do not change the position of the Front/Rear button on the front panel while signals are present on either the front or rear set of terminals. Switching while high voltages or currents are present may cause instrument damage, and increase the risk of electric shock.

- **Remote Interface Operation:** You may only select the terminals using the front panel switch, but you may remotely query the multimeter to determine which terminals are selected. The query:

ROUTe:TERMinals?

returns either “FRON” or “REAR”

Refer to the *Agilent 34410A/34411A Programmer’s Reference* for complete description and syntax for this command.

Advanced Configuration Options

Power-On State

At power-on, the multimeter displays all segments of the two-line display and all annunciators, for a period of several seconds, then changes to the default display mode. The following tables show the state of multimeter parameters at power on. Parameters marked with a bullet (●) are stored in non-volatile memory, and are not affected by power-on or a system reset. For those parameters, the initial factory settings are shown. All other parameters are stored in volatile memory, and are reset to the indicated values at power-on, after a front-panel Reset command, or after a *RST or SYSTem:PRESet command is issued from the remote interface.

| Measurement Configuration | Factory Setting |
|--|--|
| Function | DC Volts |
| Range | Autorange (for all functions) * |
| Resolution | 6.5 digits (0.3 ppm x Range) * |
| Integration Time | NPLC on, 1 PLC * |
| Autozero | On * |
| Aperture | Off, 1 second * |
| ● Input Impedance | ● 10 M Ω (fixed for all VDC ranges) |
| AC Input Filter (bandwidth) | 20 Hz (medium filter) |
| Nulls (for individual measurement functions) | Off, 0 for all measurement functions |
| Second Display | Off |
| | *for all dc measurements |

| Math Operations | Factory Setting |
|--------------------------|-------------------------|
| Math State | Off |
| Math Registers | Cleared (all registers) |
| dB relative value | 0 |
| dBm reference resistance | 600 Ω |

| Triggering Operations | Factory Setting |
|-----------------------|-----------------|
| Trigger Count | 1 |
| Trigger Source | Immediate |
| Trigger Delay | Auto Delay |
| Sample Count | 1 |
| Sample Source | Auto |
| Sample Timer | 1 second |

| System-Related Operations | Factory Setting |
|---------------------------|--|
| ● Beeper Mode | ● On |
| ● Radix Character | ● Period |
| ● Thousands Separator | ● On |
| Display State | On |
| Reading Memory | Cleared |
| Error Queue | Cleared at Power-On; <u>not cleared</u> by a front panel or remote interface Reset command |
| ● Stored States | ● No change |
| ● Calibration State | ● Secured |

| Input/Output Configuration | Factory Setting |
|---|--|
| Enable Interfaces:* | |
| ● LAN | ● Enabled |
| ● GPIB | ● Enabled |
| ● USB | ● Enabled |
| Lan Settings:* | |
| ● DHCP | ● On |
| ● Auto IP | ● On |
| ● IP Address | ● 169.254.4.10** |
| ● Subnet Mask | ● 255.255.0.0 |
| ● Default Gateway | ● 0.0.0.0 |
| ● DNS Server | ● 0.0.0.0 |
| ● Host Name | ● A-34410A-nnnn** |
| ● LAN Services | ● Enable All |
| GPIB Settings:* | |
| ● GPIB Address | ● 22 |
| * Interface enable or LAN setting changes take effect only after a CPU reboot | ** For model 34411A, the default IP address is 169.254.4.11 and host name is A-34411A-nnnn; also note that nnnn is the last 4 digits of the serial number. |

During a measurement session, configuration settings may be saved in one of four Stored States, for recall after a power-on or reset operation. See *“Multimeter State Storage”* on page 51 for more information.

Multimeter State Storage






The current multimeter state, including all settings for measurement configuration, math operations, triggering operations, system operations and I/O configuration, can be saved in one of five system memory states, and subsequently recalled. Store State 0 retains the multimeter configuration at power down. Store States 1 through 4 are available for storing other configurations.

- **Front Panel Operation:** To *store* the current multimeter state, press **(Shift)** **(Data Log)** (**Utility**). UTILITY MENU will be displayed. Press **(▶)** as needed to select STORE/RECALL, and press **(Enter)**. Select STORE, and press **(Enter)**. STORE STATE will be displayed on the secondary display line. Press **(▶)** as needed to select 1: STATE_1, 2: STATE_2, 3: STATE_3, or 4: STATE_4, and press **(Enter)**. CHANGE NAME will be displayed, along with the current state name on the secondary display line. Use the navigation keypad to enter a name of your choice for the selected multimeter state, up to twelve characters in length, and press **(Enter)**. STATE STORED will be displayed briefly.

To *recall* any of the five stored multimeter states, enter the STORE/RECALL level of the UTILITY MENU. Press **(▶)** as needed to select RECALL, and press **(Enter)**. RECALL STATE will be displayed, along with any stored states, on the second display line. Press **(▶)** as needed to select a stored state, and press **(Enter)**. STATE RECALLED will be displayed briefly.

To *name* any manually stored state (1 through 4), enter the STORE/RECALL level of the UTILITY MENU. Press **(▶)** as needed to select RENAME, and press **(Enter)**. RENAME STATE will be displayed, along with any stored states, on the second display line. Press **(▶)** as needed to select a stored state, and press **(Enter)**. CHANGE NAME will be displayed. Use the navigation keypad to change the name of the selected state, up to 8 alphanumeric characters. CHANGE SAVED will be displayed briefly.



To *delete* any manually stored state (1 through 4), enter the STORE/RECALL level of the UTILITY MENU. Press **(▶)** as needed to select DELETE, and press **(Enter)**. DELETE STATE will be displayed, along with any stored states, on the second display line. Press **(▶)** as needed to select a stored state, and press **(Enter)**. STATE DELETED will be displayed briefly.

To select any stored state (0 through 4) as the power-on default state, enter the STORE/RECALL level of the UTILITY MENU. Press  as needed to select PWR-ON, and press . PWR-ON-AUTO will be displayed. Select ON (OFF is the default), and press . PWR-ON STATE will be displayed, along with any stored states, on the second display line. Press  as needed to select a stored state, and press . CHANGE SAVED will be briefly displayed on the secondary display line.

- **Remote Interface Operation:** Refer to the MEMORY command subsystem in the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for the commands which store, recall and name multimeter storage states.

Multimeter Reset

A fast system reset feature is provided. This function resets all multimeter settings to their factory settings, except if the power-on state has been manually set to a stored state (see explanation on [page 52](#)). The result is the same as cycling power to the unit with the front panel **Power** button (except for the Error Queue, which is not cleared with a fast system reset), but does so several seconds faster.

- Refer to “Power-On State” on [page 49](#) for a complete listing of the settings affected by a (front panel or remote interface) reset command.
- **Front Panel Operation:** To reset the multimeter, press   (Reset). RESET DMM will be displayed, along with the options NO (default) and YES. Select YES to enable the reset operation or NO to cancel it.
- **Remote Interface Operation:** The following commands resets the multimeter to the instrument preset state:

```
SYSTem:PRESet
*RST
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Measurement Time and Resolution

The table below lists the measurement time configuration options available for the multimeter, for each measurement function.

| Measurement Function | Selectable Measurement Time Parameter(s) |
|---|---|
| dc voltage, dc current, resistance, temperature | NPLC Values: 0.001*, 0.002*, 0.006, 0.02, 0.06, 0.2, 1, 2, 10, 100 (PLCs) Aperture Values: settable from 300 μ s to 1s** |
| ac voltage, ac current | AC Filter Values: 3 Hz, 20 Hz, 200 Hz |
| frequency / period | AC Filter Values: 3 Hz, 20 Hz, 200 Hz Gate Time Values: 0.001, 0.01, 0.1, 1 second |
| capacitance, continuity check, diode check | fixed measurement time— no selectable parameters |
| | *These two settings are provided on model 34411A only. **Model 34411A is settable down to 100 μ s. |

DC, Resistance and Temperature Measurements

For dc voltage, dc current, resistance and temperature measurements only, the multimeter allows for two ways to set integration *time*, both of which affect the measurement *resolution*. These are in the number of power-line cycles (NPLCs) and aperture.

Using *NPLCs* sets the number of power line cycles, during which the multimeter's analog-to-digital (A/D) converter samples the input signal for a measurement. The multimeter automatically detects the AC line frequency, using it and the NPLC selection to set integration time. Selecting a larger NPLC value yields better resolution; a shorter value provides for faster measurements. Choices are 0.001 *, 0.002*, 0.006, 0.02, 0.06, 0.2, 1, 2, 10 or 100 (PLCs).

**These two additional settings are provided on Model 34411A only.*

- To allow for normal mode (line frequency noise) rejection, you must select an integral number of power line cycles (e.g. 1, 10 or 100 NPLC).

- **Front Panel Operation:** After selecting an applicable measurement function (**DC V**, **DC I**, **Ω 2W**, **Ω 4W** or **TEMP**), press **Config** until INTEGRATION is displayed. Press **Left** or **Right** to select NPLC, then press **Enter** or **Config** to display NPLC on the primary line and a range of choices on the secondary line. Press **Left** or **Right** to select the desired NPLC value, and press **Enter**. Then step through or exit the configuration menu.

- **Remote Interface Operation:** The following commands set the integration time in NPLC:

```
[SENSe:]VOLTage[:DC]:NPLC {<PLCS>|MIN|MAX|DEF}
[SENSe:]CURRent[:DC]:NPLC {<PLCS>|MIN|MAX|DEF}
[SENSe:]RESistance:NPLC {<PLCS>|MIN|MAX|DEF}
[SENSe:]FREStance:NPLC {<PLCS>|MIN|MAX|DEF}
[SENSe:]TEMPerature:NPLC {<PLCS>|MIN|MAX|DEF}
```

The following command (similar queries for current, resistance and temperature) queries the integration time setting:

```
[SENSe:]VOLTage[:DC]:NPLC? [{MIN|MAX}]
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Aperture is the period, measured in *seconds*, during which the multimeter's analog-to-digital (A/D) converter samples the input signal for a measurement. A longer aperture yields better resolution; a shorter aperture provides for faster measurements. This selectable feature allows the user to set a specific measurement period, not based on power line frequency. Selectable values range from 300 μs to 1 second for the 34410A, and from 100 μs to 1 second for the 34411A.

- To allow for normal mode (line frequency noise) rejection, select the NPLC option for INTEGRATION, with an integral number of NPLCs. Use the APERTURE method only if you *need* precise control over the multimeter's integration time, in seconds.
- **Front Panel Operation:** After selecting an applicable measurement function (**DC V**, **DC I**, **Ω 2W**, **Ω 4W** or **TEMP**), press **Config** until INTEGRATION is displayed. Press **Left** or **Right** as needed to select APERTURE, then press **Enter** or **Config** to display APERTURE on the primary line and the current aperture value on the secondary line. Use the navigation keypad to select the desired aperture value, and press **Enter**. Then step through or exit the configuration menu.

- **Remote Interface Operation:** The following commands set the aperture value, in seconds:

```
[SENSe:]VOLTage[:DC]:APERTure {<seconds>|MIN|MAX|DEF}
[SENSe:]CURRent[:DC]:APERTure {<seconds>|MIN|MAX|DEF}
[SENSe:]RESistance:APERTure {<seconds>|MIN|MAX|DEF}
[SENSe:]FRESistance:APERTure {<seconds>|MIN|MAX|DEF}
[SENSe:]TEMPerature:APERTure {<seconds>|MIN|MAX|DEF}
```

The following command (similar queries for current, resistance and temperature) queries the aperture setting:

```
[SENSe:]VOLTage[:DC]:APERTure?[ {MIN|MAX} ]
```

The following command (similar queries for current, resistance and temperature) queries if aperture mode is enabled:

```
[SENSe:]VOLTage[:DC]:APERTure:ENABLEd?
```

This query returns a “0” (disabled) or “1” (enabled)

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

- The following table indicates the resulting resolution for each integration time value (in power-line cycles) selected.

| Integration Time | Resolution |
|--|------------------|
| 0.001 PLC* | 30 ppm x Range |
| 0.002 PLC* | 15 ppm x Range |
| 0.006 PLC | 6.0 ppm x Range |
| 0.02 PLC | 3.0 ppm x Range |
| 0.06 PLC | 1.5 ppm x Range |
| 0.2 PLC | 0.7 ppm x Range |
| 1 PLC (default) | 0.3 ppm x Range |
| 2 PLC | 0.2 ppm x Range |
| 10 PLC | 0.1 ppm x Range |
| 100 PLC | 0.03 ppm x Range |
| *These two settings are provided on model 34411A only. | |

AC Measurements

See “*AC Filter*” on page 56 for configuration options for ac voltage, ac current and frequency/period measurements.

AC Filter

This feature applies to ac voltage, ac current, frequency and period measurements only.

The multimeter provides three choices of bandwidth (ac signal filter), enabling you to optimize low-frequency accuracy or achieve faster ac settling times. Set the bandwidth for the lowest frequency you expect to encounter, noting that a lower bandwidth results in longer settling times. The three filters, and their corresponding settling times, are shown below:

| AC Filter Selected | Input Frequency | Settling Time ACV | Settling Time ACI |
|-------------------------|------------------|-----------------------|-----------------------|
| Slow filter | 3 Hz – 300 kHz | 2.5 seconds/reading | 1.67 seconds/reading |
| Medium filter (default) | 20 Hz – 300 kHz | 0.63 seconds/reading | 0.25 seconds/reading |
| Fast filter | 200 Hz – 300 kHz | 0.025 seconds/reading | 0.025 seconds/reading |

- **Front Panel Operation:** After selecting either the AC V or AC I function, press **Config** to display AC FILTER. with the current setting on the secondary display line. Press **Left Arrow** or **Right Arrow** to select 3 HZ: SLOW, 20 HZ: MEDIUM, or 200 HZ: FAST, then press **Enter**. Then step through or exit the configuration menu.
- **Remote Interface Operation:** The following commands set the ac filter (3, 20 or 200 Hz) for ac measurements:

```
[SENSe:]VOLTage:AC:BANDwidth {<filter>|MIN|MAX|DEF}
[SENSe:]CURRent:AC:BANDwidth {<filter>|MIN|MAX|DEF}
```

The following commands query the filter setting:

```
[SENSe:]VOLTage:AC:BANDwidth? [{MIN|MAX}]
[SENSe:]CURRent:AC:BANDwidth? [{MIN|MAX}]
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

DC Input Impedance

This feature applies to dc voltage measurements only.

The default setting for the multimeter's input impedance is fixed at 10 M Ω for all dc voltage ranges, to minimize noise pickup. To reduce the effects of measurement loading errors when making low-voltage measurements, this fixed resistance can be set to >10 G Ω (HI-Z) for the 100 mVDC, 1 VDC and 10 VDC ranges.

- **Front Panel Operation:** After the **DC V** function is selected, press **Config** repeatedly until INPUT Z is displayed. Press **Left Arrow** or **Right Arrow** to select 10M or HI-Z, then press **Enter**. Then step through or exit the configuration menu.

Note: when HI-Z is selected, the multimeter will *only* set an input impedance of >10 G Ω for the three lowest dc ranges; it will auto-default to 10 M Ω for all measurement ranges above 10 VDC.

- **Remote Interface Operation:** The following command turns on the auto input impedance function for dc voltage measurements. The auto function (equivalent of setting HI-Z from the front panel) uses 10 M Ω for the 100V and 1000V ranges, and >10 G Ω for all other ranges:
[SENSe:]VOLTage:DC:IMPedance:AUTO {OFF|0|ON|1}

The following command queries the auto impedance function setting:

[SENSe:]VOLTage:DC:IMPedance:AUTO?

This query returns a "0" (OFF) or "1" (ON).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.


Autozero

This feature applies to dc voltage, dc current and 2-wire resistance measurements only. (Autozero is always enabled when you select 4-wire resistance or 4-wire temperature measurements.)

When autozero is ON (default) the multimeter internally disconnects the input signal immediately following each measurement, and takes a *zero* reading. It then subtracts the zero reading from the preceding measurement. This method prevents small offset voltages present on the multimeter's input circuitry from affecting measurement accuracy.

When autozero is OFF, the multimeter takes one zero reading and subtracts it from all subsequent measurements. A new zero reading is taken each time you change the function, range or resolution (integration time).

When autozero is set to ONCE, the multimeter takes one zero reading, then sets auto zero to OFF. The zero reading taken is used for all subsequent measurements until the next change to the function, range or integration time. If the selected integration time is less than 1 PLC, the zero reading is taken at 1 PLC to ensure normal mode noise rejection in the zero reading; then subsequent readings are taken at the set integration time.

- **Front Panel Operation:** The autozero function is enabled (on) by default at power-on. To turn autozero to OFF or ONCE for a selected function, press config repeatedly until AUTO ZERO is displayed, then make the desired selection, and press . Then step through or exit the configuration menu.
- **Remote Interface Operation:** Autozero may be enabled or disabled using this SENSE command:

```
SENSE:<function>:ZERO:AUTO {OFF|ONCE|0|ON|1}
```

Autozero may be also set indirectly using the CONFIGure or MEASure commands.

The following command queries the autozero feature status for the specified function:

```
SENSE:<function>:ZERO:AUTO?
```

This query command returns “0” (OFF) or “1” (ON).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Ranging

This feature applies to voltage, current, resistance, capacitance and frequency/period measurements only.

You can let the multimeter automatically select the range using *autoranging*, or you can select a fixed range using *manual ranging*. Autoranging is convenient because the multimeter automatically selects the appropriate range for sensing and displaying each measurement. However, manual ranging results in better performance, since the multimeter does not have to determine which range to use for each measurement.

- **Autorange thresholds** – The multimeter will shift range as follows:
Down range at <10% of current range
Up range at >120% of current range
- Ranging is local to the selected function; the multimeter remembers the selected ranging method (auto or manual) and selected manual range when you switch between measurement functions.
- *For frequency and period measurements*, the selected range is for the *ac voltage* level of the input signal.
- *For temperature measurements*, the multimeter uses auto ranging, depending on the probe type.
- *For continuity tests*, the multimeter range is fixed at 1 k Ω , and *for diode tests* the range is fixed at 1 VDC with a 1 mA current source output.
- **Front Panel Operation:** For applicable measurement functions, the ranging method and manual range may be selected by front panel shortcuts (see *“Ranging”* on page 43), or through the configuration menu for the selected function. For the latter method, press **Config** until RANGE is displayed, then select AUTO or MANUAL using the navigation keypad and press **Enter**. If MANUAL has been selected, press **Left** or **Right** as needed to select the desired range, and press **Enter**. Then step through or exit the configuration menu.

Manual ranging – If the input signal is greater than can be measured on the selected range, the multimeter provides these overload indications: \pm OVLD from the front panel or “ $\pm 9.9\text{E}+37$ ” from the remote interface.

- **Remote Interface Operation:** *For all measurements except temperature, diode check and continuity:*

Autoranging may be enabled or disabled for the specified <function> using this SENSE command:

```
SENSe:<function>:RANGe:AUTO {OFF|ONCE|0|ON|1};  
    where <function> = VOLTage:DC, VOLTage:AC, CURRent:DC,  
    CURRent:AC,RESistance, FRESistance or FREQuency
```

The following command queries the autoranging feature status for the specified <function>:

```
SENSe:<function>:RANGe:AUTO?
```

This query command returns “0” (OFF) or “1” (ON).

The following command manually sets the multimeter range for the specified <function>:

```
SENSe:<function>:RANGe[:UPPER] {<range>|MIN|MAX|DEF}
```

Note: for <function> = FREQuency, this command changes the ac input range.

A manual range may also be set using the CONFIgure or MEASure commands.

The following command queries the multimeter range setting for the specified <function>:

```
SENSe:<function>:RANGe[:UPPER]? [{MIN|MAX}]
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for all commands on this page.

Null Measurements

The multimeter allows separate null settings to be saved for each of the following measurement functions: DC Volts, AC Volts, DC Current, AC Current, Resistance, Frequency/Period, Capacitance and Temperature.

When making null (also called *relative*) measurements, each reading is the difference between a stored (selected or measured) null value and the input signal. One possible application is to increase accuracy of two-wire resistance measurements by nulling the test lead resistance. Nulling the leads is particularly important prior to making capacitance measurements. The formula used for calculating null measurements is:

Result = reading – null value

- The null value is adjustable, and you can set it to any value between 0 and $\pm 120\%$ of the highest range, for the present function. Alternately, you can measure the null value.
- **Front Panel Operation:** For any selected measurement function, to enable null measurements press **Config** repeatedly until NULL is displayed, then select ON with the navigation keypad, then press **Enter** to display NULL VALUE. Enter the desired null value with the navigation keypad, then press **Enter**. Then step through or exit the configuration menu. The **Null** annunciator will turn on, indicating that the null function is enabled.

Alternately, you directly measure and store the null value by pressing **Null** with the test leads open (nulls the test lead capacitance), shorted (nulls the test lead resistance) or across a desired null value circuit.

- **Remote Interface Operation:** The following command enables the null measurement feature for the specified <function>:
SENSe:<function>:NULL[:STATe] {ON|OFF}

The following command queries the null measurement feature setting:

SENSe:<function>:NULL[:STATe]?

This query returns a “0” (OFF) or “1” (ON).

The following command stores a null value for the specified <function>:

SENSe:<function>:NULL[:VALue] {<value>|MIN|MAX}

The following command queries the null value stored for the specified function:

SENSe:<function>:NULL[:VALue]?

This query returns the stored null value.

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Miscellaneous Configuration Settings

Radix Character

This feature is available from the front panel only.

The multimeter can display the radix character (decimal point) as a period or a comma.

- The factory (default) setting is PERIOD.
- The radix character setting is stored in non-volatile memory.
- **To change the radix character:** Press **Shift** **Data Log** (**Utility**) to display UTILITY MENU, and press **▶** as needed until MISC SETTINGS is displayed. Press **Enter** as needed to display RADIX CHAR, press **◀** or **▶** as needed to select PERIOD or COMMA, and press **Enter**. Then step through or exit the configuration menu.

Thousands Separator

The multimeter can display front panel readings with or without a comma (thousands separator) delimiting the first set of 3 digits left of the radix character.

- The factory (default) setting is ON.
- **Front Panel Operation:** Press **Shift** **Data Log** (**Utility**) to display UTILITY MENU, and press **▶** as needed until MISC SETTINGS is displayed. Press **Enter** as needed to display THOUSAND SEP, press **◀** or **▶** to select OFF or ON, and press **Enter**. Then step through or exit the configuration menu.

Beeper








Normally, the multimeter will emit a tone from the front panel whenever certain conditions are met (e.g. the multimeter will beep when a stable reading is captured in reading hold mode). The beeper is factory set to ON, but may be disabled or enabled manually.

Only when the beeper is *enabled*, the multimeter will emit a tone when:

- 1 A set LO or HI limit is exceeded in a limit test.
- 2 A stable reading is captured in reading hold mode.
- 3 A forward-biased diode is measured in the diode test function.

Disabling the beeper will cancel the tone in the three cases listed above. However, the multimeter will *always* emit a tone when:

- 1 An error is generated.
- 2 The continuity threshold is exceeded.
- 3 A SYST:BEEP command is sent.

- **Front Panel Operation:** Press   (Utility) to display UTILITY MENU, and press  as needed until MISC SETTINGS is displayed. Press  as needed to display BEEPER, press  or  to select OFF or ON, and press . Then step through or exit the configuration menu.

- **Remote Interface Operation:** The following command disables or enables the front panel beeper:

```
SYSTem:BEEPer:STATe {OFF|0|ON|1}
```

The following command queries the state of the beeper:

```
SYSTem:BEEPer:STATe?
```

This query returns a “0” (OFF) or “1” (ON).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Math Functions

In addition to providing separate null measurement per function capability, the multimeter provides four additional math functions: dB measurements (dB), dBm measurements (dBm), statistics for multiple readings (STATS) and limit testing (LIMITS). Only one of these four functions can be enabled at a time (in addition to null measurement), and remains in effect until you turn it off or change it.

- **Front Panel Operation:** To enable or change an enabled math function, press **Shift** **Null** (**Math**) to display MATH. Press **Left Arrow** or **Right Arrow** as needed to select the desired math function (OFF, dB, dBm, STATS or LIMITS), and press **Enter**. Follow the instructions in the following sections of this guide to set parameters for dB measurements, dBm measurements or limit testing, or to display statistics.

- **Remote Interface Operation:** The following command selects the math function to be used:

```
CALCulate:FUNCTION {NULL|DB|DBM|AVERage|LIMIT}
```

The following command queries the currently selected math function:

```
CALCulate:FUNCTION?
```

This query returns the currently selected function

The following command turns the CALCulate subsystem, and thus all math functions, on or off:

```
CALCulate[:STATe] {OFF|ON}
```

The following command queries the current calculation state:

```
CALCulate:STATe?
```

This query returns a “0” (OFF) or a “1” (ON).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

dBm Measurements

The dBm math function applies to ac and dc voltage measurements only.

Because of the wide range of values used in RF signal measurements, the logarithmic dBm (decibels relative to one milliwatt) scale is often used. The multimeter's dBm operation takes a measured voltage, and calculates the power delivered to a reference resistance (typically 50, 75 or 600Ω). The formula used for conversion from the voltage reading is:

$$dBm = 10 \times \log_{10}(mW) = 10 \times \log_{10}(reading^2 / ref. resistance / 1 mW)$$

- You can choose from 17 different reference resistance values: 50, 75, 93, 110, 124, 125, 135, 150, 250, 300, 500, 600, 800, 900, 1000, 1200 or 8000 (Ω). The default setting is 600Ω.
- **Front Panel Operation:** To enable dBm measurements: Press **(Shift)** **(Null)** **(Math)** to display MATH. Press **(F1)** or **(F2)** as needed to select dBm, and press **(Enter)**. Press **(F1)** or **(F2)** as needed to select the desired dBm REF R, and press **(Enter)**. The **Math** annunciator will turn on, and the primary display line will indicate a voltage reading in dBm.
- **Remote Interface Operation:** The following command sequence will select the dBm function, turn that function on, and set the reference resistance.
 CALCulate:FUNCTION DBM
 CALCulate:STATE ON
 CALCulate:DBM:REFERENCE <value>

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

dB Measurements

The dB math function applies to ac and dc voltage measurements only.

The dB operation calculates the difference between the input voltage signal and a stored relative value, with both values converted to dBm. The formula used for calculation from the converted reading is:

$$dB = reading\ in\ dBm - relative\ value\ in\ dBm$$

- The relative value is adjustable, and you can set it to any value between 0 dBm and ±200.0 dBm. The default relative value is 0 dBm.

There are two ways to specify the relative value. First, you can enter a specific number into the register from the front panel menu or from the remote interface. The new value will replace any previously stored value.

The second way to enter the relative value is to take an initial reading in dBm (or take a reading and convert it to dBm), and store that value in the register. Note that the reading in dBm *and* the relative value in dBm are computed using the dBm reference resistance.

- **Front Panel Operation:** To enable dB measurements: Press **Shift** **Null** (**Math**) to display MATH. Press **Left Arrow** or **Right Arrow** as needed to select dB, and press **Enter**.

*If you want to set a specific dBm relative value, Press **Right Arrow** as needed to select VALUE, and press **Enter**. Use the navigation keypad to set the desired dB REL VALUE, and press **Enter**. The **Math** annunciator will turn on, and the primary display line will indicate a voltage reading in dB.*

*Else, if you want to set the dBm relative value by measurement, Select MEASURE, and press **Enter** to set the value to the measured voltage connected to the input terminals. The **Math** annunciator will turn on, the primary display line will briefly flash VDC or VAC to indicate that the relative value has been measured, and then will indicate a voltage reading in dB.*

If the configured settings will result in a long measurement time or have the multimeter waiting for an external trigger, the Math annunciator will flash until the relative value measurement has been taken. Subsequently, 0.000 VDC (or VAC) will be displayed, until the following measurement is completed.

- **Remote Interface Operation:** The following command sequence will select the dBm function, turn that function on, and store a relative value in the meter's dB Relative Register.

```
CALCulate:FUNCTION DB
CALCulate:STATE ON
CALCulate:DB:REFERENCE <value>
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Using Statistics

The statistics math function applies to all measurement functions except continuity and diode tests.

The statistics you may view for any set of readings are: average value (AVG), maximum value (MAX), minimum value (MIN), standard deviation (SDEV) and number of samples taken (COUNT). These are shown on the second line of the display when the statistics math function is enabled, and are updated in real time as subsequent readings are taken.

- **Front Panel Operation:** To enable statistics: Press **Shift** **Null** (**Math**) to display MATH. Press **Left Arrow** or **Right Arrow** as needed to select STATS, and press **Enter**. The **Stats** annunciator will turn on, indicating that statistics are enabled. Press **Left Arrow** or **Right Arrow** as needed to scroll through the options of AVG, MAX, MIN, SDEV and COUNT.

- **Remote Interface Operation:** The following command enables the statistics function:

```
CALCulate:FUNCTION AVERage
```

The following queries return the mean, minimum value, maximum value, standard deviation, peak-to-peak value, and number of readings, respectively, since statistics were enabled or cleared.

```
CALCulate:AVERage:AVERage?
```

```
CALCulate:AVERage:MINimum?
```

```
CALCulate:AVERage:MAXimum?
```

```
CALCulate:AVERage:SDEViation?
```

```
CALCulate:AVERage:PTPeak?
```

```
CALCulate:AVERage:COUNT?
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Limit Testing

The limit test math function applies to all measurement functions except continuity and diode tests.

The limit test function (LIMITS) enables you to perform pass/fail testing to upper and lower limits which you specify.

You can set the upper and lower limits to any value between 0 and $\pm 120\%$ of the highest range, for the present function. The upper limit you select should always be a more positive number than the lower limit. The initial factory settings for both are “0”.

- **Front Panel Operation:** To enable limit testing: Press **(Shift)** **(Null)** **(Math)** to display MATH. Press **(Left Arrow)** or **(Right Arrow)** as needed to select LIMITS, and press **(Enter)**. LOW LIMIT will be displayed, and the multimeter’s second display line will show the current or default low limit. Use the navigation keypad to set the desired low limit, and press **(Enter)**. HIGH LIMIT will be displayed, and the multimeter’s second display line will show the current or default high limit. Use the navigation keypad to set the desired high limit, and press **(Enter)**. The second display line will briefly show LIMITS ENABLED, then will display a bar graph that indicates the reading on a scale from LO to HI. The **Limits** annunciator will also turn on, indicating that the limits function has been enabled. If the reading is lower than the set low limit, LO will flash. If the reading exceeds the set high limit, HI will flash. In either case, as limits are exceeded, the multimeter will also beep, if the beeper is enabled.
- **Remote Interface Operation:** The following command sequence will select the limit test function, turn that function on, and set the lower and upper limits.

```
CALCulate:FUNCTION LIMit
CALCulate:STATe {OFF|ON}
CALCulate:LIMit:LOWer {<value>|MINimum|MAXimum}
CALCulate:LIMit:UPPer {<value>|MINimum|MAXimum}
```

You can assign a lower limit, an upper limit, or both.

The following commands query the selected lower and upper limits.

```
CALCulate:LIMit:LOWer?
CALCulate:LIMit:UPPer?
```

Refer to the *Agilent 34410A/34411A Programmer’s Reference* for complete description and syntax for these commands.

Triggering the Multimeter

The multimeter's triggering system allows you to generate triggers either manually or automatically, take multiple readings per trigger, and insert a delay before each reading.

From the front panel, you can trigger the multimeter using a single manual trigger or auto-triggering. Single triggering takes one reading each time you press **Trigger**, or upon receiving an external trigger signal. Auto triggering takes continuous readings at the fastest rate possible for the set configuration (e.g. selected measurement function, auto-zero setting, resolution setting, etc.).

From the remote interface, triggering the multimeter is a three-step process: configure measurements, identify trigger source and initiate the trigger.

- 1 First, you must configure the multimeter for the measurement by selecting the function, range, resolution, etc.
- 2 Second, you must specify the source from which the multimeter will accept a trigger. Choices are – a software (bus) trigger from the remote interface, a hardware trigger from the **Ext Trig** terminal, or an immediate internal trigger (default trigger source).
- 3 Third, you must ensure that the multimeter is ready to accept a trigger from the specified source (called the *wait-for-trigger* state).

From the rear panel, an **Ext Trig** terminal accepts hardware triggers.

Selecting a Trigger Source

You must specify the source from which the multimeter will accept a trigger. The power-on default trigger source is auto-triggering, from the front panel.

- In local operation, the multimeter will accept single triggers by pressing the **Trigger** key (see “*Single Triggering*” on page 70), a hardware trigger using the rear panel **Ext Trig** terminal (see “*External Triggering*” on page 76), or continuously take readings in auto trigger mode (see “*Auto Triggering*” on page 70).
- **Remote Interface Operation:** The following command selects the trigger source from the remote interface:

```
TRIGger:SOURce {BUS|IMMediate|EXTernal}
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Auto Triggering

The auto trigger mode is available from the front panel only.

The power-on trigger mode for the multimeter is front panel operation, in auto trigger mode.

- Auto triggering takes continuous readings at the fastest rate possible for the set configuration (e.g. selected measurement function, auto-zero setting, resolution setting, etc.)
- *To enable auto triggering*, press **Shift** **Trigger** (**Auto Trig**) to display TRIGGER. Press **Left Arrow** or **Right Arrow** as needed to select AUTO, then press **Enter**.

Single Triggering

The single trigger mode is available from the front panel only.

- The multimeter takes one reading, or a number of readings specified by a sample count you enter, each time you press **Trigger**, or upon receiving an external trigger signal. *See also “Number of Samples per Trigger” on page 72.*
- When in single trigger mode, the **Trig** annunciator is displayed to indicate that the multimeter is waiting for a trigger.

Reading Hold

The reading hold mode is available from the front panel only.

The reading hold feature allows you to capture and hold a stable reading on the front panel display. This is especially useful in situations when you want to take a reading, remove the test probes, and have the reading remain on the display. When a stable reading is detected, the multimeter emits a beep (if the front-panel beeper is enabled) and holds the reading on the display.

- The sensitivity band for reading hold is based on the selected measurement function. The multimeter will capture and display a new value only after three consecutive readings are within this band.
- With reading hold enabled, if you change to remote operation, reading hold is ignored; returning to local (front panel) operation disables reading hold.

- The configured range mode (auto or manual) will be used for reading hold.
- To enable reading hold, press **Shift** **Trigger** (Auto Trig) to display TRIGGER. Press **Enter** as needed to select HOLD, and press **Enter**.

Internal Triggering

The internal triggering mode is available from the remote interface only.

In the internal trigger mode, the trigger signal is always present. When you place the multimeter in the wait-for-trigger state, the trigger is issued immediately. This is the default trigger source for remote interface operation.

- **Remote Interface Operation:** The following command selects the internal trigger source:

```
TRIGger:SOURce IMMEDIATE
```

The CONFIGure and MEASure? commands automatically set the trigger source to IMMEDIATE.

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Software (Bus) Triggering

The bus trigger mode is available from the remote interface only.

The bus trigger mode corresponds in function to pressing the **Trigger** key from the front panel, except that it is initiated by sending a bus trigger command, after selecting BUS as the trigger source.

- The following command selects the bus trigger source:

```
TRIGger:SOURce BUS
```

Then, any of the following commands will initiate readings:

```
MEASure?
```

```
READ?
```

```
INITiate
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Number of Samples per Trigger

By default, when the multimeter is in the wait-for-trigger state, it takes one reading (or sample) each time you trigger the multimeter. You can, however, instruct the multimeter to take up to 50,000 readings (up to 1 million for model 34411A) each time a trigger is initiated, whether from the front panel or remote interface.

- **Front Panel Operation:** To change the number of samples taken per trigger, press **(Shift) (Trigger) (Auto Trig)** to display TRIGGER. Press **(▶)** as needed to select ADVANCED, and press **(Enter)** to display NSAMPLES. Use the navigation keypad to select the desired number of samples per trigger, and press **(Enter)**. Then step through or exit the advanced triggering menu.

- **Remote Interface Operation:** The following command selects the number of samples the multimeter will take per trigger:

```
SAMPlE:COUNT {<count>|MIN|MAX}
```

After setting the sample count, you must place the meter in the wait-for-trigger state before readings are triggered (see *“Software (Bus) Triggering”* on page 71).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Trigger Delay

You can manually specify a delay between the trigger signal and the first sample that follows. This may be useful in applications where you want to allow the input signal to settle before taking a reading, or for pacing a burst of readings.

- The trigger delay may be set from 0 to 3600 seconds.
- If a trigger delay is not manually set, the default trigger delay is automatically set, based on function, range, integration time and/or ac filter setting (see also *“Automatic Trigger Delay”* on page 74).
- If you manually specify a trigger delay, *that delay* is used for *all* measurement functions.

- **Front Panel Operation:** To manually specify the trigger delay, press **(Shift) (Trigger) (Auto Trig)** to display TRIGGER. Press **(▶)** twice to select ADVANCED, and press **(Enter)** as needed to display TRIG DELAY. Press **(▶)** as needed to select MANUAL, and press **(Enter)**. Use the navigation keypad to set the desired trigger delay, and press **(Enter)**. Then step through or exit the advanced triggering menu.

To specify a trigger delay of *zero*, press **(Shift) (Trigger) (Auto Trig)** to display TRIGGER. Press **(▶)** twice to select ADVANCED, and press **(Enter)** as needed to display TRIG DELAY. Press **(◀)** or **(▶)** as needed to select ZERO, and press **(Enter)**. Then step through or exit the advanced triggering menu.

- **Remote Interface Operation:** The following command specifies the trigger delay, in seconds:

```
TRIGger:DElay {<seconds>|MIN|MAX}
```

If the multimeter is configured to take more than one sample per trigger, the trigger delay you specify is inserted between the trigger and *each* reading (if the sample source is set to AUTO), or only before the first reading (if the sample source is set to TIMer). See the **SAMPLE:SOURce** command description for more information.

After setting the trigger delay, you must use the **INITiate** or **READ** command to place the meter in the wait-for-trigger state before readings are triggered (see *“Software (Bus) Triggering”* on page 71). The **MEASure?** command sets the trigger delay to AUTO.

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these command.

Automatic Trigger Delay

If you do not specify a trigger delay manually, the multimeter selects the trigger delay time automatically. Automatic trigger delays are set to ensure that completely settled and accurate measurements are taken. The delay is determined by function, range, integration time and ac filter setting, as shown in the following tables

DC Voltage Measurements (all ranges):

| Integration Time | Trigger Delay |
|-------------------|---------------|
| ≥ 1 PLC | 160 μ s |
| 0.2 PLC, 0.06 PLC | 130 μ s |
| ≤ 0.02 PLC | 100 μ s |

DC Current Measurements (all ranges):

| Integration Time | Trigger Delay |
|------------------|---------------|
| ≥ 1 PLC | 1.5 ms |
| ≤ 0.2 PLC | 1.0 ms |

2-wire Resistance Measurements :

| Range | Trigger Delay (for ≤ 0.02 PLC) | Trigger Delay (for 0.06 or 0.2 PLC) | Trigger Delay (for ≥ 1 PLC) |
|------------------------------|--|--|-------------------------------------|
| 100 Ω | 80 μ s | 100 μ s | 130 μ s |
| 1 k Ω | 110 μ s | 130 μ s | 160 μ s |
| 10 k Ω | 130 μ s | 160 μ s | 190 μ s |
| 100 k Ω | 540 μ s | 670 μ s | 800 μ s |
| 1 M Ω | 5.0 ms | 6.0 ms | 7.5 ms |
| 10 M Ω – 1 G Ω | 60 ms | 70 ms | 84 ms |

4-wire Resistance Measurements

| Range | Trigger Delay (for ≤ 0.02 PLC) | Trigger Delay (for 0.06 or 0.2 PLC) | Trigger Delay (for ≥ 1 PLC) |
|-------------------------------|--|--|-------------------------------------|
| 100 Ω – 100 k Ω | 1.0 ms | 1.0 ms | 1.5 ms |
| 1 M Ω | 10 ms | 10 ms | 15 ms |
| 10 M Ω – 1 G Ω | 100 ms | 100 ms | 100 ms |

The following tables list the automatic trigger delays for ac measurements, triggered from the remote interface. From the front panel, assume an automatic trigger delay of 50 ms for all ac measurements.

AC Voltage Measurements (all ranges):

| AC Filter | Trigger Delay |
|----------------|---------------|
| Slow (3 Hz) | 2.5 sec |
| Medium (20 Hz) | 625 ms |
| Fast (200 Hz) | 25 ms |

AC Current Measurements (all ranges):

| AC Filter | Trigger Delay |
|----------------|---------------|
| Slow (3 Hz) | 1.66 sec |
| Medium (20 Hz) | 250 ms |
| Fast (200 Hz) | 25 ms |

Frequency and Period


| Trigger Delay |
|---------------|
| 1 sec |

Temperature measurements actually use the 2-wire or 4-wire resistance functions. The above tables for resistance apply to temperature measurements, but all temperature measurements use autoranging. Since the range in use cannot be predicted, nor can the delay. Use the TRIGger:DElay? command to show the actual trigger delay.


Capacitance measurements have a trigger delay of zero, because discharging the capacitor is part of the measurement time.

External Triggering

External triggering takes one reading (or the specified number of readings) each time the multimeter receives a pulse on the rear-panel (coaxial) **Ext Trig** terminal. You may select whether the multimeter uses the rising edge (POS) or falling edge (NEG) of the applied external trigger signal to trigger a reading (see *“Trigger Slope”* on page 77). The diagram below shows the **Ext Trig** terminal and NEG timing:



- The multimeter buffers one external trigger. If the multimeter is currently taking a reading while another trigger occurs, that second trigger is accepted. After the reading in progress is completed, the stored trigger is issued.
- The **Trig** annunciator turns on when the multimeter is waiting for an external trigger.
- The rear panel **VM Comp** (voltmeter complete) terminal provides a pulse after completion of each measurement. Voltmeter complete and external trigger implement a standard hardware handshake sequence between measurement and switching devices. The diagram below shows the **VM Comp** terminal and NEG timing:



- **Front Panel Operation:** The external trigger mode corresponds in function to pressing the **Trigger** key from the front panel, except that you apply the trigger signal to the **Ext Trig** terminal.
- **Remote Interface Operation:** The following command selects the trigger source from the external terminal:
`TRIGger:SOURce EXternal`

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Trigger Slope

You may select whether the multimeter uses the rising edge (POS) or falling edge (NEG) of the applied external trigger signal to trigger a reading, or (independently) for the resultant voltmeter complete signal. The default for both is NEG.

- **Front Panel Operation:** To select the *trigger slope* for external triggering, press **(Shift) (Trigger) (Auto Trig)** to display TRIGGER. Press **⬅** or **➡** as needed to display ADVANCED, and press **(Enter)**. Press **⬅** or **➡** as needed to select EXT:TRG SLOPE, and press **(Enter)**. Press **⬅** or **➡** as needed to select NEG or POS, and press **(Enter)**. VM:COMP SLOPE will be displayed.

Then, to select the slope for the *voltmeter complete* signal, press **⬅** or **➡** as needed to select NEG or POS, and press **(Enter)**. Then step through or exit the configuration menu.

- **Remote Interface Operation:** The following command selects the trigger slope for the external terminal:

```
TRIGger:SLOPe {POSitive|NEGative}
```

The following query returns the selected trigger slope for the external terminal:

```
TRIGger:SLOPe?
```

This query returns POS or NEG.

The following command selects the signal slope for the voltmeter complete signal:

```
OUTPut:TRIGger:SLOPe {POSitive|NEGative}
```

The following query returns the selected trigger slope for the external terminal:

```
OUTPut:TRIGger:SLOPe?
```

This query returns POS or NEG.

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Reading Memory

This feature is available from the remote interface only.

The multimeter's reading memory is a first-in, first out (FIFO) buffer holding up to 50,000 readings (model 34410A) or 1 million readings (model 34411A). The oldest readings are preserved.

- **Remote Interface Operation:** The following command transfers readings stored in non-volatile memory into the multimeter's output buffer, from where you can read them into your computer:

FETCH?

The following command will obtain whatever readings are present in NVMEM, and erase them as they are read:













R?

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.




Data Logging




The Data Logger function makes the multimeter a programmable tools for taking and storing a series of timed measurement readings. This feature can be used in combination with any primary measurement function. The readings are stored in non-volatile memory, and can be accessed from the front panel or remote interface.






To customize a data logging event, the multimeter allows you to set the following parameters: START DELAY, INTERVAL, TIME/EVENT (DURATION or COUNT).

- START DELAY is the delay time, settable from 0 to 3600 seconds, from initiating a trigger before the data logging function takes its first reading.
- INTERVAL is the time, settable from 0 to 3600 seconds, between subsequent readings.
- TIME/EVENT is the total duration of the data logging event. You may choose to set a DURATION in hours, minutes and seconds, from 1 second to 100 hours, or a COUNT of total readings, settable from 1 to 50,000 readings (model 34410A) or up to 1 million readings (model 34411A).
- **Front Panel Operation:** To set up a data logging event, press  to display DATA LOGGER. Select SETUP and press  to display START DELAY. Use the navigation keypad to set the desired start delay, and press  to display INTERVAL. Use the navigation keypad to set the desired reading interval, and press  to display TIME/EVENT. Press  or  as needed to select DURATION or COUNT, and press .
 - If DURATION was selected, use the navigation keypad to set the desired reading interval, and press . If COUNT was selected, use the navigation keypad to set the desired total number of readings, and press .
 - Upon pressing , the displays will briefly read TO START and PRESS TRIGGER KEY. The data logger is now programmed. The primary display line will then show the selected primary measurement function. The second display line will show a progress bar and the count of set total readings. These displays will remain static until you press , or pulse the rear panel Ext Trig terminal.
 - When you press , the multimeter will begin to take readings, after the set start delay has expired. While it is reading, the primary display line will show each reading, and the second display line will show a progress bar and a countdown of readings remaining. The multimeter will continue taking readings until the programmed total readings count has been reached, or unless the data logger is stopped manually.

- After the programmed count has been reached, the display will show SAVING READINGS, then LOGGING COMPLETE. The readings are stored in non-volatile memory.

To stop a data logging event in progress, you may press either ,  or . The primary display line will show DATA LOGGER? and offers selections of CONTINUE or STOP. The data logger continues to take readings while this is displayed.

- If you select STOP and press , the primary display will read DATA TO NV?, prompted you to SAVE or DISCARD the readings already logged. Select one of these options and press  to terminate the data logging function.
- If you select CONTINUE and press , the data logging function will continue as programmed, until complete.

To read the data logged from the front panel, press  to display DATA LOGGER. Press  to select VIEW-RDGS, and press . Press  or  to scroll through the stored readings.

- **Remote Interface Operation:** The following command returns all readings stored in non-volatile memory (NVMEM):

```
DATA:DATA? NVMEM
```

The following command deletes all readings stored in NVMEM.

```
DATA:DELeTe NVMEM
```

The following command returns the number of data points stored in NVMEM

```
DATA:POINTs? NVMEM
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

- **Web Server Operation:** To access the data in the multimeter's non-volatile memory, launch the 34410A/11A web server as described in “34410A/34411A Web Browser Interface” on page 93. The following Welcome Screen will appear:

Agilent Technologies 6-1/2 Digit Multimeter

Welcome Page

Welcome to your
Web-Enabled 6-1/2 Digit Multimeter

Information about this Web-Enabled Instrument

| | |
|-----------------------------------|-------------------------------|
| Instrument: | 34410A 6-1/2 Digit Multimeter |
| Serial Number: | 2000920082 |
| Description: | Agilent 34410A (2000920082) |
| Hostname: | host.lvd.agilent.com |
| IP Address: | 156.140.0.0 |
| VISA TCPIP Connect String: | TCPIP0::host::INSTR |

[Turn Off Front Panel Identification Indicator](#)

[Advanced information](#)

Use the navigation bar on the left to access your 6-1/2 Digit Multimeter and related information.

© Agilent Technologies, Inc. 2005

Click on “Browser Web Control” to display the Control DMM dialog box:

Control DMM * OBSERVE ONLY *

Start DMM Meas Stop DMM Meas View Data...

Measurement Settings

Function: DC Volts DC Input Resistance: ☒ 10M ☐ High

Range: Auto Autozero: ☒ On ☐ Off

Integration time ; Resolution: 1 PLC, < 3.0E-07 x Range

Null: ☐ Enable Null Null Value:

Math Functions: ☐ Enable Math Statistics

Trigger Settings

Trigger Source: Immediate

Trigger Count: 1 ☐ Infinite

Trigger Delay: sec ☒ Auto

Sample Count: 1

Sample Interval: sec ☒ Auto

VM Complete Slope: ☐ Pos ☒ Neg

OK Close Apply

Java Applet Window

Now click on “View Data”. In the dialog, select Non-volatile Memory Readings and then click on Get Data to view the logged data:

View Data * OBSERVE ONLY *

Get Data Clear Data Window

☐ Readings Readings in Memory 0
Start Index 1 Number of Readings to Get 500

☒ Non-volatile Memory Readings Readings in NV Memory 389
Start Index 1 Number of Readings to Get 389

☐ Last Value Copy Readings to NV Delete Readings in NV

☐ Statistics (Not Enabled)

☒ Index Readings ☒ Units

| Index | Readings | Units |
|------------------------------|-----------------|-------|
| Non-volatile Memory Readings | | |
| 1 | -8.65864122E-05 | VDC |
| 2 | -5.50412391E-04 | VDC |
| 3 | -5.52301927E-04 | VDC |
| 4 | -5.50643459E-04 | VDC |
| 5 | -5.53175222E-04 | VDC |
| 6 | -5.52910804E-04 | VDC |
| 7 | -5.92685248E-04 | VDC |

Java Applet Window

From this window, you can select (click) and copy the data into another application such as a spreadsheet using the Windows® clipboard.

Microsoft® and Windows® are U.S. registered trademarks of Microsoft Corporation.

System-Related Operations

The utility menu accesses the following system-related operations: self-test, display of error conditions, calibration, and instrument information. These features are described in the subsections that follow.

The utility menu is *also* used to access the following three menus:

- REMOTE I/O menu (see *“Remote Interface Configuration Methods”* on page 86 for a complete description of the remote interface features).
- STORE/RECALL menu (see *“Multimeter State Storage”* on page 51 for a complete description of the state storage feature).
- MISC SETTINGS menu (see *“Miscellaneous Configuration Settings”* on page 62 for a complete description of these features).

Self-Test

A *power-on self-test* occurs automatically when you turn on the instrument. This limited test assures you that the multimeter is operational. This self-test does not perform the extensive self test described below.

A *complete* self-test performs a series of internal tests, and takes approximately 5 seconds to execute.

If the power-on or complete self-test fails, an error is stored in the error queue. See the *Agilent 34410A/34411A Service Guide* for more information on returning the instrument to Agilent for service.

- Following the complete self-test, the instrument issues a Factory Reset (*RST) command.
- **Front Panel Operation:** Press **Shift** **Data Log** (**Utility**) to display UTILITY MENU. Press **▶** as needed until SELF TEST is displayed, and press **Enter** to initiate the self-test procedure. If the test fails, the **Error** annunciator will light.
- **Remote Interface Operation:** The following command returns "+0" if the self-test is successful or "+1" if it fails.
*TST?

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for this command.

Error Conditions

When the front panel ERROR annunciator turns on, one or more command syntax or hardware errors have been detected. A record of up to 20 errors can be stored in the instrument's *error queue*.

- The instrument beeps once each time a command syntax or hardware error is generated.
- Each remote interface I/O session (e.g., GPIB, USB, LAN) has its own interface-specific error queue.
- A special *global* error queue holds all power-on and hardware-related errors (e.g., over-temperature).
- Errors are retrieved in first-in-first-out (FIFO) order. The first error returned is the first error that was stored. Errors are cleared as you read them. Once you have read all of the interface-specific errors, the errors in the global queue are retrieved.
- Errors are cleared as you read them. When you have read all errors from the interface-specific and global error queues, the ERROR annunciator turns off and the errors are cleared.
- If more than 20 errors have occurred, the last error stored in the queue (the most recent error) is replaced with
-350, "Error queue overflow".

No additional errors are stored until you remove errors from the queue. If no errors have occurred when you read the error queue, the instrument responds with
+0, "No error".


- The front panel reports errors from all I/O sessions as well as the global error queue.
- Both the interface-specific and global error queues are cleared by the *CLS (Clear Status) command and when power is cycled. The errors are also cleared when you read the error queue. The error queue is not cleared by a Factory Reset (*RST) command or an Instrument Preset (SYSTem:PRESet) command.

Calibration

NOTE

Only service-qualified personnel should calibrate the multimeter. Improper use of the front-panel CALIBRATION procedure in the UTILITY menu could result in damage to the multimeter.

Refer to the *Agilent 34410A/34411A Service Guide* for calibration procedures.



3 Remote Interface Configuration

Remote Interface Configuration Methods 86

Configuring a GPIB Interface 87

Configuring a USB Interface 88

Configuring a LAN Interface 89

LAN Configuration Parameters 89

Assigning the LAN IP Address Using Auto-IP 90

Setting the LAN IP Address Manually 90

Setting the LAN Subnet Mask 91

Setting the LAN Default Gateway 91

Setting the LAN Host Name 92

Setting the LAN DNS Server 92

Setting a Web Password 92

34410A/34411A Web Browser Interface 93

Setting up a LAN connection from the Front Panel 94

Setting up a LAN connection from the Remote Interface 95



Remote Interface Configuration Methods

This section gives information on configuring the instrument for remote interface communication. Complete information on configuration, and on using SCPI commands to program the instrument over the remote interface, can be found in the following resources:

- The *Agilent Connectivity Guide*, at www.agilent.com/find/connectivity.
- The *Programmer's Reference Help* file included on the *Agilent 34410A/34411A Product Reference* CD-ROM.

The Agilent 34410A/34411A multimeters support GPIB, USB, and LAN interfaces. All three interfaces are enabled at power on. The front panel **Remote** annunciator turns on whenever there is activity on the remote interface.

- **GPIB Interface** You need only set the GPIB address for the instrument (the factory default is 22) and connect it to your PC using a GPIB cable (sold separately).
- **USB Interface** There is nothing to configure on your instrument for a USB connection. Just connect the instrument to your PC using the USB 2.0 cable included with the instrument.
- **LAN Interface** By default, DHCP is enabled on the instrument, which may enable network communication over the LAN interface (10BaseT/100BaseTx). You may need to set several configuration parameters as described in the LAN configuration sections that follow.

NOTE

To easily configure and verify an interface connection between the 34410A/34411A and your PC, you can use the *Agilent IO Libraries Suite* (E2094M Agilent IO Libraries for Windows) or an equivalent. For more information about Agilent's I/O connectivity software, go to www.agilent.com/find/iolib.

- Agilent IO Libraries Suite for Windows® 98/2000/ME/XP. For more information and to install this software, see the Automation-Ready CD, which is shipped with your 34410A/34411A.
- To download the latest (and previous) version(s) of this software for Windows® 98/NT/2000/ME/XP *from the Web*, go to www.agilent.com/find/iolib.











NOTE

For more information on connecting instruments to USB, LAN, and GPIB and how to configure and troubleshoot these interfaces, refer to the *Agilent Connectivity Guide*.

- If you have installed the Agilent IO Libraries Suite, you can access the guide from the Agilent IO Libraries Control icon.

Configuring a GPIB Interface

Each device on the GPIB (IEEE-488) interface must have a unique address. You can set the multimeter's address to any integral value between 0 and 30. The address is set to "22" when the instrument is shipped from the factory.

- Your computer's GPIB interface card has its own address. Be sure to avoid using *the computer's* address for any instrument on the interface bus.
- The GPIB address is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.
- **Front Panel Operation:** To enable GPIB and set the GPIB address, Press   (Utility) to display UTILITY MENU. Press  or  as needed to select REMOTE I/O, and press  to display I/O PORT. Press  as needed to select GPIB, and press  to display ENABLE GPIB?. Press  as needed to select YES, and press  to display GPIB ADDRESS. Use the navigation keypad to set the desired GPIB address, and press .

After enabling or disabling GPIB connectivity, power to the multimeter must be cycled off/on for the change to take effect.

- **Remote Interface Operation:** The following command enables the GPIB remote interface:

```
SYSTem:COMMunicate:ENABle ON,GPIB
```

The following command queries the state of the GPIB interface:

```
SYSTem:COMMunicate:ENABle? GPIB
```

This query returns a "0" (OFF) or a "1" (ON).

The following command sets the multimeter's GPIB (IEEE-488) address:

```
SYSTem:COMMunicate:GPIB:ADDress {<address>}
```

The following query returns the IP address, in the form "+XX":

```
SYSTem:COMMunicate:GPIB:ADDress?
```

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Configuring a USB Interface

For the USB interface, no configuration parameters are *required* to set up the multimeter. Connect your multimeter to a USB port on your computer. Note that it may take several seconds for the computer to recognize and establish a connection to the multimeter.

- **Front Panel Operation:** To enable USB: Press **(Shift)** **(Data Log)** (**Utility**) to display UTILITY MENU. Press **(Left Arrow)** or **(Right Arrow)** as needed to select REMOTE I/O, and press **(Enter)** to display I/O PORT. Press **(Right Arrow)** as needed to select USB, and press **(Enter)** to display ENABLE USB?. Press **(Left Arrow)** as needed to select YES, and press **(Enter)** to display the multimeter's USB ID. Press **(Enter)** or **(Exit)** to exit the menu.

After enabling or disabling USB connectivity, power to the multimeter must be cycled off/on for the change to take effect.

- **Remote Interface Operation:** The following command enables the USB remote interface:

```
SYSTem:COMMunicate:ENABle ON,USB
```

The following command queries the state of the USB interface:

```
SYSTem:COMMunicate:ENABle? USB
```

This query returns a "0" (OFF) or a "1" (ON).

Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete description and syntax for these commands.

Configuring a LAN Interface

By default, local access network (LAN) connectivity with DHCP (Dynamic Host Configuration Protocol) is enabled on the multimeter. DHCP (Dynamic Host Configuration Protocol) is a protocol for automatically assigning a dynamic IP address, subnet mask and default gateway to a device on a network, and is typically the *easiest* way to configure your multimeter for remote communication using the LAN interface.

- Changing the DHCP setting will cause an automatic LAN restart.
- When DHCP is *enabled* (factory setting), the multimeter will try to obtain an IP address from a DHCP server. If a DHCP server is found, it will assign a dynamic IP address, Subnet Mask, and Default Gateway to the instrument. The DHCP server may also assign the DNS address, and may change the specified Host Name if a manually specified Host Name is already in use.
- When DHCP is *disabled* or unavailable, the multimeter will use the static IP address, Subnet Mask, and Default Gateway during power-on.
- If a DHCP LAN address is *not* assigned by a DHCP server, then a static IP will be assumed after approximately 1 minute.
- If Auto-IP is enabled, a *dynamic* – rather than static – IP address will be assigned by the server at power-on.

LAN Configuration Parameters

You may choose to manually set several of the following configurable parameters, as described in the subsections below. Following these descriptions are procedures for setting up a LAN configuration from the front panel and the remote interface.

- IP Address*
- Subnet Mask*
- Default Gateway*
- DNS Server*
- Host Name
- LAN Services (Visa LAN, Sockets, Telnet, Agilent Web Server)
- Web Password

*These four parameters use dot-notation addresses. See **NOTE** below.

NOTE

Dot-notation addresses (“nnn.nnn.nnn.nnn” where “nnn” is a byte value) must be expressed with care:

Most *computers* will interpret byte values with leading zeros as *octal numbers*. For example, “255.255.020.011” is actually equivalent to decimal “255.255.16.9” not “255.255.20.11” because the computer will interpret “.020” as “16” expressed in octal, and “.011” as “9”.

However, *the multimeter* assumes that all dot-notation addresses are expressed as *decimal byte values* and strips all leading zeros from these byte values. Thus, attempting to set an IP address of “255.255.020.011” will become “255.255.20.11” (a purely decimal expression). Be sure to enter the exact expression, “255.255.20.11”, in your computer web software to address the instrument. To avoid confusion, use only decimal expressions of byte values (0 to 255), with no leading zeros.

Assigning the LAN IP Address Using Auto-IP

The Auto-IP standard automatically assigns an IP address to the multimeter when on a network that does not have DHCP servers.

- Changing the Auto-IP setting will cause an automatic LAN reset.
- Auto-IP allocates IP addresses from the link- local address range (169.254.xxx.xxx).
- From the factory, the Auto-IP setting is enabled.
- The IP address is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.

Setting the LAN IP Address Manually

An Internet Protocol (IP) Address is required for all IP and TCP/IP communications with the instrument. If DHCP is enabled (factory setting), the specified static IP address is not used. However, if the DHCP server fails to assign a valid IP address, *or* if DHCP and Auto-IP are *both* off, the currently configured static IP address will be used.

- Changing the IP address will cause an automatic LAN reset.
- The default IP Address for the multimeter is “169.254.4.10” for the 34410A, and “169.254.4.11” for the 34411A.
- If you are planning to use a static IP address on a Corporate LAN, contact your network administrator to obtain a fixed IP address to be used exclusively for your instrument.

Setting the LAN Subnet Mask

The multimeter uses the Subnet Mask to determine if a client IP address is on the same local subnet. When a client IP address is on a different subnet, all packets must be sent to the Default Gateway. Contact your network administrator to determine if subnetting is being used and for the correct Subnet Mask.

- Changing the Subnet Mask setting will cause an automatic LAN reset.
- The default Subnet Mask for the 34410A multimeter is “255.255.0.0”.
- A value of “0.0.0.0” or “255.255.255.255” indicates that subnetting is not being used.
- The Subnet Mask is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.

Setting the LAN Default Gateway

A Default Gateway address allows the multimeter to communicate with systems that are not on the local subnet. Thus, this is the Default Gateway where packets are sent which are destined for a device not on the local subnet, as determined by the Subnet Mask setting. Contact your network administrator to determine if a gateway is being used and for the correct address.

- Changing the Default Gateway setting will cause an automatic LAN reset.
- The default for the multimeter is “0.0.0.0” (no gateway, and subnetting is not being used).
- The Default Gateway is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.

Setting the LAN Host Name

The Host Name is the host portion of the domain name, which is translated into an IP address.

- Changing the Host Name will cause an automatic LAN reset.
- The default Host Name for the multimeter is “A-34410A-*nnn*” for the 34410A, and “A-34411A-*nnn*” for the 34411A, where *nnn* is the last three digits of the instrument’s serial number representation.
- If Dynamic Domain Name System (DNS) is available on your network and your multimeter uses DHCP, the Host Name is registered with the Dynamic DNS service at power-on.
- The Host Name is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.

Setting the LAN DNS Server

The Domain Name Service (DNS) is an Internet service that translates Domain names into IP addresses. Contact your network administrator to determine if DNS is being used and for the correct address.

- If you change the DNS address, you must cycle power on the multimeter to activate the new setting.
- The default DNS Address for the multimeter is “0.0.0.0”.
- The DNS Server address is stored in non-volatile memory, and does not change when power has been off, after a Factory Reset (*RST) command, or after an Instrument Preset (SYSTem:PRESet) command.

Setting a Web Password

If desired, you can control access to the multimeter’s Web Interface (*see “34410A/34411A Web Browser Interface” on page 93*) using password protection. As shipped from the factory, no password is set. Once the Web server is launched, follow its instructions to establish or change a password.

34410A/34411A Web Browser Interface

The multimeter provides a built-in Web Interface. You can use this interface over LAN for remote access and control of the multimeter via a Java enabled Web browser, such as Microsoft® Internet Explorer.

- *To access and use the 34410A/34411A Web Interface:*
 - 1 Establish a LAN interface connection from your computer to the multimeter.
 - 2 Open your computer's Web browser.
 - 3 Launch the *34410A/34411A Web Interface* by entering the IP address of your multimeter, or its fully-qualified host name, in the browser address field. The following welcome screen appears:

| Information about this Web-Enabled Instrument | |
|---|-------------------------------|
| Instrument: | 34410A 6-1/2 Digit Multimeter |
| Serial Number: | 2000920082 |
| Description: | Agilent 34410A (2000920082) |
| Hostname: | host.lvd.agilent.com |
| IP Address: | 156.140.0.0 |
| VISA TCPIP Connect String: | TCPIP0::host::INSTR |

Turn Off Front Panel Identification Indicator

☒ [Advanced information](#)

Use the navigation bar on the left to access your 6-1/2 Digit Multimeter and related information.

© Agilent Technologies, Inc. 2005

- 4 Follow the instructions in the Web Interface's on-line Help.

Setting up a LAN connection from the Front Panel

- Press **(Shift)** **(Data Log)** (**Utility**) to display UTILITY MENU. Press **(Left Arrow)** or **(Right Arrow)** as needed to select REMOTE I/O, and press **(Enter)** to display I/O PORT. Select LAN, and press **(Enter)** to display ENABLE LAN?. Select YES, and press **(Enter)** to display LAN SETTINGS. Select VIEW and press **(Enter)** to step through the existing LAN settings, or select MODIFY and press **(Enter)** to change them. *If you choose to modify LAN settings, the following submenus will be displayed:*
 - 1 RESET LAN? – Select YES and press **(Enter)** to restart the LAN connection. Select NO and press **(Enter)** to continue modifying LAN settings.
 - 2 DHCP – Select YES and press **(Enter)** to enable DHCP, and jump to **Step 8**. Select NO and press **(Enter)** to continue modifying LAN settings.
 - 3 AUTO IP – Select YES and press **(Enter)** to enable Auto IP, and jump to **Step 8**. Select NO and press **(Enter)** to continue modifying LAN settings.
 - 4 IP ADDRESS. – Use the navigation keypad to enter the desired IP address, in dot notation with no leading zeros, and press **(Enter)**.
 - 5 SUBNET MASK – Use the navigation keypad to enter the desired Subnet Mask, in dot notation with no leading zeros, and press **(Enter)**.
 - 6 DEF GATEWAY – Use the navigation keypad to enter the desired Default Gateway address, in dot notation with no leading zeros, and press **(Enter)**.
 - 7 DNS SERVER – Use the navigation keypad to enter the desired DNS Server address, in dot notation with no leading zeros, and press **(Enter)**.
 - 8 HOST NAME – Use the navigation keypad to enter the desired Host Name, and press **(Enter)**. The Host Name must be a string of alphanumeric characters plus dashes (“-”), up to 15 characters, with the first character a letter.
 - 9 LAN SERVICES – Select ENABLE ALL to xxxxxx, and press **(Enter)** to jump to **Step 10**. Select SELECT and press **(Enter)** to individually enable or disable the following specific services: VISA LAN, SOCKETS, TELNET or WEB SERVER.

Changing LAN services will require a computer reboot for the change to take effect.
 - 10 WEB PASSWORD – Select ENABLE, and press **(Enter)**. Then use the navigation keypad to enter the desired password, up to 12 alphanumeric digits in length.

Setting up a LAN connection from the Remote Interface

- To enable or disable the LAN remote interface:
`SYSTem:COMMUnicate:ENABle {OFF|0|ON|1},LAN`
- To enable or disable the use of DHCP for the LAN interface:
`SYSTem:COMMUnicate:LAN:DHCP {OFF|0|ON|1}`
- To enable or disable the use of Auto-IP for the LAN interface:
`SYSTem:COMMUnicate:LAN:AUTOip[STATe] {OFF|0|ON|1}`
- To assign the LAN a static IP address:
`SYSTem:COMMUnicate:LAN:IPAdDress <address>`
- To assign a LAN Subnet Mask:
`SYSTem:COMMUnicate:LAN:SMASk <address>`
- To assign a LAN Default Gateway:
`SYSTem:COMMUnicate:LAN:GATEWay <address>`
- To assign a LAN Host Name:
`SYSTem:COMMUnicate:LAN:HOSTname "<name>"`
- To assign the LAN a static DNS address:
`SYSTem:COMMUnicate:LAN:DNS <address>`
- To assign a LAN Domain Name:
`SYSTem:COMMUnicate:LAN:DOMain "<name>"`

Query forms of these commands are also available. Refer to the *Agilent 34410A/34411A Programmer's Reference* for complete command description and syntax.



4 Measurement Tutorial

The Agilent 34410A and 34411A multimeters are capable of making highly accurate measurements. In order to achieve the greatest accuracy, you must take the necessary steps to eliminate potential measurement errors. This chapter describes common errors found in measurements and gives suggestions to help you avoid these errors.

DC Measurement Considerations 99

Thermal EMF Errors 99

Loading Errors (dc volts) 99

Noise Rejection 100

Rejecting Power-Line Noise Voltages 100

Common Mode Rejection (CMR) 100

Noise Caused by Magnetic Loops 101

Noise Caused by Ground Loops 101

Resistance Measurement Considerations 102

4-Wire Ohms Measurements 102

Removing Test Lead Resistance Errors 103

Minimizing Power Dissipation Effects 103

Errors in High Resistance Measurements 103

True RMS AC Measurements 104

True RMS Accuracy and High-Frequency Signal Content 105

Estimating High-Frequency (Out-of-Band) Error 107



Other Primary Measurement Functions 109

Frequency and Period Measurement Errors 109

DC Current Measurements 109

Capacitance Measurements 110

Temperature Measurements 112

Probe Type Choice 112

2–Wire vs. 4–Wire Measurements 112

Auto Zero On/Off 113

Integration 113

Offset Compensation 113

NULL Reading: 113

High-Speed Measurements 114

Making High–Speed AC Measurements 114

Making High–Speed AC Measurements 114

Other Sources of Measurement Error 116

Settling Time Effects 116

Loading Errors (ac volts) 116

Measurements Below Full Scale 117

High–Voltage Self–Heating Errors 117

AC Current Measurement Errors (Burden Voltage) 117

Low–Level Measurement Errors 117

Common Mode Errors 119

Leakage Current Errors 119

DC Measurement Considerations


Thermal EMF Errors

Thermoelectric voltages are the most common source of error in low-level dc voltage measurements. Thermoelectric voltages are generated when you make circuit connections using dissimilar metals at different temperatures. Each metal-to-metal junction forms a thermocouple, which generates a voltage proportional to the junction temperature. You should take the necessary precautions to minimize thermocouple voltages and temperature variations in low-level voltage measurements. The best connections are formed using copper-to-copper crimped connections, as the multimeter's input terminals are a copper alloy. The table below shows common thermoelectric voltages for connections between dissimilar metals.

| Copper to – | Approx. mV / °C | Copper to – | Approx. mV / °C |
|--------------------|-----------------|-------------------|-----------------|
| Cadmium-Tin Solder | 0.2 | Aluminum | 5 |
| Copper | <0.3 | Tin-Lead Solder | 5 |
| Gold | 0.5 | Kovar or Alloy 42 | 40 |
| Silver | 0.5 | Silicon | 500 |
| Brass | 3 | Copper-Oxide | 1000 |
| Beryllium Copper | 5 | | |

Loading Errors (dc volts)

Measurement loading errors occur when the resistance of the device-under-test (DUT) is an appreciable percentage of the multimeter's own input resistance. The diagram below shows this error source.



V_s = ideal DUT voltage
 R_s = DUT source resistance
 R_i = multimeter input resistance
 (10 M Ω or >10 G Ω)

$$\text{Error (\%)} = \frac{100 \times R_s}{R_s + R_i}$$

To reduce the effects of loading errors, and to minimize noise pickup, you can set the multimeter's input resistance to >10 G Ω (the HI-Z setting) for the 100 mVdc, 1 Vdc, and 10 Vdc ranges. The input resistance is maintained at 10 M Ω for the 100 Vdc and 1000 Vdc ranges.

Noise Rejection

Rejecting Power-Line Noise Voltages


A desirable characteristic of integrating analog-to-digital (A/D) converters is their ability to reject power-line related noise present with dc input signals. This is called normal mode noise rejection, or NMR. The multimeter achieves NMR by measuring the average dc input by "integrating" it over a fixed period. If you set the integration time to a whole number of power line cycles (PLCs), these errors (and their harmonics) will average out to approximately zero.

The multimeter provides four integration selections (1, 2, 10 and 100 PLCs) which achieve NMR. The multimeter measures the power-line frequency (50 Hz or 60 Hz), and then determines the corresponding integration time. For a complete listing of NMR, approximate added RMS noise, reading rate and resolution for each integration setting, *see the Performance vs. Integration Time table on page 124.*

You can also program specific apertures, using the INTEGRATION settings, to reject undesired signal frequency components.

Common Mode Rejection (CMR)

Ideally, a multimeter is completely isolated from earth-referenced circuits. However, there is finite resistance between the multimeter's input LO terminal and earth ground, as shown below. This can cause errors when measuring low voltages which are floating relative to earth ground.



V_f = float voltage
 R_s = DUT source resistance
 imbalance
 R_i = multimeter isolation
 resistance (LO-Earth)
 C_i = multimeter input
 capacitance:
 ≈ 200 pF (LO-Earth)


$$\text{Error (v)} = \frac{V_f \times R_s}{R_s + R_i}$$

Noise Caused by Magnetic Loops

If you are making measurements near magnetic fields, take caution to avoid inducing voltages in the measurement connections. You should be especially careful when working near conductors carrying large currents. Use twisted-pair connections to the multimeter to reduce the noise pickup loop area, or dress the test leads as close together as possible. Loose or vibrating test leads will also induce error voltages. Tie down test leads securely when operating near magnetic fields. Whenever possible, utilize magnetic shielding materials or increased distance from magnetic sources.

Noise Caused by Ground Loops

When measuring voltages in circuits where the multimeter and the device-under-test are both referenced to a common earth ground, a "ground loop" is formed. As shown below, any voltage difference between the two ground reference points (V_{ground}) causes a current to flow through the measurement leads. This causes noise and offset voltage (usually power-line related), which are added to the measured voltage.



R_L = lead resistance

R_i = multimeter isolation resistance

V_{ground} = voltage drop on ground bus

The best way to eliminate ground loops is to isolate the multimeter from earth by *not* grounding the input terminals. If the multimeter must be earth-referenced, connect it *and* the device-under-test to the same common ground point. Also connect the multimeter and device-under-test to the same electrical outlet whenever possible.


Resistance Measurement Considerations

The multimeter offers two methods for measuring resistance: 2-wire and 4-wire ohms. For both methods, the test current flows from the input HI terminal and then through the resistor being measured. For 2-wire ohms, the voltage drop across the resistor being measured is sensed internal to the multimeter. Therefore, test lead resistance is also measured. For 4-wire ohms, separate "sense" connections are required. Since no current flows in the sense leads, the resistance in these leads does not give a measurement error.

The errors mentioned earlier in this chapter for dc voltage measurements also apply to resistance measurements. Additional error sources unique to resistance measurements are discussed on the following pages.

4-Wire Ohms Measurements

The 4-wire ohms method provides the most accurate way to measure small resistances. Test lead resistances and contact resistances are automatically reduced using this method. Four-wire ohms is often used in automated test applications where resistive and/or long cable lengths, numerous connections, or switches exist between the multimeter and the device-under-test. The recommended connections for 4-wire ohms measurements are shown below. See also ["To Make a 4-wire Resistance Measurement"](#) on page 25.



Removing Test Lead Resistance Errors

To eliminate offset errors associated with the test lead resistance in 2-wire ohms measurements, follow the steps below.

- 1 Short the ends of the test leads together. The multimeter displays the test lead resistance.
- 2 Press **[Null]**. The multimeter will store the test lead resistance as the 2-wire ohms null value, and enable that value to be subtracted from subsequent measurements.

See also *"Null Measurements"* on page 61.

Minimizing Power Dissipation Effects

When measuring resistors designed for temperature measurements (or other resistive devices with large temperature coefficients), be aware that the multimeter will dissipate some power in the device-under-test.

If power dissipation is a problem, you should select the multimeter's next higher measurement range to reduce the errors to acceptable levels. The following table shows several examples.





| Range | Test Current | DUT Power at Full Scale |
|----------------|--------------|----------------------------|
| 100 Ω | 1 mA | 100 μ W |
| 1 k Ω | 1 mA | 1 mW |
| 10 k Ω | 100 μ A | 100 μ W |
| 100 k Ω | 10 μ A | 10 μ W |
| 1 M Ω | 5 μ A | 25 μ W |
| 10 M Ω | 500 nA | 2.5 μ W |

Errors in High Resistance Measurements

When you are measuring large resistances, significant errors can occur due to insulation resistance and surface cleanliness. You should take the necessary precautions to maintain a "clean" high-resistance system. Test leads and fixtures are susceptible to leakage due to moisture absorption in insulating materials and "dirty" surface films. Nylon and PVC are relatively poor insulators ($10^9 \Omega$) when compared to PTFE (Teflon) insulators ($10^{13} \Omega$). Leakage from nylon or PVC insulators can easily contribute a 0.1% error when measuring a 1 M Ω resistance in humid conditions.

True RMS AC Measurements

True RMS responding multimeters, like the Agilent 34410A/34411A, measure the "heating" potential of an applied voltage. Power dissipated in a resistor is proportional to the square of an applied voltage, independent of the waveshape of the signal. This multimeter accurately measures true RMS voltage or current, as long as the wave shape contains negligible energy above the meter's effective bandwidth.¹

| Waveform Shape | Crest Factor | AC RMS | AC + DC RMS |
|--|------------------------|---|----------------------|
|  | $\sqrt{2}$ | $\frac{V}{\sqrt{2}}$ | $\frac{V}{\sqrt{2}}$ |
|  | $\sqrt{3}$ | $\frac{V}{\sqrt{3}}$ | $\frac{V}{\sqrt{3}}$ |
|  | $\sqrt{\frac{T}{t_p}}$ | $\frac{V}{CF} \times \sqrt{1 - \frac{1}{CF^2}}$ | $\frac{V}{CF}$ |
|  | 1 | V | V |

The multimeter's ac voltage and ac current functions measure the *ac-coupled* true RMS value. In this Agilent meter, the "heating value" of *only the ac components* of the input waveform are measured (dc is rejected). As seen in the figure above; for sinewaves, triangle waves, and square waves, the *ac-coupled* and *ac+dc* values are equal, since these waveforms do not contain a dc offset. However, for non-symmetrical waveforms, such as pulse trains, there is a dc voltage content, which is rejected by Agilent's ac-coupled true RMS measurements. This can provide a significant benefit.

An ac-coupled true RMS measurement is desirable when you are measuring small ac signals in the presence of large dc offsets. For example, this situation is common when measuring ac ripple present on dc power supplies.

There are situations, however, where you might *want* to know the ac+dc true RMS value. You can determine this value by combining results from dc and ac measurements, as shown below:

$$ac + dc = \sqrt{ac^2 + dc^2}$$

For the best ac noise rejection, you should perform the dc measurement using an integration time of at least 10 power-line cycles (PLCs).

True RMS Accuracy and High-Frequency Signal Content

A common misconception is that "since an ac multimeter is true RMS, its sine wave accuracy specifications apply to all waveforms." Actually, the shape of the input signal can dramatically affect measurement accuracy, for any multimeter, especially when that input signal contains high-frequency components which exceed the instrument's bandwidth.



As an example, consider a pulse train, one of the most challenging waveforms for a multimeter. The pulse-width of that waveform largely determines its high-frequency content. The pulse waveform's frequency spectrum is represented by its Fourier Integral. The Fourier Series frequency components are just samples along the Fourier Integral, at multiples of the input pulse repetition frequency (prf).

On the following page, the first figure shows the Fourier Integral of two very different pulses: one of broad width ($200\mu s$), hence low prf; the other narrow ($6.7\mu s$), hence high prf. The second figure is an approximation of the shape of the input frequency response for the 34410A/34411A multimeters. Comparing these two figures along the time axis, notice that the $\frac{\sin(\pi f T)}{\pi f T}$ spectrum of the narrow pulse exceeds the effective bandwidth of the instrument. The net result will be a less accurate measurement of the narrow, high-frequency pulse.

In contrast, the frequency spectrum of the broad pulse has fallen off significantly below the multimeter's 300kHz (approximately) band-edge, so measurements of this pulse will be more accurate.

Reducing the prf increases the density of lines in the Fourier spectrum, and increases the portion of the input signal's spectral energy within the multimeter's bandwidth, *which improves accuracy*.

In summary, error in RMS measurements arise when there is significant input signal energy at frequencies above the multimeter's bandwidth.



Estimating High-Frequency (Out-of-Band) Error

A common way to describe signal waveshapes is to refer to their “Crest Factor”. Crest factor is the ratio of the peak value to RMS value of a waveform. For a pulse train, for example, the crest factor is approximately equal to the square root of the inverse of the duty cycle.

$$CF = \frac{1}{\sqrt{d}} = \frac{1}{\sqrt{\frac{t_p}{T}}} = \sqrt{prf \cdot t_p}$$

Notice that crest factor is a composite parameter, dependent upon the pulse-width and repetition frequency; crest factor alone is not enough to characterize the frequency content of a signal.

Traditionally, DMMs include a crest factor derating table that applies at all frequencies. The measurement algorithm used in the 34410A/11A multimeters is not inherently sensitive to crest factor, so no such derating is necessary. With this multimeter, as discussed in the previous section, the focal issue is high-frequency signal content which exceeds the multimeter’s bandwidth.

For periodic signals, the combination of crest factor and repetition rate can suggest the amount of high-frequency content and associated measurement error. We know that the first zero crossing of a simple pulse

occurs at $f_1 = \frac{1}{t_p}$, so we can get an immediate impression of the

high-frequency content by identifying where this crossing occurs as a function of crest factor: $f_1 = CF^2 \cdot prf$

The following table shows the typical error for various pulse waveforms as a function of input pulse frequency:

| Typical Error, for Square wave, Triangular wave, and a pulse train of CF=3, 5, or 10 | | | | | |
|--|-------------|---------------|--------|--------|---------|
| prf | square wave | triangle wave | CF=3 | CF=5 | CF=10 |
| 200 | -0.02% | 0.00% | -0.04% | -0.09% | -0.34% |
| 1000 | -0.07% | 0.00% | -0.18% | -0.44% | -1.71% |
| 2000 | -0.14% | 0.00% | -0.34% | -0.88% | -3.52% |
| 5000 | -0.34% | 0.00% | -0.84% | -2.29% | -8.34% |
| 10000 | -0.68% | 0.00% | -1.75% | -4.94% | -26.00% |
| 20000 | -1.28% | 0.00% | -3.07% | -8.20% | -45.70% |
| 50000 | -3.41% | -0.04% | -6.75% | -32.0% | -65.30% |
| 100000 | -5.10% | -0.12% | -21.8% | -50.6% | -75.40% |

The Agilent multimeter's specifications are valid for $CF \leq 10$, *provided there is insignificant signal energy present above the 300kHz bandwidth of the meter*. Multimeter performance is not specified for $CF > 10$, or when significant high-frequency signal content is present.

Example:

An ac waveform to be measured is typically $1V_{\text{rms}}$, and will be measured on the 1 V range. It has occasional spikes of about 3 V (i.e. representing a Crest Factor of 10) and duration not less than $10 \mu\text{s}$ (zero crosses at 100 kHz). This ac waveform can be measured without introducing error.

However, had this signal level been much lower (e.g. in the range of $0.1 V_{\text{rms}}$, the 3V spike would represent a Crest Factor of 30 – out of the specified performance range of the meter.


Other Primary Measurement Functions

Frequency and Period Measurement Errors

The multimeter uses a reciprocal counting technique to measure frequency and period. This method generates constant measurement resolution for any input frequency. The multimeter's ac voltage measurement section performs input signal conditioning. All frequency counters are susceptible to errors when measuring low-voltage, low-frequency signals. The effects of both internal noise and external noise pickup are critical when measuring "slow" signals. The error is inversely proportional to frequency. Measurement errors will also occur if you attempt to measure the frequency (or period) of an input following a dc offset voltage change. You must allow the multimeter's input dc blocking capacitor to fully settle before making frequency measurements.

DC Current Measurements

When you connect the multimeter in series with a test circuit to measure current, a measurement error is introduced. The error is caused by the multimeter's series burden voltage. A voltage is developed across the wiring resistance and current shunt resistance of the multimeter, as shown below.




V_s = source voltage
 R_s = DUT source resistance
 V_b = multimeter burden voltage
 R = multimeter current shunt


$$\text{Error (\%)} = \frac{-100\% \times V_b}{V_s}$$

Capacitance Measurements

The multimeter implements capacitance measurements by applying a known current to the capacitor as shown below:



An Illustration of the response curve while charging is shown below:



Capacitance is calculated by measuring the change in voltage (ΔV) that occurs over a "short aperture" time, (Δt). This measurement is repeated at two different times during the exponential rise that occurs. An algorithm takes the data from these four points, and by linearizing that exponential rise over these "short apertures", accurately calculates the capacitance value.

The measurement cycle consists of two parts: a charge phase (shown in the graph) and a discharge phase. The time-constant during the discharge phase is longer, due to a 100k Ω protective resistor in the measurement path. This time-constant plays an important role in the resultant reading rate (measurement time).

The incremental times, or “sample times”, as well as the width of the “short apertures”, vary by range, in order to minimize noise and increase reading accuracy. The following table lists the current amplitude, peak voltage and average dc voltage developed across the capacitor during the measurement.

| Range | Current Source | Reading Rate at full scale | Reading Rate @ 10% of full scale | Applied Voltage | Approx. dc bias @ full scale |
|------------|----------------|----------------------------|----------------------------------|-----------------|------------------------------|
| 1 nF | 500nA | 5/second | 12/second | 5V | 2V |
| 10 nF | 1 μ A | 5/second | 24/second | 5V | 2V |
| 100 nF | 10 μ A | 5/second | 26/second | 4V | 2V |
| 1 μ F | 10 μ A | 2/second | 18/second | 1.5V | 1V |
| 10 μ F | 100 μ A | 0.3/second | 2.5/second | 1.5V | 1V |

These values all vary by range. Control of the peak voltage across the capacitor is important in some cases, such as when measuring larger electrolytic capacitors.

The values of capacitance and loss resistance measured with the multimeter may differ from the values measured using an LCR meter. This is to be expected, since this is essentially a dc measurement method, while LCR measurement uses applied frequencies anywhere from 100 Hz to 100 kHz. In most cases, neither method measures the capacitor at its exact frequency of application.

The multimeter will measure capacitance over a range from 1nF to 10 μ F. Voltage developed across the capacitor being measured is limited to less than 10V. The multimeter’s measurement accuracy is 0.4% of the reading, + 0.1% of the range in use (except for the 1nF range, for which the accuracy is 0.5% of the reading, + 0.5% of the range).

Example: For a 5 nF capacitor, measured using the 10 nF range, the accuracy will be (0.4%)(5 nF) + (0.1%)(10 nF) = 30 pF total error possible.

For the best accuracy, take a zero null measurement with open probes, to null out the test lead capacitance, before connecting the probes across the capacitor to be measured.

Temperature Measurements

The multimeter allows the measurement of temperature by measurement of the temperature sensitive resistance of two different "Probe" types: the resistance temperature detector (RTD) of $.0385\%/^{\circ}\text{C}$; and thermistors of 2.2 K Ω , 5 K Ω or 10 K Ω). There are a number of measurement parameter and technique choices available to you, and these will affect various aspects of the measurement:

- Temperature range and resolution can direct the probe-type choice.
- Choice of four-wire or two-wire technique will affect measurement accuracy.
- Use of the auto zero feature will impact measurement speed and accuracy.
- Choice of integration (measurement time) setting will affect measurement accuracy and power-line noise rejection.
- Use of the offset compensation feature can eliminate residual voltages in the test instrumentation or circuit.

Probe Type Choice

RTD's provide very accurate, highly linear relationships between resistance and temperature, over a range of roughly -200 to 500°C . There is very little conversion complexity for an RTD since it is so intrinsically linear. The multimeter provides measurement for the IEC751 standard RTD, which has a sensitivity of $.0385\%/^{\circ}\text{C}$.

Thermistors consist of semiconductor materials, and provide roughly 10 times the sensitivity of the RTD. Because they are semiconductors, their temperature range is more limited, commonly to -80°C to 150°C . Thermistors have highly non-linear temperature-resistance relationships; therefore their conversion algorithms are more complex. The Agilent multimeters use the standard Hart-Steinhart Approximation to provide accurate conversions, with a typical resolution of $.08^{\circ}\text{C}$.

2-Wire vs. 4-Wire Measurements

As with resistance measurements, four-wire temperature measurement is more accurate, since it *completely* eliminates errors due to lead wire resistance. Alternately, you can use the multimeter's Null function to remove the test lead resistance from the measurement (see "[NULL Reading:](#)" on page 113).

Auto Zero On/Off

Enabling the auto zero feature (ON) provides greater accuracy; however, the additional measurement will reduce the reading speed.

Integration

There are two methods of integrating the sampled data taken in the measurement, NPLC's and Aperture.

NPLC's sets the number of power line cycles in the gating of the measurement. The range of choices for NPLC includes 0.001 and 0.002 (for model 34411A only), 0.006, 0.06, 0.02, 0.2, 1, 2, 10 and 100.

The fractional NPLC values offer faster measurements, at the expense of some time integration accuracy. When you set the NPLC to 1 or more, you not only achieve improved accuracy associated with time averaging, but also achieve rejection of the power-line interference (normal mode rejection, or NMR); the greater the integral NPLC value, the larger the NMR.

Aperture is the period, measured in seconds, during which the multimeter's analog-to-digital (A/D) converter samples the input signal for a measurement. A longer aperture yields better resolution; a shorter aperture provides for faster measurements. This selectable feature allows the user to set a specific measurement period, not based on power line frequency. Selectable values range from 300 μ s to 1s for the 34410A, and from 300 μ s to 1s for the 34411A. Setting an aperture value provides no NMR.

Offset Compensation

With offset compensation enabled (ON), the multimeter makes a normal temperature measurement first, followed by a second measurement to determine any offset voltage in the input circuitry. The resultant displayed measurement corrects for this offset. Enabling offset compensation increases measurement time.

NULL Reading:

The multimeter allows a separate null setting to be saved for the temperature function. When making null measurements, each reading is the difference between a stored null value and the input signal. One application of NULL is to increase accuracy of two-wire resistance measurements by first nulling the closed-circuit test lead resistance.

High-Speed Measurements

Making High-Speed AC Measurements

The multimeter's ac voltage and ac current functions implement three different low-frequency filters. These filters allow you to trade-off minimum measured frequency for faster reading speed. The FAST filter settles in 0.025 seconds, and is useful for frequencies above 200 Hz. The MEDIUM filter settles in 0.63 seconds for voltage and 0.25 seconds for current, and is useful for measurements above 20 Hz. The SLOW filter settles in 2.5 seconds for voltage and 1.67 seconds for current, and is useful for frequencies above 3 Hz.

With a few precautions, you can perform ac measurements at speeds up to 500 readings per second. Use manual ranging to eliminate autoranging delays. By setting the trigger delay to 0, the FAST, MEDIUM, and SLOW filters will allow up to 500, 150, and 50 readings per second, albeit with reduced accuracy, since the filter may not fully settle. If the sample-to-sample levels are similar, little settling time is required for each new reading. Under this specialized condition, the MEDIUM filter will provide reduced accuracy results at 20 readings per second, and the FAST filter will provide reduced accuracy results at 200 readings per second.

| AC Filter | Filter Bandwidth | Settling Time (Seconds) | | Full Settling (rdgs/Sec) | | Partial Settling | Maximum |
|---------------|------------------|-------------------------|-------|--------------------------|-----|------------------|----------|
| | | ACV | ACI | ACV | ACI | ACV/ACI | rdgs/Sec |
| Slow | 3 Hz | 2.5 | 1.67 | 0.4 | 0.6 | 2 | 50 |
| Medium | 20 Hz | 0.63 | 0.25 | 1.6 | 4 | 20 | 150 |
| Fast | 200 Hz | 0.025 | 0.025 | 40 | 40 | 200 | 500 |

In applications where sample-to-sample levels vary widely, but the dc offset level does not change, the MEDIUM filter will settle at 2 to 4 readings per second (depending upon the lowest frequency component in the waveform) as shown in the following table:

| Medium Filter Performance | | Full Accuracy Reading Rate No DC Level Change | | | |
|--------------------------------------|--|--|-------|--------|--------|
| Lowest Frequency Component | | 20 Hz | 50 Hz | 100 Hz | 200 Hz |
| AC Current (allowable rate rdgs/Sec) | | 4 | 4 | 4 | 4 |
| AC Voltage (allowable rate rdgs/Sec) | | 2 | 3 | 4 | 4 |

For ac voltage, additional settling time may be required when the dc level varies from sample to sample. The default sample delays allow for a dc level change of 3% of range for all filters. If the dc level change exceeds these levels, additional settling time is required. The multimeter's dc blocking circuitry has a settling time constant of 0.2 seconds. This settling time only affects measurement accuracy when dc offset levels vary from sample to sample. If maximum measurement speed is desired in a scanning system, you may want to add an external dc blocking circuit to those channels with significant dc voltages present. This circuit can be as simple as a resistor and a capacitor.

For ac current, additional settling time is not required when the dc level varies sample to sample.

Making High-Speed dc and Resistance Measurements

The multimeter incorporates an automatic zero measurement procedure (autozero) to eliminate internal thermal EMF and bias current errors. Each measurement actually consists of a measurement of the input terminals followed by a measurement of the internal offset voltage. The internal offset voltage error is subtracted from the input for improved accuracy. This compensates for offset voltage changes due to temperature. For maximum reading speed, turn autozero off. This will more than double your reading speeds for dc voltage, resistance, and dc current functions. Autozero does not apply to other measurement functions.

Other Sources of Measurement Error

Settling Time Effects

The multimeter has the ability to insert automatic measurement settling delays. These delays are adequate for resistance measurements with less than 200 pF of combined cable and device capacitance. This is particularly important if you are measuring resistances above 100 kΩ. Settling due to RC time constant effects can be quite long. Some precision resistors and multi-function calibrators use large parallel capacitors (1000 pF to 0.1 μF) with high resistor values to filter out noise currents injected by their internal circuitry. Non-ideal capacitances in cables and other devices may have much longer settling times than expected just by RC time constants due to dielectric absorption (soak) effects. Errors will be measured when settling after the initial connection and after a range change.

Loading Errors (ac volts)

In the ac voltage function, the input of the multimeter appears as a 1 MΩ resistance in parallel with 100 pF of capacitance. The cabling that you use to connect signals to the multimeter will also add additional capacitance and loading. The table below shows the multimeter's approximate input resistance at various frequencies.

| Input Frequency | Input Resistance |
|-----------------|------------------|
| 100 Hz | 1 MΩ |
| 1 kHz | 850 kΩ |
| 10 kHz | 160 kΩ |
| 100 kHz | 16 kΩ |

For low frequencies, the loading error is:

$$\text{Error (\%)} = \frac{-100 \times R_s}{R_s + 1 \text{ M}\Omega}$$

At high frequencies, the additional loading error is:

$$\text{Error (\%)} = 100 \times \left[\frac{1}{\sqrt{1 + (2 \pi \times F \times R_s \times C_{in})^2}} - 1 \right]$$

R_s = source resistance
 F = input frequency
 C_{in} = input capacitance (100 pF) plus cable capacitance

Measurements Below Full Scale

You can make the most accurate ac measurements when the multimeter is at or near the full scale of the selected range. Autoranging occurs at 10% (down-range) and 120% (up-range) of full scale. This enables you to measure some inputs at full scale on one range and 10% of full scale on the next higher range. In general, the accuracy will be better on the lower range; for the highest accuracy, select the lowest manual range possible for the measurement.

High-Voltage Self-Heating Errors

If you apply more than 300 V_{rms}, self-heating will occur in the multimeter's internal signal-conditioning components. These errors are included in the multimeter's specifications.

Temperature changes inside the multimeter due to self-heating may cause additional error on other ac voltage ranges. The additional error will be less than 0.02% and will dissipate in a few minutes.

AC Current Measurement Errors (Burden Voltage)

Burden voltage errors, which apply to dc current, also apply to ac current measurements. However, the burden voltage for ac current is larger due to the multimeter's series inductance and your measurement connections. The burden voltage increases as the input frequency increases. Some circuits may oscillate when performing current measurements due to the multimeter's series inductance and your measurement connections.

Low-Level Measurement Errors

When measuring ac voltages less than 100 mV, be aware that these measurements are especially susceptible to errors introduced by extraneous noise sources. An exposed test lead will act as an antenna and a properly functioning multimeter will measure the signals received. The entire measurement path, including the power line, act as a loop antenna. Circulating currents in the loop will create error voltages across any impedances in series with the multimeter's input. For this reason, you should apply low-level ac voltages to the multimeter through shielded cables. You should connect the shield to the input LO terminal.

Make sure the multimeter and the ac source are connected to the same electrical outlet whenever possible. You should also minimize the area of any ground loops that cannot be avoided. A high-impedance source is more susceptible to noise pickup than a low-impedance source. You can reduce the high-frequency impedance of a source by placing a capacitor in parallel with the multimeter's input terminals. You may have to experiment to determine the correct capacitor value for your application.

Most extraneous noise is not correlated with the input signal. You can determine the error as shown below.

$$\text{Voltage Measured} = \sqrt{V_{\text{in}}^2 + \text{Noise}^2}$$

Correlated noise, while rare, is especially detrimental. Correlated noise will always add directly to the input signal. Measuring a low-level signal with the same frequency as the local power line is a common situation that is prone to this error.


Common Mode Errors


Errors are generated when the multimeter's input LO terminal is driven with an ac voltage relative to earth. The most common situation where unnecessary common mode voltages are created is when the output of an ac calibrator is connected to the multimeter "backwards." Ideally, a multimeter reads the same regardless of how the source is connected. Both source and multimeter effects can degrade this ideal situation. Because of the capacitance between the input LO terminal and earth (approximately 200 pF), the source will experience different loading depending on how the input is applied. The magnitude of the error is dependent upon the source's response to this loading.

The multimeter's measurement circuitry, while extensively shielded, responds differently in the backward input case due to slight differences in stray capacitance to earth. The multimeter's errors are greatest for high-voltage, high-frequency inputs. Typically, the multimeter will exhibit about 0.06% additional error for a 100 V, 100 kHz reverse input. You can use the grounding techniques described for dc common mode problems to minimize ac common mode voltages.

Leakage Current Errors

The multimeter's input capacitance will "charge up" due to input bias currents when the terminals are open-circuited (if the input resistance is $>10\text{ G}\Omega$). The multimeter's measuring circuitry exhibits approximately 30pA of input bias current for ambient temperatures from 0 °C to 30 °C. Bias current will double (X2) for every 8 °C change in ambient temperature above 30 °C. This current generates small voltage offsets dependent upon the source resistance of the device-under-test. This effect becomes evident for a source resistance of greater than 100 k Ω , or when the multimeter's operating temperature is significantly greater than 30 °C.





5 Specifications

| | |
|---|-----|
| DC Characteristics | 123 |
| AC Characteristics | 126 |
| Frequency and Period Characteristics | 128 |
| Capacitance Characteristics | 130 |
| Temperature Characteristics | 130 |
| Measurement and System Speeds | 131 |
| General Specifications | 133 |
| Dimensions | 135 |
| To Calculate Total Measurement Error | 136 |
| Accuracy Specifications | 138 |
| Configuring for Highest Accuracy Measurements | 139 |



These specifications apply when using the 34410A/34411A multimeter in an environment that is *free* of electromagnetic interference and electrostatic charge.

When using the multimeter in an environment where electromagnetic interference or significant electrostatic charge *is* present, measurement accuracy may be reduced. *Particularly note:*

- The voltage measurement probes are not shielded and can act as antennas, causing electromagnetic interference to be added to the signal being measured.
- Electrostatic discharges of 4000 V or greater may cause the multimeter to temporarily stop responding, resulting in a lost or erroneous reading.

Note: Specifications are subject to change without notice. For the latest specifications, go to the Agilent 34410A/11A product page.

www.agilent.com/find/34410A

This ISM device complies with Canadian ICES-001.

Cet appareil ISM est conforme à la norme NMB-001 du Canada.



DC Characteristics

Accuracy Specifications (% of reading + % of range) ^[1]

| Function | Range ^[3] | Test Current or Burden Voltage | 24 Hour ^[2] $T_{CAL} \pm 1\text{ }^{\circ}\text{C}$ | 90 Day $T_{CAL} \pm 5\text{ }^{\circ}\text{C}$ | 1 Year $T_{CAL} \pm 5\text{ }^{\circ}\text{C}$ | Temperature Coefficient $0\text{ }^{\circ}\text{C} - (T_{CAL} - 5\text{ }^{\circ}\text{C})$ $(T_{CAL} + 5\text{ }^{\circ}\text{C}) - 55\text{ }^{\circ}\text{C}$ |
|----------------------------------|---------------------------|--------------------------------|---|---|---|--|
| DC | 100.0000 mV | | 0.0030+0.0030 | 0.0040+0.0035 | 0.0050+0.0035 | 0.0005+0.0005 |
| | 1.000000 V | | 0.0020+0.0006 | 0.0030+0.0007 | 0.0035+0.0007 | 0.0005+0.0001 |
| | 10.00000 V | | 0.0015+0.0004 | 0.0020+0.0005 | 0.0030+0.0005 | 0.0005+0.0001 |
| | 100.0000 V | | 0.0020+0.0006 | 0.0035+0.0006 | 0.0040+0.0006 | 0.0005+0.0001 |
| | 1000.000 V ^[5] | | 0.0020+0.0006 | 0.0035+0.0006 | 0.0040+0.0006 | 0.0005+0.0001 |
| Resistance ^[4] | 100.0000 Ω | 1 mA Current Source | 0.0030+0.0030 | 0.008+0.004 | 0.010+0.004 | 0.0006+0.0005 |
| | 1.000000 K Ω | 1 mA | 0.0020+0.0005 | 0.007+0.001 | 0.010+0.001 | 0.0006+0.0001 |
| | 10.00000 K Ω | 100 μ A | 0.0020+0.0005 | 0.007+0.001 | 0.010+0.001 | 0.0006+0.0001 |
| | 100.0000 K Ω | 10 μ A | 0.0020+0.0005 | 0.007+0.001 | 0.010+0.001 | 0.0006+0.0001 |
| | 1.000000 M Ω | 5.0 μ A | 0.0020+0.0010 | 0.010+0.001 | 0.012+0.001 | 0.0010+0.0002 |
| | 10.00000 M Ω | 500 nA | 0.0100+0.0010 | 0.030+0.001 | 0.040+0.001 | 0.0030+0.0004 |
| | 100.0000 M Ω | 500 nA 10 M Ω | 0.200+0.001 | 0.600+0.001 | 0.800+0.011 | 0.1000+0.0001 |
| | 1000.000 M Ω | 500 nA 10 M Ω | 2.000+0.001 | 6.000+0.001 | 8.000+0.001 | 1.0000+0.0001 |
| DC Current | 100.0000 μ A | <0.03 V Burden V | 0.010+0.020 | 0.040+0.025 | 0.050+0.025 | 0.0020+0.0030 |
| | 1.000000 mA | <0.3 V | 0.007+0.006 | 0.030+0.006 | 0.050+0.005 | 0.0020+0.0005 |
| | 10.00000 mA | <0.03 V | 0.007+0.020 | 0.030+0.020 | 0.050+0.020 | 0.0020+0.0020 |
| | 100.0000 mA | <0.3 V | 0.010+0.004 | 0.030+0.005 | 0.050+0.005 | 0.0020+0.0005 |
| | 1.000000 A | <0.80 V | 0.050+0.006 | 0.080+0.010 | 0.100+0.010 | 0.0050+0.0010 |
| | 3.00000 A | <2.0 V | 0.100+0.020 | 0.120+0.020 | 0.150+0.020 | 0.0050+0.0020 |
| Continuity | 1000 Ohms | 1 mA Test Current | 0.002+0.010 | 0.008+0.020 | 0.010+0.020 | 0.0010+0.0020 |
| Diode Test | 1.0000 V ^[6] | 1 mA Test Current | 0.002+0.010 | 0.008+0.020 | 0.010+0.020 | 0.0010+0.0020 |

[1] Specifications are for 1-hour warm-up and integration setting of 100 NPLC.

[2] Relative to calibration standards.

[3] 20% overrange on all ranges, except 1000 Vdc, 3 A range.

[4] Specifications are for 4-wire ohms function, or 2-wire ohms using Math Null. Without Math Null, add 0.2 Ω additional error in 2-wire ohms function.

[5] For each additional volt over ± 500 VDC add 0.02 mV of error.

[6] Accuracy specifications are for the voltage measured at the input terminals only. 1 mA test current is typical. Variation in the current source will create some variation in the voltage drop across a diode junction

Performance Versus Integration Time – 60Hz (50Hz) Power line frequency

| Integration Time Number of Power Line Cycles (NPLC) | Resolution ppm Range ^[1] | NMR db ^[2] | Readings / Second ^[3] | RMS Noise adder % range ^[4] | | |
|---|--|-----------------------|-------------------------------------|--|--|---|
| | | | | DCV 10, 1000 V | DCV 1, 100 V Resistance 1K, 10K ohm | DCV 0.1 V Resistance 100 ohm DCI 1 amp |
| 0.001 ^[6] | 30 | 0 | 50,000 | 0.0060 | 0.0100 | 0.1000 |
| 0.002 ^[6] | 15 | 0 | 25,000 | 0.0030 | 0.0060 | 0.0600 |
| 0.006 | 6 | 0 | 10,000 | 0.0012 | 0.0040 | 0.0600 |
| 0.02 | 3 | 0 | 3000 | 0.0006 | 0.0030 | 0.0300 |
| 0.06 | 1.5 | 0 | 1000 | 0.0003 | 0.0020 | 0.0200 |
| 0.2 | 0.7 | 0 | 300 | 0.0002 | 0.0015 | 0.0150 |
| 1 | 0.3 | 55 | 60(50) | 0.0 | 0.0001 | 0.0010 |
| 2 | 0.2 | 110 ^[5] | 30(25) | 0.0 | 0.0001 | 0.0010 |
| 10 | 0.1 | 110 ^[5] | 6(5) | 0.0 | 0.0 | 0.0005 |
| 100 | 0.03 | 110 ^[5] | 0.6(0.5) | 0.0 | 0.0 | 0.0 |

[1] Resolution is defined as the typical 10 VDC range RMS noise.

[2] Normal mode rejection for power-line frequency $\pm 0.1\%$.

[3] Maximum rate for DCV, DCI, and 2-Wire resistance functions
(using zero settling delay, autozero off, etc.).

[4] Autozero on for $\Rightarrow 1$ NPLC.

[5] For power-line frequency $\pm 1\%$ 75 dB and for $\pm 3\%$ 55 dB.

[6] Only for 34411A.

Transfer Accuracy (Typical)

All DC volts, <0.12 A DC Current, < 1.2 M Ω : (24 hour % of range error) / 2)

All other DC current and resistance: (24 hour % of range error + % of reading)/2

Conditions: - Within 10 minutes and ± 0.5 °C

- Within $\pm 10\%$ of initial value.

- Following a 2-hour warm-up.

- Fixed range.

- Using ≥ 10 .

- Measurements are made using accepted metrology practices.

DC Voltage

| | |
|-------------------------|---|
| Measurement Method: | Continuously integrating multi-slope IV |
| 10 VDC Linearity: | 0.0002% of reading + 0.0001% of range |
| Input Resistance: | |
| 0.1 V, 1 V, 10 V Ranges | Selectable 10 M Ω or >10 G Ω (For these ranges, inputs beyond ± 17 V are clamped through 100 k Ω typical) |
| 100 V, 1000 V Ranges | 10 M Ω $\pm 1\%$ |
| Input Bias Current: | < 30 pA at 25 °C |
| Input Terminals: | Copper alloy |
| Input Protection: | 1000 V |
| DC CMRR | 140 dB for 1 k Ω unbalance in LO lead. ± 500 VDC maximum |

Resistance

| | |
|----------------------|--|
| Measurement Method: | Selectable 4-wire or 2-wire ohms. |
| Max. Lead Resistance | 10% of range per lead for 100 Ω , 1 k Ω ranges. |
| (4-wire ohms) | 1 k Ω per lead on all other ranges |
| Input Protection: | 1000 V on all ranges |
| Offset Compensation: | Selectable on the 100 Ω , 1 k Ω , and 10 k Ω ranges |

DC Current

| | |
|-------------------|--|
| Shunt Resistor: | 0.1 Ω for 1 A, 3 A. 2 Ω for 10 mA, 100 mA. 200 Ω for 100 μ A, 1 mA. |
| Input Protection: | Externally accessible 3 A, 250 V fuse |

Continuity / Diode Test

| | |
|-----------------------|-------------------------------------|
| Response Time: | 300 samples / sec with audible tone |
| Continuity Threshold: | Fixed at 10 Ω |

Autozero OFF Operation (Typical)

Following instrument warm-up at a stable ambient temperature ± 1 °C and <5 minutes.
Add 0.0002% of range + 2 μ V for DCV or + 2 m Ω for resistance.

Settling Considerations

Reading settling times are affected by source impedance, cable dielectric characteristics, and input signal changes. Default delays are selected to give first reading right for most measurements.

Measurement Considerations

Agilent recommends the use of Teflon or other high-impedance, low-dielectric absorption wire insulation for these measurements.

AC Characteristics

Accuracy Specifications (% of reading + % of range) ^[1]

| Function | Range ^[3] | Frequency Range | 24 Hour ^[2] $T_{CAL} \pm 1^{\circ}C$ | 90 Day $T_{CAL} \pm 5^{\circ}C$ | 1 Year $T_{CAL} \pm 5^{\circ}C$ | Temperature Coefficient $0^{\circ}C - (T_{CAL} - 5^{\circ}C)$ $(T_{CAL} + 5^{\circ}C) - 55^{\circ}C$ |
|---|----------------------------------|-------------------|--|------------------------------------|------------------------------------|---|
| True RMS AC Voltage ^[4] | 100.0000 mV to 750.000 V | 3 Hz – 5 Hz | 0.50 + 0.02 | 0.50 + 0.03 | 0.50 + 0.03 | 0.010 + 0.003 |
| | | 5 Hz – 10 Hz | 0.10 + 0.02 | 0.10 + 0.03 | 0.10 + 0.03 | 0.008 + 0.003 |
| | 750.000 V | 10 Hz – 20 kHz | 0.02 + 0.02 | 0.05 + 0.03 | 0.06 + 0.03 | 0.005 + 0.003 |
| | | 20 kHz – 50 kHz | 0.05 + 0.04 | 0.09 + 0.05 | 0.10 + 0.05 | 0.010 + 0.005 |
| | | 50 kHz – 100 kHz | 0.20 + 0.08 | 0.30 + 0.08 | 0.40 + 0.08 | 0.020 + 0.008 |
| | | 100 kHz – 300 kHz | 1.00 + 0.50 | 1.20 + 0.50 | 1.20 + 0.50 | 0.120 + 0.020 |
| True RMS AC Current ^[5] | 100.0000 μ A to 3.00000 A | 3 Hz – 5 kHz | 0.10 + 0.04 | 0.10 + 0.04 | 0.10 + 0.04 | 0.015 + 0.006 |
| | | 5 kHz – 10 kHz | 0.20 + 0.04 | 0.20 + 0.04 | 0.20 + 0.04 | 0.030 + 0.006 |

[1] Specifications are for 1-hour warm-up, slow ac filter, sinewave.

[2] Relative to calibration standards.

[3] 20% overrange on all ranges, except 750 Vac, 3 A range.

[4] Specifications are for sinewave input >0.3% of range and > 1mVrms.

Add 30 μ V error to AC voltage specification for frequencies < 1kHz.

750 VAC range limited to 8×10^7 Volt-Hz.

750 VAC range add 0.7 mV of error for each additional volt over 300 VAC.

[5] Specifications are for sinewave input >1% of range and > 10uArms.

Frequencies > 5 kHz are typical for 1.0 A and 3.0 A ranges.

For 3.0 A range add 0.05 + 0.02.

Low Frequency Performance

Three filter settings are available: 3 Hz, 20 Hz, 200Hz.

Frequencies greater than these filter settings are specified with no additional errors.

AC Current Burden Voltage

| ACI Ranges | Voltage |
|------------------|---------|
| 100.0000 μ A | <0.03 V |
| 1.000000 mA | <0.3 V |
| 10.00000 mA | <0.03 V |
| 100.0000 mA | <0.3 V |
| 1.000000 A | <0.8 V |
| 3.00000 A | <2.0 V |

Voltage Transfer Accuracy (typical)

| | |
|------------------|--|
| Frequency | Error |
| 10 Hz to 300 kHz | (24 hour % of range + % of reading)/5 |
| Conditions: | <ul style="list-style-type: none"> - Sinewave input only using slow filter. - Within 10 minutes and $\pm 0.5^{\circ}\text{C}$. - Within $\pm 10\%$ of initial voltage and $\pm 1\%$ of initial frequency. - Following a 2-hour warm-up. - Fixed range between 10% and 100% of full scale (and $< 120\text{ V}$). - Measurements are made using accepted metrology practices |

True RMS AC Voltage

| | |
|--------------------------|--|
| Measurement Type | AC-coupled True RMS. Measures the AC component of the input. |
| Measurement Method: | Digital sampling with anti-alias filter. |
| AC Common Mode Rejection | 70 dB For 1 k Ω unbalanced in LO lead and $< 60\text{ Hz}$. $\pm 500\text{ V}$ peak maximum. |
| Maximum Input: | 400 Vdc, 1100 Vpeak |
| Input Impedance: | 1 M $\Omega \pm 2\%$, in parallel with $< 150\text{ pF}$ |
| Input Protection: | 750 V rms all ranges |

True RMS AC Current

| | |
|---------------------|---|
| Measurement Type: | Directly coupled to the fuse and shunt. AC-coupled True RMS measurement (measure the AC component only). |
| Measurement Method: | Digital sampling with anti-alias filter. |
| Maximum Input: | The peak value of the DC + AC current must be $< 300\%$ of range. The RMS current $< 3\text{ A}$ including the DC current content. |
| Shunt Resistor: | 0.1 Ω for 1A, 3A, 2 Ω for 10 mA 100 mA, 200 Ω for 100 μA , 1 mA |
| Input Protection: | Externally accessible 3A, 250 V fuse |

Crest Factor and Peak Input

| | |
|------------------|--|
| Crest Factor: | For $< 10:1$ errors included. Limited by peak input and 300 kHz bandwidth. |
| Peak Input: | 300% of Range. Limited by maximum input |
| Overload Ranging | Will select higher range if peak input overload is detected during auto range. Overload is reported in manual ranging. |

Settling Considerations

Default delays are selected to give first reading right for most measurements. The input blocking RC time constant must be allowed to fully settle before the most accurate measurements are possible

Frequency and Period Characteristics

Accuracy Specifications (% of reading) ^[1, 3]

| Function | Range | Frequency Range | 24 Hour ^[2] $T_{CAL} \pm 1\text{ }^{\circ}\text{C}$ | 90 Day $T_{CAL} \pm 5\text{ }^{\circ}\text{C}$ | 1 Year $T_{CAL} \pm 5\text{ }^{\circ}\text{C}$ | Temperature Coefficient $0\text{ }^{\circ}\text{C} - (T_{CAL} - 5\text{ }^{\circ}\text{C})$ $(T_{CAL} + 5\text{ }^{\circ}\text{C}) - 55\text{ }^{\circ}\text{C}$ |
|-----------------------------|--------|-----------------|---|---|---|---|
| Frequency Period | 100 mV | 3 Hz – 5 Hz | 0.07 | 0.07 | 0.07 | 0.005 |
| | to | 5 Hz – 10 Hz | 0.04 | 0.04 | 0.04 | 0.005 |
| | 750 V | 10 Hz – 40 Hz | 0.02 | 0.02 | 0.02 | 0.001 |
| | | 40 Hz – 300 kHz | 0.005 | 0.006 | 0.007 | 0.001 |

Additional Errors (% of reading) ^[3]

| Frequency | Aperture (resolution / range) | | | |
|-----------------|-------------------------------|-----------------------|-------------------------|---------------------------|
| | 1 Second (0.1 ppm) | 0.1 Second (1 ppm) | 0.01 Second (10 ppm) | 0.001 Second (100 ppm) |
| 3 Hz – 5 Hz | 0 | 0.11 | 0.11 | 0.11 |
| 5 Hz – 10 Hz | 0 | 0.14 | 0.14 | 0.14 |
| 10 Hz – 40 Hz | 0 | 0.16 | 0.16 | 0.16 |
| 40 Hz – 300 kHz | 0 | 0.045 | 0.17 | 0.17 |

[1] Specifications are for 1–hour warm–up, using 1 second aperture.

[2] Relative to calibration standards.

[3] For AC input voltages 10% to 120% of range except where noted. 750 V range limited to 750 Vrms. 100 mV range specifications are for full scale or greater inputs. For inputs from 10 mV to 100 mV, multiply total % of reading error by 10.

Transfer Accuracy (typical) 0.0003% of reading

Conditions:

- Within 10 minutes and $\pm 0.5\text{ }^{\circ}\text{C}$.
- Within $\pm 10\%$ of initial voltage and $\pm 1\%$ of initial frequency.
- Following a 2–hour warm–up.
- For inputs $> 1\text{ kHz}$ and $> 100\text{ mV}$
- Using 1 second gate time
- Measurements are made using accepted metrology practices.

Frequency and Period

| | |
|-------------------|--|
| Measurement Type: | Reciprocal-counting technique. AC-coupled input using the AC voltage measurement function. |
| Input Impedance: | 1 M Ω \pm 2%, in parallel with <150 pF |
| Input Protection: | 750 V rms all ranges |

Measurement Considerations

All frequency counters are susceptible to error when measuring low-voltage, low-frequency signals. Shielding inputs from external noise pickup is critical for minimizing measurement errors.

Settling Considerations

Errors will occur when attempting to measure the frequency or period of an input following a dc offset voltage change. The input blocking RC time constant must be allowed to fully settle (up to 1 sec.) before the most accurate measurements are possible.

Capacitance Characteristics

Accuracy Specifications (% of reading + % of range) ^[1]

| Function | Range ^[2] | Test Current | 1 Year 23 °C ± 5 °C | Temperature Coefficient 0 °C – (T _{CAL} – 5 °C) (T _{CAL} + 5 °C) – 55 °C |
|-------------|----------------------|--------------|------------------------|---|
| Capacitance | 1 nF | 500 nA | 0.50 + 0.50 | 0.05 + 0.05 |
| | 10 nF | 1 µA | 0.40 + 0.10 | 0.05 + 0.01 |
| | 100 nF | 10 µA | 0.40 + 0.10 | 0.01 + 0.01 |
| | 1 µF | 100 µA | 0.40 + 0.10 | 0.01 + 0.01 |
| | 10 µF | 1 mA | 0.40 + 0.10 | 0.01 + 0.01 |

[1] Specifications are for 1-hour warm-up using Math Null. Measurement Method: Current input with measurement of resulting ramp. Additional errors may occur for non-film capacitors.

[2] Specifications are for 1% to 120% of range on the 1 nF range and 10% to 120% of range on all other ranges.

Capacitance

Measurement Type: Current input with measurement of resulting ramp.

Connection Type: 2 Wire

Temperature Characteristics

Accuracy Specifications (% of reading + % of range) ^[1]

| Function | Probe Type | R ₀ | --80 °C to 150 °C | Best Range | 1 Year | Temperature Coefficient |
|-------------|------------|----------------|---------------------|-------------------|---------|----------------------------|
| Temperature | RTD | | from 49 Ω to 2.1 kΩ | –200 °C to 600 °C | 0.06 °C | 0.003 °C |
| | Thermistor | N/A | | –80 °C to 150 °C | 0.08 °C | 0.002 °C |

[1] For total measurement accuracy, add temperature probe error

Measurement and System Speeds

DMM Measurements Speeds

| Function | Resolution (NPLC) | Direct I/O Measurements ^[1] Single Reading – Measure and I/O Time | | | | Measurement Into Memory (Readins/Sec) (VM Complete) |
|---|----------------------|---|----------------|---------------------|----------------------|--|
| | | GPIB Sec | USB 2.0 Sec | LAN (VXI-11) Sec | LAN (Sockets) Sec | |
| DCV (10 V Range) | 0.006 | 0.0030 | 0.0036 | 0.0050 | 0.0035 | 10000 |
| | 0.06 | 0.0035 | 0.0044 | 0.0048 | 0.0043 | 1000 |
| | 1 | 0.0200 | 0.0200 | 0.0200 | 0.0200 | 60 |
| ACV (10 V Range) | Slow Filter | 0.0100 | 0.0100 | 0.0100 | 0.0100 | 50 |
| | Medium Filter | 0.0100 | 0.0100 | 0.0100 | 0.0100 | 150 |
| | Fast Filter | 0.0100 | 0.0100 | 0.0100 | 0.0100 | 500 |
| 2-Wire Ω (10 kΩ Range) | 0.006 | 0.0035 | 0.0036 | 0.0049 | 0.0035 | 10000 |
| | 0.06 | 0.0043 | 0.0045 | 0.0049 | 0.0043 | 1000 |
| | 1 | 0.0195 | 0.0200 | 0.0200 | 0.0200 | 60 |
| 4-wire Ω (10 kΩ Range) | 0.006 | 0.0054 | 0.0040 | 0.0045 | 0.0056 | 1200 |
| | 0.06 | 0.0074 | 0.0078 | 0.0078 | 0.0074 | 380 |
| | 1 | 0.0390 | 0.0390 | 0.0390 | 0.0390 | 30 |
| Frequency 1 KHz, 10 V Range Fast Filter | 1 ms Gate | 0.0100 | 0.0100 | 0.0100 | 0.0100 | 500 |
| | 10 mS Gate | 0.0200 | 0.0200 | 0.0200 | 0.0200 | 80 |
| | 100 mS Gate | 0.1150 | 0.1150 | 0.1130 | 0.1130 | 10 |
| | 1 S Gate | 1.0200 | 1.0200 | 1.0200 | 1.0200 | 1 |
| Capacitance (100 nF Range) | | 0.0820 | 0.0820 | 0.0820 | 0.0820 | 11 |

[1] ½ scale input signal, immediate trigger, trigger delay 0, autozero off, autorange off, no math, 60 Hz line, null off, sample count 1, trig count 1

Direct I/O Measurements ^[1] (any remote interface)

Sustained maximum reading rate to I/O, 32-bit BINARY data ("SAMP:COUN 50000::R?")

| Function | Resolution (NPLC) | rdgs/Sec |
|------------------------------------|------------------------|----------|
| DCV | 0.006 | 10000 |
| ACV | Fast Filter | 500 |
| 2-Wire Ω | 0.006 | 10000 |
| 4-Wire Ω | 0.006 | 1200 |
| Frequency/Period (1 k rdgs) | 1 mS gate, fast filter | 450 |
| Capacitance (100 rdgs) | | 11 |

[1] ½ scale input signal, immediate trigger, trigger delay 0, autozero off, autorange off, no math, 60 Hz line, null off, sample count 50000, trig count 1

Data From Memory**Maximum reading rate out of memory**

(Sample count 50000, trigger count 1, "FETC?" or "R?")

| Readings | GPIO rdg/Sec | USB 2.0 rdg/Sec | LAN (VXI-11) rgs/Sec | LAN (Sockets) rdg/Sec |
|----------------------|-----------------|--------------------|-------------------------|--------------------------|
| ASCII | 2850 | 2000 | 4800 | 4000 |
| 4-byte Binary | 89,000 | 265,000 | 110,000 | 270,000 |
| 8-byte Binary | 47,000 | 154,000 | 60,000 | 160,000 |

System Speeds

| | Configuration ^[2] (Sec) | Range ^[3] Change (Sec) | Auto Range ^[4] (Sec) | Maximum External Trigger Rate ^[1] | Maximum Internal Trigger Rate ^[1] |
|-------------------------------------|---------------------------------------|---|------------------------------------|--|--|
| DCV | 0.022 | 0.0055 | 0.0075 | 5000 / S | 10000 / S |
| ACV | 0.037 | 0.0065 | 0.019 | 500 / S | 500 / S |
| 2/4-Wire Ω | 0.022 | 0.0055 | 0.0075 | 5000 / S | 10000 / S |
| Frequency/Period | 0.037 | 0.0065 | 0.019 | 500 / S | 500 / S |

[1] Readings to memory.

[2] Time for configuration change from 2W ohms to listed function (or from dc volts to 2W ohms) using appropriate FUNCtion command.

[3] Time to change from one range to next higher range, <=10V, <=10Mohm.

[4] Time to automatically change one range and be ready for new measurement, <=10V, <=10Mohm.

General Specifications

| | |
|---------------------------|---|
| Power Supply: | 100V/120V/ 220V / 240V \pm 10% |
| Power Line Frequency: | 50–60 Hz \pm 10%, 400 Hz \pm 10%. Automatically sensed at power–on, 400 Hz defaults to 50Hz. |
| Power Consumption: | 25 VA peak (16 W average) |
| Operating Environment: | Full accuracy for 0 °C to 55 °C Full accuracy to 95% R.H. at 40 °C Non–condensing |
| Storage Temperature | –40 °C to 70 °C |
| Operating Altitude | Up to 3000m |
| Rack Dimensions (WxHxD): | 212.8mm x 88.3mm x 272.3mm |
| Bench Dimensions (WxHxD): | 261.2mm x 103.8mm x 303.2mm |
| Weight: | 3.72 kg (8.2 lbs) |
| Safety: | IEC 61010-1 EN 61010-1 UL 61010-1 CAN/CSA-C22.2 No. 61010-1 Refer to Declaration of Conformity for current revisions. Measurement CAT II 300V, CAT I 1000V Pollution Degree 2 |
| EMC: | IEC 61326 EN 61326 CISPR 11 ICES-001 AS/NZS 2064.1 Refer to Declaration of Conformity for current revisions. |
| Vibration & Shock: | MIL-T-28800, type III, Class 5 |
| Acoustic Noise | 37 dBA |
| Display: | Dual–line, 17–segment vacuum florescent display |
| State Storage Memory | Power Off state automatically saved, 4 User Configurable Stored States |
| Remote Interfaces | GPB IEEE–488, 10/100Mbit LAN, USB 2.0 Standard |
| Language | SCPI – 1999, IEEE–488.2 |
| LXI Compliance | Level C without auto–MDIX |
| Warm–up Time | 1 hour |

Triggering and Memory

| | |
|---------------------------|--|
| Reading Hold Sensitivity: | 1% of reading |
| Samples per Trigger: | 1 to 50,000 |
| Trigger Delay: | 0 to 3600 sec (20 μ s step size) |
| External Trigger | Low-power TTL compatible input programmable edge triggered |









| | |
|----------------|-------------|
| Delay: | < 1 μ S |
| Jitter: | < 1 μ S |
| Max rate | up to 5 kHz |
| Min Pulsewidth | 1 us |

| | |
|---------------------------|-------------------------|
| Voltmeter Complete | 3 V Logic output |
| Polarity | Programmable edge pulse |
| Pulsewidth | Approximately 2 μ s |
| Non-volatile Memory | 50,000 reading |

Sample Timer

| | |
|--------|------------------------------------|
| Range | Up to 3600 sec in 20 μ s steps |
| Jitter | < 100 ns |

Dimensions



All dimensions are shown in millimeters

To Calculate Total Measurement Error

The multimeter's accuracy specifications are expressed in the form: (% of reading + % of range). In addition to the reading error and range error, you may need to add additional errors for certain operating conditions. Check the list below to make sure you include all measurement errors for a given function. Also, make sure you apply the conditions as described in the footnotes on the specification pages.

- If you are operating the multimeter outside the temperature range specified, apply an additional temperature coefficient error.
- For dc voltage, dc current, and resistance measurements, you may need to apply an additional reading speed error or autozero OFF error.
- For ac voltage and ac current measurements, you may need to apply an additional low frequency error or crest factor error.

Understanding the " % of reading " Error The reading error compensates for inaccuracies that result from the function and range you select, as well as the input signal level. The reading error varies according to the input level on the selected range. This error is expressed in percent of reading. The following table shows the reading error applied to the multimeter's 24-hour dc voltage specification.

| Range | Input Level | Reading Error (% of reading) | Reading Error (Voltage) |
|--------|-------------|---------------------------------|----------------------------|
| 10 VDC | 10 VDC | 0.0015 | $\pm 150\ \mu\text{V}$ |
| 10 VDC | 1 VDC | 0.0015 | $\pm 15\ \mu\text{V}$ |
| 10 VDC | 0.1 VDC | 0.0015 | $\pm 1.5\ \mu\text{V}$ |

Understanding the " % of range " Error The range error compensates for inaccuracies that result from the function and range you select. The range error contributes a constant error, expressed as a percent of range, independent of the input signal level. The following table shows the range error applied to the multimeter's 24-hour dc voltage specification.

| Range | Input Level | Range Error (% of range) | Range Error (Voltage) |
|--------|-------------|-----------------------------|--------------------------|
| 10 VDC | 10 VDC | 0.0004 | $\pm 40 \mu\text{V}$ |
| 10 VDC | 1 VDC | 0.0004 | $\pm 40 \mu\text{V}$ |
| 10 VDC | 0.1 VDC | 0.0004 | $\pm 40 \mu\text{V}$ |

Total Measurement Error To compute the total measurement error, add the reading error and range error. You can then convert the total measurement error to a "percent of input" error or a "ppm (parts-per-million) of input" error as shown below.

$$\% \text{ of input error} = \frac{\text{Total Measurement Error}}{\text{Input Signal Level}} \times 100$$

$$\text{ppm of input error} = \frac{\text{Total Measurement Error}}{\text{Input Signal Level}} \times 1,000,000$$

Error Example Assume that a 5 VDC signal is input to the multimeter on the 10 V range. Compute the total measurement error using the 90-day accuracy specifications: \pm (0.0020% of reading + 0.0005% of range).

$$\text{Reading Error} = 0.0020\% \times 5 \text{ VDC} = 100 \mu\text{V}$$

$$\text{Range Error} = 0.0005\% \times 10 \text{ VDC} = 50 \mu\text{V}$$

$$\begin{aligned} \text{Total Error} &= 100 \mu\text{V} + 50 \mu\text{V} = \pm 150 \mu\text{V} \\ &= \pm 0.003\% \text{ of } 5 \text{ VDC} \\ &= \pm 30 \text{ ppm of } 5 \text{ VDC} \end{aligned}$$

Accuracy Specifications

Transfer Accuracy

Transfer accuracy refers to the error introduced by the multimeter due to noise and short-term drift. This error becomes apparent when comparing two nearly-equal signals for the purpose of "transferring" the known accuracy of one device to the other.

24-Hour Accuracy

The 24-hour accuracy specification indicates the multimeter's relative accuracy over its full measurement range for short time intervals and within a stable environment. Short-term accuracy is usually specified for a 24-hour period and for a ± 1 °C temperature range.

90-Day and 1-Year Accuracy

These long-term accuracy specifications are valid for a $23\text{ °C} \pm 5\text{ °C}$ temperature range. These specifications include the initial calibration errors plus the multimeter's long-term drift errors.

Temperature Coefficients

Accuracy is usually specified for a $23\text{ °C} \pm 5\text{ °C}$ temperature range. This is a common temperature range for many operating environments. You must add additional temperature coefficient errors to the accuracy specification if you are operating the multimeter outside a $23\text{ °C} \pm 5\text{ °C}$ temperature range (the specification is per °C).

Configuring for Highest Accuracy Measurements

The measurement configurations shown below assume that the multimeter is in its power-on or reset state. It is also assumed that auto-ranging is enabled to ensure proper full scale range selection.

DC Voltage, DC Current, and Resistance Measurements:

- Select NPLC and 100 (NPLCs) for INTEGRATION.
- Set INPUT Z to HI-Z (for the 100 mV, 1 V, and 10 V ranges) for the best dc voltage accuracy.
- Use the 4-wire ohms function (Ω 4W) for the best resistance measurement accuracy.
- For 2-wire ohms, dc voltage and dc current measurements, set AUTOZERO to ON to remove thermal EMF and offset errors.
- Null the test lead resistance for 2-wire ohms measurements, and to remove any interconnection offset for dc voltage measurements.

AC Voltage and AC Current Measurements:

- Set the AC FILTER to 3 Hz: SLOW.

Frequency and Period Measurements:

- Set the GATE TIME to 1 sec.

Index

1-Year Specifications, [138](#)
24-hour accuracy, [138](#)
34410A, [7](#)
 Dimensions, [135](#)
34411A, [7](#)
90-Day Specifications, [138](#)

A

AC Characteristics, [126](#)
AC Current Measurements, [24](#)
 Configuring, [46](#)
 Configuring for Accuracy, [139](#)
 Errors In, [117](#)
AC Filter, [46, 47, 56](#)
AC Voltage Measurements
 Configuring, [46](#)
 Configuring for Accuracy, [139](#)
 Errors In, [104](#)
 High Speed, [114](#)
 Loading Errors, [116](#)
 Specifications, [126](#)
AC Volts Measurements, [23](#)
Accuracy, [139](#)
Accuracy Specification Explained, [136](#)
Annunciators, [41](#)
Aperture, [54](#)
Auto Triggering, [70](#)
Auto Zero, [45, 46, 47, 58](#)
Auto-IP, [90](#)
Automatic Trigger Delay, [74](#)
Autoranging, [59](#)
Average Value, [67](#)

B

Bandwidth, [22, 43, 56](#)
Beeper, [63](#)
Bumper Removal, [33](#)
Burden Voltage, [117](#)
Bus Triggering, [71](#)

C

Cable Capacitance, [116](#)
Calibration, [84](#)
Calibration Errors, [119](#)
Capacitance Measurements, [27](#)
 Configuring, [48](#)
 Errors In, [110](#)
 Specifications, [130](#)
Carry Handle, [32](#)
Changing Digits Displayed, [22, 43](#)
Character Entry, [44](#)
Configuring
 LAN, [89](#)
 USB, [88](#)
Connectors on Rear Panel, [9](#)
Continuity Test, [29](#)
Capacitance Characteristics, [130](#)

D

Data Logger, [79](#)
dB Measurements, [65](#)
dBm Measurements, [65](#)
DC Characteristics, [123](#)
DC Current Measurements, [24](#)
 Configuring, [45](#)
 Configuring for Accuracy, [139](#)
 Errors In, [109](#)

DC Voltage Measurements
 Configuring, [45](#)
 Configuring for Accuracy, [139](#)
 Errors In, [99](#)
 Hih Speed, [115](#)
 Integration Integration Time, [53](#)
 Loading Error, [99](#)
 Specifications, [123](#)
 Thermal EMF Error, [99](#)
DC Volts Measurement, [23](#)
Declaration of Conformity, [5](#)
Default Gateway, [91](#)
Default Settings, [49](#)
Delay (triggering), [72](#)
Description, [7](#)
DHCP, [89](#)
Digit Masking, [22, 43](#)
Dimensions, [135](#)
Diode Test, [29](#)
Display, [39](#)
 Character Entry, [44](#)
 Shortcuts, [22, 43](#)
 Turn Off, [42](#)
Display Annunciators, [41](#)
Display Options, [42](#)
DNS Server, [89, 92](#)

E

Error Conditions, [84](#)
EXT TRIG Terminal, [76](#)
External Triggering, [76](#)

F

- Factory Settings, 49
- Frequency Characteristics, 128
- Frequency Measurements, 26
 - Configuring, 47
 - Configuring for Accuracy, 139
 - Errors In, 109
 - Specifications, 128
- Front Panel Description, 8, 10
- Front Panel Display, 39
- Front Panel Keys, 21
- Front/Rear Terminal Switch, 48
- Fuse, 30
 - Power Line, 31

G

- Gate Time, 22, 43, 47
- General Specifications, 133
- GPIB Interface, 87
- Ground Loops, 101

H

- High Speed Measurements, 114
- High Voltage Self-Heating Error, 117
- Host Name, 92

I

- I/O Speeds, 131
- IEEE-488, 87
- Input Impedance, 45, 57
- Integration, 45, 46, 48
- INtegration Time, 22, 43
- Integration Time, 100
- Integration Time, 53
- INternal Triggering, 71
- IP Address, 89, 90

K

- Keys, 8, 10, 21

L

- LAN Interface, 86, 89
- Leakage Current, 119
- Limit TEsting, 64
- Limit Testing, 68
- Loading Errors, 99, 116

M

- Magnetic Loop Noise, 101
- Manual Ranging, 59
- MATh Functions
 - dB Measurements, 65
- Math Functions, 64
 - dBm, 65
 - Limit Testing, 68
 - Statistics, 67
- Maximum Value, 67
- Measure
 - 2-Wire Ohms, 25
 - 4-wire Ohms, 25
 - AC Current, 24
 - AC Volts, 23
 - Capacitance, 27
 - Continuity, 29
 - DC Current, 24
 - DC Volts, 23
 - Diode Test, 29
 - Frequency, 26
 - Period, 26
 - Resistance, 25
 - Temperature, 28

- Measurement Error, 136
 - Below Full Scale, 117
 - Burden Voltage, 117
 - Common Mode, 119
 - Ground Loops, 101
 - High Resistance Measurements, 103
 - Leakage Current, 119
 - Loading, 116
 - Loading Errors, 99
 - Low Level Measurements, 117
 - Magnetic Loops, 101
 - Noise, 100
 - Power Dissipation, 103
 - Self-Heating, 117
 - Test Lead Resistance, 103
 - Thermal EMF, 99
- Measurment Speeds, 131
- Menus, 39
- Messages Displayed, 39
- Minimum Value, 67
- Multimeter
 - Failure to Turn On, 30
 - Front Panel Keys, 21
 - Fuse, 30
 - Lead Connections, 21
 - Preparing for Use, 20
 - Rack Mounting, 33
 - Reset, 52
 - Supplied Items, 20
 - Triggering, 69

N

- NMR, 100
- Noise, 100, 101, 117
- Non-volatile Memory, 49
- NPLC, 53
- Null, 45, 46, 47, 48, 61
- Null Measurements, 61

O

- Offset Compensation, 46, 47

P

Period Characteristics, 128
 Period Measurements, 26
 Configuring, 47
 Configuring for Accuracy, 139
 Errors In, 109
 Specifications, 128
 Power Dissipation, 103
 Power Line Noise, Rejecting, 100
 Power On State, 49
 Prepare for Use, 20
 Probe Type, 47

R

Rack Mounting, 33
 Radix Character, 62
 Range, 45, 46, 47, 48, 59
 Reading Hold, 70
 Rear Panel Description, 9
 Relative Measurements, 61
 Remote Annunciator, 86
 Remote Interface Configuration, 86
 Replacing the Power Line Fuse, 31
 Reset, 52
 Resistance Measurements, 25
 Configuring, 46
 Configuring for Accuracy, 139
 Errors In, 102
 High Resistance Errors, 103
 High Speed, 115
 Integration Time, 53
 NPLC, 53
 Settling Time Errors, 116
 Rubber Bumper Removal, 33

S

Safety Information, 3
 Safety Notices, 2
 Safety Symbols, 3
 Sample Count, 67
 Samples per Trigger, 72

SCPI

 Commands, 38
 Language Conventions, 38
 Language Version, 38
 Second Display, 42
 Selecting Front or Rear Terminals, 48
 Self-Test, 83
 Setting
 AC Filter, 46, 47
 Auto Zero, 45, 46, 47
 Beeper, 63
 Centigrade, 48
 Fahrenheit, 48
 Gate Time, 47
 Input IMpedance, 45
 Integration Time, 45, 46, 48
 Kelvin, 48
 NPLC, 45, 46, 48
 Null, 45, 46, 47, 48
 Offset Comp, 46, 47
 Probe Type, 47
 Radix Character, 62
 Range, 45, 46, 47, 48, 59
 Temperature Units, 48
 Settling Time, 56, 116
 Single Triggering, 70
 Software Triggering, 71
 Specifications, 122, 138
 1-year, 138
 24-hour accuracy, 138
 90-day, 138
 Transfer Accuracy, 138
 Specifications Explained, 136
 Standard Deviation, 67
 State Storage, 51
 Statistics, 64, 67
 Store State, 51
 Subnet Mask, 89
 System II Rack Mounts, 33
 System Memory, 51
 System Operations, 83
 System Specifications, 133
 System Speeds, 131

T

TCP/IP, 90
 Temperature Characteristics, 130
 Temperature Coefficients (and Accuracy), 138
 Temperature Measurements, 28
 Configuring, 47
 Errors In, 112
 NPLC, 53
 Units, 48
 Test Lead Resistance, 103
 Test Leads, 21
 Test Limits, 68
 Thermal EMF Errors, 99
 Thousands Separator, 62
 Transfer Accuracy, 138
 Triggering, 69
 Auto Triggering, 70
 Automatic Delay, 74
 Bus, 71
 Delay, 72
 External, 76, 77
 Falling Edge, 77
 Internal, 71
 Reading Hold, 70
 Rising Edge, 77
 Samples Per Trigger, 72
 Single, 70
 Slope, 77
 Software, 71
 Source, 69
 Troubleshooting, 30
 True RMS, 104
 Turn Off Display, 42

Index

U

USB Interface, [86](#), [88](#)

V

VM Complete, [76](#)

W

Waste Electrical and Electronic Equipment
Directive, [2](#)

Web Browser, [93](#)

Web Password, [89](#), [92](#)