

ATTENTION

For Customers Who Have Connected The VCR To TV Via RF Connection:

If the relevant on-screen menu does not appear...

- ... when you press **PROG** in step 2 of "VCR Plus+ Timer Programming" (☞ pg. 38) or "Express Timer Programming" (☞ pg. 42),
- ... when you press **PROG. CHECK** in step 2 of "Check, Cancel And Revise Programs" (☞ pg. 44),

press **TV/VCR** on the remote control so that the VCR indicator lights up on the front display panel.

ATTENTION

Pour les utilisateurs qui ont raccordé le magnétoscope au téléviseur via le raccordement RF:

Si le menu sur écran qui a rapport n'apparaît pas...

- ... lorsque vous appuyez sur **PROG** à l'étape 2 de "Programmation de la minuterie VCR Plus+" (☞ p. 38) ou de "Programmation Express de la minuterie" (☞ p. 42),
 - ... lorsque vous appuyez sur **PROG. CHECK** à l'étape 2 de "Vérifier, annuler et corriger des programmes" (☞ p. 44),
- appuyer sur **TV/VCR** sur la télécommande pour que l'indicateur VCR s'allume sur le panneau d'affichage avant.