



This manual is for reference and historical purposes, all rights reserved.

This creation is copyright© by M. Butkus, NJ, U.S.A.

These creations may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

If you find this manual useful, how about a donation of \$2 to:

M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701

and send your e-mail address so I can thank you.

Most other places would charge you \$7.50 for a electronic copy or

\$18.00 for a hard to read Xerox copy.

This will allow me to continue this site, buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

If you use Pay Pal, go to my web site

www.orphancameras.com and choose the secure PayPal donation icon.

for setting exposure speed
depress knurled ring

shutter after release

eyepiece for prism
reflex focusing : for
explanation of linear
markings, see
page 5

socket for exposuremeter

viewfinder-eyepiece
for 50 mm standard
lenses

see page 3

space for notes,
see page 16

see pages 2/3

shutter wound up

winding knob

toothwheel for
filmcounter, see
page 3

exposure
counter

electronic flash contact,
German standard plug,
see pages 16/17

focusing and depth of field
scales ; fractions indicate
reproduction ratios, see
pages 8/9

preset diaphragm ring

shutter release
button for cable release, see
pages 3 and 12

flashbulb contact, Kalart-
Graflex standard plug,
see pages 16/17

To convert for German
standard plug ask for
«interpris» accessory

preset diaphragm ring

for rewinding film pull out
knob

coupling knob to be pressed
constantly, while rewinding
film, see page 12

to open camerabody turn
key to the right, then pull,
see page 12

loading camera : see pages 12/15

Brief instructions for use of the ALPA 5 Camera



Brief Instruction Guide for use of the



Model 5

P. S. A., April 1956.

Slow shutter speeds not to be used, unless specially mentioned for the particular type of flash bulb. These data compiled from available literature and from own experiments are published without guarantee.

72 : 9 = 8, therefore aperture is f/8

In order to obtain the f/number (aperture), divide the guide number by the distance measured in feet. Example: Film 50° ASA Flash bulb GE 6 1/100 sec. distance 9 feet

Directions for using this chart:

Film speeds		TYPES OF FLASH BULBS															
		PF 45				GE 31 WE 31 SYL 2A				OS S1		OS S2					
Sch °	ASA °	1/100	1/250	1/500	1/1000	1/100	1/250	1/500	1/1000	1/100	1/250	1/500	1/1000	1/100	1/250	1/500	1/1000
32	100	90	60	45	30	25	180	120	90	60	45	30	25	180	120	90	60
30	50	60	45	30	25	180	120	90	60	45	30	25	180	120	90	60	45
27	32	45	30	25	180	120	90	60	45	30	25	180	120	90	60	45	30
26	25	39	27	18	12	75	51	33	27	18	12	75	51	33	27	18	12