

OPERATING SYSTEM SUPPORT*		LanSafe v. 5.0.3
Windows		
Windows 2000 (Server, Advanced Server, Professional)		■
Windows 98		■
Windows Me		■
Windows NT 4.0 (Workstation, Server w/ SP6 or higher)		■
Windows XP (Home, Professional)		■
Windows Server 2003 (Standard, Web, Enterprise ¹)		■
Linux - UNIX - Macintosh		
HP-UX v. 10.20, 11.0, 11i (11.11) for PA-RISC ² v. 11i v1.6 (11.22) for Itanium ² v. 11 v. 2 (11.23) for Itanium ²		■
IBM AIX v. 4.1, 4.3.2 for RISC v. 4.3.3, 5.1, 5.2 for PowerPC ²		■
MacOS v. 10.2.8, 10.3.x		■
Red Hat Linux v. 7.1, 7.2, 7.3, x, 8.0, 9.0		■
Red Hat Enterprise Linux AS v. 2.1 ¹		■
SCO Unix OpenServer v. 5.0.5a, 5.0.7		■
SGI Irix (MIPS) v. 6.5.2.x		■
Sun Solaris v. 7, 8, 9 for SPARC v. 7, 8, 9 for Intel		■
SuSE Linux v. 7.2, 8.0, 8.2		■
SuSE Enterprise Linux AS v. 2.1 ¹		■
Novell NetWare		
Novell NetWare v. 5.0, 5.1, 6.0, 6.5		■

* Check www.powerware.com for most recent software updates and versions

¹ Supports 32 and 64 bit processors

² Supports 64 bit processors

May 14, 2004 /M. Maxwell