

**CHAPTER**

**54**

**Nacelles and Pylons**

CHAPTER 54  
Nacelles and Pylons

| Subject/Page    | Date        | COC | Subject/Page | Date | COC |
|-----------------|-------------|-----|--------------|------|-----|
| EFFECTIVE PAGES |             |     |              |      |     |
| 1               | Jun 15/2009 |     |              |      |     |
| 2               | BLANK       |     |              |      |     |
| 54-CONTENTS     |             |     |              |      |     |
| O 1             | Jun 15/2009 |     |              |      |     |
| 2               | BLANK       |     |              |      |     |
| 54-00-00        |             |     |              |      |     |
| 1               | Oct 10/2002 |     |              |      |     |
| 2               | Oct 10/2002 |     |              |      |     |
| 3               | Oct 10/2007 |     |              |      |     |
| 4               | BLANK       |     |              |      |     |

A = Added, R = Revised, D = Deleted, O = Overflow, C = Customer Originated Change

## 54-EFFECTIVE PAGES



## 737-600/700/800/900 AIRCRAFT MAINTENANCE MANUAL

### CHAPTER 54 Nacelles and Pylons

| <u>CH-SC-SU</u> | <u>Subject</u>                        | <u>Page</u> | <u>Effectivity</u> |
|-----------------|---------------------------------------|-------------|--------------------|
| 54-00-00        | NACELLES-PYLONS - GENERAL DESCRIPTION | 2           | HAP ALL            |

## 54-CONTENTS

D633A101-HAP

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 1  
Jun 15/2009

THIS PAGE IS INTENTIONALLY LEFT BLANK

**54-00-00**

D633A101-HAP

Page 1  
Oct 10/2002

## NACELLES-PYLONS - GENERAL DESCRIPTION

**General**

The nacelle is the fairings and the components that surround the engine. The nacelle gives an aerodynamically smooth surface to the strut and engine. The nacelle also contains these items:

- Inlet cowl
- Fan cowl
- Fan duct cowl and thrust reverser
- Primary exhaust nozzle
- Exhaust plug.

The pylon is the strut that attaches the engine to the wing. The strut also contains these items:

- Fuel lines
- Electrical lines
- Hydraulic lines
- Pneumatic ducts
- Fairings
- Fire detection/extinguish lines.

Nacelle stations and waterlines give locations on the nacelle-pylon. The scale for nacelle stations and waterlines is inches.

The station line is a horizontal dimension. It starts at station line zero.


The water line is a height dimension. You measure the water line from a horizontal reference plane below the nacelle-pylon.

EFFECTIVITY  
HAP ALL

**54-00-00**

D633A101-HAP

Page 2  
Oct 10/2002



**NACELLES-PYLONS - GENERAL DESCRIPTION**

**EFFECTIVITY**  
**HAP ALL**

**54-00-00**

D633A101-HAP

Page 3  
Oct 10/2007