

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*30	1	AUG 22/09	30-21-03- 3	0D	DEC 22/06
*30	2	AUG 22/09	30-21-03- 3	0E	DEC 22/06
*30	3	AUG 22/09	30-21-03- 3	0F	DEC 22/06
*30	4	AUG 22/09	30-21-03- 3	0G	DEC 22/06
*30	5	AUG 22/09	30-21-03- 3	0H	DEC 22/06
*30	6	AUG 22/09	30-21-03- 3	0I	DEC 22/06
30-11-00	1	DEC 22/06	30-21-03- 3	0J	DEC 22/06
30-11-02- 1	0	AUG 22/07	30-21-03- 3	1	DEC 22/07
30-11-02- 1	0A	AUG 22/07	30-21-03- 3	2	APR 22/09
30-11-02- 1	0B	DEC 22/06	30-21-03- 3	3	APR 22/09
30-11-02- 1	1	DEC 22/06	30-21-03- 3	4	APR 22/09
30-11-02- 1	2	APR 22/08	30-21-03- 3	5	APR 22/09
30-11-02- 1	3	APR 22/08	30-21-03- 3	6	APR 22/09
30-11-02- 1	4	APR 22/09	30-21-03- 3	7	APR 22/09
30-11-02- 1	5	APR 22/08	30-21-03- 3	8	APR 22/09
30-11-02- 1	6	APR 22/08	30-21-03- 3	9	APR 22/09
30-11-02- 1	7	APR 22/09	30-21-03- 3	10	APR 22/09
30-11-02- 1	8	APR 22/08	30-21-03- 3	11	APR 22/09
30-11-02- 1	9	APR 22/09	*30-21-03- 3	12	AUG 22/09
30-11-02- 1	10	APR 22/09	*30-21-03- 3	13	AUG 22/09
30-11-02- 1	11	APR 22/08	30-21-03- 3	14	APR 22/09
30-11-02- 1	12	APR 22/08	30-21-03- 3	15	APR 22/09
30-11-02- 1	13	APR 22/08	30-21-11- 1	0	DEC 22/06
30-11-02- 1	14	APR 22/08	30-21-11- 1	1	DEC 22/07
30-11-02- 1	15	APR 22/08	30-21-52- 2	0	DEC 22/06
30-11-02- 1	16	APR 22/08	30-21-52- 2	0A	DEC 22/06
30-11-02- 1	17	APR 22/08	30-21-52- 2	1	DEC 22/07
30-11-02- 1	18	APR 22/08	30-21-52- 2	2	DEC 22/07
*30-11-02- 1	19	AUG 22/09	30-21-52- 2	3	DEC 22/07
*30-11-02- 1	20	AUG 22/09	30-21-52- 2	4	DEC 22/07
*30-11-02- 1	21	AUG 22/09	30-21-52- 5	0	DEC 22/06
*30-11-02- 1	22	AUG 22/09	30-21-52- 5	0A	DEC 22/06
*30-11-02- 1	23	AUG 22/09	30-21-52- 5	1	DEC 22/07
*30-11-02- 1	24	AUG 22/09	30-21-52- 5	2	DEC 22/07
*30-11-02- 1	25	AUG 22/09	30-21-52- 5	3	DEC 22/07
30-11-51- 2	0	DEC 22/06	30-21-52- 5	4	DEC 22/07
30-11-51- 2	1	DEC 22/07	30-21-52- 5	5	DEC 22/07
30-11-51- 2	2	DEC 22/07	30-21-53- 3	0	DEC 22/06
30-11-51- 2	3	DEC 22/07	30-21-53- 3	0A	DEC 22/06
30-11-51- 2	4	APR 22/09	30-21-53- 3	1	AUG 22/08
30-11-52- 1	0	DEC 22/06	30-21-53- 3	2	DEC 22/07
30-11-52- 1	1	DEC 22/07	30-31-00	1	DEC 22/06
30-11-53- 2	0	DEC 22/06	30-31-01- 2	0	DEC 22/07
30-11-53- 2	0A	DEC 22/06	30-31-01- 2	1	DEC 22/07
30-11-53- 2	1	AUG 22/08	30-31-01- 2	2	DEC 22/07
30-11-53- 2	2	AUG 22/08	30-31-01- 2	3	DEC 22/07
30-21-00	1	DEC 22/06	30-31-01- 2	4	DEC 22/07
30-21-03- 3	0	DEC 22/06	30-31-51- 2	0	DEC 22/06
30-21-03- 3	0A	DEC 22/06	30-31-51- 2	0A	DEC 22/06
30-21-03- 3	0B	DEC 22/06	30-31-51- 2	1	DEC 22/08
30-21-03- 3	0C	DEC 22/06	30-31-51- 2	2	DEC 22/08

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

30 - LIST OF EFFECTIVE PAGES
PAGE 1

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
30-31-51- 2	3	DEC 22/08	30-41-52- 1C	0	DEC 22/07
30-32-00	1	DEC 22/06	30-41-52- 1C	1	DEC 22/07
30-32-51- 2	0	DEC 22/06	30-41-52- 1C	2	DEC 22/07
30-32-51- 2	1	DEC 22/08	30-41-52- 1C	3	DEC 22/07
30-32-51- 2	2	DEC 22/08	*30-41-52- 1C	4	AUG 22/09
30-32-53- 1	0	DEC 22/07	*30-41-52- 1C	5	AUG 22/09
30-32-53- 1	1	DEC 22/07	*30-41-52- 1C	6	AUG 22/09
30-32-53- 1	2	DEC 22/07	*30-41-52- 1C	7	AUG 22/09
30-33-00	1	DEC 22/06	30-42-00	1	DEC 22/06
30-33-51- 2	0	DEC 22/06	30-42-02- 1	0	DEC 22/06
30-33-51- 2	1	DEC 22/08	30-42-02- 1	0A	DEC 22/06
30-33-53- 1	0	DEC 22/07	30-42-02- 1	0B	DEC 22/06
30-33-53- 1	1	DEC 22/07	30-42-02- 1	0C	DEC 22/06
30-33-53- 1	2	DEC 22/07	30-42-02- 1	1	DEC 22/07
30-34-00	1	DEC 22/06	30-42-02- 1	2	APR 22/07
30-34-51- 2	0	DEC 22/06	30-42-02- 1	3	APR 22/07
30-34-51- 2	1	DEC 22/07	30-42-02- 1	4	APR 22/07
30-34-51- 2	2	DEC 22/08	30-42-02- 1	5	APR 22/07
30-34-51- 2	3	DEC 22/08	30-42-02- 1	6	APR 22/07
30-41-00	1	DEC 22/06	30-42-02- 1	7	APR 22/07
30-41-01- 2	0	DEC 22/06	30-42-02- 1	8	DEC 22/07
30-41-01- 2	1	DEC 22/07	30-42-02- 1	9	APR 22/07
30-41-01- 2	2	DEC 22/07	30-42-02- 1	10	APR 22/09
*30-41-03- 1	0	AUG 22/09	30-42-02- 1	11	APR 22/07
*30-41-03- 1	0A	AUG 22/09	30-42-51- 2	0	DEC 22/06
*30-41-03- 1	1	AUG 22/09	30-42-51- 2	0A	DEC 22/06
30-41-03- 1	2	DEC 22/06	30-42-51- 2	1	APR 22/09
30-41-03- 1	3	AUG 22/08	30-42-51- 2	2	APR 22/09
30-41-51- 1	0	DEC 22/06	30-42-51- 2	3	DEC 22/07
30-41-51- 1	1	DEC 22/07	30-42-51- 2	4	DEC 22/07
30-41-51- 1	2	DEC 22/07	30-43-00	1	DEC 22/06
*30-41-51- 1	3	AUG 22/09	30-43-01- 1	0	DEC 22/06
30-41-51- 1	4	DEC 22/07	30-43-01- 1	0A	DEC 22/06
30-41-52- 1	0	APR 22/09	30-43-01- 1	0B	DEC 22/06
*30-41-52- 1	1	AUG 22/09	30-43-01- 1	0C	AUG 22/08
*30-41-52- 1	2	AUG 22/09	30-43-01- 1	0D	DEC 22/06
*30-41-52- 1	3	AUG 22/09	30-43-01- 1	1	AUG 22/08
*30-41-52- 1	4	AUG 22/09	30-43-01- 1	2	DEC 22/07
*30-41-52- 1	5	AUG 22/09	30-43-01- 1	3	DEC 22/07
*30-41-52- 1	6	AUG 22/09	30-43-01- 1	4	DEC 22/07
*30-41-52- 1	7	AUG 22/09	30-43-01- 1	5	DEC 22/07
*30-41-52- 1	8	AUG 22/09	30-43-01- 1	6	DEC 22/07
*30-41-52- 1	9	AUG 22/09	30-43-01- 1	7	DEC 22/07
*30-41-52- 1	10	AUG 22/09	*30-43-01- 1	8	AUG 22/09
30-41-52- 1B	0	DEC 22/07	*30-43-01- 1	9	AUG 22/09
30-41-52- 1B	1	DEC 22/07	30-43-51- 2	0	DEC 22/06
30-41-52- 1B	2	DEC 22/07	30-43-51- 2	1	DEC 22/07
*30-41-52- 1B	3	AUG 22/09	30-43-51- 2	2	DEC 22/07
*30-41-52- 1B	4	AUG 22/09	30-71-00	1	DEC 22/06
*30-41-52- 1B	5	AUG 22/09	30-71-00- 4	0	DEC 22/06
*30-41-52- 1B	6	AUG 22/09	30-71-00- 4	0A	DEC 22/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

30 - LIST OF EFFECTIVE PAGES
PAGE 2

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
30-71-00- 4	1	DEC 22/08	30-71-05- 1	0	DEC 22/06
30-71-00- 4	2	APR 22/09	30-71-05- 1	1	DEC 22/06
30-71-00- 8	0	DEC 22/06	30-71-51- 1	0	DEC 22/06
30-71-00- 8	0A	DEC 22/06	30-71-51- 1	1	DEC 22/07
30-71-00- 8	1	DEC 22/07	30-71-51- 1	2	DEC 22/07
30-71-00-10	0	DEC 22/06	30-71-53- 2	0	APR 22/07
30-71-00-10	0A	DEC 22/06	30-71-53- 2	1	DEC 22/07
30-71-00-10	1	DEC 22/07	30-71-53- 2	2	APR 22/08
30-71-00-12	0	DEC 22/06	30-81-00	1	DEC 22/06
30-71-00-12	0A	DEC 22/06	30-81-01- 1	0	DEC 22/06
30-71-00-12	0B	DEC 22/06	30-81-01- 1	1	DEC 22/07
30-71-00-12	0C	DEC 22/06	30-81-01- 1	2	DEC 22/07
30-71-00-12	1	DEC 22/07	30-81-01- 2	0	DEC 22/06
30-71-00-12	2	DEC 22/07	30-81-01- 2	0A	DEC 22/06
30-71-00-12	3	DEC 22/07	30-81-01- 2	0B	DEC 22/06
30-71-00-12	4	DEC 22/07	30-81-01- 2	0C	DEC 22/06
30-71-00-12	5	APR 22/09	30-81-01- 2	1	DEC 22/07
30-71-01- 1	0	DEC 22/08	30-81-01- 2	2	DEC 22/07
30-71-01- 1	0A	DEC 22/08	30-81-01- 2	3	DEC 22/07
30-71-01- 1	0B	APR 22/07	30-81-01- 3	0	DEC 22/06
30-71-01- 1	0C	DEC 22/06	30-81-01- 3	1	DEC 22/07
30-71-01- 1	0D	APR 22/07			
30-71-01- 1	0E	DEC 22/06			
30-71-01- 1	1	DEC 22/07			
30-71-01- 1	2	DEC 22/07			
30-71-01- 1	3	DEC 22/07			
30-71-01- 1	4	DEC 22/07			
*30-71-01- 1	5	AUG 22/09			
30-71-01- 1	6	DEC 22/08			
30-71-01- 1	7	APR 22/09			
30-71-01-23	0	DEC 22/06			
30-71-01-23	0A	DEC 22/06			
30-71-01-23	0B	DEC 22/06			
30-71-01-23	0C	DEC 22/06			
30-71-01-23	0D	DEC 22/06			
30-71-01-23	0E	DEC 22/06			
30-71-01-23	1	DEC 22/07			
30-71-01-23	2	DEC 22/07			
30-71-01-23	3	DEC 22/07			
30-71-01-23	4	DEC 22/07			
30-71-01-23	5	APR 22/09			
30-71-01-23	6	APR 22/09			
30-71-01-52A	0	DEC 22/06			
30-71-01-52A	0A	DEC 22/06			
30-71-01-52A	1	DEC 22/07			
30-71-01-52A	2	DEC 22/07			
30-71-01-52A	3	DEC 22/07			
30-71-04- 1	0	AUG 22/08			
30-71-04- 1	0A	DEC 22/06			
30-71-04- 1	1	DEC 22/07			
30-71-04- 1	2	DEC 22/07			

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

30 - LIST OF EFFECTIVE PAGES
PAGE 3

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
WING THERMAL ANTI-ICING	30-11-00		
DUCT INSTL-THRM ANTI-ICE SYS WING LE	30-11-02	01	
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (WING THERMAL ANTI-ICING ONLY)	30-11-51	02	
PANEL INSTL-OVERHEAD (WING THERMAL ANTI-ICING ONLY)	30-11-53	02	
PANEL INSTL-R SIDE (WING THERMAL ANTI-ICING ONLY)	30-11-52	01	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
ENGINE INLET THERMAL ANTI-ICING	30-21-00		
DUCT AND WIRING INSTL-THRM ANTI-ICING	30-21-03	03	
INLET			
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD	30-21-11	01	
(ENGINE INLET THERMAL ANTI-ICING ONLY)			
EQUIPMENT ASSY-P36 MISC ELEC PNL L	30-21-52	05	
(ENGINE INLET THERMAL ANTI-ICING ONLY)			
EQUIPMENT ASSY-P37 MISC ELEC PNL R	30-21-52	02	
(ENGINE NOSE COWL THERMAL ANTI-ICING			
ONLY)			
PANEL INSTL- OVERHEAD (ENGINE NOSE	30-21-53	03	
COWL THERMAL ANTI-ICING ONLY)			

BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
PITOT STATIC PROBE ANTI-ICING	30-31-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (PITOT STATIC PROBE ANTI-ICING ONLY)	30-31-51	02	
PANEL INSTL-OVHD (PITOT STATIC PROBE ANTI-ICING ONLY)	30-31-01	02	
AOA PROBE HEAT	30-32-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (AOA PROBE HEAT ONLY)	30-32-51	02	
PANEL INSTL-OVHD (ANGLE OF ATTACK PROBE HEAT ONLY)	30-32-53	01	
TAT PROBE HEAT	30-33-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (TOTAL AIR TEMPERATURE PROBE HEAT ONLY)	30-33-51	02	
PANEL INSTL-OVHD (TOTAL AIR TEMPERATURE PROBE HEAT ONLY)	30-33-53	01	
ENGINE PROBE HEAT	30-34-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (ENGINE PROBE HEAT ONLY)	30-34-51	02	

767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
FLIGHT COMPARTMENT WINDOW ANTI-ICING	30-41-00		
EQUIPMENT INSTL-ELECTRONIC EQPT CTR	30-41-01	02	
E1/E2 RACK (ICE AND RAIN PROTECTION ONLY)			
MODULE INSTL-ELECTRONIC EQPT CTR E1/E2 RACK	30-41-03	01	
PANEL INSTL-OVERHEAD (FLIGHT COMPARTMENT WINDOW ANTI-ICING ONLY)	30-41-51	01	
WINDOW ASSY-NO. 1 (ICE AND RAIN PROTECTION ONLY)	30-41-52	01	
WINDOW ASSY-NO. 2 (ICE AND RAIN PROTECTION ONLY)	30-41-52	01B	
WINDOW ASSY-NO. 3 (ICE AND RAIN PROTECTION ONLY)	30-41-52	01C	
WINDSHIELD WIPER SYSTEM	30-42-00		
PANEL INSTL-OVERHEAD (WINDSHIELD WIPER SYSTEM ONLY)	30-42-51	02	
SYSTEM INSTL-WSHLD WIPER	30-42-02	01	
WINDSHIELD RAIN REPELLENT SYSTEM	30-43-00		
PANEL INSTL-OVERHEAD (WINDSHIELD RAIN REPELLENT SYSTEM ONLY)	30-43-51	02	
SYSTEM INSTL-RAIN REPELLENT (ICE AND RAIN PROTECTION ONLY) (DEACTIVATED FOR AAT)	30-43-01	01	

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
WATER AND DRAIN LINE HEATERS	30-71-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (WATER AND DRAIN LINE HEATERS ONLY)	30-71-53	02	
HEATER INSTL-POTABLE WATER SYS FILL FTG	30-71-05	01	
HEATER INSTL-SECT. 41 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-01	01	
HEATER INSTL-SECT. 43 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-01	23	
HEATER INSTL-SECT. 45 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-01	52A	
HEATER INSTL-SECT. 46 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-00	04	
HEATER INSTL-SECT. 46 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-00	08	
HEATER INSTL-SECT. 46 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-00	10	
HEATER INSTL-SECT. 46 POTABLE WATER SYS (ICE AND RAIN PROTECTION ONLY)	30-71-00	12	
SUPPORT INSTL-POTABLE WATER TANK HEATING	30-71-04	01	
THERMOSTAT INSTL-OVERWING POTABLE WATER SYS SUPPLY HOSE	30-71-51	01	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 30 — ICE AND RAIN PROTECTION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
ICE DETECTION SYSTEM	30-81-00		
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (DETECTION ONLY)	30-81-01	02	
PANEL INSTL-RT SIDE (ICE DETECTION ONLY)	30-81-01	03	
PLUG AND PROBE INSTL-ICE DETECTOR	30-81-01	01	