

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*36	1	AUG 22/09	36-11-01- 5	1	DEC 22/07
*36	2	AUG 22/09	36-11-01- 5	2	DEC 22/06
*36	3	AUG 22/09	36-11-01- 5	3	APR 22/09
36-11-00	1	DEC 22/06	36-11-01- 5	4	APR 22/09
36-11-01- 1	0	DEC 22/06	36-11-01- 5	5	APR 22/09
36-11-01- 1	0A	DEC 22/06	36-11-01- 5	6	APR 22/09
36-11-01- 1	0B	DEC 22/06	36-11-01- 5	7	APR 22/09
36-11-01- 1	0C	DEC 22/06	36-11-01- 5	8	APR 22/09
36-11-01- 1	0D	DEC 22/06	*36-11-01- 5	9	AUG 22/09
36-11-01- 1	0E	DEC 22/06	*36-11-01- 5	10	AUG 22/09
36-11-01- 1	0F	DEC 22/06	*36-11-01- 5	11	AUG 22/09
36-11-01- 1	0G	DEC 22/06	*36-11-01- 5	12	AUG 22/09
36-11-01- 1	0H	DEC 22/06	*36-11-01- 5	13	AUG 22/09
36-11-01- 1	1	DEC 22/07	*36-11-01- 5	14	AUG 22/09
36-11-01- 1	2	DEC 22/07	*36-11-01- 5	15	AUG 22/09
36-11-01- 1	3	DEC 22/07	*36-11-01- 5	16	AUG 22/09
*36-11-01- 1	4	AUG 22/09	*36-11-01- 5	17	AUG 22/09
36-11-01- 1	5	DEC 22/07	36-11-01- 6	0	DEC 22/06
36-11-01- 1	6	DEC 22/07	36-11-01- 6	1	DEC 22/06
36-11-01- 1	7	DEC 22/07	36-11-01-10	0	DEC 22/06
36-11-01- 1	8	DEC 22/07	36-11-01-10	0A	DEC 22/06
36-11-01- 1	9	DEC 22/07	36-11-01-10	0B	DEC 22/06
36-11-01- 1	10	DEC 22/07	36-11-01-10	0C	DEC 22/08
36-11-01- 1	11	DEC 22/07	36-11-01-10	0D	APR 22/08
36-11-01- 1	12	DEC 22/07	36-11-01-10	0E	DEC 22/06
36-11-01- 1	13	DEC 22/07	36-11-01-10	0F	AUG 22/08
36-11-01- 1	14	DEC 22/07	36-11-01-10	1	DEC 22/07
36-11-01- 1	15	DEC 22/07	36-11-01-10	2	DEC 22/07
36-11-01- 1	16	DEC 22/07	36-11-01-10	3	DEC 22/07
36-11-01- 1	17	DEC 22/07	36-11-01-10	4	APR 22/08
36-11-01- 1	18	DEC 22/07	36-11-01-10	5	DEC 22/07
36-11-01- 1	19	DEC 22/07	36-11-01-10	6	APR 22/09
36-11-01- 1	20	DEC 22/07	36-11-01-10	7	DEC 22/07
36-11-01- 1	21	DEC 22/07	36-11-01-10	8	DEC 22/07
36-11-01- 1	22	DEC 22/07	36-11-01-10	9	APR 22/09
36-11-01- 1	23	DEC 22/07	36-11-01-60	0	DEC 22/06
36-11-01- 1	24	DEC 22/07	36-11-01-60	0A	DEC 22/06
36-11-01- 4	0	DEC 22/06	36-11-01-60	0B	DEC 22/06
36-11-01- 4	0A	DEC 22/06	36-11-01-60	0C	DEC 22/06
36-11-01- 4	0B	DEC 22/06	36-11-01-60	1	DEC 22/07
36-11-01- 4	0C	DEC 22/06	36-11-01-60	2	DEC 22/06
36-11-01- 4	1	DEC 22/07	36-11-01-60	3	APR 22/08
36-11-01- 4	2	APR 22/07	36-11-01-60	4	DEC 22/06
*36-11-01- 4	3	AUG 22/09	36-11-01-60	5	DEC 22/06
*36-11-01- 4	4	AUG 22/09	36-11-01-60	6	AUG 22/07
*36-11-01- 4	5	AUG 22/09	36-11-01-60	7	DEC 22/07
*36-11-01- 4	6	AUG 22/09	36-11-01-60	8	DEC 22/07
*36-11-01- 4	7	AUG 22/09	*36-11-01-60	9	AUG 22/09
36-11-01- 5	0	DEC 22/06	*36-11-01-60	10	AUG 22/09
36-11-01- 5	0A	DEC 22/06	*36-11-01-60	11	AUG 22/09
36-11-01- 5	0B	DEC 22/06	*36-11-01-60	12	AUG 22/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

36 - LIST OF EFFECTIVE PAGES
PAGE 1

767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*36-11-01-60	13	AUG 22/09	36-11-02- 1	0	DEC 22/06
36-11-01-66	0	DEC 22/06	36-11-02- 1	1	DEC 22/06
36-11-01-66	0A	DEC 22/06	36-11-03- 1	0	DEC 22/06
36-11-01-66	0B	DEC 22/06	36-11-03- 1	0A	DEC 22/06
36-11-01-66	0C	DEC 22/06	36-11-03- 1	0B	DEC 22/06
36-11-01-66	0D	DEC 22/06	36-11-03- 1	0C	DEC 22/06
*36-11-01-66	1	AUG 22/09	36-11-03- 1	1	DEC 22/08
*36-11-01-66	2	AUG 22/09	36-11-03- 1	2	DEC 22/07
*36-11-01-66	3	AUG 22/09	36-11-03- 1	3	DEC 22/07
36-11-01-66	4	APR 22/09	36-11-04- 1	0	DEC 22/06
36-11-01-66	5	APR 22/09	36-11-04- 1	1	DEC 22/07
36-11-01-66	6	DEC 22/08	36-11-04- 1	2	DEC 22/06
36-11-01-66	7	DEC 22/07	36-11-04- 1	3	DEC 22/07
36-11-01-66	8	DEC 22/07	*36-11-04- 1	4	AUG 22/09
36-11-01-66	9	DEC 22/07	36-11-04- 1	5	DEC 22/06
36-11-01-66	10	APR 22/08	36-11-04- 1	6	DEC 22/06
36-11-01-66	11	DEC 22/07	36-11-04- 1	7	DEC 22/06
36-11-01-80	0	DEC 22/06	36-11-04- 1	8	DEC 22/06
36-11-01-80	0A	DEC 22/06	36-11-05- 1	0	APR 22/07
36-11-01-80	0B	DEC 22/06	36-11-05- 1	1	DEC 22/07
36-11-01-80	1	DEC 22/07	36-11-05- 1	2	DEC 22/07
36-11-01-80	2	AUG 22/08	36-11-08- 6	0	DEC 22/06
36-11-01-80	3	DEC 22/07	36-11-08- 6	0A	DEC 22/06
36-11-01-80	4	DEC 22/07	36-11-08- 6	0B	DEC 22/06
36-11-01-80	5	DEC 22/07	36-11-08- 6	0C	DEC 22/06
36-11-01-80	6	DEC 22/07	36-11-08- 6	0D	DEC 22/06
36-11-01-80	7	DEC 22/07	36-11-08- 6	0E	DEC 22/06
36-11-01-80A	0	DEC 22/06	36-11-08- 6	1	DEC 22/08
36-11-01-80A	0A	DEC 22/06	36-11-08- 6	2	DEC 22/07
36-11-01-80A	1	DEC 22/07	36-11-08- 6	3	DEC 22/07
*36-11-01-80A	2	AUG 22/09	36-11-08- 6	4	DEC 22/08
*36-11-01-80A	3	AUG 22/09	36-11-08- 6	5	DEC 22/08
*36-11-01-80A	4	AUG 22/09	36-11-08- 6	6	DEC 22/08
36-11-01-80A	5	APR 22/08	*36-11-08- 6	7	AUG 22/09
36-11-01-80A	6	APR 22/08	*36-11-08- 6	8	AUG 22/09
36-11-01-94	0	DEC 22/06	*36-11-08- 6	9	AUG 22/09
36-11-01-94	1	DEC 22/07	*36-11-08- 6	10	AUG 22/09
36-11-01-95	0	DEC 22/08	*36-11-08- 6	11	AUG 22/09
36-11-01-95	0A	DEC 22/06	*36-11-08- 6	12	AUG 22/09
36-11-01-95	0B	DEC 22/06	*36-11-08- 6	13	AUG 22/09
36-11-01-95	1	DEC 22/07	*36-11-08- 6	14	AUG 22/09
36-11-01-95	2	DEC 22/07	*36-11-08- 6	15	AUG 22/09
36-11-01-95	3	DEC 22/06	*36-11-08- 6	16	AUG 22/09
*36-11-01-95	4	AUG 22/09	*36-11-08- 6	17	AUG 22/09
*36-11-01-95	5	AUG 22/09	*36-11-08- 6	18	AUG 22/09
*36-11-01-95	6	AUG 22/09	*36-11-08- 6	19	AUG 22/09
*36-11-01-95	7	AUG 22/09	*36-11-08- 6	20	AUG 22/09
*36-11-01-95	8	AUG 22/09	*36-11-08- 6	21	AUG 22/09
*36-11-01-95	9	AUG 22/09	*36-11-08- 6	22	AUG 22/09
*36-11-01-95	10	AUG 22/09	*36-11-08- 6	23	AUG 22/09
*36-11-01-95	11	AUG 22/09	36-11-12- 1	0	DEC 22/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

36 - LIST OF EFFECTIVE PAGES
PAGE 2


BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
36-11-12- 1	0A	DEC 22/06	36-11-55- 5	2	DEC 22/07
36-11-12- 1	1	DEC 22/07	36-11-56- 1	0	DEC 22/06
36-11-12- 1	2	DEC 22/07	36-11-56- 1	1	APR 22/09
36-11-12- 1	3	DEC 22/07	36-11-56- 1	2	APR 22/09
36-11-15- 2	0	DEC 22/06	36-11-56- 1	3	APR 22/09
36-11-15- 2	1	APR 22/07	*36-11-56- 1	4	AUG 22/09
36-11-15- 2	2	APR 22/07	*36-11-56- 1	5	AUG 22/09
36-11-15- 2	3	APR 22/09	*36-11-56- 1	6	AUG 22/09
36-11-15- 2	4	APR 22/09	*36-11-56- 1	7	AUG 22/09
36-11-15- 2	5	APR 22/09	*36-11-56- 1	8	AUG 22/09
36-11-50- 1	0	DEC 22/06	*36-11-56- 1	9	AUG 22/09
36-11-50- 1	0A	DEC 22/06	*36-11-56- 1	10	AUG 22/09
36-11-50- 1	0B	DEC 22/06	*36-11-56- 1	11	AUG 22/09
36-11-50- 1	0C	DEC 22/06	*36-11-56- 1	12	AUG 22/09
36-11-50- 1	1	DEC 22/07	*36-11-56- 1	13	AUG 22/09
36-11-50- 1	2	DEC 22/07	*36-11-56- 1	14	AUG 22/09
36-11-50- 1	3	DEC 22/07	*36-11-56- 1	15	AUG 22/09
36-11-50- 1	4	DEC 22/08	*36-11-56- 1	16	AUG 22/09
36-11-50- 1	5	DEC 22/07	*36-11-56- 1	17	AUG 22/09
36-11-50- 1	6	DEC 22/07	*36-11-56- 1	18	AUG 22/09
36-11-50- 4	0	DEC 22/06	36-11-70- 1	0	APR 22/09
*36-11-50- 4	1	AUG 22/09	36-11-70- 1	0A	DEC 22/06
*36-11-50- 4	2	AUG 22/09	36-11-70- 1	0B	DEC 22/06
36-11-51- 1	0	DEC 22/06	36-11-70- 1	1	DEC 22/07
36-11-51- 1	1	DEC 22/07	36-12-00	1	DEC 22/06
36-11-51- 1	2	DEC 22/06	36-12-02- 2	0	DEC 22/06
36-11-51- 1	3	DEC 22/06	36-12-02- 2	0A	DEC 22/06
*36-11-53- 2	0	AUG 22/09	36-12-02- 2	0B	DEC 22/06
36-11-53- 2	0A	DEC 22/06	*36-12-02- 2	1	AUG 22/09
36-11-53- 2	0B	DEC 22/06	36-12-02- 2	2	DEC 22/06
*36-11-53- 2	0C	AUG 22/09	36-12-02- 2	3	DEC 22/06
*36-11-53- 2	0D	AUG 22/09	36-12-02- 2	4	DEC 22/07
36-11-53- 2	1	DEC 22/07	36-12-02- 2	5	DEC 22/07
36-11-53- 2	2	DEC 22/07	36-12-02- 2	6	DEC 22/07
36-11-53- 2	3	DEC 22/07	36-12-02- 2	7	DEC 22/07
36-11-53- 2	4	DEC 22/07	36-12-02- 2	8	DEC 22/07
36-11-53- 2	5	DEC 22/07	36-12-02- 2	9	DEC 22/07
*36-11-53- 6	0	AUG 22/09	36-12-02- 2	10	DEC 22/07
36-11-53- 6	0A	DEC 22/06	36-21-00	1	DEC 22/06
36-11-53- 6	0B	DEC 22/06	36-21-01- 1	0	DEC 22/06
*36-11-53- 6	0C	AUG 22/09	36-21-01- 1	0A	DEC 22/06
*36-11-53- 6	0D	AUG 22/09	36-21-01- 1	0B	DEC 22/06
36-11-53- 6	1	DEC 22/07	36-21-01- 1	0C	DEC 22/06
36-11-53- 6	2	DEC 22/07	36-21-01- 1	1	DEC 22/07
36-11-53- 6	3	DEC 22/07	36-21-01- 1	2	DEC 22/07
36-11-53- 6	4	DEC 22/07	36-21-01- 1	3	DEC 22/07
36-11-53- 6	5	DEC 22/07	36-21-01- 1	4	DEC 22/07
36-11-53- 6	6	DEC 22/07	36-21-08- 1	0	DEC 22/06
36-11-53- 6	7	DEC 22/07	36-21-08- 1	1	DEC 22/07
36-11-55- 5	0	DEC 22/06	36-21-51- 1	0	DEC 22/07
36-11-55- 5	1	DEC 22/07	*36-21-51- 1	1	AUG 22/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

36 - LIST OF EFFECTIVE PAGES
PAGE 3



* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

36 - LIST OF EFFECTIVE PAGES
PAGE 4

767
PARTS CATALOG (MAINTENANCE)

CHAPTER 36 — PNEUMATIC

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
AIR SUPPLY DISTRIBUTION SYSTEM	36-11-00		
CARD FILE AND BOX INSTL-R FWD EQPT CTR (P50) (PNEUMATIC ONLY)	36-11-12	01	
CONTROLLER AND WIRING INSTL-PW4000 ENVIRONMENTAL CONT SYS (DISTRIBUTION ONLY)	36-11-08	06	
DUCT AND SHROUD INSTL-SECT. 48 AIR SUPPLY SYS	36-11-01	80	
DUCT AND WIRING INSTL-STRUT PNEU	36-11-01	01	
DUCT INSTL-AIR SUPPLY SYS AIR DRIVEN PUMP INLET	36-11-01	60	
DUCT INSTL-APU AIR SUPPLY SYS, AFT AND BULK CARGO HEAT 767-300	36-11-01	66	
DUCT INSTL-BODY CROSSOVER AIR SUPPLY SYS (DUCTS ONLY)	36-11-01	10	
DUCT INSTL-BODY CROSSOVER AIR SUPPLY SYSTEM (GROUND AIR CONNECTOR ONLY)	36-11-03	01	
DUCT INSTL-BODY CROSSOVER AIR SUPPLY SYSTEM (ISOLATION BYPASS CHECK VALVES ONLY)	36-11-05	01	
DUCT INSTL-BODY CROSSOVER AIR SUPPLY SYSTEM (ISOLATION VALVE ONLY)	36-11-04	01	
DUCT INSTL-COOLING AIR INLET INTERFACE	36-11-01	94	
DUCT INSTL-ENG START SYS INTERCONNECT BLEED	36-11-01	06	
DUCT INSTL-PNEU BLEED SYS	36-11-01	05	
DUCT INSTL-SECT. 45 APU AIR SUPPLY SYS	36-11-01	95	
DUCT INSTL-WING LE AIR SUPPLY	36-11-01	04	
END ITEM INSTL-STA 1809.5 HORIZ STAB. PIVOT CTR BHD (PNEUMATIC ONLY) (LH)	36-11-01	80A	
EQUIPMENT ASSY-AFT EQPT CTR E6 RACK P49 (PNEUMATIC ONLY)	36-11-55	05	
EQUIPMENT ASSY-P33 MISC ELEC PNL FWD (PNEUMATIC ONLY)	36-11-51	01	
EQUIPMENT ASSY-P36 MISC ELEC PNL L (PNEUMATIC ONLY)	36-11-53	02	
EQUIPMENT ASSY-P37 MISC ELC PNL R (PNEUMATIC ONLY)	36-11-53	06	
INSULATION INSTL-APU DUCT AIR SUPPLY SYS	36-11-02	01	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 36 — PNEUMATIC

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
PANEL INSTL-OVHD (AIR SUPPLY DISTRIBUTION SYSTEM ONLY)	36-11-56	01	
PRECOOLER INSTL-ENG BLEED AIR SYS	36-11-15	02	
PROVISION INSTL-SECT. 41 DIODES UPR WIRE (PNEUMATIC ONLY)	36-11-70	01	
SENSING, PLUG AND WIRING INSTL-WING LE CF6-80C2 AND PW4000 ENGINES (PNEUMATIC DISTRIBUTION ONLY)	36-11-50	01	
WIRING INSTL-ELECTRICAL STRUT (DISTRIBUTION ONLY)	36-11-50	04	
BLEED AIR PRECOOLER SYSTEM	36-12-00		
TUBING AND FAN VALVE INST ECS CONT	36-12-02	02	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 36 — PNEUMATIC

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
AIR SUPPLY PRESSURE INDICATING SYSTEM	36-21-00		
DUCT INSTL-BODY CROSSOVER AIR SUPPLY SYSTEM (DUCT PRESSURE TRANSDUCER ONLY)	36-21-01	01	
PANEL INSTL-OVHD (AIR SUPPLY PRESSURE INDICATING SYSTEM ONLY)	36-21-51	01	
SENSING INSTL-WING LEADING EDGE CF6-80C2 AND PW4000 ENGINES (PNEUMATIC INDICATING ONLY)	36-21-08	01	
AIR SUPPLY TEMPERATURE INDICATING SYSTEM	36-22-00		
WIRING INSTL-ELECTRICAL STRUT (AIR SUPPLY TEMPERATURE INDICATING SYSTEM ONLY)	36-22-50	04	
AIR SUPPLY BITE SYSTEM	36-23-00		
EQUIPMENT INST-ELECT. EQPT CTR E3 RACK (PNEUMATIC ONLY)	36-23-01	01	
WIRING INSTL-ELECTRICAL STRUT (AIR SUPPLY BITE SYSTEM ONLY)	36-23-50	03	