

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*55	1	AUG 22/09	55-12-00	1	DEC 22/06
*55	2	AUG 22/09	55-12-51- 1	0	DEC 22/06
*55	3	AUG 22/09	55-12-51- 1	0A	DEC 22/06
*55	4	AUG 22/09	55-12-51- 1	0B	DEC 22/06
*55	5	AUG 22/09	55-12-51- 1	1	DEC 22/08
*55	6	AUG 22/09	55-12-51- 1	2	APR 22/08
55-00-00	1	DEC 22/06	55-12-51- 1	3	DEC 22/08
55-00-01- 1	0	DEC 22/06	55-12-51- 1	4	DEC 22/08
55-00-01- 1	1	DEC 22/07	55-12-51- 1	5	APR 22/08
55-10-00	1	DEC 22/06	55-12-51- 1	6	APR 22/08
55-10-01- 1	0	DEC 22/06	55-12-52- 1	0	DEC 22/06
55-10-01- 1	1	DEC 22/07	55-12-52- 1	0A	DEC 22/06
55-10-01- 1	2	DEC 22/07	55-12-52- 1	1	DEC 22/06
55-10-01- 5	0	DEC 22/06	55-12-53- 1	0	DEC 22/06
*55-10-01- 5	1	AUG 22/09	*55-12-53- 1	1	AUG 22/09
55-10-01- 5	2	DEC 22/06	55-13-00	1	DEC 22/06
55-10-01-10	0	DEC 22/06	55-13-51- 1	0	DEC 22/06
*55-10-01-10	1	AUG 22/09	55-13-51- 1	1	DEC 22/06
*55-10-01-10	2	AUG 22/09	55-13-51- 5	0	DEC 22/06
*55-10-01-10	3	AUG 22/09	55-13-51- 5	1	DEC 22/06
55-10-02- 2	0	DEC 22/06	55-13-51- 5	2	DEC 22/06
55-10-02- 2	0A	DEC 22/06	55-13-52- 1	0	DEC 22/06
55-10-02- 2	0B	DEC 22/06	55-13-52- 1	0A	DEC 22/06
55-10-02- 2	1	DEC 22/06	55-13-52- 1	1	APR 22/08
55-10-02- 2	2	DEC 22/06	55-13-52- 1	2	APR 22/08
55-10-02- 2	3	DEC 22/06	55-13-53- 1	0	DEC 22/06
55-10-02- 2	4	DEC 22/06	55-13-53- 1	1	DEC 22/06
55-10-02- 2	5	DEC 22/06	55-13-53- 1	2	DEC 22/06
*55-10-02- 2	6	AUG 22/09	55-13-53- 1	3	DEC 22/06
55-10-02- 2	7	DEC 22/07	55-13-54- 1	0	DEC 22/06
55-10-02- 2	8	DEC 22/07	55-13-54- 1	0A	DEC 22/06
55-10-02- 2	9	DEC 22/07	55-13-54- 1	0B	DEC 22/06
55-10-02- 2	10	APR 22/09	55-13-54- 1	1	DEC 22/06
55-10-02- 2	11	DEC 22/07	55-13-54- 1	2	APR 22/08
55-10-02- 2	12	DEC 22/07	55-13-54- 1	3	APR 22/08
*55-10-02- 2	13	AUG 22/09	55-13-54- 1	4	APR 22/08
55-10-51- 1	0	DEC 22/06	55-13-55- 1	0	DEC 22/06
55-10-51- 1	1	DEC 22/06	55-13-55- 1	1	DEC 22/06
55-10-52- 1	0	DEC 22/06	55-14-00	1	DEC 22/06
55-10-52- 1	0A	DEC 22/06	55-14-51- 1	0	DEC 22/06
55-10-52- 1	1	DEC 22/07	55-14-51- 1	1	DEC 22/06
55-10-52- 1	2	DEC 22/06	55-16-00	1	DEC 22/06
55-10-52- 1	3	APR 22/08	55-16-51- 1	0	DEC 22/06
55-10-52- 1	4	APR 22/08	55-16-51- 1	0A	DEC 22/06
55-10-52- 1	5	APR 22/08	55-16-51- 1	1	DEC 22/06
55-10-52- 1	6	APR 22/08	55-16-51- 1	2	DEC 22/06
55-11-00	1	DEC 22/06	55-16-51- 1	3	APR 22/09
55-11-01- 1	0	DEC 22/06	55-16-51- 1	4	APR 22/09
*55-11-01- 1	1	AUG 22/09	55-16-51- 1	5	APR 22/09
55-11-01- 1	2	APR 22/09	55-16-52- 1	0	DEC 22/06
55-11-01- 1	3	APR 22/09	55-16-52- 1	0A	DEC 22/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

55 - LIST OF EFFECTIVE PAGES
PAGE 1

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
55-16-52- 1	0B	DEC 22/06	55-16-56- 4	0A	DEC 22/06
55-16-52- 1	0C	DEC 22/06	55-16-56- 4	1	DEC 22/06
55-16-52- 1	0D	DEC 22/06	*55-16-56- 4	2	AUG 22/09
55-16-52- 1	0E	DEC 22/06	*55-16-56- 4	3	AUG 22/09
55-16-52- 1	1	DEC 22/06	*55-16-56- 4	4	AUG 22/09
55-16-52- 1	2	DEC 22/06	*55-16-56- 4	5	AUG 22/09
55-16-52- 1	3	DEC 22/06	55-16-56- 5	0	DEC 22/06
55-16-52- 1	4	DEC 22/06	55-16-56- 5	0A	DEC 22/06
55-16-52- 1	5	DEC 22/06	55-16-56- 5	1	DEC 22/06
55-16-52- 1	6	DEC 22/06	*55-16-56- 5	2	AUG 22/09
55-16-53- 1	0	DEC 22/06	*55-16-56- 5	3	AUG 22/09
55-16-53- 1	0A	DEC 22/06	*55-16-56- 5	4	AUG 22/09
55-16-53- 1	1	DEC 22/06	55-16-57- 1	0	DEC 22/06
55-16-53- 1	2	DEC 22/06	55-16-57- 1	0A	DEC 22/06
55-16-53- 1	3	DEC 22/06	55-16-57- 1	0B	DEC 22/06
55-16-54- 1	0	DEC 22/06	55-16-57- 1	1	DEC 22/06
55-16-54- 1	0A	DEC 22/06	55-16-57- 1	2	DEC 22/06
55-16-54- 1	1	DEC 22/06	55-16-57- 1	3	DEC 22/06
55-16-54- 1	2	DEC 22/06	55-16-57- 1	4	DEC 22/06
55-16-54- 1	3	DEC 22/06	55-16-57- 1	5	DEC 22/08
55-16-54- 1	4	DEC 22/06	55-16-57- 1	6	DEC 22/08
55-16-55- 1	0	DEC 22/06	55-16-57- 1	7	DEC 22/08
55-16-55- 1	1	DEC 22/06	55-16-58- 1	0	DEC 22/06
55-16-56- 1	0	DEC 22/06	55-16-58- 1	1	DEC 22/06
55-16-56- 1	0A	DEC 22/06	55-16-58- 1	2	DEC 22/06
55-16-56- 1	0B	DEC 22/06	55-16-58- 1	3	DEC 22/06
55-16-56- 1	1	DEC 22/06	55-16-58- 1	4	DEC 22/06
*55-16-56- 1	2	AUG 22/09	55-16-58- 1	5	DEC 22/06
*55-16-56- 1	3	AUG 22/09	55-16-58- 1	6	DEC 22/06
*55-16-56- 1	4	AUG 22/09	55-16-58- 1	7	DEC 22/07
*55-16-56- 1	5	AUG 22/09	55-16-58- 1	8	DEC 22/06
*55-16-56- 1	6	AUG 22/09	55-16-59- 1	0	DEC 22/06
*55-16-56- 1	7	AUG 22/09	55-16-59- 1	0A	DEC 22/06
*55-16-56- 1	8	AUG 22/09	*55-16-59- 1	1	AUG 22/09
*55-16-56- 1	9	AUG 22/09	*55-16-59- 1	2	AUG 22/09
*55-16-56- 1	10	AUG 22/09	55-17-00	1	DEC 22/06
55-16-56- 2	0	DEC 22/06	55-17-51- 1	0	DEC 22/06
55-16-56- 2	0A	DEC 22/06	55-17-51- 1	1	APR 22/09
55-16-56- 2	1	DEC 22/06	*55-17-51- 1	2	AUG 22/09
*55-16-56- 2	2	AUG 22/09	*55-17-51- 1	3	AUG 22/09
*55-16-56- 2	3	AUG 22/09	*55-17-51- 1	4	AUG 22/09
*55-16-56- 2	4	AUG 22/09	*55-17-51- 1	5	AUG 22/09
55-16-56- 3	0	DEC 22/06	*55-17-51- 1	6	AUG 22/09
55-16-56- 3	0A	DEC 22/06	55-20-00	1	DEC 22/06
55-16-56- 3	1	DEC 22/06	55-20-51- 1	0	DEC 22/06
*55-16-56- 3	2	AUG 22/09	55-20-51- 1	0A	DEC 22/06
*55-16-56- 3	3	AUG 22/09	55-20-51- 1	0B	DEC 22/06
*55-16-56- 3	4	AUG 22/09	55-20-51- 1	0C	APR 22/09
*55-16-56- 3	5	AUG 22/09	55-20-51- 1	0D	DEC 22/06
*55-16-56- 3	6	AUG 22/09	55-20-51- 1	0E	DEC 22/06
55-16-56- 4	0	DEC 22/06	55-20-51- 1	0F	DEC 22/06

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

55 - LIST OF EFFECTIVE PAGES
PAGE 2

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
55-20-51- 1	0G	DEC 22/06	55-30-51- 2	0A	DEC 22/06
55-20-51- 1	0H	DEC 22/06	55-30-51- 2	1	DEC 22/06
55-20-51- 1	0I	DEC 22/06	55-30-51- 2	2	APR 22/08
55-20-51- 1	1	DEC 22/06	55-30-51- 2	3	DEC 22/06
55-20-51- 1	2	AUG 22/08	*55-30-51- 2	4	AUG 22/09
55-20-51- 1	3	DEC 22/06	55-30-51- 2	5	DEC 22/06
*55-20-51- 1	4	AUG 22/09	55-30-51- 2	6	DEC 22/06
55-20-51- 1	5	DEC 22/07	55-30-51- 3	0	DEC 22/06
55-20-51- 1	6	DEC 22/07	55-30-51- 3	1	DEC 22/06
*55-20-51- 1	7	AUG 22/09	55-30-51- 3	2	DEC 22/06
*55-20-51- 1	8	AUG 22/09	55-30-51- 4	0	DEC 22/06
*55-20-51- 1	9	AUG 22/09	55-30-51- 4	0A	DEC 22/06
55-20-51- 1	10	DEC 22/06	55-30-51- 4	0B	DEC 22/06
55-20-51- 1	11	DEC 22/06	55-30-51- 4	0C	DEC 22/06
55-20-51- 1	12	DEC 22/06	55-30-51- 4	1	DEC 22/06
55-20-51- 1	13	DEC 22/06	55-30-51- 4	2	APR 22/09
55-20-51- 1	14	DEC 22/06	55-30-51- 4	3	DEC 22/06
55-20-51- 1	15	APR 22/08	*55-30-51- 4	4	AUG 22/09
55-20-51- 1	16	APR 22/08	55-30-51- 4	5	DEC 22/06
55-20-51- 1	17	DEC 22/06	55-30-51- 4	6	DEC 22/06
55-20-51- 1	18	DEC 22/07	55-30-51- 4	7	DEC 22/06
55-20-51- 1	19	DEC 22/06	55-30-51- 4	8	DEC 22/06
55-20-51- 1	20	DEC 22/06	55-30-51- 4	9	DEC 22/06
55-20-51- 1	21	DEC 22/06	55-30-51- 5	0	DEC 22/06
55-20-51- 1	22	DEC 22/06	55-30-51- 5	0A	DEC 22/06
55-20-51- 1	23	DEC 22/06	55-30-51- 5	0B	DEC 22/06
55-20-51- 1	24	DEC 22/06	55-30-51- 5	1	APR 22/09
55-20-51- 1	25	DEC 22/06	55-30-51- 5	2	APR 22/09
55-20-51- 1	26	AUG 22/08	*55-30-51- 5	3	AUG 22/09
55-20-51- 1	27	AUG 22/08	55-30-51- 5	4	APR 22/09
55-20-51- 1	28	DEC 22/06	55-30-51- 5	5	APR 22/09
55-20-51- 1	29	DEC 22/06	55-30-51- 5	6	APR 22/09
55-20-51- 1	30	DEC 22/06	*55-30-51- 5	7	AUG 22/09
55-20-51- 1	31	DEC 22/06	55-30-51- 5	8	APR 22/09
55-20-51- 1	32	DEC 22/06	55-30-51- 5	9	APR 22/09
55-20-51- 1	33	DEC 22/06	55-30-51- 5	10	APR 22/09
55-20-51- 1	34	DEC 22/06	*55-30-51- 5	11	AUG 22/09
55-23-00	1	DEC 22/06	*55-30-51- 5	12	AUG 22/09
55-23-52- 1	0	APR 22/08	*55-30-51- 5	13	AUG 22/09
55-23-52- 1	1	DEC 22/06	*55-30-51- 5	14	AUG 22/09
55-23-52- 1	2	DEC 22/06	*55-30-51- 5	15	AUG 22/09
55-23-52- 1	3	DEC 22/06	*55-30-51- 5	16	AUG 22/09
55-30-00	1	DEC 22/06	*55-30-51- 5	17	AUG 22/09
55-30-50- 1	0	DEC 22/06	*55-30-51- 5	18	AUG 22/09
55-30-50- 1	0A	DEC 22/06	55-30-51- 6	0	DEC 22/06
55-30-50- 1	1	DEC 22/07	55-30-51- 6	0A	DEC 22/06
55-30-50- 1	2	DEC 22/07	*55-30-51- 6	1	AUG 22/09
55-30-50- 1	3	DEC 22/07	*55-30-51- 6	2	AUG 22/09
55-30-51- 1	0	DEC 22/06	*55-30-51- 6	3	AUG 22/09
55-30-51- 1	1	DEC 22/06	*55-30-51- 6	4	AUG 22/09
55-30-51- 2	0	DEC 22/06	*55-30-51- 6	5	AUG 22/09

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

55 - LIST OF EFFECTIVE PAGES
PAGE 3

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*55-30-51- 6	6	AUG 22/09	55-34-51- 1	6	DEC 22/06
55-30-51- 7	0	DEC 22/06	55-34-51- 1	7	DEC 22/06
55-30-51- 7	0A	DEC 22/06	55-35-00	1	DEC 22/06
55-30-51- 7	1	APR 22/09	55-35-01- 1	0	DEC 22/06
55-30-51- 7	2	APR 22/09	55-35-01- 1	0A	DEC 22/06
55-30-51- 7	3	APR 22/09	55-35-01- 1	1	DEC 22/07
55-30-51- 7	4	APR 22/09	55-35-01- 1	2	APR 22/09
55-30-51- 7	5	APR 22/09	55-35-01- 1	3	APR 22/09
55-30-52- 1	0	DEC 22/06	55-35-01- 2	0	DEC 22/06
55-30-52- 1	1	DEC 22/06	55-35-01- 2	0A	DEC 22/06
55-30-52- 1	2	DEC 22/06	55-35-01- 2	1	DEC 22/07
55-31-00	1	DEC 22/06	55-35-01- 2	2	DEC 22/06
55-31-01- 1	0	DEC 22/06	55-36-00	1	DEC 22/06
55-31-01- 1	0A	DEC 22/06	55-36-51- 1	0	DEC 22/06
55-31-01- 1	0B	DEC 22/06	55-36-51- 1	0A	DEC 22/06
55-31-01- 1	0C	DEC 22/06	55-36-51- 1	1	APR 22/08
55-31-01- 1	1	DEC 22/06	55-36-51- 1	2	APR 22/08
*55-31-01- 1	2	AUG 22/09	55-36-51- 1	3	APR 22/08
55-31-01- 1	3	DEC 22/06	55-36-51- 1	4	APR 22/08
55-31-01- 1	4	DEC 22/06	55-36-51- 1	5	APR 22/08
55-31-02- 1	0	DEC 22/06	55-36-52- 1	0	DEC 22/06
*55-31-02- 1	1	AUG 22/09	55-36-52- 1	0A	DEC 22/06
*55-31-02- 1	2	AUG 22/09	55-36-52- 1	0B	DEC 22/06
55-31-51- 1	0	DEC 22/06	55-36-52- 1	1	DEC 22/07
55-31-51- 1	1	DEC 22/06	55-36-52- 1	2	DEC 22/07
55-33-00	1	DEC 22/06	*55-36-52- 1	3	AUG 22/09
55-33-52- 1	0	DEC 22/06	*55-36-52- 1	4	AUG 22/09
55-33-52- 1	1	DEC 22/06	*55-36-52- 1	5	AUG 22/09
55-33-52- 1	2	DEC 22/06	*55-36-52- 1	6	AUG 22/09
55-33-52- 5	0	DEC 22/06	*55-36-52- 1	7	AUG 22/09
55-33-52- 5	1	DEC 22/06	55-36-53- 1	0	DEC 22/06
55-33-52- 5	2	DEC 22/06	55-36-53- 1	0A	DEC 22/06
55-34-00	1	DEC 22/06	55-36-53- 1	0B	DEC 22/06
55-34-01- 1	0	DEC 22/06	55-36-53- 1	1	DEC 22/06
55-34-01- 1	0A	DEC 22/06	55-36-53- 1	2	DEC 22/06
55-34-01- 1	0B	DEC 22/06	55-36-53- 1	3	DEC 22/06
55-34-01- 1	0C	DEC 22/06	55-36-53- 1	4	DEC 22/06
55-34-01- 1	1	DEC 22/06	55-36-53- 1	5	DEC 22/06
55-34-01- 1	2	DEC 22/06	55-36-55- 1	0	DEC 22/06
55-34-01- 1	3	DEC 22/06	55-36-55- 1	0A	DEC 22/06
55-34-01- 1	4	DEC 22/06	55-36-55- 1	1	DEC 22/06
55-34-01- 1	5	DEC 22/06	55-36-55- 1	2	DEC 22/06
55-34-01- 1	6	DEC 22/06	55-36-55- 1	3	APR 22/08
55-34-51- 1	0	DEC 22/06	55-36-55- 1	4	APR 22/08
55-34-51- 1	0A	DEC 22/06	55-36-55- 1	5	APR 22/08
55-34-51- 1	0B	DEC 22/06	55-36-55- 1	6	APR 22/08
55-34-51- 1	1	DEC 22/06	55-40-00	1	DEC 22/06
55-34-51- 1	2	DEC 22/06	55-40-51- 1	0	DEC 22/06
55-34-51- 1	3	DEC 22/06	55-40-51- 1	0A	DEC 22/06
55-34-51- 1	4	DEC 22/06	55-40-51- 1	1	DEC 22/06
55-34-51- 1	5	DEC 22/06	55-40-51- 1	2	DEC 22/07

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

55 - LIST OF EFFECTIVE PAGES
PAGE 4

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
55-40-55- 1	0	DEC 22/06	55-40-55- 1	26	APR 22/08
55-40-55- 1	0A	DEC 22/06	55-40-55- 1	27	APR 22/08
55-40-55- 1	0B	DEC 22/06	55-40-55- 1	28	APR 22/08
55-40-55- 1	0C	DEC 22/06	55-40-55- 1	29	APR 22/08
55-40-55- 1	0D	DEC 22/06	55-40-55- 1	30	APR 22/08
55-40-55- 1	0E	DEC 22/06	55-40-55- 1	31	APR 22/08
55-40-55- 1	0F	DEC 22/06	55-40-55- 1	32	APR 22/08
55-40-55- 1	0G	DEC 22/06	55-40-55- 1	33	APR 22/08
55-40-55- 1	0H	DEC 22/06	55-40-55- 1	34	APR 22/08
55-40-55- 1	0I	DEC 22/06	55-40-55- 1	35	APR 22/08
55-40-55- 1	0J	DEC 22/06	55-40-55- 1	36	APR 22/08
55-40-55- 1	0K	DEC 22/06	55-40-55- 1	37	APR 22/08
55-40-55- 1	0L	DEC 22/06	55-40-55- 1	38	APR 22/08
55-40-55- 1	0M	DEC 22/06	55-40-55- 1	39	APR 22/08
55-40-55- 1	0N	DEC 22/06	55-40-55- 1	40	APR 22/08
55-40-55- 1	0O	DEC 22/06	55-40-55- 1	41	APR 22/08
55-40-55- 1	0P	DEC 22/06	55-40-55- 1	42	APR 22/08
55-40-55- 1	0Q	DEC 22/06	55-40-55- 1	43	APR 22/08
55-40-55- 1	0R	DEC 22/06	55-40-55- 1	44	APR 22/08
55-40-55- 1	0S	DEC 22/06	55-40-55- 1	45	APR 22/08
55-40-55- 1	0T	DEC 22/06	55-40-55- 1	46	APR 22/08
55-40-55- 1	0U	DEC 22/06	55-40-55- 1	47	APR 22/08
55-40-55- 1	0V	DEC 22/06	55-40-55- 1	48	APR 22/08
55-40-55- 1	0W	DEC 22/06	55-40-55- 1	49	APR 22/08
55-40-55- 1	0X	DEC 22/06	55-40-55- 1	50	APR 22/08
55-40-55- 1	0Y	DEC 22/06	55-40-55- 1	51	APR 22/08
55-40-55- 1	1	DEC 22/07	55-40-55- 1	52	APR 22/08
55-40-55- 1	2	DEC 22/06	55-40-55- 1	53	APR 22/08
55-40-55- 1	3	DEC 22/06	55-40-55- 1	54	APR 22/08
55-40-55- 1	4	DEC 22/06	55-40-55- 1	55	APR 22/08
55-40-55- 1	5	DEC 22/06	55-40-55- 1	56	APR 22/08
55-40-55- 1	6	DEC 22/06	55-40-55- 1	57	APR 22/08
55-40-55- 1	7	DEC 22/06			
55-40-55- 1	8	APR 22/08			
55-40-55- 1	9	APR 22/08			
55-40-55- 1	10	APR 22/08			
55-40-55- 1	11	APR 22/08			
55-40-55- 1	12	APR 22/08			
55-40-55- 1	13	APR 22/08			
55-40-55- 1	14	APR 22/08			
55-40-55- 1	15	APR 22/08			
55-40-55- 1	16	APR 22/08			
55-40-55- 1	17	APR 22/08			
55-40-55- 1	18	APR 22/08			
55-40-55- 1	19	APR 22/08			
55-40-55- 1	20	APR 22/08			
55-40-55- 1	21	APR 22/08			
55-40-55- 1	22	APR 22/08			
55-40-55- 1	23	APR 22/08			
55-40-55- 1	24	APR 22/08			
55-40-55- 1	25	APR 22/08			

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

55 - LIST OF EFFECTIVE PAGES
PAGE 5

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
STABILIZERS	55-00-00		
VERTICAL STABILIZER INSTL-	55-00-01	01	

767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
HORIZONTAL STABILIZER	55-10-00		
CAP INSTL-LE STAB. TO BODY SEAL	55-10-01	01	
HORIZONTAL STABILIZER INSTL-	55-10-52	01	
SEAL INSTL-HORIZ STAB. TO BODY	55-10-02	02	
SPAR INSTL-CTR SECT. HORIZ STAB. REAR	55-10-51	01	
SUPPORT INSTL-HORIZ STAB. TO BODY	55-10-01	10	
FRONT SPAR FWD SEAL			
SUPPORT INSTL-TE HORIZ STAB. TO BODY	55-10-01	05	
SEAL			
HORIZONTAL STABILIZER TIP FAIRING	55-11-00		
FAIRING INSTL-TIP HORIZ STAB.	55-11-01	01	
HORIZONTAL STABILIZER CENTER SECTION	55-12-00		
CENTER SECTION ASSY-HORIZ STAB.	55-12-52	01	
DOOR INSTL-HORIZ STAB. FRONT SPAR ACCESS	55-12-53	01	
FITTING INSTL-CTR SECT. HORIZ STAB.	55-12-51	01	
JACK SCREW			
HORIZONTAL STABILIZER MAIN TORQUE BOX	55-13-00		
BOX OUTBOARD ASSY-HORIZ STAB. MAIN	55-13-53	01	
RIB INSTL-HORIZ STAB. MAIN TORQUE BOX	55-13-51	05	
RIB INSTL-HORIZ STAB. NO 5 R.S. 55.105	55-13-51	01	
MAIN TORQUE BOX			
RIB INSTL-HORIZ STAB. STA 177.605 MAIN	55-13-55	01	
TORQUE BOX NO. 10 REAR SPAR			
RIB 2 INSTL-HORIZ STAB. BBL 41.5 PIVOT	55-13-52	01	
RIB			
SPAR INSTL-HORIZ STAB. REAR	55-13-54	01	
HORIZONTAL STABILIZER FORWARD TORQUE BOX	55-14-00		
SPAR INSTL-HORIZ STAB. AUX	55-14-51	01	
HORIZONTAL STABILIZER FIXED TRAILING	55-16-00		
EDGE			
BEAM INSTL-FXD TE HORIZ STAB. LWR	55-16-57	01	
BEAM INSTL-HORIZ. STAB. FXD TE UPR	55-16-54	01	
PANEL INSTL-HORIZ STAB. ELEV FXD TE UPR	55-16-53	01	
PANEL INSTL-HORIZ STAB. FXD TE LWR	55-16-52	01	
RIB INSTL-HORIZ STAB. ELEV	55-16-56	01	
RIB INSTL-HORIZ STAB. ELEV STA 114.777	55-16-56	02	
FXD TE			
RIB INSTL-HORIZ STAB. ELEV STA 139.258	55-16-56	03	
FXD TE			

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
RIB INSTL-HORIZ STAB. ELEV STA 212.702 FXD TE	55-16-56	04	
RIB INSTL-HORIZ STAB. ELEV STA 261.665 FXD TE	55-16-56	05	
RIB INSTL-HORIZ STAB. FXD T E	55-16-51	01	
RIB INSTL-HORIZ STAB. OUTBD CLOSURE FXD TE	55-16-55	01	
TRAILING EDGE INSTL-FXD HORIZ STAB.	55-16-58	01	
TRAILING EDGE INSTL-HORIZ STAB. HSBL 314.934 TO 366.442 OUTBD	55-16-59	01	
HORIZONTAL STABILIZER ATTACH FITTINGS	55-17-00		
FITTING INSTL-HORIZ STAB. PIVOT	55-17-51	01	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
ELEVATOR	55-20-00		
ELEVATOR INSTL-INBD/OUTBD SEGMENT	55-20-51	01	
INBOARD ELEVATOR	55-23-00		
SUPPORT INSTL-AFT QUADRANT ELEV CONT AND UPR SPRT	55-23-52	01	

767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
VERTICAL STABILIZER	55-30-00		
RIB INSTL-FIXED TE VERT. STAB. FROM CLOSURE RIB TO STA 131.108	55-30-51	01	
RIB INSTL-FIXED TE VERT. STAB. STA 156.074 TO STA 380.769	55-30-51	05	
RIB INSTL-RUD STA 106.142 VERT. STAB. FXD TE	55-30-51	06	
RIB INSTL-RUD STA 131.108 VERT. STAB. FXD TE	55-30-51	07	
RIB INSTL-RUD STA 18.260 VERT. STAB. FXD TE	55-30-51	02	
RIB INSTL-RUD STA 39.232 VERT. STAB. FXD TE	55-30-51	03	
RIB INSTL-RUD STA 60.204 VERT. STAB. FXD TE	55-30-51	04	
SPAR INSTL-FWD TORQUE BOX VERT. STAB. AUX	55-30-52	01	
STABILIZER ASSY-VERT. PREMODULE	55-30-50	01	
VERTICAL STABILIZER FIN TIP	55-31-00		
FIN TIP INSTL-VERT. STAB.	55-31-01	01	
PANEL INSTL-SEAL	55-31-02	01	
SEAL INSTL-FIN/BODY WIRE BUNDLE	55-31-51	01	
VERTICAL STABILIZER AFT TORQUE BOX	55-33-00		
RIB INSTL-VERT. STAB. TORQUE BOX AFT	55-33-52	01	
SKIN ASSY-VERT. STAB. AFT TORQUE BOX	55-33-52	05	
VERTICAL STABILIZER FORWARD TORQUE BOX	55-34-00		
PANEL INSTL-VERT. STAB. FXD TE	55-34-01	01	
TORQUE BOX INSTL-VERT. STAB. FWD	55-34-51	01	
VERTICAL STABILIZER LEADING EDGE	55-35-00		
LEADING EDGE INSTL-VERT. STAB. FXD	55-35-01	01	
LEADING EDGE INSTL-VERT. STAB. REM	55-35-01	02	
VERTICAL STABILIZER FIXED TRAILING EDGE	55-36-00		
BRACKET INSTL-RUD ACTR	55-36-51	01	
RUD CONT-VERT. TAIL	55-36-52	01	
SPAR INSTL-TORQUE BOX VERT. STAB. REAR AND FRONT AFT	55-36-55	01	
TRAILING EDGE INSTL-VERT. STAB. FXD	55-36-53	01	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 55 — STABILIZERS

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
RUDDER	55-40-00		
RUDDER ASSY-	55-40-55	01	
RUDDER INSTL-	55-40-51	01	