

BOEING
 767
PARTS CATALOG (MAINTENANCE)

CH-SECT-UNIT-FIG	PAGE NO.	DATE	CH-SECT-UNIT-FIG	PAGE NO.	DATE
*74	1	AUG 22/09			
*74	2	AUG 22/09			
*74	3	AUG 22/09			
74-11-00	1	DEC 22/06			
74-11-01- 5	0	DEC 22/06			
74-11-01- 5	1	DEC 22/06			
74-11-01- 5	2	DEC 22/06			
74-11-01- 5	3	DEC 22/06			
74-11-01- 5	4	DEC 22/06			
74-11-01- 5	5	DEC 22/06			
74-11-01- 5	6	DEC 22/06			
74-21-00	1	DEC 22/06			
74-21-01- 5	0	DEC 22/06			
74-21-01- 5	1	DEC 22/06			
74-21-01- 5	2	DEC 22/06			
74-21-01- 5	3	DEC 22/06			
74-21-01- 5	4	DEC 22/06			
74-21-01- 5	5	DEC 22/06			
74-21-01- 5	6	DEC 22/06			
74-21-01- 5	7	DEC 22/06			
74-21-01- 5	8	DEC 22/06			
74-21-02- 5	0	DEC 22/06			
74-21-02- 5	1	DEC 22/07			
74-21-02- 5	2	DEC 22/07			
74-21-02- 5	3	DEC 22/07			
74-31-00	1	DEC 22/06			
74-31-50- 5	0	DEC 22/06			
74-31-50- 5	1	DEC 22/07			
74-31-50- 5	2	DEC 22/08			
74-31-50- 5	3	DEC 22/07			
74-31-51- 1	0	DEC 22/06			
74-31-51- 1	1	DEC 22/07			
74-31-52- 2	0	DEC 22/06			
*74-31-52- 2	1	AUG 22/09			
*74-31-52- 2	2	AUG 22/09			
*74-31-52- 2	3	AUG 22/09			
*74-31-52- 2	4	AUG 22/09			
*74-31-52- 2	5	AUG 22/09			
74-31-55- 2	0	DEC 22/06			
74-31-55- 2	1	DEC 22/07			
74-31-55- 2	2	DEC 22/07			
74-31-55- 2	3	DEC 22/06			

* THE ASTERISK INDICATES PAGES CHANGED OR ADDED BY THE CURRENT REVISION

HXL
AUG 22/09

74 - LIST OF EFFECTIVE PAGES
PAGE 1

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 74 — IGNITION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
IGNITION POWER SUPPLY	74-11-00		
EXCITERS-IGNITION (PW4000)	74-11-01	05	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 74 — IGNITION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
HIGH TENSION DISTRIBUTION	74-21-00		
CABLES-EXCITER TO SPARK IGNITER (PW4000)	74-21-01	05	
PLUGS-IGNITER (PW4000)	74-21-02	05	

 BOEING
767
PARTS CATALOG (MAINTENANCE)

CHAPTER 74 — IGNITION

TABLE OF CONTENTS

SUBJECT	CC-SS-UU	FIGURE	EFFECT
ENGINE IGNITION CONTROL	74-31-00		
PANEL ASSY-P11 PILOTS CB (IGNITION ONLY)	74-31-51	01	
PANEL INSTL-OVHD (IGNITION ONLY)	74-31-52	02	
SHELF ASSY-ELECTRONIC EQPT CTR E1-2 (IGNITION ONLY)	74-31-55	02	
WIRING INSTL-ENGINE BUILD-UP (IGNITION ONLY)	74-31-50	05	