

FOR SAFE OPERATIONS (IMPORTANT)

WARNING!!

- The lamp body becomes extremely hot when turned on. Never touch the lamp body or lens until thoroughly cooled. Injury may result.
- This lamp kit is not intended for use by young children or infirm persons without supervision; young children should be supervised to ensure that they do not play with this appliance.
- Never short-circuit the plug of the battery charger. It may cause the battery to overheat, resulting in fire or damage of the components.

CAUTION

- Use only the included battery charger for charging.
- Safely dispose of the old battery when it comes to the end of its useful life.
- Never mix different types of batteries or old / new batteries together.
- Although dry batteries can be used, never recharge them.
- Overcharge may cause the battery trouble.
- Avoid leaving the battery under direct sunlight. It may cause the battery leak.
- A long period of non-use will lower the voltage of the battery due to natural self discharge. Always charge the battery before using.
- If the cord of the battery charger or other parts are damaged, it must only be replaced by the shop where this lamp kit was purchased, because special purpose tools are required.
- The charger may become hot during recharging.
- The charging time may vary depending on the use environment.
- If the battery does not serve the proper run time even after it is fully charged, it may be at the end of its useful life. Replace it with a new one.

HOW TO CHARGE


If the batteries are not inserted, please see "How To Replace The Battery".

When the indicator of the lamp body turns red, it means the battery voltage is lowered; recharge the battery.
 The factory-loaded battery is not charged.




Open the jack cover on the bottom of the lamp body and connect it with the plug of the charger. Plug the charger with the home power outlet.

Caution Use only the provided battery charger.
 Never recharge dry batteries.
 Make sure to close the jack cover after charging.





Using CHR-105 Charger

This charger is only for Ni-Cd batteries. It takes 8-10 hours to be full-charged. Unplug the charger after charging.




Using CHR-145 Charger

This charger is for Ni-Cd and Ni-MH batteries. The indicator is on during charging. When the battery is full-charged, it will start flashing. (It takes 8-10 hours.)




HOW TO ATTACH THE BRACKET AND THE LAMP BODY

TO MOUNT: Adjust the bracket using the rubber pad and fix it with the screw.




TO REMOVE: Pull off the lamp body while pushing the lever as the arrow shows.




HOW TO REPLACE THE BATTERY AND THE BULB

Loosen the screw on the bottom of the lamp body and remove the upper body.




A Battery

Insert the batteries as the picture shows.
Caution Make sure of the correct polarity.
 Never mix different types of batteries or old / new batteries together.



B Bulb

Take out the lens component. Remove the bulb holder and replace the bulb with a new one. Insert the bulb aligning the gap of the clasp with the projection of the lens component.
Caution Do not touch the bulb and the reflective mirror with bare fingers.
 Use only the CAT EYE halogen bulb.



SPARE PARTS

NiMH Battery #533-8477	6V-2.4A Halogen Bulb #533-8060		
Ni-Cd Battery #533-8478	H-24 Bracket #533-8597		H-24 Bracket & Spacer #533-8598
CHR-145 Battery Charger #533-8496			
CHR-105 Battery Charger #533-8491			

SPECIFICATIONS

Bulb:	6V-2.4W Halogen Bulb
Battery:	Ni-Cd / Ni-MH
Charger:	CAT EYE Battery Charger CHR-105 / 145
Operation time:	Ni-Cd: 2.5 hours Ni-MH: 4 hours Alkaline: 4 hours
Charging time:	8 - 10 hours
Temperature Range:	Charging: 0°C ~ 40°C Operating: -15°C ~ 45°C
Recharge/Discharge Number of Times:	More than 500 times (until rated capacity drops to 50%)

*The specifications and design are subject to change without notice.

LIMITED WARRANTY

1- Year Warranty:
Only Lamp Unit And Battery Charger (Excluding bulb and battery)
 If trouble or damage occurs during normal use, the product will be repaired or replaced free of charge. Type your name, address, date of purchase and the situation of trouble clearly, and send it back to the appropriate service center together with the product. Insurance, handling and transportation charges shall be borne by the customer. After being repaired or replaced, the product will be shipped back to the customer.

Address for the service: CATEYE CO., LTD.
 2-8-25 Kuwazu, Higashi sumiyoshi-ku, Osaka 546-0041 JAPAN
 Attention: **CAT EYE CO., LTD. Customer Service Section**
 Phone: 81-6-6719-7781 Fax: 81-6-6719-2362

Service & Research Center
 1705 14th St. #115 Boulder, CO 80302
 Phone: 303-443-4595 Toll Free: 800-5CATEYE(800-522-8393)
 Fax: 303-473-0006 e-mail: CatEyeUSA@aol.com
 Web site: http://www.cateye.com