

# Component Placing T68

## by Toko (toko@gsm-free.org)

### Contents


<b>1</b>	<b>Mounting Drawing Table</b>	<b>2</b>
<b>2</b>	<b>1078-2/ROA 117 9738/2 Rev. D</b>	<b>3</b>
2.1	Component Position Location Table for 1078-2/ROA 117 9738/2 Rev. D	5
<b>3</b>	<b>Revision History</b>	<b>5</b>

# 1 Mounting Drawing Table

Board Number	Mounting Drawing
2/ROA 117 9732/2 Rev. R1D	1078-2/ROA 117 9732/2 Rev. D

## 2 1078-2/ROA 117 9732/2 Rev R1D

### 1078-2/ROA 117 9732/2 Rev. R1D Primary Side





## 2.1 Component Position Location Table for 1078-2/ROA 117 9732/2 Rev. R1D

The highlighted components are the only components possible to replace according to the service concept for T68.

1. located on primary side
2. located on secondary side

Pos.	Loc.
S50	2
H623	2
H600	2
J602	1
W001	1
J602	1

## 3 Revision History

Rev.	Date	Changes / Comments
A	2001-10-01	First Revision