

3 *Setting-Up*

Chapter 3 contains instructions for commissioning the stations of a connection and is subdivided into the following sections:

- ◆ *Introduction*
 - ◆ *Front Panel Devices*
 - ◆ *Hardware Settings*
 - ◆ *Link Line Up*
 - ◆ *Service Telephone Channel Operating Instructions*
-

PAGE INTENTIONALLY LEFT BLANK

Description Index

Introduction	3.1-1
Front Panel Devices	3.2-1
Subrack Layout	3.2-1
Unit Front Panels	3.2-2
<i>MOST Unit Type 2 MOST Unit Type 2S</i>	3.2-3
<i>Tributary Unit</i>	3.2-4
<i>STM-1 Optical/Mux Unit</i>	3.2-5
<i>Communication Unit</i>	3.2-6
<i>Auxiliary Unit</i>	3.2-7
Hardware Settings	3.3-1
Types of Settings	3.3-1
MOST Unit	3.3-3
STM-1 Optical/Mux Unit Type 2	3.3-13
STM-1 G.703 Electrical/Mux Unit	3.3-16
1x140Mbit/s / STM-1 (with VC-12 handling) G.703 Tributary Unit	3.3-19
63x1.5/2Mbit/s G.703 Tributary Unit	3.3-21
32x1.5/2Mbit/s G.703 Tributary Unit	3.3-23
3x34Mbit/s Tributary Unit	3.3-25
Auxiliary Unit	3.3-28
<i>Solder Pad Settings (Soldering Side)</i>	3.3-28
<i>Adjustable Dip Switch Settings (Component Side)</i>	3.3-29
Communication Unit	3.3-34
3x45Mbit/s Tributary Unit	3.3-36
Link Line Up	3.4-1
Instruments and Accessories	3.4-1
Power Supply Voltages Check	3.4-2
<i>Description</i>	3.4-2
<i>Procedure</i>	3.4-2
Commissioning	3.4-2
<i>Procedure</i>	3.4-2
Internal Fault Check	3.4-3
<i>Description</i>	3.4-3
<i>Procedure</i>	3.4-3
Bit Error Rate Check	3.4-4
<i>Description</i>	3.4-4
<i>Procedure</i>	3.4-4
Alarm Check	3.4-8
<i>Description</i>	3.4-8
<i>Procedure</i>	3.4-8
Protection Check	3.4-10
<i>Description</i>	3.4-10
<i>Procedure</i>	3.4-10
Synchronization Sources Check	3.4-13
<i>Description</i>	3.4-13
<i>Procedure</i>	3.4-13
Synchronism Protections Check	3.4-16
<i>Description</i>	3.4-16

<i>Procedure</i>	3.4-16
Out of Frequency Management Check	3.4-17
<i>Description</i>	3.4-17
<i>Procedure</i>	3.4-17
Emitted Optical Power Check	3.4-18
<i>Description</i>	3.4-18
<i>Procedure</i>	3.4-18
Receiver Sensitivity Check	3.4-20
<i>Description</i>	3.4-20
<i>Procedure</i>	3.4-20
Service Telephone Channel Operating Instructions	3.5-1
Collective Call	3.5-1
Selective Call	3.5-5
Access to a Conversation	3.5-6
Insertion/Replacement of an Auxiliary Unit	3.5-7
Making Calls in a Ring Network	3.5-8
Phone Number Assignment	3.5-8