

Document History

Volume Issue Record

Issue	Date	System Release
EN/LZB 101 3949/03	09-97	2.1
EN/LZB 101 3949/04	12-97	2.2
EN/LZB 101 3949/05	01-99	3.1
EN/LZB 101 3949/06	03-99	3.2

Structure of Volume1 Issue EN/LZB 101 3949/06 R1A

(✓ = Modified in relation to the previous release)

<i>Chapter name</i>	<i>Rev.</i>		<i>File name</i>
Title Pages		✓	1087c04
Document History	07	✓	1084dh_07
General Index	07	✓	1084i_07

Section 0 – General Information

<i>Chapter name</i>	<i>Rev.</i>		<i>File name</i>
Safety Rules	12	✓	00_01_12

Section 1 – Information for the System Engineer

<i>Chapter name</i>	<i>Rev.</i>		<i>File name</i>
Description Index	07	✓	01_00_07
General Technical Characteristics	07	✓	01_01_07
Equipment Description	02	✓	01_02_02
Network Applications	03		01_03_03
Equipment Composition	07	✓	01_04_07
Technical Specification	04	✓	01_05_04
Attached Documents	03		01_06_03

Section 2 – Installation

<i>Chapter name</i>	<i>Rev.</i>	<i>File name</i>
Description Index	05 ✓	02_00_05
Rack Installation	03	02_01_03
Sub-rack Installation	04	02_02_04
Connectors Layout	04 ✓	02_03_04
Electrical Connections	02	02_04_02
Connectors Pin-out	03 ✓	02_05_03
Attached Documents	01	02_06_01

Section 3 – Setting-up

<i>Chapter name</i>	<i>Rev.</i>	<i>File name</i>
Description Index	07 ✓	03_00_07
Introduction	01	03_01_01
Front Panel Devices	07 ✓	03_02_07
Hardware Settings	07 ✓	03_03_07
Link Line Up	02 ✓	03_04_02
Service Telephone Channel Operating Instructions	02	03_05_02

Section 4 – Maintenance

<i>Chapter name</i>	<i>Rev.</i>	<i>File name</i>
Description Index	05	04_00_05
Routine Maintenance	02	04_01_02
Fault Location: General	04	04_02_04

Section 5 – Functional description

<i>Chapter name</i>	<i>Rev.</i>	<i>File name</i>
Description Index	06 ✓	05_00_06
MOST Unit	04 ✓	9141xx_4
63x1.5/2Mbit/s G.703 Tributary Unit	01	897701_01
Communication Unit	01	892401_01
STM 1 G.703 Electrical Unit – Type 2	01	868301_01
STM–1 Optical/Mux Unit	01	8682xx_01
Auxiliary Unit Type 1	03	869001_3
3x34Mbit/s Tributary Unit	01	868501_1
3x45Mbit/s Tributary Unit	01	925101_1
32x1.5/2Mbit/s G.703 Tributary Unit	01	897702_1
1x140Mbit/s / STM–1 G.703 Tributary Unit	01	931011_1

Issue EN/LZB 101 3949/06 R1A Updating Form

Section 1 – Information for the System Engineer

<i>Chapter name</i>	<i>Old Rev.</i>	<i>New Rev.</i>	<i>Reasons for updating</i>
Description Index	05	06	(M)
General Technical Characteristics	05	06	(M)
Equipment Description	01	02	(M)
Equipment Composition	05	06	(M)
Technical Specification	03	04	(M)

————— (A) = Added; (M) = Modified; (R) = Removed

Section 2 – Installation

<i>Chapter name</i>	<i>Old Rev.</i>	<i>New Rev.</i>	<i>Reasons for updating</i>
Description Index	04	05	(M)

————— (A) = Added; (M) = Modified; (R) = Removed

Section 3 – Setting Up

<i>Chapter name</i>	<i>Old Rev.</i>	<i>New Rev.</i>	<i>Reasons for updating</i>
Description Index	06	07	(M)
Front Panel Devices	06	07	(M)
Hardware Settings	06	07	(M)
Link Line Up	01	02	(M)

————— (A) = Added; (M) = Modified; (R) = Removed

Section 5 – *Functional description*

<i>Chapter name</i>	<i>Old Rev.</i>	<i>New Rev.</i>	<i>Reasons for updating</i>
Description Index	04	05	(<i>M</i>)
Most Unit	03	04	(<i>M</i>)

————— (*A*) = Added; (*M*) = Modified; (*R*) = Removed