



LaserJet 1100/3200  
Series Maintenance  
Kit



## HP LaserJet 1100/3200 Series Maintenance Kit Instruction Sheet

This HP LaserJet Printer Maintenance Kit provides you with the parts most commonly used to repair the paper path wear components of the HP LaserJet 1100/3200 series printers. Using the HP LaserJet Printer Maintenance kit helps provide convenience and cost savings as you eliminate the need for individual subcomponent ordering where multiple part needs exist. Using HP authorized parts allows for maximum paper feed and print quality performance of your Laserjet printer. This kit is intended for HP Authorized Service Providers in non-warranty applications.

LaserJet 1100/3200 Maintenance Kits	
H3965-60001 (110V ONLY)	
H3965-60002 (220V ONLY)	
Part Num	Description
RG5-4589-040CN	FUSER 110V *
RG5-4590-040CN	FUSER 220V *
RG5-4657-000CN	TRANSFER ROLLER
RB2-4026-000CN	PU ROLLER
RF5-2886-000CN	SEPARATION PAD (LJ 1100)
RY7-5050-000CN	SUB PAD KIT
RF5-2823-000CN	PRESURE ROLLER
RF5-2830-000CN	FACE DOWN ROLLER
HB1-3035-000CN	SEPARATION PAD (LJ 3200)
* This component may not be included depending on the voltage.	

### Caution

Please refer to your HP LaserJet Service Manual for proper installation of kit parts.  
(P/N C4224-60140 for the LJ 1100; P/N C7052-90930 for the LJ 3200)

### For More Information

HP offers a wide selection of maintenance kits for its HP LaserJet line of printers. Within the U.S., orders may be placed on-line at [www.partsdirect.hp.com](http://www.partsdirect.hp.com) or by calling (800) 798-KITS. For outside the U.S., please contact your local HP Sales Office.