
Contents

About This Document.....	1
1 Safety Precautions.....	1-1
2 BTS3012 Cabinet.....	2-1
2.1 Physical Structure of the BTS3012.....	2-2
2.2 Cable Distribution of the BTS3012.....	2-4
2.3 Engineering Specifications for the BTS3012	2-7
3 Space and Location Requirements of the BTS3012.....	3-1
4 Preparations for Installing the BTS3012.....	4-1
4.1 Unpacking the Cases and Checking the Items.....	4-2
4.2 BTS3012 Mounting Tools.....	4-3
5 Installing the BTS3012.....	5-1
6 Installing the BTS3012 Cabinet.....	6-1
6.1 Installing the BTS3012 Cabinet on the Concrete Floor with Sufficient Load Capacity.....	6-2
6.2 Installing the BTS3012 Cabinet on the Concrete Floor with Insufficient Load Capacity.....	6-9
6.2.1 Installing the BTS3012 Cabinet on the Bearing Wall.....	6-11
6.2.2 Installing the BTS3012 Cabinet on the Spandrel Girder.....	6-16
6.3 Installing the BTS3012 Cabinet on the ESD Floor.....	6-24
6.4 Installing the BTS3012 Cabinet in Combined Cabinets or in a Cabinet Group Side by Side.....	6-33
6.5 Installing the BTS3012 Cabinet in a Combined Group of BTS3012 and BTS312.....	6-35
7 Installing the Power Cables and Equipotential Cables of the BTS3012.....	7-1
7.1 Installing the BTS3012 Power Cables.....	7-2
7.2 Installing the BTS3012 PGND Cables.....	7-6
7.3 Installing the BTS3012 Equipotential Cables.....	7-7
8 Installing the BTS3012 Boards and Modules.....	8-1
8.1 List of the BTS3012 Boards and Modules.....	8-2
8.2 Preparations for Installing the BTS3012/BTS3012AE Boards and Modules.....	8-3
8.3 Installing the DTMU, DATU, and DEMU.....	8-4
8.4 Installing the DTRU.....	8-6
8.5 Installing the DDPU, DCOM, DFCU, and DFCB.....	8-6
8.6 Installing the DMLC, DELC, and DSAC.....	8-8

9 Installing the BTS3012 Cables.....	9-1
9.1 List of the BTS3012 cables.....	9-2
9.2 Cabling Specifications for the BTS.....	9-9
9.3 Installing the Busbar Power Cables of the BTS3012.....	9-11
9.3.1 Installing the Power Cables from the BTS3012 Busbar to the Common Subrack and DTRU Subrack.....	9-11
9.3.2 Installing the Power Cables from the BTS3012 Busbar to the Fan Subrack.....	9-12
9.3.3 Installing the Power Cables from the BTS3012 Busbar to the DAFU Subrack.....	9-13
9.4 Installing the BTS3012 Transmission Cables.....	9-14
9.4.1 Installing the BTS3012 E1 Cables.....	9-14
9.4.2 Installing the BTS3012 Optical Cables.....	9-15
9.5 Installing the BTS3012 RF Cables.....	9-16
9.5.1 Installing the BTS3012/BTS3012AE RF Signal Cables.....	9-16
9.5.2 Installing the Indoor 1/2-Inch Jumpers of the BTS3012.....	9-17
9.6 Installing the BTS3012 Signal Cables.....	9-18
9.6.1 Installing the Combining Short-Circuiting Signal Cables of the BTS3012/BTS3012AE.....	9-19
9.6.2 Installing the Four-In-One Short-Circuiting Signal Cables of the BTS3012/BTS3012AE.....	9-20
9.6.3 Installing the BTS3012/BTS3012AE Signal Cables Between the DFCB and the DFCU.....	9-21
9.6.4 Installing the BTS3012/BTS3012AE Power Detection Cables.....	9-21
9.6.5 Installing the Diversity Receive Short-Circuiting Signal Cables of the BTS3012/BTS3012AE.....	9-22
9.6.6 Installing the Lightning Protection Failure Alarm Cables of the BTS3012.....	9-23
9.6.7 Installing the Lightning Protection Failure Alarm Cables for the Combined Cabinets.....	9-23
9.6.8 Installing the Boolean Input Cables of the BTS3012.....	9-24
9.6.9 Installing the Boolean Output Cables of the BTS3012.....	9-24
9.6.10 Installing the EAC Signal Cables of the BTS3012.....	9-25
9.6.11 Installing the Dedicated Monitoring Signal Cable of the BTS3012.....	9-25
9.6.12 Installing the EMI Signal Cables of the BTS3012.....	9-26
9.6.13 Installing the RET Control Signal Cables of the BTS3012.....	9-26
9.6.14 Installing the Signal Cables Between the DCTB and the DAFU Subrack for the BTS3012.....	9-27
9.6.15 Installing the Signal Cables for Combined Cabinets.....	9-27
9.6.16 Installing the Signal Cables for Cabinet Groups.....	9-27
9.6.17 Installing the Signal Cables for the Combined Group of the BTS3012 and BTS312.....	9-28
9.7 Installing the Cables Between the Sidepower and the BTS3012.....	9-29
9.7.1 Installing the Power Cables Between the Sidepower and the BTS3012.....	9-29
9.7.2 Installing the Alarm Cables Between the Sidepower and the BTS3012.....	9-29
9.8 Installing the Cables Between the EMU and the BTS3012.....	9-29
9.8.1 Installing the Signal Cables of the External Environment Alarm Box Between the EMU and the BTS3012.....	9-30
9.9 Installing the Cables Between the EAC-2 and the BTS3012.....	9-30
9.9.1 Installing the Signal Cables of the External Environment Alarm Box Between the EAC-2 and the BTS3012.....	9-30
10 Installing the BTS3012 Sensors.....	10-1
10.1 Fixing the BTS3012 Sensors.....	10-2

10.2 Connecting the Sensors to the BTS3012 Cabinet.....	10-3
11 Checking the Hardware Installation of the BTS3012.....	11-1
11.1 Checklist for the Installation of the BTS3012 Cabinet.....	11-5
11.2 Checklist for the Installation of the BTS Cables.....	11-6
11.3 Checklist for the Sanitation in the Installation Environment.....	11-8

Figures

Figure 1-1 Wearing an ESD wrist strap.....	1-6
Figure 1-2 Fully unfolded A-shaped ladder.....	1-8
Figure 1-3 Ladder slant.....	1-9
Figure 1-4 Using the long ladder in a safe way.....	1-9
Figure 1-5 Ladder with its top end one meter above the eave.....	1-10
Figure 1-6 Hoisting a heavy object.....	1-10
Figure 1-7 Laying down and placing upright the cabinet.....	1-11
Figure 2-1 Fully configured BTS3012 cabinet	2-2
Figure 2-2 Cable distribution on the cabinet front (configured with the DDPU).....	2-4
Figure 2-3 Cable distribution on the cabinet front (configured with the DFCU).....	2-5
Figure 2-4 Internal cable distribution on the cabinet top.....	2-6
Figure 3-1 Installation of a single BTS3012 cabinet with base A (in mm).....	3-2
Figure 3-2 Installation of a single BTS3012 cabinet with base B (in mm).....	3-2
Figure 3-3 Installation of multiple BTS3012 cabinets with base A (in mm).....	3-3
Figure 3-4 Installation of multiple BTS3012 cabinets with base B (in mm).....	3-3
Figure 3-5 Installation of the BTS3012 and BTS312 cabinets with base A (in mm).....	3-4
Figure 3-6 Installation of the BTS3012 and BTS312 cabinets with base B (in mm).....	3-4
Figure 6-1 Installation directions of the cabinets.....	6-2
Figure 6-2 Template for marking installation positions (unit: mm).....	6-3
Figure 6-3 Installing the expansion bolt assembly.....	6-4
Figure 6-4 Disassembling the expansion bolt assembly.....	6-5
Figure 6-5 Insulation plate.....	6-5
Figure 6-6 Installing the lower frame (unit: mm).....	6-6
Figure 6-7 Testing the resistance between the lower frame and the expansion bolts.....	6-7
Figure 6-8 Securing the upper and lower frames.....	6-8
Figure 6-9 Tightening the panel screw assembly.....	6-9
Figure 6-10 Drilling holes on the U-steels (unit: mm).....	6-12
Figure 6-11 Determining positions for the U-steels on the bearing walls.....	6-12
Figure 6-12 Installing the U-steels between the bearing walls.....	6-13
Figure 6-13 Installing the lower frame (unit: mm).....	6-14
Figure 6-14 Testing the resistance between the lower frame and the expansion bolts.....	6-14
Figure 6-15 Installing the BTS3012 cabinet on the concrete floor with insufficient load capacity.....	6-15
Figure 6-16 Tightening the panel screw assembly.....	6-16

Figure 6-17 Drilling holes on the U-steels (unit: mm).....	6-17
Figure 6-18 Determining positions for the U-steels (unit: mm).....	6-18
Figure 6-19 Installing the expansion bolt assembly.....	6-19
Figure 6-20 Disassembling the expansion bolt assembly.....	6-20
Figure 6-21 Securing the U-steels.....	6-20
Figure 6-22 Installing the lower frame (unit: mm).....	6-21
Figure 6-23 Testing the resistance between the lower frame and the expansion bolts.....	6-22
Figure 6-24 Installing the BTS3012 cabinet on the concrete floor with insufficient load capacity.....	6-23
Figure 6-25 Tightening the panel screw assembly.....	6-24
Figure 6-26 Installation directions of the cabinets.....	6-25
Figure 6-27 Structure of the support of A600 series.....	6-25
Figure 6-28 Template for marking installation positions (unit: mm).....	6-26
Figure 6-29 Connecting the support and the ESD floor.....	6-27
Figure 6-30 Installing the expansion bolt assembly.....	6-28
Figure 6-31 Disassembling the expansion bolt assembly.....	6-29
Figure 6-32 Installing the A600 support under the ESD floor.....	6-30
Figure 6-33 Installing the lower frame (unit: mm).....	6-31
Figure 6-34 Testing the resistance between the lower frame and the expansion bolts.....	6-31
Figure 6-35 Installing the BTS3012 cabinet on the ESD floor.....	6-32
Figure 6-36 Tightening the panel screw assembly.....	6-33
Figure 6-37 Connecting cabinets from the top.....	6-34
Figure 6-38 Positions for attaching the labels.....	6-39
Figure 7-1 Removing the protection cover.....	7-2
Figure 7-2 Installing the power cable.....	7-3
Figure 7-3 Securing the power cable.....	7-4
Figure 7-4 Installing OT terminals of multiple cables.....	7-5
Figure 7-5 Installing the power cable.....	7-6
Figure 7-6 Installing the PGND cable.....	7-7
Figure 7-7 Connecting the equipotential cables for the combined cabinets.....	7-8
Figure 8-1 Installing the boards.....	8-5
Figure 8-2 Handles on the front panel hooking into the subrack.....	8-5
Figure 8-3 Position for attaching a cell label on the panel of the DDPU.....	8-7
Figure 8-4 Position for attaching a cell label on the panel of the DFCU.....	8-8
Figure 8-5 Configurations of the subrack on top of the cabinet.....	8-9
Figure 9-1 Cabling of power cables connected to boards and subracks.....	9-12
Figure 9-2 Cabling of power cables connected to boards and subracks.....	9-13
Figure 9-3 Cabling of power cables connected to boards and subracks.....	9-14
Figure 9-4 Connecting the combining short-circuiting signal cables (black).....	9-20
Figure 10-1 Connecting the DMLC to the DDF box.....	10-3

Tables

Table 2-1 Cable distribution in the cabinet.....	2-6
Table 2-2 Dimensions (appearance)	2-8
Table 2-3 Weight of the cabinet	2-8
Table 2-4 Specifications for the input power	2-8
Table 2-5 Power consumption	2-9
Table 2-6 Power consumption	2-9
Table 4-1 List of tools and instruments.....	4-3
Table 6-1 Comparison between different installation methods.....	6-10
Table 6-2 Relation between the four types of supports and the height of the ESD floor.....	6-25
Table 6-3 Settings of the S1 DIP switches on the CMB.....	6-36
Table 6-4 Settings of the S2 DIP switches on the CMB.....	6-36
Table 6-5 Settings of the S3 DIP switches on the CMB.....	6-37
Table 6-6 Settings of the S4 DIP switches on the CMB.....	6-37
Table 6-7 Settings of the S5 DIP switches on the CMB.....	6-37
Table 6-8 Settings of the DIP switches on the TDU.....	6-37
Table 6-9 Settings of the S1 and S3 DIP switches on the TRB.....	6-38
Table 6-10 Settings of the S5 and S6 DIP switches on the TRB.....	6-38
Table 8-1 Boards and modules of the BTS3012.....	8-2
Table 9-1 List of the BTS3012 cables.....	9-2
Table 11-1 Checklist for indoor equipment installation.....	11-5
Table 11-2 Checklist for the installation of the power cables and grounding cables.....	11-6
Table 11-3 Checklist for the installation of the signal cables.....	11-7
Table 11-4 Checklist for the sanitation in the installation environment.....	11-8