



3746 Nways Multiprotocol Controller  
Models 900 and 950

SY33-2126-01

**Network Node Processor  
Installation and Maintenance  
(based on 6275)  
Addendum  
EC F70099**

These revised pages are intended to replace the equivalent pages in the current version of the *Network Node Processor Installation and Maintenance (Based on 6275)*, SY33-2126-01. The pages affected are: 5-15, 5-16, F-19 and F-20.



```

Change Configuration Parameters
Adapters Mode | Plug and Play | Other Parameters

Select each mode for a detailed description

Adapter Modes
- Enhanced Modes
- Auto 16 Mode
- ISA 16 Mode

OK          Cancel    Help

```

8. Using the **Up** and **Down** keys select the **ISA 16 Mode** ( note that the response time is very slow) then press simultaneously **Alt** and **P** keys to select the **Plug and Play** window.

9. The following window is displayed.

```

Change Configuration Parameters
Adapters Mode | Plug and Play | Other Parameters

Make any Changes to the configuration, then select <OK>

- Plug and Play Automatic Configuration
- Manual (locked) Configuration for Plug and Play systems
- Manual Configuration for no Plug and Play (legacy) systems

OK          Cancel    Help

```

10. Select the **Manual (locked) Configuration for Plug and Play systems**, using the tab key select **Interrupt**, and using the arrow key, select interrupt: **7**

11. Press simultaneously the **Alt** and **R** keys.

12. The following window is displayed.

```

Change Configuration Parameters

Remote IPL                                Data Rates
o Enable                                  o 16 Mbps
o Disable                                 o 4 Mbps

Auto Sense                                Bus Wide
o Enable                                  o 16 Mbps
o Disable                                 o 8 Mbps

OK          Cancel    Help

```

13. Using the **Up**, **Down**, and **Tab** keys select:

- Remote IPL: **Disable**

- Data Rates: **16 Mbps**
- Auto Sense: **Disable**
- Bus Wide: **16 bits**

Select **OK** and press **Enter**.

14. The following window is displayed.

View Adapter Configuration

Configurable	Hardware
Select <Suggest> or <Change> to make changes to the configuration below Then press <Store> to store these changes to the adapter.	
Mode	ISA 16
Remote IPL:	Disabled
Data Rate:	16 MBps
Auto Sens	Disabled
Bus Width	16 bits
Adapter Plug and Play	Manual (legacy)
Interrupt:	7
I/O Address:	A20-A23
ROM Address	CA000-CBFFF
RAM Address	C8000-C9FFF
<div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>Suggest</span> <span>Change</span> <span>Defaults</span> <span>Store</span> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>Done</span> <span>Cancel</span> <span>Help</span> </div>	

15. Using the **Up** and **Down** keys select the **Store**, then press **Enter**.

16. The adapter configuration is stored. Wait until the following window is displayed.

Storing Configuration

The adapter configuration settings that you have chosen are now stored.

NOTE: Changes made to the adapter do not become effective until your computer is powered OFF and back ON: A reboot will not activate the changes.

OK

17. Press **Enter**.

18. The following window is displayed.

View Adapter Configuration

Configurable	Hardware
Select <Suggest> or <Change> to make changes to the configuration below Then press <Store> to store these changes to the adapter.	
Mode	ISA 16
Remote IPL:	Disabled
Data Rate:	16 MBps
Auto Sens	Disabled
Bus Width	16 bits
Adapter Plug and Play	Manual (legacy)
Interrupt:	7
I/O Address:	A20-A23
ROM Address	CA000-CBFFF
RAM Address	C8000-C9FFF
<div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>Suggest</span> <span>Change</span> <span>Defaults</span> <span>Store</span> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <span>Done</span> <span>Cancel</span> <span>Help</span> </div>	

19. If not selected, using the **Tab** key, select **Done**, then press **Enter**.

**1**

#### System Summary

Processor	Pentium III
Processor Speed	450MHz
L2 Cache Size	512 KB
Cache State	Enabled with NO ECC
System Memory	128 MB
Memory Type	Non-Parity
Video Controller	S3 Incorporated. TRI03D.
Diskette Drive A	1.44 MB 3.5"
Diskette Drive B	Not Installed
IDE Hard Disk Drive 0	4224 MB
IDE Hard Disk Drive 1	Not Installed
IDE CD-ROM Drive 2	Installed
IDE Hard Disk Drive 3	Not Installed

**Note:** The extended memory can also be 160 MB or higher.

**2**

#### Product Data

Machine type/ Model	627583U
Flash EEPROM Revision Level	PDKT21AUS
Boot Block Revision Level	PD21A
System Board Identifier	xxxxxxx
System Serial Number	xxxxxxx
System UUID	xxxxxxx
BIOS Date	02/08/99
BIOS Mode	Desktop

## Device and I/O Ports

Mouse	(Installed)
Diskette Drive A:	(1.44 MB 3.5")
Diskette Drive B:	(Not Installed)

- Serial Port Setup...
- USB Setup...
- Parallel Port Setup...
- Video Setup...
- IDE Drives Setup...

## Serial Port Setup

Serial Port A Address	(3F8h)
Serial Port A IRQ	(IRQ 4)
Serial Port B Address	(2F8h)
Serial Port B IRQ	(IRQ 3)

## USB Setup

USB Support	(Disabled)
USB Keyboard/Mouse Support	(Autodetect)

## Parallel Port Setup

Parallel Port	(Disabled)
Parallel Port Mode	Standard
Parallel Port Extended Mode	Bidirectionnal
Parallel Port Extended Mode DMA	No DMA
Parallel Port IRQ	IRQ 7

## Video Setup

Video Controller	S3 Incorporated. Trio3D
Video Memory	4096 KB
Primary Display	(PCI)
Palette Spooning	(Disabled)
Video interrupt	(Enabled)