


JVC

SERVICE MANUAL

COMPACT VHS CAMCORDER

GR-AX460EA/AX460EE/ AX627EG/AX827EG



Compact VHS



Regarding service information other than these sections, refer to the GR-AX260EG/360EG/460EG service manual (No. 86278).

Also, be sure to note important safety precautions provided in the service manual.

SPECIFICATIONS *(The specifications shown pertain specifically to the model GR-AX627EG/AX827EG)*

GENERAL

Format	: VHS PAL standard
Power source	: DC 6 V $\equiv$
Power consumption	
GR-AX827 light on	: 8.9 W
GR-AX827 light off	: 5.9 W
GR-AX427	: 5.9 W
GR-AX627 light on	: 8.7 W
GR-AX627 light off	: 5.7 W
GR-AX327	: 5.7 W
Signal system	: PAL-type
Video recording system	
Luminance	: FM recording
Colour	: Converted sub-carrier direct recording Conforms to VHS standard
Cassette	: VHS cassette
Tape speed	
SP	: 23.39 mm/sec
LP	: 11.70 mm/sec
Recording time Max.	
SP	: 45 minutes (with EC-45 cassette)
LP	: 90 minutes (with EC-45 cassette)
Operating temperature	: 0°C to +40°C
Operating humidity	: 35% to 80%
Storage temperature	: -20°C to +50°C
Weight	
GR-AX827	: Approx. 760 g
GR-AX627	: Approx. 780 g
GR-AX427	: Approx. 750 g
GR-AX327	: Approx. 770 g
Dimensions	
GR-AX827/AX427	: 109 (W) x 113 (H) x 206 (D) mm
GR-AX627/AX327	: 109 (W) x 113 (H) x 226 (D) mm

CAMERA

Pick up	: 1/4" format CCD
Minimum required illumination	: 2 lx (F1.2)
Illumination range	: 2 to 100,000 lx
Lens	: F1.2, f = 4.1 to 57.4 mm, 14:1 power zoom lens with auto iris and macro control, filter diameter 46 mm
Viewfinder	: Electronic viewfinder • with 0.55" colour LCD (GR-AX827/AX427) • with 0.5" black/white CRT (GR-AX627/AX327)
White balance adjustment	: Auto/Manual adjustment

VIDEO

Output	: 1 Vp-p, 75 ohms, unbalanced (via VIDEO out connector)
--------	---

AUDIO

Output	: -8 dBs, 1 k-ohm (via AUDIO out connector)
--------	---

AC POWER ADAPTER/BATTERY CHARGER (AA-V11EG/EK) SPECIFICATIONS

Power requirement	: AC 110 to 240 V $\sim$, 50/60 Hz
Power consumption	: 23 W
Output	: DC 8.5 V $\equiv$, 1.3 A (CHARGE), DC 6.3 V $\equiv$, 1.8 A (VTR)
Charging system	: Constant current, peak detection, timer controlled

Dimensions	: 150 (W) x 42 (H) x 68 (D) mm
------------	--------------------------------

Weight	
AA-V11EG	: Approx. 350 g
AA-V11EK	: Approx. 400 g

CASSETTE ADAPTER (C-P7U) SPECIFICATIONS

Dimensions	: 188 (W) x 25 (H) x 104 (D) mm
Weight	: Approx. 240 g
Accessory	: "R6 (AA)" size battery x 1

Provided Accessories pg. 3

Optional Accessories

- Battery Packs BN-V12U, BN-V22U, BN-V25U
- Car Battery Charger BH-V3E
- Battery Charger BH-VC10EG
- Car Battery Cord AP-V7E
- RF Unit RF-VSE
- Wireless Remote Control Unit RM-V704U
- Wired Remote Control Unit RM-V20U
- Compact VHS-C Cassettes EC-45/30
- Active Carrying Bag CB-V7U

* Some accessories are not available in some areas. Please consult your nearest JVC dealer for details on accessories and their availability.

E.&O.E. Design and specifications subject to change without notice.

TABLE OF CONTENTS

4. CHARTS AND DIAGRAMS

4.2 POWER SYSTEM BLOCK DIAGRAM	4-5
4.7 LINEAR AUDIO SCHEMATIC DIAGRAM	4-17
4.8 PROCESS AND Y/C SCHEMATIC DIAGRAM	4-19
4.15 CCD AND UPPER DRAM CIRCUIT BOARDS	4-39

5. PARTS LIST

5.1 PACKING ASSEMBLY <M1>	5-1
---------------------------------	-----

The following table lists the different points between models [GR-AX460EA, GR-AX460EE, GR-AX627EG(S) and GR-AX827EG(SH)] in this series.

ITEM \ MODEL	AX460EA	AX460EE	AX627EG(S)	AX827EG(SH)
ELECTRONIC VIEWFINDER	black/white	←	←	color
AC P ADAPTER	AA-V11EA	AA-V11EG	←	AA-V11EK
REMOTE CONTROLLER	RM-V705U	RM-V704U	RM-V705U	←
AV CABLE	×	○	○	○
CONVERSION PLUG	×	×	○	×

Notes : · Mark ← is same as left.
 · Mark ○ is used. · Mark × is not used.

The following table lists the different points between models [GR-AX460EG, GR-AX460EA, GR-AX460EE, GR-AX627EG(S) and GR-AX827EG(SH)] in this series.

PACKING ASSEMBLY <M1>

REF.NO.	ITEM \ MODEL	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX827EG(SH)
2	PACKING CASE	YQ32238-14	YQ32238-41-7	YQ32238-58-7	YQ32238-42-7	YQ32238-43-7
3	CUSHION	YQ32239-1-5	YQ32330	←	←	←
4	POLY BAG	YQM30061-2	←	YQM30061	←	←
△ 5	INSTRUCTIONS	YU30052-562 YU30052-563 YU30052-564 YU30052-565 YU30052-566	YU30052-543	YU30052-580 YU30052-581 YU30052-582	YU30052-545	←
7	CABLE ASSY,AV	PEAC0362-150	—	PEAC0362-150	←	←
14	REMOCON	YQ20710C	YQ20932A	YQ20710C	YQ20932A	←
15	WARRANTY CARD	—	BT-56001-1	—	—	—
16	SER. NET CARD	—	BT-56002-1	—	—	—
17	INST. SHEET	—	—	—	PU59932	—
18	CONVERSION PLUG	—	—	—	PEMC1012-02	—

FINAL ASSEMBLY <M2>

REF.NO.	ITEM \ MODEL	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX827EG(SH)
△ 101	LOWER CASE ASSY	YQ10575F	YQ10575G	←	←	←
△ 112	CASS. COVER ASSY	YQ10580H-3	YQ10580L-3	YQ10580H-3	YQ10580L-3	←
117	TOP COVER(ASSY)	YQ32302S	YQ20904-13	YQ20904-11	YQ20904-24	YQ20904-25

MECHANISM ASSEMBLY <M3>

REF.NO.	ITEM \ MODEL	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX827EG(SH)
468	DRUM ASSY	YDV2066A	YDV2065A	←	←	←
468A	UPPER DRUM ASSY	YDV2067B	YDV2067D	←	←	←

Notes : · Mark — is not used.
 · Mark ← is same as left.

The following table lists the different points between models [GR-AX460EG, GR-AX460EA, GR-AX460EE and GR-AX627EG(S)]
[GR-AX360EG and GR-AX827EG(SH)] in this series.

ELECTRONIC VIEWFINDER ASSEMBLY <M4>

REF.NO.	MODEL		AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
	ITEM							
—	E.VF ASSY	YQ32236C	←	←	←	YS20782R	←	
		YQ32237C	←	←	←			

MAIN BOARD ASSEMBLY <01>

REF.NO.	MODEL		AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
	ITEM							
PWBA	MAIN BOARD ASSY	YB10160J-01	YB10160K-01	←	←	YB10160I-01	YB10160O-01	
Q406	TRANSISTOR	—	DTC144EE	←	←	—	DTC144EE	
Q407	TRANSISTOR	—	DTC144EE	←	←	—	DTC144EE	
Q501	TRANSISTOR	—	DTC144EE	←	←	—	DTC144EE	
Q507	TRANSISTOR	—	DTC144EE	←	←	—	DTC144EE	
D501	DIODE	—	DAN222	←	←	—	DAN222	
D504	DIODE	—	—	—	—	DAN222	←	
D507	DIODE	—	DAN222	←	←	—	DAN222	
R60	RESISTOE	—	—	—	—	NRSA63J-103X	←	
R61	RESISTOE	NRSA63J-103X	←	←	←	NRSA63J-152X	←	
R62	RESISTOE	—	NRSA63J-103X	←	←	—	NRSA63J-103X	
R63	RESISTOE	NRSA63J-103X	—	—	—	NRSA63J-103X	—	
R407	RESISTOE	—	NRSA63J-153X	←	←	—	NRSA63J-153X	
R415	RESISTOE	NRSA63J-132X	—	—	—	NRSA63J-132X	—	
R416	RESISTOE	—	NRSA63J-132X	←	←	—	NRSA63J-132X	
R419	RESISTOE	—	NRSA63J-102X	←	←	—	NRSA63J-102X	
R423	RESISTOE	—	NRSA63J-682X	←	←	—	NRSA63J-682X	
R512	RESISTOE	—	NRSA63J-182X	←	←	—	NRSA63J-182X	
R513	RESISTOE	NRSA63J-182X	NRSA63J-102X	←	←	NRSA63J-182X	NRSA63J-102X	
R517	RESISTOE	—		←	←	—	NRSA63J-103X	
R519	RESISTOE	NRSA63J-102X	NRSA63J-222X	←	←	NRSA63J-102X	NRSA63J-222X	
R527	RESISTOE	NRSA63J-102X	←	←	←	NRSA63J-821X	←	
R530	RESISTOE	NRSA63J-102X	←	←	←	NRSA63J-821X	←	
R539	RESISTOE	—	NRSA63J-182X	←	←	—	NRSA63J-182X	
R541	RESISTOE	—	—	—	—	NRSA63J-103X	←	
R701	RESISTOE	NRSA63J-821X	NRSA63J-122X	←	←	NRSA63J-821X	NRSA63J-122X	
R722	RESISTOE	—	NRSA63J-822X	←	←	—	NRSA63J-822X	
R723	RESISTOE	—	NRSA63J-472X	←	←	—	NRSA63J-472X	
R731	RESISTOE	NRSA63J-821X	NRSA63J-681X	←	←	NRSA63J-821X	NRSA63J-681X	
R732	RESISTOE	NRSA63J-821X	NRSA63J-102X	←	←	NRSA63J-821X	NRSA63J-102X	
R733	RESISTOE	NRSA63J-222X	NRSA63J-332X	←	←	NRSA63J-222X	NRSA63J-332X	
C406	CAPACITOR	—	NCB31HK-152X	←	←	—	NCB31HK-152X	
C413	CAPACITOR	—	NCB31HK-332X	←	←	—	NCB31HK-332X	
C515	CAPACITOR	NDC31HJ-560X	NDC31HJ-101X	←	←	NDC31HJ-560X	NDC31HJ-101X	
C601	E CAPACITOR	NEA70JM-476X	NBE41AM-226X	←	←	NEA70JM-476X	NBE41AM-226X	
C639	CAPACITOR	NDC31HJ-560X	NDC31HJ-101X	←	←	NDC31HJ-560X	NDC31HJ-101X	
C640	CAPACITOR	NDC31HJ-221X	NDC31HJ-331X	←	←	NDC31HJ-221X	NDC31HJ-331X	
C719	CAPACITOR	NDC31HJ-680X	NDC31HJ-820X	←	←	NDC31HJ-680X	NDC31HJ-820X	
L605	COIL	YU41134-271JY	YU41134-221JY	←	←	YU41134-271JY	YU41134-221JY	

Notes : • Mark — is not used.
• Mark ← is same as left.

REAR BOARD ASSEMBLY <02>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA	REAR BOARD ASSY	YB20750F1-02	←	←	←	YB20750C1-02	YB20750J1-02
△CP5	CIRCUIT PROTECTOR	—	—	—	—	ICP-S0.5-X	←

E.VF BOARD ASSEMBLY <10>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA	E.VF BOARD ASSY	YB20748E-03	←	←	←	—	—

UPPER DRUM BOARD <40>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWB	BOARD(UPPER)	YDM3073-2-1	YDM3073-4	←	←	YDM3073-2-1	YDM3073-4

E.VF BOARD ASSEMBLY <50>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA	E.VF BOARD ASSY	YQ31803-600	←	←	←	—	—

PBL BOARD ASSEMBLY <51>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA1	PBL BOARD ASSY	—	—	—	—	YB20747B1-01	←

CLD BOARD ASSEMBLY <52>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA2	CLD BOARD ASSY	—	—	—	—	YB20747B2-01	←

BL BOARD ASSEMBLY <53>

REF.NO.	MODEL ITEM	AX460EG	AX460EA	AX460EE	AX627EG(S)	AX360EG	AX827EG(SH)
PWBA3	BL BOARD ASSY	—	—	—	—	YB20747B3-01	←



Notes : ・Mark — is not used.
 ・Mark ← is same as left.

SECTION 10

CHARTS AND





SECTION 4
AND DIAGRAMS



4.7 LINEAR AUDIO SCHEMATIC DIAGRAM

01 MAIN(LINEAR AUDIO)






[illegible]

P4-19,20,21-c

P4-19,20,21-d


4.8 PROCESS AND Y/C SCHEMATIC DIAGRAM





P4-39,40.5-1-a

P4-39,40.5-1-b




Technical drawing of a Printed Circuit Board (PCB) layout, labeled "CCD PWB". The board is oriented with a coordinate system (A, B, C) and a scale bar (1, 2).


Key components and labels visible on the board include:

- Resistors (R):** R201, R202, R203, R204, R205, R206, R207, R208, R209, R210, R211, R212, R213, R214, R215, R216, R217, R218, R219, R220, R221, R222, R223, R224, R225, R226, R227, R228, R229, R230, R231, R232, R233, R234, R235, R236, R237, R238, R239, R240, R241, R242, R243, R244, R245, R246, R247, R248, R249, R250, R251, R252, R253, R254, R255, R256, R257, R258, R259, R260, R261, R262, R263, R264, R265, R266, R267, R268, R269, R270, R271, R272, R273, R274, R275, R276, R277, R278, R279, R280, R281, R282, R283, R284, R285, R286, R287, R288, R289, R290, R291, R292, R293, R294, R295, R296, R297, R298, R299, R300.
- Capacitors (C):** C201, C202, C203, C204, C205, C206, C207, C208, C209, C210, C211, C212, C213, C214, C215, C216, C217, C218, C219, C220, C221, C222, C223, C224, C225, C226, C227, C228, C229, C230, C231, C232, C233, C234, C235, C236, C237, C238, C239, C240, C241, C242, C243, C244, C245, C246, C247, C248, C249, C250, C251, C252, C253, C254, C255, C256, C257, C258, C259, C260, C261, C262, C263, C264, C265, C266, C267, C268, C269, C270, C271, C272, C273, C274, C275, C276, C277, C278, C279, C280, C281, C282, C283, C284, C285, C286, C287, C288, C289, C290, C291, C292, C293, C294, C295, C296, C297, C298, C299, C300.
- Inductors (L):** L201, L202, L203, L204, L205, L206, L207, L208, L209, L210, L211, L212, L213, L214, L215, L216, L217, L218, L219, L220, L221, L222, L223, L224, L225, L226, L227, L228, L229, L230, L231, L232, L233, L234, L235, L236, L237, L238, L239, L240, L241, L242, L243, L244, L245, L246, L247, L248, L249, L250, L251, L252, L253, L254, L255, L256, L257, L258, L259, L260, L261, L262, L263, L264, L265, L266, L267, L268, L269, L270, L271, L272, L273, L274, L275, L276, L277, L278, L279, L280, L281, L282, L283, L284, L285, L286, L287, L288, L289, L290, L291, L292, L293, L294, L295, L296, L297, L298, L299, L300.
- Other components:** X201, CN201, CN202, CN203, CN204, CN205, CN206, CN207, CN208, CN209, CN210, CN211, CN212, CN213, CN214, CN215, CN216, CN217, CN218, CN219, CN220, CN221, CN222, CN223, CN224, CN225, CN226, CN227, CN228, CN229, CN230, CN231, CN232, CN233, CN234, CN235, CN236, CN237, CN238, CN239, CN240, CN241, CN242, CN243, CN244, CN245, CN246, CN247, CN248, CN249, CN250, CN251, CN252, CN253, CN254, CN255, CN256, CN257, CN258, CN259, CN260, CN261, CN262, CN263, CN264, CN265, CN266, CN267, CN268, CN269, CN270, CN271, CN272, CN273, CN274, CN275, CN276, CN277, CN278, CN279, CN280, CN281, CN282, CN283, CN284, CN285, CN286, CN287, CN288, CN289, CN290, CN291, CN292, CN293, CN294, CN295, CN296, CN297, CN298, CN299, CN300.

IC202	B	C	2B
IC203	B	C	2B
COIL			
L201	A	C	2A
L202	A	C	1A
L203	A	C	2A
L204	A	C	1B
L205	A	C	1B
L206	B	C	1B
L207	B	C	1B
L208	B	C	1B







#△ REF No. PART No. PART NAME, DESCRIPTION

PACKING ASSEMBLY <M1>

1	YQM30021-34	POLY BAG	
2	YQ32238-41-7	PACKING CASE,AX460EA	
	YQ32238-42-7	PACKING CASE,AX627EG(S)	
	YQ32238-43-7	PACKING CASE,AX827EG(SH)	
	YQ32238-58-7	PACKING CASE,AX460EE	
3	YQ32330	CUSHION	
4	YQM30061	POLY BAG,AX460EA	
	YQM30061-2	POLY BAG,AX460EE/AX627EG(S)/AX827EG(SH)	
5	YU30052-543	INSTRUCTIONS,EN AX460EA	
△	YU30052-545	INSTRUCTIONS,EN CH,RU AX627EG(S)/AX827EG(SH)	
△	YU30052-580	INSTRUCTIONS,EN AX460EE	
△	YU30052-581	INSTRUCTIONS,RU,CZ AX460EE	
△	YU30052-582	INSTRUCTIONS,PO,HU AX460EE	
6	PECA0903	LI BATTERY, X2	
7	PEAC0362-150	CABLE ASSY,AUDIO/VIDEO AX460EE/AX627EG(S)/AX827EG(SH)	
8	PEAC0428-150	CABLE ASSY,EDITING CABLE	
9	PEAC0134-01-04	DC PLUG CORD	
10	YQ10188A-1	S STRAP ASSY	
11	R6PRPA-B	BATTERY	
12	PEMC1174	CONNECTOR, CABLE ADAPTER	
13	YQ31963A-3	CASS,ADAPTER ASSY	
	or YQ31963B-3	CASS,ADAPTER ASSY	
14	YQ20710C	REMOTE CONTROLLER,AX460EE	
	YQ20932A	REMOTE CONTROLLER,AX460EA/AX627EG(S)/AX827EG(SH)	
15	BT-56001-1	WARRANTY CARD,AX460EA	
16	BT-56002-1	SER,NET CARD,AX460EA	
17	PU59932	INST,SHEET,AX627EG(S)	
18	PEMC1012-02	CONVERSION PLUG,AX627EG(S)	

INSTRUCTIONS
 EN ENGLISH
 CH CHINESE
 RU RUSSIAN
 CZ CZECH
 PO POLISH
 HU HANGARIAN

SECTION 5 PARTS LIST

SAFETY PRECAUTION

Parts identified by the  symbol are critical for safety. Replace only with specified part numbers.

5.1 PACKING ASSEMBLY <M1>

(AA-V11EA for AX460EA
AA-V11EG for AX460EE/
AX627EG(S)
AA-V11EK for AX827EG(SH))

