
## SECTION 4 CHARTS AND DIAGRAMS

## 4.1 BOARD INTERCONNECTIONS




Note 1: How to find the page showing the continuative schematic diagram


Example) TO AUDIO (Page 4-13): Refer to the GR-DVL200EG service manual (No. 86558)

TO SYSCON (Page 4-3): Refer to this service manual

2: The mark ★ means modified points.



## 4.2 SYSCON SCHEMATIC DIAGRAM



## 4.3 CAMERA DSP SCHEMATIC DIAGRAM

