

取扱説明書

ブラケット


KRB11-PAD

Part No. Z1-003-020, IA003093

Feb. 2008


次の手順で機器にブラケットを取付け、ラックに組み込みます。

1. 底部のキャスタ、および側面のねじを取り外します。




2. ③のねじを使用して①と②のブラケットを図のように取付けます。

③のねじは、付属のねじ (M4 x 14皿ねじ) 以外は使用しないでください。




3. ⑥のねじを使用して⑤のサポートアングルをラックのフレームへ取り付けます。

図のように④のプレートを一に貼り付けます。



4. ⑧のねじと⑦のワッシャを使用してラックに取り付けます。



NOTE

付属のサポートアングル (⑤) は、当社のラックKROシリーズ専用です。他のラックを使用する場合は、ラックに適合したサポートアングルを取り付けてください。

No.	コード	説 明	数量
1	B9-000-105	BRKT KRB11-PAD (R)	1
2	B9-000-106	BRKT KRB11-PAD (L)	1
3	M2-101-018	FLH SCREW S-NI M4X0.7X14	6
4	Q3-000-062	PHENOL PLATE T0.5X15X360 KRB SERIES	2
5	D4-988-701	RAIL FOR EXTRA WEIGHT	2
6	M3-112-041	DBL SEMS K-MARU PNH SCR S-NI M5X0.8X10	8
7	M5-003-031	CUP WASHER 5 CW	8
8	M2-102-002	OVH SCREW S-NI M5X0.8X14	8



菊水電子工業株式会社


本社・技術センター 〒224-0023 横浜市都筑区東山田 1-1-3 TEL: 045-593-0200 (代)

INSTRUCTION MANUAL


Bracket KRB11-PAD

Install the brackets to the instrument in the next procedure and build in it to the rack.


1. Remove the casters on the bottom panel and the screws on the side panel.




2. As shown in figure, using ③ screws, install ① and ② brackets.
For ③ screws, do not use except the accompanying screws (M4 x 14 flat head screws).



3. Using ⑥ screws, install ⑤ support angles to the frame of the rack.
As shown in figure, stick ④ plates on the rails.



4. Using ⑧ screws and ⑦ washers, mount the instrument in the rack.



NOTE

The accompanying support angles (⑤) have been exclusively designed for the KRO series, KIKUSUI rack system. If you use other rack system, install the appropriate support angles applying to its rack system.

No.	CODE	DESCRIPTION	QTY
1	B9-000-105	BRKT KRB11-PAD (R)	1
2	B9-000-106	BRKT KRB11-PAD (L)	1
3	M2-101-018	FLH SCREW S-NI M4X0.7X14	6
4	Q3-000-062	PHENOL PLATE T0.5X15X360 KRB SERIES	2
5	D4-988-701	RAIL FOR EXTRA WEIGHT	2
6	M3-112-041	DBL SEMS K-MARU PNH SCR S-NI M5X0.8X10	8
7	M5-003-031	CUP WASHER 5 CW	8
8	M2-102-002	OVH SCREW S-NI M5X0.8X14	8



KIKUSUI ELECTRONICS CORP.

1-1-3, Higashiyamata, Tsuzuki-ku, Yokohama, 244-0023, Japan