



Kurz-Kasch, Inc.


Electronics Division
Box 1246
1501 Webster Street
Dayton, Ohio 45401
Telephone (513)223-8161

Operating Instructions For Model

265ABC

SUPER BUG

ATARI



1. Insert the 265B card into the Program B connector, number side up.
2. Insert the 265A card into the Program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the Super Bug game board into the 265C card.
5. Connect a speaker to the speaker leads.
6. Slide the power switch to "ON"
7. Press:
 - COIN or SR-6 to coin game
 - SL-7 to select track
 - START to start game
 - START--2 to reset game
 - SR-7 to reset score
8.
 - SL-1 1st
 - SL-2 2nd
 - SL-3 3rd
 - SL-6 Gas
 - SL-5 Left
 - SR-5 Right