



---

***DF-635***

**PARTS LIST**

Published in Oct.'02  
5HC70770

## NOTE

1.Indicate parts number and machine model when placing an order.

|     |              |                   |               |       |          |
|-----|--------------|-------------------|---------------|-------|----------|
| eg. | Parts Number | Parts Name        | Machine Model | Cycle | Quantity |
|     | 5HC10010     | SHIFT MOTOR A'SSY | DF-635        | 60Hz  | 1        |

2.Service calls and freight will be charged separately.

## Parts List

***DF-635***

## — CONTENTS —

|        |                   |    |               |                   |    |
|--------|-------------------|----|---------------|-------------------|----|
| FIG.1  | DF-635 (1) .....  | 2  | FIG.16        | DF-635 (16) ..... | 32 |
| FIG.2  | DF-635 (2) .....  | 4  | FIG.17        | DF-635 (17) ..... | 34 |
| FIG.3  | DF-635 (3) .....  | 6  | FIG.18        | DF-635 (18) ..... | 36 |
| FIG.4  | DF-635 (4) .....  | 8  | FIG.19        | DF-635 (19) ..... | 38 |
| FIG.5  | DF-635 (5) .....  | 10 | FIG.20        | DF-635 (20) ..... | 40 |
| FIG.6  | DF-635 (6) .....  | 12 | FIG.21        | DF-635 (21) ..... | 42 |
| FIG.7  | DF-635 (7) .....  | 14 | FIG.22        | DF-635 (22) ..... | 44 |
| FIG.8  | DF-635 (8) .....  | 16 | FIG.23        | DF-635 (23) ..... | 46 |
| FIG.9  | DF-635 (9) .....  | 18 | FIG.24        | DF-635 (24) ..... | 48 |
| FIG.10 | DF-635 (10) ..... | 20 | FIG.25        | DF-635 (25) ..... | 50 |
| FIG.11 | DF-635 (11) ..... | 22 | FIG.26        | DF-635 (26) ..... | 52 |
| FIG.12 | DF-635 (12) ..... | 24 | FIG.27        | DF-635 (27) ..... | 54 |
| FIG.13 | DF-635 (13) ..... | 26 | FIG.28        | DF-635 (28) ..... | 56 |
| FIG.14 | DF-635 (14) ..... | 28 | FIG.29        | DF-635 (29) ..... | 58 |
| FIG.15 | DF-635 (15) ..... | 30 |               |                   |    |
|        |                   |    | • INDEX ..... |                   | 60 |




FIG. 1 DF-635 (1)

5HC

| Ref.No. | Parts No. | Description                 | Standard parts |
|---------|-----------|-----------------------------|----------------|
| 1       | 5HC10710  | PAPER EXIT TRAY/LOWER       | a-5A912150     |
| 2       | 5C511170  | STOPPER RUBBER              | b-5A912200     |
| 3       | 5A907640  | REGULATING SHAFT            | c-5C331630     |
| 4       | 5C510120  | PAPER EXIT PRESSURE PLATE   | d-5A807460     |
| 5       | 5HB10170  | PAPER EXIT SIDE PLATE/FRONT | e-5A807910     |
| 6       | 5HB10180  | PAPER EXIT SIDE PLATE/REAR  | f-5A809700     |
| 7       | 5C411660  | MAIN MOUNT PLATE/LOWER      | g-5HA50230     |
| 8       | 5HC10100  | CONTROL UNIT                | h-5A807450     |
| 9       | 5C410170  | CARRIAGE ROLLER/1           | i-5A912660     |
| 10      | 5A907270  | CARRIAGE ROLLER/R           | j-5A809690     |
| 11      | 5C410180  | ACTUATOR/1                  | k-5A808630     |
| 12      | 5C410160  | SLIDE RAIL/LEFT             | m-5A808640     |
| 13      | 5C410150  | SLIDE RAIL/RIGHT            | n-5A807490     |
| 14      | 5HA11390  | PHOTO SENSOR                | p-5A825670     |
| 15      | 5HC10230  | PROTECTION COVER/1          | q-5A808370     |
| 16      | 5A822060  | MAGNET CATCH                | r-5A912260     |
| 17      | 5HB11510  | ROM ASSEMBLY                | s-5A814230     |
| 18      | 5A909330  | NEUTRALIZING BRUSH          | t-5A811610     |
| 19      | 5C410110  | WIRING GUIDE ARM            | u-5A823610     |
| 20      | 5C511180  | LOCK LEVER                  | v-5A807930     |
| 21      | 5C511130  | ROLLER                      | w-5A810740     |
| 22      | 5C410140  | LOCK SPRING                 |                |
| 23      | 5HC10650  | PRESSURE ROLLER             |                |
| 24      | 5C511220  | CAM FOLLOWER SLIDE SCREW    |                |
| 25      | 5HB10070  | SENSOR PROTECT BLOCK        |                |
| 26      | 5A907091  | CONNECTING STAY             |                |
| 27      | 5D510310  | MAIN BODY FIXING PLATE/1    |                |
| 28      | 5A907221  | MAIN MT PLATE               |                |
| 29      | 5C411650  | MAIN MOUNT PLATE/UPPER      |                |
| 30      | 5HC10240  | PROTECTION COVER/2          |                |
| 31      | 5HC10690  | CAUTION LABEL/B             |                |




FIG. 2 DF-635 (2)

5HC

| Ref.No. | Parts No. | Description         | Standard parts |
|---------|-----------|---------------------|----------------|
| 1       | 5C511240  | PAPER EXIT TRAY/2   | a-5A807460     |
| 2       | 5C511230  | PAPER EXIT TRAY/1   | b-5C331630     |
| 3       | 5A808530  | MAGNET PLATE        | c-5C331390     |
| 4       | 5C510070  | SEAL                | d-5A808380     |
| 5       | 5HB11540  | CAUTION LABEL/A     | e-5A809280     |
| 7       | 5A808710  | SCREW COVER         | f-5A912180     |
| 8       | 5C510030  | UPPER PLATE         | g-5A912140     |
| 9       | 5C410230  | SIDE COVER/UPPER    | h-5A810200     |
| 10      | 5A813710  | MAGNET CATCH        |                |
| 11      | 5A823820  | STICK MATERIAL      |                |
| 12      | 5C410240  | SIDE COVER/RIGHT    |                |
| 13      | 5C410250  | SIDE COVER/LEFT     |                |
| 14      | 5C410260  | HINGE PLATE/UPPER   |                |
| 15      | 5HC10140  | JAM HANDLING LABEL  |                |
| 16      | 5C510050  | SIDE COVER /FRONT   |                |
| 17      | 5C410270  | HINGE PLATE/LOWER   |                |
| 18      | 5HB10870  | HANDLE              |                |
| 19      | 5A907720  | ACTUATOR            |                |
| 20      | 5HB10880  | FRONT DOOR ASSEMBLY |                |
| 21      | 5HB11530  | CAUTION LABEL/C     |                |




FIG. 3 DF-635 (3)

5HC

| Ref.No. | Parts No. | Description                 | Standard parts |
|---------|-----------|-----------------------------|----------------|
| 1       | 5A907131  | SLIDE STAY/A                | a-5A807460     |
| 2       | 5HA11390  | PHOTO SENSOR                | b-5HA50050     |
| 3       | 5C411630  | SPEWING PV PAD              | c-5A808630     |
| 4       | 5A907330  | DRIVEN SHAFT HOLDER         | d-5A808370     |
| 5       | 5A907340  | SUPPORT PLATE/A             | e-5A807450     |
| 6       | 5C410100  | PAPER EXIT UP-DOWN ACTUATOR | f-5A912250     |
| 7       | 5HB10100  | REAR MOUNTING PLATE         | g-5C331390     |
| 8       | 5A808200  | KEY COUNTER LID             | h-5A809700     |
| 9       | 5C510060  | REAR COVER                  | i-5C331520     |
| 10      | 5A808170  | EXTERNAL AUX PANEL          | j-5HA50520     |
| 11      | 5HA10440  | MAIN BODY FAN MOTOR         | k-5A912110     |
| 12      | 5C710620  | INTER LOCK SWITCH           | m-5A912160     |
| 13      | 5C511100  | SWITCH INSULATING SHEET     |                |
| 14      | 5BA08000  | ACTUATOR                    |                |
| 15      | 5A907150  | COVER                       |                |
| 16      | 5C411370  | FNS WIRING/D                |                |




FIG. 4 DF-635 (4)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5HB11190  | CONVEYANCE GUIDE PLATE/3          | a-5A808640     |
| 2       | 5HB11150  | PAPER EXIT GUIDE PLATE/A          | b-5A807450     |
| 3       | 5C410950  | CONVEYANCE DRIVING ROLLER/A       | c-5A808630     |
| 4       | 5C411250  | BELT/E(L=222)                     | d-5A808640     |
| 5       | 5C411040  | CONVEYANCE PRESSURE SPRING        | e-5A807440     |
| 6       | 5HB11180  | CONVEYANCE GUIDE PLATE/2          | f-5C331570     |
| 7       | 5C511090  | DOUBLE FEED FIXED COLLAR          | g-5HA50360     |
| 8       | 5A908030  | STOPPER RUBBER                    |                |
| 9       | 5C411100  | TENSION SHAFT HOLDER              |                |
| 10      | 5C511210  | DRIVING PULLEY/B(Z=24)            |                |
| 11      | 5A824740  | PIN(A)(2X12)                      |                |
| 12      | 5HA11390  | PHOTO SENSOR                      |                |
| 13      | 5C319220  | BALL BEARING(B)                   |                |
| 14      | 5C411000  | OPEN-CLOSE/2                      |                |
| 15      | 5A908160  | ENTRANCE ROLLER                   |                |
| 16      | 5A908490  | CONVEYANCE PRESSURE SHAFT/B ASS'Y |                |
| 17      | 5HB10130  | CONVEYANCE PRESSING SPRING/2      |                |
| 18      | 5HB11170  | CONVEYANCE GUIDE PLATE/1          |                |
| 19      | 5HB11160  | PAPER EXIT GUIDE PLATE/C          |                |
| 20      | 5A816830  | STEPPED SCREW(M3X4)               |                |
| 21      | 5C710710  | OPEN-CLOSE LEVER                  |                |
| 22      | 5C410990  | OPEN-CLOSE LEVER/1                |                |




FIG. 5 DF-635 (5)

5HC

| Ref.No. | Parts No. | Description                    | Standard parts |
|---------|-----------|--------------------------------|----------------|
| 1       | 5HA11390  | PHOTO SENSOR                   | a-5HA50220     |
| 2       | 5HB11260  | EXIT SENSOR ASSEMBLY           | b-5HA50360     |
| 3       | 5HB11480  | FNS WIRING/B                   | c-5A818080     |
| 4       | 5HB11210  | PAPER EXIT GUIDE PLATE/D       | d-5A807440     |
| 5       | 5HB10160  | PAPER EXIT DETECTING ACTUATOR  | e-5A808630     |
| 6       | 5HB10240  | SENSOR MOUNTING PLATE ASSEMBLY | f-5A817290     |
| 7       | 5HB11200  | PAPER EXIT COVER ASSEMBLY      | g-5A809690     |
| 8       | 5A823820  | STICK MATERIAL                 | h-5A808640     |
| 9       | 5A907620  | SHAFT/LOWER                    | i-5A808380     |
| 10      | 5A818950  | PAPER EXIT DRIVEN ROLLER (B)   | j-5A807450     |
| 11      | 5A909330  | NEUTRALIZING BLUSH             |                |
| 12      | 5C410980  | EARTH PLATE                    |                |
| 13      | 5C410970  | NEUTRALIZING PLATE             |                |
| 14      | 5HB11220  | GUIDE SHEET                    |                |
| 15      | 5HB10200  | PAPER EXIT PRESSING PLATE/1    |                |
| 16      | 5HB10210  | PAPER EXIT PRESSING PLATE/2    |                |
| 17      | 5A909160  | SOLENOID ASS'Y                 |                |
| 18      | 5HB10190  | PAPER EXIT PRESSING LEVER      |                |
| 19      | 5C319220  | BALL BEARING(B)                |                |
| 20      | 5HC10050  | PAPER EXIT ROLLER/B            |                |
| 21      | 5HB10220  | PAPER EXIT ROLLER/A            |                |
| 22      | 5HB10230  | SOLENOID ASSEMBLY              |                |
| 23      | 5HB11390  | DRIVE PULLEY/A                 |                |
| 24      | 5HB11460  | PAPER EXIT DRIVING BELT/C      |                |
| 25      | 5HB10310  | BELT HOLDER                    |                |
| 26      | 5C511210  | DRIVING PULLEY/B(Z=24)         |                |
| 27      | 5C411250  | BELT/E(L=222)                  |                |
| 28      | 5A820190  | ADU CONVEYANCE SHAFT HOLDER    |                |
| 29      | 5HB10250  | PAPER EXIT DRIVING PULLEY/C    |                |




FIG. 6 DF-635 (6)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5C319220  | BALL BEARING(B)                   | a-5A808640     |
| 2       | 5HB11350  | DETECTING SENSOR/2                | b-5A807490     |
| 3       | 5HC10040  | CONVEYANCE ROLLER/C               | c-5A812850     |
| 4       | 5HB11100  | CONVEYING ROLLER/B                | d-5A807440     |
| 5       | 5C410790  | CONVEYANCE PRESSURE SPRING        | e-5A809280     |
| 6       | 5A825890  | MAGNET CATCH                      | f-5A807450     |
| 7       | 5C410850  | HINGE SPRING/C                    | g-5A809690     |
| 8       | 5C410860  | HINGE SPRING/D                    | h-5A912170     |
| 9       | 5A908450  | RELEASE LEVER KNOB                | i-5A814200     |
| 10      | 5A811720  | PAPER FEED DELIVERY SHAFT HOLDER  | j-5C331800     |
| 11      | 5C511140  | RELEASE KNOB                      | k-5C331630     |
| 12      | 5A908160  | ENTRANCE ROLLER                   |                |
| 13      | 5HB11040  | CONVEYANCE GUIDE PLATE/B          |                |
| 14      | 5A908490  | CONVEYANCE PRESSURE SHAFT/B ASS'Y |                |
| 15      | 5C410810  | PAPER GUIDE PART                  |                |
| 16      | 5HB11030  | CONVEYANCE GUIDE/A                |                |
| 17      | 5A908030  | STOPPER RUBBER                    |                |
| 18      | 5HB11090  | CONVEYING ROLLER/A                |                |
| 19      | 5HA11390  | PHOTO SENSOR                      |                |
| 20      | 5A908590  | SOLENOID SPRING                   |                |




FIG. 7 DF-635 (7)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5A908450  | RELEASE LEVER KNOB                | a-5A818080     |
| 2       | 5C410820  | PRESSURE RUBBER                   | b-5A807450     |
| 3       | 5A813710  | MAGNET CATCH                      | c-5A809690     |
| 4       | 5HB11120  | CONVEYANCE DRIVING PLATE          | d-5A912170     |
| 5       | 5HB11020  | CONVEYANCE PRESSING SPRING/1      | e-5A808640     |
| 6       | 5HB11340  | DRIVEN ROLLER/B                   | f-5A807490     |
| 7       | 5A908030  | STOPPER RUBBER                    | g-5A812850     |
| 8       | 5HB11060  | CONVEYANCE GUIDE PLATE/D          | h-5A807440     |
| 9       | 5HB11350  | DETECTING SENSOR/2                | i-5A809280     |
| 10      | 5C511280  | SENSOR COVER                      | j-5A814200     |
| 11      | 5HA11390  | PHOTO SENSOR                      |                |
| 12      | 5HB11080  | CONVEYANCE GUIDE PLATE            |                |
| 13      | 5A908830  | HINGE SPRING/A                    |                |
| 14      | 5HB10110  | HINGE SPRING/B                    |                |
| 15      | 5HB11070  | CONVEYANCE GUIDE PLATE/E          |                |
| 16      | 5HB11050  | CONVEYANCE GUIDE PLATE/C          |                |
| 17      | 5A908970  | SOLENOID SPRING                   |                |
| 18      | 5A908960  | GUIDE SHAFT/A                     |                |
| 19      | 5A908980  | GUIDE SHAFT/B                     |                |
| 20      | 5A908490  | CONVEYANCE PRESSURE SHAFT/B ASS'Y |                |
| 21      | 5HB10120  | CONVEYANCE GUIDE SHEET/B          |                |
| 22      | 5A811720  | PAPER FEED DELIVERY SHAFT HOLDER  |                |
| 23      | 5C319220  | BALL BEARING(B)                   |                |
| 24      | 5HB11130  | CONVEYANCE ROLLER/C               |                |
| 25      | 5A908430  | CONVEYANCE PRESSURE SPRING        |                |
| 26      | 5HC10110  | CONVEYANCE CLEANING BRUSH         |                |




FIG. 8 DF-635 (8)

5HC

| Ref.No. | Parts No. | Description                   | Standard parts |
|---------|-----------|-------------------------------|----------------|
| 1       | 5A909760  | SLIDE SHAFT                   | a-5A807490     |
| 2       | 5A909770  | ROLLER                        | b-5A809800     |
| 3       | 5C411610  | SLIDE STOPPER/A               | c-5A816190     |
| 4       | 5A909800  | UP-DOWN STAY                  | d-5A815170     |
| 5       | 5A909820  | UP-DOWN COVER/R               | e-5A807460     |
| 6       | 5A909840  | UP-DOWN COVER/F               | f-5A816190     |
| 7       | 5C510010  | PAPER EXIT UP-DOWN TRAY/1     | g-5A809280     |
| 8       | 5C510020  | PAPER EXIT UP-DOWN TRAY/2     | h-5A807450     |
| 9       | 5C410050  | PAPER EXIT REINFORCING STAY   | i-5A811610     |
| 10      | 5C330980  | DRIVING SLIDE SHAFT HOLDER(A) | j-5A808370     |
| 11      | 5A910020  | UP-DOWN GEAR/C(Z=30)          | k-5HA50380     |
| 12      | 5HB10150  | PAPER EXIT STOPPER SHEET/2    |                |
| 13      | 5A909910  | TENSION PULLEY                |                |
| 14      | 5A909920  | TENSION PLATE ASS'Y           |                |
| 15      | 5C410120  | UP-DOWN WIRE/R                |                |
| 16      | 5C410130  | UP-DOWN WIRE/F                |                |
| 17      | 5C410090  | AUXILIARY PLATE               |                |
| 18      | 5A909330  | NEUTRALIZING BLUSH            |                |
| 19      | 5A811470  | METAL                         |                |
| 20      | 5A909970  | UP-DOWN GEAR/A(Z=44,21)       |                |
| 21      | 5A909980  | UP-DOWN GEAR/B(Z=52,15)       |                |
| 22      | 5C410210  | MOTOR ASSEMBLY                |                |
| 23      | 5A910000  | UP-DOWN PULLEY                |                |
| 24      | 5HB10140  | PAPER EXIT STOPPER SHEET/1    |                |




FIG. 9 DF-635 (9)

5HC

| Ref.No. | Parts No. | Description                      | Standard parts |
|---------|-----------|----------------------------------|----------------|
| 1       | 5HC10010  | SHIFT MOTOR A'SSY                | a-5A809700     |
| 2       | 5HB10090  | DRIVE GEAR/E(Z=30)               | b-5A808640     |
| 3       | 5HA11390  | PHOTO SENSOR                     | c-5A808630     |
| 4       | 5A908080  | SHAFT HOLDER/A                   | d-5A912260     |
| 5       | 5A907940  | EDGE SADDLE                      | e-5A812850     |
| 6       | 5C410020  | GUIDE PLATE                      | f-5A807450     |
| 7       | 5A818490  | PAPER LIFT UP LEVER SHAFT HOLDER | g-5A807440     |
| 8       | 5HB10260  | SLIDE GEAR/D(Z=34/72)            | h-5A807490     |
| 9       | 5C410070  | SLIDE GEAR/B(Z=100)              | i-5A810180     |
| 10      | 5A907990  | SLIDE ARM                        | j-5A809280     |
| 11      | 5A908430  | CONVEYANCE PRESSURE SPRING       | k-5A912130     |
| 12      | 5A908120  | STOPPER SHEET                    | m-5HA50370     |
| 13      | 5HB10080  | CONVEYANCE SLIDE SHAFT           |                |
| 14      | 5A910910  | CONVEYANCE PRESSURE SHAFT ASSY   |                |
| 15      | 5A908040  | ROLLER                           |                |
| 16      | 5HB10270  | SLIDE GEAR/E(Z=62/100)           |                |
| 17      | 5HB11140  | SLIDE PLATE/LOWER                |                |
| 18      | 5A908160  | ENTRANCE ROLLER                  |                |




FIG. 10 DF-635 (10)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5HB10940  | SOLENOID ASSEMBLY                 | a-5A807450     |
| 2       | 5HB10920  | PAPER EXIT ASSEMBLY               | b-5A912170     |
| 3       | 5HB11230  | SOLENOID MOUNTING PLATE           | c-5A809690     |
| 4       | 5HB11250  | SOLENOID SPRING                   | d-5A808640     |
| 5       | 5HB11240  | SOLENOID LEVER                    | e-5A810180     |
| 6       | 5A811470  | METAL                             | f-5A809280     |
| 7       | 5A907990  | SLIDE ARM                         | g-5A807500     |
| 8       | 5A823820  | STICK MATERIAL                    | h-5A808380     |
| 9       | 5A815900  | PIN(B)(3X14)                      | i-5A807490     |
| 10      | 5A909250  | PAPER EXIT CONVEYANCE SHAFT       | j-5A811550     |
| 11      | 5A909260  | PAPER EXIT SUPPORT SHAFT          |                |
| 12      | 5A909270  | PAPER EXIT ROLLER                 |                |
| 13      | 5A909620  | PAPER EXIT GUIDE STAY/B           |                |
| 14      | 5A909280  | ROTARY STOPPER                    |                |
| 15      | 5A818490  | PAPER LIFT UP LEVER SHAFT HOLDER  |                |
| 16      | 5A909300  | SHAFT HOLDER                      |                |
| 17      | 5A909310  | PAPER EXIT PRESSURE SPRING        |                |
| 18      | 5A909320  | PAPER EXIT GUIDE STAY             |                |
| 19      | 5A909330  | NEUTRALIZING BLUSH                |                |
| 20      | 5HB11280  | STOPPER PAD/1                     |                |
| 21      | 5A909350  | PAPER EXIT GUIDE SHEET            |                |
| 22      | 5HB11290  | STOPPER PAD/2                     |                |
| 23      | 5HB11270  | STOPPER                           |                |
| 24      | 5HA11390  | PHOTO SENSOR                      |                |
| 25      | 5HB10950  | SENSOR COVER ASSEMBLY             |                |
| 26      | 5HB10930  | PAPER GUIDE PLATE/MIDDLE ASSEMBLY |                |




FIG. 11 DF-635 (11)

5HC

| Ref.No. | Parts No. | Description                      | Standard parts |
|---------|-----------|----------------------------------|----------------|
| 1       | 5HB11520  | SENSOR STOPPER PART              | a-5A807490     |
| 2       | 5A811720  | PAPER FEED DELIVERY SHAFT HOLDER | b-5BA08980     |
| 3       | 5HB11300  | PAPER EXIT DRIVING SHAFT         | c-5BA08320     |
| 4       | 5A909420  | PAPER EXIT ROLLER                | d-5A809320     |
| 5       | 5HB11310  | PAPER EXIT GUIDE PLATE           | e-5A807450     |
| 6       | 5A909440  | ROTARY DISK ASS'Y                | f-5A808640     |
| 7       | 5A909461  | PAPER EXIT PULLEY/A(Z=26)        | g-5A815180     |
| 8       | 5C511290  | PAPER FEED DRIVING MOTOR         |                |
| 9       | 5A909480  | MOTOR PULLEY(Z=16)               |                |
| 10      | 5A909490  | BELT/B(L=192)                    |                |
| 11      | 5C411260  | BELT/F(L=315)                    |                |
| 12      | 5A909510  | SHAFT HOLDER                     |                |
| 13      | 5A811470  | METAL                            |                |
| 14      | 5A908190  | DRIVING PULLEY/A                 |                |
| 15      | 5A909560  | PAPER EXIT PULLEY/B(Z=40,52,26)  |                |
| 16      | 5A909570  | COLLAR/A                         |                |
| 17      | 5A909580  | PAPER EXIT SPRING                |                |
| 18      | 5C319220  | BALL BEARING(B)                  |                |
| 19      | 5HB10980  | PAPER EXIT GUIDE SHEET           |                |
| 20      | 5HB11110  | PAPER EXIT GUIDE PLATE/UPPER     |                |




FIG. 12 DF-635 (12)

5HC

| Ref.No. | Parts No. | Description                        | Standard parts |
|---------|-----------|------------------------------------|----------------|
| 1       | 5HC10060  | CONVEYANCE MOTOR A'SSY             | a-5A807490     |
| 2       | 5C319380  | SHAFT HOLDER                       | b-5A807460     |
| 3       | 5HB11440  | BELT/A(L=315)                      | c-5A808640     |
| 4       | 5C319220  | BALL BEARING(B)                    | d-5HA50280     |
| 5       | 5C411160  | SLIDE GEAR/A(Z=100)                | e-5A808630     |
| 6       | 5HB11380  | CONVEYANCE DRIVING PULLEY(Z=24/51) | f-5A807440     |
| 7       | 5HB11450  | BELT/B(L=558)                      | g-5A818680     |
| 8       | 5A910360  | PAPER EXIT GEAR(Z=100,20)          | h-5A809690     |
| 9       | 5HB11370  | BASE PLATE SUPPORT RUBBER          | i-5A809700     |
| 10      | 5A910380  | DRIVING PULLEY/D(Z=30,24)          | j-5HA50370     |
| 11      | 5HB10960  | GEAR /E(Z=20)                      | k-5A809310     |
| 12      | 5HC10070  | ROLLING BEARING                    | m-5A912260     |
| 13      | 5HB11360  | SLEEVE                             | n-5HA50510     |
| 14      | 5HA11390  | PHOTO SENSOR                       | p-5A912120     |
| 15      | 5C411200  | DRIVE CONNECTING GEAR(Z=18)        | q-5HA50270     |
| 16      | 5HB11550  | PAPER PULLEY                       | r-5C331650     |
| 17      | 5HB10910  | TENSION ROLLER/A                   |                |
| 18      | 5C411300  | PAPER EXIT DRIVING BELT/B(L=267)   |                |
| 19      | 5A909540  | BELT/E(L=180)                      |                |
| 20      | 5A909570  | COLLAR/A                           |                |
| 21      | 5A909510  | SHAFT HOLDER                       |                |
| 22      | 5C411150  | DRIVING PULLEY/A(Z=40/24)          |                |
| 23      | 5A907900  | SHIFT MOTOR ASS'Y                  |                |
| 24      | 5HB10900  | BELT TENSION ROLLER                |                |
| 25      | 5HB10280  | SHAFT HOLDER/2                     |                |




FIG. 13 DF-635 (13)

5HC

| Ref.No. | Parts No. | Description                      | Standard parts |
|---------|-----------|----------------------------------|----------------|
| 1       | 5HB11400  | DRIVE PULLEY/C(Z=24)             | a-5A807490     |
| 2       | 5C319220  | BALL BEARING(B)                  | b-5A810180     |
| 3       | 5C511160  | DRIVING PULLEY/C(Z=30/24)        | c-5A807450     |
| 4       | 5A908190  | DRIVING PULLEY/A                 | d-5A811610     |
| 5       | 5C411230  | BELT/D(L=228)                    |                |
| 6       | 5C411240  | BELT/C(L=207)                    |                |
| 7       | 5C510080  | BELT TENSION SPRING              |                |
| 8       | 5A823820  | STICK MATERIAL                   |                |
| 9       | 5A910240  | SPRING                           |                |
| 10      | 5A908220  | FNS SOLENOID ASS'Y               |                |
| 11      | 5C319380  | SHAFT HOLDER                     |                |
| 12      | 5HB11450  | BELT/B(L=558)                    |                |
| 13      | 5C411300  | PAPER EXIT DRIVING BELT/B(L=267) |                |
| 14      | 5A908200  | SOLENOIDE LEVER                  |                |
| 15      | 5A909570  | COLLAR/A                         |                |
| 16      | 5HB11430  | IDLING GEAR(Z=24)                |                |




FIG. 14 DF-635 (14)

5HC

| Ref.No. | Parts No. | Description           | Standard parts |
|---------|-----------|-----------------------|----------------|
| 1       | 5C410390  | CARTRIDGE GUIDE RAIL  | a-5C331630     |
| 2       | 5HC10750  | STAPLE HANDLING LABEL | b-5A808630     |
| 3       | 5C410330  | WIRING ROTARY PLATE/2 | c-5A811550     |
| 4       | 5C410620  | CARRIAGE COVER/LEFT   | d-5A912660     |
| 5       | 5C410311  | SHAFT SUPPORT PLATE/C | e-5A807460     |
| 6       | 5A822121  | KNOB                  | f-5A808350     |
| 7       | 5C511190  | LOCK CAM              | g-5A809800     |
| 8       | 5C410290  | PANEL/REAR            |                |
| 9       | 5C410300  | SHAFT SUPPORT PLATE/B |                |
| 10      | 5C411440  | RELAY BOARD ASSEMBLY  |                |
| 11      | 5C410600  | CARRIAGE COVER/UPPER  |                |
| 12      | 5HC10280  | BELT FIXING BLOCK     |                |
| 13      | 5C410440  | STAPLE ROTARY ROLLER  |                |




FIG. 15 DF-635 (15)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5HB11010  | GUIDE PLATE/3                     | a-5A807490     |
| 2       | 5A910790  | BELT HOLDER                       | b-5A810180     |
| 3       | 5A910810  | BELT DRIVING PULLEY(Z=18)         | c-5A809690     |
| 4       | 5A811470  | METAL                             | d-5A808630     |
| 5       | 5HB11500  | FNS WIRING/G                      | e-5A809700     |
| 6       | 5A815900  | PIN(B)(3X14)                      | f-5A912170     |
| 7       | 5C411070  | PAPER REGULATING PLATE/1 COMBINED | g-5A807450     |
| 8       | 5A908120  | STOPPER SHEET                     | h-5A808640     |
| 9       | 5HA11390  | PHOTO SENSOR                      | i-5A810700     |
| 10      | 5C411320  | FNS CORRECTION MOTOR              | j-5A807430     |
| 11      | 5HB11420  | COUPLING GEAR(Z=18)               | k-5HA50370     |
| 12      | 5A910720  | BELT DETECTING GEAR(Z=102)        |                |
| 13      | 5A910730  | BELT DETECTING SCREW              |                |
| 14      | 5HC10590  | PAPER EXIT BELT(L=518.16)         |                |
| 15      | 5A823820  | STICKING PART                     |                |
| 16      | 5A910830  | BELT/A(L=752)                     |                |
| 17      | 5A910840  | BELT HOLDER/B                     |                |
| 18      | 5A910820  | REGULATION GEAR/S(Z=55,28)        |                |
| 19      | 5HB10710  | PRESSURE SPRING                   |                |
| 20      | 5HB10950  | SENSOR COVER ASSEMBLY             |                |
| 21      | 5HB10970  | NEUTRALIZING BRUSH                |                |
| 22      | 5HB10990  | GUIDE PLATE/1                     |                |
| 23      | 5HB11320  | GUIDE PLATE/2                     |                |
| 24      | 5HC10360  | REGULATING PLATE/REAR ASSEMBLY    |                |
| 25      | 5A910750  | ROCKING BLOCK ASS'Y               |                |
| 26      | 5HC10350  | REGULATING PLATE/FRONT ASSEMBLY   |                |
| 27      | 5A910760  | BELT HOLDER PLATE                 |                |
| 28      | 5A910850  | IDLER PULLEY(Z=28)                |                |
| 29      | 5HB10700  | PAPER DETECTING ACTUATOR          |                |




FIG. 16 DF-635 (16)

5HC

| Ref.No. | Parts No. | Description                    | Standard parts |
|---------|-----------|--------------------------------|----------------|
| 1       | 5A911040  | BELT HOLDER/B                  | a-5A807490     |
| 2       | 5A911050  | ENTRANCE GUIDE PULLEY/A        | b-5HA50100     |
| 3       | 5HC10540  | ENTRANCE GUIDE PULLEY/A(Z=34)  | c-5HA50370     |
| 4       | 5A823820  | STICK MATERIAL                 | d-5A811550     |
| 5       | 5HC10030  | DRIVING ROLLER                 | e-5A812850     |
| 6       | 5HC10660  | ENTRANCE GUIDE PULLEY/B(Z=31)  | f-5A807440     |
| 7       | 5HC10250  | COLLAR/C                       | g-5A807450     |
| 8       | 5A811470  | METAL                          | h-5A808640     |
| 9       | 5C410470  | SHAFT HOLDER MOUNT OLATE       | i-5A807460     |
| 10      | 5HC10620  | BELT/H(L=120)                  | j-5HA50360     |
| 11      | 5HB11000  | REGULATING BELT/1              |                |
| 12      | 5C410570  | BELT MOUNT ROLLER              |                |
| 13      | 5C410590  | REGULATING BELT/2              |                |
| 14      | 5HC10290  | CONVEYANCE GUIDE PLATE         |                |
| 15      | 5HC10310  | PAPER EXIT GUIDE SHEET         |                |
| 16      | 5HC10700  | DRIVING ROLLER                 |                |
| 17      | 5A911180  | BELT/J(L=159)                  |                |
| 18      | 5C410560  | OSCILLATE PULLEY/1(Z=20)       |                |
| 19      | 5A909540  | BELT/E(L=180)                  |                |
| 20      | 5HB11410  | MOTOR PULLEY(Z=18)             |                |
| 21      | 5C410680  | CONVEYANCE GUIDE SHEET/2       |                |
| 22      | 5A811870  | PIN (2X8)                      |                |
| 23      | 5HB10300  | DRIVING MOTOR ASSEMBLY         |                |
| 24      | 5A908190  | DRIVING PULLEY/A               |                |
| 25      | 5C411420  | FNS WIRING/I                   |                |
| 26      | 5A910910  | CONVEYANCE PRESSURE SHAFT ASSY |                |
| 27      | 5A909060  | CONVEYANCE ROLLER              |                |
| 28      | 5A908430  | CONVEYANCE PRESSURE SPRING     |                |
| 29      | 5A909330  | NEUTRALIZING BRUSH             |                |
| 30      | 5HB11330  | CONVEYANCE GUIDE PLATE/A       |                |

FIG. 17 DF-635 (17)

5HC




FIG. 17 DF-635 (17)

5HC

| Ref.No. | Parts No. | Description                     | Standard parts |
|---------|-----------|---------------------------------|----------------|
| 1       | 5C411470  | CARTRIDGE CASE(FS108BM)         | a-5A807450     |
| 2       | 5C410320  | STAPLE SLIDE SHAFT HOLDER       | b-5A811560     |
| 3       | 5A911760  | STAPLES                         | c-5A808640     |
| 4       | 5A911800  | IDLER SHAFT                     | d-5A810240     |
| 5       | 5A908040  | ROLLER                          | e-5A808380     |
| 6       | 5C410400  | LOCK BLOCK                      | f-5C331680     |
| 7       | 5HC10510  | FIXING BLOCK                    | g-5A807460     |
| 8       | 5HC10600  | BELT/H(L=972)                   | h-5A808630     |
| 9       | 5C410410  | LOCK SPRING                     | i-5A815180     |
| 10      | 5C410370  | TOPPER SPRING                   |                |
| 11      | 5C410520  | STOPPER BOTTOM PLATE/FRONT      |                |
| 12      | 5C410640  | CONVEYANCE GUIDE SHEET/1        |                |
| 13      | 5C410420  | LOCK PIN(D8)                    |                |
| 14      | 5HC10190  | PRESSURE STOPPER/FRONT COMBINED |                |
| 15      | 5C410530  | STOPPER BOTTOM PLATE/REAR       |                |
| 16      | 5HC10180  | PRESSURE STOPPER/REAR COMBINED  |                |
| 17      | 5C410650  | SLIDE SHEET/1                   |                |
| 18      | 5C410660  | SLIDE SHEET/2                   |                |
| 19      | 5HC10020  | STAPLE MAIN BODY                |                |
| 20      | 5C511060  | ADF PRESSURE PART               |                |
| 21      | 5HB10410  | ROTARY ROLLER                   |                |
| 22      | 5HC10120  | STAPLE SLIDE PLATE/A            |                |
| 23      | 5HC10130  | STAPLE SLIDE PLATE/B            |                |




FIG. 18 DF-635 (18)

5HC

| Ref.No. | Parts No. | Description               | Standard parts |
|---------|-----------|---------------------------|----------------|
| 1       | 5C410650  | SLIDE SHEET/1             | a-5A807450     |
| 2       | 5HC10510  | FIXING BLOCK              | b-5A811560     |
| 3       | 5HC10600  | BELT/H(L=972)             | c-5A808640     |
| 4       | 5C410400  | LOCK BLOCK                | d-5A810240     |
| 5       | 5C410320  | STAPLE SLIDE SHAFT HOLDER | e-5A808380     |
| 6       | 5HC10260  | STAPLE GUIDE PLATE/FRONT  | f-5A809700     |
| 7       | 5C410500  | WIRING REGULATING PLATE   | g-5C331680     |
| 8       | 5C410610  | STAPLE COVER              | h-5A807440     |
| 9       | 5A911800  | IDLER SHAFT               | i-5A807460     |
| 10      | 5A908040  | ROLLER                    | j-5A807940     |
| 11      | 5C410420  | LOCK PIN(D8)              | k-5A808630     |
| 12      | 5C410410  | LOCK SPRING               | m-5A811550     |
| 13      | 5C410660  | SLIDE SHEET/2             | n-5A815180     |
| 14      | 5C511060  | ADF PRESSURE PART         |                |
| 15      | 5HA11390  | PHOTO SENSOR              |                |
| 16      | 5HC10270  | STAPLE GUIDE PLATE/REAR   |                |
| 17      | 5HC10020  | STAPLE MAIN BODY          |                |
| 18      | 5C411470  | CARTRIDGE CASE(FS108BM)   |                |
| 19      | 5A911760  | STAPLES                   |                |
| 20      | 5C410440  | STAPLE ROTARY ROLLER      |                |




FIG. 19 DF-635 (19)

5HC

| Ref.No. | Parts No. | Description                  | Standard parts |
|---------|-----------|------------------------------|----------------|
| 1       | 5HC10720  | IDLING PULLEY(Z=16)          | a-5A807490     |
| 2       | 5A910840  | BELT HOLDER/B                | b-5A811530     |
| 3       | 5HC10600  | BELT/H(L=972)                | c-5A813080     |
| 4       | 5HC10520  | DRIVING SHAFT/A ASSEMBLY     | d-5A808640     |
| 5       | 5C330850  | PAPER FEED SHAFT HOLDER      | e-5A810700     |
| 6       | 5A911500  | STAPLE DRIVING GEAR(Z=51,21) | f-5A823610     |
| 7       | 5C411330  | CORRECTION MORTOR            |                |
| 8       | 5HC10610  | BELT/I(L=642)                |                |
| 9       | 5HC10580  | REGULATING GEAR/S(Z=16)      |                |
| 10      | 5HC10530  | DRIVING SHAFT/B ASSEMBLY     |                |
| 11      | 5HC10500  | TENSION PLATE/2 ASSEMBLY     |                |
| 12      | 5HC10490  | TENSION PLATE/1 ASSEMBLY     |                |




FIG. 20 DF-635 (20)

5HC

| Ref.No. | Parts No. | Description                       | Standard parts |
|---------|-----------|-----------------------------------|----------------|
| 1       | 5C411320  | FNS CORRECTION MOTOR              | a-5A807490     |
| 2       | 5A908120  | STOPPER SHEET                     | b-5A810180     |
| 3       | 5HA11390  | PHOTO SENSOR                      | c-5A809690     |
| 4       | 5C510240  | SENSOR COVER                      | d-5A808630     |
| 5       | 5C510700  | PAPER REGULATING PLATE/2 COMBINED | e-5A809700     |
| 6       | 5A910750  | ROCKING BLOCK ASS'Y               | f-5A807430     |
| 7       | 5A910760  | BELT HOLDER PLATE                 | g-5A807440     |
| 8       | 5C510250  | PAPER REGULATING PLATE/FRONT      | h-5C331630     |
| 9       | 5C510260  | PAPER REGULATING PLATE/REAR       | i-5A807450     |
| 10      | 5HC10320  | GUIDE PLATE                       | j-5A807910     |
| 11      | 5HC10330  | CONVEYANCE GUIDE PLATE/1          | k-5A811610     |
| 12      | 5A910850  | IDLER PULLEY(Z=28)                |                |
| 13      | 5A910840  | BELT HOLDER/B                     |                |
| 14      | 5A910830  | BELT/A(L=752)                     |                |
| 15      | 5A910820  | REGULATION GEAR/S(Z=55,28)        |                |
| 16      | 5HC10570  | FNS WIRING/P                      |                |
| 17      | 5HC10340  | CONVEYANCE GUIDE PLATE/2          |                |
| 18      | 5C510300  | RELEASE PART                      |                |
| 19      | 5C510310  | RELEASE SPRING/2                  |                |
| 20      | 5C511080  | BELT PRESSURE SPRING COMBINED     |                |
| 21      | 5C510330  | CONVEYANCE GUIDE SHEET/B          |                |




FIG. 21 DF-635 (21)

5HC

| Ref.No. | Parts No. | Description                  | Standard parts |
|---------|-----------|------------------------------|----------------|
| 1       | 5C510200  | SHAFT SUPPORT COLLAR         | a-5A808640     |
| 2       | 5C510190  | LEVER LOCKING GEAR(Z=36)     | b-5C331880     |
| 3       | 5C510320  | CONVEYANCE GUIDE SHEET/A     | c-5A807490     |
| 4       | 5A824740  | PIN(A)(2X12)                 | d-5A808630     |
| 5       | 5C510150  | SLIDE PART                   | e-5A807450     |
| 6       | 5A911690  | FIXED BLOCK                  | f-5A807440     |
| 7       | 5C510140  | STOPPER BOARD                | g-5C331530     |
| 8       | 5C510180  | LEVER LOCKING CAM            | h-5A809690     |
| 9       | 5C510950  | STOPPER MOTOR                | i-5A809700     |
| 10      | 5C510940  | BELT/M(L=386)                | j-5A807920     |
| 11      | 5C510230  | RELEASE SPRING/2             |                |
| 12      | 5A910850  | IDLER PULLEY(Z=28)           |                |
| 13      | 5C510170  | STOPPER SPRING/MIDDLE        |                |
| 14      | 5HC10300  | RELEASE STOPPER              |                |
| 15      | 5C510220  | STOPPER SHEET                |                |
| 16      | 5A910840  | BELT HOLDER/B                |                |
| 17      | 5C319250  | PHOTO SENSOR                 |                |
| 18      | 5C511020  | FNS WIRING/7                 |                |
| 19      | 5C330850  | PAPER FEED SHAFT HOLDER      |                |
| 20      | 5C411330  | CORRECTION MORTOR            |                |
| 21      | 5C510100  | STAPLE SLIDE GEAR/B(Z=55)    |                |
| 22      | 5HC10160  | RELEASE LEVER                |                |
| 23      | 5C510090  | STAPLE SLIDE PULLEY(Z=28)    |                |
| 24      | 5A911500  | STAPLE DRIVING GEAR(Z=51,21) |                |
| 25      | 5HA11390  | PHOTO SENSOR                 |                |
| 26      | 5A823820  | STICK MATERIAL               |                |
| 27      | 5HC10480  | SLIDE BASE PLATE ASSEMBLY    |                |
| 28      | 5HC10170  | STOPPER SHEET/REAR           |                |




FIG. 22 DF-635 (22)

5HC

| Ref.No. | Parts No. | Description                  | Standard parts |
|---------|-----------|------------------------------|----------------|
| 1       | 5HC10470  | ADJUSTING COVER/1            | a-5A807490     |
| 2       | 5HC10460  | PAPER EXIT GUIDE PLATE/LOWER | b-5A807450     |
| 3       | 5A908030  | STOPPER RUBBER               | c-5A807460     |
| 4       | 5C510510  | PRESSURE ROLLER              | d-5A809690     |
| 5       | 5C510501  | FOLD DOWN ROLLER/UPPER       | e-5A807440     |
| 6       | 5C510681  | FOLD DOWN ROLLER/LOWER       | f-5A825670     |
| 7       | 5C510660  | REGULATING RUBBER            | g-5A825250     |
| 8       | 5C510570  | ACTUATOR/3                   | h-5A807910     |
| 9       | 5HC10450  | PAPER EXIT GUIDE PLATE/UPPER | i-5A814230     |
| 10      | 5C511310  | PRESSURE ROLLER/UPPER        | j-5A811610     |
| 11      | 5HC10440  | PRESSING ARM/FRONT           |                |
| 12      | 5C510521  | PAPER HOLD DOWN SPRING/UPPER |                |
| 13      | 5C510490  | PRESSURE ARM/REAR            |                |
| 14      | 5HC10420  | FOLDING ARM/UPPER            |                |
| 15      | 5C510531  | PAPER HOLD DOWN SPRING/LOWER |                |
| 16      | 5HC10430  | FOLDING ARM/LOWER            |                |
| 17      | 5C510540  | PRESSURE SPRING              |                |
| 18      | 5C511220  | CAM FOLLOWER SLIDE SCREW     |                |
| 19      | 5C510550  | JAM RELEASE KNOB             |                |
| 20      | 5C319250  | PHOTO SENSOR                 |                |
| 21      | 5C510560  | SENSOR MOUNT PLATE/B         |                |
| 22      | 5C511030  | FNS WIRING/9                 |                |
| 23      | 5C510590  | SENSOR PRESSURE SPRING/1     |                |
| 24      | 5C319220  | BALL BEARING(B)              |                |
| 25      | 5C510580  | ACTUATOR/4                   |                |
| 26      | 5FD02110  | NEUTRALIZING BRUSH/REAR      |                |




FIG. 23 DF-635 (23)

5HC

| Ref.No. | Parts No. | Description                      | Standard parts |
|---------|-----------|----------------------------------|----------------|
| 1       | 5A813710  | MAGNET CATCH                     | a-5A807490     |
| 2       | 5C510390  | CONVEYANCE FULCRUM PLATE/FRONT   | b-5A808640     |
| 3       | 5C510400  | GUIDE SHEET/A                    | c-5A809700     |
| 4       | 5HC10390  | GUIDE PLATE/B                    | d-5A809280     |
| 5       | 5A908450  | RELEASE LEVER KNOB               | e-5A807450     |
| 6       | 5A818490  | PAPER LIFT UP LEVER SHAFT HOLDER | f-5A807460     |
| 7       | 5HA11390  | PHOTO SENSOR                     | g-5A811610     |
| 8       | 5C331000  | PIN A                            | h-5A810200     |
| 9       | 5A815960  | ACTUATOR(1)                      | i-5A810210     |
| 10      | 5C511260  | BELT DRIVEN ROLLER               | j-5A809690     |
| 11      | 5HC10400  | CONVEYANCE ROLLER/B              | k-5A814200     |
| 12      | 5C510890  | CONVEYANCE BELT(L=381)           |                |
| 13      | 5C510410  | CONVEYANCE ROLLER/A              |                |
| 14      | 5A811470  | METAL                            |                |
| 15      | 5HC10220  | SENSOR PRESSURE SPRING           |                |




FIG. 24 DF-635 (24)

5HC

| Ref.No. | Parts No. | Description                  | Standard parts |
|---------|-----------|------------------------------|----------------|
| 1       | 5C411330  | CORRECTION MORTOR            | a-5A807460     |
| 2       | 5HC10550  | FNS WIRING/M                 | b-5A808640     |
| 3       | 5HA11390  | PHOTO SENSOR                 | c-5A807490     |
| 4       | 5HC10220  | SENSOR PRESSURE SPRING       | d-5C331440     |
| 5       | 5A910820  | REGULATION GEAR/S(Z=55,28)   | e-5A807450     |
| 6       | 5A911500  | STAPLE DRIVING GEAR(Z=51,21) | f-5A807900     |
| 7       | 5A815960  | ACTUATOR(1)                  | g-5A808630     |
| 8       | 5A910850  | IDLER PULLEY(Z=28)           | h-5A809690     |
| 9       | 5C510860  | BELT/J(L=354)                | i-5A809300     |
| 10      | 5A910840  | BELT HOLDER/B                | j-5A809700     |
| 11      | 5HC10370  | PAPER STOPPER BOTTOM PLATE   | k-5A814230     |
| 12      | 5C511460  | ADJUSTMENT CAM               | m-5A811610     |
| 13      | 5C510150  | SLIDE PART                   |                |
| 14      | 5HC10380  | PAPER STOPPER                |                |
| 15      | 5C510361  | PAPER STOPPER HOLDER         |                |
| 16      | 5A911690  | FIXED BLOCK                  |                |
| 17      | 5C510690  | GUIDE SHEET/B                |                |
| 18      | 5C511470  | ADJUSTMENT SPRING            |                |




FIG. 25 DF-635 (25)

5HC

| Ref.No. | Parts No. | Description               | Standard parts |
|---------|-----------|---------------------------|----------------|
| 1       | 5C510110  | FNS MOTOR                 | a-5A807450     |
| 2       | 5C510440  | GUIDE SHAFT HOLDER/A      | b-5A808640     |
| 3       | 5HA11390  | PHOTO SENSOR              | c-5A807460     |
| 4       | 5HC10410  | FOLDING BLADE             | d-5A816190     |
| 5       | 5C510820  | BLADE DRIVING CAM(Z=114)  | e-5A807490     |
| 6       | 5C510810  | BLADE IDLER GEAR(Z=25/33) | f-5A807460     |
| 7       | 5C510650  | CAM FOLLOWER SHAFT HOLDER | g-5C331800     |
| 8       | 5C510450  | GUIDE SHAFT HOLDER/B      | h-5C332110     |
| 9       | 5HC10740  | FNS WIRING/T              | i-5A807900     |
| 10      | 5C511110  | UP-DOWN WORM              | j-5A815170     |
|         |           |                           | k-5A809700     |
|         |           |                           | m-5A818080     |
|         |           |                           | n-5A814230     |
|         |           |                           | p-5A807910     |




FIG. 26 DF-635 (26)

5HC

| Ref.No. | Parts No. | Description                  | Standard parts |
|---------|-----------|------------------------------|----------------|
| 1       | 5A909570  | COLLAR/A                     | a-5A807490     |
| 2       | 5C510870  | BELT/K(L=144)                | b-5A808640     |
| 3       | 5C510730  | CONVEYANCE PULLEY/C(Z=25)    | c-5A807460     |
| 4       | 5C510920  | DRIVING BELT/C(L=285)        | d-5A810230     |
| 5       | 5C510660  | REGULATING RUBBER            | e-5A809800     |
| 6       | 5C510720  | CONVEYANCE PULLEY/B(Z=16)    | f-5HA50360     |
| 7       | 5C331000  | PIN A                        | g-5HA50380     |
| 8       | 5A910840  | BELT HOLDER/B                |                |
| 9       | 5C510740  | CONVEYANCE PULLEY/D(Z=21)    |                |
| 10      | 5C510800  | REVERSAL PULLEY(Z=20)        |                |
| 11      | 5C510710  | CONVEYANCE PULLEY/A(Z=20)    |                |
| 12      | 5C510880  | REVERSAL BELT(L=378)         |                |
| 13      | 5HC10080  | DRIVING BELT/A               |                |
| 14      | 5C510930  | DRIVING BELT/D(L=318)        |                |
| 15      | 5C511150  | SHAFT HOLDER/2               |                |
| 16      | 5HC10560  | IDLING PULLEY/A(Z=20/41)     |                |
| 17      | 5C319380  | SHAFT HOLDER                 |                |
| 18      | 5HC10090  | DRIVING BELT/B               |                |
| 19      | 5C510610  | IDLER COLLAR                 |                |
| 20      | 5C510790  | IDLER PULLEY/B(Z=20/24)      |                |
| 21      | 5C510670  | SPRING                       |                |
| 22      | 5C510770  | DRIVING PULLEY(Z=16)         |                |
| 23      | 5C510960  | PAPER FEED MOTOR             |                |
| 24      | 5C510830  | PRESSURE GEAR(Z=30)          |                |
| 25      | 5A814410  | ROLLER COLLAR(16X6)          |                |
| 26      | 5C510850  | PRESSURE IDLER/B(Z=46)       |                |
| 27      | 5C330850  | PAPER FEED SHAFT HOLDER      |                |
| 28      | 5C510840  | PRESSURE IDLER/A(Z=20)       |                |
| 29      | 5C510760  | PRESSURE PULLEY(Z=36)        |                |
| 30      | 5C510750  | PAPER FOLD DOWN PULLEY(Z=30) |                |
| 31      | 5C511200  | BELT HOLDER PLATE/A          |                |




FIG. 27 DF-635 (27)

5HC

| Ref.No. | Parts No. | Description  | Standard parts |
|---------|-----------|--------------|----------------|
| 1       | 5HB11470  | FNS WIRING/A |                |
| 2       | 5HB11480  | FNS WIRING/B |                |
| 3       | 5HB11500  | FNS WIRING/G |                |
| 4       | 5C411370  | FNS WIRING/D |                |
| 5       | 5HB11490  | FNS WIRING/C |                |




FIG. 28 DF-635 (28)

5HC

| Ref.No. | Parts No. | Description                   | Standard parts |
|---------|-----------|-------------------------------|----------------|
| 1       | 5HC10630  | FNS WIRING /F                 |                |
| 2       | 5HC10540  | ENTRANCE GUIDE PULLEY/A(Z=34) |                |
| 3       | 5HC10740  | FNS WIRING/T                  |                |
| 4       | 5HC10550  | FNS WIRING/M                  |                |
| 5       | 5HC10730  | FNS WIRING/O                  |                |
| 6       | 5HC10570  | FNS WIRING/P                  |                |
| 7       | 5HC10670  | FNS WIRING/V                  |                |




FIG. 29 DF-635 (29)

5HC

| Ref.No. | Parts No. | Description  | Standard parts |
|---------|-----------|--------------|----------------|
| 1       | 5C411380  | FNS WIRING/E |                |
| 2       | 5C411420  | FNS WIRING/I |                |
| 3       | 5C510990  | FNS WIRING/4 |                |
| 4       | 5C510970  | FNS WIRING/1 |                |
| 5       | 5C511020  | FNS WIRING/7 |                |
| 6       | 5C511030  | FNS WIRING/9 |                |

# INDEX

5HC

| Parts No. | Description                      | Fig. No.               |
|-----------|----------------------------------|------------------------|
| 5A808170  | EXTERNAL AUX PANEL               | 3                      |
| 5A808200  | KEY COUNTER LID                  | 3                      |
| 5A808530  | MAGNET PLATE                     | 2                      |
| 5A808710  | SCREW COVER                      | 2                      |
| 5A811470  | METAL                            | 8,10,11,15,16,<br>23   |
| 5A811720  | PAPER FEED DELIVERY SHAFT HOLD   | 6,7,11                 |
| 5A811870  | PIN (2X8)                        | 16                     |
| 5A813710  | MAGNET CATCH                     | 2,7,23                 |
| 5A814410  | ROLLER COLLAR(16X6)              | 26                     |
| 5A815900  | PIN(B)(3X14)                     | 10,15                  |
| 5A815960  | ACTUATOR(1)                      | 23,24                  |
| 5A816830  | STEPPED SCREW(M3X4)              | 4                      |
| 5A818490  | PAPER LIFT UP LEVER SHAFT HOLDER | 9,10,23                |
| 5A818950  | PAPER EXIT DRIVEN ROLLER (B)     | 5                      |
| 5A820190  | ADU CONVEYANCE SHAFT HOLDER      | 5                      |
| 5A822060  | MAGNET CATCH                     | 1                      |
| 5A822121  | KNOB                             | 14                     |
| 5A823820  | STICK MATERIAL                   | 2,5,10,13,15,16,<br>21 |
| 5A824740  | PIN(A)(2X12)                     | 4,21                   |
| 5A825890  | MAGNET CATCH                     | 6                      |
| 5A907091  | CONNECTING STAY                  | 1                      |
| 5A907131  | SLIDE STAY/A                     | 3                      |
| 5A907150  | COVER                            | 3                      |
| 5A907221  | MAIN MT PLATE                    | 1                      |
| 5A907270  | CARRIAGE ROLLER/R                | 1                      |
| 5A907330  | DRIVEN SHAFT HOLDER              | 3                      |
| 5A907340  | SUPPORT PLATE/A                  | 3                      |
| 5A907620  | SHAFT/LOWER                      | 5                      |
| 5A907640  | REGULATING SHAFT                 | 1                      |
| 5A907720  | ACTUATOR                         | 2                      |
| 5A907900  | SHIFT MOTOR ASS'Y                | 12                     |
| 5A907940  | EDGE SADDLE                      | 9                      |
| 5A907990  | SLIDE ARM                        | 9,10                   |
| 5A908030  | STOPPER RUBBER                   | 4,6,7,22               |
| 5A908040  | ROLLER                           | 9,17,18                |
| 5A908080  | SHAFT HOLDER/A                   | 9                      |
| 5A908120  | STOPPER SHEET                    | 9,15,20                |
| 5A908160  | ENTRANCE ROLLER                  | 4,6,9                  |

| Parts No. | Description                       | Fig. No.    |
|-----------|-----------------------------------|-------------|
| 5A908190  | DRIVING PULLEY/A                  | 11,13,16    |
| 5A908200  | SOLENOID LEVER                    | 13          |
| 5A908220  | FNS SOLENOID ASS'Y                | 13          |
| 5A908430  | CONVEYANCE PRESSURE SPRING        | 7,9,16      |
| 5A908450  | RELEASE LEVER KNOB                | 6,7,23      |
| 5A908490  | CONVEYANCE PRESSURE SHAFT/B ASS'Y | 4,6,7       |
| 5A908590  | SOLENOID SPRING                   | 6           |
| 5A908830  | HINGE SPRING/A                    | 7           |
| 5A908960  | GUIDE SHAFT/A                     | 7           |
| 5A908970  | SOLENOID SPRING                   | 7           |
| 5A908980  | GUIDE SHAFT/B                     | 7           |
| 5A909060  | CONVEYANCE ROLLER                 | 16          |
| 5A909160  | SOLENOID ASS'Y                    | 5           |
| 5A909250  | PAPER EXIT CONVEYANCE SHAFT       | 10          |
| 5A909260  | PAPER EXIT SUPPORT SHAFT          | 10          |
| 5A909270  | PAPER EXIT ROLLER                 | 10          |
| 5A909280  | ROTARY STOPPER                    | 10          |
| 5A909300  | SHAFT HOLDER                      | 10          |
| 5A909310  | PAPER EXIT PRESSURE SPRING        | 10          |
| 5A909320  | PAPER EXIT GUIDE STAY             | 10          |
| 5A909330  | NEUTRALIZING BRUSH                | 1,5,8,10,16 |
| 5A909350  | PAPER EXIT GUIDE SHEET            | 10          |
| 5A909420  | PAPER EXIT ROLLER                 | 11          |
| 5A909440  | ROTARY DISK ASS'Y                 | 11          |
| 5A909461  | PAPER EXIT PULLEY/A(Z=26)         | 11          |
| 5A909480  | MOTOR PULLEY(Z=16)                | 11          |
| 5A909490  | BELT/B(L=192)                     | 11          |
| 5A909510  | SHAFT HOLDER                      | 11,12       |
| 5A909540  | BELT/E(L=180)                     | 12,16       |
| 5A909560  | PAPER EXIT PULLEY/B(Z=40,52,26)   | 11          |
| 5A909570  | COLLAR/A                          | 11,12,13,26 |
| 5A909580  | PAPER EXIT SPRING                 | 11          |
| 5A909620  | PAPER EXIT GUIDE STAY/B           | 10          |
| 5A909760  | SLIDE SHAFT                       | 8           |
| 5A909770  | ROLLER                            | 8           |
| 5A909800  | UP-DOWN STAY                      | 8           |
| 5A909820  | UP-DOWN COVER/R                   | 8           |
| 5A909840  | UP-DOWN COVER/F                   | 8           |
| 5A909910  | TENSION PULLEY                    | 8           |
| 5A909920  | TENSION PLATE ASS'Y               | 8           |

## 5HC

| Parts No. | Description                    | Fig. No.            |
|-----------|--------------------------------|---------------------|
| 5A909970  | UP-DOWN GEAR/A(Z=44,21)        | 8                   |
| 5A909980  | UP-DOWN GEAR/B(Z=52,15)        | 8                   |
| 5A910000  | UP-DOWN PULLEY                 | 8                   |
| 5A910020  | UP-DOWN GEAR/C(Z=30)           | 8                   |
| 5A910240  | SPRING                         | 13                  |
| 5A910360  | PAPER EXIT GEAR(Z=100,20)      | 12                  |
| 5A910380  | DRIVING PULLEY/D(Z=30,24)      | 12                  |
| 5A910720  | BELT DETECTING GEAR(Z=102)     | 15                  |
| 5A910730  | BELT DETECTING SCREW           | 15                  |
| 5A910750  | ROCKING BLOCK ASS'Y            | 15,20               |
| 5A910760  | BELT HOLDER PLATE              | 15,20               |
| 5A910790  | BELT HOLDER                    | 15                  |
| 5A910810  | BELT DRIVING PULLEY(Z=18)      | 15                  |
| 5A910820  | REGULATION GEAR/S(Z=55,28)     | 15,20,24            |
| 5A910830  | BELT/A(L=752)                  | 15,20               |
| 5A910840  | BELT HOLDER/B                  | 15,19,20,21,24,26   |
| 5A910850  | IDLER PULLEY(Z=28)             | 15,20,21,24         |
| 5A910910  | CONVEYANCE PRESSURE SHAFT ASSY | 9,16                |
| 5A911040  | BELT HOLDER/B                  | 16                  |
| 5A911050  | ENTRANCE GUIDE PULLEY/A        | 16                  |
| 5A911180  | BELT/J(L=159)                  | 16                  |
| 5A911500  | STAPLE DRIVING GEAR(Z=51,21)   | 19,21,24            |
| 5A911690  | FIXED BLOCK                    | 21,24               |
| 5A911760  | STAPLES                        | 17,18               |
| 5A911800  | IDLER SHAFT                    | 17,18               |
| 5BA08000  | ACTUATOR                       | 3                   |
| 5C319220  | BALL BEARING(B)                | 4,5,6,7,11,12,13,22 |
| 5C319250  | PHOTO SENSOR                   | 21,22               |
| 5C319380  | SHAFT HOLDER                   | 12,13,26            |
| 5C330850  | PAPER FEED SHAFT HOLDER        | 19,21,26            |
| 5C330980  | DRIVING SLIDE SHAFT HOLDER(A)  | 8                   |
| 5C331000  | PIN A                          | 23,26               |
| 5C410020  | GUIDE PLATE                    | 9                   |
| 5C410050  | PAPER EXIT REINFORCING STAY    | 8                   |
| 5C410070  | SLIDE GEAR/B(Z=100)            | 9                   |
| 5C410090  | AUXILIARY PLATE                | 8                   |
| 5C410100  | PAPER EXIT UP-DOWN ACTUATOR    | 3                   |
| 5C410110  | WIRING GUIDE ARM               | 1                   |

| Parts No. | Description                | Fig. No. |
|-----------|----------------------------|----------|
| 5C410120  | UP-DPWN WIRE/R             | 8        |
| 5C410130  | UP-DOWN WIRE/F             | 8        |
| 5C410140  | LOCK SPRING                | 1        |
| 5C410150  | SLIDE RAIL/RIGHT           | 1        |
| 5C410160  | SLIDE RAIL/LEFT            | 1        |
| 5C410170  | CARRIAGE ROLLER/1          | 1        |
| 5C410180  | ACTUATOR/1                 | 1        |
| 5C410210  | MOTOR ASSEMBLY             | 8        |
| 5C410230  | SIDE COVER/UPPER           | 2        |
| 5C410240  | SIDE COVER/RIGHT           | 2        |
| 5C410250  | SIDE COVER/LEFT            | 2        |
| 5C410260  | HINGE PLATE/UPPER          | 2        |
| 5C410270  | HINGE PLATE/LOWER          | 2        |
| 5C410290  | PANEL/REAR                 | 14       |
| 5C410300  | SHAFT SUPPORT PLATE/B      | 14       |
| 5C410311  | SHAFT SUPPORT PLATE/C      | 14       |
| 5C410320  | STAPLE SLIDE SHAFT HOLDER  | 17,18    |
| 5C410330  | WIRING ROTARY PLATE/2      | 14       |
| 5C410370  | TOPPER SPRING              | 17       |
| 5C410390  | CARTRIDGE GUIDE RAIL       | 14       |
| 5C410400  | LOCK BLOCK                 | 17,18    |
| 5C410410  | LOCK SPRING                | 17,18    |
| 5C410420  | LOCK PIN(D8)               | 17,18    |
| 5C410440  | STAPLE ROTARY ROLLER       | 14,18    |
| 5C410470  | SHAFT HOLDER MOUNT OLATE   | 16       |
| 5C410500  | WIRING REGULATING PLATE    | 18       |
| 5C410520  | STOPPER BOTTOM PLATE/FRONT | 17       |
| 5C410530  | STOPPER BOTTOM PLATE/REAR  | 17       |
| 5C410560  | OSCILLATE PULLEY/1(Z=20)   | 16       |
| 5C410570  | BELT MOUNT ROLLER          | 16       |
| 5C410590  | REGULATING BELT/2          | 16       |
| 5C410600  | CARRIAGE COVER/UPPER       | 14       |
| 5C410610  | STAPLE COVER               | 18       |
| 5C410620  | CARRIAGE COVER/LEFT        | 14       |
| 5C410640  | CONVEYANCE GUIDE SHEET/1   | 17       |
| 5C410650  | SLIDE SHEET/1              | 17,18    |
| 5C410660  | SLIDE SHEET/2              | 17,18    |
| 5C410680  | CONVEYANCE GUIDE SHEET/2   | 16       |
| 5C410790  | CONVEYANCE PRESSURE SPRING | 6        |
| 5C410810  | PAPER GUIDE PART           | 6        |

| Parts No. | Description                       | Fig. No. |
|-----------|-----------------------------------|----------|
| 5C410820  | PRESSURE RUBBER                   | 7        |
| 5C410850  | HINGE SPRING/C                    | 6        |
| 5C410860  | HINGE SPRING/D                    | 6        |
| 5C410950  | CONVEYANCE DRIVING ROLLER/A       | 4        |
| 5C410970  | NEUTRALIZING PLATE                | 5        |
| 5C410980  | EARTH PLATE                       | 5        |
| 5C410990  | OPEN-CLOSE LEVER/1                | 4        |
| 5C411000  | OPEN-CLOSE/2                      | 4        |
| 5C411040  | CONVEYANCE PRESSURE SPRING        | 4        |
| 5C411070  | PAPER REGULATING PLATE/1 COMBINED | 15       |
| 5C411100  | TENSION SHAFT HOLDER              | 4        |
| 5C411150  | DRIVING PULLEY/A(Z=40/24)         | 12       |
| 5C411160  | SLIDE GEAR/A(Z=100)               | 12       |
| 5C411200  | DRIVE CONNECTING GEAR(Z=18)       | 12       |
| 5C411230  | BELT/D(L=228)                     | 13       |
| 5C411240  | BELT/C(L=207)                     | 13       |
| 5C411250  | BELT/E(L=222)                     | 4,5      |
| 5C411260  | BELT/F(L=315)                     | 11       |
| 5C411300  | PAPER EXIT DRIVING BELT/B(L=267)  | 12,13    |
| 5C411320  | FNS CORRECTION MOTOR              | 15,20    |
| 5C411330  | CORRECTION MOTOR                  | 19,21,24 |
| 5C411370  | FNS WIRING/D                      | 3,27     |
| 5C411380  | FNS WIRING/E                      | 29       |
| 5C411420  | FNS WIRING/I                      | 16,29    |
| 5C411440  | RELAY BOARD ASSEMBLY              | 14       |
| 5C411470  | CARTRIDGE CASE(FS108BM)           | 17,18    |
| 5C411610  | SLIDE STOPPER/A                   | 8        |
| 5C411630  | SPEWING PV PAD                    | 3        |
| 5C411650  | MAIN MOUNT PLATE/UPPER            | 1        |
| 5C411660  | MAIN MOUNT PLATE/LOWER            | 1        |
| 5C510010  | PAPER EXIT UP-DOWN TRAY/1         | 8        |
| 5C510020  | PAPER EXIT UP-DOWN TRAY/2         | 8        |
| 5C510030  | UPPER PLATE                       | 2        |
| 5C510050  | SIDE COVER /FRONT                 | 2        |
| 5C510060  | REAR COVER                        | 3        |
| 5C510070  | SEAL                              | 2        |
| 5C510080  | BELT TENSION SPRING               | 13       |
| 5C510090  | STAPLE SLIDE PULLEY(Z=28)         | 21       |
| 5C510100  | STAPLE SLIDE GEAR/B(Z=55)         | 21       |
| 5C510110  | FNS MOTOR                         | 25       |

| Parts No. | Description                       | Fig. No. |
|-----------|-----------------------------------|----------|
| 5C510120  | PAPER EXIT PRESSURE PLATE         | 1        |
| 5C510140  | STOPPER BOARD                     | 21       |
| 5C510150  | SLIDE PART                        | 21,24    |
| 5C510170  | STOPPER SPRING/MIDDLE             | 21       |
| 5C510180  | LEVER LOCKING CAM                 | 21       |
| 5C510190  | LEVER LOCKING GEAR(Z=36)          | 21       |
| 5C510200  | SHAFT SUPPORT COLLAR              | 21       |
| 5C510220  | STOPPER SHEET                     | 21       |
| 5C510230  | RELEASE SPRING/2                  | 21       |
| 5C510240  | SENSOR COVER                      | 20       |
| 5C510250  | PAPER REGULATING PLATE/FRONT      | 20       |
| 5C510260  | PAPER REGULATING PLATE/REAR       | 20       |
| 5C510300  | RELEASE PART                      | 20       |
| 5C510310  | RELEASE SPRING/2                  | 20       |
| 5C510320  | CONVEYANCE GUIDE SHEET/A          | 21       |
| 5C510330  | CONVEYANCE GUIDE SHEET/B          | 20       |
| 5C510361  | PAPER STOPPER HOLDER              | 24       |
| 5C510390  | CONVEYANCE FULCRUM PLATE/FRONT    | 23       |
| 5C510400  | GUIDE SHEET/A                     | 23       |
| 5C510410  | CONVEYANCE ROLLER/A               | 23       |
| 5C510440  | GUIDE SHAFT HOLDER/A              | 25       |
| 5C510450  | GUIDE SHAFT HOLDER/B              | 25       |
| 5C510490  | PRESSURE ARM/REAR                 | 22       |
| 5C510501  | FOLD DOWN ROLLER/UPPER            | 22       |
| 5C510510  | PRESSURE ROLLER                   | 22       |
| 5C510521  | PAPER HOLD DOWN SPRING/UPPER      | 22       |
| 5C510531  | PAPER HOLD DOWN SPRING/LOWER      | 22       |
| 5C510540  | PRESSURE SPRING                   | 22       |
| 5C510550  | JAM RELEASE KNOB                  | 22       |
| 5C510560  | SENSOR MOUNT PLATE/B              | 22       |
| 5C510570  | ACTUATOR/3                        | 22       |
| 5C510580  | ACTUATOR/4                        | 22       |
| 5C510590  | SENSOR PRESSURE SPRING/1          | 22       |
| 5C510610  | IDLER COLLAR                      | 26       |
| 5C510650  | CAM FOLLOWER SHAFT HOLDER         | 25       |
| 5C510660  | REGULATING RUBBER                 | 22,26    |
| 5C510670  | SPRING                            | 26       |
| 5C510681  | FOLD DOWN ROLLER/LOWER            | 22       |
| 5C510690  | GUIDE SHEET/B                     | 24       |
| 5C510700  | PAPER REGULATING PLATE/2 COMBINED | 20       |

## 5HC

| Parts No. | Description                   | Fig. No. |
|-----------|-------------------------------|----------|
| 5C510710  | CONVEYANCE PULLEY/A(Z=20)     | 26       |
| 5C510720  | CONVEYANCE PULLEY/B(Z=16)     | 26       |
| 5C510730  | CONVEYANCE PULLEY/C(Z=25)     | 26       |
| 5C510740  | CONVEYANCE PULLEY/D(Z=21)     | 26       |
| 5C510750  | PAPER FOLD DOWN PULLEY(Z=30)  | 26       |
| 5C510760  | PRESSURE PULLEY(Z=36)         | 26       |
| 5C510770  | DRIVING PULLEY(Z=16)          | 26       |
| 5C510790  | IDLER PULLEY/B(Z=20/24)       | 26       |
| 5C510800  | REVERSAL PULLEY(Z=20)         | 26       |
| 5C510810  | BLADE IDLER GEAR(Z=25/33)     | 25       |
| 5C510820  | BLADE DRIVING CAM(Z=114)      | 25       |
| 5C510830  | PRESSURE GEAR(Z=30)           | 26       |
| 5C510840  | PRESSURE IDLER/A(Z=20)        | 26       |
| 5C510850  | PRESSURE IDLER/B(Z=46)        | 26       |
| 5C510860  | BELT/J(L=354)                 | 24       |
| 5C510870  | BELT/K(L=144)                 | 26       |
| 5C510880  | REVERSAL BELT(L=378)          | 26       |
| 5C510890  | CONVEYANCE BELT(L=381)        | 23       |
| 5C510920  | DRIVING BELT/C(L=285)         | 26       |
| 5C510930  | DRIVING BELT/D(L=318)         | 26       |
| 5C510940  | BELT/M(L=386)                 | 21       |
| 5C510950  | STOPPER MOTOR                 | 21       |
| 5C510960  | PAPER FEED MOTOR              | 26       |
| 5C510970  | FNS WIRING/1                  | 29       |
| 5C510990  | FNS WIRING/4                  | 29       |
| 5C511020  | FNS WIRING/7                  | 21,29    |
| 5C511030  | FNS WIRING/9                  | 22,29    |
| 5C511060  | ADF PRESSURE PART             | 17,18    |
| 5C511080  | BELT PRESSURE SPRING COMBINED | 20       |
| 5C511090  | DOUBLE FEED FIXED COLLAR      | 4        |
| 5C511100  | SWITCH INSULATING SHEET       | 3        |
| 5C511110  | UP-DOWN WORM                  | 25       |
| 5C511130  | ROLLER                        | 1        |
| 5C511140  | RELEASE KNOB                  | 6        |
| 5C511150  | SHAFT HOLDER/2                | 26       |
| 5C511160  | DRIVING PULLEY/C(Z=30/24)     | 13       |
| 5C511170  | STOPPER RUBBER                | 1        |
| 5C511180  | LOCK LEVER                    | 1        |
| 5C511190  | LOCK CAM                      | 14       |
| 5C511200  | BELT HOLDER PLATE/A           | 26       |

| Parts No. | Description                    | Fig. No.                                         |
|-----------|--------------------------------|--------------------------------------------------|
| 5C511210  | DRIVING PULLEY/B(Z=24)         | 4,5                                              |
| 5C511220  | CAM FOLLOWER SLIDE SCREW       | 1,22                                             |
| 5C511230  | PAPER EXIT TRAY/1              | 2                                                |
| 5C511240  | PAPER EXIT TRAY/2              | 2                                                |
| 5C511260  | BELT DRIVEN ROLLER             | 23                                               |
| 5C511280  | SENSOR COVER                   | 7                                                |
| 5C511290  | PAPER FEED DRIVING MOTOR       | 11                                               |
| 5C511310  | PRESSURE ROLLER/UPPER          | 22                                               |
| 5C511460  | ADJUSTMENT CAM                 | 24                                               |
| 5C511470  | ADJUSTMENT SPRING              | 24                                               |
| 5C710620  | INTER LOCK SWITCH              | 3                                                |
| 5C710710  | OPEN-CLOSE LEVER               | 4                                                |
| 5D510310  | MAIN BODY FIXING PLATE/1       | 1                                                |
| 5FD02110  | NEUTRALIZING BRUSH/REAR        | 22                                               |
| 5HA10440  | MAIN BODY FAN MOTOR            | 3                                                |
| 5HA11390  | PHOTO SENSOR                   | 1,3,4,5,6,7,9,10,<br>12,15,18,20,21,<br>23,24,25 |
| 5HB10070  | SENSOR PROTECT BLOCK           | 1                                                |
| 5HB10080  | CONVEYANCE SLIDE SHAFT         | 9                                                |
| 5HB10090  | DRIVE GEAR/E(Z=30)             | 9                                                |
| 5HB10100  | REAR MOUNTING PLATE            | 3                                                |
| 5HB10110  | HINGE SPRING/B                 | 7                                                |
| 5HB10120  | CONVEYANCE GUIDE SHEET/B       | 7                                                |
| 5HB10130  | CONVEYANCE PRESSING SPRING/2   | 4                                                |
| 5HB10140  | PAPER EXIT STOPPER SHEET/1     | 8                                                |
| 5HB10150  | PAPER EXIT STOPPER SHEET/2     | 8                                                |
| 5HB10160  | PAPER EXIT DETECTING ACTUATOR  | 5                                                |
| 5HB10170  | PAPER EXIT SIDE PLATE/FRONT    | 1                                                |
| 5HB10180  | PAPER EXIT SIDE PLATE/REAR     | 1                                                |
| 5HB10190  | PAPER EXIT PRESSING LEVER      | 5                                                |
| 5HB10200  | PAPER EXIT PRESSING PLATE/1    | 5                                                |
| 5HB10210  | PAPER EXIT PRESSING PLATE/2    | 5                                                |
| 5HB10220  | PAPER EXIT ROLLER/A            | 5                                                |
| 5HB10230  | SOLENOID ASSEMBLY              | 5                                                |
| 5HB10240  | SENSOR MOUNTING PLATE ASSEMBLY | 5                                                |
| 5HB10250  | PAPER EXIT DRIVING PULLEY/C    | 5                                                |
| 5HB10260  | SLIDE GEAR/D(Z=34/72)          | 9                                                |
| 5HB10270  | SLIDE GEAR/E(Z=62/100)         | 9                                                |
| 5HB10280  | SHAFT HOLDER/2                 | 12                                               |

## 5HC

| Parts No. | Description                       | Fig. No. |
|-----------|-----------------------------------|----------|
| 5HB10300  | DRIVING MOTOR ASSEMBLY            | 16       |
| 5HB10310  | BELT HOLDER                       | 5        |
| 5HB10410  | ROTARY ROLLER                     | 17       |
| 5HB10700  | PAPER DETECTING ACTUATOR          | 15       |
| 5HB10710  | PRESSURE SPRING                   | 15       |
| 5HB10870  | HANDLE                            | 2        |
| 5HB10880  | FRONT DOOR ASSEMBLY               | 2        |
| 5HB10900  | BELT TENSION ROLLER               | 12       |
| 5HB10910  | TENSION ROLLER/A                  | 12       |
| 5HB10920  | PAPER EXIT ASSEMBLY               | 10       |
| 5HB10930  | PAPER GUIDE PLATE/MIDDLE ASSEMBLY | 10       |
| 5HB10940  | SOLENOID ASSEMBLY                 | 10       |
| 5HB10950  | SENSOR COVER ASSEMBLY             | 10,15    |
| 5HB10960  | GEAR /E(Z=20)                     | 12       |
| 5HB10970  | NEUTRALIZING BRUSH                | 15       |
| 5HB10980  | PAPER EXIT GUIDE SHEET            | 11       |
| 5HB10990  | GUIDE PLATE/1                     | 15       |
| 5HB11000  | REGULATING BELT/1                 | 16       |
| 5HB11010  | GUIDE PLATE/3                     | 15       |
| 5HB11020  | CONVEYANCE PRESSING SPRING/1      | 7        |
| 5HB11030  | CONVEYANCE GUIDE/A                | 6        |
| 5HB11040  | CONVEYANCE GUIDE PLATE/B          | 6        |
| 5HB11050  | CONVEYANCE GUIDE PLATE/C          | 7        |
| 5HB11060  | CONVEYANCE GUIDE PLATE/D          | 7        |
| 5HB11070  | CONVEYANCE GUIDE PLATE/E          | 7        |
| 5HB11080  | CONVEYANCE GUIDE PLATE            | 7        |
| 5HB11090  | CONVEYING ROLLER/A                | 6        |
| 5HB11100  | CONVEYING ROLLER/B                | 6        |
| 5HB11110  | PAPER EXIT GUIDE PLATE/UPPER      | 11       |
| 5HB11120  | CONVEYANCE DRIVING PLATE          | 7        |
| 5HB11130  | CONVEYANCE ROLLER/C               | 7        |
| 5HB11140  | SUIDE PLATE/LOWER                 | 9        |
| 5HB11150  | PAPER EXIT GUIDE PLATE/A          | 4        |
| 5HB11160  | PAPER EXIT GUIDE PLATE/C          | 4        |
| 5HB11170  | CONVEYANCE GUIDE PLATE/1          | 4        |
| 5HB11180  | CONVEYANCE GUIDE PLATE/2          | 4        |
| 5HB11190  | CONVEYANCE GUIDE PLATE/3          | 4        |
| 5HB11200  | PAPER EXIT COVER ASSEMBLY         | 5        |
| 5HB11210  | PAPER EXIT GUIDE PLATE/D          | 5        |
| 5HB11220  | GUIDE SHEET                       | 5        |

| Parts No. | Description                        | Fig. No. |
|-----------|------------------------------------|----------|
| 5HB11230  | SOLENOID MOUNTING PLATE            | 10       |
| 5HB11240  | SOLENOID LEVER                     | 10       |
| 5HB11250  | SOLENOID SPRING                    | 10       |
| 5HB11260  | EXIT SENSOR ASSEMBLY               | 5        |
| 5HB11270  | STOPPER                            | 10       |
| 5HB11280  | STOPPER PAD/1                      | 10       |
| 5HB11290  | STOPPER PAD/2                      | 10       |
| 5HB11300  | PAPER EXIT DRIVING SHAFT           | 11       |
| 5HB11310  | PAPER EXIT GUIDE PLATE             | 11       |
| 5HB11320  | GUIDE PLATE/2                      | 15       |
| 5HB11330  | CONVEYANCE GUIDE PLATE/A           | 16       |
| 5HB11340  | DRIVEN ROLLER/B                    | 7        |
| 5HB11350  | DETECTING SENSOR/2                 | 6,7      |
| 5HB11360  | SLEEVE                             | 12       |
| 5HB11370  | BASE PLATE SUPPORT RUBBER          | 12       |
| 5HB11380  | CONVEYANCE DRIVING PULLEY(Z=24/51) | 12       |
| 5HB11390  | DRIVE PULLEY/A                     | 5        |
| 5HB11400  | DRIVE PULLEY/C(Z=24)               | 13       |
| 5HB11410  | MOTOR PULLEY(Z=18)                 | 16       |
| 5HB11420  | COUPLING GEAR(Z=18)                | 15       |
| 5HB11430  | IDLING GEAR(Z=24)                  | 13       |
| 5HB11440  | BELT/A(L=315)                      | 12       |
| 5HB11450  | BELT/B(L=558)                      | 12,13    |
| 5HB11460  | PAPER EXIT DRIVING BELT/C          | 5        |
| 5HB11470  | FNS WIRING/A                       | 27       |
| 5HB11480  | FNS WIRING/B                       | 5,27     |
| 5HB11490  | FNS WIRING/C                       | 27       |
| 5HB11500  | FNS WIRING/G                       | 15,27    |
| 5HB11510  | ROM ASSEMBLY                       | 1        |
| 5HB11520  | SENSOR STOPPER PART                | 11       |
| 5HB11530  | CAUTION LABEL/C                    | 2        |
| 5HB11540  | CAUTION LABEL/A                    | 2        |
| 5HB11550  | PAPER PULLEY                       | 12       |
| 5HC10010  | SHIFT MOTOR A'SSY                  | 9        |
| 5HC10020  | STAPLE MAIN BODY                   | 17,18    |
| 5HC10030  | DRIVING ROLLER                     | 16       |
| 5HC10040  | CONVEYANCE ROLLER/C                | 6        |
| 5HC10050  | PAPER EXIT ROLLER/B                | 5        |
| 5HC10060  | CONVEYANCE MOTOR A'SSY             | 12       |
| 5HC10070  | ROLLING BEARING                    | 12       |

## 5HC

| Parts No. | Description                     | Fig. No. |
|-----------|---------------------------------|----------|
| 5HC10080  | DRIVING BELT/A                  | 26       |
| 5HC10090  | DRIVING BELT/B                  | 26       |
| 5HC10100  | CONTROL UNIT                    | 1        |
| 5HC10110  | CONVEYANCE CLEANING BRUSH       | 7        |
| 5HC10120  | STAPLE SLIDE PLATE/A            | 17       |
| 5HC10130  | STAPLE SLIDE PLATE/B            | 17       |
| 5HC10140  | JAM HANDLING LABEL              | 2        |
| 5HC10160  | RELEASE LEVER                   | 21       |
| 5HC10170  | STOPPER SHEET/REAR              | 21       |
| 5HC10180  | PRESSURE STOPPER/REAR COMBINED  | 17       |
| 5HC10190  | PRESSURE STOPPER/FRONT COMBINED | 17       |
| 5HC10220  | SENSOR PRESSURE SPRING          | 23,24    |
| 5HC10230  | PROTECTION COVER/1              | 1        |
| 5HC10240  | PROTECTION COVER/2              | 1        |
| 5HC10250  | COLLAR/C                        | 16       |
| 5HC10260  | STAPLE GUIDE PLATE/FRONT        | 18       |
| 5HC10270  | STAPLE GUIDE PLATE/REAR         | 18       |
| 5HC10280  | BELT FIXING BLOCK               | 14       |
| 5HC10290  | CONVEYANCE GUIDE PLATE          | 16       |
| 5HC10300  | RELEASE STOPPER                 | 21       |
| 5HC10310  | PAPER EXIT GUIDE SHEET          | 16       |
| 5HC10320  | GUIDE PLATE                     | 20       |
| 5HC10330  | CONVEYANCE GUIDE PLATE/1        | 20       |
| 5HC10340  | CONVEYANCE GUIDE PLATE/2        | 20       |
| 5HC10350  | REGULATING PLATE/FRONT ASSEMBLY | 15       |
| 5HC10360  | REGULATING PLATE/REAR ASSEMBLY  | 15       |
| 5HC10370  | PAPER STOPPER BOTTOM PLATE      | 24       |
| 5HC10380  | PAPER STOPPER                   | 24       |
| 5HC10390  | GUIDE PLATE/B                   | 23       |
| 5HC10400  | CONVEYANCE ROLLER/B             | 23       |
| 5HC10410  | FOLDING BLADE                   | 25       |
| 5HC10420  | FOLDING ARM/UPPER               | 22       |
| 5HC10430  | FOLDING ARM/LOWER               | 22       |
| 5HC10440  | PRESSING ARM/FRONT              | 22       |
| 5HC10450  | PAPER EXIT GUIDE PLATE/UPPER    | 22       |
| 5HC10460  | PAPER EXIT GUIDE PLATE/LOWER    | 22       |
| 5HC10470  | ADJUSTING COVER/1               | 22       |
| 5HC10480  | SLIDE BASE PLATE ASSEMBLY       | 21       |
| 5HC10490  | TENSION PLATE/1 ASSEMBLY        | 19       |
| 5HC10500  | TENSION PLATE/2 ASSEMBLY        | 19       |

| Parts No. | Description                   | Fig. No. |
|-----------|-------------------------------|----------|
| 5HC10510  | FIXING BLOCK                  | 17,18    |
| 5HC10520  | DRIVING SHAFT/A ASSEMBLY      | 19       |
| 5HC10530  | DRIVING SHAFT/B ASSEMBLY      | 19       |
| 5HC10540  | ENTRANCE GUIDE PULLEY/A(Z=34) | 16,28    |
| 5HC10550  | FNS WIRING/M                  | 24,28    |
| 5HC10560  | IDLING PULLEY/A(Z=20/41)      | 26       |
| 5HC10570  | FNS WIRING/P                  | 20,28    |
| 5HC10580  | REGULATING GEAR/S(Z=16)       | 19       |
| 5HC10590  | PAPER EXIT BELT(L=518.16)     | 15       |
| 5HC10600  | BELT/H(L=972)                 | 17,18,19 |
| 5HC10610  | BELT/I(L=642)                 | 19       |
| 5HC10620  | BELT/H(L=120)                 | 16       |
| 5HC10630  | FNS WIRING /F                 | 28       |
| 5HC10650  | PRESSURE ROLLER               | 1        |
| 5HC10660  | ENTRANCE GUIDE PULLEY/B(Z=31) | 16       |
| 5HC10670  | FNS WIRING/V                  | 28       |
| 5HC10690  | CAUTION LABEL/B               | 1        |
| 5HC10700  | DRIVING ROLLER                | 16       |
| 5HC10710  | PAPER EXIT TRAY/LOWER         | 1        |
| 5HC10720  | IDLING PULLEY(Z=16)           | 19       |
| 5HC10730  | FNS WIRING/O                  | 28       |
| 5HC10740  | FNS WIRING/T                  | 25,28    |
| 5HC10750  | STAPLE HANDLING LABEL         | 14       |



## KYOCERA MITA AMERICA, INC.

### Headquarters:

225 Sand Road, P.O. Box 40008  
Fairfield, New Jersey 07004-0008  
TEL : (973) 808-8444  
FAX : (973) 882-6000

### New York Show Room:

1410 Broadway 23rd floor  
New York, NY 10018  
TEL : (917) 286-5400  
FAX : (917) 286-5402

### Northeastern Region:

225 Sand Road, P.O. Box 40008  
Fairfield, New Jersey 07004-0008  
TEL : (973) 808-8444  
FAX : (973) 882-4401

### Midwestern Region:

201 Hansen Court Suite 119  
Wood Dale, Illinois 60191  
TEL : (630) 238-9982  
FAX : (630) 238-9487

### Western Region:

14101 Alton Parkway,  
Irvine, California 92618-7006  
TEL : (949) 457-9000  
FAX : (949) 457-9119

### Southeastern Region:

1500 Oakbrook Drive,  
Norcross, Georgia 30093  
TEL : (770) 729-9786  
FAX : (770) 729-9873

### Southwestern Region:

2825 West Story Road,  
Irving, Texas 75038-5299  
TEL : (972) 550-8987  
FAX : (972) 570-4704

### Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,  
Irving, Texas 75038-5299  
TEL : (972) 659-0055  
FAX : (972) 570-5816

## KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,  
Ontario L5T 1S8, Canada  
TEL : (905) 670-4425  
FAX : (905) 670-8116

## KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407  
Col. Santa Inés,  
02130 Azcapotzalco  
México, D.F. México  
TEL : (55) 383-2741  
FAX : (55) 383-7804

© 2002 KYOCERA MITA CORPORATION

 **KYOCERA** is a trademark of Kyocera Corporation

**mita** is a registered trademark of KYOCERA MITA CORPORATION

Printed in U.S.A.