



LASER PRINTER

DP-560

PARTS LIST

Published in Feb.'97
35370771
Revision 1

DP-560

CLASSIFICATION OF THE SCREWS IN ILLUSTRATION

<u>REF.</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>
BAI	B1003150	BINDING SCREW CVM3X15
BAZ	B1004250	BINDING SCREW CVM4X25(CHROMATING)
BBA	B1303040	BINDING SCREW BVM3X4 (BLACK)
BBB	B1303050	BINDING SCREW BVM3X5 (BLACK)
BBK	B1303060	BINDING SCREW BVM3X6 (BLACK)
BBR	B1303080	BINDING SCREW BVM3X8 (BLACK)
BHI	B3313080	BINDING TAP-TITE SCREW M3X08
<i>BHN</i>	<i>B8013080</i>	<i>BINDING TAP-TITE SCREW M3X08</i>
BHT	B8313060	BINDING TAP-TITE P SCREW M3X06
EGC	B3303060	BIND TAPPING SCREW M3X6(B TYPE)
E05	D1000500	STOP RING (E-5)
GEC	B9603050	GROUNDING SCREW M3X5(BRASS,NI/)
HCD	B4103080	TRIPLE SCREW M3X08(CHROMIUM)
RDC	D4000300	STOP RING CSTW-3

Parts List

DP-560

———— CONTENTS ————

FIG.1	EXTERIOR COVERS	2
FIG.2	FRAMES	4
FIG.3	PAPER FEED TRAY SECTION	6
FIG.4	DRIVING SECTION	8
FIG.5	CHARGING SECTION	10
FIG.6	FIXING SECTION	12
FIG.7	ELECTRICAL COMPONENTS	14
FIG.8	IMAGING UNIT	16
FIG.9	ACCESSORIES AND OPTION	18
	• INDEX	20

FIG. 1 EXTERIOR COVERS

353




FIG. 1 EXTERIOR COVERS

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35304010	UPPER COVER	1
2	35304020	COVER,RELEASE	1
3	35304080	LEVER,RELEASE	1
4	35304090	RETAINER,LEVER	2
5	35304100	JUNCTION PLATE,LED	1
6	35304110	LEVER B,RELEASE	1
7	68305090	CAUTION LABEL,HIGH TEMPERATURE L(EXP)	1
8	35320350	FILM,EJECT	1
9	35304130	EXTERIOR COVER,COOLING FAN	1
10	66205080	LABEL,FUSE	1
11	76705140	CAUTION LABEL	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

353-1



FIG. 2 FRAMES

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35302010	FRAME,MACHINE	1
2	35302020	UPPER FRAME	1
3	35302040	TERMINAL,DEVELOPING BIAS	1
4	35302050	TERMINAL,SUB DEVELOPING BIAS	1
5	35302060	TERMINAL,TRANSFER MACHINE	1
6	35302070	TERMINAL,MAIN CHARGER	1
7	35302080	TERMINAL,GRID	1
8	35302090	TERMINAL,BRUSH	1
9	35302100	HOOK A	1
10	35302110	HOOK B	1
11	35302120	SPRING,HOOK	1
12	35302240	HOLDER,GEAR DAMPER	1
13	35302260	GROUND PLATE,FRAME	1
14	35302170	SPRING,RELEASE RETAINING	3
15	35304050	BASE RUBBER	2
16	35302480	STRAP B,MACHINE RELEASE	1
17	35304070	BASE	1
18	68802110	GEAR 14,DAMPER	1
19	68802120	GEAR 11/34	1
20	35302270	SPRING,HOOK	1
21	35305060	LABEL, HIGH VOLTAGE CAUTION,L	1
22	35302410	LID,HIGH VOLTAGE TERMINAL	1
23	35302290	GUIDE,DRUM SHAFT	1
24	35302420	LOWER SHEET,TERMINAL INSULATOR	1
25	35302380	ACTUATOR,IU DETECTION	1
26	35302390	MOUNT,IU DETECTION SWITCH	1
27	68827010	SWITCH,INTERLOCK	1
28	35302210	PLATE SPRING A,DRUM UNIT HOLDER	1
29	35302220	PLATE SPRING B,DRUM UNIT HOLDER	1
30	35302520	UPPER MOUNT,FRAME SPRING	1
31	35302250	RIGHT LEVER,RELEASE RETAINING	1
32	35302160	LEVER,RELEASE RETAINING	1
33	35302360	COVER,TERMINAL	1
34	66006350	SWITCH,CASSETTE LIFT	1
35	35302400	TERMINAL BASE,MAIN CHARGER	1
36	35302340	SHEET,FRAME SHIELD (USA)	1
37	35302320	PROJECTION,DRUM UNIT LIMITATION (USA)	1
38	35306360	CUSHION,TRAY	2
39	35302500	PIN,MACHINE FULCRUM	2
40	29820420	PIN,BEARING	1

353-1

Ref. No.	Part. No.	Description	Quantity USA (120V)
41	35302430	SPRING,MAIN CHARGER	1
42	35302440	SPRING,IU DETECTION	2
43	35327170	GROUND WIRE,UPPER FRAME	1
44	35302470	STRAP A,MACHINE RELEASE	1
45	35302490	SHEET,FIXING	2
46	35327300	GROUND WIRE,CLEANING BRUSH	1
47	35302510	VIBRATION INSULATOR,DEVELOPING TERMINAL	2

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

FIG. 3 PAPER FEED TRAY SECTION

353




FIG. 3 PAPER FEED TRAY SECTION

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35306040	TRAY,PAPER FEED	1
2	35306050	GUIDE,TRAY	1
3	35306060	TRAY,AUXILIARY	1
4	35306070	FRONT CURSOR	1
5	35306080	REAR CURSOR	1
6	35306090	RACK,CURSOR	2
7	35306100	GEAR,CURSOR	1
8	35306110	SPRING,TRAY	1
9	35306190	PAD,TRAY	1
10	35306200	LEVER,GUIDE RELEASE	1
11	35305120	LABEL,CASSETTE OPERATION	1
12	35306340	SPONGE,TRAY	1
13	35306420	BRAKE,CURSOR	2

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

	A	B	C	D	E	F	G	H	I	J	
1											1
2											2
3											3
4											4
5											5
6											6
7											7
	A	B	C	D	E	F	G	H	I	J	

FIG. 4 DRIVING SECTION

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35306010	PULLEY,PAPER FEED	1
2	35306020	SHAFT,PAPER FEED ROLLER	1
3	35306030	COLLAR,PAPER FEED	4
4	35306120	SPRING,PAPER FEED CLUTCH	1
5	35306130	GEAR,PAPER FEED CLUTCH	1
6	35306140	BOSS,PAPER FEED CLUTCH	1
7	35306150	COLLAR,PAPER FEED CLUTCH	1
8	35306160	HOLDER,PAD	1
9	35306170	PAD,PAPER FEED	1
10	35306180	SPRING,PAD	1
11	63527240	PI,GP1A71A	1
12	35306210	UPPER ROLLER,FEED	1
13	35306220	LOWER ROLLER,FEED	1
14	35306230	UPPER GEAR,FEED ROLLER	1
15	35306240	GEAR 20,PAPER FEED IDLE	1
16	35306250	BUSHING 4	2
17	35306260	ACTUATOR,PAPER FEED DETECTION	1
18	35306270	SPRING,PRESSING	2
19	35393040	PARTS SOLENOID PAPER FEED(SP)	1
20	35306290	BUSHING 6,FEED	2
21	35306300	GROUND PLATE,PAPER FEED	1
22	35306320	SPONGE,PAD HOLDER	2
23	35306330	GUIDE FILM,PAD	1
24	35306350	SPRING,ACTUATOR	1
25	35322010	MOUNT,MOTOR	1
26	35322020	GEAR 20,PAPER FEED DRIVE	1
27	35322030	GEAR 16/24,PAPER FEED DRIVE	1
28	35322040	GEAR 18/21,PAPER FEED DRIVE	1
29	35322050	GEAR 96/20,MOTOR	1
30	35322070	GEAR 20/32,DEVELOPING DRIVE	1
31	35322090	GEAR 25/22,DRUM DRIVE	1
32	35322110	GEAR 16,DEVELOPING DRIVE	1
33	35322150	REINFORCEMENT,DRIVE	1
34	35322160	GEAR 20,FIXING DRIVE	1
35	35322170	GEAR 32,DEVELOPING JOINT	1
36	35393110	PARTS MOTOR MAIN(SP)	1
37	29806560	BUSHING 6	2
38	63511220	STOP RING,4	3
39	68827010	SWITCH,INTERLOCK	1
40	35302130	LEVER,SAFETY SWITCH	1

353

Ref. No.	Part. No.	Description	Quantity USA (120V)
41	35302140	MOUNT,SAFETY SWITCH	1
42	35302030	TERMINAL,DRUM GROUND	1
43	35302280	STAY,SENSOR	1
44	29820420	PIN,BEARING	1
45	35302450	SPRING B,SAFETY SWITCH	1
46	35302460	HOLDER,SAFETY SWITCH	1
47	35327290	JUNCTION WIRING,POWER SOURCE	1
48	35322220	GROUND PLATE,DRIVE	1
49	35306390	COLLAR B,PAPER FEED	2
50	35306400	SPONGE B,PAD HOLDER	1
51	35327280	JUNCTION WIRING,CONVEYING SWITCH	1
52	35322230	GEAR 64,DRIVE	1
53	35322240	GEAR 24,DRIVE JOINT	1
54	35322180	GEAR 20,FIXING COUPLER	1
55	35322190	GEAR 28,FIXING COUPLER	1
56	35322200	COUPLER,FIXING DRIVE	1
57	35322210	SPRING,FIXING COUPLER	1
58	35327320	GROUND WIRE,SOLENOID	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

FIG. 5 CHARGING SECTION

353




FIG. 5 CHARGING SECTION

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35316010	ROLLER,TRANSFER	1
2	35316020	BUSHING,TRANSFER	2
3	35316030	SPRING,TRANSFER	2
4	35316110	PULLEY C,TRANSFER ROLLER	2
5	35316050	GUIDE,TRANSFER	1
6	35316060	SPRING,TRANSFER GUIDE	2
7	35316080	UPPER TERMINAL,TRANSFER	1
8	35316090	MOUNT,CLEANING LAMP	1
9	35393130	PARTS LAMP CLEANING(SP)	1
10	35306380	SEAL,PAPER DUST DISPOSAL	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

FIG. 6 FIXING SECTION

353-1




FIG. 6 FIXING SECTION

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35320320	BUSHING B,HEAT ROLLER	1
2	35393070	PARTS ROLLER HEAT(SP)	1
3	35320030	BUSHING,HEAT ROLLER	1
4	35393080	PARTS ROLLER PRESSURE(SP)	1
5	35320380	BEARING,PRESS ROLLER	2
6	35393090	PARTS HEATER 120 FIXING(SP)	1
7	35320070	SEPARATION CLAW,HEAT ROLLER	2
8	35320080	PULLEY,EJECT	2
9	35320090	GEAR,HEAT ROLLER	1
10	35320100	GEAR,FIXING IDLE	1
11	35320110	UPPER HOUSING,FIXING	1
12	35320120	LOWER HOUSING,FIXING	1
13	35320130	TERMINAL,THERMOSTAT	1
14	35320140	FRONT TERMINAL,FIXING	1
15	35320150	REAR TERMINAL A,FIXING	1
16	35320160	REAR TERMINAL B,HEATER	1
17	35320170	SPRING,FIXING PRESSURE	2
18	35320180	SPRING,SEPARATION CLAW	2
19	35320190	SPRING,EJECT PULLEY	2
20	35320220	GROUND PLATE,HEAT ROLLER	1
21	35320370	HOLDER,PRESS ROLLER BEARING	2
22	35320250	THERMISTOR,FIXING	1
23	35320260	ACTUATOR,EJECT SWITCH	1
24	35320280	THERMAL PROTECTOR A	1
25	35320290	THERMAL PROTECTOR B	1
26	35320300	SPRING,EJECT ACTUATOR	1
27	35320310	GEAR,EJECT ROLLER	1
28	29820420	PIN,BEARING	1
29	35300010	EJECT ROLLER ASS'Y	1
30	35320360	FILM,FIXING THERMISTOR	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

This exploded view diagram illustrates the assembly of the HP LaserJet 1020 printer. The main body (1) is shown with various internal components like the fan (13), toner cartridge (21), and rollers (14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31) being installed. The diagram is labeled with numbers 1 through 31 and letters A through J, corresponding to the parts list on the right.

1
2
3
4
5
6
7

FIG. 7 ELECTRICAL COMPONENTS

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35393170	PARTS MAIN PCB ASS'Y ROM(SP)	1
2	35393190	PARTS ASS'Y GDI(SP)	1
3	35393050	PARTS UNIT SCANNER(SP)	1
4	35326010	MOUNT A,PCB	1
5	M1758010	FUSE GMC 8A(BUSSMANN)	2
6	63827080	FERRITE CORE	1
7	35327020	WIRE,POWER SOURCE	1
8	35327030	WIRE,LSU	1
9	35327040	WIRE,OUTPUT	1
10	35327060	WIRE,SWITCH	1
11	35327100	WIRE,HEATER	1
12	35327120	WIRE GDI1	1
13	35393120	PARTS FAN COOLING(SP)	1
14	35327160	WIRE,INLET	1
15	35312040	CAP,LSU	1
16	35327200	IC,GDI CPU	1
17	35327210	INSULATING PLATE PSU,SHEET	2
18	35393140	PARTS POWER SOURCE PCB 120(SP)	1
19	35393161	PARTS HIGH VOLTAGE UNIT PCB(SP)	1
20	78027100	POWER CORD(USA)	1
21	35304120	INNER COVER,COOLING FAN	1
22	35301030	INLET ASS'Y	1
23	*71827340	INLET 3P,POWER	1
24	35304061	REAR COVER	1
25	35312030	GROUND PLATE,LSU	1
26	M2108810	SPACER,KGLS-SRF(KITAGAWA)	7
27	35312020	COVER,LSU	1
28	67305310	CAUTION LABEL,HV	1
29	35393180	PARTS INDICATION PLATE PCB(SP)	1
30	35326060	GROUND PLATE,CIRCUIT PCB	1
31	M1754010	FUSE GMC 4A(BUSSMANN)	1
32	66927030	CORE,9-19X11	1
33	35368020	GLASS,COVER	1
34	63527320	MAIN SWITCH M	1

* Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

FIG. 8 IMAGING UNIT




FIG. 8 IMAGING UNIT

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35377020	SET,IU(H+STD.)EUR	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

FIG. 9 ACCESSORIES AND OPTION




FIG. 9 ACCESSORIES AND OPTION

Ref. No.	Part. No.	Description	Quantity USA (120V)
1	35327230	FD GDI	1
2	35305070	LABEL GDI,FD	1
3	35306410	GUIDE,AUXILIARY	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

Part. No.	Description	Quantity USA (120V)	Fig. No.
29806560	BUSHING 6	2	4
29820420	PIN,BEARING	3	2, 4, 6
35300010	EJECT ROLLER ASS'Y	1	6
35301030	INLET ASS'Y	1	7
35302010	FRAME,MACHINE	1	2
35302020	UPPER FRAME	1	2
35302030	TERMINAL,DRUM GROUND	1	4
35302040	TERMINAL,DEVELOPING BIAS	1	2
35302050	TERMINAL,SUB DEVELOPING BIAS	1	2
35302060	TERMINAL,TRANSFER MACHINE	1	2
35302070	TERMINAL,MAIN CHARGER	1	2
35302080	TERMINAL,GRID	1	2
35302090	TERMINAL,BRUSH	1	2
35302100	HOOK A	1	2
35302110	HOOK B	1	2
35302120	SPRING,HOOK	1	2
35302130	LEVER,SAFETY SWITCH	1	4
35302140	MOUNT,SAFETY SWITCH	1	4
35302160	LEVER,RELEASE RETAINING	1	2
35302170	SPRING,RELEASE RETAINING	3	2
35302210	PLATE SPRING A,DRUM UNIT HOLDER	1	2
35302220	PLATE SPRING B,DRUM UNIT HOLDER	1	2
35302240	HOLDER,GEAR DAMPER	1	2
35302250	RIGHT LEVER,RELEASE RETAINING	1	2
35302260	GROUND PLATE,FRAME	1	2
35302270	SPRING,HOOK	1	2
35302280	STAY,SENSOR	1	4
35302290	GUIDE,DRUM SHAFT	1	2
35302320	PROJECTION,DRUM UNIT LIMITATION (U	1	2
35302340	SHEET,FRAME SHIELD (USA)	1	2
35302360	COVER,TERMINAL	1	2
35302380	ACTUATOR,IU DETECTION	1	2
35302390	MOUNT,IU DETECTION SWITCH	1	2
35302400	TERMINAL BASE,MAIN CHARGER	1	2
35302410	LID,HIGH VOLTAGE TERMINAL	1	2
35302420	LOWER SHEET,TERMINAL INSULATOR	1	2
35302430	SPRING,MAIN CHARGER	1	2
35302440	SPRING,IU DETECTION	2	2
35302450	SPRING B,SAFETY SWITCH	1	4

Part. No.	Description	Quantity USA (120V)	Fig. No.
35302460	HOLDER,SAFETY SWITCH	1	4
35302470	STRAP A,MACHINE RELEASE	1	2
35302480	STRAP B,MACHINE RELEASE	1	2
35302490	SHEET,FIXING	2	2
35302500	PIN,MACHINE FULCRUM	2	2
35302510	VIBRATION INSULATOR,DEVELOPING TERMINAL	2	2
35302520	UPPER MOUNT,FRAME SPRING	1	2
35304010	UPPER COVER	1	1
35304020	COVER,RELEASE	1	1
35304050	BASE RUBBER	2	2
35304061	REAR COVER	1	7
35304070	BASE	1	2
35304080	LEVER,RELEASE	1	1
35304090	RETAINER,LEVER	2	1
35304100	JUNCTION PLATE,LED	1	1
35304110	LEVER B,RELEASE	1	1
35304120	INNER COVER,COOLING FAN	1	7
35304130	EXTERIOR COVER,COOLING FAN	1	1
35305060	LABEL, HIGH VOLTAGE CAUTION,L	1	2
35305070	LABEL GDI,FD	1	9
35305120	LABEL,CASSETTE OPERATION	1	3
35306010	PULLEY,PAPER FEED	1	4
35306020	SHAFT,PAPER FEED ROLLER	1	4
35306030	COLLAR,PAPER FEED	4	4
35306040	TRAY,PAPER FEED	1	3
35306050	GUIDE,TRAY	1	3
35306060	TRAY,AUXILIARY	1	3
35306070	FRONT CURSOR	1	3
35306080	REAR CURSOR	1	3
35306090	RACK,CURSOR	2	3
35306100	GEAR,CURSOR	1	3
35306110	SPRING,TRAY	1	3
35306120	SPRING,PAPER FEED CLUTCH	1	4
35306130	GEAR,PAPER FEED CLUTCH	1	4
35306140	BOSS,PAPER FEED CLUTCH	1	4
35306150	COLLAR,PAPER FEED CLUTCH	1	4
35306160	HOLDER,PAD	1	4
35306170	PAD,PAPER FEED	1	4
35306180	SPRING,PAD	1	4
35306190	PAD,TRAY	1	3
35306200	LEVER,GUIDE RELEASE	1	3
35306210	UPPER ROLLER,FEED	1	4

Part. No.	Description	Quantity USA (120V)	Fig. No.
35306220	LOWER ROLLER,FEED	1	4
35306230	UPPER GEAR,FEED ROLLER	1	4
35306240	GEAR 20,PAPER FEED IDLE	1	4
35306250	BUSHING 4	2	4
35306260	ACTUATOR,PAPER FEED DETECTION	1	4
35306270	SPRING,PRESSING	2	4
35306290	BUSHING 6,FEED	2	4
35306300	GROUND PLATE,PAPER FEED	1	4
35306320	SPONGE,PAD HOLDER	2	4
35306330	GUIDE FILM,PAD	1	4
35306340	SPONGE,TRAY	1	3
35306350	SPRING,ACTUATOR	1	4
35306360	CUSHION,TRAY	2	2
35306380	SEAL,PAPER DUST DISPOSAL	1	5
35306390	COLLAR B,PAPER FEED	2	4
35306400	SPONGE B,PAD HOLDER	1	4
35306410	GUIDE,AUXILIARY	1	9
35306420	BRAKE,CURSOR	2	3
35312020	COVER,LSU	1	7
35312030	GROUND PLATE,LSU	1	7
35312040	CAP,LSU	1	7
35316010	ROLLER,TRANSFER	1	5
35316020	BUSHING,TRANSFER	2	5
35316030	SPRING,TRANSFER	2	5
35316050	GUIDE,TRANSFER	1	5
35316060	SPRING,TRANSFER GUIDE	2	5
35316080	UPPER TERMINAL,TRANSFER	1	5
35316090	MOUNT,CLEANING LAMP	1	5
35316110	PULLEY C,TRANSFER ROLLER	2	5
35320030	BUSHING,HEAT ROLLER	1	6
35320070	SEPARATION CLAW,HEAT ROLLER	2	6
35320080	PULLEY,EJECT	2	6
35320090	GEAR,HEAT ROLLER	1	6
35320100	GEAR,FIXING IDLE	1	6
35320110	UPPER HOUSING,FIXING	1	6
35320120	LOWER HOUSING,FIXING	1	6
35320130	TERMINAL,THERMOSTAT	1	6
35320140	FRONT TERMINAL,FIXING	1	6
35320150	REAR TERMINAL A,FIXING	1	6

Part. No.	Description	Quantity USA (120V)	Fig. No.
35320160	REAR TERMINAL B,HEATER	1	6
35320170	SPRING,FIXING PRESSURE	2	6
35320180	SPRING,SEPARATION CLAW	2	6
35320190	SPRING,EJECT PULLEY	2	6
35320220	GROUND PLATE,HEAT ROLLER	1	6
35320250	THERMISTOR,FIXING	1	6
35320260	ACTUATOR,EJECT SWITCH	1	6
35320280	THERMAL PROTECTOR A	1	6
35320290	THERMAL PROTECTOR B	1	6
35320300	SPRING,EJECT ACTUATOR	1	6
35320310	GEAR,EJECT ROLLER	1	6
35320320	BUSHING B,HEAT ROLLER	1	6
35320350	FILM,EJECT	1	1
35320360	FILM,FIXING THERMISTOR	1	6
35320370	HOLDER,PRESS ROLLER BEARING	2	6
35320380	BEARING,PRESS ROLLER	2	6
35322010	MOUNT,MOTOR	1	4
35322020	GEAR 20,PAPER FEED DRIVE	1	4
35322030	GEAR 16/24,PAPER FEED DRIVE	1	4
35322040	GEAR 18/21,PAPER FEED DRIVE	1	4
35322050	GEAR 96/20,MOTOR	1	4
35322070	GEAR 20/32,DEVELOPING DRIVE	1	4
35322090	GEAR 25/22,DRUM DRIVE	1	4
35322110	GEAR 16,DEVELOPING DRIVE	1	4
35322150	REINFORCEMENT,DRIVE	1	4
35322160	GEAR 20,FIXING DRIVE	1	4
35322170	GEAR 32,DEVELOPING JOINT	1	4
35322180	GEAR 20,FIXING COUPLER	1	4
35322190	GEAR 28,FIXING COUPLER	1	4
35322200	COUPLER,FIXING DRIVE	1	4
35322210	SPRING,FIXING COUPLER	1	4
35322220	GROUND PLATE,DRIVE	1	4
35322230	GEAR 64,DRIVE	1	4
35322240	GEAR 24,DRIVE JOINT	1	4
35326010	MOUNT A,PCB	1	7
35326060	GROUND PLATE,CIRCUIT PCB	1	7
35327020	WIRE,POWER SOURCE	1	7
35327030	WIRE,LSU	1	7
35327040	WIRE,OUTPUT	1	7
35327060	WIRE,SWITCH	1	7
35327100	WIRE,HEATER	1	7

Part. No.	Description	Quantity USA (120V)	Fig. No.
35327120	WIRE,GDI1	1	7
35327160	WIRE,INLET	1	7
35327170	GROUND WIRE,UPPER FRAME	1	2
35327200	IC,GDI CPU	1	7
35327210	INSULATING PLATE PSU,SHEET	2	7
35327230	FD GDI	1	9
35327280	JUNCTION WIRING,CONVEYING SWITCH	1	4
35327290	JUNCTION WIRING,POWER SOURCE	1	4
35327300	GROUND WIRE,CLEANING BRUSH	1	2
35327320	GROUND WIRE,SOLENOID	1	4
35368020	GLASS,COVER	1	7
35377020	SET,IU(H+STD.)EUR	1	8
35393040	PARTS SOLENOID PAPER FEED(SP)	1	4
35393050	PARTS UNIT SCANNER(SP)	1	7
35393070	PARTS ROLLER HEAT(SP)	1	6
35393080	PARTS ROLLER PRESSURE(SP)	1	6
35393090	PARTS HEATER 120 FIXING(SP)	1	6
35393110	PARTS MOTOR MAIN(SP)	1	4
35393120	PARTS FAN COOLING(SP)	1	7
35393130	PARTS LAMP CLEANING(SP)	1	5
35393140	PARTS POWER SOURCE PCB 120(SP)	1	7
35393161	PARTS HIGH VOLTAGE UNIT PCB(SP)	1	7
35393170	PARTS MAIN PCB ASS'Y ROM(SP)	1	7
35393180	PARTS INDICATION PLATE PCB(SP)	1	7
35393190	PARTS ASS'Y GDI(SP)	1	7
63511220	STOP RING,4	3	4
63527240	PI,GP1A71A	1	4
63527320	MAIN SWITCH M	1	7
63827080	FERRITE CORE	1	7
66006350	SWITCH,CASSETTE LIFT	1	2
66205080	LABEL,FUSE	1	1
66927030	CORE,9-19X11	1	7
67305310	CAUTION LABEL,HV	1	7
68305090	CAUTION LABEL,HIGH TEMPERATURE L(E	1	1
68802110	GEAR 14,DAMPER	1	2
68802120	GEAR 11/34	1	2
68827010	SWITCH,INTERLOCK	2	2, 4
71827340	INLET 3PPOWER	1	7
76705140	CAUTION LABEL	1	1
78027100	POWER CORD(USA)	1	7

Part. No.	Description	Quantity USA (120V)	Fig. No.
M1754010	FUSE GMC 4A(BUSSMANN)	1	7
M1758010	FUSE GMC 8A(BUSSMANN)	2	7
M2108810	SPACER,KGLS-5RF(KITAGAWA)	7	7

NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	35304010	UPPER COVER	DP-560	60Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	35301030	INLET ASS'Y	•71827340	INLET 3P, POWER

4. See the last page of this parts list for the classification of the screws in the illustrations.

5. Items indicated by shaded areas () are supply parts and should be ordered through your Regional Office.

MITA COPYSTAR AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (201) 808-8444
FAX : (201) 882-6000

New York Show Room:

149 West 51st street,
New York, NY 10019
TEL : (212) 554-2679
FAX : (212) 554-2625

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (201) 808-8444
FAX : (201) 882-4401

Midwestern Region:

225 Spring Lake Drive,
Itasca, Illinois 60143
TEL : (630) 250-7447
FAX : (630) 250-8787

Western Region:

14101 Alton Parkway,
P.O.Box 57006,Irvine,
California 92618-7006
TEL : (714) 457-9000
FAX : (714) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (214) 550-8987
FAX : (214) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (214) 659-0055
FAX : (214) 570-5816

MITA COPYSTAR CANADA, LTD.

6120 Kestrel Road,
Mississauga, Ontario L5T 1S8
TEL : (905) 670-4425
FAX : (905) 670-8116

MITA COPYSTAR MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Delegación Azcapotzalco
México, D.F. C.P. 02130
TEL : 3-83-27-41
FAX : 3-83-78-04

© 1997 MITA INDUSTRIAL CO., LTD.

MITA and *mita* are registered trademarks of MITA INDUSTRIAL CO., LTD.

Printed in U.S.A.