

mita[®]

EF-100

PARTS LIST

Published in Sept.'98
5A270830

EF-100

NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5A213560	SPRING A	EF-100	60Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	5A213310	FRAME SUB ASSY	•5A213450	FRAME
			•5A213460	PLATE CONTROL

- Parts without "*" are produced only upon order.

Parts List

EF-100

———— CONTENTS ————

FIG.1	ENVELOPE FEEDER ······	2
-------	------------------------	---

FIG. 1 ENVELOP FEEDER

5A2




FIG. 1 ENVELOP FEEDER

5A2

Ref. No.	Part. No.	Description
1	82220092	EF-100
2	5A213560	SPRING A
3	*5A213070	HOOK
4	5A213320	BUTTON RELEASE
5	5A213330	GEAR Z12
6	5A213340	GEAR Z23-Z63
7	5A213350	GEAR Z27-Z58
8	5A213360	GEAR Z26A
9	5A213370	GEAR Z26B
10	5A213380	GEAR Z18
11	5A213390	GEAR Z19
12	5A213400	BUSHING A
13	5A213410	BUSHING B
14	5A213420	SPRING B
15	5A213430	SPRING CLUTCH
16	*5A213080	ROLLER ASS'Y A
17	*5A213090	ROLLER ASS'Y B
18	5A213440	PAD MOTOR
19	*5A213100	DC MOTOR ASS'Y
20	*5A213110	SENSOR ASS'Y A
21	*5A213120	PWB MAIN
22	5A213470	TP TAP SCREW
23	5A213480	BIND TAP SCREW
24	5A213290	PAN HEAD SCREW
25	5A213490	E STOP RING
26	5A213490	E STOP RING
27	5A213470	TP TAP SCREW
28	5A213310	FRAME SUB ASS'Y
29	*5A213450	FRAME
30	*5A213460	PLATE CONTROL
31	5A213500	PLATE CENTER
32	*5A213160	PLATE GUIDE L
33	*5A213150	PLATE GUIDE R
34	5A213510	RACK
35	5A213520	GEAR Z19
36	*5A213130	LEVER SENSOR
37	*5A213200	COVER UNDER
38	*5A213140	SPRING EARTH
39	*5A213180	HOLDER WEIGHT
	5A213540	SHAFT LATCH

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

Ref. No.	Part. No.	Description
40	5A213550	SPRING PAD
41	*5A213190	SENSOR ASS'Y B
42	5A213530	ARM ASS'Y
43	*5A213590	SHAFT WEIGHT
44	*5A213580	ARM
45	*5A213170	SEPARATER ASS'Y
46	*5A213600	HOLDER SEPARATER
47	*5A213610	PAD SEPARATER
48	5A213620	PAN HEAD SCREW
49	5A213300	TP TAP SCREW
50	5A213630	E STOP RING
51	*5A213220	COVER RIGHT
52	5A213640	COVER TOP ASS'Y
53	*5A213650	LABEL SERIAL
54	*5A213670	COVER TOP
55	*5A213680	HOLDER CONNECTOR
56	*5A213240	PWB CONNECTOR ASS'Y
57	5A213290	PAN HEAD SCREW
58	5A213300	TP TAP SCREW
59	5A213470	TP TAP SCREW
60	*5A213210	TRAY STACKER
61	*5A213230	COVER LEFT
62	5A213570	CHANNEL SENSOR
63	5A213300	TP TAP SCREW

• Parts without "*" are produced only upon order.

Part. No.	Description	Quantity USA (120V)	Fig. No.
5A213070	HOOK	1	1
5A213080	ROLLER ASS'Y A	1	1
5A213090	ROLLER ASS'Y B	1	1
5A213100	DC MOTOR ASS'Y	1	1
5A213110	SENSOR ASS'Y A	1	1
5A213120	PWB MAIN	1	1
5A213130	LEVER SENSOR	1	1
5A213140	SPRING EARTH	1	1
5A213150	PLATE GUIDE R	1	1
5A213160	PLATE GUIDE L	1	1
5A213170	SEPARATER ASS'Y	1	1
5A213180	HOLDER WEIGHT	1	1
5A213190	SENSOR ASS'Y B	1	1
5A213200	COVER UNDER	1	1
5A213210	TRAY STACKER	1	1
5A213220	COVER RIGHT	1	1
5A213230	COVER LEFT	1	1
5A213240	PWB CONNECTOR ASS'Y	1	1
5A213290	PAN HEAD SCREW	2	1
5A213300	TP TAP SCREW	3	1
5A213310	FRAME SUB ASS'Y	1	1
5A213320	BUTTON RELEASE	1	1
5A213330	GEAR Z12	1	1
5A213340	GEAR Z23-Z63	1	1
5A213350	GEAR Z27-Z58	1	1
5A213360	GEAR Z26A	1	1
5A213370	GEAR Z26B	1	1
5A213380	GEAR Z18	1	1
5A213390	GEAR Z19	1	1
5A213400	BUSHING A	1	1
5A213410	BUSHING B	1	1
5A213420	SPRING B	1	1
5A213430	SPRING CLUTCH	1	1
5A213440	PAD MOTOR	1	1
5A213450	FRAME	1	1
5A213460	PLATE CONTROL	1	1
5A213470	TP TAP SCREW	3	1
5A213480	BIND TAP SCREW	1	1
5A213490	E STOP RING	2	1
5A213500	PLATE CENTER	1	1

Part. No.	Description	Quantity USA (120V)	Fig. No.
5A213510	RACK	1	1
5A213520	GEAR Z19	1	1
5A213530	ARM ASS'Y	1	1
5A213540	SHAFT LATCH	1	1
5A213550	SPRING PAD	1	1
5A213560	SPRING A	1	1
5A213570	CHANNEL SENSOR	1	1
5A213580	ARM	1	1
5A213590	SHAFT WEIGHT	1	1
5A213600	HOLDER SEPARATER	1	1
5A213610	PAD SEPARATER	1	1
5A213620	PAN HEAD SCREW	1	1
5A213630	E STOP RING	1	1
5A213640	COVER TOP ASS'Y	1	1
5A213650	LABEL SERIAL	1	1
5A213670	COVER TOP	1	1
5A213680	HOLDER CONNECTOR	1	1
82220092	EF-100	1	1

MITA COPYSTAR AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Show Room:

149 West 51st street,
New York, NY 10019
TEL : (212) 554-2679
FAX : (212) 554-2625

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

225 Spring Lake Drive,
Itasca, Illinois 60143
TEL : (630) 250-7447
FAX : (630) 250-8787

Western Region:

14101 Alton Parkway,
P.O.Box 57006,Irvine,
California 92618-7006
TEL : (714) 457-9000
FAX : (714) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

MITA COPYSTAR CANADA, LTD.

6120 Kestrel Road,
Mississauga, Ontario L5T 1S8
TEL : (905) 670-4425
FAX : (905) 670-8116

MITA COPYSTAR MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Delegación Azcapotzalco
México, D.F. C.P. 02130
TEL : 3-83-27-41
FAX : 3-83-78-04

MITA COPYSTER SOUTH AMERICA S.A.

Av. Mitre 1345 Florida (1602)
Pcia, Buenos Aires,Argentina
TEL : (54) 1-730-1070
FAX : (54) 1-760-2071

© 1998 MITA INDUSTRIAL CO., LTD.

MITA and *mita* are registered trademarks of MITA INDUSTRIAL CO., LTD.

Printed in U.S.A.