



PRINTER OPTIONS

DU-1

PARTS CATALOGUE

DU-1 Parts Catalogue

Table of Contents

Stacker Assembly (Fig.1).....	3
Top Cover Assembly (Fig.2).....	7
Base Assembly (Fig.3).....	9
Overall (Fig.4).....	13


Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.

Fig.1 - Stacker Assembly




Ref No.	Part Code	Description	Quantity
01-001	5SNSP0008871	BASE STACKER ASSY	1
01-002	5SNSP0008909	ROLLER PINCH	1
01-003	5SNSP0008940	BRACKET ROLLER	1
01-004	5SNSP0008909	ROLLER PINCH	1
01-005	5SNSP0008884	CONE. CORD S00750	1
01-006	5SNSP0008868	SNESOR ASSY	1
01-007	5SNSP0008850	EPS ASSY	1
01-008	5SNSP0008847	ADJUST ASSY	1
01-009	5SNSP0008872	GUIDE ENT ASSY	1
01-010	5SNSP0008973	GATE ENT	1
01-011	5SNSP0009009	BUSHING 4	1
01-012	5SNSP0008852	DS SENSOR ASSY	1
01-013	5SNSP0008982	SPRING GATE B	1
01-014	5MVX717NN005	SNAP BAND	1
01-015	5SNSP0008976	ROLLER C	1
01-016	5SNSP0009016	BUSH DS	2
01-017	5SNSP0008912	GEAR Z16	1
01-018	5SNSP0008918	GUIDE PRONT	1
01-019	5SNSP0008944	GUIDE ENT B	1
01-020	5SNSP0008974	ROI.1.PR A	1
01-021	5SNSP0009016	BUSH DS	2
01-022	5SNSP0008901	GEAR Z16	1
01-023	5SNSP0008917	PULLEY T20	1
01-024	5SNSP0008975	ROLLER B	1
01-025	5SNSP0009016	BUSH DS	2
01-026	5SNSP0008932	FLANGE	1
01-027	5SNSP0008917	PULLEY T20	2
01-028	5SNSP0008721	CLUTCH FEED DRIVE	1
01-029	5SNSP0008906	GEAR Z28-T20	1
01-030	5SNSP0008919	GUIDE COVER B	1
01-031	5SNSP0008873	GUIDE COVER ASSY	1
01-032	5SNSP0008943	GUIDE PLATE B	1
01-033	5SNSP0008874	GUIDE PLATE ASSY	1
01-034	5SNSP0008953	SPRING EARTH	1
01-035	5SNSP0008848	PU ROLLER ASSY	1
01-036	5SNSP0009016	BUSH DS	2
01-037	5SNSP0008902	GEAR Z20	1
01-038	5SNSP0008851	JOINT C ASSY	1
01-039	5SNSP0008912	GEAR Z16	1
01-040	5SNSP0008983	SPRING JOINT C	1
01-041	5SNSP0008978	BELT T106	1
01-042	5SNSP0008979	BELT T113	1
01-043	5SNSP0008927	COVER CLT	1
01-044	5SNSP0008946	FRONT COVER ASSY	1
01-045	5SNSP0008933	COVER HARNESS	1

Ref No.	Part Code	Description	Quantity
01-046	5SNSP0008959	BRACKET ADJUSTER	1
01-047	5SNSP0009000	SCREW ADJUSTER	1
08-001	5SNSP0008928	BASE STACKER	1
08-002	5SNSP0008996	FILM SENSOR	1
10-001	5SNSP0008936	BRACKET EPS	1
10-002	5SNSP0008715	SENSOR	1
10-003	5SNSP0008907	LEVER EPS	1
10-004	5SNSP0008964	SHAFT EPS	1
11-001	5SNSP0008921	BASE ADJUST	1
11-002	5SNSP0008865	ADJUSTER-L ASSY	1
11-003	5SNSP0008866	ADJUSTER-R ASSY	1
11-004	5SNSP0008915	RACK ADJUSTER	2
11-005	5SNSP0008911	PINION ADJUSTER	1
11-006	5SNSP0008905	GEAR Z18-67	1
11-007	5SNSP0008908	GEAR Z148	1
11-008	5SNSP0008999	FASTENER 4	1
11-009	5SNSP0009007	MOTOR ADJUSTER	1
11-010	5SNSP0008949	HPS ASSY	1
12-001	5SNSP0008942	GUIDE ENT A	1
12-002	5SNSP0009005	SHEET ENT	1
13-001	5SNSP0008937	BRACKET DS SENSOR	1
13-002	5SNSP0008879	PWB DS SENSOR	1
14-001	5SNSP0008920	GUIDE COVERT	1
14-002	5SNSP0008967	SHAFT PINCH	1
14-003	5SNSP0008923	ROLLER PINCH	2
14-004	5SNSP0008939	SPRING PINCH F	1
15-001	5SNSP0008945	GUIDE PLATE A	1
15-002	5SNSP0008967	SHAFT PINCH	1
15-003	5SNSP0008923	ROLLER PINCH	2
15-004	5SNSP0008938	SPRING PINCH R	1
16-001	5SNSP0008916	FRAME PU	1
16-002	5SNSP0008965	PIN PU	1
16-003	5SNSP0008972	ROLLER PU	1
16-004	5SNSP0008980	BELT T59	1
16-005	5SNSP0008966	SHAFT PU	1
16-006	5SNSP0008981	SPRING CLT	1
16-007	5SNSP0008970	CLT-PU	1
16-008	5SNSP0008972	ROLLER PU	1
17-001	5SNSP0008941	BRACKET JOINT C	1
17-002	5SNSP0008912	GEAR Z16	1
17-003	5SNSP0008910	COLLAR B	1
18-001	5SNSP0008922	COVER FRONT	1
18-002	5SNSP0008772	SPRING TENSION	4
18-003	5SNSP0008924	ROLLER EXIT	2
18-004	5SNSP0008774	SHAFT ROLLER PINCH	2


Ref No.	Part Code	Description	Quantity
19-001	5SNSP0008926	BRACKET SOLENOID	1
19-002	5SNSP0008727	SOLENOID	1
26-001	5SNSP0008913	ADJUSTER L	1
26-002	5SNSP0008971	FILM ADJUSTER	1
27-001	5SNSP0008914	ADJUSTER R	1
27-002	5SNSP0008971	FILM ADJUSTER	1

Fig.2 - Top Cover Assembly



Ref No.	Part Code	Description	Quantity
02-001	5SNSP0008887	COVER TOP F	1
02-002	5SNSP0008960	PLATE TOP	1
02-003	5SNSP0008977	ARM	1
02-004	5SNSP0008858	SOLENOID ASSY	1
02-005	5SNSP0008989	SPRING LOCK	1

Fig.3 - Base Assembly




Ref No.	Part Code	Description	Quantity
03-001	5SNSP0008869	BASE SUB ASSY	1
03-002	5SNSP0008889	COVER REAR	1
03-003	5SNSP0008987	SPRING R COVER	1
03-004	5SNSP0008904	LEVER LOCK	2
03-005	5SNSP0008988	SPRING LOCK DS	2
03-006	5SNSP0008855	LED ASSY	1
03-007	5SNSP0008885	CONN. CORD S00751	1
03-008	5SNSP0008880	CONN. CORD S00716	1
03-009	5SNSP0008949	BRACKET DB CONNECTOR	1
03-010	5SNSP0008883	CONN. CORD S00719	1
03-011	5SNSP0008997	STUD CONNECTOR	2
03-012	5SNSP0008856	PASSAGE ASSY	1
03-013	5SNSP0008951	PLATE EARTH	1
03-014	5SNSP0008857	DRIVE ASSY	1
03-016	5SNSP0009004	STAD FRAME	1
03-017	5SNSP0008876	PWB REAR SW	1
03-018	5SNSP0009634	PWB MAIN	1
04-001	5SNSP0008886	BASE	1
04-002	5SNSP0008688	FOOT	4
04-003	5SNSP0008993	SEAT RAIL	2
05-001	5SNSP0008870	LED COYER ASSY	1
05-002	5SNSP0008877	PWB LED	1
06-001	5SNSP0008891	BASE PASSAGE	1
06-002	5SNSP0008860	FRAME L ASSY	1
06-003	5SNSP0008859	PASSAGE GUIDE ASSY	1
06-004	5SNSP0008957	FRAME R	1
06-005	5SNSP0008946	GUIDE PASSAGE A	1
06-006	5SNSP0008929	GATE DB1	
06-007	5SNSP0009009	BUSHING 4	1
06-008	5SNSP0008931	LEVER GATE B	1
06-009	5MBCG3060XSN	G STOP RING	2
06-010	5SNSP0008958	LINK GATE	1
06-011	5MBCG2060XSN	G STOP RING	2
06-012	5SNSP0008990	SPRING GATE A	1
07-001	5SNSP0008861	DRIVE SUB ASSY A	1
07-002	5SNSP0008862	DRIVE SUB ASSY B	1
07-003	5SNSP0008985	SPRING JOINT A	1
07-004	5SNSP0008992	SPRING JOINT C	1
07-005	5SNSP0008963	SHAFT CLT	1
07-006	5SNSP0008896	GEAR CLT Z18	1
07-007	5SNSP0008895	GEAR CLT Z24	1
07-008	5SNSP0009012	BUSHING 6	2
07-009	5SNSP0008894	GEAR Z24	1
07-010	5SNSP0008867	TENSION ASSY	1
07-011	5SNSP0008998	STUD TENSION	1

Ref No.	Part Code	Description	Quantity
07-012	5SNSP0008969	BELT T158	1
07-013	5SNSP0008962	SHAFT B	1
07-014	5SNSP0008917	PULLEY T20	1
07-015	5SNSP0008932	FLANGE	1
07-016	5SNSP0009012	BUSHING 6	2
07-017	5SNSP0008893	GEAR H44	1
07-018	5SNSP0008738	GEAR FEED Z16	1
07-020	5SNSP0008892	GEAR H16-T56	1
07-021	5SNSP0009001	BEARING 6	1
07-022	5SNSP0009002	BUSHING SLEEVE	1
07-023	5SNSP0008711	PULLEY ENCODER P16	1
07-024	5SNSP0008968	BELT T95	1
07-025	5SNSP0008715	SENSOR	1
07-026	5SNSP0008714	BRACKET ENCODER	1
07-027	5SNSP0008952	PIECE EARTH	1
07-028	5SNSP0009013	PIECE EMC	1
07-029	5SNSP0009014	CAP EMC	1
07-030	5SNSP0008882	CONN. CORD S00718	1
07-031	5MVX118NN001	MINI CLAMP	1
07-032	5MVK121NB003	EDGING SADDLE	7
07-033	5MVX717NN005	SNAP BAND	2
07-034	5SNSP0008994	RUBBER	5
11-001	5SNSP0008921	BASE ADJUST	1
11-002	5SNSP0008865	ADJUSTER-L ASSY	1
11-003	5SNSP0008866	ADJUSTER-R ASSY	1
11-004	5SNSP0008915	RACK ADJUSTER	2
11-005	5SNSP0008911	PINION ADJUSTER	1
11-006	5SNSP0008905	GEAR Z18-67	1
11-007	5SNSP0008908	GEAR Z48	1
11-008	5SNSP0008999	FASTENER 4	1
11-009	5SNSP0009007	MOTOR ADJUSTER	1
11-010	5SNSP0008849	HPS ASSY	1
20-001	5SNSP0008890	COVER PANEL	1
20-002	5SNSP0008991	SHEET PANEL	1
21-001	5SNSP0008956	FRAME L	1
21-002	5MVK121NB002	EDGING SADDLE	1
21-003	5SNSP0008930	LEVER GATE A	1
22-001	5SNSP0008925	GUIDE PASSAGE B	1
22-002	5SNSP0008950	BRACKET DB SEBSOR	1
22-003	5SNSP0009008	SENSOR	1
22-004	5SNSP0008881	CONN. CORD S00717	1
23-001	5SNSP0008954	FRAME DRIVE A	1
23-002	5SNSP0009006	MOTOR MAIN	1
23-003	5SNSP0008863	JOINT B ASSY	1
23-004	5SNSP0008738	GEAR FEED Z16	1

Ref No.	Part Code	Description	Quantity
23-005	5SNSP0008900	GEAR Z16-T20	1
23-006	5SNSP0008932	FLANGE	1
25-001	5SNSP0008961	BRACKET TENSION	1
25-002	5SNSP0008917	PULLEY T20	1
25-003	5SNSP0008932	FLANGE	1
28-001	5SNSP0008935	BRACKET HPS	1
28-002	5SNSP0008715	SENSOR	1
29-001	5SNSP0008948	BRACKET JOINT B	1
29-002	5SNSP0008899	GEAR Z16	2
29-003	5SNSP0008903	COLLAR A	2
30-001	5SNSP0008947	BRACKET JOINT A	1
30-002	5SNSP0008899	GEAR Z16	1
30-003	5SNSP0008903	COLLAR A	1

Fig.4 - Overall



Ref No.	Part Code	Description	Quantity
50-001	5SNSP0008853	BASE ASSY	1
50-002	5SNSP0009018	STACKER ASSY	1
50-003	5SNSP0008854	TOP COVER ASSY	1
50-004	5SNSP0008888	COVER TOP R	1
50-005	5MVVSDU1***1	LABEL SERIAL	1