



LASERBEAM PRINTER

F-3300



PARTS CATALOGUE

06-11-1998

F-3300 Parts Catalogue

Table of Contents

Covers (Fig.1)	3
Upper Frame (Fig.2)	5
Lower Frame (Fig.3)	8
Controller and Power Supply (Fig.4)	11
Paper Feed Unit (Fig.5)	13
Face-down Unit (Fig.6)	16
Harness- Lower Unit (Fig.7a)	18
Harness - Upper Unit (Fig.7b)	20
Fuser Unit (Fig.10)	22
Scanner Unit (Fig.11)	24

Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:


'Ref No.' Reference number which corresponds to the parts in the figure
'Part code' Part code which identifies the part
'Part description' A brief description of the part
'Quantity' Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.

Consumables and Maintenance Kits


TK-7	Toner Kit
DK-6	Drum (12K pages)
DV-11	Developer (50K pages)
FK-8	Fuser (100K pages)

Fig.1 – Covers



Ref No.	Part Code	Description	Quantity
01-001	VX875SW003	Right Cover	1
01-002	AVCOVER142	Top Cover Assy	1
01-003	AYF3300*36	FD Sub Cover Assy	1
01-004	VX962SW003	Rear Cover	1
01-005	VX942SW002	Blind Cover	1
01-006	VB762SW012	Left Cover	1
01-007	VX531SH001	Panel Cover	1
01-008	VX631SH001	Option Panel	1
01-009	VB873SH011	Controller Panel R	1
01-010	VB222RB001	Cord Press	2
01-011	VX864SH001	Controller Panel F	1
01-012	APRVRC1004AH	PWB KP-130A	1
01-013	VS818RF005	Seal Cover	1
01-014	AYF3300*51	Key Board Assy	1
01-015	AYF3300*52	FRT Cover Assy	1
01-016	VN110SH018	Knob	1
	AMW****09	Print Tray	1
	VB873SW017	DLP Cover	1


Fig.2 – Upper Frame



Ref No.	Part Code	Description	Quantity
02-001	ML144SL001	Hook Plate B	1
02-002	VX632DN001	Hinge Hook B	1
02-003	MW172LJ003	Hinge Spring	1
02-004	MX861SL003	Hinge Arm	1
02-005	MX433SL002	Hook Plate A	1
02-006	VX654DN001	Hinge Hook A	1
02-007	VX643DG001	Level DLP A	1
02-008	VX622EB001	Level DLP B	1
02-009	VF121XN001	Bushing DLP A	1
02-010	AYF3300*15	DLP Connector Assy	1
02-011	VX661SB004	Guide DLP F	1
02-012	MW162LJ006	Spring DLP B	1
02-013	VX641EB002	Lever DLP F	1
02-014	VX651DL001	Lever DLP C	1
02-015	AYF2010*10	Counter Bkt Assy	1
02-016	VF277NB006	Bushing	2
02-017	AVFRAME067	Frame Assy	1
02-018	VX221DB006	Frame Guide F	1
02-019	VS642VF002	Seal Frame F	1
02-020	MX431RD004	Plate Earth F	1
02-021	NXGP1A05HR*01	PT Sensor	1
02-022	AYF1010*67	M Feed Guide Assy	1
02-023	AYF1800*25	Erase Assy	1
02-024	VS818RJ003	Seal Drum FR	1
02-025	VS768RF001	Pad Fuser Upper F	1
02-026	VS768RF002	Pad Fuser Upper R	1
02-027	MP421LJ001	Pressure A	1
02-028	MP632LJ002	Pressure B	1
02-029	MP632LJ001	Pressure C	1
02-030	MG132SX001	Gear Z23	1
02-031	BE1280ZZ**	Bearing	1
02-032	MG122SX001	Gear Z18	1
02-033	AYF1800*49	DLP Joint Assy	1
02-034	MU541SL001	Sorter Connector Bkt	1
02-035	VS627RF003	Seal Holder	1
02-036	VX221DN005	Frame Guide R	1
02-037	MS876SL003	Top Cover Plate	1
02-038	AVFILTR001	Filter Assy	1
02-039	APRZZC1012BH	PW Board Assy	1
02-040	VX331SB005	Cover Contact	1
02-041	VS642VF003	Seal Frame R	1
02-042	MG158SX001	Gear Z41-Z22B	1
02-043	VG144DB002	Gear Z36 B	1
02-044	AYF1800*50	Drive Assy	1
02-045	VB763SN001	Duct R	1

Ref No.	Part Code	Description	Quantity
02-046	VB765SN001	Duct F	1
02-047	VS828RF001	Seal Scanner Pad	1
02-048	VS318RF008	Seal Frame A	2
02-049	AYF3300*32	Hopper SW Sub Assy	1
02-050	VX661SB005	Guide DLP R	1
02-051	AYF3300*33	DLP Lever Assy	1
02-052	VX221NN019	Locking Spacer LS-3S	6
02-053	TNB55101***01	High Voltage Unit	1
02-054	APRCZG2003DH	PW Board Assy	1
02-055	M162SP001	Spring DLP A	1
02-056	VX651DL002	Lever DIP D	1
02-057	VX331DL001	Lever DLP E	1
02-058	TNB66202***01	Main HV Unit	1
02-059	VX333SN002	Connect MCH	1
02-060	AYF1800*47	Main Motor Assy	1
02-061	AYF1800*63	Fan Assy	1


Fig.3 – Lower Frame



Ref No.	Part Code	Description	Quantity
03-001	VS722KF001	Guide Sheet F	1
03-002	VS622KF001	Guide Sheet R	1
03-003	VX832DB001	Controller Guide B	1
03-004	MC832SL001	Base Support	1
03-005	VS428RH002	Tank Pad A	1
03-006	VS439RH002	Tank Pad B	1
03-007	VB222RB001	Cord Press	7
03-008	VX964SB002	Inner Cover F	1
03-009	MX752CJ001	Controller Earth A	1
03-010	MZ173SL001	Earth Plate	1
03-011	MX762CJ001	Controller Earth B	1
03-012	VS642KC001	Tray Hole Seal	2
03-013	YHF102004**01	Fuse Block	1
03-014	YFBQ50205**01	Fuse	1
03-015	VX822DB001	Controller Guide A	1
03-016	AVBASE*006	Base Assy	1
03-017	MX622SL001	Base Hinge Plate L	1
03-018	MX332SM001	Cord Keep	1
03-019	MS536SL003	Plate Feed Frame	1
03-020	ACCNAN7GEA	Conn.Cord PCA2031	1
03-021	AYF3000*01	Lock Plate Assy	1
03-022	VX766SB008	Cover Inner A	1
03-023	MX764SL005	Arm Frame L	1
03-024	AYF3000*02	Pressure Arm Assy	1
03-025	MW905SM001	Torsion Bar A	1
03-026	MW905SM002	Torsion Bar B	1
03-027	MX764SL006	Arm Frame R	1
03-028	FNZSB22100501	Noise Filter	1
03-029	MU686SL003	Plate Elec	1
03-030	AYF3300*34	Elec Plate Assy	1
03-031	VX332XH002	TC Receptacle	1
03-032	MX763SL007	Inlet Cover	1
03-033	VX635CB001	Power Cord Cover	1
03-034	APRHCG2003DH	PW Board Assy	1
03-035	TNB66201***02	Solidate Relay	1
03-036	ZR1G012301*01	Solidate Relay	1
03-037	VX221NN019	Locking Spacer LS-35	2
03-038	VK121NB002	Edging Saddle	2
03-039	MX321SM001	Cord Keep	1
03-040	MX765SL004	Cord Part Plate	1
03-041	MX662SL003	Base Hinge Plate R	1
03-042	MT264LJ006	Bar Stopper	1
03-043	ML622LJ001	Bar Stopper Spring	1
03-044	AYMT910*21	Main SW BKT Assy	1
03-045	AYF1010*95	Cassette SW Assy	1


Ref No.	Part Code	Description	Quantity
03-046	APRSS005FA	PW Board Assy	1
03-047	MX222RJ001	Sensor Earth Plate	1
03-048	MS746SB001	Sensor Plate	1
03-049	VX766SB009	Cover Inner B	1
03-050	AYF1800*58	P.Guide Plate Assy	1
03-051	AVSH1LD030	TC Assy	1

Fig.4 – Controller and Power Supply



Ref No.	Part Code	Description	Quantity
04-001	ACCNBZ2GEA	Conn Cord	1
04-002	MX421SL002	Cont.Box Stopper KC	1
04-003	AVFRAME044	Cont.Box Assy KC	1
04-004	ACCNFX1GFA	Conn Cord	1
04-005	VC811CL001	PCB Guide Rail	2
04-006	MX876SL007	Cont Middle Plate KC	1
04-007	ZNF240240*01	Fan Motor	1
04-008	APRLGG4003AH	PW Board Assy	1
04-009	AYF3300*53	Cont R Cover Assy	1
04-010	ML876SL002	P/S Support KC	1
04-011	VS872KF001	Sheet MT	1
04-012	AEZF1800*01	Switch Regulator	1


Fig.5 – Paper Feed Unit



Ref No.	Part Code	Description	Quantity
05-001	AYF3300*62	Paper Feed Unit	1
05-002	VX6525B006	Sensor Cover	2
05-003	APRSS005HA	P.W. Board Assy	1
05-004	MX653SN001	Paper Holder	4
05-005	VX663SB007	Cassette Guide UF	1
05-006	MW341LJ001	M Feed Spring	2
05-007	MX876SL014	Frame Feed F	1
05-008	VX211DB003	MF Bush	2
05-009	VX532SB002	Main SW Bkt	1
05-010	AXSW018GEA	Interlock SW Assy	1
05-011	MX321SM001	Cord Keep	1
05-012	VX663SB008	Cassette Guide LF	1
05-013	VG147DN001	Regist Gear Z32	1
05-014	MM176CJ003	Metal Bush KD	8
05-015	MW251LJ008	Spring Regist F	1
05-016	VX221NN007	Mini Clamper	3
05-017	AVROLL*010	Feed Wheel Low Assy	2
05-018	MX321SM001	Cord Keep	1
05-019	MX875SM003	Feed Unit Stay B	1
05-020	MT876SN009	M Feed Roller B	1
05-021	MT876SN029	Roller M Feed A	1
05-022	APRSS005EA	PW Board Assy	1
05-023	MS866SL011	Sensor Plate A	1
05-024	APRSS005DA	P.W. Board Assy	1
05-025	VX664SB001	Cassette Guide LR	1
05-026	AYF1800*39	Roller Regist A Assy	1
05-027	AYF1800*35	Paper Chute Assy	1
05-028	MW241LJ019	Regist Paper Chute	2
05-029	AYF3300*46	Support TC Assy	1
05-030	MX876SL018	Bracket Clutch	1
05-031	ACCNAN8GEA	Conn. Cord PCA2032	1
05-032	VG144DB002	Gear Z36 B	1
05-033	AYF3300*62	Paper Feed Unit	1
05-034	VG138DN011	Feed Unit Gear Z28	2
05-035	VG169DB003	Feed Gear Z65	1
05-036	YYAFAAE01**01	Micro Clutch Z16-B	1
05-037	YYAFAAE02**01	Micro Clutch Z26-A-1	1
05-038	YYAFAAE03**01	Micro Clutch Z26-A-2	1
05-039	YYAFAAE05**01	Micro Clutch Z16-C	1
05-040	AYF3300*56	Feed Motor Assy	1
05-041	APRZZC1017AH	PW Board Assy	1
05-042	AYF3300*62	Paper Feed Unit	1
05-043	MX875SL002	Frame Feed R	1
05-044	VX866SB001	Paper Guide	1
05-045	VX331DB003	Actuator B	1


Ref No.	Part Code	Description	Quantity
05-046	VX532DB002	Actuator A	1
05-047	MW163LJ002	Sensor Spring B	1
05-048	NXGP1A05HR*01	PT Sensor GP1A05HR	1
05-049	AXAP002GEA	P.W. Board Assy	1
05-050	VS227RB003	Solenoid Pad	1
05-051	VS221KF006	Film Regist	7
05-052	MS866SN001	M Feed Paper Shoot B	1
05-053	VS412KF001	Guide Sheet PS	1
05-054	MS878SN001	M Feed Paper Shoot A	1
05-055	VS621KC001	Paper Shoot Guide	2
05-056	ACCNBS9GEA	Conn. Cord CCA5022	1

Fig.6 – Face-down Unit



Ref No.	Part Code	Description	Quantity
06-000	AYF3300*63	Face Down Unit	1
06-001	AYF3300*44	Guide FD Paper Assy	1
06-002	AYF3300*43	Solenoid C Assy	1
06-003	AXSW019GEA	FD Switch Assy	1
06-004	VX442SW002	FD Switch Cover	1
06-005	VM176DN009	Bearing	6
06-006	MW167LJ001	FD Spring F	1
06-007	NXGP1A05HR*01	PT. Sensor GP1A05HR	1
06-008	MW163LJ001	FD Actuator Spring	1
06-009	VX422DB003	FD Jam Indicator	1
06-010	MT876SN015	FD Exit Roller	1
06-011	AYF3300*63	Face Down Unit	1
06-012	MU131LX001	FD Pressure	4
06-013	VM474DB001	FD Bulley B	2
06-014	MT876SN017	FD Middle Roller	1
06-015	MT876SN027	Roller FD Enter	1
06-016	AYF3300*63	Face Down Unit	1
06-017	VX842SB005	Plate Change	1
06-018	VX886SW004	FD Cover	1
06-019	VM366SW001	FD Pin	2
06-020	VM123DB001	FD Feed Pulley	2
06-021	MX321LJ005	Exit Pulley Bracket	2
06-022	MS216SN003	FD Magnet Plate	4
06-023	MS218FJ001	FD Magnet	2
06-024	VG307DB002	Pulley FD Belt	1
06-025	VG127DB011	Gear Z15	1
06-026	MW265SJ001	Spring FD CL	1
06-027	VX917RB001	FD Belt	1
06-028	VG327DB001	Belt Pulley	1
06-029	VF176DB001	Pulley Flange	1
06-030	VG022DB001	Belt Pulley Gear	1
06-031	VG127DB002	FD Exit Gear	1
06-032	MX421SL001	Idle Bracket	1
06-033	VM177DB004	Belt Idle Pulley	1
06-034	MW161LJ018	Idle Spring	1
06-035	MW167LJ002	FD Spring R	1
06-036	AYF3300*45	Plate FD Side Assy	1
06-037	ACCNGEZGEA	Conn. Cord S00113	1

Fig. 7a – Harness– Lower Unit



Ref No.	Part Code	Description	Quantity
07-001	ACCNBS6GEA	Conn.Cord CCA4004	1
07-002	ACCNFX4GEA	Conn.Cord S00110	1
07-003	ACCNBS7GEA	Conn.Cord CCA4002	1
07-004	ACCNBY4GEA	Conn.Cord CCA4003	1
07-005	ACCNGE5GEA	Conn.Cord S00114	1
07-007	ACCNCKOULA	Conn.Cord Assy	1





Fig.7b - Harness - Upper Unit

Ref No.	Part Code	Description	Quantity
07-006	ACCNGE6GEA	Conn.Cord S00115-1	1

Fig.10 – Fuser Unit



Ref No.	Part Code	Description	Quantity
10-00A	FK-7	Fuser Unit	1
10-0B1	ZPB2413320202	Lamp	Heater 800W
	MT887AX002	Fixing Roller	1
	MT896SX015	Press Roller	1




Fig.11 – Scanner Unit

Ref No.	Part Code	Description	Quantity
11-00A	AYF1800*78	Scanner Unit	1
11-001	VS422SB001	Scanner Lid	1
11-002	APRAPC1003AH	PWB	APC