



PRINTER OPTIONS

PF-20 / PF-20 mini

PARTS CATALOGUE

PF-20 / PF-20 mini Parts Catalogue

Table of Contents

Overall (Fig.1)	3
Base Assembly (Fig.2).....	5
Top Cover Assembly (Fig.3).....	7
Cassettes (Fig.4).....	10


Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option


Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.

Fig.1 - Overall




Ref No.	Part Code	Description	Quantity
01-001	5SNSP0009958	Base Assy (PF-20)	1
01-001	5SNSP0009982	Base Assy (PF-20 mini)	1
01-002	5SNSP0009956	Cover Top Assy	1
01-003	5SNSP0008775	Cover Top Rear (PF-20)	1
01-003	5SNSP0009988	Cover Top Rear (PF-20 mini)	1
01-004	5SNSP0008776	Sheet Cover (PF-20 Only)	1

Fig.2 - Base Assembly



Ref No.	Part Code	Description	Quantity
02-001	5SNSP0008687	Base (PF-20)	1
02-001	5SNSP0009983	Base (PF-20 mini)	1
02-002	5SNSP0008688	Foot	4
02-003	5SNSP0008689	Plate Earth Cassette	1
02-004	5SNSP0009959	Cover Panel Assy (PF-20)	1
02-004	5SNSP0009985	Cover Panel Assy (PF-20 mini)	1
02-005	5SNSP0008694	Switch Assy (PF-20)	1
02-005	5SNSP0009998	Switch Assy (PF-20 mini)	1
02-008	5SNSP0008697	Cover Rear (PF-20 only)	1
02-009	5SNSP0008698	Spring Cover Rear (PF-20 only)	1
02-010	5SNSP0008699	Guide Slide (PF-20 only)	1
02-011	5MVX211NN024	Nylon Clamp (PF-20)	1
02-011	5MVX211NN024	Nylon Clamp (PF-20 mini)	1
02-012	5MVVSPF20**1	Serial No. Plate (PF-20)	1
02-012	5MVVSPF20MN1	Serial No. Plate (PF-20 mini)	1
03-001	5SNSP0009960	Cover Panel	1
03-002	5SNSP0009948	PWB Panel Assy (PF-20)	1
03-002	5SNSP0009986	PWB Panel Assy (PF-20 mini)	1
03-003	5SNSP0009949	Sheet Panel (PF-20)	1
03-003	5SNSP0009987	Sheet Panel (PF-20 mini)	1


Fig.3 - Top Cover Assembly



Ref No.	Part Code	Description	Quantity
01-002	5SNSP0009956	Cover Top Assy	1
04-001	5SNSP0009607	Cover Top N (PF-20)	1
04-001	5SNSP0009992	Cover Top N (PF-20 mini)	1
04-002	5SNSP0008702	Level Sens PA-1 (PF-20)	1
04-002	5SNSP0009609	Level Sens PA-1 (PF-20 mini)	1
04-003	5SNSP0008703	Spring Level Sens	1
04-004	5SNSP0008704	Drive Unit	1
04-005	5SNSP0009612	Bracket Cover Top N	1
04-006	5SNSP0008717	Shaft Roll A Assy	1
04-007	5SNSP0008722	Bracket Sensor Feed	1
04-008	5SNSP0008715	Sensor	1
04-009	5SNSP0009604	Actuator Sensor N	1
04-013	5SNSP0008729	Connector Assy	1
04-014	5SNSP0008732	Shaft Roller Assy	1
04-015	5SNSP0008734	Stopper	1
04-016	5SNSP0008735	Roller Feed Assy	1
04-017	5SNSP0008739	Cover Front L	1
04-018	5SNSP0008740	Cover Front R	1
04-019	5SNSP0008741	Roll Pick Up Assy	1
04-020	5SNSP0008742	Plate Earth	1
04-021	5SNSP0009952	PWB Main	1
04-022	5AACCNLZ2GEA	Conn. Cord S00702	1
04-023	5MVX717NN005	Snap Band	1
04-024	5SNSP0009957	Label Cover Top	1
05-001	5SNSP0008705	Gear Drive Assy	1
05-002	5SNSP0008713	Sensor Encoder Assy	1
05-003	5SNSP0008715	Sensor	1
05-004	5AACCNLZ1GEA	Conn. Cord S00701	1
05-005	5MVX717NN005	Snap Band	1
05-006	5MVK121NB002	Edging Saddle	1
06-001	5SNSP0008706	Bracket Motor	1
06-002	5SNSP0008707	Gear Z32	1
06-003	5SNSP0008708	Gear Z20-H56	1
06-004	5SNSP0008709	Gear H16-P56	1
06-005	5SNSP0008710	Motor Assy	1
06-006	5SNSP0008711	Pulley Encoder P16	1
06-007	5SNSP0008712	Belt Drive Z86	1
07-001	5SNSP0008714	Bracket Encoder	1
07-002	5SNSP0008715	Sensor	1
08-001	5SNSP0008718	Shaft Roll A	1
08-002	5SNSP0008721	Clutch Feed Drive	1
08-003	5SNSP0008719	Bushing A	1
08-004	5SNSP0008720	Bushing B	1
10-001	5SNSP0008730	Holder Connector	1
10-002	5SNSP0008731	Spacer	2

Ref No.	Part Code	Description	Quantity
10-003	5AACCNLZ3GEA	Conn. Cord S00703	1
10-004	5MVX221NN028	Locking Wire Saddle	1
11-001	5SNSP0008733	Shaft Roller	1
12-001	5SNSP0008736	Roller Feed	1
12-002	5SNSP0008737	Gear Joint Z16	1
12-003	5SNSP0008738	Gear Feed Z16	1
12-004	5SNSP0008719	Bushing A	1
12-005	5SNSP0008720	Bushing B	1

Fig.4 - Cassettes



Ref No.	Part Code	Description	Quantity
41-000	PC-20	Paper Cassette (PF-20)	1
41-000	5SNSP0009996	Paper Cassette A4 (PF-20 mini)	1
41-001	5SNSP0009879	Base Cassette Assy (PF-20)	1
41-001	5SNSP0009995	Base Cassette Assy (PF-20 mini)	1
41-002	5SNSP0009950	Cover Front Assy (PF-20)	1
41-002	5SNSP0009989	Cover Front Assy (PF-20 mini)	1
42-001	5SNSP0009883	Base Cassette (PF-20)	1
42-001	5SNSP0009995	Base Cassette (PF-20 mini)	1
42-003	5SNSP0008748	Flat Washer	2
42-004	5SNSP0008749	Spring Lever Lock	2
42-005	5SNSP0008750	Sheet Guide A	1
42-006	5SNSP0009614	Sheet Guide B	1
42-007	5SNSP0009615	Sheet Guide C	1
42-008	5SNSP0008753	Plate Spring Earth	1
42-009	5SNSP0008754	Knob Size Select	1
42-010	5SNSP0009613	Spring Cassette	1
42-011	5SNSP0008756	Plate Bottom Assy	1
42-012	5SNSP0008759	Plate Side L Assy (PF-20)	1
42-012	5SNSP0009991	Plate Side L Assy (PF-20 mini)	1
42-013	5SNSP0008762	Plate Side R Assy (PF-20)	1
42-013	5SNSP0010008	Plate Side R Assy (PF-20 mini)	1
42-014	5SNSP0008766	Back End Assy	1
42-015	5SNSP0009884	Lever Lock L	1
42-016	5SNSP0009885	Lever Lock R	1
42-017	5SNSP0009881	Flap Nail L	1
42-018	5SNSP0009882	Flap Nail R	1
43-001	5SNSP0009611	Plate Bottom N	1
43-002	5SNSP0008758	Pad Friction	1
44-001	5SNSP0008760	Plate Side L (PF-20)	1
44-001	5SNSP0009992	Plate Side L (PF-20 mini)	1
44-002	5SNSP0009609	Nail LN	1
45-001	5SNSP0008763	Plate Side R (PF-20)	1
45-001	5SNSP0009994	Plate Side R (PF-20 mini)	1
45-002	5SNSP0009610	Nail RN	1
45-003	5SNSP0008765	Spring Adjust Side	1
46-001	5SNSP0008767	Back End	1
46-002	5SNSP0008768	Spring Adjust Rear	1
46-003	5SNSP0008769	Cover Back End	1
47-001	5SNSP0009951	Cover Front (PF-20)	1
47-001	5SNSP0009990	Cover Front (PF-20 mini)	1
47-002	5SNSP0008772	Sprint Tension	4
47-003	5SNSP0008773	Roller Pinch	2
47-004	5SNSP0008774	Shaft Roller Pinch	2