



PRINTER OPTION

PF-30

PARTS CATALOGUE

PF-30 Parts Catalogue

Table of Contents

Main Assembly (Fig.20A).....	3
Drive Assembly (Fig.20B).....	6
Cassette (Fig.21).....	8


Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.


Fig.20A - Main Assembly



Ref No.	Part Code	Description	Quantity
20-001	5MMX965SD001	Plate Feed A	1
20-002	5MMX963SD001	Plate Feed B	1
20-003	5MMX652SD002	Plate Connector	1
20-004	5MVX985SH001	Cover Feed Left	1
20-005	5MVX873SH016	Cover Feed Right	1
20-006	5MVX962SH001	Cover Feed Front A	1
20-007	5MVX985SH002	Cover Feed	1
20-008	5MVX986SH002	Cover Feed Rear	1
20-009	5AAGEAR*028	Gear Nip Assy	1
20-010	5MMX973SD002	Stay A-Pin	1
20-011	5MMX952SD001	Stay B	1
20-012	5MMX855SD001	Stay C	1
20-013	5MMX955SD001	Rail Cassette L	1
20-014		Rail Cassette R	1
20-015	5MMZ885SD001	Plate Feed Drive	1
20-024	5MVG132DN002	Gear Feed Z23S	1
20-025	5MMW261SD003	Spring Nip Feed	1
20-026	5MMT876SN052	Roller Nip Feed	1
20-027	5MVM276DN005	Pulley Middle	1
20-028	5MMT643SN001	Shaft Nip Pulley	1
20-031	5AAMPS6***02	Foot	4
20-032	5MMM121CX001	Bush Drum	1
20-033	5MMX432LD001	Spring Shaft FD	1
20-034	5MVX962SH002	Cover Feed Front B	1
20-035	5MMB972SD001	Stay A Right	1
20-036	5MVX622DN001	Arm Cover	1
20-037	5MVX421DN003	Lock Cover R	1
20-038	5MMW261SD004	Spring Cover R	1
20-039	5MMX872SD002	Plate Feed Right	1
20-040		Plate Feed C	1
20-042	5MMX732SD001	BKT Cover Front	1
20-043	5MMX952SD002	Stay B Front	1
20-044	5MVX321DN010	Latch Rail	1
20-045		Collar DLP	1
20-049	5ESP01000100*01	Push Switch	1
20-050	5MVX111DN002	Bush SP Pulley	1
20-051	5MMVX721SB001	Holder Cord	
20-052	5MVX754SB009	Spacer Motor	
20-053	5MMZ211LD003	Plate Earth Cover	1
20-054	5AAGEAR*028	Gear Nip Assy	1
20-055	5AAPLATE031	Rail Plate Assy	1
20-056	5MMX661SX001	Plate Motor	1
20-057	5MVX531NB004	Edge Clip	1
20-058	5MVVSPF30**1	Ser No Plate	1
20-059	5MMM140SZ012	Collar Spacer A	1


Ref No.	Part Code	Description	Quantity
20-060	5MMM140SZ013	Collar Spacer B	1
20-061	5MVS431KF013	Sheet Path	1
20-062	5MVS816EF001	Sheet Rail Cass	1
20-063	5MMX221SW002	Cord Keep	1
20-064	5MMT743LD001	Shaft Nip Pulley	1
20-080	5AACCNQD8GEA	Conn Cord Assy	1
20-081	5AACCNQD9GEA	Conn Cord Assy	1
20-083	5AACCNQE1GEA	Conn Cord Assy	1
20-084	5AACCNQE2GEA	Conn Cord Assy	1
20-085	5AACCNQE3GEA	Conn Cord Assy	1
20-086	5AACCNQF8GEA	Conn Cord Assy	1
20-087	5AAPRCZR2004BH	Feed PWB	1

Fig.20B - Drive Assembly



Ref No.	Part Code	Description	Quantity
20-015	5MMZ885SD001	Plate Feed Drive	1
20-016	5MVX774SN001	Cover Feed Drive	1
20-017	5MVG137DN017	Feed Gear Z24SJ	1
20-018	5MVG158DN023	Gear Free Z41S	1
20-019	5MVG148DN022	Gear Z36S - Z30S	1
20-020	5MVG148DN023	Gear Z39S	1
20-021	5MVG169DN022	Gear Z63S	1
20-022	5MVX331CN001	Gear Holder	1
20-023	5MMW261LD021	Spring Joint Feed	1
20-029	5EZNT2400404*03	DC Motor (Feed)	1
20-030	5EZNT2400404*02	DC Motor (Nip)	1
20-041	5MVG148DN027	Gear Z37S	1
20-046	5EZND2400001*01	Gear D Motor	1
20-047	5ENXGP1A44E1*01	Photo Sencor	1
20-048	5ESP01000101*01	Push Switch	1
20-082	5AACCNQE0GEA	Conn Cord Assy	1
20-087	5AAPRCZR2004BH	Feed PWB KP-546	1

Fig.21 - Cassette



Ref No.	Part Code	Description	Quantity
21-000		Cassette Assy	1
21-001	5MVB996SH006	Base Cassette	1
21-002	5MVX882SH001	Plate Bottom	1
21-003	5MML763SW002	Guide Paper Side R	1
21-004	5MML765SW001	Guide Paper Side L	1
21-005	5MVL666SH002	Rear Stopper	1
21-006	5MVX863SH006	BKT Lift Bottom	1
21-007	5AAVROLL*032	Roller Retard Assy	1
21-008	5AAVROLL*033	Roller Feed Assy	1
21-009		Gear Nip Assy	1
21-010	5AAVCLTCH008	Clutch Assy	1
21-011	5MMT665SN001	Shaft Retard	1
21-012	5MMT864SN006	Shaft Feed	1
21-013	5MMT864SN007	Shaft Pick	1
21-014	5MVX521DB002	Actuator Size	1
21-015	5MVG147DN014	Gear Z35S	1
21-016	5MVG147DN012	Gear Z30	1
21-017	5AAVROLL*031	Turque Limmitor	1
21-018	5MMU752SD002	BKT Lift Pick	1
21-019	5MMX863SD006	Stay Feed	1
21-020	5MVM276DN009	Bush Retard	1
21-021	5MVX731CN001	Rack	1
21-022	5MVX665AC003	Holder LED	1
21-023	5MMS756SD008	Holder Paper Side R	1
21-024	5MMS756SD009	Holder Paper Side L	1
21-025	5MVS522KX001	Label Size	1
21-026	5MVX642CG002	Lever Lock Rear	1
21-027	5MVX642CG001	Lever Lock Side	1
21-028	5MVS628CN001	Actuator Rear	1
21-029	5MVG127DN045	Pinion	1
21-030		Spring Retard	1
21-031	5MVM176DN001	Pulley Rail Cass	1
21-032	5MML222SD006	BKT Rail Cass	1
21-033	5MVS637WK001	Pad Friction	1
21-034		Actuator Retard	1
21-035	5MVX843SH010	Lid Cassette	1
21-036	5ESZ010201***01	Mode Switch	1
21-037		Spring Separator	1
21-038	5MMW261SD005	Spring Rack	1
21-039	5MVX221DN009	Spacer Pick Up	1
21-040	5MVG165DN002	Gear Mode SW	1
21-041	5MVG147DN013	GearZ32	1
21-042		Bush Joint	1
21-043	5MMB871SD001	Plate Cassette	1
21-044	5MVX631DB001	Actuator Empty	1

Ref No.	Part Code	Description	Quantity
21-045	5MMW411LD003	Spring Lever	1
21-046	5MVS331KN003	Sheet Retard	1
21-047	5MMU531LD001	Plate Retard	1
21-048	5MVS331RN001	Pad Earth Rail	1
21-049	5MMZ331LD002	Plate Earth Rail	1
21-050	5MVX865SX001	Cover Connect	1
21-051	5MVX642SX001	Cover Pick up	1
21-052	5MVVL642WN08	Label Pick up	1
21-054	5MVVL632WN04	Label Cassette A	1
21-055	5MVVL632WN05	Label Cassette B	1
21-056	5MVVL431WN13	Paper Limit Label	1
21-057	5MMW241SD003	Spring Retard L	1
21-058	5MMW241SD004	Spring Retard R	1
21-060	5MML821SD005	Stay Bottom	1
21-062	5MMW264LD003	Spring Actuator	1
21-080	5AACCNQE4GEA	Conn Cord Assy	1
21-081	5AACCNQE5GEA	Conn Cord Assy	1
21-082	5AACCNQF5GEA	Conn Cord Assy	1
21-083	5AACCNQF6GEA	Conn Cord Assy	1
21-084	5APRSSC1019AH	Psize PWB KP-581	1
21-085	5APRSSC1018AH	Pickup PWB KP-583	1
21-086	5APRLDC1002AH	LED PWB KP-585	1