



PRINTER OPTIONS

HS-3

PARTS CATALOGUE

HS-3 Parts Catalogue

Table of Contents


Exploded view (Fig.1)3

Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.



Ref No.	Part Code	Description	Quantity
01-000	HS-3	500 SHEET HANDLER STACKER	1
01-001	5MVB885SW002	COVER RIGHT	1
01-002	5MVB885SW003	COVER LEFT	1
01-003	5MVX874SW002	LID TOP	1
01-004	5MMT733SN001	SHAFT EXIT	2
01-005	5MMW251LD005	SPRING PULLEY	4
01-006	5MVM174DB002	PULLEY EXIT	4
01-007	5MVX863SW005	COVER TOP	1
01-008	5AAYHS3***03	PUSH SWITCH ASSY	1
01-009	5MVB872SW029	TRAY BACK	1
01-010	5MVB876SW008	BKT HS	1
01-011	5MVS432SW001	COVER JOINT	1
01-012	5MVX332SB016	COVER GEAR	1
01-013	5MMW162LJ012	SPRING COVER	1
01-014	5MVM150RB009	BELT MXL109-32	1
01-015	5MVG048DB007	GEAR FUX Z32-P19	1
01-016	5MVG138DB020	GEAR ED Z30	1
01-017	5MVVSH3J**1	LABEL SERIAL J	1
01-017	5MVVSHS3***1	LABEL SERIAL	1
01-018	5MVS631KN001	SHEET STACK	2
01-019	5MVS111KN002	SEAL PWB	2
01-020	5MBWN92135NB	POLY WASHER	1
01-022	5MVM196DB003	PLATE ENCODER	1
02-001	5MMZ866SL002	FRAME LOW	1
02-002	5MVB764SW005	BOX PWB	1
02-003	5AACCNNB3GEA	CONN. CORD S00844	1
02-004	5MMS866SL017	GUIDE PAPER F	1
02-005	5MMT875SN005	ROLLER TRANS A	1
02-006	5MMT875SN006	ROLLER EXIT	1
02-007	5MVG127DB029	GEAR Z14	2
02-008	5MVG327DB003	PULLEY P17	1
02-009	5MMM176CJ005	BUSHING SBK	2
02-010	5MVM176DB006	BUSHING POM	2
02-011	5MVL866SW001	GUIDE PAPER R	1
02-015	5MVX431NN001	SPACING CLIP	2
02-016	5MMX777SL001	FRAME RIGHT	1
02-017	5AAYHS3***02	TRNS MOTOR ASSY	1
02-018	5MVG368DB001	GEAR Z28-P56	1
02-019	5MVG127DB030	GEAR FEED Z14	2
02-020	5MVG148DB018	GEAR Z28-P56	1
02-021	5MVM150RB007	BELT MOTOR Z70	1
02-023	5MMX777SL002	FRAME LEFT	1
02-024	5ESM010234***01	MICRO SWITCH	1
02-025	5AACCNNB4GEA	CONN CORD S00845	1
02-025	5MVG326DB001	PULLEY MXL14	1

Ref No.	Part Code	Description	Quantity
02-025	5MVS862KN002	SHEET TRANSFER	1
02-026	5MVS421KN002	SHEET A	2
02-027	5MVS217SF001	SPACER BOX	1
03-001	5MMX876SL020	FRAME ELEVATOR R	1
03-002	5MMX876SL007	FRAME ELEVATOR L	1
03-003	5MMS886SL007	FRAME STACK	1
03-004	5MMT865SN002	SHAFT FOOT	1
03-005	5MVX643SW002	FOOT	2
03-006	5MMT866SN018	SHAFT ELEVATOR	1
03-007	5MMM176CJ003	METAL BUSH KD	1
03-008	5MVM122DB003	BUSH POW	2
03-009	5MVG318DN001	PULLEY XL14	4
03-010	5MVB882SW003	TRAY ELEVATOR	1
03-011	5MVX665DN001	GUIDE ELEVATOR R	1
03-012	5MVX665DN002	GUIDE ELEVATOR L	1
03-013	5MVM190RB016	BELT XL280 9.6	2
03-014	5MVG138DN018	GEAR WHEEL H30	1
03-015	5MVG127DN031	GEAR MOTOR	1
03-016	5MVX532DN001	BKT SENSOR BOTTLE	1
03-017	5MBRP3045QNB	PAN HEAD RIVET	1
03-018	5ESM010235***01	MICRO SWITCH	1
03-019	5MVX211NN019	LOCKING CARD SPACER	2
03-020	5MMT865SN004	SHAFT STAY	1
03-021	5AAYHS3***14	PAPER SIZE R ASSY	1
03-022	5AAYHS3***15	PAPER SIZE L ASSY	1
03-024	5AAXPS022GEA	PT. SENSOR ASSY	1
03-025	5MMU654SL001	BKT WORM	1
03-026	5MMS336SL008	PLATE WORM	1
03-027	5MVG117DN001	GEAR WORM	1
03-028	5MVM122DB003	BUSH POW	2
03-029	5MVG137DB024	GEAR CLUTCH Z22	1
03-030	5AAYHS3***01	ELEV MOTOR ASSY	1
03-031	5MML654SL002	BKT DC MOTOR	1
03-032	5MVX832CB006	GUIDE CHANGE	1
03-033	5MMW162LJ011	SPRING GUIDE	1
03-034	5MMT263SZ016	PIN STUD	2
03-035	5MVS824XF001	DISCHARGER HS	1
03-036	5MVS643KN001	SEAL TRAY	2
KP395B	5AAPRIFC2004AH	PWB ASSY	1
KP396B	5AAPRDVC2004AH	PWB ASSY	1
KP398B	5AAPRSSC2002AH	PWB ASSY	1