

mita[®]

AS-M8111

AS-M8111

PARTS LIST

Published in Oct. '98
5BD70770

NOTE

1.Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5BD09100	COVER FRONT	AS-M8111	60Hz	1

2.Service calls and freight will be charged separately.

3.Symbols in the "Parts Number" column.

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	5BD07570	COVER TOP ASSEMBLY	•5BD08760	BRUSH EXIT
			•5BD08770	PLATE EARTH EXIT

Parts List

AS-M8111

———— CONTENTS ————

FIG. 1	EXTERNAL COVERS	2
FIG. 2	PAPER CONVEYING ASSEMBLY	4
FIG. 3	FRAME ASSEMBLY	6
FIG. 4	TRAY MAIL ASSEMBLY	8
FIG. 5	TRAY MAIL ASSEMBLY	10
FIG. 6	DRIVE ASSEMBLY	12
FIG. 7	MULTI TRAY ,DOOR ASSEMBLY	14
FIG. 8	BASE ASSEMBLY	16
	•INDEX	18

FIG. 1 EXTERNAL COVERS




FIG. 1 EXTERNAL COVERS

Ref. No.	Part. No.	Description
1	5BD09100	COVER FRONT
2	5BD09110	COVER REAR
3	5BD07570	COVER TOP ASSEMBLY
4	•5BD08760	BRUSH EXIT
5	•5BD08770	PLATE EARTH EXIT
6	•5BD08750	LEVER SENSOR TOP
7	•5BD08710	COVER TOP
8	•5BD08720	PLATE SPRING ROLLER
9	•5BD08730	ROLLER TOP
10	•5BD08740	SHAFT ROLLER TOP
11	•5BD07260	BIND T-T SCREW
12	•5BD09200	CLAMP WIRE
13	•5BD07140	BIND HD SCREW
14	5BD07480	PWB SENSOR TOP
15	5BD07240	BIND T-T SCREW
16	5BD07140	BIND HD SCREW
17	5BD07490	CONN.ASM-CK2

FIG. 2 PAPER CONVEYING ASSEMBLY




FIG. 2 PAPER CONVEYING ASSEMBLY

Ref. No.	Part. No.	Description	Ref. No.	Part. No.	Description
1	5BD07110	BIND HD SCREW	69	*5BD08810	SHAFT GUIDE
2	5BD07650	M4*7 ROUNDED END	70	*5BD08820	GUIDE CENTER
3	5BD07030	E STOP RING	71	*5BD08790	ROLLER GUIDE
4	5BD07070	SPRING PIN	72	*5BD09280	CUSHION GUIDE ROLLER
5	*5BD07010	E STOP RING	73	*5BD07060	SPRING PIN
6	*5BD07160	CEMS SCREW	74	*5BD07010	E STOP RING
7	5BD07160	CEMS SCREW	75	5BD08260	PLATE EARTH HOLDER 1
8	5BD08100	FLAPPER	76	5BD08270	PLATE EARTH HOLDER 2
9	5BD08110	GUIDE FLAPPER	77	5BD09400	GUIDE ROLLER LOWER
10	5BD08130	SPRING FLAPPER	78	*5BD08800	GUIDE LOWER
11	5BD08140	GUIDE PAPER EXIT	79	*5BD08780	SHAFT GUIDE 2
12	5BD07380	PWB LR43	80	*5BD08790	ROLLER GUIDE
13	5BD09190	SENSOR TLP1241	81	*5BD09280	CUSHION GUIDE ROLLER
14	5BD07350	CONN.CORD ASSEMBLY PES	82	*5BD07060	SPRING PIN
15	5BD07860	GUIDE PAPER ENTRANCE	83	*5BD07010	E STOP RING
16	5BD07850	BUSHING 6	84	5BD07880	GUIDE PAPER ENTRANCE
17	5BD07130	BIND T-T SCREW	85	5BD08120	BUSHING 4
18	5BD07240	BIND T-T SCREW	86	5BD08160	BKT SENSOR
19	5BD08150	ROLLER EXIT	87	5BD07590	REEL FILM ASSEMBLY
20	5BD07690	COVER SENSOR	88	*5BD08060	FILM PAPER GUIDE
21	5BD08240	CLIP 5			
22	5BD08480	FLANGE PULLEY			
23	5BD09370	GEAR LIMIT			
24	5BD08170	HOLDER SENSOR			
25	5BD07360	PWB SENSOR			
26	5BD08080	GUIDE FILM 2			
27	5BD08070	GUIDE FILM 1			
28	5BD08250	HOLDER INDEXER			
29	5BD08280	ROLLER INDEXER BELT			
30	5BD07580	INDEXER ASSEMBLY			
31	*5BD08400	PULLEY GEAR Z31			
32	*5BD08410	FLANGE PULLEY			
33	*5BD08420	GEAR Z20			
34	*5BD08390	PLATE EARTH INDEXER 1			
35	*5BD08290	FRAME INDEXER LOWER			
36	*5BD08300	RIB FRONT INDEXER			
37	*5BD08310	RIB REAR INDEXER			
38	*5BD09250	BUSHING 4			
39	*5BD08320	ROLLER INDEXER			
40	*5BD08330	FRAME INDEXER UPPER			
41	*5BD08430	BRUSH INDEXER LOWER			
42	*5BD07010	E STOP RING			
43	*5BD08450	PLATE EARTH INDEXER 2			
44	*5BD09280	CUSHION GUIDE ROLLER			
45	*5BD08440	BRUSH INDEXER UPPER			
46	*5BD08340	PLATE INDEXER			
47	*5BD08380	GUIDE INDEXER I			
48	*5BD08360	ROLLER INDEXER W			
49	*5BD08350	ROLLER INDEXER A			
50	*5BD08370	SPRING INDEXER A			
51	*5BD07240	BIND T-T SCREW			
52	*5BD07100	BIND HD SCREW			
53	*5BD07160	CEMS SCREW			
54	*5BD07050	SPRING PIN			
55	*5BD07410	BKT INDEXER			
56	5BD07620	SHEET SENSOR			
57	5BD09140	WIRE CLAMP			
58	5BD07370	CONN.CORD INDEXER			
59	5BD07390	CONN.CORD REVERSE			
60	5BD09380	GUIDE RILLER UPPER			
61	*5BD08780	SHAFT GUIDE 2			
62	*5BD08830	GUIDE UPPER			
63	*5BD08790	ROLLER GUIDE			
64	*5BD07010	E STOP RING			
65	*5BD07060	SPRING PIN			
66	5BD09200	CLAMP WIRE			
67	5BD07870	CUSHION SENSOR			
68	5BD09390	GUIDE ROLLER MIDDLE			

FIG. 3 FRAME ASSEMBLY




FIG. 3 FRAME ASSEMBLY

Ref. No.	Part. No.	Description
1	5BD07760	RAIL INDEXER
2	5BD08840	GUIDE A RAIL
3	5BD07820	GUIDE B RAIL
4	5BD07730	PIN ROCK
5	5BD07740	ACTUATOR K
6	5BD07610	BKT SENSOR
7	5BD07620	SHEET SENSOR
8	5BD09130	SENSOR GP1S74P
9	5BD07690	COVER SENSOR
10	5BD07700	FILM SENSOR
11	5BD07660	PLATE B STOPPER F
12	5BD07320	PWB PT43
13	5BD07630	LEVER SENSOR
14	5BD07680	PLATE B STOPPER R
15	5BD07770	GUIDE C RAIL
16	5BD07710	FRAME FRONT
17	5BD07790	FRAME REAR
18	5BD07330	CONN.CORD ASSMBLY PT
19	5BD09140	WIRE CLAMP
20	5BD07720	MAT CUSHION
21	5BD07640	SPRING LEVER
22	5BD09360	COVER CASTER
23	5BD09410	FRAME BASE
24	5BD07230	BRAS.TAP SCREW
25	5BD07230	BRAS.TAP SCREW
26	5BD07670	M4*9 ROUNDED END
27	5BD07650	M4*7 ROUNDED END
28	5BD07090	CEMS SCREW W/FW
29	5BD07170	CEMS SCREW W/FW
30	5BD07750	M4*5 ROUND END

FIG. 4 TRAY MAIL ASSEMBLY




FIG. 4 TRAY MAIL ASSEMBLY

Ref. No.	Part. No.	Description
1	5BD09040	TRAY MAIL
2	5BD09050	LEVER EMPTY
3	5BD09060	LEVER FULL 1
4	5BD09070	LEVER FULL 2
5	5BD09290	SPRING LEVER EMPTY
6	5BD09300	ADDITIONAL MAIN TRAY
7	5BD07190	CEMS SCREW

FIG. 5 TRAY MAIL ASSEMBLY




FIG. 5 TRAY MAIL ASSEMBLY

Ref. No.	Part. No.	Description
1	5BD09040	TRAY MAIL
2	5BD09050	LEVER EMPTY
3	5BD09290	SPRING LEVER EMPTY
4	5BD09300	ADDITIONAL MAIN TRAY
5	5BD07190	CEMS SCREW

FIG. 6 DRIVE ASSEMBLY




FIG. 6 DRIVE ASSEMBLY

Ref. No.	Part. No.	Description	Ref. No.	Part. No.	Description
1	5BD07530	PWB SENSOR A	69	5BD07370	CONN.CORD INDEXER
2	5BD07840	ROLLER ENTRANCE	70	5BD07550	CONN.CORD BIN
3	5BD08090	SHAFT HANGER FILM	71	5BD07450	CONN.CORD MOTOR
4	5BD07980	SHAFT REEL FILM	72	5BD07420	CONN.CORD TOP
5	5BD08010	ARBOR REEL FILM	73	5BD07620	SHEET SENSOR
6	5BD07990	PULLEY REEL FILM	74	5BD07390	CONN.CORD REVERSE
7	5BD09160	SPACER KGLS-18S	75	5BD09270	SPACER KGLS-6S
8	5BD08000	SPRING REEL FILM	76	5BD08540	BKT SENSOR INDEXER
9	5BD08030	SPRING REEL FILM R	77	5BD09180	SENSOR TLP1225
10	5BD07940	BELT S3M 442 60	78	5BD08460	PLATE ENCODER 4
11	5BD07920	BELT S3M 430 60	79	5BD07970	GEAR Z30
12	5BD07900	PULLEY S3M 18 A	80	5BD07160	CEMS SCREW
13	5BD07960	PULLEY S3M 18 B	81	5BD07210	CEMS SCREW
14	5BD08040	REEL ADJUST ARBOR	82	5BD07190	CEMS SCREW
15	5BD08050	SPRING REEL ADJUST	83	5BD07650	M4*7 ROUNDED END
16	5BD09220	BUSHING MF	84	5BD07310	FLAT S WASHAER
17	5BD07850	BUSHING 6	85	5BD07010	E STOP RING
18	5BD08180	SPRING REEL SHAFT	86	5BD07030	E STOP RING
19	5BD07890	SHAFT DRIVE LOWER	87	5BD07070	SPRING PIN
20	5BD07910	PULLEY S3M 23	88	5BD07080	SPRING PIN
21	5BD08240	CLIP 5	89	5BD07230	BRAS.TAP SCREW
22	5BD09260	WIRE CLAMP	90	5BD07160	CEMS SCREW
23	5BD07930	BELT S3M 57 60	91	5BD07300	HEXA SET SCREW
24	5BD09130	SENSOR GP1S74P	92	5BD09210	WASHER T
25	5BD08860	BKT CONN.INTER	93	5BD07120	BIND HD SCREW
26	5BD07510	PWB CONT SUB	94	5BD07180	CEMS SCREW
27	5BD07520	EPROM ASSEMBLY	95	5BD08020	FC PARALLEL PIN
28	5BD08850	SWITCHING REG			
29	5BD09420	INDEXER MOTOR ASSY			
30	*5BD08530	PLATE ENCODER 40			
31	*5BD08520	COLLAR MOTOR			
32	*5BD08510	GEAR WORM			
33	*5BD08500	BKT MOTOR INDEXER			
34	*5BD08490	MOTOR INDEXER			
35	*5BD07040	G STOP RING			
36	*5BD07200	CEMS SCREW			
37	*5BD07300	HEXA SET SCREW			
38	5BD09170	SPACER KGLS-16S			
39	5BD07950	SHAFT DRIVE INDEXER			
40	5BD07810	PLATE CONT.PWB			
41	5BD09150	SW INDEXER POSITION			
42	5BD07800	BKT PWB SENSOR			
43	5BD09370	GEAR LIMIT			
44	5BD09200	CLAMP WIRE			
45	5BD07400	BKT MOTOR CONVEYING			
46	5BD08220	SHAFT DRIVE UPPER			
47	5BD08230	GEAR Z23			
48	5BD09240	BEARING MF106ZZ			
49	5BD09230	BELT S2M 60			
50	5BD08190	PULLEY IDLER GEAR			
51	5BD08200	MOTOR CONVEYING			
52	5BD08210	PULLEY S2M 16			
53	5BD07540	CONN.CORD BIN 2			
54	5BD07560	PWB SENSOR B			
55	5BD08470	BKT MOTOR REVERSE			
56	5BD09140	WIRE CLAMP			
57	5BD09310	BELT S2M 56-40			
58	5BD09320	MOTOR REVERSE			
59	5BD09330	BKT REAR COVER			
60	5BD07460	BKT SOLENOID			
61	5BD08550	LEVER FLAPPER			
62	5BD08560	SOLENOID NS38			
63	5BD08570	SPRING SOLENOID			
64	5BD07830	BKT SENSOR COVER			
65	5BD07430	CONN.CORD SENSOR 2			
66	5BD07500	CONN.CORD REG.			
67	5BD07340	CONN.CORD SW			
68	5BD07440	CONN.CORD MOTOR			

FIG. 7 MULTI TRAY ,DOOR ASSEMBLY




FIG. 7 MULTI TRAY ,DOOR ASSEMBLY

Ref. No.	Part. No.	Description
1	5BD08590	BKT INTERLOOK JAM
2	5BD07780	STOPPER DOOR
3	5BD08700	PLATE STOPPER DOOR
4	5BD09080	COVER SENSOR
5	5BD09060	LEVER FULL 1
6	5BD09070	LEVER FULL 2
7	5BD08680	SPRING LEVER JAM
8	5BD08690	LOCKER DOOR
9	5BD07270	BIND T-T SCREW
10	5BD07250	BIND T-T SCREW
11	5BD07190	CEMS SCREW
12	5BD09090	TRAY MULTI
13	5BD09350	GUIDE TRAY MULTI
14	5BD07600	DOOR ASSEMBLY
15	*5BD08700	PLATE STOPPER DOOR
16	*5BD08690	LOCKER DOOR
17	*5BD08680	SPRING LEVER JAM
18	*5BD09340	BEARING LF1360ZZ
19	*5BD08660	LEVER JAM
20	*5BD07470	CONN.CORD
21	*5BD08640	FRAME DOOR
22	*5BD08580	COVER DOOR
23	*5BD08610	BELT CONVEYING
24	*5BD08670	SEAL LEVER JAM
25	*5BD08590	BKT INTERLOOK JAM
26	*5BD08600	SUPPORT DOOR LOCK
27	*5BD07780	STOPPER DOOR
28	*5BD07270	BIND T-T SCREW
29	*5BD07250	BIND T-T SCREW
30	*5BD07190	CEMS SCREW
31	*5BD07250	BIND T-T SCREW
32	*5BD07030	E STOP RING
33	*5BD07140	BIND HD SCREW
34	*5BD08650	ROLLER CONVEYING
35	*5BD08630	ROLLER IDLER
36	**5BD07850	BUSHING 6
37	*5BD08620	SHAFT ROLLER IDLER
38	**5BD07030	E STOP RING

FIG. 8 BASE ASSEMBLY




FIG. 8 BASE ASSEMBLY

Ref. No.	Part. No.	Description
1	5BD08870	BKT HEIGHT ADJUST
2	5BD08880	FRAME KC
3	5BD09020	PLATE COVER L
4	5BD09030	PLATE COVER R
5	5BD08890	REINFORCEMENT SIDE
6	5BD08990	COVER CASTER
7	5BD08980	RAIL
8	5BD08960	FRAME ADJUST
9	5BD08970	PLATE JOINT
10	5BD09120	BKT JOINT
11	5BD08950	BKT ADJUST CASTER
12	5BD09010	SCREW ADJUST
13	5BD08920	PLATE
14	5BD08930	ROLLER CASTER
15	5BD08940	SHAFT CASTER
16	5BD08900	PLATE
17	5BD08910	MAGNET CATCH
18	5BD07280	BRAS.TAP SCREW
19	5BD07650	M4*7 ROUNDED END
20	5BD07020	E STOP RING
21	5BD07290	BRAS.TAP SCREW
22	5BD07150	BIND HD SCREW
23	5BD09000	SCR4*10 WAVE
24	5BD07670	M4*9 ROUNDED END
25	5BD07220	PAN HEAD SCREW
26	5BD07140	BIND HD SCREW

INDEX

Part. No.	Description	Fig. No.
5BD07010	E STOP RING	2, 6
5BD07020	E STOP RING	8
5BD07030	E STOP RING	2, 6, 7
5BD07040	G STOP RING	6
5BD07050	SPRING PIN	2
5BD07060	SPRING PIN	2
5BD07070	SPRING PIN	2, 6
5BD07080	SPRING PIN	6
5BD07090	CEMS SCREW W/FW	3
5BD07100	BIND HD SCREW	2
5BD07110	BIND HD SCREW	2
5BD07120	BIND HD SCREW	6
5BD07130	BIND T-T SCREW	2
5BD07140	BIND HD SCREW	1, 7, 8
5BD07150	BIND HD SCREW	8
5BD07160	CEMS SCREW	2, 6
5BD07170	CEMS SCREW W/FW	3
5BD07180	CEMS SCREW	6
5BD07190	CEMS SCREW	4, 5, 6, 7
5BD07200	CEMS SCREW	6
5BD07210	CEMS SCREW	6
5BD07220	PAN HEAD SCREW	8
5BD07230	BRAS.TAP SCRE	3, 6
5BD07240	BIND T-T SCREW	1, 2
5BD07250	BIND T-T SCREW	7
5BD07260	BIND T-T SCREW	1
5BD07270	BIND T-T SCREW	7
5BD07280	BRAS.TAP SCREW	8
5BD07290	BRAS.TAP SCREW	8
5BD07300	HEXA SET SCREW	6
5BD07310	FLAT S WASHAER	6
5BD07320	PWB PT43	3
5BD07330	CONN.CORD ASSEMBLY PT	3
5BD07340	CONN.CORD SW	6
5BD07350	CONN.CORD ASSEMBLY PES	2
5BD07360	PWB SENSOR	2
5BD07370	CONN.CORD INDEXER	2, 6
5BD07380	PWB LR43	2
5BD07390	CONN.CORD REVERSE	2, 6
5BD07400	BKT MOTOR CONVEYING	6
5BD07410	BKT INDEXER	2
5BD07420	CONN.CORD TOP	6
5BD07430	CONN.CORD SENSOR 2	6
5BD07440	CONN.CORD MOTOR	6
5BD07450	CONN.CORD MOTOR	6
5BD07460	BKT SOLENOID	6
5BD07470	CONN.CORD	7
5BD07480	PWB SENSOR TOP	1
5BD07490	CONN.ASM-CK2	1
5BD07500	CONN.CORD REG.	6
5BD07510	PWB CONT SUB	6
5BD07520	EPROM ASSEMBLY	6
5BD07530	PWB SENSOR A	6
5BD07540	CONN.CORD BIN 2	6
5BD07550	CONN.CORD BIN	6
5BD07560	PWB SENSOR B	6
5BD07570	COVER TOP ASSEMBLY	1
5BD07580	INDEXER ASSEMBLY	2
5BD07590	REEL FILM ASSEMBLY	2
5BD07600	DOOR ASSEMBLY	7
5BD07610	BKT SENSOR	3
5BD07620	SHEET SENSOR	2, 3, 6
5BD07630	LEVER SENSOR	3
5BD07640	SPRING LEVER	3
5BD07650	M4*7 ROUNDED END	2, 3, 6, 8
5BD07660	PLATE B STOPPER F	3
5BD07670	M4*9 ROUNDED END	3, 8
5BD07680	PLATE B STOPPER R	3

Part. No.	Description	Fig. No.
5BD07690	COVER SENSOR	2, 3
5BD07700	FILM SENSOR	3
5BD07710	FRAME FRONT	3
5BD07720	MAT CUSHION	3
5BD07730	PIN ROCK	3
5BD07740	ACTUATOR K	3
5BD07750	M4*5 ROUND END	3
5BD07760	RAIL INDEXER	3
5BD07770	GUIDE C RAIL	3
5BD07780	STOPPER DOOR	7
5BD07790	FRAME REAR	3
5BD07800	BKT PWB SENSOR	6
5BD07810	PLATE CONT.PWB	6
5BD07820	GUIDE B RAIL	3
5BD07830	BKT SENSOR COVER	6
5BD07840	ROLLER ENTRANCE	6
5BD07850	BUSHING 6	2, 6, 7
5BD07860	GUIDE PAPER ENTRANCE	2
5BD07870	CUSHION SENSOR	2
5BD07880	GUIDE PAPER ENTRANCE	2
5BD07890	SHAFT DRIVE LOWER	6
5BD07900	PULLEY S3M 18 A	6
5BD07910	PULLEY S3M 23	6
5BD07920	BELT S3M 430 60	6
5BD07930	BELT S3M 57 60	6
5BD07940	BELT S3M 442 60	6
5BD07950	SHAFT DRIVE INDEXER	6
5BD07960	PULLEY S3M 18 B	6
5BD07970	GEAR Z30	6
5BD07980	SHAFT REEL FILM	6
5BD07990	PULLEY REEL FILM	6
5BD08000	SPRING REEL FILM	6
5BD08010	ARBOR REEL FILM	6
5BD08020	FC PARALLEL PIN	6
5BD08030	SPRING REEL FILM R	6
5BD08040	REEL ADJUST ARBOR	6
5BD08050	SPRING REEL ADJUST	6
5BD08060	FILM PAPER GUIDE	2
5BD08070	GUIDE FILM 1	2
5BD08080	GUIDE FILM 2	2
5BD08090	SHAFT HANGER FILM	6
5BD08100	FLAPPER	2
5BD08110	GUIDE FLAPPER	2
5BD08120	BUSHING 4	2
5BD08130	SPRING FLAPPER	2
5BD08140	GUIDE PAPER EXIT	2
5BD08150	ROLLER EXIT	2
5BD08160	BKT SENSOR	2
5BD08170	HOLDER SENSOR	2
5BD08180	SPRING REEL SHAFT	6
5BD08190	PULLEY IDLER GEAR	6
5BD08200	MOTOR CONVEYING	6
5BD08210	PULLEY S2M 16	6
5BD08220	SHAFT DRIVE UPPER	6
5BD08230	GEAR Z23	6
5BD08240	CLIP 5	2, 6
5BD08250	HOLDER INDEXER	2
5BD08260	PLATE EARTH HOLDER 1	2
5BD08270	PLATE EARTH HOLDER 2	2
5BD08280	ROLLER INDEXER BELT	2
5BD08290	FRAME INDEXER LOWER	2
5BD08300	RIB FRONT INDEXER	2
5BD08310	RIB REAR INDEXER	2
5BD08320	ROLLER INDEXER	2
5BD08330	FRAME INDEXER UPPER	2
5BD08340	PLATE INDEXER	2
5BD08350	ROLLER INDEXER A	2
5BD08360	ROLLER INDEXER W	2

Part. No.	Description	Fig. No.
5BD08370	SPRING INDEXER A	2
5BD08380	GUIDE INDEXER I	2
5BD08390	PLATE EARTH INDEXER 1	2
5BD08400	PULLEY GEAR Z31	2
5BD08410	FLANGE PULLEY	2
5BD08420	GEAR Z20	2
5BD08430	BRUSH INDEXER LOWER	2
5BD08440	BRUSH INDEXER UPPER	2
5BD08450	PLATE EARTH INDEXER 2	2
5BD08460	PLATE ENCODER 4	6
5BD08470	BKT MOTOR REVERSE	6
5BD08480	FLANGE PULLEY	2
5BD08490	MOTOR INDEXER	6
5BD08500	BKT MOTOR INDEXER	6
5BD08510	GEAR WORM	6
5BD08520	COLLAR MOTOR	6
5BD08530	PLATE ENCODER 40	6
5BD08540	BKT SENSOR INDEXER	6
5BD08550	LEVER FLAPPER	6
5BD08560	SOLENOID NS38	6
5BD08570	SPRING SOLENOID	6
5BD08580	COVER DOOR	7
5BD08590	BKT INTERLOCK JAM	7
5BD08600	SUPPORT DOOR LOCK	7
5BD08610	BELT CONVEYING	7
5BD08620	SHAFT ROLLER IDLER	7
5BD08630	ROLLER IDLER	7
5BD08640	FRAME DOOR	7
5BD08650	ROLLER CONVEYING	7
5BD08660	LEVER JAM	7
5BD08670	SEAL LEVER JAM	7
5BD08680	SPRING LEVER JAM	7
5BD08690	LOCKER DOOR	7
5BD08700	PLATE STOPPER DOOR	7
5BD08710	COVER TOP	1
5BD08720	PLATE SPRING ROLLER	1
5BD08730	ROLLER TOP	1
5BD08740	SHAFT ROLLER TOP	1
5BD08750	LEVER SENSOR TOP	1
5BD08760	BRUSH EXIT	1
5BD08770	PLATE EARTH EXIT	1
5BD08780	SHAFT GUIDE 2	2
5BD08790	ROLLER GUIDE	2
5BD08800	GUIDE LOWER	2
5BD08810	SHAFT GUIDE	2
5BD08820	GUIDE CENTER	2
5BD08830	GUIDE UPPER	2
5BD08840	GUIDE A RAIL	3
5BD08850	SWITCHING REG	6
5BD08860	BKT CONN.INTER	6
5BD08870	BKT HEIGHT ADJUST	8
5BD08880	FRAME KC	8
5BD08890	REINFORCEMENT SIDE	8
5BD08900	PLATE	8
5BD08910	MAGNET CATCH	8
5BD08920	PLATE	8
5BD08930	ROLLER CASTER	8
5BD08940	SHAFT CASTER	8
5BD08950	BKT ADJUST CASTER	8
5BD08960	FRAME ADJUST	8
5BD08970	PLATE JOINT	8
5BD08980	RAIL	8
5BD08990	COVER CASTER	8
5BD09000	SCR4*10 WAVE	8
5BD09010	SCREW ADJUST	8
5BD09020	PLATE COVER L	8
5BD09030	PLATE COVER R	8
5BD09040	TRAY MAIL	4, 5

Part. No.	Description	Fig. No.
5BD09050	LEVER EMPTY	4, 5
5BD09060	LEVER FULL 1	4, 7
5BD09070	LEVER FULL 2	4, 7
5BD09080	COVER SENSOR	7
5BD09090	TRAY MULTI	7
5BD09100	COVER FRONT	1
5BD09110	COVER REAR	1
5BD09120	BKT JOINT	8
5BD09130	SENSOR GP1S74P	3, 6
5BD09140	WIRE CLAMP	2, 3, 6
5BD09150	SW INDEXER POSITION	6
5BD09160	SPACER KGLS-18S	6
5BD09170	SPACER KGLS-16S	6
5BD09180	SENSOR TLP1225	6
5BD09190	SENSOR TLP1241	2
5BD09200	CLAMP WIRE	1, 2, 6
5BD09210	WASHER T	6
5BD09220	BUSHING MF	6
5BD09230	BELT S2M 60	6
5BD09240	BEARING MF106ZZ	6
5BD09250	BUSHING 4	2
5BD09260	WIRE CLAMP	6
5BD09270	SPACER KGLS-6S	6
5BD09280	CUSHION GUIDE ROLLER	2
5BD09290	SPRING LEVER EMPTY	4, 5
5BD09300	ADDITIONAL MAIN TRAY	4, 5
5BD09310	BELT S2M 56-40	6
5BD09320	MOTOR REVERSE	6
5BD09330	BKT REAR COVER	6
5BD09340	BEARING LF1360ZZ	7
5BD09350	GUIDE TRAY MULTI	7
5BD09360	COVER CASTER	3
5BD09370	GEAR LIMIT	2, 6
5BD09380	GUIDE ROLLER UPPER	2
5BD09390	GUIDE ROLLER MIDDLE	2
5BD09400	GUIDE ROLLER LOWER	2
5BD09410	FRAME BASE	3
5BD09420	INDEXER MOTOR ASSY	6

MITA COPYSTAR AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Show Room:

149 West 51st street,
New York, NY 10019
TEL : (212) 554-2679
FAX : (212) 554-2625

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

225 Spring Lake Drive,
Itasca, Illinois 60143
TEL : (630) 250-7447
FAX : (630) 250-8787

Western Region:

14101 Alton Parkway,
P.O.Box 57006, Irvine,
California 92618-7006
TEL : (714) 457-9000
FAX : (714) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

MITA COPYSTAR CANADA, LTD.

6120 Kestrel Road,
Mississauga, Ontario L5T 1S8
TEL : (905) 670-4425
FAX : (905) 670-8116

MITA COPYSTAR MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Delegación Azcapotzalco
México, D.F. C.P. 02130
TEL : 3-83-27-41
FAX : 3-83-78-04

MITA COPYSTAR SOUTH AMERICA S.A.

Av. Mitre 1345 Florida (1602)
Pcia, Buenos Aires, Argentina.
TEL : (54) 1-730-1070
FAX : (54) 1-760-2071

©1998 MITA INDUSTRIAL CO., LTD.

MITA and **mita** are registered trademarks of MITA INDUSTRIAL CO., LTD.

Printed in U.S.A.