

mita[®]

ST-520/AD-34

PARTS LIST

Published in Jan.'00
5B770770

ST-520/AD-34

NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5B707010	FRONT COVER ASSY	ST-520	60Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	5B707530	BASE CASSETTE ASSY	•5B707230	BASE
			•5B707240	FOOT

- Parts with "••" are component parts or the sub-assembly with "•" appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	•5B807360	PASSAGE GUIDE ASSY	••5B808480	SENSOR
			••5B807500	CONN.CORD S00717

- The parts with "☉" only are available as spare parts.

Parts List

ST-520/AD-34

———— CONTENTS ————

FIG.1	EXTERIOR COVERS(ST-520)	2
FIG.2	FRAMES(ST-520)	4
FIG.3	CASSETTE(ST-520)	6
FIG.4	PAPER FEED-IN SECTION(ST-520)	8
FIG.5	EXTERIOR COVERS(AD-34)	10
FIG.6	FRAMES(AD-34)	12
FIG.7	DUPLEX SECTION(AD-34)	16
	• INDEX	20

FIG. 1 EXTERIOR COVERS(ST-520)

5B7/5B8




FIG. 1 EXTERIOR COVERS(ST-520)

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	01-001	5B707220	BASE UNIT	1
	01-002	5B707210	COVER TOP ASSY	1
	01-003	5B707160	COVER TOP REAR	1
	01-004	5B707300	SHEET COVER	1
	01-B10	B3304100	BIND TAPPING SCREW M4X10(BTYP.BLACK)	5
	01-B11	B3304100	BIND TAPPING SCREW M4X10(BTYP.BLACK)	2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "•••" are component parts or sub-assembly with "*" appearing immediately above them.

FIG. 2 FRAMES(ST-520)

5B7/5B8




FIG. 2 FRAMES(ST-520)

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
● ●	01-001	5B707530	BASE CASSETTE ASSY	1
	02-001	•5B707230	BASE	1
	02-002	•5B707240	FOOT	4
	02-003	•5B707250	PLATE EARTH CASSETTE	1
	02-004	•5B707590	COVER PANEL ASSY	1
	02-005	•5B707020	SWITCH ASSY	1
	02-008	•5B707030	COVER REAR	1
	02-009	•5B707260	SPRING COVER REAR	1
	02-010	•5B707270	GUIDE SLIDE	1
	02-011	•5B707180	NYLON CLAMP	1
	02-B10	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	02-B11	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	02-B12	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	2

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 3 CASSETTE(ST-520)

5B7/5B8




FIG. 3 CASSETTE(ST-520)

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	01-001	5B707530	BASE CASSETTE ASSY	1
	02-001	*5B707560	BASE CASSETTE	1
	02-003	*5B707410	FLAT WASHER	2
	02-004	*5B707420	SPRING LEVER LOCK	2
	02-005	*5B707430	SHEET GUIDE A	1
	02-006	*5B707510	SHEET GUIDE BN	1
	02-007	*5B707520	SHEET GUIDE CN	1
	02-008	*5B707440	PLATE SPRING EARTH	1
	02-009	*5B707450	KNOB SIZE SELECT	1
	02-010	*5B707500	SPRING CASSETTE N	1
	02-011	*5B707460	PLATE BOTTOM ASSY	1
●	02-012	*5B707470	PLATE SIDE L S/ASSY	1
●	02-013	*5B707480	PLATE SIDE SUB ASSY	1
●	02-014	*5B707060	BACK END SUB ASSY	1
	02-015	*5B707570	LEVER LOCK L	1
	02-016	*5B707580	LEVER LOCK R	1
	02-017	*5B707540	FLAP NAIL L	1
	02-018	*5B707550	FLAP NAIL R	1
	02-B10	*D0200200	PUSH NUT SPN-2	2
	02-B11	*B3313080	BINDING TAP-TITE SCREW M3X08	2
●	01-002	5B707010	COVER FRONT ASSY	1
	07-001	*5B707600	COVER FRONT	1
	07-002	*5B707490	SPRING TENSION	4
	07-003	*5B707120	ROLLER PINCH	2
	07-004	*5B707150	SHAFT ROLLER PINCH	2
	01-B10	B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "•••" are component parts or sub-assembly with "*" appearing immediately above them.

5B7/5B8



FIG. 4 PAPER FEED-IN SECTION(ST-520)

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
●	01-002	5B707210	COVER TOP ASSY	1
	04-001	•5B707040	COVER TOP N	1
	04-002	•5B707280	LEVER SENS PA-1	1
	04-003	•5B707290	SPRING LEVER SENS	1
	04-004	•5B707080	DRIVE UNIT	1
	04-005	•5B707050	BRACKET COVER TOP N	1
	04-006	•5B707320	SHAFT ROLL A ASSY	1
	04-007	•5B707330	BRACKET SENSOR FEED	1
	04-008	•5B707310	SENSOR	1
	04-009	•5B707070	ACTUATOR SENSOR N	1
	04-013	•5B707340	CONNECTER ASSY	1
	04-014	•5B707350	SHAFT ROLLER ASSY	1
	04-015	•5B707360	STOPPER	1
	04-016	•5B707370	ROLLER FEED ASSY	1
	04-017	•5B707380	COVER FRONT L	1
	04-018	•5B707390	COVER FRONT R	1
	04-019	•5B707090	ROLL PICK UP ASSY	1
	04-020	•5B707400	PLATE EARTH	1
	04-021	•5B707100	PWB MAIN	1
	04-022	•5B707140	CONN CORD S00702	1
	04-023	•5B707190	SNAP BAND	1
●	04-B10	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	04-B11	•B3023060	BINDING TAP TIGHT SCREW M3X6	2
	04-B12	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	2
	04-B19	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	04-B20	•B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	04-B22	•B3023060	BINDING TAP TIGHT SCREW M3X6	1
	06-005	•5B707110	MOTOR ASSY	1
	08-002	•5B807020	CLUTCH FEED DRIVE	1
	12-001	•5B707130	ROLLER FEED	1
	12-B10	•E0020120	SPRING PIN 2X12	2
●	12-B11	•D1000400	STOP RING (E-4)	3

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 5 EXTERIOR COVERS(AD-34)

5B7/5B8




FIG. 5 EXTERIOR COVERS(AD-34)

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	02-001	5B807560	COVER TOP F	1
	02-002	5B808100	PLATE TOP	1
	02-006	5B808580	CONN. CORD S00766	1
	02-B02	B4104060	TRIPLE SCREW M4X6(CHROMIUM)	2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "••" are component parts or sub-assembly with "*" appearing immediately above them.

FIG. 6 FRAMES(AD-34)

5B7/5B8




FIG. 6 FRAMES(AD-34)

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
●	03-001	5B807080	BASE SUB ASSY	1
	04-001	*5B807550	BASE	1
●	04-002	*5B807230	FOOT	4
	04-003	*5B808350	SHEET RAIL	2
●	03-002	5B807090	COVER REAR	1
	03-003	5B808310	SPRING R COVER	1
	03-004	5B807650	LEVER LOCK	2
	03-005	5B808320	SPRING LOCK DS	2
●	03-006	5B807100	LED ASSY	1
	03-B01	*B3023060	BINDING TAP TIGHT SCREW M3X6	1
	05-001	*5B808710	LED COVER ASSY	1
	05-002	*5B808720	PWB LED	1
	05-B01	*B3313080	BINDING TAP-TITE SCREW M3X08	1
	03-007	5B807540	CONN.CORD S00751	1
	03-008	5B807490	CONN.CORD S00716	1
	03-009	5B808030	BRACKET DB CONNECT	1
	03-010	5B807520	CONN.CORD S00719	1
	03-011	5B808380	STAD CONNECTOR	2
●	03-012	5B807110	PASSAGE ASSY	1
	06-001	*5B807580	BASE PASSAGE	1
	06-002	*5B807370	FRAME L ASSY	1
	06-003	*5B807360	PASSAGE GUIDE ASSY	1
	22-003	**5B808480	SENSOR	1
	22-004	**5B807500	CONN.CORD S00717	1
	22-B01	**B3313080	BINDING TAP-TITE SCREW M3X08	1
	06-004	*5B808070	FRAME R	1
	06-005	*5B808020	GUIDE PASSAGE A	1
	06-006	*5B807860	GATE DB	1
	06-007	*5B808490	BUSHING 4	1
	06-008	*5B807870	LEVER GATE B	1
	06-010	*5B808080	LINK GATE	1
	06-012	*5B808330	SPRING GATE A	1
	06-B01	*B3034120	TAPPING SCREW M4X12 (B-TYP)	3
	06-B02	*B3023060	BINDING TAP TIGHT SCREW M3X6	4
	03-013	5B808040	PLATE EARTH	1
●	03-014	5B807120	DRIVE ASSY	1
●	03-014	5B808690	DRIVE ASSY	1
	07-001	*5B807380	DRIVE SUB ASSY A	1
	07-002	*5B807390	DRIVE SUB ASSY B	1
	07-003	*5B808650	SPRING JOINT R	1

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	07-004	*5B808340	SPRING JOINT C	1
	07-005	*5B808120	SHAFT CLT	1
	07-006	*5B807630	GEAR CLT Z18	1
	07-007	*5B807620	GEAR CLT Z24	1
	07-008	*5B808510	BUSHING 6	2
	07-009	*5B807610	GEAR Z24	1
	07-010	*5B807420	TENSION ASSY	1
	07-012	*5B808190	BELT T158	1
	07-013	*5B808110	SHAFT B	1
	07-014	*5B807760	PULLEY T20	1
	07-015	*5B807880	FLANGE	1
	07-017	*5B807600	GEAR H44	1
	07-018	*5B807290	GEAR FEED Z16	1
	07-020	*5B807590	GEAR H16-T56	1
	07-021	*5B808410	BEARING 6	1
	07-022	*5B808420	BUSHING SLEEVE	1
	07-023	*5B807240	PULLEY ENCODER P16	1
	07-024	*5B808180	BELT T95	1
	07-025	*5B807260	SENSOR	1
	07-026	*5B807250	BRACKET ENCODER	1
	07-027	*5B808050	PEASE EARTH	1
	07-030	*5B807510	CONN.CORD S00718	1
	07-031	*5B807170	EDGING SADDLE	1
	07-032	*5B807190	MINI CLAMP	4
	07-034	*5B808360	RUBBER	5
	07-035	*5B808630	RACK DS	1
	07-B01	*B0023060	ROUND HEAD SCREW WITH SW.W M3X6	3
	07-B02	*D1000500	STOP RING (E-5)	2
	07-B03	*E5020100	PIN 2X10 (M6 TYP)	1
	07-B04	*D1000500	STOP RING (E-5)	2
	07-B05	*E5020100	PIN 2X10 (M6 TYP)	1
	07-B06	*D1000500	STOP RING (E-5)	1
	07-B07	*E5020100	PIN 2X10 (M6 TYP)	1
	07-B12	*B3023060	BINDING TAP TIGHT SCREW M3X6	1
	07-B13	*B3023060	BINDING TAP TIGHT SCREW M3X6	1
●	23-002	*5B808460	MOTOR MAIN	1
	03-015	5B808430	TAPPING SCREW	4
	03-016	5B808440	STAD FRAME	1
●	03-017	5B807460	P.W.BOARD ASSY REAR SW	1
●	03-018	5B807130	P.W.BOARD ASSY MAIN	1

- Parts with "*" are component parts or sub-assembly with "*" appearing immediately above them.

FIG. 6 FRAMES(AD-34)

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
●	03-018	5B807140	PWB MAIN	1
	03-019	5B808660	SCREW CONNECTOR	2
	03-020	5B808740	IC. UPD75004CU 3	1
	03-021	5B807200	CLAMP	1
	03-B01	B3023060	BINDING TAP TIGHT SCREW M3X6	1

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

- Parts with "•••" are component parts or sub-assembly with "*" appearing immediately above them.

FIG. 7 DUPLEX SECTION(AD-34)

5B7/5B8




FIG. 7 DUPLEX SECTION(AD-34)

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
●	01-001	5B807440	BASE STACKER ASSY	1
	08-001	*5B807850	BASE STACKER	1
	08-002	*5B808370	FILM SENSOR	1
	08-003	*5B808550	FILM STACKER	1
	01-002	5B807220	STACKER ASSY	1
	01-003	5B808700	TOP COVER ASSY	1
	01-004	5B807570	COVER TOP R	1
	01-005	5B807530	CONN.CORD S00750	1
	01-006	5B807430	SENSOR ASSY	1
	01-007	5B807330	EPS ASSY	1
	10-001	*5B807930	BRACKET EPS	1
	10-002	*5B807260	SENSOR	3
	10-003	*5B807680	LEVER EPS	1
	10-004	*5B808130	SHAFT EPS	1
	10-B01	*D1000200	STOP RING (E-2)	1
●	01-008	5B807010	ADJUST ASSY	1
	01-B05	*B3313080	BINDING TAP-TITE SCREW M3X08	4
	11-001	*5B807800	BASE ADJUST	1
	11-002	*5B807400	ADJUSTER-L ASSY	1
	11-003	*5B807410	ADJUSTER-R ASSY	1
	11-004	*5B807740	RACK ADJUSTER	2
	11-005	*5B807710	PINION ADJUSTER	1
	11-006	*5B807660	GEAR Z18-67	1
	11-007	*5B807690	GEAR Z48	1
	11-008	*5B808390	FASTNER 4	1
	11-009	*5B808470	MOTOR ADJUSTER	1
	11-010	*5B807320	HPS ASSY	1
	11-011	*5B808570	TAPE EARTH	1
	11-B01	*B3313080	BINDING TAP-TITE SCREW M3X08	2
	11-B02	*B0003060	ROUND HEAD SCREW M3X6	1
	11-B03	*B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	01-009	5B807450	GUIDE ENT ASSY	1
	12-001	*5B807980	GUIDE ENT A	1
	12-002	*5B808450	SHEET ENT	1
	01-010	5B808220	GATE ENT	1
	01-011	5B808490	BUSHING 4	1
	01-012	5B807350	DS SENSOR ASSY	1
	01-013	*5B808290	SPRING GATE B	1
	13-001	*5B807940	BRACKET DS SENSOR	1
	13-002	*5B807480	P.W.B. DS SENSOR	1

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	01-014	5B807210	SNAP BAND	1
	01-015	5B808250	ROLLER C	1
	01-016	5B808530	BUSH DS	2
	01-017	5B807720	GEAR Z16	1
	01-018	5B807780	GUIDE FRONT	1
	01-019	5B808000	GUIDE ENT B	1
	01-020	5B808230	ROLLER A	1
	01-022	5B808600	GEAR CLT Z16	1
	01-023	5B807760	PULLEY T20	1
	01-024	5B808240	ROLLER B	1
	01-026	5B807880	FLANGE	1
●	01-028	5B807020	CLUTCH FEED DRIVE	1
	01-029	5B807670	GEAR Z28-T20	1
●	01-030	5B807030	GUIDE COVER B	1
●	01-031	5B807040	GUIDE COVER ASSY	1
	14-001	*5B807790	GUIDE COVER T	1
	14-002	*5B808160	SHAFT PINCH	1
	14-003	*5B807810	ROLLER PINCH	2
	14-004	*5B807960	SPRING PINCH F	1
	14-005	*5B807180	LABEL CAUTION	1
	14-B01	*D1000300	STOP RING (E-3)	2
	01-032	5B807990	GUIDE PLATE B	1
●	01-033	5B807050	GUIDE PLATE ASSY	1
	01-B26	*B3313080	BINDING TAP-TITE SCREW M3X08	2
	15-001	*5B808010	GUIDE PLATE A	1
	15-002	*5B808160	SHAFT PINCH	1
	15-003	*5B807810	ROLLER PINCH	2
	15-004	*5B807950	SPRING PINCH R	1
	15-005	*5B808560	FILM PG5	2
	15-B01	*D1000300	STOP RING (E-3)	2
	01-034	5B808060	SPRING EARTH	1
●	01-035	5B807060	PU ROLLER ASSY	1
	01-B28	*E5020100	PIN 2X10 (M6 TYP)	1
	16-001	*5B807750	FRAME PU	1
	16-002	*5B808140	PIN PU	1
	16-003	*5B808200	ROLLER PU	2
	16-004	*5B808280	BELT T59	1
	16-005	*5B808150	SHAFT PU	1
	16-006	*5B808680	SPRING CLUTCH	1
	16-007	*5B808670	BUSHING CLUTCH	1

- Parts with "*" are component parts or sub-assembly with "*" appearing immediately above them.

5B7/5B8



FIG. 7 DUPLEX SECTION(AD-34)

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
●	16-008	*5B808200	ROLLER PU	1
	16-B01	*E5020100	PIN 2X10 (M6 TYP)	1
	16-B02	*D1000500	STOP RING (E-5)	2
	16-B03	*E5120080	SPRING PIN H7A 2X8 SUS	1
	16-B04	*D1000500	STOP RING (E-5)	3
	01-037	5B807640	GEAR Z20	1
	01-038	5B807340	JOINT C ASSY	1
	01-B30	*D1000500	STOP RING (E-5)	1
	17-001	*5B807970	BRACKET JOINT C	1
	17-002	*5B807720	GEAR Z16	1
	17-003	*5B807700	COLLOR B	1
	17-B01	*D1000500	STOP RING (E-5)	1
	01-040	5B808300	SPRING JOINT C	1
	01-041	5B808260	BELT T106	1
	01-042	5B808270	BELT T113	1
	01-043	5B807840	COVER CLT	1
	01-044	5B807070	FRONT COVER ASSY	1
	01-B32	*B3313080	BINDING TAP-TITE SCREW M3X08	4
	18-001	*5B808730	COVER FRONT	1
	18-002	*5B807300	SPRING TENSION	2
	18-003	*5B807830	ROLLER EXIT	2
	18-004	*5B807310	SHAFT ROLLER PINCH	2
	01-045	5B807910	COVER HARNESS	1
	01-046	5B808090	BRACKET ADJUSTER	1
	01-047	5B808400	SCREW ADJUSTER	1
	01-048	5B808610	SHEET PROTECTOR	1
	01-049	5B808590	PLATE ROLLER EARTH	1
	01-050	5B808640	BUSHING 6	3
	01-051	5B808620	KNOB DS	1
	01-052	5B807880	FLANGE	1
	01-B01	B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	1
	01-B02	B3023100	BINDING TAP TIGHT SCREW M3X10	2
	01-B03	B3303060	BIND TAPPING SCREW M3X6(B TYPE)	1
	01-B04	B3313080	BINDING TAP-TITE SCREW M3X08	2
	01-B05	B3313080	BINDING TAP-TITE SCREW M3X08	4
	01-B07	B3313080	BINDING TAP-TITE SCREW M3X08	3
	01-B08	B0003080	ROUND HEAD SCREW M3X8	1
	01-B09	E5020100	PIN 2X10 (M6 TYP)	1
	01-B10	D1000500	STOP RING (E-5)	2
	01-B11	B3313080	BINDING TAP-TITE SCREW M3X08	2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- The parts with "●" only are available as spare parts.

5B7/5B8

SP	Ref. No.	Part. No.	Description	Quantity USA(120V)
	01-B12	B0003060	ROUND HEAD SCREW M3X6	2
	01-B13	B1603100	BINDING SCREW M3X10 (BRASS,NI)	2
	01-B14	B3313080	BINDING TAP-TITE SCREW M3X08	1
	01-B16	D1000500	STOP RING (E-5)	2
	01-B17	E5020100	PIN 2X10 (M6 TYP)	1
	01-B18	D1000500	STOP RING (E-5)	2
	01-B21	D1000500	STOP RING (E-5)	2
	01-B22	E5020100	PIN 2X10 (M6 TYP)	1
	01-B25	B3304100	BIND TAPPING SCREW M4X10(BTYP.BLACK)	1
	01-B26	B3313080	BINDING TAP-TITE SCREW M3X08	2
	01-B27	B3313080	BINDING TAP-TITE SCREW M3X08	3
	01-B28	E5020100	PIN 2X10 (M6 TYP)	1
	01-B29	D1000500	STOP RING (E-5)	2
	01-B30	D1000500	STOP RING (E-5)	1
	01-B31	B3313080	BINDING TAP-TITE SCREW M3X08	3
	01-B32	B3304100	BIND TAPPING SCREW M4X10(BTYP.BLACK)	4
	01-B33	B3313080	BINDING TAP-TITE SCREW M3X08	2

- Parts with "*" are component parts or sub-assembly with "*" appearing immediately above them.

INDEX

5B7/5B8

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
●	5B707010	COVER FRONT ASSY	1	3
●	5B707020	SWITCH ASSY	1	2
●	5B707030	COVER REAR	1	2
	5B707040	COVER TOP N	1	4
	5B707050	BRACKET COVER TOP N	1	4
●	5B707060	BACK END SUB ASSY	1	3
	5B707070	ACTUATOR SENSOR N	1	4
●	5B707080	DRIVE UNIT	1	4
●	5B707090	ROLL PICK UP ASSY	1	4
●	5B707100	PWB MAIN	1	4
●	5B707110	MOTOR ASSY	1	4
	5B707120	ROLLER PINCH	2	3
●	5B707130	ROLLER FEED	1	4
	5B707140	CONN CORD S00702	1	4
	5B707150	SHAFT ROLLER PINCH	2	3
	5B707160	COVER TOP REAR	1	1
	5B707180	NYLON CLAMP	1	2
	5B707190	SNAP BAND	1	4
	5B707210	COVER TOP ASSY	2	1,4
	5B707220	BASE UNIT	1	1
	5B707230	BASE	1	2
	5B707240	FOOT	4	2
	5B707250	PLATE EARTH CASSETTE	1	2
	5B707260	SPRING COVER REAR	1	2
	5B707270	GUIDE SLIDE	1	2
	5B707280	LEVER SENS PA-1	1	4
	5B707290	SPRING LEVER SENS	1	4
	5B707300	SHEET COVER	1	1
	5B707310	SENSOR	1	4
	5B707320	SHAFT ROLL A ASSY	1	4
	5B707330	BRACKET SENSOR FEED	1	4
	5B707340	CONNECTER ASSY	1	4
	5B707350	SHAFT ROLLER ASSY	1	4
	5B707360	STOPPER	1	4
	5B707370	ROLLER FEED ASSY	1	4
	5B707380	COVER FRONT L	1	4
	5B707390	COVER FRONT R	1	4
	5B707400	PLATE EARTH	1	4
	5B707410	FLAT WASHER	2	3
	5B707420	SPRING LEVER LOCK	2	3

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
	5B707430	SHEET GUIDE A	1	3
	5B707440	PLATE SPRING EARTH	1	3
	5B707450	KNOB SIZE SELECT	1	3
	5B707460	PLATE BOTTOM ASSY	1	3
●	5B707470	PLATE SIDE L S/ASSY	1	3
●	5B707480	PLATE SIDE SUB ASSY	1	3
	5B707490	SPRING TENSION	4	3
	5B707500	SPRING CASSETTE N	1	3
	5B707510	SHEET GUIDE BN	1	3
	5B707520	SHEET GUIDE CN	1	3
	5B707530	BASE CASSETTE ASSY	1	2
	5B707530	BASE CASSETTE ASSY	1	3
	5B707540	FLAP NAIL L	1	3
	5B707550	FLAP NAIL R	1	3
	5B707560	BASE CASSETTE	1	3
	5B707570	LEVER LOCK L	1	3
	5B707580	LEVER LOCK R	1	3
	5B707590	COVER PANEL ASSY	1	2
	5B707600	COVER FRONT	1	3
●	5B807010	ADJUST ASSY	1	7
●	5B807020	CLUTCH FEED DRIVE	2	4,7
●	5B807030	GUIDE COVER B	1	7
●	5B807040	GUIDE COVER ASSY	1	7
●	5B807050	GUIDE PLATE ASSY	1	7
●	5B807060	PU ROLLER ASSY	1	7
●	5B807070	FRONT COVER ASSY	1	7
●	5B807080	BASE SUB ASSY	1	6
●	5B807090	COVER REAR	1	6
●	5B807100	LED ASSY	1	6
●	5B807110	PASSAGE ASSY	1	6
●	5B807120	DRIVE ASSY	1	6
●	5B807130	P.W.BOARD ASSY MAIN	1	6
●	5B807140	PWB MAIN	1	6
	5B807170	EDGING SADDLE	1	6
	5B807180	LABEL CAUTION	1	7
	5B807190	MINI CLAMP	4	6
	5B807200	CLAMP	1	6
	5B807210	SNAP BAND	1	7
	5B807220	STACKER ASSY	1	7
	5B807230	FOOT	4	6

• The parts with "●" only are available as spare parts.

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
	5B807240	PULLEY ENCODER P16	1	6
	5B807250	BRACKET ENCODER	1	6
	5B807260	SENSOR	4	6,7
	5B807290	GEAR FEED Z16	1	6
	5B807300	SPRING TENSION	2	7
	5B807310	SHAFT ROLLER PINCH	2	7
	5B807320	HPS ASSY	1	7
	5B807330	EPS ASSY	1	7
	5B807340	JOINT C ASSY	1	7
	5B807350	DS SENSOR ASSY	1	7
	5B807360	PASSAGE GUIDE ASSY	1	6
	5B807370	FRAME L ASSY	1	6
	5B807380	DRIVE SUB ASSY A	1	6
	5B807390	DRIVE SUB ASSY B	1	6
	5B807400	ADJUSTER-L ASSY	1	7
	5B807410	ADJUSTER-R ASSY	1	7
	5B807420	TENSION ASSY	1	6
	5B807430	SENSOR ASSY	1	7
	5B807440	BASE STACKER ASSY	1	7
	5B807450	GUIDE ENT ASSY	1	7
	5B807460	P.W.BOARD ASSY REAR SW	1	6
	5B807480	P.W.B. DS SENSOR	1	7
	5B807490	CONN.CORD S00716	1	6
	5B807500	CONN.CORD S00717	1	6
	5B807510	CONN.CORD S00718	1	6
	5B807520	CONN.CORD S00719	1	6
	5B807530	CONN.CORD S00750	1	7
	5B807540	CONN.CORD S00751	1	6
	5B807550	BASE	1	6
	5B807560	COVER TOP F	1	5
	5B807570	COVER TOP R	1	7
	5B807580	BASE PASSAGE	1	6
	5B807590	GEAR H16-T56	1	6
	5B807600	GEAR H44	1	6
	5B807610	GEAR Z24	1	6
	5B807620	GEAR CLT Z24	1	6
	5B807630	GEAR CLT Z18	1	6
	5B807640	GEAR Z20	1	7
	5B807650	LEVER LOCK	2	6
	5B807660	GEAR Z18-67	1	7

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
	5B807670	GEAR Z28-T20	1	7
	5B807680	LEVER EPS	1	7
	5B807690	GEAR Z48	1	7
	5B807700	COLLOR B	1	7
	5B807710	PINION ADJUSTER	1	7
	5B807720	GEAR Z16	2	7
	5B807740	RACK ADJUSTER	2	7
	5B807750	FRAME PU	1	7
	5B807760	PULLEY T20	2	6,7
	5B807780	GUIDE FRONT	1	7
	5B807790	GUIDE COVER T	1	7
	5B807800	BASE ADJUST	1	7
	5B807810	ROLLER PINCH	4	7
	5B807830	ROLLER EXIT	2	7
	5B807840	COVER CLT	1	7
	5B807850	BASE STACKER	1	7
	5B807860	GATE DB	1	6
	5B807870	LEVER GATE B	1	6
	5B807880	FLANGE	3	6,7
	5B807910	COVER HARNESS	1	7
	5B807930	BRACKET EPS	1	7
	5B807940	BRACKET DS SENSOR	1	7
	5B807950	SPRING PINCH R	1	7
	5B807960	SPRING PINCH F	1	7
	5B807970	BRACKET JOINT C	1	7
	5B807980	GUIDE ENT A	1	7
	5B807990	GUIDE PLATE B	1	7
	5B808000	GUIDE ENT B	1	7
	5B808010	GUIDE PLATE A	1	7
	5B808020	GUIDE PASSAGE A	1	6
	5B808030	BRACKET DB CONNECT	1	6
	5B808040	PLATE EARTH	1	6
	5B808050	PEASE EARTH	1	6
	5B808060	SPRING EARTH	1	7
	5B808070	FRAME R	1	6
	5B808080	LINK GATE	1	6
	5B808090	BRACKET ADJUSTER	1	7
	5B808100	PLATE TOP	1	5
	5B808110	SHAFT B	1	6
	5B808120	SHAFT CLT	1	6

• The parts with "●" only are available as spare parts.

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
	5B808130	SHAFT EPS	1	7
	5B808140	PIN PU	1	7
	5B808150	SHAFT PU	1	7
	5B808160	SHAFT PINCH	2	7
	5B808180	BELT T95	1	6
	5B808190	BELT T158	1	6
	5B808200	ROLLER PU	3	7
	5B808220	GATE ENT	1	7
	5B808230	ROLLER A	1	7
	5B808240	ROLLER B	1	7
	5B808250	ROLLER C	1	7
	5B808260	BELT T106	1	7
	5B808270	BELT T113	1	7
	5B808280	BELT T59	1	7
	5B808290	SPRING GATE B	1	7
	5B808300	SPRING JOINT C	1	7
	5B808310	SPRING R COVER	1	6
	5B808320	SPRING LOCK DS	2	6
	5B808330	SPRING GATE A	1	6
	5B808340	SPRING JOINT C	1	6
	5B808350	SHEET RAIL	2	6
	5B808360	RUBBER	5	6
	5B808370	FILM SENSOR	1	7
	5B808380	STAD CONNECTOR	2	6
	5B808390	FASTNER 4	1	7
	5B808400	SCREW ADJUSTER	1	7
	5B808410	BEARING 6	1	6
	5B808420	BUSHING SLEEVE	1	6
	5B808430	TAPPING SCREW	4	6
	5B808440	STAD FRAME	1	6
	5B808450	SHEET ENT	1	7
	5B808460	MOTOR MAIN	1	6
	5B808470	MOTOR ADJUSTER	1	7
	5B808480	SENSOR	1	6
	5B808490	BUSHING 4	2	6,7
	5B808510	BUSHING 6	2	6
	5B808530	BUSH DS	2	7
	5B808550	FILM STACKER	1	7
	5B808560	FILM PG5	2	7
	5B808570	TAPE EARTH	1	7

SP	Part. No.	Description	Quantity USA (120V)	Fig. No.
	5B808580	CONN. CORD S00766	1	5
	5B808590	PLATE ROLLER EARTH	1	7
	5B808600	GEAR CLT Z16	1	7
	5B808610	SHEET PROTECTOR	1	7
	5B808620	KNOB DS	1	7
	5B808630	RACK DS	1	6
	5B808640	BUSHING 6	3	7
	5B808650	SPRING JOINT R	1	6
	5B808660	SCREW CONNECTOR	2	6
	5B808670	BUSHING CLUTCH	1	7
	5B808680	SPRING CLUTCH	1	7
	5B808690	DRIVE ASSY	1	6
	5B808700	TOP COVER ASSY	1	7
	5B808710	LED COVER ASSY	1	6
	5B808720	PWB LED	1	6
	5B808730	COVER FRONT	1	7
	5B808740	IC. UPD75004CU 3	1	6
	B0003060	ROUND HEAD SCREW M3X6	3	7
	B0003080	ROUND HEAD SCREW M3X8	1	7
	B0023060	ROUND HEAD SCREW WITH SW.W M3X6	3	6
	B1603100	BINDING SCREW M3X10 (BRASS,NI)	2	7
	B3023060	BINDING TAP TIGHT SCREW M3X6	11	4,6
	B3023100	BINDING TAP TIGHT SCREW M3X10	2	7
	B3034120	TAPPING SCREW M4X12 (B-TYP)	3	6
	B3303060	BIND TAPPING SCREW M3X6(B TYP)	1	7
	B3304100	BIND TAPPING SCREW M4X10(BTYP.BLACK)	12	1,7
	B3313080	BINDING TAP-TITE SCREW M3X08	37	3,6,7
	B4104060	TRIPLE SCREW M4X6(CHROMIUM)	2	5
	B4364080	TRIPLE SCREW (BLACK) M4X8,B-TYP.	13	2,3,4,7
	D0200200	PUSH NUT SPN-2	2	3
	D1000200	STOP RING (E-2)	1	7
	D1000300	STOP RING (E-3)	4	7
	D1000400	STOP RING (E-4)	3	4
	D1000500	STOP RING (E-5)	23	6,7
	E0020120	SPRING PIN 2X12	2	4
	E5020100	PIN 2X10 (M6 TYP)	9	6,7
	E5120080	SPRING PIN H7A 2X8 SUS	1	7

• The parts with "●" only are available as spare parts.

MITA COPYSTAR AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Show Room:

149 West 51st street,
New York, NY 10019
TEL : (212) 554-2679
FAX : (212) 554-2625

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

225 Spring Lake Drive,
Itasca, Illinois 60143
TEL : (630) 250-7447
FAX : (630) 250-8787

Western Region:

14101 Alton Parkway,
P.O.Box 57006,Irvine,
California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

MITA COPYSTAR CANADA, LTD.

6120 Kestrel Road,
Mississauga, Ontario L5T 1S8
TEL : (905) 670-4425
FAX : (905) 670-8116

MITA COPYSTER SOUTH AMERICA S.A.

Av. Mitre 1345 Florida (1602)
Pcia, Buenos Aires,Argentina
TEL : (54) 11-4730-1070
FAX : (54) 11-4760-2071

MITA COPYSTAR MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Delegación Azcapotzalco
México, D.F. C.P. 02130
TEL : 3-83-27-41
FAX : 3-83-78-04

© 1999 MITA INDUSTRIAL CO., LTD.

MITA and *mita* are registered trademarks of MITA INDUSTRIAL CO., LTD.

Printed in U.S.A.