



UF-100

PARTS LIST

Published in Sept.'98
5A270850

UF-100

NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5A213690	FRAME SUB ASSY	UF-100	60Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts without "*" are produced only upon order.

Parts List

UF-100

———— CONTENTS ————

FIG.1	UNIVERSAL FEEDER	2
-------	------------------------	---

FIG. 1 UNIVERSAL FEEDER

5A2




FIG. 1 UNIVERSAL FEEDER

Ref. No.	Part. No.	Description
1	82220093	UF-100
2	5A213690	FRAME SUB ASS'Y
3	5A213070	HOOK
4	5A213700	BOTTOM RELEASE
5	5A213330	GEAR Z12
6	5A213340	GEAR Z23-Z63
7	5A213350	GEAR Z27-Z58
8	5A213360	GEAR Z26A
9	5A213370	GEAR Z26B
10	5A213380	GEAR Z18
11	5A213390	GEAR Z19
12	5A213400	BUSHING A
13	5A213410	BUSHING B
14	5A213420	SPRING B
15	5A213430	SPRING CLUTCH
16	*5A213250	ROLLER ASS'Y A
17	*5A213260	ROLLER ASS'Y B
18	5A213440	PAD MOTOR
19	*5A213270	DC MOTOR ASS'Y
20	*5A213110	SENSOR ASS'Y A
21	*5A213120	PWB MAIN
22	5A213710	LEVER SENSOR
23	5A213720	PLATE EARTH A
24	5A213730	PLATE EARTH B
25	5A213740	PLATE CENTER
26	5A213750	GUIDE PLATE L
27	5A213760	GUIDE PLATE R
28	5A213770	RACK
29	5A213520	GEAR Z19
30	5A213580	ARM
31	5A213590	SHAFT WEIGHT
32	5A213620	PAN HEAD SCREW
33	5A213180	HOLDER WEIGHT
34	5A213540	SHAFT LATCH
35	5A213780	SPRING PAD
36	*5A213190	SENSOR ASS'Y B
37	5A213790	CHANNEL CENTER
38	5A213800	COVER TOP
39	5A213810	COVER UNDER
	5A213820	COVER LEFT

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

5A2

Ref. No.	Part. No.	Description
40	5A213830	COVER RIGHT
41	5A213840	TRAY STACKER
42	5A213850	STACKER WIRE
43	5A213680	HOLDER CONNECTOR
44	*5A213240	PWB CONNECTOR ASS'Y
45	5A213860	SIZE LABEL R
46	5A213870	SIZE LABEL L
47	5A213770	RACK
48	5A213880	GUIDE CAP
49	5A213890	COVER SPRING
50	5A213900	SPRING
51	5A213290	PAN HEAD SCREW
52	5A213470	TP TAP SCREW
53	5A213300	TP TAP SCREW
54	5A213490	E STOP RING
55	5A213490	E STOP RING
56	5A213480	BIND TAP SCREW
57	*5A213280	SEPARATER ASS'Y

• Parts without "*" are produced only upon order.

Part. No.	Description	Quantity USA (120V)	Fig. No.
5A213070	HOOK	1	1
5A213110	SENSOR ASS'Y A	1	1
5A213120	PWB MAIN	1	1
5A213180	HOLDER WEIGHT	1	1
5A213190	SENSOR ASS'Y B	1	1
5A213240	PWB CONNECTOR ASS'Y	1	1
5A213250	ROLLER ASS'Y A	1	1
5A213260	ROLLER ASS'Y B	1	1
5A213270	DC MOTOR ASS'Y	1	1
5A213280	SEPARATOR ASS'Y	1	1
5A213290	PAN HEAD SCREW	1	1
5A213300	TP TAP SCREW	1	1
5A213330	GEAR Z12	1	1
5A213340	GEAR Z23-Z63	1	1
5A213350	GEAR Z27-Z58	1	1
5A213360	GEAR Z26A	1	1
5A213370	GEAR Z26B	1	1
5A213380	GEAR Z18	1	1
5A213390	GEAR Z19	1	1
5A213400	BUSHING A	1	1
5A213410	BUSHING B	1	1
5A213420	SPRING B	1	1
5A213430	SPRING CLUTCH	1	1
5A213440	PAD MOTOR	1	1
5A213470	TP TAP SCREW	1	1
5A213480	BIND TAP SCREW	1	1
5A213490	E STOP RING	2	1
5A213520	GEAR Z19	1	1
5A213540	SHAFT LATCH	1	1
5A213580	ARM	1	1
5A213590	SHAFT WEIGHT	1	1
5A213620	PAN HEAD SCREW	1	1
5A213680	HOLDER CONNECTOR	1	1
5A213690	FRAME SUB ASS'Y	1	1
5A213700	BUTTON RELEASE	1	1
5A213710	LEVER SENSOR	1	1
5A213720	PLATE EARTH A	1	1
5A213730	PLATE EARTH B	1	1
5A213740	PLATE CENTER	1	1
5A213750	GUIDE PLATE L	1	1

Part. No.	Description	Quantity USA (120V)	Fig. No.
5A213760	GUIDE PLATE R	1	1
5A213770	RACK	2	1
5A213780	SPRING PAD	1	1
5A213790	CHANNEL CENTER	1	1
5A213800	COVER TOP	1	1
5A213810	COVER UNDER	1	1
5A213820	COVER LEFT	1	1
5A213830	COVER RIGHT	1	1
5A213840	TRAY STACKER	1	1
5A213850	STACKER WIRE	1	1
5A213860	SIZE LABEL R	1	1
5A213870	SIZE LABEL L	1	1
5A213880	GUIDE CAP	1	1
5A213890	COVER SPRING	1	1
5A213900	SPRING	1	1
82220093	UF-100	1	1

MITA COPYSTAR AMERICA, INC.

Headquarters:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Show Room:

149 West 51st street,
New York, NY 10019
TEL : (212) 554-2679
FAX : (212) 554-2625

Northeastern Region:

225 Sand Road, P.O. Box 40008
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

225 Spring Lake Drive,
Itasca, Illinois 60143
TEL : (630) 250-7447
FAX : (630) 250-8787

Western Region:

14101 Alton Parkway,
P.O.Box 57006,Irvine,
California 92618-7006
TEL : (714) 457-9000
FAX : (714) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 570-4704

Dallas Parts Distribution Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

MITA COPYSTAR CANADA, LTD.

6120 Kestrel Road,
Mississauga, Ontario L5T 1S8
TEL : (905) 670-4425
FAX : (905) 670-8116

MITA COPYSTAR MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Delegación Azcapotzalco
México, D.F. C.P. 02130
TEL : 3-83-27-41
FAX : 3-83-78-04

MITA COPYSTER SOUTH AMERICA S.A.

Av. Mitre 1345 Florida (1602)
Pcia, Buenos Aires,Argentina
TEL : (54) 1-730-1070
FAX : (54) 1-760-2071

© 1998 MITA INDUSTRIAL CO., LTD.

MITA and *mita* are registered trademarks of MITA INDUSTRIAL CO., LTD.

Printed in U.S.A.