



Safety Information

OPERATOR SAFETY

The probe is intended to be used only with instruments that are connected to earth ground through the input BNC connector. When you are using it with the ADPPS Power Supply Adapter, make sure that the adapter is connected to a BNC connector that is grounded by the test instrument before you connect the probe inputs to the test circuit.

Do not use in wet or explosive atmospheres. Remove any contamination from the probe housing before you connect the probe inputs to any circuit. Make sure that the surface of the probe head is completely dry before connecting the inputs.

Use of the probe and/or the instrument it is connected to in a manner other than that specified may impair the protection mechanisms.

Do not use the probe if any part is damaged. All maintenance should be referred to qualified service personnel.

#



BLANK PAGE