

# Table of Contents

## Overview



Description .....	1-1
Key features .....	1-1
Conventions Used in this Manual .....	1-1
Accessories .....	1-2



## Safety Information

Operator safety .....	2-1
-----------------------	-----

## Operation

Precautions .....	3-1
Connecting the Probe to the Test Instrument .....	3-1
Connecting the Probe to the Test Circuit .....	3-1
Operation with a LeCroy Oscilloscope .....	3-2
Auto Zero .....	3-2
Degauss Probe .....	3-3



## Care and Maintenance

Cleaning .....	4-1
Calibration Interval .....	4-1
Service Strategy .....	4-1
Troubleshooting .....	4-1
Returning a Defective Probe .....	4-1

## Performance Verification

Test Equipment Required .....	5-1
Preliminary Procedure .....	5-2
Functional Check .....	5-2
Performance verification Procedure .....	5-2
Check DC Accuracy .....	5-3

## Adjustment Procedure



Test Equipment Required .....	6-1
Adjustment Procedure .....	6-2
Preliminary Procedure .....	6-2
Adjust DC Accuracy. ....	6-2

## Specifications

**CP150 Current Probe**

---

Nominal Characteristics .....	7-1
Warranted Characteristics .....	7-1
Typical characteristics .....	7-1
Environmental Characteristics .....	7-2
Physical Characteristics .....	7-2
Compliances and Certifications .....	7-2

**Appendix A**

Performance Verification Test Record .....	A-1
CP150 Test Record .....	A-2