
Table of Contents

Safety Information	1-1
OPERATOR SAFETY	1-1
CONVENTIONS USED IN THIS MANUAL	1-2
 Overview	 2-1
DESCRIPTION	2-1
MODEL DESCRIPTION	2-2
RACK MOUNT VERSIONS	2-2
POWER CABLE OPTION	2-2
STANDARD ACCESSORIES	2-3
OPTIONAL ACCESSORIES	2-3
 Operation	 3-1
GENERAL INFORMATION	3-1
DYNAMIC RANGE	3-1
FRONT PANEL	3-2
Input Connectors	3-2
Attenuators	3-2
Gain	3-2
Output Termination	3-2
Input Resistance	3-3
Auto Zero	3-3
+ Input Coupling (AC – OFF – DC)	3-3
–Input Coupling (AC–OFF – DC – VCOMP)	3-4
Precision Voltage Generator	3-6
Differential Offset	3-7
Effective Gain	3-8
BW Limit	3-8
Overload	3-9
REAR PANEL	3-9
Power	3-9
Power up indication	3-10
Precision Voltage Generator Offset Voltage	3-10
Amplifier Output	3-12
Remote Operation	3-12
Probe Coding Input	3-13
INSTRUMENT SETTINGS	3-13
Retained Settings	3-13

DA1855A Differential Amplifier

Sensitivity, Position and Offset	3-14
Gain Control Modes	3-15
Probes and Differential Amplifiers	3-17
The DXC100A Differential Probe Pair	3-18
Probe Grounding	3-18
 General Operating Information	4-1
GETTING STARTED	4-1
POWER CONNECTION	4-1
COMPARATOR MODE	4-1
DIFFERENTIAL MODE	4-2
SETTING UP THE OSCILLOSCOPE WITH PROBUS INTERFACE	4-2
ATTENUATOR AND GAIN OPERATION	4-4
COMPARISON VOLTAGE OPERATION (VCOMP)	4-5
DIFFERENTIAL OFFSET OPERATION (VDIFF)	4-6
SETTING UP THE OSCILLOSCOPE WITHOUT PROBUS INTERFACE	4-9
ATTENUATOR AND GAIN OPERATION	4-10
COMPARISON VOLTAGE OPERATION (VCOMP)	4-11
DIFFERENTIAL OFFSET OPERATION (VDIFF)	4-13
DETERMINING THE PROPER OFFSET MODE	4-15
AVOIDING COMMON PROBLEMS	4-16
Exceeding the Common Mode Range	4-16
Using the Oscilloscope POSITION control	4-17
Using scale factors greater than 100 mV/Div	4-17
Failure to Terminate the Amplifier into 50 W	4-18
POOR OVERDRIVE RECOVERY	4-18
 Care and Maintenance	5-1
CLEANING	5-1
CALIBRATION INTERVAL	5-1
SERVICE STRATEGY	5-1
TROUBLESHOOTING	5-1
RETURNING AN AMPLIFIER	5-1
RETURNING AN AMPLIFIER TO A DIFFERENT COUNTRY	5-2
 Applications	6-1
INTRODUCTION	6-1
VOLTAGE MEASUREMENTS	6-1
MEASURING CURRENT	6-1
SETUP AND CONFIGURING FOR POWER DEVICES ANALYSIS	6-2
EFFECTS OF PROBES ON SATURATION VOLTAGE MEASUREMENTS	6-3

SATURATION VOLTAGE MEASUREMENT	6-6
GATE DRIVE VOLTAGE	6-7
UPPER AND LOWER GATE DRIVE	6-9
AVOIDING MEASUREMENT ERRORS	6-11
Reference Information	7-1
DIFFERENTIAL MODE AND COMMON MODE	7-1
DIFFERENTIAL MODE RANGE AND COMMON MODE RANGE	7-1
COMMON MODE REJECTION RATIO	7-1
Remote Control Commands	8-1
INTRODUCTION	8-1
COMMAND LIST	8-1
GAIN CONTROL MODE	8-2
ATTENUATION	8-3
AUTO ZERO	8-4
BANDWIDTH LIMIT	8-5
COUPLING	8-6
GAIN	8-7
OFFSET	8-8
INPUT RESISTANCE	8-9
PROBE ATTENUATION	8-10
PRECISION VOLTAGE GENERATOR	8-11
VOLT/DIV	8-12
Performance Verification	9-1
INTRODUCTION	9-1
TEST EQUIPMENT REQUIRED	9-1
PRELIMINARY PROCEDURE	9-3
FUNCTIONAL CHECK	9-4
FUNCTIONAL CHECK PROCEDURE	9-5
1. ProBus operation.	9-5
2. Coupling.	9-5
3. Bandwidth Limiting.	9-5
4. X10 Gain and μ 10 Attenuator	9-5
VERIFICATION PROCEDURE	9-6
1. Check X1 Gain Accuracy	9-6
2. Check X10 Gain Accuracy	9-7
3. Check μ 10 Attenuator Accuracy	9-11
4. Check X1 Bandwidth and Calculate Rise Time	9-13
5. Check High Frequency CMRR	9-15

DA1855A Differential Amplifier

6. Check Low Frequency CMRR.	9-19
7. Check the Precision Voltage Generator Accuracy	9-23
Specifications	10-1
NOMINAL CHARACTERISTICS	10-1
General	10-1
Dynamic Ranges	10-2
Precision Voltage Generator	10-3
Power Requirements	10-3
WARRANTED CHARACTERISTICS	10-3
TYPICAL CHARACTERISTICS	10-4
ENVIRONMENTAL CHARACTERISTICS	10-5
PHYSICAL CHARACTERISTICS	10-5
COMPLIANCES AND CERTIFICATIONS	10-6
CE Declaration of Conformity	10-6
Appendix A	A-1
PERFORMANCE VERIFICATION TEST RECORD	A-1