

TABLE OF CONTENTS

INTRODUCTION	1
PART ONE: ABOUT REMOTE CONTROL.....	3
CHAPTER ONE: OVERVIEW.....	4
Operate Your WaveMaster by Remote Control	5
STANDARDS	5
PROGRAM MESSAGES.....	5
COMMANDS AND QUERIES	7
HEADERS.....	8
HEADER PATHS	8
DATA	9
CHARACTER DATA	9
NUMERIC DATA	9
STRING DATA	10
BLOCK DATA	10
RESPONSE MESSAGES	10
CHAPTER TWO: CONTROL BY GPIB.....	12
Talk, Listen or Control.....	13
INTERFACE	14
ADDRESS.....	14
GPIB SIGNALS	15
I/O BUFFERS	16
USE IEEE 488.1 STANDARD MESSAGES	16
DEVICE CLEAR.....	17
GROUP EXECUTE TRIGGER.....	17
REMOTE ENABLE	17
INTERFACE CLEAR.....	17
CONFIGURE THE GPIB-DRIVER SOFTWARE	17
MAKE SIMPLE TRANSFERS	19
USE ADDITIONAL DRIVER CALLS	21
MAKE SERVICE REQUESTS	22
Take Instrument Polls.....	23
DO CONTINUOUS POLLING	23
TAKE A SERIAL POLL	24
DO A PARALLEL POLL.....	24
PERFORM AN *IST POLL	26

TABLE OF CONTENTS

Timing and Synchronization	27
STATUS REGISTERS	28
SYNCHRONIZING WITH *OPC? AND WAIT	29
CHAPTER THREE: CONTROL BY LAN.....	32
Introduction	33
IMPLEMENTATION STANDARD	33
CONNECTIONS	33
Connecting the Instrument to its Host	34
SCOPE REAR PANEL	34
ETHERNET CONNECTION	34
HEADERS FOR LAN DATA TRANSFERS	35
MANUAL SETTING OF LAN ADDRESS.....	37
MAKING PHYSICAL CONNECTION	39
NETWORK CONNECTION	40
Introduction to Software Tools.....	41
Using ActiveDSO.....	42
CONTROL INSTANTIATION.....	42
CHAPTER FOUR: UNDERSTAND AND MANAGE WAVEFORMS.....	50
Know Your Waveform.....	51
LOGICAL DATA BLOCKS	51
INSPECT WAVEFORM CONTENTS	52
USE THE WAVEFORM QUERY	54
INTERPRET VERTICAL DATA	57
CALCULATE A DATA POINT'S HORIZONTAL POSITION	58
USE THE WAVEFORM COMMAND.....	60
Transfer Waveforms at High Speed.....	61
CHAPTER FIVE: CHECK WAVEFORM STATUS.....	62
Use Status Registers.....	63
OVERVIEW.....	63
STATUS BYTE REGISTER (STB).....	65
STANDARD EVENT STATUS REGISTER (ESR).....	65
STANDARD EVENT STATUS ENABLE REGISTER (ESE)	66
SERVICE REQUEST ENABLE REGISTER (SRE).....	66
PARALLEL POLL ENABLE REGISTER (PRE).....	66
INTERNAL STATE CHANGE STATUS REGISTER (INR)	66
INTERNAL STATE CHANGE ENABLE REGISTER (INE)	67
COMMAND ERROR STATUS REGISTER (CMR)	67
DEVICE DEPENDENT ERROR STATUS REGISTER (DDR)	67
EXECUTION ERROR STATUS REGISTER (EXR).....	67
USER REQUEST STATUS REGISTER (URR)	67

TABLE OF CONTENTS

CHAPTER SIX: <i>LINKING WITH AUTOMATION</i>.....	69
What is Automation?	69
OVERVIEW	69
SOME DETAILS	69
HOW TO USE THE VBS COMMAND.....	71
HOW TO USE X-STREAM BROWSER.....	72
ACTIONS	75
 PART TWO: COMMANDS	 77
Use Commands and Queries	79
COMMAND NOTATION	79
Table of Commands and Queries – By Short Form	81
Table of Commands and Queries – By Subsystem	84
 APPENDIX I, <i>PROGRAMMING EXAMPLES</i>.....	 237
Introduction to Instrument Software Tools.....	237
EXECUTABLE PROGRAMS	237
Source Code Example GPIB-1.....	238
USE THE INTERACTIVE GPIB PROGRAM “IBIC”	238
Source Code Example GPIB-2.....	239
USE THE GPIB PROGRAM FOR IBM PC (HIGH-LEVEL FUNCTION CALLS)	239
Source Code Example GPIB-3.....	241
USE THE GPIB PROGRAM FOR IBM PC (LOW-LEVELFUNCTION CALLS)	241
Source Code Example: ActiveDSO – 1 and 2	244
Source Code Example: ActiveDSO – 3 and 4	246
Source Code Example: ActiveDSO – 5	250
Translation Example	250
Introduction to ActiveDSO	251
Using ActiveDSO	252
Instantiation	252
Example Using PowerPoint 97	253
Example in VBA	257
 APPENDIX II, <i>WAVEFORM TEMPLATE</i>.....	 259
Waveform Template.....	259
WAVEDESC: Block.....	261
Decoding Floating Point Numbers.....	271
How to Construct a Floating Point Number from Four Bytes.....	276

BLANK PAGE