
SETUP INSTRUCTIONS

CT-2/CD-2M

Copy Table/Copy Desk

for Product Code 4004



WARNING

- *Be sure to attach the stabilizers; otherwise, the unit may become unbalanced and fall over, causing injuries.*
- *Before setting up this unit, be sure to unplug the power cord of the copier.*




CAUTION

- *Keep all packing materials out of the reach of children.*

■ Unpacking the Copy Table


If there are a total of four copier drawers and optional paper feed units, first install the copy table, and then install the optional paper feed units.

- (1) Copy table 1
- (2) Stabilizers A 2
- (3) Stabilizer B 1
- (4) Stabilizers screws 3
- (5) Adjusters 2
- (6) Fixing plates 4
- (7) Fixing plate screws 4
- (8) Grounding plates (inside) 2
- (9) Grounding plate (right-front) 1
- (10) Grounding plate screws 3
- (11) Setup Instructions (this manual) 1



■ Unpacking the Copy Desk

- (1) Copy desk 1
- (2) Stabilizers A 2
- (3) Stabilizer B 1
- (4) Stabilizers screws 3
- (5) Adjusters 2
- (6) Fixing plates 4
- (7) Fixing plate screws 4
- (8) Grounding plates (inside) 2
- (9) Grounding plate (right-front) 1
- (10) Grounding plate screws 3
- (11) Setup Instructions (this manual) 1



C4619U051AA

Copy Table/Copy Desk

■ Installing the Copy Table/Copy Desk

NOTE


If the copier stand is used, do not install the adjusters and Stabilizers A and B; only install the grounding plates.

- Using one screw for each stabilizers, attach the two stabilizers A and stabilizer B to the copy table or copy desk at the positions shown in the illustration below.



NOTE

△ Be sure to attach the stabilizers; otherwise, the unit may become unbalanced and fall over, causing injuries.


- Attach the two adjusters to the copy table or copy desk at the positions shown in the illustration at the left.



- Attach the three grounding plates (two inside and one at the right-front corner) to the copy table/copy desk at the positions shown in the illustrations at the left (using a grounding plate screw for each plate).




■ Adjusting the Adjusters



With the wrench (1031-7809-01), adjust the height of the adjusters (front and back) to stabilize the unit on the floor.

The wrench is not enclosed.




⚠ CAUTION

Be sure to set the adjusters as specified. Failure to set the adjusters correctly may cause the unit to become unbalanced and fall, possibly resulting in serious injuries.

Copy Table/Copy Desk


■ Attaching the paper feed unit to the copy table



C4619U057AA

1. Place the paper feed unit on top of the copy table so that the rubber feet on the paper feed unit are correctly aligned on the copy table.

2. Using the four enclosed fixing plates and fixing plate screws, secure the paper feed unit to the copy table as shown.




C4619U058AA

This completes the setup of the copy table.

For instructions on making connections to the copier, refer to "Connecting the Optional Paper Feed Unit to the Copier" in the Setup Instructions for the paper feed unit.


■ Attaching the paper feed unit to the copy desk

1. Place the paper feed unit on top of the copy desk so that the rubber feet on the paper feed unit are correctly aligned on the copy desk.



C4619U058AB

2. Using the four enclosed fixing plates and fixing plate screws, secure the paper feed unit to the copy desk as shown.



C4619U056AA


Copy Table/Copy Desk

■ If the Copy Desk or Copy Table Is To Be Used Together With the Copier Stand

NOTE


Make sure that supports A and B are not installed. If supports A and B are installed, remove them.

1. Position the scanner (attached to the copier stand) over the printer engine (attached to the copy table or copy desk).
(The illustration shows the copy desk used with the copier stand.)




C4004U091AA

2. Turn the adjusters on the copier stand (one on each leg) until the four holes in the copier stand align with the holes in the lower unit (copy table or copy desk).



C4004U092AA

3. Attach the lower unit (copy table or copy desk) to the copier stand using the four screws supplied with the copier stand. Do not tighten the screws.




C4004U147AA

Copy Table/Copy Desk

NOTE


If the copy table is installed, insert the two spacers (supplied with the copier stand) as shown.

* If the copy desk is installed, the spacers are not needed.



C4004U148AA

5. Install the five decorative covers supplied with the copier stand.



C4004U093AA

4. Firmly tighten the four screws installed in step 3.