

\*\*\*\*\* **CAL. 5R21/5R32 SLIM MOV'T PART LIST** \*\*\*\*\*

ORIGINAL PARTS, MADE IN JAPAN

| <u>PART NAME</u>                        | <u>5R21</u> | <u>5R32</u> |
|-----------------------------------------|-------------|-------------|
| BATTERY                                 | 280-750     | 280-750     |
| BATTERY CONNECTOR                       | 231-182     | 231-182     |
| BATTERY STRAP                           | 234-7215    | 234-7992    |
| BRAKE LEVER                             | -           | 269-330     |
| CANNON PINION WITH DRIVING WHEEL        | -           | 028-225     |
| CENTER WHEEL & PINION W/T CANNON PINION | 012-193     | -           |
| CLUTCH WHEEL                            | 064-900     | 064-900     |
| CLUTCH WHEEL GUARD                      | 212-175     | 212-175     |
| COIL UNIT                               | 246-137     | 246-135     |
| CIRCUIT INSULATOR                       | 233-412     | 233-412     |
| DIAL WASHER                             | 078-190     | 078-210     |
| ELECTRONIC CIRCUIT UNIT                 | 279-G25     | 279-751     |
| FIFTH WHEEL AND PINION                  | -           | 084-540     |
| FOURTH WHEEL AND PINION                 | -           | 023-273     |
| HOURLY WHEEL                            | 075-345     | 075-401     |
| MINUTE WHEEL AND PINION                 | 072-103     | 072-103     |
| ROTOR                                   | 285-111     | 285-106     |
| SCREW FOR ELECTRIC CIRCUIT (X1)         | 929-530     | 929-530     |
| SCREW FOR TRAIN WHEEL BRIDGE (X1)       | 922-166     | 922-166     |
| SETTING LEVER                           | 067-181     | 067-181     |
| SETTING STEM                            | 065-413     | 065-413     |
| SETTING WHEEL                           | 076-670     | 076-670     |
| STATOR                                  | 190-105     | 190-101     |
| THIRD WHEEL AND PINION                  | 017-131     | 017-129     |
| TRAIN WHEEL BRIDGE                      | 701-776     | 701-765     |
| YOKE                                    | 071-124     | 071-124     |
|                                         |             |             |
| ( LONGER SETTING STEM(15.32MM) )        | 065-427     | 065-427     |
| LONGER SETTING STEM(18.82MM)            | 065-462     | 065-462     |

# CAL. 5R SERIES

|  | 5R32      | 5R21                     | PARTS NAME                                            |
|--|-----------|--------------------------|-------------------------------------------------------|
|  | 929-530   | ←                        | SCREW                                                 |
|  | 234-799   | 234-721<br>( -965) ※1    | POWERCELL STRAP                                       |
|  | 279-751   | 279-G25                  | ELECTRONIC CIRCUIT                                    |
|  | 280-750   | ←                        | POWERCELL                                             |
|  | 233-412   | ←                        | INSULATOR                                             |
|  | 231-182   | ←                        | POWERCELL CONNECTOR                                   |
|  | 922-166   | ←                        | SCREW                                                 |
|  | 701-765   | 701-776                  | TRAIN WHEEL BRIDGE                                    |
|  | 023-273   | —                        | 4TH WHEEL                                             |
|  | 017-129   | 017-131                  | 3RD WHEEL                                             |
|  | 084-540   | —                        | 5TH WHEEL                                             |
|  | ① 028-225 | ② 012-193<br>( -203) ※1  | ① CANNON PINION W/<br>DRIVING WHEEL<br>② CENTER WHEEL |
|  | 076-670   | ←                        | SETTING WHEEL                                         |
|  | 246-135   | 246-137                  | COIL UNIT                                             |
|  | 269-330   | —                        | BRAKE LEVER                                           |
|  | 212-175   | ←                        | SPACER                                                |
|  | 071-124   | ←                        | YOKE                                                  |
|  | 067-181   | ←                        | SETTING LEVER                                         |
|  | 072-103   | ←                        | MINUTE WHEEL                                          |
|  | 190-101   | 190-105                  | STATOR                                                |
|  | 064-900   | ←                        | CLUTCH WHEEL                                          |
|  | 065-413   | 065-413 ※2<br>065-427 ※3 | SETTING STEM                                          |
|  | 075-401   | 075-345<br>( -372) ※1    | HOURL WHEEL                                           |
|  | 078-210   | 078-190                  | WHEELWASHER                                           |
|  | 285-106   | 285-111                  | ROTOR                                                 |

※1: ( ) is for cal. 5R22 (high hand version)

※2: 12.320 mm

※3: 15.320 mm