

***** **CAL. 6T33 MOV'T PARTS LIST** *****

ORIGINAL PARTS, MADE IN JAPAN

<u>PART NAME</u>	<u>6T33</u>	<u>6T33 GILT</u>
BALANCE BRIDGE	710-207	710-206
BALANCE WITH HAIRSPRING REGULATED	039-690	039-690
BARREL AND TRAIN WHEEL BRIDGE	701-H17	701-H14
BARREL COMPLETE	001-994	001-990
CANNON PINION	014-132	014-132
CAP JEWELLED SPRING	933-050	933-050
CENTER SECONDS PINION	025-920	025-920
CENTER WHEEL & PINION	012-207	012-207
CENTER WHEEL COCK	711-159	711-239
CLICK	060-490	060-480
CLICK SPRING	902-250	902-250
CLUTCH WHEEL	064-210	064-210
FRICTION SPRING FOR SWEEP SEC PINION	903-360	903-360
DIAL WASHER	078-040	078-040
ESCAPE WHEEL AND PINION	032-840	032-840
FORTH WHEEL AND PINION	023-700	023-700
HOUR WHEEL	075-378	075-378
HOUR WHEEL SPRING	176-A05	176-950
JEWELLED PALLET FORK AND STAFF	035-420	035-420
LOWER CAP JEWEL MOUNTED	094-240	094-240
MINUTE TRAIN COVER	079-250	079-860
MINUTE WHEEL AND PINION	072-340	072-340
PALLET BRIDGE	708-054	708-078
RATCHET WHEEL	059-440	059-660
SCREW FOR BALANCE BRIDGE	922-172	922-172
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE(×3)	922-172	922-172
SCREW FOR CENTER WHEEL COCK (×2)	922-172	922-172
SCREW FOR CLICK	921-320	921-320
SCREW FOR HOUR WHEEL SPRING(×2)	929-550	929-550
SCREW FOR MINUTE TRAIN COVER	929-550	929-550
SCREW FOR PALLET BRIDGE	922-173	922-173
SCREW FOR SETTING LEVER SPRING(×2)	929-550	929-550
SCREW FOR STUD	927-020	927-020
SETTING LEVER	067-997	067-179
SETTING LEVER SPRING	077-390	077-118
SETTING STEM	065-117	065-117
SETTING WHEEL	076-270	076-270
SPIRAL SPRING WITH JEWEL(× 2)	098-040	098-040
THIRD WHEEL AND PINION	017-520	017-520
UPPER CAP JEWEL MOUNTED	094-240	094-240
WINDING PINION	063-200	063-200
YOKE	071-122	071-994
YOKE SPRING	902-260	902-260
** LONGER SETTING STEM **	065-489	065-489